IMPORTANT! READ ALL THE SAFETY INFORMATION BEFORE INSTALLING THE HARDWARE

Getting Started and Product Document of Compliance for the Cisco IR807 Integrated Services Router

- Cisco Information, page 2
- Introduction, page 2
- Items Shipped with your Router, page 2
- Equipment that you supply, page 2
- Related Documentation, page 3
- Installation Warning and Caution Statements, page 3
- Grounding the Router, page 5
- Connecting DC Power, page 6
- Connecting to the Router Ports, page 9
- Connecting to the USB Port, page 9
- EMC Information, page 10
- Declaration of Conformity with Regard to the EU Directive 2014/53/EU, page 14

Cisco Information

Table 1

Cisco Company Name and Address Details

Company Name	Cisco Address
Cisco Systems, Inc.	170 West Tasman Drive, San Jose, CA 95134-1706, United States.

Introduction

The purpose of this document is to provide the installer the necessary information for installing the Cisco IR807 Industrial Integrated Services Router (IR807). The documentation is on-line, and subject to change. Make sure that you are downloading or viewing on-line the latest version before beginning an installation.

This document also contains Product Compliance and Safety information as well as Declaration of Conformity.

Items Shipped with your Router

Unpack the box and verify that all items listed on the invoice were shipped with the Cisco IR807.

The following items are shipped with your router:

- · This document Part Number 78-
- · Grounding Lug Kit
- Mounting Screws
- · Power Connector

Equipment that you supply

- ESD-preventive cord and wrist strap.
- · Wire-stripping tools for stripping 14- and 18-gauge wires
- · Crimping tool
- Ratcheting torque screwdriver that exerts up to 15 in-lb (1.69 N-m) of pressure.

Related Documentation

To access resources or to display the latest Cisco IR800 Series Router documentation on-line, go to this URL:

https://www.cisco.com/c/en/us/support/routers/800-series-industrial-routers/tsd-products-support-serie s-home.html

This portal has all of the information you need to get to know your router, install and configure it, as well as access software. Look at the right side of the page under **Support**. You will see the following categories as well as other important information:

- All support information for Cisco IR800 Series Routers: Provides the most requested resources and a list of all of the models in the series.
- Software Downloads, Release and General Information: Links to the Software Download site, Compatibility Information, Licensing Information, and Product Release notes.
- Install and Upgrade: This is your starting point for Installing the Router. look under The Install and Upgrade Guide section for this model,
- **Configure:** These links provide configuration information. Look first under the Configuration Guide section for this model.

Other important and helpful links to Cisco information are here:

- Cisco.com: www.cisco.com
- · Warranty Information: www.cisco-warrantyfinder.com
- Cisco Information Packet, consisting of Cisco Limited Warranty, Disclaimer of Warranty, End User License Agreement, and United States Federal Communications Commission Notice: www.cisco.com/en/US/docs/general/warranty/English/SL3DEN__.html
- · Cisco Marketplace: www.cisco.com/pcgi-bin/marketplace/welcome.pl
- · Cisco Product Documentation: www.cisco.com/go/techdocs
- Regulatory Compliance and Safety Information: https://www.cisco.com/c/en/us/td/docs/routers/access/800/829/regulatory/IR800rcsi.html
- · Cisco Support: www.cisco.com/cisco/web/support/index.html

Installation Warning and Caution Statements



IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071



In order to comply with FCC radio frequency (RF) exposure limits, antennas for this product should be located a minimum of 7.9 in. (20 cm) or more from the body of all persons. Statement 332



Read the installation instructions before connecting the system to the power source. Statement 1004



This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security. Statement 1017

<u>A</u> Warning

g This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection

absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available. Statement 1024



Only trained and qualified personnel should be allowed to install, replace, or service this equipment. Statement 1030



Ultimate disposal of this product should be handled according to all national laws and regulations. Statement 1040



To prevent the system from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of:

140°F (60°C) Statement 1047



Use twisted-pair supply wires suitable for 86°F (30°C) above surrounding ambient temperature outside the enclosure. Statement 1067



Installation of the equipment must comply with local and national electric codes. Statement 1074



Avoid using or servicing any equipment that has outdoor connections during an electrical storm. There may be a risk of electric shock from lightning. Statement 1088

Caution

The equipment shall only be used in an area of not more than pollution degree 2, as defined in IEC/EN 60664-1.

The equipment shall be installed in **a certified ATEX** enclosure that provides a degree of protection not less than IP 54 in accordance with IEC 60079-15.

Caution

Airflow around the Router must be unrestricted. The dimensions (height x width x depth) are $1.15 \times 5.05 \times 6.27$ in. (19.6 x 27.9 x 4.39 cm). To prevent the Router from overheating, there must be a minimum of 1.0 in. (25.4 mm) around all surfaces of the Router.

Contact your Cisco Technical Assistance Centre (TAC) if tighter spacings are required.



This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D, or only nonhazardous locations.



This product is suitable for use in environmental air space in accordance with section 300.22.C of the National Electrical Code and sections 2-128, 12-010(3), and 12-100 of the Canadian Electrical Code, Part 1, C22.1. You should not install the power supply or power injector in air handling spaces.



Marked DC Input ratings: 12-48Vdc, 0.5-1.5A.



The maximum ambient (Tamb) operating temperature range is -40 to 140°F (-40 to 60°C).

Grounding the Router

Make sure to follow any grounding requirements at your site.

Warning

This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available. Statement 1024

Warning

This equipment is intended to be grounded to comply with emission and immunity requirements. Ensure that the equipment functional ground lug is connected to earth ground during normal use. Statement 1064

Caution

To make sure that the equipment is reliably connected to earth ground, follow the grounding procedure instructions, and use 14-to-16 AWG (1.6mm -to- 1.3mm) wire.

Caution

Use at least a 2.3mm conductor to connect to the external grounding screw.

The router must be connected to a reliable earth ground. Install the ground wire in accordance with local electrical safety standards.


- For NEC-compliant grounding, use size 14 AWG (1.6mm) or larger copper wire and a ring terminal with an inner diameter of 1/4 in. (5 to 7 mm).
- For EN/IEC 60950-compliant grounding, use size 18 AWG (1.02mm) or larger copper wire.

Note

Depending on the kit shipped with your router, the grounding lug may have one hole or two holes.

Step 1	Locate the ring terminal lug in the packaging kit. Store the ground screw for later use.
Step 2	Use a wire stripping tool to strip the 14-16 AWG (1.6mm -to- 1.3mm) grounding wire to 0.22 in. (5.56 mm).

Step 3 Insert the ground wire into the ring terminal lug, and using a crimping tool, crimp the terminal to the wire.



Step 4 Slide the ground screw through the ground lug.

- **Step 5** Insert the ground screws (1) into the grounding lug (2) shown in the graphic and attach the lug to the router.
 - Note

If your grounding lug is a single hole type, attach it in the same manner as the dual hole using the first hole from the front panel.



- Step 6 Use a ratcheting torque screwdriver to tighten the ground screw and ring terminal to the router side panel to 3.5 in-lb (0.4 N-m). The torque should not exceed 3.5 in-lb (0.4 N-m).
- Step 7 Attach the other end of the ground wire(#1 in the graphic above) to a grounded bare metal surface, such as a ground bus, a grounded DIN rail, or a grounded bare rack.

Connecting DC Power

A Warning

When you connect or disconnect the power and/or alarm connector with power applied, an electrical arc can occur. This could cause an explosion in hazardous area installations. Be sure that all power is removed from the equipment and any other circuits. Be sure that power cannot be accidentally turned on or verify that the area is nonhazardous before proceeding. Statement 1058



Explosion Hazard—The area must be known to be nonhazardous before installing, servicing, or replacing the unit. Statement 1082



Explosion Hazard—Substitution of components may impair suitability for Class I, Division 2/Zone 2. Statement 1083



Connect the unit only to DC power source that complies with the safety extra-low voltage (SELV) requirements in IEC 60950 based safety standards. Statement 1033



Maximum DC input operating range is 9.6-60Vdc, 0.5-1.5A

Plugs and Pin-Outs

The following is a brief overview of connecting to DC power. Details can be found in the Cisco IR807 Integrated Services Router Hardware Installation Guide and should be understood before beginning. See Related Documentation, page 3.

The IR807 ships with a DC power accessory kit that contains a 4-pin screw on connector.

The power entry receptacle is on the IR807. The power connector plug is shown in Figure 1. The Power Receptacle is shown in Figure 2

Descriptions are shown in Figure 3.

Figure 1 Power Connector Plug



Figure 2

Power Receptacle




Figure 3 Power connector Descriptions

Pin Number	Name	Description	Color
1	DC In +	DC Power In (BAT+)	Red
2	DC In -	DC Power Return (GND-)	Black
3	AC	Alarm Common	N/A
4	AI	Alarm Input	N/A

To connect DC power:

Step 1		the power and alarm connector on the router front panel. The pins ir function are found in Figure 3. Your connector may not have the labels V RT A A appear on it. The pins are 1-4 from left to right.	
	V—Po RT— I A— A	abeled connector, the pins are: sitive DC power connection Return DC power connection larm Common	3915C
Step 2	• 1- • 2- • 3-	y the connector positive and return DC power connections. The con –Positive DC power connection –Return DC power connection –Alarm Common –Alarm Input	nections are:
Step 3		re two strands of twisted-pair copper wire 18-to-20 AWG (1.02 -to- wer source. The maximum length of the cable before twisting is 15 feet (4.6 m	
Step 4	wires c ± 0.02 insulat	an 18-gauge wire-stripping tool, strip each of the two twisted pair soming from each DC-input power source to 0.25 inch (6.3 mm) inch (0.5 mm). Do not strip more than 0.27 inch (6.8 mm) of ion from the wire. Stripping more than the recommended amount c an leave exposed wire from the power connector after tion.	333064
Step 5	Remov	e the two captive screws that attach the power and alarm connector	to the router, and remove the connector.
Step 6	wire in wire in	power and alarm connector, insert the exposed part of the positive to the connection labeled "V" and the exposed part of the return to the connection labeled "RT". Make sure that you cannot see any ad. Only wire with insulation should extend from the connector.	
			I—Power connector captive screws

Step 7	Use a ratcheting torque flathead screwdriver to torque the power connector captive screws (above the installed wire leads) to 2 in-lb (0.23 N-m).
Step 8	Connect the other end of the positive wire to the positive terminal on the DC power source, and connect the other
	end of the return wire to the return terminal on the DC power source.
	Connect the other end of the Alarm wires to your alarm source.

Connecting to the Router Ports

For hazardous location environments, follow these warnings when connecting to the destination ports (Fast Ethernet, and console ports).

A Warning

If you connect or disconnect the console cable with power applied to the equipment or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding. Statement 1080



Do not connect or disconnect cables to the ports while power is applied to the equipment or any device on the network because an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed from the equipment and cannot be accidentally be turned on, or verify that the area is nonhazardous before proceeding. Statement 1070

Connecting to the USB Port

6 Note

If you are connecting to the USB port:

- a connection (to the USB port) can only be made in a non-hazardous environment

- the USB port cover must be reinstalled before the router can be deployed in a hazardous environment

Hazardous Locations Standards and Marking Strings

 The following standards were used for the hazardous locations approvals and certifications:

 ISA 12.12.01-15

 CSA CAN/CSA-C22.2 NO. 60079-0:15

 CSA CAN/CSA-C22.2 NO. 60079-15:16

 CSA C22.2 No. 213-16

 EN 60079-0:2012 + A11:2013

 EN 60079-0 6th Edition

 IEC 60079-0 6th Edition

 UL 60079-0, 6th Edition

 UL 60079-1, 5, 4th Edition

Class 1, Div 2, Groups A B C D	
Class I, Zone 2, AEx nA IIC T4 Gc X	
CE II 3G, Ex nA IIC T4 Gc	
DEMKO 17 ATEX ???	
Class 1, Zone 2, Ex nA IIC T4 Gc X	

EMC Information

For EMC and safety information, see the Regulatory Compliance and Safety Information at this URL: https://www.cisco.com/c/en/us/td/docs/routers/access/800/829/regulatory/IR800rcsi.html

Class A Notice for FCC

Modifying the equipment without Cisco's authorization may result in the equipment no longer complying with FCC requirements for Class A digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired
 operation.

This equipment has been tested and found to comply with the limits of a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses, and radiates radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference. However, there is no guarantee that interference will not occur. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician.



The Part 15 radio device operates on a non-interference basis with other devices operating at this frequency when using the integrated antennas. Any changes or modification to the product not expressly approved by Cisco could void the user's authority to operate this device.

APAC Compliance

Cisco® 807 Industrial Integrated Services Router Model IR807G-LTE Cisco® 807 Industrial Integrated Services Router PIDS

Getting Started and Product Document of Compliance for the Cisco IR807 Integrated Services Router

- IR807G-LTE-VZ-K9
- IR807G-LTE-NA-K9
- IR807G-LTE-GA-K9

Industry Canada

Canadian Compliance Statement

Cisco® 807 Industrial Integrated Services Router Model

IR807G-LTE

Cisco® 807 Industrial Integrated Services Router PIDS

- IR807G-LTE-VZ-K9
- IR807G-LTE-NA-K9
- IR807G-LTE-GA-K9

Industry Canada Certification Number

• IR807G-LTE

This Class A Digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.

This device complies with Class A Limits of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Cisco® 807 Industrial Integrated Services Routers are certified to the requirements of RSS-210. The use of this device in a system operating either partially or completely outdoors may require the user to obtain a license for the system according to the Canadian regulations. For further information, contact your local Industry Canada office.

This device has been designed to operate with antennas having a maximum gain of 6 dBi. Antennas having a gain greater than 6 dBi are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotopically radiated power (EIRP) is not more than that permitted for successful communication.

European Community, Switzerland, Norway, Iceland, and Liechtenstein

Cisco® 807 Industrial Integrated Services Router PID

• IR807G-LTE-GA-K9

Declaration of Conformity with regard to the R&TTE Directive 1999/5/EC & Medical Directive 93/42/EEC

The following standards were applied:

- EMC-EN 301.489-1 v1.9.2; EN 301.489-17 v2.2.1
- Health & Safety-EN60950-1: 2005; EN 50385: 2002
- Radio-EN 300 328 v 1.9.1; EN 301.893 v 1.7.1, EN62311

The conformity assessment procedure referred to in Article 10.4 and Annex III of Directive 1999/5/EC has been followed.

This device also conforms to the EMC requirements of the Medical Devices Directive 93/42/EEC.



This equipment is intended to be used in all EU and EFTA countries. Outdoor use may be restricted to certain frequencies and/or may require a license for operation. For more details, contact Cisco Corporate Compliance.

The product carries the CE Mark:

(())

Declaration of Conformity for RF Exposure

This section contains information on compliance with guidelines related to RF exposure.

Generic Discussion on RF Exposure

The Cisco products are designed to comply with the following national and international standards on Human Exposure to Radio Frequencies:

- US 47 Code of Federal Regulations Part 2 Subpart J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers / IEEE C 95.1 (99)
- International Commission on Non Ionizing Radiation Protection (ICNIRP) 98
- Ministry of Health (Canada) Safety Code 6. Limits on Human Exposure to Radio Frequency Fields in the range from 3kHz to 300 GHz
- Australia Radiation Protection Standard

To ensure compliance with various national and international Electromagnetic Field (EMF) standards, the system should only be operated with Cisco approved antennas and accessories.

This Device Meets International Guidelines for Exposure to Radio Waves

The IR807 series device includes a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

As such the systems are designed to be operated as to avoid contact with the antennas by the end user. It is recommended to set the system in a location where the antennas can remain at least a minimum distance as specified from the user in accordance to the regulatory guidelines which are designed to reduce the overall exposure of the user or operator.

Separation Distance		
MPE	Distance	Limit
0.63 mW/cm ²	20 cm (7.87 inches)	1.00 mW/cm ²

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of wireless devices. They recommend that if you are interested in further reducing your exposure then you can easily do so by reorienting antennas away from the user or placing he antennas at a greater separation distance then recommended.

This Device Meets FCC Guidelines for Exposure to Radio Waves

The IR807 series device includes a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) as referenced in FCC Part 1.1310. The guidelines are based on IEEE ANSI C 95.1 (92) and include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

As such the systems are designed to be operated as to avoid contact with the antennas by the end user. It is recommended to set the system in a location where the antennas can remain at least a minimum distance as specified from the user in accordance to the regulatory guidelines which are designed to reduce the overall exposure of the user or operator.

The device has been tested and found compliant with the applicable regulations as part of the radio certification process.

Separation Distance		
MPE	Distance	Limit
0.63 mW/cm ²	20 cm (7.87 inches)	1.00 mW/cm ²

The US Food and Drug Administration has stated that present scientific information does not indicate the need for any special precautions for the use of wireless devices. The FCC recommends that if you are interested in further reducing your exposure then you can easily do so by reorienting antennas away from the user or placing the antennas at a greater separation distance then recommended or lowering the transmitter power output.

This Device Meets the Industry Canada Guidelines for Exposure to Radio Waves

The IR807 series device includes a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) as referenced in Health Canada Safety Code 6. The guidelines include a substantial safety margin designed into the limit to ensure the safety of all persons, regardless of age and health.

As such the systems are designed to be operated as to avoid contact with the antennas by the end user. It is recommended to set the system in a location where the antennas can remain at least a minimum distance as specified from the user in accordance to the regulatory guidelines which are designed to reduce the overall exposure of the user or operator.

Separation Distance		
MPE	Distance	Limit
0.63 mW/cm ²	20 cm (7.87 inches)	1.00 mW/cm ²

Health Canada states that present scientific information does not indicate the need for any special precautions for the use of wireless devices. They recommend that if you are interested in further reducing your exposure you can easily do so by reorienting antennas away from the user, placing the antennas at a greater separation distance than recommended, or lowering the transmitter power output.

Additional Information on RF Exposure

You can find additional information on the subject at the following links:

- FCC Bulletin 56: Questions and Answers about Biological Effects and Potential Hazards of Radio Frequency Electromagnetic Fields
- FCC Bulletin 65: Evaluating Compliance with the FCC guidelines for Human Exposure to Radio Frequency Electromagnetic Fields
- FCC Bulletin 65C (01-01): Evaluating Compliance with the FCC guidelines for Human Exposure to Radio Frequency Electromagnetic Fields: Additional Information for Evaluating Compliance for Mobile and Portable Devices with FCC limits for Human Exposure to Radio Frequency Emission

You can obtain additional information from the following organizations:

- World Health Organization Internal Commission on Non-Ionizing Radiation Protection at this URL: www.who.int/emf
- United Kingdom, National Radiological Protection Board at this URL: www.nrpb.org.uk
- Cellular Telecommunications Association at this URL: www.wow-com.com
- The Mobile Manufacturers Forum at this URL: www.mmfai.org

EMC Class A Notices and Warnings

Statement 340—Class A Warning for CISPR22

Warnung Dies ist ein Produkt der Klasse A. Bei der Verwendung dieses Produkts im Haus- oder Wohnungsbereich kann es zu Funkstörungen kommen. In diesem Fall muss der Benutzer u. U. angemessene Maßnahmen ergreifen.

Declaration of Conformity with Regard to the EU Directive 2014/53/EU

The information in this document is applicable to the Cisco IR807 series wireless LAN product that currently includes the IR807G-LTE-GA-K9.

The equipment operates in the 2400 -MHz to 2483.5-MHz frequency range.

National regulations may require that operations be limited to portions of the frequency ranges identified above and/or at reduced power levels. See the "National Restrictions" section for complete details

This declaration is only valid for configurations (combinations of software, firmware and hardware) provided and/or supported by Cisco Systems for use within the EU or countries that have implemented the EU Directives. The use of software or firmware not supported/provided by Cisco Systems may result that the equipment is no longer compliant with the regulatory requirements.

Country	Statement
Български [Bulgarian]	Това оборудване отговаря на съществените изисквания и приложими клаузи на Директива 2014/53/EC.
Česky [Czech]:	Toto zařízení je v souladu se základními požadavky a ostatními odpovídajícími ustanoveními Směrnice 2014/53/EU.
Dansk [Danish]:	Dette udstyr er i overensstemmelse med de væsentlige krav og andre relevante bestemmelser i Direktiv 2014/53/EU.
Deutsch [German]:	Dieses Gerät entspricht den grundlegenden Anforderungen und den weiteren entsprechenden Vorgaben der Richtlinie 2014/53/EU.
Eesti [Estonian]:	See seade vastab direktiivi 2014/53/EL olulistele nõuetele ja teistele asjakohastele sätetele.
English:	This equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

Español [Spanish]:	Este equipo cumple con los requisitos esenciales así como con otras
Ellenné (Carable	disposiciones de la Directiva 2014/53/UE. Αυτός ο εξοπλισμός είναι σε συμμόρφωση με τις ουσιώδεις απαιτήσεις και
Ελληνική [Greek]:	άλλες σχετικές διατάξεις της Οδηγίας 2014/53/ΕΕ.
Français [French]:	Cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la Directive 2014/53/UE.
Hrvatski:[Croatian]	Ova oprema je u sukladnosti s bitnim zahtjevima i drugim relevantnim odredbama Direktive 2014/53/EU
Íslenska [Icelandic]:	Þetta tæki er samkvæmt grunnkröfum og öðrum viðeigandi ákvæðum Tilskipunar 2014/53/EU.
Italiano [Italian]:	Questo apparato é conforme ai requisiti essenziali ed agli altri principi sanciti dalla Direttiva 2014/53/UE.
Latviski [Latvian]:	Šī iekārta atbilst Direktīvas 2014/53/ES būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių [Lithuanian]:	Šis įrenginys tenkina 2014/53/ES Direktyvos esminius reikalavimus ir kitas šios direktyvos nuostatas.
Nederlands [Dutch]:	Dit apparaat voldoet aan de essentiele eisen en andere van toepassing zijnde bepalingen van de Richtlijn 2014/53/EU.
Malti [Maltese]:	Dan I-apparat huwa konformi mal-ħtiģiet essenzjali u I-provedimenti I-oħra rilevanti tad-Direttiva 2014/53/UE.
Magyar [Hungarian]:	Ez a készülék teljesíti az alapvető követelményeket és más 2014/53/EU irányelvben meghatározott vonatkozó rendelkezéseket.
Norsk [Norwegian]:	Dette utstyret er i samsvar med de grunnleggende krav og andre relevante bestemmelser i EU-direktiv 2014/53/EU.
Polski [Polish]:	Urządzenie jest zgodne z ogólnymi wymaganiami oraz szczególnymi warunkami określonymi Dyrektywą UE: 2014/53/UE.
Português [Portuguese]:	Este equipamento está em conformidade com os requisitos essenciais e outras provisões relevantes da Directiva 2014/53/UE.
Română [Romanian]	Acest echipament este in conformitate cu cerintele esentiale si cu alte prevederi relevante ale Directivei 2014/53/EU.
Slovensko [Slovenian]:	Ta naprava je skladna z bistvenimi zahtevami in ostalimi relevantnimi pogoji Direktive 2014/53/UE.
Slovensky [Slovak]:	Toto zariadenie je v zhode so základnými požiadavkami a inými príslušnými nariadeniami direktív: 2014/53/EÚ.
Suomi [Finnish]:	Tämä laite täyttää direktiivin 2014/53/EU olennaiset vaatimukset ja on siinä asetettujen muiden laitetta koskevien määräysten mukainen.
Svenska [Swedish]:	Denna utrustning är i överensstämmelse med de väsentliga kraven och andra relevanta bestämmelser i Direktiv 2014/53/EU.
Türk [Turkish]	Bu cihaz 2014/53/EU Direktifi'nin temel gereklerine ve ilgili diğer hükümlerine uygundur.

٩, Note

The full declaration of conformity for this product can be found

at:<u>https://www.cisco.com/c/en/us/support/routers/807-industrial-integrated-services-routers/model.html.</u> See the Obtaining Documents from Cisco.com, page 17 section for instructions for downloading these documents.

The following standards were applied during the assessment of the product against the requirements of the Directive 1999/5/EC:

- Radio: EN 301 893, EN 300 328
- EMC: EN 301 489-1, EN 301 489-17
- Safety: EN 60950-1

CE Mark

For the Cisco IR807-LTE, the following CE mark is affixed to the equipment and its packaging:

CE

National Restrictions

In the EU and other European Countries, the 2.4GHz and 5GHz bands have been made available for the use of wireless LANs.

The following sections identify countries having additional requirements or restrictions.

Denmark

In Denmark, the band 5150 - 5350 MHz is also allowed for outdoor usage. I Danmark må frekvensbåndet 5150 - 5350 også anvendes udendørs.

Italy

This product meets the National Radio Interface and the requirements specified in the National Frequency Allocation Table for Italy. Unless this wireless LAN product is operating within the boundaries of the owner's property, its use requires a "general authorization". Please check

http://www.comunicazioni.it/it/ for more details.

Questo prodotto è conforme alla specifiche di Interfaccia Radio Nazionali e rispetta il Piano Nazionale di ripartizione delle frequenze in Italia. Se non viene installato all'interno del proprio fondo, l'utilizzo di prodotti Wireless LAN richiede una "Autorizzazione Generale". Consultare

http://www.mise.gov.it/index.php/it/comunicazioni

Latvia

The outdoor usage of the 2.4 GHz band requires an authorization from the Electronic Communications Office. Please check http://www.esd.lv for more details.

2,4 GHz frekvenču joslas izmantošanai ārpus telpām nepieciešama atļauja no Elektronisko sakaru direkcijas. Vairāk informācijas: <u>http://www.esd.lv</u>.

Note

Although Norway, Switzerland, Liechtenstein and Turkey are not EU member states, the EU Directive 1999/5/EC has also been implemented in those countries.

78-

Antennas

The IR807 series products are equipped with antenna connectors to allow the use of dedicated (external) antennas available from Cisco.

The following link to the data sheet lists the antennas that can be used by the IR807 series. All antennas where assessed together with the equipment against the requirements of the R&TTE directive.

http://www.cisco.com/c/en/us/products/collateral/routers/807-industrial-router/datasheet-c78-734980.html

Depending on the country a different regulatory limit might be applicable. It is therefore the responsibility of the end user to select a power level that, together with the antenna, results in an eirp (radiated power) level that is below the applicable limit.

6 Note

The antenna gain mentioned does not include the cable loss. For all combinations, the total of power level, antenna gain and cable loss is equal to or below 43.5 dBm (eirp).

Obtaining Documents from Cisco.com

Follow these steps to obtain any of the online documents mentioned in this document.

Step 1	Browse to this URL on Cisco.com:
	http://www.cisco.com/cisco/web/psa/default.html?mode=prod&level0=278875243
Step 2	For Cisco IR807 Series wireless products, click:
	https://www.cisco.com/cisco/web/psa/default.html?mode=prod&level0=278875243

Note

If you still have questions regarding the compliance of these products or you can not find the information you are looking for, please send an email request to Cisco at complianceinfo@cisco.com.

This page left intentionally blank

This page left intentionally blank

19

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2017 Cisco Systems, Inc. All rights reserved.

C Printed in the USA on recycled paper containing 10% postconsumer waste.