



Cisco Prime Infrastructure 3.7 Appliance Hardware Installation Guide

First Published: 2019-05-30

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2019 Cisco Systems, Inc. All rights reserved.



CONTENTS

Introduction ?

CHAPTER 1

Installation and Initial Configuration 1

Overview 1

System Configuration 1

Set the Appliance 2

 Improve Performance on Physical Appliances 4

 Upgrade and Migrate from Previous Releases of Cisco Prime Infrastructure 4

CHAPTER 2

Install the ISO on the Appliance 5

Install the ISO on the Appliance 5

 Manage the Appliance Using CIMC 7

CHAPTER 3

Additional Functions 9

Connect to the Console 9

 Connect to the Console Using Serial Over LAN 9

 Connect to the vKVM Console 11

 Set the Baud Rate 12

DVD Mount Options 12

 Mount vKVM DVD 12

 Mount a CIMC vMedia DVD 13

Password Recovery 13

How to Recover Administrator Passwords on Gen 3 Appliance 13

Related Documentation 15



CHAPTER 1

Installation and Initial Configuration

- [Overview, on page 1](#)
- [System Configuration, on page 1](#)
- [Set the Appliance, on page 2](#)

Overview

This guide provides the information on how to install the Cisco Prime Infrastructure 3.7 Physical Appliances Gen2, Gen 3, and Cisco Digital Network Architecture (DNA) Center.

System Configuration

Table 1: System Configuration

Specification	Gen-2 Appliance	Gen-3 Appliance	DNAC Appliance	DNAC 2 Appliance
CPU	1 X 10 core processor (20 threads)	20C/40T	44 C/ 88 T	44 C/ 88 T
RAM	64 GB	64GB	256GB	256 GB
HDD	4 X 900 GB in RAID 10 configuration and 2.5inch drive	4 x 1.2 TB	3.6 TB	2 x 480 GB in RAID 1 2 x 1.9 TB in RAID 1 6 x 1.9 TB in RAID 10
CIMC	Cisco UCS C-Series Integrated Management Controller	Cisco UCS C-Series Integrated Management Controller	Cisco UCS C-Series Integrated Management Controller	Cisco UCS C-Series Integrated Management Controller
NIC	Integrated dual-port Gigabit Ethernet	Integrated dual-port Gigabit Ethernet	Integrated dual-port Gigabit Ethernet	Integrated dual-port Gigabit Ethernet

For scaling information on this server see the *Scaling* Prime Infrastructure section in [Cisco Prime Infrastructure Quick Start Guide](#).



Note When there is a flap time in hard appliance, ensure that the hardware clock (BIOS / CIMC) and the Network Time Protocol time are in sync.

Set the Appliance

This section describes how to set the Prime Infrastructure appliance.

-
- Step 1** Attach a keyboard and monitor to the USB ports on the rear panel of the appliance or by using a KVM cable and connector to access the appliance console.
- Step 2** Power on the appliance.
- Step 3** To set up CIMC press F8 to enter the CIMC configuration utility and continue with Step 3 to Step 11. Continue with Step 12 in case you do not wish to configure CIMC.
- You might need to press the function keys (F8, F6 and F2) more than once until the system responds. If you do not press F8 quickly enough you may enter the EFI shell. Press Ctrl, Alt, Del to reboot the system and press F8 again.
- Note** The Cisco Integrated Management Controller (CIMC) is the management service that you use to remotely access, configure, administer, and monitor the Prime Infrastructure server.
- Step 4** In the Configuration Utility window, change the following fields as specified:
- NIC mode—Select **Dedicated**.
 - IP (Basic)—Select **IPv4**.
 - DHCP—Disable DHCP if enabled.
 - CIMC IP—Enter the IP address of the CIMC.
 - Prefix/Subnet—Enter the subnet of the CIMC.
 - Gateway—Enter the Gateway address.
 - Pref DNS Server—Enter the preferred DNS server address.
 - NIC Redundancy—Null

Step 5 Press **F1** to specify additional settings.

```

Cisco IMC Configuration Utility Version 2.0 Cisco Systems, Inc.
*****
Common Properties
Hostname:      C220-FCH1843V0L3
Dynamic DNS:   [ ]
DDNS Domain:
FactoryDefaults
Factory Default: [ ]
Default User(Basic)
Default password:
Reenter password:
Port Properties
Auto Negotiation: [ ]
Speed[1000/100 Mbps]: 100
Duplex mode[half/full]: full
Port Profiles
Reset: [ ]
Name:

*****
<Up/Down>Selection <F10>Save <Space>Enable/Disable <F5>Refresh <ESC>Exit
<F2>PreviousPage

```

Step 6 Make the following changes on the Additional Settings window:

- Enter a hostname for CIMC.
- Turn off Dynamic DNS.
- Enter the admin password. If you leave the password field blank, the default password is **password**.

Step 7 Press **F10** to save the settings.

Step 8 Press escape to exit and reboot the server.

For remote management move to current step 7.

Step 9 After the settings are saved, open a browser and enter the following URL:

https://CIMC_ip_address where *CIMC_IP_address* is the IP address that you entered in Step 3 above.

Step 10 Log in to CIMC web interface using the following credentials:

- Username—admin
- Password—the password configured in Step 6

You will be prompted to reset the password if you did not change the default password in Step 6.

Improve Performance on Physical Appliances

For better performance on the Prime Infrastructure Physical Appliance Gen 2, Gen 3, and DNAC Appliance, make sure you configure the virtual drive Write Policy to Write Back Good BBU. To configure the virtual drive Write Policy, follow these steps:

-
- Step 1** Launch the CIMC web interface.
 - Step 2** Click the **Storage** tab, click on the SAS Modular Controller name, click the **Virtual Drive Info** tab, select the **Virtual Drive** and then click **Edit Virtual Drive**.
 - Step 3** Click **OK** on the dialog box that appears.
 - Step 4** In the Write Policy field, select **Write Back Good BBU** fro the drop-down, then click **Save Changes**.
-

Upgrade and Migrate from Previous Releases of Cisco Prime Infrastructure

See the sections *Upgrading from Previous Releases of Cisco Prime Infrastructure* and *Migrating from Previous Releases of Cisco Prime Infrastructure* in [Cisco Prime Infrastructure Quick Start Guide](#).



CHAPTER 2

Install the ISO on the Appliance

- [Install the ISO on the Appliance, on page 5](#)

Install the ISO on the Appliance

The appliance is shipped with the software version pre-installed. You do not have to perform these steps during the initial installation of the appliance. However in case you need to re-image the appliance, you can install the software from the ISO file.

To reduce the installation time, choose **Admin > Network > Network Settings** in the CIMC interface and check the **Auto Negotiation** check box.

Before You Begin

Download the ISO file `PI-APL-3.7.0.0.159-1-K9.iso` from cisco.com and verify file integrity using the checksum values listed for it on cisco.com.

You can verify the Cisco Signature for the ISO image with the following steps:

1. Download `PI-APL-3.7.0.0.159-1-K9.iso`, `CiscoPI3.7.pem` and `PI-APL-3.7.0.0.159-1-K9.iso.signature`.
2. Copy these file to any Linux server and enter the following command.

```
openssl dgst -sha512 -verify  
CiscoPI3.7.pem -signature PI-APL-3.7.0.0.159-1-K9.iso.signature PI-APL-3.7.0.0.159-1-K9.iso
```

The result will be shown as “Verified”.



Note Ensure no storage devices are connected to the USB port of the appliance before upgrading or installing the ISO image. The installation fails if a USB storage device is connected to the USB port of the appliance as the installer selects the USB storage device.



Note When you connect Gen 2 and Gen 3 appliances through serial console connection after reboot, there are chances that you might encounter garbled screen display. To overcome this issue, you can connect through CIMC or VGA console.

- Step 1** Connect to the console using one of the options mentioned in [Connect to the Console](#).
- Step 2** Mount ISO using any one of the mounting options. See [DVD Mount Options](#) for more details.
- Step 3** Reboot the appliance by pressing the power switch or select **Power > Reset System(Warm Boot)** if you are using vKVM to restart.
- Step 4** After the appliance reboots, press **F6** to enter the boot option.
- Step 5** Select one of the DVD mount option with the Cisco Prime Infrastructure 3.7 software image. See [DVD Mount Options](#) for more information.

```

Please select boot device:
-----
(Bus 05 Dev 00)PCI RAID Adapter
UEFI: Built-in EFI Shell
IBA GE Slot 0100 v1553
IBA GE Slot 0101 v1553
Cisco vKVM-Mapped vDVD1.22
Cisco vKVM-Mapped vHDD1.22
Cisco vKVM-Mapped vFDD1.22
Cisco CIMC-Mapped vDVD1.22
Cisco CIMC-Mapped vHDD1.22
Enter Setup
-----
↑ and ↓ to move selection
ENTER to select boot device
ESC to boot using defaults

```

- Step 6** From the available boot options, enter **1** or **2** carefully, as all future management messages will be displayed in the selected display.
- 1 —Prime Infrastructure System Installation (Keyboard/Monitor) if you are connected through the VGA port/vKVM (KVM console).
- All console data/information will appear on the VGA port /vKVM (KVM console).
- 2 —Prime Infrastructure System Installation (Serial connection) if you are connected through the serial port or Serial Over LAN. See [Connect to the Console Using Serial Over LAN](#) for more information.
- All console data/information will appear on the serial port or Serial Over LAN.

```

Welcome to Cisco Prime Infrastructure

To boot from hard disk, press <Enter>.

Available boot options:
[1] Prime Infrastructure System Installation (Keyboard/Monitor)
[2] Prime Infrastructure System Installation (Serial Console)
[3] Recover administrator password. (Keyboard/Monitor)
[4] Recover administrator password. (Serial Console)
<Enter> Boot existing OS from Hard Disk.

Enter boot option and press <return>.

boot:

```

The time taken to deploy the image will depend on the network speed.

Step 7 Enter **setup** at the login prompt when prompted to initiate the installation.

What to do next

See *Set Up Prime Infrastructure on a Virtual Machine or Physical Appliance* section (Step 3 onwards) in [Cisco Prime Infrastructure Quick Start Guide](#) for more information about installing the software.



Note Cisco Prime Infrastructure is installed only using the 1 Gbps ports. To disable the 10 Gbps ports on Cisco DNA Center appliance and use the 1 Gbps ports to install Prime Infrastructure, perform the following steps.

1. Login to **CIMC Console**.
2. Navigate to **Compute > BIOS > Configure BIOS > Advanced > LOM and PCIe Slots Configuration**.
3. Choose the **Disabled** option from the **PCIeSlot:MLOM OptionROM** and **PCIeSlot:MLOM LinkSpeed** drop-down lists.
4. Click the **Save** button.
5. Navigate to **Host Power**, Power Cycle the machine and then Power ON.

Manage the Appliance Using CIMC

You can connect to the vKVM console by launching the CIMC and log in using your username and password configured in [Set the Appliance](#). Using the vKVM console you can do the following:

- Remotely power on or off the server.

- Monitor the server and disk status.
- Change the BIOS settings. Following table displays the hardware types and their respective latest firmware and BIOS versions that support the Cisco Prime Infrastructure 3.7 Physical Appliance ISO image:

Hardware Type	Firmware Version	BIOS Version
Gen 2	4.0(1c)	C220M4.3.0.1b.0.1201161639
Gen 3	3.1(3d)	C220M5.3.1.3c.0.0307181404
DNAC	3.0(3f)	C220M4.3.0.3c.0.0831170216

- Launch a virtual console on the appliance.
- Mount *iso* files as virtual DVD drives.
- Other server management functions. Note that if there are additional slots configured with JBOD, the upgrade will fail, hence ensure that you set the status of additional slots to be “Unconfigured Good”.
- See [Cisco Integrated Management Controller](#) documentation for more information.



CHAPTER 3

Additional Functions

- [Connect to the Console, on page 9](#)
- [DVD Mount Options, on page 12](#)
- [Password Recovery, on page 13](#)
- [How to Recover Administrator Passwords on Gen 3 Appliance, on page 13](#)
- [Related Documentation, on page 15](#)

Connect to the Console

You can physically connect to the console on the server using the VGA port or the serial port on the server.

The baud rate should be 9600 while connecting to the console using the serial port. See [Set the Baud Rate, on page 12](#).

You can also connect to the console remotely using the following options:


- Serial over LAN
- Using vKVM

Connect to the Console Using Serial Over LAN

You can use a terminal server to connect to the serial port of the appliance or use Serial over Lan (SOL) to connect to the serial console over the network.

To enable Serial over LAN (SOL):

-
- Step 1** Launch CIMC and log in using your username and password configured in [Set the Appliance, on page 2](#).
 - Step 2** Select **Compute > Remote Management > Serial Over LAN**.
 - Step 3** Check the check box **Enabled**.



Step 4 Connect to CIMC using SSH.

Step 5 Enter these commands in the following sequence:

- **scope sol**
- **show**

Serial over LAN must be enabled. If it is not enabled, use the user interface to enable it.

- **connect host**

Step 6 Launch Cisco Integrated Management Controller server using SSH .

```
# ssh admin@(server IP)
Enter the admin password
```

Step 7 Map the ISO image.

```
# scope vmedia
# map-www <VOLUME NAME> <http-location> <PI_ISO_FILE>
where - <http-location> is http location of iso image

Press Enter
# Server Username:<username>
# Server Password:<password>
# Confirm Password:<reenter the password>
# show mappings
      Volume      Map-Status      Drive-Type      Remote-Share      Remote-File
      Mount-Type
-----
      vol1         OK              CD              http://nmtgre-sjc.cis...
PI-APL-3.7.0.0.159-SNA...      www
```

```
# exit
```

Step 8 Reboot the server:

```
# scope chassis
# power off
  This operation will change the server's power state.
  Do you want to continue?[y|N]y
#
#
# power on
  This operation will change the server's power state.
  Do you want to continue?[y|N]y
# exit
```

Step 9 Connect to Serial Over Lan Console.

```
# scope sol
# show detail
Serial Over LAN:
  Enabled: yes
  Baud Rate(bps): 9600
  Com Port: com0
# set enabled yes
# set baud-rate 9600
# commit

# connect host // to connect sol console
```

Step 10 The machine reboots and prompts to enter F6 for boot option. Press the function-key **F6**.

You may need to press F6 multiple times to see **Enter boot selection menu...** in the screen. You must wait for a few minutes to get the boot device option.

Step 11 Select the desired DVD mount option and in this case, you must select **Cisco CIMC-Mapped vDVD1.22**.**Step 12** From the available boot options, enter option 1.**Step 13** Enter setup at the login prompt when prompted to initiate the installation.**Step 14** Close Network Connection to Exit.

Connect to the vKVM Console

Step 1 Launch CIMC and log in using your username and password configured in [Set the Appliance, on page 2](#).

Step 2 Choose **Chassis > Summary**.

Step 3 Click **Launch KVM** link and select **Java based KVM** or **HTML based KVM** to open KVM Console .
The Security Warning dialogue box opens.

Step 4 Click **Continue**.

The vKVM console is downloaded and the credentials are verified.

Step 5 Click **Run** to install the KVM console.

Set the Baud Rate

- Step 1** Launch CIMC.
- Step 2** Select **Compute > BIOS**.
- Step 3** Click **Configure BIOS**.
The **Configure BIOS Parameter** dialog box opens.
- Step 4** Click **Advanced** Tab
- Step 5** Expand **Serial Configuration**.
- Step 6** Select 9600 from the **Bits Second field** drop-down list.
- Step 7** Click **Save**.
-

DVD Mount Options

To re-image the appliance from an *iso* file the DVD mount options available are:

The following DVD mounting options are available:

- Physical DVD Mount
Burn the *iso* file to a DVD and mount it through a physical DVD drive connected to the USB port of the appliance. A physical DVD mount is used when CIMC remote management is not configured. This is the fastest option.
- CIMC mapped vMedia
 - The *iso* file is on the HTTPS, CIFS or NFS server and the speed depends on the Prime Infrastructure Server and File-Server bandwidth. The client server must remain connected till the installation is completed. This is the preferred mode for mounting the *iso* file.
- vKVM DVD mount
 - The *iso* file can also be mounted using a virtual console. The *iso* file is on client machine and the speed depends on server appliance bandwidth.

Mount vKVM DVD

The virtual KVM console (vKVM) is an interface accessible from CIMC that emulates a direct keyboard, video, and mouse connection to the server.

To mount an *iso* file from the desktop client using the vKVM DVD mount:

- Step 1** Connect to the vKVM console. See [Connect to the vKVM Console](#) for more details.
- Step 2** Click **Continue** in the **Warning-Security** dialog box to launch the **vKVM Console**.
- Step 3** Select **Virtual Media > Activate Virtual Devices**.

The **Unencrypted Virtual Media Session** dialogue box opens.

Step 4 Select the radio button **Accept this session**.

Step 5 Click **Apply**.

The Virtual Device is activated.

Step 6 Select **Virtual Media > Map CD/DVD** and browse to the Prime Infrastructure 3.7 ISO image on your computer. After mounting the vKVM DVD continue with Installing the ISO on the Appliance

Step 7 Click **Map Device** to mount the ISO image.

Mount a CIMC vMedia DVD

To mount an iso file from CIFS, NFS, HTTP server as a virtual DVD drive on the appliance:

Step 1 Launch CIMC and log in using your username and password configured in [Set the Appliance](#).

Step 2 Select **Compute > Remote Management**.

Step 3 Click **Virtual Media** and expand **Cisco IMC-Mapped vMedia**.

Step 4 Click **Add New Mapping** under **Current Mappings**.

Step 5 Enter the following parameters:

- Volume
- Remote Share
- Remote File
- Mount Options
- User Name
- Password

Step 6 Click **Save**.

Password Recovery

You can recover (that is, reset) administrator passwords on Prime Infrastructure physical appliances. See *How to Recover Administrator Passwords on Physical Appliances* in the [Cisco Prime Infrastructure Administrator Guide](#) for more information.

How to Recover Administrator Passwords on Gen 3 Appliance

You can recover (reset) administrator passwords on Prime Infrastructure Gen 3 appliances.

Before You Begin

Ensure that you have an current version of ISO image

You can reset the password using,

- **Console:** CIMC Console (Other console options are KVM Console, VGA Console and Serial Console/Serial Over Lan-SOL)
- **DVD mount option:** KVM mapped DVD (Other mount options are CIMC mapped DVD and Physical External DVD)

To recover the password using Serial Console/Serial Over Lan-SOL, follow these steps:

Step 1 Launch Cisco Integrated Management Controller server using SSH .

```
# ssh admin@(server IP)
Enter the admin password
```

Step 2 Map the ISO image.

```
# scope vmedia
# map-www <VOLUME NAME> <http-location> <PI_ISO_FILE>
where - <http-location> is http location of iso image
```

Press Enter

```
# Server Username:<username>
# Server Password:<password>
# Confirm Password:<reenter the password>
```

```
# show mappings
      Volume          Map-Status      Drive-Type      Remote-Share      Remote-File
      Mount-Type
-----
      voll            OK              CD              http://nmtgre-sjc.cis...
PI-APL-3.7.0.0.159-SNA...      www
```

```
# exit
```

Step 3 Reboot the server:

```
# scope chassis
# power off
This operation will change the server's power state.
Do you want to continue?[y|N]y
#
#
# power on
This operation will change the server's power state.
Do you want to continue?[y|N]y
# exit
```

Step 4 Connect to Serial Over Lan Console.

```
# scope sol
# show detail
Serial Over LAN:
Enabled: yes
Baud Rate(bps): 9600
```

```
Com Port: com0
# set enabled yes
# set baud-rate 9600
# commit

# connect host // to connect sol console
```

- Step 5** The machine reboots and prompts to enter F6 for boot option. Press the function-key **F6**.
You may need to press F6 multiple times to see **Enter boot selection menu...** in the screen. You must wait for a few minutes to get the boot device option.
- Step 6** Select the desired DVD mount option and in this case, you must select **Cisco CIMC-Mapped vDVD1.22**.
- Step 7** The vSphere client displays a list of boot options. Enter **4** to select the **Recover administrator password (Serial Console)** boot option.
- Note** To recover administrator password for Gen 3 appliances, it is recommended to use Serial Over Lan (Serial console)
- Step 8** The vSphere client displays a list of administrator user names. Enter the number shown next to the administrator user name for which you want to recover (reset) the password and press **Enter**.
- Step 9** Enter the new password and verify it with a second entry.
- Step 10** Enter **Y** to save your changes and reboot the system.
- Step 11** Login to the admin CLI with the new administrator password.
-

Related Documentation

- Cisco Integrated Management Controller documentation:
<http://www.cisco.com/c/en/us/support/servers-unified-computing/ucs-c-series-integrated-management-controllers/products-support-series-home.html>
- Cisco UCS C220 M4 Rack Server Specifications Sheet:
<http://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-c-series-rack-servers/c220m4-sff-spec-sheet.pdf>
- Cisco UCS C220 Server Installation and Service Guide:
http://www.cisco.com/c/en/td/docs/unified_computing/ucs/hw/C220/install/C220.html
- Cisco UCS C220 M5 Rack Server Specifications Sheet:
<https://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-c-series-rack-servers/c220m5-sff-specsheet.pdf>
- Cisco UCS C220 Server Installation and Service Guide:
https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/c/hw/C240M5/install/C240M5.html

