



# Overview

---

This chapter provides an overview of the enhanced management feature of the Cisco 1100 Series Integrated Services Router (ISR). This chapter contains the following topics:

- [MIB Description, page 1-1](#)
- [Benefits of MIB Enhancements, page 1-2](#)
- [Object Identifiers, page 1-2](#)
- [SNMP Overview, page 1-3](#)
- [Related Information and Useful Links, page 1-5](#)

## MIB Description

A Management and Information Base (MIB) is a database of the objects that can be managed on a device. The managed objects, or variables, can be set or read to provide information on the network devices and interfaces and are organized hierarchically. The MIB consists of collections of managed objects identified by object identifiers. MIBs are accessed using a network management protocol such as SNMP. A managed object (sometimes called a MIB object or an object) is one of a number of characteristics of a managed device, such as a router. Managed objects comprise one or more object instances, which are essentially variables. The Cisco implementation of SNMP uses the definitions of MIB II variables described in RFC 1213.

MIBs can contain two types of managed objects:

- **Scalar objects**—Define a single object instance (for example, `ifNumber` in the IF-MIB and `bgpVersion` in the BGP4-MIB).
- **Columnar objects**—Define multiple related objects such as zero, one, or more instances at any point in time that are grouped together in MIB tables (for example, `ifTable` in the IF-MIB defines the interface).

System MIB variables are accessible through SNMP as follows:

- **Accessing a MIB variable**—Function is initiated by the SNMP agent in response to a request from the NMS. The agent retrieves the value of the requested MIB variable and responds to the NMS with that value.
- **Setting a MIB variable**—Function is initiated by the SNMP agent in response to a message from the NMS. The SNMP agent changes the value of the MIB variable to the value requested by the NMS.

# Benefits of MIB Enhancements

The enhanced management feature on the Cisco 1100 Series ISR allow you to manage the router through the Simple Network Management Protocol (SNMP). The feature also expands the number of MIBs included with the router. See the “[SNMP Overview](#)” section on page 1-3 for more information about SNMP and MIBs.

Using the Cisco 1100 Series ISR enhanced management feature, you can:

- Manage and monitor Cisco 1100 Series ISR resources through an SNMP-based network management system (NMS)
- Use SNMP **set** and **get** requests to access information in Cisco 1100 Series ISR MIBs
- Reduce the amount of time and system resources required to perform functions such as inventory management

Other benefits include:

- A standards-based technology (SNMP) for monitoring faults and performance on the router
- Support for all SNMP versions (SNMPv1, SNMPv2c, and SNMPv3)
- Notification of faults, alarms, and conditions that might affect services
- A way to access router information other than through the command-line interface (CLI)

# Object Identifiers

An object identifier (OID) uniquely identifies a MIB object on a managed network device. The OID identifies the MIB object’s location in the MIB hierarchy, and provides a means of accessing the MIB object in a network of managed devices:

- Standard RFC MIB OIDs are assigned by the Internet Assigned Numbers Authority (IANA)
- Enterprise MIB OIDs are assigned by Cisco Assigned Numbers Authority (CANA)

Each number in the OID corresponds to a level of MIB hierarchy. For example, the OID 1.3.6.1.4.1.9.9.xyz represents the .xyz with the location in the MIB hierarchy as follows. Note that the numbers in parentheses are included to help show correspondence to the MIB hierarchy. In actual use, OIDs are represented as numerical values only.

iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).cisco(9).ciscoMgt(9).nm-MIB

You can uniquely identify a managed object, such as ifNumber in the IF-MIB, by its object name (iso.org.dod.internet.mgmt.enterprises.interfaces.ifNumber) or by its OID (1.3.6.1.2.1.2.1).

For a list of OIDs assigned to MIB objects, go to the following URL:

<ftp://ftp.cisco.com/pub/mibs/oid/>

# SNMP Overview

The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a standardized framework and a common language used for monitoring and managing devices in a network.

The SNMP framework has three parts:

- **SNMP manager**—A system used to control and monitor the activities of network hosts using SNMP. The most common managing system is called a Network Management System (NMS). The term NMS can be applied to either a dedicated device used for network management, or the applications used on a network management device. A variety of network management applications are available for use with SNMP. These features range from simple command-line applications to feature-rich graphical user interfaces (such as the CiscoWorks2000 line of products).
- **SNMP agent**—A software component in a managed device that maintains the data for the device and reports the data, as needed, to managing systems. The agent and MIB reside on the routing device (router, access server, or switch). To enable the SNMP agent on a managed device, you must define the relationship between the manager and the agent (see the [“Enabling SNMP Support”](#) section on page 2-3).
- **Management Information Base (MIB)**—MIB is a database of the objects that can be managed on a device.

Instead of defining a large set of commands, SNMP places all operations in a get-request, get-next-request, and set-request format. For example, an SNMP manager can get a value from an SNMP agent or set a value in that SNMP agent.

## SNMP Notifications

An SNMP agent can notify the SNMP manager when important system events occur, such as the following:

- An interface or card starts or stops running
- Temperature thresholds are crossed
- Authentication failures occur

When an agent detects an alarm condition, the agent:

- Logs information about the time, type, and severity of the condition
- Generates a notification message, which it then sends to a designated IP host

SNMP notifications are sent as either:

- **Traps**—Unreliable messages, which do not require receipt acknowledgment from the SNMP manager.
- **Informs**—Reliable messages, which are stored in memory until the SNMP manager issues a response. Informs use more system resources than traps.

The Cisco implementation of SNMP uses the definitions of SNMP traps described in RFC 1215.

When an agent detects an alarm condition, it logs information about the time, type, and severity of the condition and generates a notification message, which it then sends to a designated IP host. SNMP notifications can be sent as either *traps* or *informs*. For more information, see [“Enabling Notifications”](#)

section on page 4-2 on the Cisco 1100 Series ISR. Use the `snmp-server host` command to specify whether to send SNMP notifications as traps or informs. See Chapter 4, “Monitoring Notifications,” for information about Cisco 1100 Series ISR traps.

## SNMP Versions

Cisco IOS software supports the following versions of SNMP:

- SNMPv1—The Simple Network Management Protocol: An Internet standard, defined in RFC 1157. Security is based on community strings.
- SNMPv2c—The community-string-based administrative framework for SNMPv2. SNMPv2c is an update of the protocol operations and data types of SNMPv2p (SNMPv2 classic), and uses the community-based security model of SNMPv1.
- SNMPv3—Version 3 of SNMP. SNMPv3 uses the following security features to provide secure access to devices:
  - Message integrity—Ensuring that a packet has not been tampered with in transit.
  - Authentication—Determining that the message is from a valid source.
  - Encryption—Scrambling the contents of a packet to prevent it from being learned by an unauthorized source.

### SNMPv1 and SNMPv2c

Both SNMPv1 and SNMPv2c use a community-based form of security. The community of managers who are able to access the agent MIB is defined by an IP address access control list and password.

SNMPv2c support includes a bulk-retrieval mechanism and more detailed error message reporting to management stations. The bulk-retrieval mechanism supports the retrieval of tables and large quantities of information, minimizing the number of round-trip transmissions required. SNMPv2c improved error-handling support includes expanded error codes that distinguish different kinds of error conditions; these conditions are reported through a single error code in SNMPv1. Error return codes report the error type. Three kinds of exceptions are also reported:

- No such object
- No such instance
- End of MIB view

### SNMPv3

SNMPv3 provides security models and security levels:

- A security *model* is an authentication strategy that is set up for a user and the group in which the user resides.
- A security *level* is the permitted level of security within a security model.
- A combination of a security model and a security level determines the security mechanism employed when handling an SNMP packet.

## SNMP Security Models and Levels

Table 1-1 describes the security models and levels provided by the different SNMP versions.

*Table 1-1 SNMP Security Models and Levels*

Model	Level	Authentication	Encryption	Description
v1	noAuthNoPriv	Community string	No	Uses match on community string for authentication.
v2c	noAuthNoPriv	Community string	No	Uses match on community string for authentication.
v3	noAuthNoPriv	Username	No	Uses match on username for authentication.
	authNoPriv	MD5 or SHA	No	Provides authentication based on HMAC-MD5 or HMAC-SHA algorithm.
	authPriv	MD5 or SHA	DES	Provides authentication based on HMAC-MD5 or HMAC-SHA algorithm. Also provides DES 56-bit encryption based on CBC-DES (DES-56) standard.

You must configure the SNMP agent to use the version of SNMP supported by the management station. An agent can communicate with multiple managers; for this reason, you can configure the Cisco IOS software to support communications with one management station using the SNMPv1 protocol, one using the SNMPv2c protocol, and another using SMNPv3.

## RFC

MIB modules are written in the SNMP MIB module language, and are typically defined in RFC documents submitted to the Internet Engineering Task Force (IETF). RFCs are written by individuals or groups for consideration by the Internet Society and the Internet community as a whole. Before being given RFC status, recommendations are published as Internet Draft (I-D) documents. RFCs that have become recommended standards are also labeled as standards (STD) documents. For more information, see the Internet Society website (<http://www.internetsociety.org>) and IETF website (<http://www.ietf.org>).

We provide private MIB extensions with each Cisco system. Cisco enterprise MIBs comply with the guidelines described in the relevant RFCs unless otherwise noted in the documentation.

## Related Information and Useful Links

The following URL provides access to general information about Cisco MIBs. Use the links on this page to access MIBs for download, and to access related information (such as application notes and OID listings).

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

## TAC Information and FAQs

The following Cisco documents provide access to SNMP information developed by the Cisco Technical Assistance Center (TAC):

- Cisco TAC page for SNMP at:  
[http://www.cisco.com/en/US/tech/tk648/tk362/tk605/tsd\\_technology\\_support\\_sub-protocol\\_home.html](http://www.cisco.com/en/US/tech/tk648/tk362/tk605/tsd_technology_support_sub-protocol_home.html). It provides links to general SNMP information and tips for using SNMP to gather data.
- Frequently Asked Questions (FAQs) about Cisco MIBs at:  
[http://www.cisco.com/en/US/customer/tech/tk648/tk362/technologies\\_q\\_and\\_a\\_item09186a0080094bc0.shtml](http://www.cisco.com/en/US/customer/tech/tk648/tk362/technologies_q_and_a_item09186a0080094bc0.shtml).

## SNMP Configuration Information

The following Cisco documents provide information about configuring SNMP:

- Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.2, Part 3 System Management, “*Configuring SNMP Support*” at:  
[http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/configuration/guide/fcf014.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/fcf014.html)
- Cisco IOS Configuration Fundamentals Command Reference, Release 12.2, Part 3 System Management Commands, “*SNMP Commands*” at:  
[http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/command/reference/frf014.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/command/reference/frf014.html)



## Configuring MIB Support

---

This chapter describes how to configure SNMP and MIB support for the Cisco 1100 Series Integrated Services Router (ISR). It includes the following sections:

- [Determining MIB Support for Cisco IOS Releases, page 2-1](#)
- [Downloading and Compiling MIBs, page 2-1](#)
- [Enabling SNMP Support, page 2-3](#)

### Determining MIB Support for Cisco IOS Releases

Follow these steps to determine which MIBs are included in the Cisco IOS release running on your router:

- 
- Step 1** Go to the Cisco MIBs Support page:  
[ftp://ftp.cisco.com/pub/mibs/supportlists/isr1100/ISR1100\\_supportlist.html](ftp://ftp.cisco.com/pub/mibs/supportlists/isr1100/ISR1100_supportlist.html)
- Step 2** Under Cisco Access Products, select **Cisco 1100 Series ISRs** to display a list of MIBs supported on the Cisco 1100 Series ISR.
- Step 3** Scroll through the list to find the release you are interested in.
- 

### Downloading and Compiling MIBs

The following sections provide information about how to download and compile MIBs for the Cisco 1100 ISR:

- [Considerations for Working with MIBs, page 2-2](#)
- [Downloading MIBs, page 2-3](#)
- [Compiling MIBs, page 2-3](#)

## Considerations for Working with MIBs

While working with MIBs, consider the following:

- Mismatches on datatype definitions might cause compiler errors or warning messages. Although Cisco MIB datatype definitions are not mismatched, some standard RFC MIBs do mismatch as in the following example:

```
MIB A defines: SomeDatatype ::= INTEGER(0..100)
MIB B defines: SomeDatatype ::= INTEGER(1..50)
```

This example is considered to be a trivial error and the MIB loads successfully with a warning message.

The following example is considered as a nontrivial error (even though the two definitions are essentially equivalent), and the MIB is not successfully parsed:

```
MIB A defines: SomeDatatype ::= DisplayString
MIB B defines: SomeDatatype ::= OCTET STRING (SIZE(0..255))
```

If your MIB compiler treats these as errors, or you want to delete the warning messages, edit one of the MIBs that defines this same datatype so that the definitions match.

- Many MIBs import definitions from other MIBs. If your management application requires MIBs to be loaded, and you experience problems with undefined objects, you might want to load the following MIBs in this order:
  1. SNMPv2-SMI.my
  2. SNMPv2-TC.my
  3. SNMPv2-MIB.my
  4. RFC1213-MIB.my
  5. IF-MIB.my
  6. CISCO-SMI.my
  7. CISCO-PRODUCTS-MIB.my
  8. CISCO-TC.my
- For additional information and SNMP technical tips, go to the Locator page and click **SNMP MIB Technical Tips** or go to the following URL:
 

<http://tools.cisco.com/ITDIT/MIBS/servlet/index>
- For a list of SNMP object identifiers (OIDs) assigned to MIB objects, go to the following URL and click on **SNMP Object Navigator** and follow the links:
 

<http://tools.cisco.com/ITDIT/MIBS/servlet/index>




---

**Note** To access this tool, you must have a Cisco.com login account.

---

- For information about how to download and compile Cisco MIBs, go to the following URL:
 

[http://www.cisco.com/en/US/tech/tk648/tk362/technologies\\_tech\\_note09186a00800b4cee.shtml](http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a00800b4cee.shtml)



## Downloading MIBs

Follow these steps to download the MIBs onto your system if they are not already there:

- 
- Step 1** Review the considerations in the “[Considerations for Working with MIBs](#)” section.
- Step 2** Go to one of the following Cisco URLs. If the MIB you want to download is not there, try the other URL; otherwise, go to one of the URLs in Step 5.
- <ftp://ftp.cisco.com/pub/mibs/v2>  
<ftp://ftp.cisco.com/pub/mibs/v1>
- Step 3** Click the link for a MIB to download that MIB to your system.
- Step 4** Select **File > Save** or **File > Save As** to save the MIB on your system.
- Step 5** You can download industry-standard MIBs from the following URLs:
- <http://www.ietf.org>
  - <http://www.broadband-forum.org/>
- 

## Compiling MIBs

If you plan to integrate the Cisco 1100 ISR with an SNMP-based management application, then you must also compile the MIBs for that platform. For example, if you are running HP OpenView on a UNIX operating system, you must compile Cisco 1100 ISR MIBs with the HP OpenView Network Management System (NMS). For instructions, see the NMS documentation.

## Enabling SNMP Support

The following procedure summarizes how to configure the Cisco 1100 ISR for SNMP support.

For detailed information about SNMP commands, see the following Cisco documents:

- *Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.2, Part 3 System Management*, “Network Monitoring Using Cisco Service Assurance Agent”, available at the following URL:  
[http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/configuration/guide/fcf017.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/fcf017.html)
- *Cisco IOS Configuration Fundamentals Command Reference, Release 12.2, Part 3 System Management Commands*, “Cisco Service Assurance Agent (SAA) Commands”, available at the following URL:  
[http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/command/reference/frf017.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/command/reference/frf017.html)

To configure the Cisco 1100 ISR for SNMP support, follow these steps:

- 
- Step 1** Set up your basic SNMP configuration through the command-line interface (CLI) on the router. Note that these basic configuration commands are issued for SNMPv2c. For SNMPv3, you must also set up SNMP users and groups. (See the preceding list of documents for command and setup information.)
- a. Define SNMP based read-only and read-write communities:

```
Router (config)# snmp-server community Read_Only_Community_Name ro
Router (config)# snmp-server community Read_Write_Community_Name rw
```

- b. Configure SNMP views (to limit the range of objects accessible to different SNMP user groups):

```
Router (config)# snmp-server view view_name oid-tree {included | excluded}
```

- Step 2** Identify (by IP address) the host to receive SNMP notifications from the router:

```
Router (config)# snmp-server host host
```

- Step 3** Configure the router to generate notifications. You can use keywords to limit the number and types of messages generated.

```
Router (config)# snmp-server enable traps [notification-type] [notification-option]
```

---



## MIB Specifications

---

This chapter describes the Management Information Base (MIB) on the Cisco 1100 Series Integrated Services Router (ISR). It includes the following sections:

- [Cisco 1100 Series ISR MIBs, page 3-1](#)
- [Cisco 1100 Series ISR MIB Categories, page 3-1](#)

### Cisco 1100 Series ISR MIBs

Each MIB description lists relevant constraints about the MIB's implementation on the Cisco 1100 Series Integrated Services Router platform. Any objects not listed in a table are implemented as defined in the MIB. For detailed MIB descriptions, see the standard MIB.



**Note**

Your Cisco 1100 Series ISR may or may not fully support all the MIBs included in a Cisco IOS software release. Certain MIBs might work but they have not been tested on the router. In addition, some MIBs are deprecated, but cannot be removed from the software. When a MIB is included in the software image, it does not necessarily mean that it is supported on a Cisco 1100 Series ISR platform.

For more information about the MIBs that are included in this releases, see the [“Downloading and Compiling MIBs” section on page 2-1](#).

### Cisco 1100 Series ISR MIB Categories

The subsequent tables list the following categories of MIBs in the Cisco 1100 Series ISR Image on the Cisco 1100 Series ISR:

- Supported and verified MIBs (tested for Cisco 1100 Series ISR)—The MIBs exist in the image, the code is implemented, and Cisco has verified that all the supported objects work properly ([Table 3-1](#)).
- Supported and unverified MIBs (not tested Cisco 1100 Series ISR)—The MIBs exist in the image, the code is implemented, but Cisco has not verified if it is working properly ([Table 3-2](#)).
- Unsupported MIBs (no level of support or testing on the Cisco 1100 Series ISR)—The MIBs may be posted on Cisco.com, but are not present in the image and cannot be queried ([Table 3-3](#)).

The MIB version string indicates the date and time that it was most recently modified. The format is YYMMDDHHMMZ or YYYYMMDDHHMMZ, where:

- YY is the last two digits of the year (only years between 1900 and 1999).

- YYYY is all four digits of the year (any year).
- MM is the month (01 through 12).
- DD is the day of the month (01 through 31).
- HH is hours (00 through 23).
- MM is minutes (00 through 59).
- Z (the ASCII character Z), denotes Coordinated Universal Time (UTC, formerly Greenwich Mean Time [GMT]). This data type stores the date and time fields YEAR, MONTH, DAY, HOUR, MINUTE, SECOND, TIMEZONE\_HOUR, and TIMEZONE\_MINUTE.



**Note** For example, 9502192015Z and 199502192015Z represent 8:15 GMT on 19 February 1995. Years after 1999 use the four-digit format. Years 1900-1999 may use the two-digit or four-digit format.



**Note** In the following tables you might see the term *Unknown*. This term refers to the MIB that does not have a recorded time stamp indicating the latest modification.

## Supported and Verified MIBs

Table 3-1 lists the MIBs that are *supported* and *verified* in the following Cisco IOS release. The table lists the MIBs, corresponding notification name, and applicable MIB versions.

**Table 3-1** Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
BGP4-MIB (RFC 1657)	bgpEstablished	9405050000Z
	bgpBackwardTransition	
CISCO-AAA-SERVER-MIB	casServerStateChange	200001200000Z
CISCO-AAA-SESSION-MIB		200603210000Z
CISCO-ADSL-LINE-MIB		
CISCO-ATM-EXT-MIB		200301060000Z
CISCO-BGP4-MIB	cbgpFsmStateChange	200302240000Z
	cbgpBackwardTransition	
	cbgpPrefixThresholdExceeded	
	cbgpPrefixThresholdClear	
	cbgpPeer2EstablishedNotification	
	cbgpPeer2BackwardTransNotification	
	cbgpPeer2FsmStateChange	
	cbgpPeer2BackwardTransition	
	cbgpPeer2PrefixThresholdExceeded	
cbgpPeer2PrefixThresholdClear		

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
CISCO-BULK-FILE-MIB	cbfDefineFileCompletion	200108220000Z
CISCO-CBP-TARGET-MIB	–	200605240000Z
CISCO-CDP-MIB	–	200503210000Z
CISCO-CEF-MIB	cefResourceFailure cefPeerStateChange cefPeerFIBStateChange cefInconsistencyDetection	200601300000Z
CISCO-CLASS-BASED-QOS-MIB	–	200901260000Z
CISCO-CONFIG-COPY-MIB	ccCopyCompletion	200403170000Z
CISCO-CONFIG-MAN-MIB	ciscoConfigManEvent ccmCLIRunningConfigChanged ccmCTIDRolledOver	200608220000Z
CISCO-CONTEXT-MAPPING-MIB	–	200503170000Z
CISCO-DATA-COLLECTION-MIB	cdcVFileCollectionError cdcFileXferComplete	200210300530Z
CISCO-EMBEDDED-EVENT-MGR-MIB	cEventManagerServerEvent cEventManagerPolicyEvent	200304160000Z
CISCO-ENHANCED-MEMPOOL-MIB	cempMemBufferNotify	200302240000Z <sup>1</sup>
CISCO-ENTITY-ALARM-MIB	ceAlarmAsserted ceAlarmCleared	9907062150Z
CISCO-ENTITY-EXT-MIB	–	200811240000Z
CISCO-ENTITY-FRU-CONTROL-MIB	cefcModuleStatusChange cefcPowerStatusChange cefcFRUInserted cefcFRURemoved cefcUnrecognizedFRU cefcFanTrayStatusChange	201112220000Z
CISCO-ENTITY-SENSOR-MIB	entSensorThresholdNotification	200601010000Z
CISCO-ENTITY-VENDORTYPE- OID-MIB	–	200505050930Z
CISCO-ETHERLIKE-EXT-MIB	–	201006040000Z
CISCO-EVC-MIB	cevcEvcCreationNotification cevcEvcDeletionNotification cevcEvcStatusChangedNotification	200805010000Z

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
CISCO-FLASH-MIB	ciscoFlashCopyCompletionTrap ciscoFlashPartitioningCompletionTrap ciscoFlashMiscOpCompletionTrap ciscoFlashDeviceChangeTrap ciscoFlashDeviceInsertedNotif ciscoFlashDeviceRemovedNotif ciscoFlashDeviceInsertedNotifRev1 ciscoFlashDeviceRemovedNotifRev1	200403180000Z
CISCO-FTP-CLIENT-MIB	–	9710091700Z
CISCO-HSRP-EXT-MIB	–	9808030000Z
CISCO-HSRP-MIB	cHsrpStateChange	9808030000Z
CISCO-IETF-FRR-MIB	cmplsFrrProtected	200211051200Z
CISCO-IETF-ISIS-MIB	ciiDatabaseOverload ciiManualAddressDrops ciiCorruptedLSPDetected ciiAttemptToExceedMaxSequence ciiIDLenMismatch ciiMaxAreaAddressesMismatch ciiOwnLSPPurge ciiSequenceNumberSkip ciiAuthenticationTypeFailure ciiAuthenticationFailure ciiVersionSkew ciiAreaM	200508161200Z
CISCO-IETF-PPVPN-MPLS-VPN-MIB	cMplsNumVrfRouteMaxThreshCleared	200304171200Z
CISCO-IETF-PW-ENET-MIB	–	200209221200Z
CISCO-IETF-PW-MIB	cpwVcDown cpwVcUp	200403171200Z
CISCO-IETF-PW-MPLS-MIB	–	200302261200Z
CISCO-IF-EXTENSION-MIB	–	200311140000Z
CISCO-IGMP-FILTER-MIB	–	200111080000Z
CISCO-IMAGE-MIB	–	9508150000Z
CISCO-IMAGE-LICENSE-MGMT-MIB	cilmBootImageLevelChanged	200710160000Z
CISCO-IP-LOCAL-POOL-MIB	ciscoIpLocalPoolInUseAddrNoti	200304032000Z

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
CISCO-IPMROUTE-MIB	ciscoIpMRouteMissingHeartBeats	200503070000Z
CISCO-IPSEC-FLOW-MONITOR-MIB	cikeTunnelStart cikeTunnelStop cikeSysFailure cikeCertCrIFailure cikeProtocolFailure cikeNoSa cipSecTunnelStart cipSecTunnelStop cipSecSysFailure cipSecSetUpFailure cipSecEarlyTunTerm cipSecProtocolFailure cipSecNoSa	200010131800Z
CISCO-IPSEC-MIB	cipsIsakmpPolicyAdded cipsIsakmpPolicyDeleted cipsCryptomapAdded cipsCryptomapDeleted cipsCryptomapSetAttached cipsCryptomapSetDetached cipsTooManySAs	200008071139Z
CISCO-IPSEC-POLICY-MAP-MIB	–	200008171257Z
CISCO-IP-URPF-MIB	cipUrpIfDropRateNotify	200411120000Z

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
<a href="#">CISCO-LICENSE-MGMT-MIB</a>	clmgmtLicenseExpired clmgmtLicenseExpiryWarning clmgmtLicenseUsageCountExceeded clmgmtLicenseUsageCountAboutToExceed clmgmtLicenseInstalled clmgmtLicenseCleared clmgmtLicenseRevoked clmgmtLicenseEULAAccepted clmgmtLicenseNotEnforced clmgmtLicenseSubscriptionExpiryWarning clmgmtLicenseSubscriptionExtExpiryWarning clmgmtLicenseSubscriptionExpired clmgmtLicenseEvalRTUTransitionWarning clmgmtLicenseEvalRTUTransition	201104190000Z
<a href="#">CISCO-MVPN-MIB</a>	ciscoMvpnMvrfChange	200402231200Z
<a href="#">CISCO-NETFLOW-MIB</a>	–	200604200000Z
<a href="#">CISCO-OSPF-MIB</a> (draft-ietf-ospf-mib-update-05)	–	200307180000Z
<a href="#">CISCO-OSPF-TRAP-MIB</a> (draft-ietf-ospf-mib-update-05)	cospfIfConfigError cospfVirtIfConfigError cospfTxRetransmit cospfVirtIfTxRetransmit cospfOriginateLsa cospfMaxAgeLsa cospfNssaTranslatorStatusChange cospfShamLinkStateChange cospfShamLinksStateChange cospfShamLinkNbrStateChange cospfShamLinkConfigError cospfShamLinkAuthFailure cospfShamLinkRxBadPacket cospfShamLinkTxRetransmit	200307180000Z



Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
CISCO-PIM-MIB	ciscoPimInterfaceUp ciscoPimInterfaceDown ciscoPimRPMappingChange ciscoPimInvalidRegister ciscoPimInvalidJoinPrune	200011020000Z
CISCO-PING-MIB	ciscoPingCompletion	200108280000Z
CISCO-PPPOE-MIB	cPppoeSystemSessionThresholdTrap cPppoeVcSessionThresholdTrap	200102200000Z
CISCO-PROCESS-MIB	cpmCPURisingThreshold cpmCPUFallingThreshold	201005060000Z
CISCO-PRODUCTS-MIB	–	200505051930Z
CISCO-QINQ-VLAN-MIB	–	200411290000Z
CISCO-RTTMON-MIB	rttMonConnectionChangeNotification rttMonTimeoutNotification rttMonThresholdNotification rttMonVerifyErrorNotification rttMonNotification rttMonLpdDiscoveryNotification rttMonLpdGrpStatusNotification	200701260000Z
CISCO-SYSLOG-MIB	clogMessageGenerated	9508070000Z
CISCO-UNIFIED-FIREWALL-MIB	–	200509220000Z
CISCO-VLAN-IFTABLE-RELATIONSHIP-MIB	–	9904010530Z
CISCO-VPDN-MGMT-MIB	cvpdnNotifSession cvpdnTrapDeadcacheEvent	200601200000Z
CISCO-VOICE-DIAL-CONTROL-MIB	cvdcFallbackNotification	200905070000Z
DS1-MIB (RFC 2495)	dsx1LineStatusChange	9808011830Z
DS3-MIB (RFC 2496)	dsx3LineStatusChange	9808012130Z
ENTITY-MIB (RFC 4133)	entConfigChange	200508100000Z
ENTITY-SENSOR-MIB (RFC 3433)	–	200212160000Z
ENTITY-STATE-MIB	entStateOperEnabled entStateOperDisabled	200511220000Z

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
NotePower supply and fan alarms are generated on either the Power Entry Module or Fan Tray module. Therefore no alarm is generated on the entStateAlarm associated with either the power supply or the fan.	–	200309190000Z
ETHERLIKE-MIB (RFC 3635)	–	200309190000Z
EVENT-MIB (RFC 2981)	mteTriggerFired mteTriggerRising mteTriggerFalling mteTriggerFailure mteEventSetFailure	200010160000Z
IF-MIB (RFC 2863)	linkDown linkUp	9611031355Z
IGMP-STD-MIB (RFC 2933)	–	200009280000Z
IP-FORWARD-MIB (RFC 4292)	–	200602010000Z
IP-MIB (RFC 4293)	–	200602020000Z
IPMROUTE-STD-MIB (RFC 2932)	–	200009220000Z
MPLS-L3VPN-STD-MIB (RFC 4382)	mplsL3VpnVrfUp mplsL3VpnVrfDown mplsL3VpnVrfRouteMidThreshExceeded mplsL3VpnVrfNumVrfRouteMaxThreshExceeded mplsL3VpnNumVrfSecIllglLblThrshExcd mplsL3VpnNumVrfRouteMaxThreshCleared	200601230000Z
MPLS-LDP-GENERIC-STD-MIB (RFC 3815)	–	200406030000Z
MPLS-LDP-STD-MIB (RFC 3815)	mplsLdpInitSessionThresholdExceeded mplsLdpPathVectorLimitMismatch mplsLdpSessionUp mplsLdpSessionDown	200406030000Z
MPLS-LSR-STD-MIB (RFC 3813)	mplsXCUp mplsXCDown	200406030000Z
MPLS-TE-MIB	mplsTunnelUp mplsTunnelDown mplsTunnelRerouted	200011211200Z

Table 3-1 Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
MPLS-VPN-MIB	mplsVrfIfUp mplsVrfIfDown mplsNumVrfRouteMidThreshExceeded mplsNumVrfRouteMaxThreshExceeded mplsNumVrfSecIllegalLabelThreshExceeded	200110151200Z
MSDP-MIB	msdpEstablished msdpBackwardTransition	9912160000Z
NHRP-MIB	–	9908260000Z
NOTIFICATION-LOG-MIB (RFC 3014)	–	200011270000Z
OLD-CISCO-SYS-MIB	–	
OSPF-MIB (RFC 1850)	–	9501201225Z
OSPF-TRAP-MIB (RFC 1850)	ospfIfStateChange ospfVirtIfStateChange ospfNbrStateChange ospfVirtNbrStateChange ospfIfConfigError ospfVirtIfConfigError ospfIfAuthFailure ospfVirtIfAuthFailure ospfIfRxBadPacket ospfVirtIfRxBadPacket ospfTxRetransmit ospfVirtIfTxRetransmit ospfOriginate	9501201225Z
PIM-MIB (RFC 2934)	pimNeighborLoss	200009280000Z
RFC1213-MIB	–	UNKNOWN
RFC2982	–	UNKNOWN
RMON-MIB (RFC 1757)	–	9606111939Z
RSVP-MIB	newFlow lostFlow	9808251820Z
SNMP-COMMUNITY-MIB (RFC 2576)	–	UNKNOWN
SNMP-FRAMEWORK-MIB (RFC 2571)	–	9901190000Z
SNMP-MPD-MIB (RFC 2572)	–	9905041636Z

**Table 3-1** Supported and Verified Cisco 1100 Series ISR MIBs in the Cisco 1100 Series ISR Image

MIB	Notification Name	Revision ID
<a href="#">SNMP-NOTIFICATION-MIB (RFC 2573)</a>	–	9808040000Z
<a href="#">SNMP-PROXY-MIB (RFC 2573)</a>	–	9808040000Z
<a href="#">SNMP-TARGET-MIB (RFC 2573)</a>	–	9808040000Z
<a href="#">SNMPv2-MIB (RFC 1907)</a>	coldStart warmStart linkDown linkUp authenticationFailure egpNeighborLoss	9511090000Z
<a href="#">SNMP-VIEW-BASED-ACM-MIB (RFC 2575)</a>	–	9901200000Z
<a href="#">CISCO-SONET-MIB</a>	–	9810190000Z
<a href="#">TCP-MIB (RFC 4022)</a>	–	200502180000Z
<a href="#">TUNNEL-MIB (RFC 4087)</a>	–	200505160000Z
<a href="#">UDP-MIB (RFC 4113)</a>	–	200505200000Z
<a href="#">VRRPV3-MIB (RFC 6527)</a>	vrrpv3NewMaster vrrpv3ProtoError	201202120000Z

1. For Release 02.03.02, the version for CISCO-ENHANCED-MEMPOOL-MIB is 200812050000Z.

## Supported and Unverified MIBs

Table 3-2 lists the MIBs, notification name, and versions in the routers image that are *supported* and *unverified* in the following Cisco IOS release.

**Table 3-2** Supported and Unverified MIBs in your router Image

MIB	Notification Name	Revision ID
<a href="#">CISCO-DIAL-CONTROL-MIB</a>	–	200505260000Z
<a href="#">CISCO-DYNAMIC-TEMPLATE-MIB</a>	–	200709060000Z
<a href="#">CISCO-EIGRP-MIB</a>	–	200411160000Z
<a href="#">CISCO-ENTITY-PERFORMANCE-MIB</a>	–	201205150000Z
<a href="#">CISCO-FRAME-RELAY-MIB</a>	–	200010130000Z
<a href="#">CISCO-IETF-BFD-MIB</a>	ciscoBfdSessUp ciscoBfdSessDown	201104160000Z
<a href="#">CISCO-IP-TAP-MIB</a>	–	200403110000Z
<a href="#">CISCO-LAG-MIB</a>	–	–

Table 3-2 Supported and Unverified MIBs in your router Image (continued)

MIB	Notification Name	Revision ID
CISCO-NBAR-PROTOCOL-DISCOVERY-MIB	–	200208160000Z
CISCO-RADIUS-EXT-MIB	–	201005250000Z
CISCO-RTTMON-IP-EXT-MIB	–	200608020000Z
CISCO-SESS-BORDER-CTRLR-CALL-STATS-MIB	–	200808270000Z
CISCO-SESS-BORDER-CTRLR-EVENT-MIB	csbAlarmSubsystem csbAlarmSeverity csbAlarmID csbAlarmTime csbSBCServiceName csbDynamicBlackListSubFamily csbDynamicBlackListVpnId csbDynamicBlackListAddressType csbDynamicBlackListAddress csbDynamicBlackListTransportType csbDynamicBlackListPortNumber csbDynamicBlackListSrcBlocked csbAlarmDescription	200808270000Z
CISCO-SESS-BORDER-CTRLR-STATS-MIB	–	201009150000Z
CISCO-SUBSCRIBER-SESSION-MIB	csbJobFinishedNotify	200709060000Z
CISCO-SIP-UA-MIB	–	200402190000Z
CISCO-TAP2-MIB	ciscoTap2MIBActive ciscoTap2MediationTimedOut ciscoTap2MediationDebug ciscoTap2StreamDebug ciscoTap2Switchover	200611270000Z
CISCO-UBE-MIB	–	201011290000Z
CISCO-USER-CONNECTION-TAP-MIB	–	200708090000Z
CISCO-VOICE-COMMON-DIAL-CONTROL-MIB	–	200903180000Z
CISCO-VOIP-TAP-MIB	–	200910010000Z
DIAL-CONTROL-MIB (RFC 2128)	dialCtlPeerCallInformation dialCtlPeerCallSetup	9609231544Z
EXPRESSION-MIB	–	9802251700Z

Table 3-2 Supported and Unverified MIBs in your router Image (continued)

MIB	Notification Name	Revision ID
FRAME-RELAY-DTE-MIB (RFC1315-MIB)	–	9511170836Z
HC-ALARM-MIB	–	200212160000Z

## Unsupported MIBs

Table 3-3 lists the MIBs, notification name, and versions in the Cisco 1100 Series Integrated Services Router image that are *unsupported* in the following Cisco IOS release.

Table 3-3 Unsupported MIBs in your router Image

MIB	Notification Name	Revision ID
ATM-ACCOUNTING-INFORMAT ION-MIB	–	9711050000Z
ATM-FORUM-ADDR-REG-MIB	–	9606200322Z
ATM-FORUM-MIB	–	9606200322Z
ATM-SOFT-PVC-MIB	atmSoftPvcCallFailuresTrap	9703010000Z
ATM-TRACE- MIB	–	UNKNOWN
CISCO-802-TAP-MIB	–	200607100000Z
CISCO-ATM2-MIB	–	9803040000Z
CISCO-ATM-CONN-MIB	–	200108060000Z

Table 3-3 Unsupported MIBs in your router Image (continued)

MIB	Notification Name	Revision ID
CISCO-ATM-PVCTRAP-EXTN-MIB	catmIntfPvcUpTrap	200303240000Z
	catmIntfPvcOAMFailureTrap	
	catmIntfPvcSegCCOAMFailureTrap	
	catmIntfPvcEndCCOAMFailureTrap	
	catmIntfPvcAISRDIOAMFailureTrap	
	catmIntfPvcAnyOAMFailureTrap	
	catmIntfPvcOAMRecoverTrap	
	catmIntfPvcSegCCOAMRecoverTrap	
	catmIntfPvcEndCCOAMRecoverTrap	
	catmIntfPvcAISRDIOAMRecoverTrap	
	catmIntfPvcAnyOAMRecoverTrap	
	catmIntfPvcUp2Trap	
	catmIntfPvcDownTrap	
	catmIntfPvcSegAISRDIFailureTrap	
	catmIntfPvcEndAISRDIFailureTrap	
	catmIntfPvcSegAISRDIREcoverTrap	
catmIntfPvcEndAISRDIREcoverTrap		
CISCO-ATM-QOS-MIB	–	200206100000Z
CISCO-ATM-RM-MIB	–	200101290000Z
CISCO-ATM-TRAFFIC-MIB	–	9705290000Z
CISCO-ADSL-LINE-MIB	–	200309220000Z
CISCO-CALL-APPLICATION-MIB	–	9909220000Z
CISCO-ENHANCED-IMAGE-MIB	–	200501060000Z
CISCO-ENTITY-ASSET-MIB	–	200207231600Z
CISCO-ENTITY-QFP-MIB	–	201205150000Z
CISCO-IETF-ATM2-PVCTRAP-MIB	atmIntfPvcFailuresTrap	9802030000Z
CISCO-IETF-NAT-MIB	–	200103010000Z
CISCO-IETF-PW-ATM-MIB	–	200504191200Z
CISCO-IETF-PW-FR-MIB	–	200312160000Z
CISCO-IETF-PW-TDM-MIB	–	200607210000Z
CISCO-LAG-MIB	–	200212130000Z

Table 3-3 Unsupported MIBs in your router Image (continued)

MIB	Notification Name	Revision ID
CISCO-RF-MIB	ciscoRFSwactNotif ciscoRFProgressionNotif ciscoRFIssuStateNotifRev1	200803180000Z
CISCO-SLB-EXT-MIB	cslbxFtStateChange	200302111000Z
CISCO-SLB-MIB	ciscoSlbVirtualStateChange ciscoSlbRealStateChange	200203180000Z
CISCO-TAP-MIB	cTapMIBActive, cTapMediationTimedOut cTapMediationDebug cTapStreamIpDebug	200401090000Z
CISCO-VLAN-MEMBERSHIP-MIB	vmVmmpsChange	200404070000Z
CISCO-VOICE-ANALOG-IF-MIB	–	200510030000Z
CISCO-VOICE-IF-MIB	–	9803060000Z
NotePower supply and fan alarms are generated on either the Power Entry Module or Fan Tray module. Therefore no alarm is generated on the entStateAlarm associated with either the power supply or the fan.		200309190000Z
IEEE8023-LAG-MIB	–	200006270000Z
OLD-CISCO-CHASSIS-MIB	–	UNKNOWN

## ATM-ACCOUNTING-INFORMATION-MIB

The ATM-ACCOUNTING-INFORMATION-MIB contains objects to manage accounting information applicable to ATM connections.



Note

This MIB is not supported on Cisco 1100 Series ISR.

## ATM-FORUM-ADDR-REG-MIB

The ATM-FORUM-ADDR-REG-MIB contains objects to manage information, such as ATM user-network interface (UNI) addresses and ports. This MIB also contains ATM address registration administration information.



Note

This MIB is not supported on Cisco 1100 Series ISR.



## ATM-FORUM-MIB

The ATM-FORUM-MIB contains ATM object definitions and object identifiers (OIDs).



Note

---

This MIB is not supported on Cisco 1100 Series ISR.

---

## ATM-SOFT-PVC-MIB

The ATM-SOFT-PVC-MIB contains ATM Forum definitions of managed objects for ATM Soft Permanent Virtual Circuits.



Note

---

This MIB is not supported on Cisco 1100 Series ISR.

---

## ATM-TRACE- MIB

The ATM-TRACE-MIB is a MIB module for ATM path and connection trace.



Note

---

This MIB is not supported on Cisco 1100 Series ISR.

---

## BGP4-MIB (RFC 1657)

The BGP4-MIB (RFC 1657) provides access to the implementation information for the Border Gateway Protocol (BGP). The MIB provides:

- BGP configuration information
- Information about BGP peers and messages exchanged within
- Information about the advertised networks

## CISCO-802-TAP-MIB

The CISCO-802-TAP-MIB contains object to manage Cisco intercept feature for 802 streams (IEEE 802 intercept, layer 2). This MIB is used along with CISCO-TAP2-MIB to intercept 802 traffic.

## CISCO-AAA-SERVER-MIB

The CISCO-AAA-SERVER-MIB contains objects to manage information such as authentication, authorization, and accounting (AAA) servers within the router and external to the router. This MIB provides:


- Configuration information for AAA servers, including identities of external AAA servers

- Statistics for AAA functions
- Status (state) information for AAA servers

## MIB Constraints

The configuration objects in the MIB are read-only. To configure AAA servers, use the CLI commands **aaa new-model**, **aaa authentication ppp**, **aaa authorization**, **aaa accounting**, and **radius-server host**. [Table 3-4](#) lists the constraints that the router places on the objects in the CISCO-AAA-SERVER-MIB.

*Table 3-4 CISCO-AAA-SERVER-MIB Constraints*

MIB Object	Notes
<b>casConfigTable</b> <ul style="list-style-type: none"> <li>• casAddress</li> <li>• casAuthenPort</li> <li>• casAcctPort</li> <li>• casKey</li> <li>• casConfigRowStatus</li> </ul>	<p>Read only.</p> <p>Read only. The default value is 1645.</p> <p>Read only. The default value is 1646.</p> <p>Read only. The value is shown as " " (null string) for security reasons.</p> <p>Read only.</p>
<b>casStatisTable</b> <ul style="list-style-type: none"> <li>• casAuthorTable</li> <li>• casAuthorRequest</li> <li>• casAuthorRequestTimeouts</li> <li>• casAuthorUnexpectedResponses</li> <li>• casAuthorServerErrorResponses</li> <li>• casAuthorIncorrectResponses</li> <li>• casAuthorResponseTime</li> <li>• casAuthorTransactionSuccesses</li> <li>• casAuthorTransactionFailures</li> </ul>	<p>For RADIUS servers, the value of these attributes is always 0. Only TACACS+ servers can have nonzero values.</p> <p> <b>Note</b> RADIUS servers do not make authorization requests.</p>

## CISCO-AAA-SESSION-MIB

The CISCO-AAA-SESSION-MIB contains information about accounting sessions based on authentication, authorization, and accounting (AAA) protocols.

## CISCO-ADSL-LINE-MIB

The MIB module defining objects for the management of a pair of ADSL modems at each end of the ADSL line. ADSL lines may support optional Fast or Interleaved channels.

### MIB Constraints

Table 3-5 Cisco-ADSL-Line-MIB Constraints

MIB Object	Notes
<b>adslLineTable</b> <ul style="list-style-type: none"> <li>• adslLineSpecific</li> <li>• adslLineConfProfile</li> <li>• adslLineAlarmConfProfile</li> </ul>	Not Supported Not Supported Not Supported
<b>adslAtucPhysTable</b> <ul style="list-style-type: none"> <li>• adslAtucInvSerialNumber</li> <li>• adslAtucCurrStatus</li> </ul>	Not Supported Not Supported
<b>adslAturPhysTable</b> <ul style="list-style-type: none"> <li>• adslAturCurrStatus</li> </ul>	Not Supported
<b>adslAtucChanTable</b> <ul style="list-style-type: none"> <li>• adslAtucChanInterleaveDelay</li> <li>• adslAtucChanPrevTxRate</li> <li>• adslAtucChanCrcBlockLength</li> </ul>	Not Supported Not Supported Not Supported
<b>adslAturChanTable</b> <ul style="list-style-type: none"> <li>• adslAturChanInterleaveDelay</li> <li>• adslAturChanPrevTxRate</li> <li>• adslAturChanCrcBlockLength</li> </ul>	Not Supported Not Supported Not Supported

Table 3-5 Cisco-ADSL-Line-MIB Constraints (continued)

MIB Object	Notes
<b>adslAtucPerfDataTable</b>	Not Supported
• adslAtucPerfValidIntervals	Not Supported
• adslAtucPerfInvalidIntervals	Not Supported
• adslAtucPerfCurr15MinTimeElapsed	Not Supported
• adslAtucPerfCurr15MinLols	Not Supported
• adslAtucPerfCurr1DayTimeElapsed	Not Supported
• adslAtucPerfCurr1DayLols	Not Supported
• adslAtucPerfPrev1DayMoniSecs	Not Supported
• adslAtucPerfPrev1DayLofs	Not Supported
• adslAtucPerfPrev1DayLoss	Not Supported
• adslAtucPerfPrev1DayLols	Not Supported
• adslAtucPerfPrev1DayLprs	Not Supported
• adslAtucPerfPrev1DayESs	Not Supported
• adslAtucPerfPrev1DayInits	Not Supported
<b>adslAturPerfDataTable</b>	Not Supported
• adslAturPerfValidIntervals	Not Supported
• adslAturPerfInvalidIntervals	Not Supported
• adslAturPerfCurr15MinTimeElapsed	Not Supported
• adslAturPerfCurr1DayTimeElapsed	Not Supported
• adslAturPerfPrev1DayMoniSecs	Not Supported
• adslAturPerfPrev1DayLofs	Not Supported
• adslAturPerfPrev1DayLoss	Not Supported
• adslAturPerfPrev1DayLprs	Not Supported
• adslAturPerfPrev1DayESs	Not Supported
<b>adslAtucIntervalTable</b>	Not Supported
<b>adslAturIntervalTable</b>	Not Supported

Table 3-5 Cisco-ADSL-Line-MIB Constraints (continued)

MIB Object	Notes
<b>adslAtucChanPerfDataTable</b> <ul style="list-style-type: none"> <li>• adslAtucChanReceivedBlks</li> <li>• adslAtucChanTransmittedBlks</li> <li>• adslAtucChanPerfValidIntervals</li> <li>• adslAtucChanPerfInvalidIntervals</li> <li>• adslAtucChanPerfCurr15MinTimeElapsed</li> <li>• adslAtucChanPerfCurr15MinReceivedBlks</li> <li>• adslAtucChanPerfCurr15MinTransmittedBlks</li> <li>• adslAtucChanPerfCurr1DayTimeElapsed</li> <li>• adslAtucChanPerfCurr1DayReceivedBlks</li> <li>• adslAtucChanPerfCurr1DayUncorrectBlks</li> <li>• adslAtucChanPerfPrev1DayMoniSecs</li> <li>• adslAtucChanPerfPrev1DayReceivedBlks</li> <li>• adslAtucChanPerfPrev1DayTransmittedBlks</li> </ul>	Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported
<b>adslAturChanPerfDataTable</b> <ul style="list-style-type: none"> <li>• adslAturChanReceivedBlks</li> <li>• adslAturChanTransmittedBlks</li> <li>• adslAturChanPerfValidIntervals</li> <li>• adslAturChanPerfInvalidIntervals</li> <li>• adslAturChanPerfCurr15MinTimeElapsed</li> <li>• adslAturChanPerfCurr15MinReceivedBlks</li> <li>• adslAturChanPerfCurr15MinTransmittedBlks</li> <li>• adslAturChanPerfCurr1DayTimeElapsed</li> <li>• adslAturChanPerfCurr1DayReceivedBlks</li> <li>• adslAturChanPerfCurr1DayTransmittedBlks</li> <li>• adslAturChanPerfPrev1DayMoniSecs</li> <li>• adslAturChanPerfPrev1DayReceivedBlks</li> <li>• adslAturChanPerfPrev1DayTransmittedBlks</li> <li>• adslAturChanPerfPrev1DayCorrectedBlks</li> <li>• adslAturChanPerfPrev1DayUncorrectBlks</li> </ul>	Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported Not Supported
<b>adslAtucChanIntervalTable</b> <ul style="list-style-type: none"> <li>• adslAtucChanIntervalNumber</li> <li>• adslAtucChanIntervalReceivedBlks</li> <li>• adslAtucChanIntervalTransmittedBlks</li> </ul>	Not Supported Not Supported Not Supported

Table 3-5 Cisco-ADSL-Line-MIB Constraints (continued)

MIB Object	Notes
<b>adslAturChanIntervalTable</b>	Not Supported
<ul style="list-style-type: none"> <li>adslAturChanIntervalNumber</li> <li>adslAturChanIntervalReceivedBlks</li> <li>adslAturChanIntervalTransmittedBlks</li> </ul>	Not Supported
<b>adslLineConfProfileTable</b>	Not Supported
<b>adslLineAlarmConfProfileTable</b>	Not Supported
<b>TRAPS</b>	Not Supported
<ul style="list-style-type: none"> <li>adslAtucPerfLofsThreshTrap</li> <li>adslAtucPerfLossThreshTrap</li> <li>adslAtucPerfLprsThreshTrap</li> <li>adslAtucPerfESsThreshTrap</li> <li>adslAtucRateChangeTrap</li> <li>adslAtucPerfLolsThreshTrap</li> <li>adslAtucInitFailureTrap</li> <li>adslAturPerfLofsThreshTrap</li> <li>adslAturPerfLossThreshTrap</li> <li>adslAturPerfLprsThreshTrap</li> <li>adslAturPerfESsThreshTrap</li> <li>adslAturRateChangeTrap</li> </ul>	Not Supported

## CISCO-ATM-EXT-MIB

The CISCO-ATM-EXT-MIB contains extensions to the Cisco ATM that are used to manage ATM entities. This MIB provides additional AAL5 performance statistics for a virtual channel connection (VCC) on an ATM interface.



Note

This MIB is not supported on Cisco 1100 Series ISR.

## CISCO-ATM-PVCTRAP-EXTN-MIB

The CISCO-ATM-PVCTRAP-EXTN-MIB contains objects to extend the functionality for the ATM-MIB. This MIB provides additional notifications and traps for permanent virtual circuits (PVCs) on your router. The CISCO-ATM-PVCTRAP-EXTN-MIB is supplemented by CISCO-IETF-ATM2-PVCTRAP-MIB.

# CISCO-ATM-QOS-MIB

The CISCO-ATM-QOS-MIB contains objects to manage the following ATM QoS information:

- Traffic shaping on a per-VC basis
- Traffic shaping on a per-VP basis
- Per-VC queuing/buffering.

[Table 3-6](#) lists the constraints that the Cisco 1100 Series ISR places on the objects in the Cisco ATM-QOS-MIB.

*Table 3-6 Cisco-ATM-QOS-MIB Constraints*

MIB Object	Notes
caqVpcParamsTable	Not supported.
caqQueuingParamsTable	Not supported.



**Note**

This MIB is not supported on the Cisco 1100 Series ISR.

## CISCO-ATM2-MIB

The CISCO-ATM2-MIB contains objects to supplement ATM-MIB.



Note

---

The CISCO-ATM2-MIB is not supported for any routers.

---

## CISCO-ATM-CONN-MIB

The CISCO-ATM-CONN-MIB contains objects to extend the VPL/VCL table defined in RFC1695 for ATM switch connection management.



Note

---

The CISCO-ATM-CONN-MIB is not supported for any routers.

---

## CISCO-ATM-RM-MIB

The CISCO-ATM-RM-MIB contains object to provide resource management functionality. This MIB complements standard ATM MIBs for Cisco devices.



Note

---

This CISCO-ATM-RM-MIB is not supported in this release.

---

## CISCO-ATM-TRAFFIC-MIB

The CISCO-ATM-TRAFFIC-MIB contains objects that provide extension to traffic OIDs and variables defined in RFC1695.



Note

---

The CISCO-ATM-TRAFFIC-MIB is not supported in this release.

---

## CISCO-BGP4-MIB

The CISCO-BGP4-MIB provides access to information related to the implementation of the Border Gateway Protocol (BGP). The MIB provides:

- BGP configuration information
- Information about BGP peers and messages exchanged with them
- Information about advertised networks

Beginning with Cisco IOS Release 15.2(1)S, CISCO-BGP4-MIB supports IPv6 addresses in addition to IPv4 addresses. To support IPv6-based peers, four new tables are added in the CISCO-BGP4-MIB:

- cbgpPeer2Table
- cbgpPeer2CapsTable



- cbgpPeer2AddrFamilyTable
- cbgpPeer2AddrFamilyPrefixTable



Note

These four tables have flexible indexing to support both the IPv4 and IPv6 peers.

## MIB Tables

Table 3-7 lists the tables in the CISCO-BGP4-MIB.

Table 3-7 CISCO-BGP4-MIB Tables

MIB Table	Description
<b>cbgpRouteTable</b>	Contains information about the routes to the destination networks from all the BGP4 peers.
<b>cbgpPeerTable</b>	Contains information about the connections with the BGP peers, one entry for each BGP peer.
<b>cbgpPeerCapsTable</b>	Contains information about the capabilities supported by a peer. The capabilities of a peer are received while establishing the BGP connection.
<b>cbgpPeerAddrFamilyTable</b>	Contains information related to the address families supported by a peer.
<b>cbgpPeerAddrFamilyPrefixTable</b>	Contains prefix-related information for the address families supported by a peer.
<b>cbgpPeer2Table</b>	Contains information about the connection with the BGP peers, one entry for each BGP peer. This table supports IPv4 and IPv6 peers.
<b>cbgpPeer2CapsTable</b>	Contains information about the capabilities supported by a BGP peer. The capabilities of a peer are received while establishing the BGP connection. This table supports IPv4 and IPv6 peers.
<b>cbgpPeer2AddrFamilyTable</b>	Contains information related to the address families supported by a BGP peer. This table supports IPv4 and IPv6 peers.
<b>cbgpPeer2AddrFamilyPrefixTable</b>	Contains prefix-related information for the address families supported by a peer. This table supports IPv4 and IPv6 peers.

## CISCO-BGP-POLICY-ACCOUNTING-MIB

The CISCO-BGP-POLICY-ACCOUNTING-MIB contains BGP policy-based accounting information (such as ingress traffic on an interface), which can be used for billing purposes. The MIB provides support for BGP Policy Accounting, which enables you to classify IP traffic into different classes and to maintain statistics for each traffic class.

The MIB contains counts of the number of bytes and packets of each traffic type on each input interface. This information can be used to charge customers according to the route that their traffic travels.

## CISCO-BULK-FILE-MIB

The CISCO-BULK-FILE-MIB contains objects to create and delete files of SNMP data for bulk-file transfer.

### MIB Constraints

Table 3-8 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-BULK-FILE-MIB.

Table 3-8 CISCO-BULK-FILE-MIB Constraints

MIB Object	Notes
<b>cbfDefineFileTable</b> <ul style="list-style-type: none"> <li>cbfDefinedFileStorage</li> </ul>	Only <i>ephemeral</i> type of file storage is supported.  <b>Note</b> The ephemeral bulk file created can be moved to a remote FTP server using CISCO-FTP-CLIENT-MIB.
<ul style="list-style-type: none"> <li>cbfDefinedFileFormat</li> </ul>	Only <i>bulkBinary</i> and <i>bulkASCII</i> file formats are supported.

Notes: The cbfDefineFileTable has objects that are required for defining a bulk file and for controlling its creation. The cbfDefineObjectTable has information regarding the contents (SNMP data) that go into the bulk file.

When an entry in the cbfDefineFileTable and its corresponding entries in the cbfDefineObjectTable are active, then cbfDefineFileNow can then be set to create. This causes a bulkFile to be created as defined in cbfDefineFileTable and it will also create an entry in the cbfStatusFileTable.

## CISCO-CALL-APPLICATION-MIB

The CISCO-CALL-APPLICATION-MIB manages the call applications on a network device. A call application is a software module that processes data, voice, video, and fax calls.



Note

This MIB is not supported on the Cisco 1100 Series ISR

## CISCO-CBP-TARGET-MIB

The CISCO-CBP-TARGET-MIB (common class-based policy) contains objects that provide a mapping of targets to which class-based features, such as QoS are applied. These features can be enabled in a feature-specific manner or through the Class-based Policy Language (CPL).

The CISCO-CBP-TARGET-MIB abstracts the knowledge of the specific types of targets from the class-based policy feature-specific MIB definitions.

## MIB Constraints

The configuration objects in the MIB are read-only. To configure AAA servers, use the CLI commands **aaa new-model**, **aaa authentication ppp**, **aaa authorization**, **aaa accounting**, and **radius-server host**. [Table 3-9](#) lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-CBP-TARGET-MIB.

*Table 3-9 CISCO-CBP-TARGET-MIB Constraints*

MIB Object	Notes
<b>CbpTargetTable</b>	
• ccbptTargetType	Values are: <ul style="list-style-type: none"> <li>• genIf(1)</li> <li>• atmPvc(2)</li> <li>• frDlci(3)</li> <li>• controlPlane(4)</li> </ul>
• ccbptTargetDir	Values are: <ul style="list-style-type: none"> <li>• input(2)</li> <li>• output(3)</li> </ul>
• ccbptPolicyType	Value is always ciscoCbQos(1) to indicate mapping to CLASS-BASED-QOS-MIB.
• ccbptPolicyId	Contains the cbQosPolicyIndex value for this service-policy.
• ccbptTargetStorageType	Value is always volatile(2).
• ccbptTargetStatus	Value is always volatile(1).
• ccbptPolicyMap	Contains the OID for a cbQosPolicyMapName instance.
• ccbptPolicyInstance	Contains the OID for a cbQosIfType instance.

## CISCO-CDP-MIB

The CISCO-CDP-MIB contains objects to manage the Cisco Discovery Protocol (CDP) on the router.

## MIB Constraints

[Table 3-10](#) lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-CDP-MIB.

*Table 3-10 CISCO-CDP-MIB Constraints*

MIB Object	Notes
<b>cdpCtAddressTable</b>	Not supported.
<b>cdpGlobalLastChange</b>	Not supported.
<b>cdpGlobalDeviceIdFormatCpb</b>	Not supported.

Table 3-10 CISCO-CDP-MIB Constraints (continued)

MIB Object	Notes
<code>cdpGlobalDeviceIdFormat</code>	Not supported.
<code>cdpInterfaceExtTable</code>	Not Implemented.

## CISCO-CEF-MIB

The CISCO-CEF-MIB contains objects that manage Cisco Express Forwarding (CEF) technology. CEF is the key data plane forwarding path for Layer 3 IP switching technology. The CISCO-CEF-MIB monitors CEF operational data and provides notification when encountering errors in CEF, through SNMP.

### MIB Constraints

Table 3-11 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-CEF-MIB.

Table 3-11 CISCO-CEF-MIB Constraints

MIB Object	Notes
<code>cefCfgAdminState</code>	Read only. This object is enabled by default.
<code>cefCCCount</code>	Read only.
<code>cefCCPeriod</code>	Read only.
<code>cefCCEnabled</code>	Read only.



Note

Cisco Express Forwarding (CEF) is a high-speed switching mechanism that a router uses to forward packets from the inbound to the outbound interface.



Note

The Cisco 1100 ISR does not support per packet load sharing and therefore does not allow you to set the SNMP object `cefIntLoadSharing` to the value of 1 (per packet). If `cefIntLoadSharing` is set to 1, the SNMP set fails and the `COMMIT_FAILED_ERROR` message is displayed.

## CISCO-CLASS-BASED-QOS-MIB

The CISCO-CLASS-BASED-QOS-MIB provides only read access to quality of service (QoS) configuration information and statistics for Cisco platforms that support the modular Quality of Service command-line interface (modular QoS CLI).

To understand how to navigate the CISCO-CLASS-BASED-QOS-MIB tables, it is important to understand the relationship among different QoS objects. QoS objects consists of:

- Match Statement—The specific match criteria to identify packets for classification purposes.

- **Class Map**—A user-defined traffic class that contains one or more match statements used to classify packets into different categories.
- **Feature Action**—AQoS feature. Features include police, traffic shaping, queueing, random detect, and packet marking. After the traffic has been classified, apply actions to each traffic class.
- **Policy Map**—A user-defined policy that associates a QoS feature action to the user-defined class map.
- **Service Policy**—A policy map that has been attached to an interface.

The MIB uses the following indices to identify QoS features and distinguish among instances of those features:

- **cbQosObjectsIndex**—Identifies each QoS feature on the router.
- **cbQoSConfigIndex**—Identifies a type of QoS configuration. This index is shared by QoS objects that have identical configuration.
- **cbQosPolicyIndex**—Uniquely identifies a service policy.

QoS MIB information is stored in:

- **Configuration instances**—includes all class maps, policy maps, match statements, and feature action configuration parameters. Might have multiple identical instances. Multiple instances of the same QoS feature share a single configuration object, which is identified by **cbQoSConfigIndex**.
- **Runtime Statistics instances**—Includes summary counts and rates by traffic class before and after any configured QoS policies are enforced. In addition, detailed feature-specific statistics are available for select Policy Map features. Each has a unique run-time instance. Multiple instances of a QoS feature have a separate statistics object. Run-time instances of QoS objects are each assigned a unique identifier (**cbQosObjectsIndex**) to distinguish among multiple objects with matching configuration.

## MIB Constraints

Table 3-12 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-CLASS-BASED-QOS-MIB.

Table 3-12 CISCO-CLASS-BASED-QOS-MIB Constraints

MIB Object	Notes
<b>cbQosATMPVCPolicyTable</b>	Not implemented.
<b>cbQosFrameRelayPolicyTable</b>	Not implemented.
<b>cbQosInterfacePolicyTable</b>	Not implemented.
<b>cbQosIPHCCfgTable</b>	Not implemented.
<b>cbQosPoliceColorStatsTable</b>	Not implemented.
<b>cbQosPoliceCfgConformColor</b>	Not implemented.
<b>cbQosPoliceCfgExceedColor</b>	Not implemented.
<b>cbQosQueueingCfgTable</b>	
<ul style="list-style-type: none"> <li>• <b>cbQosQueueingCfgDynamicQNumber</b></li> </ul>	Not implemented.
<b>cbQosREDCfgTable</b>	

Table 3-12 CISCO-CLASS-BASED-QOS-MIB Constraints

MIB Object	Notes
• cbQosREDCfgECNEnabled	Not implemented.
cbQosTableMapCfgTable	Not implemented.
cbQosTableMapSetCfgTable	Not implemented.
cbQosQueueingClassCfgTable	Not implemented.
cbQosMeasureIPSLACfgTable	Not implemented.
cbQosQueueingCfgPriorityLevel	Not implemented.
cbQosREDClassCfgMaxThresholdUnit	Not implemented.
cbQosREDClassCfgMinThresholdUnit	Not implemented.
cbQosTSCfgRate64	Not implemented.
cbQosREDECNMarkPktOverflow	Not implemented.
cbQosREDECNMarkPkt	Not implemented.
cbQosREDECNMarkPkt64	Not implemented.
cbQosREDECNMarkByteOverflow	Not implemented.
cbQosREDECNMarkByte	Not implemented.
cbQosREDECNMarkByte64	Not implemented.
cbQosREDMeanQSizeUnits	Not implemented.
cbQosREDMeanQSize	Not implemented.
cbQosQueueingCfgPrioBurstSize	Not supported.
cbQosQueueingCfgIndividualQSize	Not supported.
cbQosQueueingCfgDynamicQNumber	Not supported.
cbQosQueueingMaxQDepth	Not supported.
cbQosREDECNMarkPktOverflow	Not supported.
cbQosREDECNMarkPkt	Not supported.
cbQosREDECNMarkPkt64	Not supported.
cbQosREDECNMarkByteOverflow	Not supported.
cbQosREDECNMarkByte	Not supported.
cbQosREDECNMarkByte64	Not supported.
cbQosSetCfgL2CosInnerValue	Not supported.
cbQosSetDscpTunnelPkt64	Not supported.
cbQosSetPrecedenceTunnelPkt64	Not supported.
cbQosPoliceCfgConformAction	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.
cbQosPoliceCfgConformSetValue	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.
cbQosPoliceCfgExceedAction	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.

Table 3-12 CISCO-CLASS-BASED-QOS-MIB Constraints

MIB Object	Notes
<b>cbQosPoliceCfgExceedSetValue</b>	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.
<b>cbQosPoliceCfgViolateAction</b>	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.
<b>cbQosPoliceCfgViolateSetValue</b>	This object is deprecated. Refer to equivalent object in cbQosPoliceActionCfgTable.
<b>cbQosPoliceCfgRate</b> <b>cbQosPoliceCfgBurstSize</b> <b>cbQosPoliceCfgExtBurstSize</b>	These objects will have zero value when cir (committed information rate) is configured as percent for policing configuration.

## CISCO-CONFIG-COPY-MIB

The CISCO-CONFIG-COPY-MIB contains objects to copy configuration files on the router. For example, the MIB enables the SNMP agent to copy:

- Configuration files to and from the network
- The running configuration to the startup configuration and startup to running
- The startup or running configuration files to and from a local Cisco IOS file system

## CISCO-CONFIG-MAN-MIB

The CISCO-CONFIG-MAN-MIB contains objects to track and save changes to the router configuration. The MIB represents a model of the configuration data that exists elsewhere in the router and in peripheral devices. Its main purpose is to report changes to the running configuration through the SNMP notification ciscoConfigManEvent.

## CISCO-CONTEXT-MAPPING-MIB

The CISCO-CONTEXT-MAPPING-MIB provides mapping tables that contain the information that a single SNMP agent sometimes needs to support multiple instances of the same MIB. In such cases, network management applications need to know the specific data/identifier values in each context. This is accomplished through the use of multiple SNMP contexts.

## CISCO-DATA-COLLECTION-MIB

The CISCO-DATA-COLLECTION-MIB retrieves data periodically when the data displays as a set of discontinuous rows spread across multiple tables. This MIB facilitates data retrieval of tabular objects. This MIB can be used for performance and accounting purposes, where several row instances of a set of objects are polled over a period of time.

The MIB provides the user a way to specify which objects and which instances are required. In addition the MIB provides two ways in which this data can be retrieved.

## MIB Constraints

Table 3-13 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-DATA-COLLECTION-MIB. Any MIB object not listed in this table is implemented as defined in the MIB.

Table 3-13 CISCO-DATA-COLLECTION-MIB Constraints

MIB Object	Notes
cdcVFileMgmtTable	Not implemented.
cdcDGTable	Not implemented.
cdcDGBaseObjectTable	Not implemented.
cdcDGInstanceTable	Not implemented.

## CISCO-DIAL-CONTROL-MIB

The CISCO-DIAL-CONTROL-MIB module is an extension of RFC 2128, and defines the callHistoryTable that stores information pertaining to earlier calls.

## CISCO-DYNAMIC-TEMPLATE-MIB

The CISCO-DYNAMIC-TEMPLATE-MIB contains objects that describe the dynamic templates. A dynamic template is a set of configuration attributes that a system can dynamically apply to a target.



## MIB Tables

Table 3-14 lists the tables in the CISCO-DYNAMIC-TEMPLATE-MIB.

Table 3-14 CISCO-DYNAMIC-TEMPLATE-MIB Tables

MIB Table	Description
<b>cdtTemplateTable</b>	Lists the dynamic templates maintained by the system, including those that are locally configured on the system, and those that are pushed to the system by external policy servers.
<b>cdtTemplateTargetTable</b>	Lists the targets associated with one or more dynamic templates.
<b>cdtTemplateAssociationTable</b>	Lists the templates associated with each target.
<b>cdtTemplateUsageTable</b>	Contains a list of targets that use each dynamic template.
<b>cdtTemplateCommonTable</b>	Contains attributes that relate to all the dynamic templates.
<b>cdtIfTemplateTable</b>	Contains attributes that relate to the interface configuration.
<b>cdtPppTemplateTable</b>	Contains attributes that relate to PPP connection configuration.
<b>cdtPppPeerIpAddrPoolTable</b>	Contains a prioritized list of named pools for each PPP template.
<b>cdtEthernetTemplateTable</b>	Contains attributes pertaining to the dynamic interfaces initiated on ethernet virtual interfaces or automatically created VLANs.
<b>cdtSrvTemplateTable</b>	Contains attributes pertaining to a service.

## MIB Constraints

Table 3-15 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-DYNAMIC-TEMPLATE-MIB. Any MIB object not listed in this table is implemented as defined in the MIB.

Table 3-15 CISCO-DYNAMIC-TEMPLATE-MIB Constraints

MIB Object	Notes
<b>cdtTemplateTable</b>	
• cdtTemplateName	Read only.
• cdtTemplateUsageCount	Read only.
• cdtTemplateStatus	Read only.
• cdtTemplateStorage	Not implemented.
• cdtTemplateType	Not implemented.
• cdtTemplateSrc	Not implemented.
<b>cdtTemplateAssociationTable</b>	
• cdtTemplateAssociationName	Read only.
<b>cdtTemplateUsageTable</b>	
• cdtTemplateUsageTargetType	Read only.
• cdtTemplateUsageTargetId	Read only.
<b>cdtTemplateTargetTable</b>	Not implemented.

Table 3-15 CISCO-DYNAMIC-TEMPLATE-MIB Constraints (continued)

MIB Object	Notes
cdtTemplateCommonTable	Not implemented.
cdtIfTemplateTable	Not implemented.
cdtPppTemplateTable	Not implemented.
cdtPppPeerIpAddrPoolTable	Not implemented.
cdtEthernetTemplateTable	Not implemented.
cdtSrvTemplateTable	Not implemented.

## CISCO-EIGRP-MIB

The CISCO-EIGRP-MIB contains objects to manage Enhanced Interior Gateway Protocol (EIGRP). EIGRP is a Cisco proprietary distance vector routing protocol, based on the Diffusing Update Algorithm (DUAL). DUAL defines the method to identify loop-free paths through a network.

## CISCO-EMBEDDED-EVENT-MGR-MIB

The CISCO-EMBEDDED-EVENT-MGR-MIB provides descriptions and stores events generated by the Cisco Embedded Event Manager. The Cisco Embedded Event Manager detects hardware and software faults and other events such as OIR for the system.

## CISCO-ENHANCED-IMAGE-MIB

The CISCO-ENHANCED-IMAGE-MIB provides information about events running on the system. The MIB modular operating systems.

## CISCO-ENHANCED-MEMPOOL-MIB

The CISCO-ENHANCED-MEMPOOL-MIB contains objects to monitor memory pools on all of the physical entities on a managed system. It represents the different types of memory pools that may be present in a managed device. Memory use information is provided to users at three different intervals of time: 1 minute, 5 minutes, and 10 minutes. Memory pools can be categorized into two groups, predefined pools and dynamic pools. The following pool types are currently predefined:

- 1:Processor memory
- 2:I/O memory
- 3:PCI memory
- 4:Fast memory
- 5:Multibus memory
- Other memory

Dynamic pools have a pool type value greater than any of the predefined types listed above. Only the processor pool is required to be supported by all devices. Support for other pool types is dependent on the device being managed.

## MIB Constraints

The CISCO-ENHANCED-MEMPOOL-MIB is supported only in the Active RP module. [Table 3-16](#) lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-ENHANCED-MEMPOOL-MIB.

*Table 3-16 CISCO-ENHANCED-MEMPOOL-MIB Constraints*

MIB Object	Notes
<b>cempMemBufferPoolTable</b>	
• cempMemBufferSize	Read only.
• cempMemBufferMin	Read only.
• cempMemBufferMax	Read only.
• cempMemBufferPermanent	Read only.
• cempMemBufferTransient	Read only.
<b>cempMemPoolTable</b>	
• cempMemPoolUsedLowWaterMark	Not Implemented.
• cempMemPoolAllocHit	Not Implemented.
• cempMemPoolAllocMiss	Not Implemented.
• cempMemPoolFreeHit	Not Implemented.
• cempMemPoolFreeMiss	Not Implemented.
• cempMemPoolHCShared	Not Implemented.
• cempMemPoolHCUsedLowWaterMark	Not Implemented.
• cempMemPoolShared	Not Implemented.
• cempMemPoolSharedOvrflw	Not Implemented.
• cempMemPoolUsedLowWaterMarkOvrflw	Not Implemented.
<b>cempMemBufferPoolTable</b>	
• cempMemBufferFreeHit	Not Implemented.
• cempMemBufferFreeMiss	Not Implemented.

## CISCO-ETHRLIKE-EXT-MIB

The CISCO-ETHERLIKE-EXT-MIB defines generic objects for the Ethernet-like network interfaces.

## MIB Constraints

Table 3-37 lists the constraint that the Cisco 1100 Series ISR place on the objects in the CISCO-ETHERLIKE-EXT-MIB.

Table 3-17 CISCO-ETHERLIKE-EXT-MIB Constraint

MIB Object	Notes
ceeDot3PauseExtTable	Not Supported.

## CISCO-ENTITY-ALARM-MIB

The CISCO-ENTITY-ALARM-MIB enables the Cisco 1100 Series ISR to monitor the alarms generated by system components, such as chassis, slots, modules, power supplies, and ports.

## MIB Constraints

Table 3-18 lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-ENTITY-ALARM-MIB.

Table 3-18 CISCO-ENTITY-ALARM-MIB Constraints

MIB Object	Notes
<b>ceAlarmTable</b>	
<ul style="list-style-type: none"> <li>ceAlarmFilterProfile</li> <li>ceAlarmFilterProfileIndexNext</li> </ul>	Not implemented.
<b>ceAlarmFilterProfileTable</b>	Not implemented.
<b>ceAlarmDescrTable</b>	
<ul style="list-style-type: none"> <li>ceAlarmDescrSeverity</li> </ul>	Read only.

The ENTITY-MIB table, entPhysicalTable, identifies the physical system components in the router. The following list describes the table objects that describe the alarms for the CISCO-ENTITY-ALARM-MIB:

- Physical entity—The component in the Cisco 1100 Series ISR that generates the alarm.
- ceAlarmDescrVendorType—The object specifies an identifier (typically an enterprise-specific OID) that uniquely identifies the vendor type of those physical entities to which this alarm description applies.
- Alarm severity—Each alarm type defined by a vendor type and employed by the system is assigned an associated severity:
  - Critical—Indicates a severe, service-affecting condition has occurred and that immediate corrective action is imperative, regardless of the time of day or day of the week. For example, online insertion and removal or loss of signal failure when a physical port link is down.

- Major—Used for hardware or software conditions. Indicates a serious disruption of service or the malfunctioning or failure of important hardware. Requires immediate attention and response of a technician to restore or maintain system stability. The urgency is less than in critical situations because of a lesser effect on service or system performance.
- Minor—Used for troubles that do not have a serious effect on service to customers or for alarms in hardware that are not essential to the operation of the system.
- Info—Notification about a condition that could lead to an impending problem or notification of an event that improves operation.

The syntax values are critical(1), major(2), minor(3), and info(4).

- Alarm description text—Specifies a readable message describing the alarm.
- Alarm type—Identifies the type of alarm that is generated. An arbitrary integer value (0 through 255) that uniquely identifies an event relative to a physical entity in the Cisco 1100 Series ISR.

Table 3-19 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR SFP Container.

Table 3-19 Alarms Supported for Cisco 1100 Series ISR SFP Container

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText	Scenario
SFP container	cevContainerSFP	critical	Transceiver missing	When the interface is <i>not</i> using RJ-45 and is in link down state.
SFP container	cevContainerSFP	info	Transceiver missing	When the interface is configured to use RJ-45 (only applicable to SPA-2X1GE) or is in admin down state.

Table 3-20 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR modules.

Table 3-20 Alarms Supported for the Cisco 1100 Series ISR Modules

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
Modules	cevModuleC111X8PLteEA	major	Unknown state
	cevModuleC111X8PLteLA	major	Boot state
	cevModuleC111X8PNIM	major	Disabled
	cevModuleC111X4PLteEA	critical	Failed
	cevModuleC111X4PLteLA	major	Stopped
	cevModuleC111X4PNIM		
	cevModuleISRAP1100D		

Table 3-21 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR sensors.

Table 3-21 Alarms Supported for Cisco 1100 Series ISR Sensors

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
Sensor	cevSensor	critical	Faulty sensor.
		critical	Reading above normal (Shutdown).
		critical	Reading above normal.
		major	Reading above normal.
		minor	Reading above normal.
		critical	Reading below normal (Shutdown).
		critical	Reading below normal.
		minor	Reading below normal.



**Note**

These alarms are not supported for the module and XCVR sensors. You can use CISCO-ENTITY-SENSOR-MIB to monitor the alarms listed in the Table 3-21.

Table 3-22 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR Network Interface Module (NIM) subslot containers.

**Table 3-22** *Alarms Supported for Cisco 1100 Series ISR Container*

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
NIM Subslot	cevContainerISR1100NIMSlot	critical	Active card removed OIR alarm.
		critical	Card stopped responding.

[Table 3-23](#) lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR USB ports.

**Table 3-23** *Alarms Supported for the Cisco 1100 Series ISR USB Ports*

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
USB port	cevPortUSB	critical	Active card removed OIR alarm.
		critical	Card stopped responding.

[Table 3-24](#) lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR hard disk containers.

**Table 3-24** *Alarms Supported for the Cisco 1100 Series ISR Hard Disk Container*

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
hard disk container	cevContainerHardDiskSlot	major	Hard disk missing.



Table 3-25 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR power supply bay.

*Table 3-25 Alarms Supported for CCisco 1100 Series ISR Power Supply Bay*

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
Power Supply Bay	cevContainerPowerSupply ISR1100 Bay	critical	Power supply/Fan module missing.

Table 3-26 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR RP.

*Table 3-26 Alarms Supported for Cisco 1100 Series ISR RP Module*

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
RP Module	cevModuleC111x4PRP cevModuleC111X8PRP	major	Unknown state.
		major	Boot state.
		major	Disabled.
		critical	Incompatible
		critical	CPLD incompatible
		critical	Active RP CPLD incompatible
		critical	Failed.
		critical	Cutover.
		major	Secondary failure.
		major	Secondary removed.
		major	Secondary not synchronized.
		critical	No working ESP.
major	Hard disk Missing		

Table 3-27 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR Unknown RP Module.

**Table 3-27** Alarms Supported for Cisco 1100 Series ISR Unknown RP Modules

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
RP Module	cevPowerSupplyISR1100Unknown	major	Unknown state.
		major	Boot state.
		major	Disabled.
		critical	Failed.
		critical	Stopped.

Table 3-28 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR Power Supply Module.

**Table 3-28** Alarms Supported for Cisco 1100 Series ISR Power Supply Module

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
Power Supply Modules	cevPowerSupplyISR1100PWR450	critical	Power Supply Failure.
		critical	All Fans Failed.
		critical	Multiple Fan Failures.
		major	Fan 0 Failure.
		major	Fan 1 Failure.
		major	Fan 2 Failure.

Table 3-29 lists the alarm descriptions and severity levels for the Cisco 1100 Series ISR modules.

Table 3-29 Alarms Supported for Cisco 1100 Series ISR Module

Physical Entity	ceAlarmDescVendorType	ceAlarmDescrSeverity	ceAlarmDescrText
Module	cevModuleC111x4PFP	major	Unknown state.
	cevModuleC111X8PFP	major	Boot State.
		major	Disabled.
		critical	Incompatible
		critical	CPLD incompatible
		critical	Active RP CPLD incompatible
		critical	Failed.
		major	Stopped.

## CISCO-ENTITY-ASSET-MIB

The CISCO-ENTITY-ASSET-MIB provides asset tracking information (ceAssetTable) for the physical components in the ENTITY-MIB (RFC 4133) entPhysicalTable.

The ceAssetTable contains an entry (ceAssetEntry) for each physical component on the router. Each entry provides information about the component. The component information includes:

- Orderable part number
- Serial number
- Hardware revision
- Manufacturing assembly number
- Manufacturing revision.

Most physical components are programmed with a standard Cisco-generic ID PROM value that specifies asset information for the component. If possible, the MIB accesses the component's ID PROM information.



Note

The ENTITY-MIB (RFC 4133) contains all the objects defined under the CISCO-ENTITY-ASSET-MIB. Thus, you can use the ENTITY-MIB (RFC 4133) instead of the CISCO-ENTITY-ASSET-MIB.

## CISCO-ENTITY-EXT-MIB

The CISCO-ENTITY-EXT-MIB contains extensions for the processor modules listed in the ENTITY-MIB entPhysicalTable. A processor module is any physical entity that has a CPU, RAM, and NVRAM, and can load a boot image and save a configuration. The extensions in this MIB provide information such as RAM and NVRAM sizes, configuration register settings, and bootload image name for each processor module.

## MIB Constraints

Table 3-30 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-ENTITY-EXT-MIB.

Table 3-30 CISCO-ENTITY-EXT-MIB Constraints

MIB Object	Notes
ceExtConfigRegNext	Read only.
ceExtSysBootImageList	Read only.

## CISCO-ENTITY-FRU-CONTROL-MIB

The CISCO-ENTITY-FRU-CONTROL-MIB contains objects to configure and monitor the status of the field-replaceable units (FRUs) on the Cisco 1100 Series ISR listed in the ENTITY-MIB entPhysicalTable. A FRU is a hardware component (such as a line card and module, fan, or power supply) that can be replaced on site.

## MIB Constraints

Table 3-31 lists the constraints that your router places on the objects in the CISCO-ENTITY-FRU-CONTROL-MIB.

Table 3-31 CISCO-ENTITY-FRU-CONTROL-MIB Constraints

MIB Object	Notes
<b>cefcModuleTable</b>	
<ul style="list-style-type: none"> <li>cefcModuleAdminStatus</li> <li>cefcModuleOperStatus</li> </ul>	<p>Read only.</p> <p>The following values are supported:</p> <ul style="list-style-type: none"> <li>unknown(1)</li> <li>ok(2)</li> <li>boot(5)</li> <li>failed(7)</li> <li>dormant(12)</li> <li>outOfServiceAdmin(13)</li> <li>disabled (3)</li> </ul>
<ul style="list-style-type: none"> <li>cefcModuleLastClearConfigTime</li> <li>cefcModuleStateChangeReasonDescr</li> </ul>	<p>Not implemented.</p> <p>Not implemented.</p>
<b>cefcFRUPowerSupplyGroupTable</b>	Not implemented.
<b>cefcFRUPowerSupplyValueTable</b>	Not implemented.
<b>cefcFRUPowerStatusTable</b>	
<ul style="list-style-type: none"> <li>cefcFRUPowerAdminStatus</li> </ul>	always on(1)

Table 3-31 CISCO-ENTITY-FRU-CONTROL-MIB Constraints (continued)

MIB Object	Notes
<ul style="list-style-type: none"> <li>cefcFRUPowerOperStatus</li> </ul>	The following values are supported: <ul style="list-style-type: none"> <li>always on(2)</li> <li>failed(8)</li> <li>onButFanFail(9)</li> </ul>
<b>cefcFanTrayStatusTable</b> <ul style="list-style-type: none"> <li>cefFanTrayOperStatus</li> </ul>	always up(2)
<b>cefcIntelliModuleTable</b>	Not implemented.
<b>cefcPhysicalTable</b>	Not implemented.
<b>cefcModuleUpTime</b>	Always zero for Hard disk.

## CISCO-ENTITY-PERFORMANCE-MIB

The CISCO-ENTITY-PERFORMANCE-MIB defines objects to monitor the performance of the Crypto ASIC module of the Extended Service Platform (ESP). Performance monitoring includes utilization of resources and I/O rate for packets and bytes.

### MIB Constraints

Table 3-32 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-ENTITY-PERFORMANCE-MIB. These constraints are applicable only for the Crypto ASIC module.

Table 3-32 CISCO-ENTITY-PERFORMANCE-MIB Constraints

MIB Object	Notes
<b>cepEntityTable</b>	Not supported.
<b>cepConfigTable</b> <ul style="list-style-type: none"> <li>CiscoEntPerfType</li> </ul>	Read only. These MIB object values are supported: <ul style="list-style-type: none"> <li>utilization(1)</li> <li>packetInputRate(5) – Mapped to Decrypt Packet Rate (DPR.)</li> <li>packetOutputRate(6) – Mapped to Encrypt Packet Rate (EPR).</li> </ul>
<ul style="list-style-type: none"> <li>cepConfigRisingThreshold</li> <li>cepConfigFallingThreshold</li> <li>cepConfigThresholdNotifEnabled</li> </ul>	Read only. Read only. Read only.
<b>cepEntityIntervalTable</b>	Supports performance monitoring every 15 minutes.

Table 3-32 CISCO-ENTITY-PERFORMANCE-MIB Constraints (continued)

MIB Object	Notes
cepIntervalStatsTable	Supports interval value, fifteenMinutes (3).
cepPerfThreshFallingEvent	Not supported.
cepPerfThreshRisingEvent	Not supported.
cepThresholdNotifEnabled	Read only.

## CISCO-ENTITY-QFP-MIB

The CISCO-ENTITY-QFP-MIB defines objects to manage Quantum Flow Processors (QFP) listed as entPhysicalClass attribute in the entPhysicalTable of ENTITY-MIB. The Quantum Flow Processors (QFP) technology control functions such as packet forwarding via fully integrated and programmable networking chipsets. This MIB module contains objects to monitor various QFP statistics such as system state, processor utilization, and memory.

The processor utilization statistics comprise these attributes:

- Input—Communication channel where packets arrive on the QFP.
- Output—Communication channel where packets exit the QFP.
- Priority—Indicates that the processing priority for the packet is high.
- Non-Priority—Indicates that the processing priority for the packet is low.
- Processing Load—Indicates the percentage of time spent forwarding packets.



Note

QFP entities from an inactive or standby FP are not monitored.

## MIB Tables

Table 3-33 lists the tables in CISCO-ENTITY-QFP-MIB.

Table 3-33 CISCO-ENTITY-QFP-MIB Tables

MIB Table	Description
<b>ceqfpSystemTable</b>	Contains the QFP system information for each QFP physical entity. A separate row is created for each QFP physical entity when a physical entity supporting the QFP system information is detected. If a physical entity supporting the QFP system information is removed, the corresponding row is deleted from the table.
<b>ceqfpUtilizationTable</b>	Contains the utilization statistics for each QFP physical entity. A separate row is created for each QFP physical entity when a physical entity supporting the QFP system information is detected. If a physical entity supporting the QFP system information is removed or the utilization statistics are not received for a specific interval, the corresponding row is deleted from the table. The interval to wait before deleting an entry from this table depends on the supporting device.
<b>ceqfpMemoryResourceTable<sup>1</sup></b>	Contains the memory resources statistics for each QFP physical entity. A separate row is created for each QFP physical entity when a physical entity supporting the QFP system information is detected. If a physical entity supporting the QFP system information is removed or the memory resource statistics are not received for a specific interval, the corresponding row is deleted from the table.
<b>ciscoEntityQfpSystemGroup</b>	Contains objects related to QFP system information.
<b>ciscoEntityQfpUtilizationGroup</b>	Contains objects related to QFP utilization information.
<b>ciscoEntityQfpMemoryResource Group</b>	Contains objects related to QFP memory resource information.
<b>ciscoEntityQfpNotifGroup</b>	Contains QFP notification such as memory resource crossing threshold.
<b>ciscoEntityQfpMemoryResNotif Group</b>	Contains the QFP memory resource notification control object.

1. The physical DRAM memory resource is logically divided into DRAM and IRAM in the CLI, but the `ceqfpMemoryResourceTable` table would show the aggregate of DRAM and IRAM data. The IRAM memory is secondary and is used when DRAM memory is exhausted. The notification is generated whenever the threshold is greater or less than the aggregated value.

## MIB Constraints

Table 3-34 lists the constraints that the Cisco 1100 Series ISR places on the objects in the CISCO-ENTITY-QFP-MIB.

Table 3-34 CISCO-ENTITY-QFP-MIB Constraints

MIB Object	Notes
<b>ciscoEntityQfpMemoryResourceGroup</b>	
<ul style="list-style-type: none"> <li>ceqfpMemoryResRisingThreshold</li> <li>ceqfpMemoryResFallingThreshold</li> </ul>	Read only. Read only.

## CISCO-ENTITY-SENSOR-MIB

The CISCO-ENTITY-SENSOR-MIB contains objects that support the monitoring of sensors. The MIB is applicable to sensors present in various modules. This MIB allows you to monitor sensor values and thresholds on sensors that are discovered by the ENTITY-MIB. The sensor support is provided for the following hardware

- RP
- Transceivers

## MIB Constraints

Table 3-35 lists the constraints that the Cisco 1100 Series ISR places on the CISCO-ENTITY-SENSOR-MIB.

Table 3-35 CISCO-ENTITY-SENSOR-MIB Constraints

MIB Object	Notes
<b>entSensorValueTable</b>	
<ul style="list-style-type: none"> <li>entSensorMeasuredEntity</li> </ul>	Implemented for all sensors except for SPA and transceiver sensors.
<b>entSensorThresholdTable</b>	
<ul style="list-style-type: none"> <li>entSensorThresholdRelation</li> <li>entSensorThresholdSeverity</li> <li>entSensorThresholdValue</li> </ul>	Read only. Read only. Read only.

## MIB Usage Values for Cisco Transceivers

The table in this section lists each type of sensor's value represented in the entSensorValueTable and the entSensorThresholdTable.



Table 3-36 lists CISCO-ENTITY-SENSOR-MIB sensor objects and their usage values for the Cisco 1100 Series Integrated Services Router transceivers in the entSensorValueTable.

Table 3-36 CISCO-ENTITY-SENSOR-MIB Usage Values in the entSensorValueTable for Cisco Transceivers

MIB Sensor Object	Notes
<b>Module Temperature Sensor</b>	
• entSensorType	celsius(8)
• entSensorScale	units(9)
• entSensorPrecision	3
• entSensorStatus	ok(1)
• entSensorValue	Reports most recent measurement seen by the sensor.
• entSensorValueTimeStamp	Value indicates the age of the value reported by entSensorValue object.
• entSensorValueUpdateRate	Value indicates the rate that the agent updates entSensorValue in seconds (for example, 60 seconds).
<b>Tx Supply Voltage Sensor</b>	
• entSensorType	voltsDC(4)
• entSensorScale	milli(8)
• entSensorPrecision	1
• entSensorStatus	ok(1)
• entSensorValue	Reports most recent measurement seen by the sensor.
• entSensorValueTimeStamp	Value indicates the age of the value reported by entSensorValue object.
• entSensorValueUpdateRate	Value indicates the rate that the agent updates entSensorValue in seconds (for example, 60 seconds).
<b>Tx Laser Current Sensor</b>	
• entSensorType	amperes(5)
• entSensorScale	milli(8)
• entSensorPrecision	0
• entSensorStatus	ok(1)
• entSensorValue	Reports most recent measurement seen by the sensor.
• entSensorValueTimeStamp	Value indicates the age of the value reported by entSensorValue object.
• entSensorValueUpdateRate	Value indicates the rate that the agent updates entSensorValue in seconds (for example, 60 seconds).
<b>Transmit Power Sensor (Optical Tx)</b>	
<b>Receive Power Sensor (Optical Rx)</b>	
• entSensorType	dBm(14)
• entSensorScale	units(9)
• entSensorPrecision	0
• entSensorStatus	ok(1)

**Table 3-36** CISCO-ENTITY-SENSOR-MIB Usage Values in the entSensorValueTable for Cisco Transceivers

MIB Sensor Object	Notes
• entSensorValue	Reports most recent measurement seen by the sensor.
• entSensorValueTimeStamp	Value indicates the age of the value reported by entSensorValue object.
• entSensorValueUpdateRate	Value indicates the rate that the agent updates entSensorValue in seconds (for example, 60 seconds).

## CISCO-ENTITY-VENDORTYPE-OID-MIB

The CISCO-ENTITY-VENDORTYPE-OID-MIB defines the object identifiers (OIDs) assigned to various Cisco 1100 Series ISR components. The OIDs in this MIB are used by the entPhysicalTable of the ENTITY-MIB as values for the entPhysicalVendorType field in the entPhysicalTable. Each OID uniquely identifies a type of physical entity.

## CISCO-ETHERLIKE-EXT-MIB

The CISCO-ETHERLIKE-EXT-MIB defines generic objects for the Ethernet-like network interfaces.

### MIB Constraints

[Table 3-37](#) lists the constraint that your router places on the objects in the CISCO-ETHERLIKE-EXT-MIB.

**Table 3-37** CISCO-ETHERLIKE-EXT-MIB Constraint

MIB Object	Notes
ceeDot3PauseExtTable	Not Supported.

## CISCO-EVC-MIB

The CISCO-EVC-MIB defines the managed objects and notifications describing Ethernet Virtual Connections (EVCs).

## MIB Constraints

Table 3-38 lists the constraints that your router places on the objects in the CISCO-EVC-MIB.

Table 3-38 CISCO-EVC-MIB Constraint

MIB Object	Notes
<b>cevcEvcUniTable</b>	Not supported.
<b>cevcEvcActiveUnis</b>	Not supported.
<b>ciscoEvcStatusChangedNotification</b>	Not supported.
<ul style="list-style-type: none"> <li>cevcEvcOperStatus</li> </ul>	Returns unknown as value.

## CISCO-FLASH-MIB

The CISCO-FLASH-MIB contains objects to manage flash cards and flash-card operations.

## MIB Constraints

Table 3-39 lists the constraints that your router places on the objects in the CISCO-FLASH-MIB.

Table 3-39 CISCO-FLASH-MIB Constraints

MIB Object	Notes
<b>ciscoFlashDeviceTable</b>	
<ul style="list-style-type: none"> <li>ciscoFlashDeviceInitTime</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashPhyEntIndex</li> </ul>	Not Implemented.
<b>ciscoFlashPartitionTable</b>	
<ul style="list-style-type: none"> <li>ciscoFlashPartitionFileCount</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashPartitionChecksumAlgorithm</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashPartitionUpgradeMethod</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashPartitionNeedErasure</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashPartitionFileNameLength</li> </ul>	Not Implemented.
<b>ciscoFlashFileTable</b>	
<ul style="list-style-type: none"> <li>ciscoFlashFileChecksum</li> </ul>	Not Implemented.
<ul style="list-style-type: none"> <li>ciscoFlashFileType</li> </ul>	Values not supported: config(2) image(3) crashinfo(5)

**Note**

The index of files stored in USB changes frequently since the files are mounted and unmounted after regular intervals.

**Note**

Once the file is copied successfully via tftp, it takes at least 50 seconds to reflect the correct file size in ciscoFlashFileSize object.

## CISCO-FRAME-RELAY-MIB

The CISCO-FRAME-RELAY-MIB contains Frame Relay information that is specific to Cisco products or that is missing from RFC 1315.

### MIB Constraints

Table 3-40 lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-FRAME-RELAY-MIB. Objects that are not listed in the table are implemented as defined in the MIB.

**Note**

Frame Relay Switched Virtual Circuits (SVCs) are not currently supported on your router.

*Table 3-40 CISCO-FRAME-RELAY-MIB Constraints*

MIB Object	Notes
<b>cfrCircuitTable</b> <ul style="list-style-type: none"> <li>cfrCircuitType</li> </ul>	Supported value is pvc(1).
<b>cfrExtCircuitTable</b> <ul style="list-style-type: none"> <li>cfrExtCircuitMinThroughputOut</li> <li>cfrExtCircuitMinThroughputIn</li> <li>cfrExtCircuitShapeByteLimit</li> <li>cfrExtCircuitShapeInterval</li> <li>cfrExtCircuitShapeByteIncrement</li> <li>cfrExtCircuitShapeActive</li> <li>cfrExtCircuitShapeAdapting</li> </ul>	Supported for QoS. Otherwise value is 0.
<b>cfrMapTable</b> <ul style="list-style-type: none"> <li>cfrMapType</li> </ul>	Values are: <ul style="list-style-type: none"> <li>static(1)</li> <li>dynamic(2)</li> </ul>
<b>cfrSvcTable</b>	Not implemented.

## CISCO-FTP-CLIENT-MIB

The CISCO-FTP-CLIENT-MIB contains objects to invoke File Transfer Protocol (FTP) operations for network management. This MIB has no known constraints and all objects are implemented as defined in the MIB.

## CISCO-HSRP-EXT-MIB

The CISCO-HSRP-EXT-MIB provides an extension to the CISCO-HSRP-MIB which defines the Cisco Hot Standby Router Protocol (HSRP), which is defined in RFC 2281. The extensions cover assigning of secondary IP addresses and modifying an HSRP group's priority.

## CISCO-HSRP-MIB

The CISCO-HSRP-MIB contains objects to configure and manage the Cisco Hot Standby Router Protocol (HSRP), which is defined in RFC 2281.

## CISCO-IETF-ATM2-PVCTRAP-MIB

The CISCO-IETF-ATM2-PVCTRAP-MIB contains objects that supplement the ATM-MIB. This MIB implements the Virtual Channel Link (VCL) section of the IETF document "draft-ietf-atommib-atm2-11.txt," Section 9 ATM Related Trap Support.



Note

---

This MIB is currently not supported for broadband configurations.

---

## CISCO-IETF-BFD-MIB

The CISCO-IETF-BFD-MIB contains managed object definitions for the Bidirectional Forwarding Detection (BFD) Protocol. BFD is a protocol that detects faults in the bidirectional path between two forwarding engines, including interfaces, data links, and to the extent possible, the forwarding engines themselves, with potentially very low latency. It operates independently of media, data protocols, and routing protocols.



Note

---

The CISCO-IETF-BFD-MIB is based on the draft-ietf-bfd-mib-07.txt internet draft.

---

Following is the support information on the Virtual Routing and Forwarding (VRF) context for the MIB:

- The CISCO-IETF-BFD-MIB supports IPv4 and IPv6 in the non-VRF context.
- The CISCO-IETF-BFD-MIB supports IPv4 in the VRF context, and does not support IPv6 in the VRF context.

## CISCO-IETF-FRR-MIB

The CISCO-IETF-FRR-MIB contains managed object definitions for MPLS Fast Reroute (FRR).

## CISCO-IETF-ISIS-MIB

The CISCO-IETF-ISIS-MIB introduces network management support for the IS-IS routing protocol through the use of IS-IS MIB table entries, MIB objects, and MIB trap notification objects. A new CLI is added to enable SNMP notifications for the objects. Notifications are provided for errors and other significant event information for the IS-IS network.

# CISCO-IETF-NAT-MIB

The CISCO-IETF-NAT-MIB contains objects for Network Address Translation (NAT) operations on the router, as defined in RFC 3022. The MIB included objects containing NAT configuration, NAT bindings, and run-time statistics.

The MODULE-IDENTITY for the CISCO-IETF-NAT-MIB is `ciscoIetfNatMIB`, and its top-level OID is 1.3.6.1.4.1.9.10.77 (iso.org.dod.internet.private.enterprises.cisco.ciscoExperiment.ciscoIetfNatMIB).

## MIB Constraints

Table 3-41 lists the CISCO-IETF-NAT-MIB constraints.

*Table 3-41 CISCO-IETF-NAT-MIB Constraints*

MIB Object	Notes
<b>cnatAddrBindTable</b>	Not supported for static binds.
• <code>cnatAddrBindCurrentIdleTime</code>	Not supported.
<b>cnatConfTable</b>	Not Implemented.
<b>cnatConfStaticAddrMapTable</b>	Not Implemented.
<b>cnatConfDynAddrMapTable</b>	Not Implemented.
<b>cnatInterfaceTable</b>	
• <code>cnatInterfaceRealm</code>	Read only.
• <code>cnatInterfaceStorageType</code>	Read only.
• <code>cnatInterfaceStatus</code>	Read only.
<b>cnatAddrBindTable</b>	
• <code>cnatAddrBindDirection</code>	Read only.
• <code>cnatAddrBindConfName</code>	Not Implemented.
• <code>cnatAddrBindSessionCount</code>	Not Implemented.
• <code>cnatAddrBindId</code>	Not Implemented.
<b>cnatAddrPortBindTable</b>	
• <code>cnatAddrPortBindDirection</code>	Not Implemented.
• <code>cnatAddrPortBindConfName</code>	Not Implemented.
• <code>cnatAddrPortBindSessionCount</code>	Not Implemented.
<b>cnatSessionTable</b>	Not Implemented.
<b>cnatAddrMapStatsTable</b>	Not Implemented.
<b>cnatInterfaceStatsTable</b>	Not Implemented.

## CISCO-IETF-PPVPN-MPLS-VPN-MIB

The CISCO-IETF-PPVPN-MPLS-VPN-MIB is an extension of the MPLS-VPN-MIB. It contains a new notification, `mplsNumVrfRouteMaxThreshCleared`, which was added with MPLS-VPN-MIB-DRAFT-05.

## CISCO-IETF-PW-ATM-MIB

The CISCO-IETF-PW-ATM-MIB contains managed object definitions for Pseudo Wire (PW) emulation of ATM over Packet Switched Networks (PSN).

### MIB Constraints

[Table 3-42](#) lists the constraints that your router places on the objects in the CISCO-IETF-PW-ATM-MIB.

*Table 3-42 CISCO-IETF-PW-ATM-MIB Constraints*

MIB Object	Notes
<b>CpwVcAtmPerfEntry</b>	
• <code>cpwAtmCellsReceived</code>	Not supported, returns zero.
• <code>cpwAtmCellsSent</code>	Not supported, returns zero.
• <code>cpwAtmCellsRejected</code>	Not supported, returns zero.
• <code>cpwAtmCellsTagged</code>	Not supported, returns zero.
• <code>cpwAtmHCCellsReceived</code>	Not supported, returns zero.
• <code>cpwAtmHCCellsRejected</code>	Not supported, returns zero.
• <code>cpwAtmHCCellsTagged</code>	Not supported, returns zero.
• <code>cpwAtmAvgCellsPacked</code>	Not supported, returns zero.

## CISCO-IETF-PW-ENET-MIB

The CISCO-IETF-PW-ENET-MIB contains objects that describe the model for managing Ethernet point-to-point pseudo wire services over a Packet Switched Network (PSN).



## MIB Constraints

Table 3-43 lists the constraints that your router places on the objects in the CISCO-IETF-PW-ENET-MIB.

Table 3-43 CISCO-IETF-PW-ENET-MIB Constraints

MIB Object	Notes
cpwVcEnetMplsPriMappingTable	Not supported.
cpwVcEnetStatsTable	Not supported.

## CISCO-IETF-PW-FR-MIB

The CISCO-IETF-PW-FR-MIB contains the network management objects defined for FRoPW services over a PSN.

## CISCO-IETF-PW-MIB

The CISCO-IETF-PW-MIB contains managed object definitions for PW operation.

## MIB Constraints

Table 3-44 lists the constraints that your router places on the objects in the CISCO-IETF-PW-MIB.

Table 3-44 CISCO-IETF-PW-MIB Constraints

MIB Object	Notes
<b>cpwVcTable</b>	
• CpwVcEntry	Not-accessible.
• cpwVcIndex	Not-accessible.
• cpwVcType	Read only.
• cpwVcOwner	Read only.
• cpwVcPsnType	Read only.
• cpwVcSetUpPriority	Not implemented.
• cpwVcHoldingPriority	Not implemented.
• cpwVcInboundMode	Read only.
• cpwVcPeerAddrType	Read only.
• cpwVcPeerAddr	Read only.
• cpwVcID	Read only.
• cpwVcLocalGroupID	Read only.

Table 3-44 CISCO-IETF-PW-MIB Constraints

MIB Object	Notes
<ul style="list-style-type: none"> <li>• cpwVcControlWord</li> <li>• cpwVcLocalIfMtu</li> <li>• cpwVcLocalIfString</li> <li>• cpwVcRemoteControlWord</li> <li>• cpwVcOutboundVcLabel</li> <li>• cpwVcInboundVcLabel</li> <li>• cpwVcName</li> <li>• cpwVcDescr</li> <li>• cpwVcAdminStatus</li> <li>• cpwVcTimeElapsed</li> <li>• cpwVcRowStatus</li> <li>• cpwVcStorageType</li> </ul>	<p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Not implemented.</p> <p>Read only.</p> <p>Read only.</p>
<p><b>cpwVcPerfCurrentTable</b></p> <ul style="list-style-type: none"> <li>• cpwVcPerfCurrentEntry</li> <li>• cpwVcPerfCurrentInHCPackets</li> <li>• cpwVcPerfCurrentInHCBytes</li> <li>• cpwVcPerfCurrentOutHCBytes</li> <li>• cpwVcPerfCurrentOutHCPackets</li> </ul>	<p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p>
<p><b>cpwVcPerfIntervalTable</b></p> <ul style="list-style-type: none"> <li>• cpwVcPerfIntervalEntry</li> <li>• cpwVcPerfIntervalNumber</li> <li>• cpwVcPerfIntervalValidData</li> <li>• cpwVcPerfIntervalInHCPackets</li> <li>• cpwVcPerfIntervalInHCBytes</li> <li>• cpwVcPerfIntervalOutHCPackets</li> <li>• cpwVcPerfIntervalOutHCBytes</li> </ul>	<p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p> <p>Not implemented.</p>
<p><b>cpwVcNotifRate</b></p>	<p>Not implemented.</p>

## CISCO-IETF-PW-MPLS-MIB

The CISCO-IETF-PW-MPLS-MIB contains objects that complement the CISCO-IETF-PW-MIB for PW operation over MPLS.

### MIB Constraints

[Table 3-45](#) lists the constraints that your router places on the objects in the CISCO-IETF-PW-MPLS-MIB.

*Table 3-45 CISCO-IETF-PW-MPLS-MIB Constraints*

MIB Object	Notes
cpwVcMplsOutboundIndexNext	Not supported.
cpwVcMplsInboundIndexNext	Not supported.

## CISCO-IETF-PW-TDM-MIB

The CISCO-IETF-PW-TDM-MIB contains managed object definitions for encapsulating TDM (T1,E1, T3, E3, NxDS0) as pseudo-wires over packet-switching networks (PSN).

## CISCO-IF-EXTENSION-MIB

The CISCO-IF-EXTENSION-MIB contains objects that provide additional interface-related information that is not available in the [IF-MIB \(RFC 2863\)](#).

### MIB Constraints

[Table 3-46](#) lists constraints that your router places on the object in CISCO-IF-EXTENSION-MIB

*Table 3-46 CISCO-IF-EXTENSION-MIB Constraints*

MIB Object	Notes
<b>cieInterfaceTable</b> <ul style="list-style-type: none"> <li>• cieIfDhcpMode</li> <li>• cieIfMtu</li> <li>• cieIfContextName</li> <li>• cieIfKeepAliveEnabled</li> </ul>	Not implemented. Not implemented. Not implemented. Not supported for ATM interfaces.
<b>cieSystemMtu</b>	Not implemented.
<b>cieIfUtilTable</b>	Not supported for Cisco Services Module interfaces.
<b>cieIfDot1dBaseMappingTable</b>	Not implemented.

Table 3-46 CISCO-IF-EXTENSION-MIB Constraints (continued)

MIB Object	Notes
<code>cieIfDot1qCustomEtherTypeTable</code>	Not implemented.
<code>cieIfNameMappingTable</code>	Not implemented.

## Notes

Some objects defined in `cieIfPacketStatsTable` and `cieIfInterfaceTable` are applicable to physical interfaces only. As a result, this table may be sparse for non-physical interfaces.

ATM interfaces do not support the `cieIfKeepAliveEnabled` object.

## CISCO-IGMP-FILTER-MIB

The CISCO\_IGMP-FILTER-MIB provides a mechanism for users to configure the system to intercept Internet Group Management Protocol (IGMP) joins for IP Multicast groups identified in this MIB and only allow certain ports to join certain multicast groups.

## CISCO-IMAGE-MIB

The CISCO-IMAGE-MIB contains objects that identify the capabilities and characteristics of the Cisco IOS image.

## CISCO-IMAGE-LICENSE-MGMT-MIB

The CISCO-IMAGE-LICENSE-MGMT-MIB contains objects to control the management level of the IOS image on a device. Cisco licensing mechanism provides flexibility to run a device at different image levels. This mechanism is referred to as image-level licensing. Image-level licensing leverages the universal image-based licensing solution. A universal image containing all levels of a software package is loaded on to the device. During startup, the device determines the highest level of license and loads the corresponding software features or subsystems.

## CISCO-IP-LOCAL-POOL-MIB

The CISCO-IP-LOCAL-POOL-MIB contains objects that provide a network manager with information related to the local IP address pools. This MIB provides configuration and statistics reflecting the allocation of local IP pools. Each entry provides information about a particular local IP pool, including the number of free and used addresses.

The SNMP agent does not have to be configured in any special way for CISCO-IP-LOCAL-POOL-MIB objects to be available to the network management system. You can configure the SNMP agent to send the `ciscoIpLocalPoolInUseAddrNoti` notification to a particular host using the **snmp-server host ip-address community-name iplocalpool** command.

The `ciscoIpLocalPoolInUseAddrNoti` notification is enabled:

- Through SNMP by using the `cIpLocalPoolNotificationsEnable` object
- Using the **snmp-server enable traps ip local pool** CLI configuration

## CISCO-IPMROUTE-MIB

The CISCO-IPMROUTE-MIB contains objects to manage IP multicast routing on the router.

## CISCO-IPSEC-FLOW-MONITOR-MIB

The CISCO-IPSEC-FLOW-MONITOR-MIB allows monitoring of the structures in IPsec-based virtual private networks.

## CISCO-IPSEC-MIB

The CISCO-IPSEC-MIB models the Cisco implementation-specific attributes of a Cisco entity that implements IPsec.

## CISCO-IPSEC-POLICY-MAP-MIB

The CISCO-IPSEC-POLICY-MAP-MIB contains objects that supplement the proposed IETF standards for IPsec VPNs. In particular, this MIB maps dynamically instantiated IPsec protocol structures (such as tunnels and security associations) to the policy entities that created them (such as policy definitions, crypto maps, and transforms).

The MODULE-IDENTITY for the CISCO-IPSEC-POLICY-MAP-MIB is `ciscoIpSecPolMapMIB`, and its top-level OID is 1.3.6.1.4.1.9.9.172 (iso.org.dod.internet.private.enterprises.cisco.ciscoMgmt.ciscoIpSecPolMapMIB).

## MIB Constraints

This MIB is supported only in Cisco IOS software images that support DES encryption (-k8- or -k9-).

## CISCO-IP-TAP-MIB

The CISCO-IP-TAP-MIB manages Cisco intercept feature for IP. This MIB is used along with CISCO-TAP2-MIB to intercept IP traffic.

## CISCO-IP-URPF-MIB

The CISCO-IP-URPF-MIB contains objects that allow users to specify a Unicast Reverse Path Forwarding (URPF) drop-rate threshold on interfaces of a managed device, which when exceeded, a SNMP notification is sent. It includes objects specifying global (to a managed device as a whole) and per-interface drop counts and drop rates, and also generates traps based on the drop rate exceeding a configurable per-interface threshold.

## MIB Constraints

[Table 3-47](#) lists the constraints that your router places on the CISCO-IP-URPF-MIB.

*Table 3-47 CISCO-IP-URPF-MIB Constraints*

MIB Object	Notes
<code>cipUrpflfMonTable</code>	Entries in this tables are present when URPF is enabled on an interface. They are not available when the interface is removed or if RPF is disabled on the interface.
<code>cipUrpflfConfTable</code>	Entries in this tables are present when URPF is enabled on an interface. They are not available when the interface is removed or if RPF is disabled on the interface.

## CISCO-LAG-MIB

The CISCO-LAG-MIB contains objects to manage link aggregation (LAG) on the router, as defined by IEEE Standard 802.3ad. The MIB contains link aggregation information that supplements to IEEE8023-LAG-MIB or is specific to Cisco products.

## CISCO-LICENSE-MGMT-MIB

The CISCO-LICENSE-MGMT-MIB contains objects to manage the licenses on a system. The licensing mechanism provides flexibility to enforce licensing for various features in the system. These are the different kinds of licenses:

- NODE LOCKED LICENSE
- NON-NODE LOCKED LICENSE
- METERED LICENSE
- EVALUATION LICENSE
- RIGHT TO USE (RTU) LICENSE
- EXTENSION LICENSE
- GRACE PERIOD LICENSE
- COUNTED LICENSE
- UNCOUNTED LICENSE
- IMAGE LEVEL LICENSING
- FEATURE LEVEL LICENSING

## CISCO-MVPN-MIB

The CISCO-MVPN-MIB contains managed object definitions for the Cisco implementation of multicast in VPNs defined by the Internet draft, draft-rosen-vpn-mcast-05.txt.

The Multicast VPN MIB feature introduces the capability for Simple Network Management Protocol (SNMP) monitoring of a Multicast VPN (MVPN). Using the MVPN MIB, network administrators can access MVRF information from PE routers. This information can be accessed for VPN traffic across multiple CE sites in real time. SNMP operations can be performed to monitor the MVRFs on the PE routers, using the get and set commands. These commands are entered on the Network management system (NMS) workstation for which the SNMP has been implemented. The NMS workstations is also known as the SNMP manager.



**Note**

---

Currently only IPv4 is supported.

---



**Note**

---

For all MIB objects with “read-create” access privileges, currently only “read-only” access is supported.

---

For more information on this MIB, please access the following link:

[https://www.cisco.com/en/US/docs/ios/12\\_0s/feature/guide/mcvpnmmib.html](https://www.cisco.com/en/US/docs/ios/12_0s/feature/guide/mcvpnmmib.html)

## CISCO-NBAR-PROTOCOL-DISCOVERY-MIB

The CISCO-NBAR-PROTOCOL-DISCOVERY-MIB provides SNMP support for Network-Based Application Recognition (NBAR), including enabling and disabling protocol discovery on a per-interface basis, and configuring the traps that are generated when certain events occur. You can also display the current NBAR configuration and run-time statistics.



Note

The MODULE-IDENTITY for the CISCO-NBAR-PROTOCOL-DISCOVERY-MIB is `ciscoNbarProtocolDiscoveryMIB`, and its top-level OID is 1.3.6.1.4.1.9.9.244 (iso.org.dod.internet.private.enterprises.cisco.ciscoMgmt.ciscoNbarProtocolDiscoveryMIB).



Note

The `cnpdTopNConfigTable` and `cnpdTopNStatsTable` tables do not have details for the protocol “unknown”.

## CISCO-NETFLOW-MIB

The CISCO-NETFLOW-MIB provides a simple and easy method to get NetFlow cache information, the current NetFlow configuration, and statistics.

### MIB Constraints

Table 3-48 lists the constraints that your router places on the objects in the CISCO-NETFLOW-MIB.

Table 3-48 CISCO-NETFLOW-MIB Constraints

MIB Object	Notes
<code>cnfCICacheEnable</code>	The following values are not supported: <ul style="list-style-type: none"> <li>• <code>destinationOnly(6)</code></li> <li>• <code>sourceDestination(7)</code></li> <li>• <code>fullFlow(8)</code></li> <li>• <code>expBgpPrefix(23)</code></li> </ul>

## CISCO-NTP-MIB

The CISCO-NTP-MIB contains objects to monitor a Network Time Protocol (NTP) server. NTP is used to synchronize timekeeping among a set of distributed time servers and clients. Primary time servers, which are synchronized to national time standards, are connected to widely accessible resources such as backbone gateways. These primary servers send timekeeping information to other time servers, and perform clock checking to eliminate timekeeping errors due to equipment or propagation failures.



## MIB Constraints

Table 3-49 lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-NTP-MIB.

Table 3-49 CISCO-NTP-MIB Constraints

MIB Object	Notes
cntpSysLeap	Read only.
cntpSysStratum	Read only.

## CISCO-OSPF-MIB

The CISCO-OSPF-MIB contains objects for managing OSPF implementation. Most of the MIB definitions are based on the IETF draft draft-ietf-ospf-mib-update-05.txt and include support for OSPF Sham link. The CISCO-OSPF-MIB is an extension to the OSPF-MIB defined in RFC 1850.

## CISCO-OSPF-TRAP-MIB

The CISCO-OSPF-TRAP-MIB contains new and modified notification objects and events, which are defined in the latest version for OSPF-MIB IETF draft draftietf-ospf-mib-update-05.txt in addition to support for OSPF Sham link.

## CISCO-PIM-MIB

The CISCO-PIM-MIB defines Cisco-specific objects and variables for managing Protocol Independent Multicast (PIM) on the router. These MIB definitions are an extension of those in RFC 2934, which is the IETF PIM MIB.

## CISCO-PING-MIB

The CISCO-PING-MIB contains objects to manage ping requests on the router.

## CISCO-POWER-ETHERNET-EXT-MIB

The CISCO-POWER-ETHERNET-EXT-MIB extends the POWER-ETHERNET-MIB (RFC3621) to add objects which provide additional management information about Power Sourcing Equipment (PSE) that is not available in the POWER-ETHERNET-MIB.

Table 3-50 lists the constraints that your router place on the objects in the CISCO-POWER-ETHERNET-EXT-MIB.

Table 3-50 CISCO-POWER-ETHERNET-EXT-MIB Constraints

MIB Object	Constraints
cpeExtPsePortDiscoverMode	Read only.
cpeExtPsePortDeviceDetected	Read only.
cpeExtPsePortIeeePd	Read only.
cpeExtPsePortAdditionalStatus	Read only.
cpeExtPsePortPwrMax	Read only.
cpeExtPsePortPwrAllocated	Read only.
cpeExtPsePortPwrAvailable	Read only.
cpeExtPsePortPwrConsumption	Read only.
cpeExtPsePortMaxPwrDrawn	Read only.
cpeExtPsePortEntPhyIndex	Read only.
cpeExtPsePortPolicingCapable	Read only.
cpeExtMainPseEntPhyIndex	Read only.
cpeExtMainPseDescr	Read only.
cpeExtMainPsePwrMonitorCapable	Read only.
cpeExtPdStatsTotalDevices	Read only.
cpeExtPdStatsDeviceCount	Read only.

## CISCO-PPPOE-MIB

The CISCO-PPPOE-MIB contains objects to manage Point-to-Point Protocol over Ethernet (PPPoE) sessions. These objects represent PPPoE sessions at the system and virtual channel (VC) level.

## MIB Constraints

Table 3-51 lists the constraints that your router places on the objects in the CISCO-PPPOE-MIB.

Table 3-51 CISCO-PPPOE-MIB Constraints

MIB Object	Notes
<b>cPppoeSystemMaxAllowedSessions</b>	Read only.
<b>cPppoeSystemThresholdSessions</b>	Read only.
<b>cPppoeVcCfgTable</b>	
• cPppoeVcEnable	Read only.
<b>cPppoeVcSessionsTable</b>	
• cPppoeVcMaxAllowedSessions	Read only.
• cPppoeVcExceededSessionErrors	Read only.



Note

The Object “cPppoeSystemCurrSessions” is the only object supported for PPPoE clients. For example, this holds true for NIM-VAB card variants which initiate PPPoE sessions.

## CISCO-PROCESS-MIB

The CISCO-PROCESS-MIB displays memory and CPU usage on the router and describes active system processes. CPU utilization presents a status of how busy the system is. The numbers are a ratio of the current idle time over the longest idle time. (This information should be used as an estimate only)

## MIB Constraints

Table 3-52 lists the constraints that your router places on the objects in the CISCO-PROCESS-MIB.

Table 3-52 CISCO-PROCESS-MIB Constraints

MIB Object	Notes
<b>cpmProcessTable</b>	
• cpmProcExtPriority	Read only.
<b>cpmCPURisingThreshold</b>	Not Supported
<b>cpmCPUFallingThreshold</b>	Not Supported

## CISCO-PROCESS-MIB Usage

The cpmCPUTotal5sec, cpmCPUTotal1min, and cpmCPUTotal5min objects have been deprecated and replaced by cpmCPUTotal5secRev, cpmCPUTotal1minRev, and cpmCPUTotal5minRev, respectively.

**Note**

When an object is deprecated, it does not mean that an object instance may not be returned. For these deprecated objects, object instances are returned. However, their returned values must be ignored. The values returned by the new objects must be used.

**Note**

The CPU utilization objects such as `cpmCPUTotal5sec`, `cpmCPUTotal1min`, and `cpmCPUTotal5min` are calculated for all the processes used by CPU except under idle condition.

[Table 3-53](#) lists the support matrix for the CISCO-PROCESS-MIB `cpmCPUTotalTable` object.

*Table 3-53 Support-Matrix for cpmCPUTotalTable*

<b>cpmCPUTotalTable Objects</b>	<b>RP CPU</b>
<code>cpmCPULoadAvg1min</code>	Yes
<code>cpmCPULoadAvg5min</code>	Yes
<code>cpmCPULoadAvg15min</code>	Yes
<code>cpmCPUMemoryCommitted</code>	Yes
<code>cpmCPUTotalPhysicalIndex</code>	Yes
<code>cpmCPUTotal5sec</code>	Yes
<code>cpmCPUTotal1min</code>	Yes
<code>cpmCPUTotal5min</code>	Yes
<code>cpmCPUTotal5secRev</code>	Yes
<code>cpmCPUTotal1minRev</code>	Yes
<code>cpmCPUTotal5minRev</code>	Yes
<code>cpmCPUMonInterval</code>	No
<code>cpmCPUTotalMonIntervalValue</code>	No
<code>cpmCPUInterruptMonIntervalValue</code>	No
<code>cpmCPUMemoryUsed</code>	Yes
<code>cpmCPUMemoryFree</code>	Yes
<code>cpmCPUMemoryKernelReserved</code>	No
<code>cpmCPUMemoryLowest</code>	Yes

[Table 3-54](#) lists the support matrix for the CISCO-PROCESS-MIB `cpmProcessTable` and `cpmProcessExtRevTable` objects for RP CPU.

*Table 3-54 Support Matrix for the cpmProcessTable and the cpmProcessRevExtTable for RP CPU*

<b>cpmProcessTable and cpmProcessRevExtTable Objects</b>	<b>IOSD Process [Process Name: ppc_linux_iosd-]</b>	<b>Other Process [Process Name: Cmand, hman, imand]</b>
<code>cpmProcessName</code>	Yes	Yes
<code>cpmProcessuSecs</code>	No	No

Table 3-54 Support Matrix for the *cpmProcessTable* and the *cpmProcessRevExtTable* for RP CPU

<b>cpmProcessTable and cpmProcessRevExtTable Objects</b>	<b>IOSD Process [Process Name: ppc_linux_iosd-]</b>	<b>Other Process [Process Name: Cmand, hman, imand]</b>
cpmProcessTimeCreated	Yes	Yes
cpmProcessAverageUSeCs	Yes	Yes
cpmProcExtMemAllocatedRev	Yes	Yes
cpmProcExtMemFreedRev	No	No
cpmProcExtInvokedRev	No	No
cpmProcExtRuntimeRev	No	No
cpmProcExtUtil5SecRev	No	No
cpmProcExtUtil1MinRev	No	No
cpmProcExtUtil5MinRev	No	No
cpmProcExtPriorityRev	Yes	Yes
cpmProcessType	No	No
cpmProcessRespawn	No	No
cpmProcessRespawnCount	No	No
cpmProcessRespawnAfterLastPatch	No	No
cpmProcessMemoryCore	No	No
cpmProcessLastRestartUser	No	No
cpmProcessTextSegmentSize	No	No
cpmProcessDataSegmentSize	No	No
cpmProcessStackSize	No	No
cpmProcessDynamicMemorySize	No	No

Table 3-55 lists the support matrix for the CISCO-PROCESS-MIB *cpmVirtualProcessTable* object.

Table 3-55 Support Matrix for the *cpmVirtualProcessTable*

<b>cpmVirtualProcessTable Objects</b>	<b>Process running under Active RP IOSD Process</b>
cpmVirtualProcessName	Yes
cpmVirtualProcessUtil5Sec	Yes
cpmVirtualProcessUtil1Min	Yes
cpmVirtualProcessUtil5Min	Yes
cpmVirtualProcessMemAllocated	Yes
cpmVirtualProcessMemFreed	Yes
cpmVirtualProcessInvokeCount	Yes
cpmVirtualProcessRuntime	Yes

## CISCO-PRODUCTS-MIB

The CISCO-PRODUCTS-MIB lists the object identifiers (OIDs) assigned to the Cisco hardware platforms.

## CISCO-QINQ-VLAN-MIB

The CISCO-QINQ-VLAN-MIB describes configuration and monitoring capabilities relating to 802.1QinQ interfaces.

### MIB Constraints

Table 3-56 lists the constraints that your router places on the objects in the CISCO-QINQ-VLAN-MIB.

Table 3-56 CISCO-QINQ-VLAN-MIB Constraints

MIB Object	Notes
<b>cqvTerminationTable</b>	
<ul style="list-style-type: none"> <li>cqvTerminationPeEncap</li> <li>cqvTerminationRowStatus</li> </ul>	Implemented as Read only.
<b>cqvTranslationTable</b>	Not supported.

## CISCO-RADIUS-EXT-MIB

The CISCO-RADIUS-EXT-MIB contains MIB objects used for managing the RADIUS authentication and accounting statistics.

## CISCO-RF-MIB

The CISCO-RF-MIB provides configuration control and status information for the redundancy framework subsystem. The redundancy framework subsystem provides a mechanism for logical redundancy of the software functionality and is designed to support 1:1 redundancy for the processor cards.

## CISCO-RTTMON-IP-EXT-MIB

The CISCO-RTTMON-IP-EXT-MIB provides extensions for the tables in CISCO-RTTMON-MIB to support IP layer extensions, specifically IPv6 addresses and other information related to IPv6 standards.

# CISCO-RTTMON-MIB

The CISCO-RTTMON-MIB contains objects to monitor network performance. The MIB provides information about the response times of network resources and applications. Each conceptual round-trip time (RTT) control row in the MIB represents a single probe, which is used to determine an entity's response time. The probe defines an RTT operation to perform (for example, an FTP or HTTP get request), and the results indicate whether the operation succeeded or failed, and how long it took to complete.

If you plan to schedule an RTT operation, see [Table 3-57](#) for information about `rttMonScheduleAdminRttStartTime` in the `rttMonScheduleAdminTable`.



Note

An `rttMonCtrlOperConnectionLostOccurred` trap is generated when an RTT connection cannot be established to the destination router because the router responder application is not running. However, the trap is not generated if the physical connection to the router is lost.

## MIB Constraints

[Table 3-57](#) lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-RTTMON-MIB.

*Table 3-57 CISCO-RTTMON-MIB Constraints*

MIB Object	Notes
<code>RttMonProtocol</code>	The following values are not supported: <ul style="list-style-type: none"> <li>• <code>snaRUEcho</code></li> <li>• <code>snaLU0EchoAppl</code></li> </ul>
<code>rttMonApplAuthTable</code>	Not supported.
<code>rttMonCtrlAdminTable</code> <ul style="list-style-type: none"> <li>• <code>rttMonCtrlAdminRttType</code></li> </ul>	Supported values are: <ul style="list-style-type: none"> <li>• <code>echo(1)</code></li> <li>• <code>pathEcho(2)</code></li> <li>• <code>udpEcho(5)</code></li> <li>• <code>tcpConnect(6)</code></li> <li>• <code>http(7)</code></li> <li>• <code>dns(8)</code></li> <li>• <code>jitter(9)</code></li> <li>• <code>ftp(12)</code></li> </ul> All other values not supported.
<code>rttMonEchoAdminTable</code>	

Table 3-57 CISCO-RTTMON-MIB Constraints (continued)

MIB Object	Notes
<ul style="list-style-type: none"> <li>rttMonEchoAdminProtocol</li> </ul>	Supported values: <ul style="list-style-type: none"> <li>ipIcmpEcho(2)</li> <li>ipUdpEchoAppl(3)</li> <li>ipTcpConn(24)</li> <li>httpAppl(25)</li> <li>dnsAppl(26)</li> <li>jitterAppl(27)</li> <li>ftpAppl(30)</li> </ul> All other values not supported.
<b>rttMonScheduleAdminTable</b> <ul style="list-style-type: none"> <li>rttMonScheduleAdminRttStartTime</li> </ul>	Before setting this object to a date/time value, make sure the ESR clock was set through the CLI <b>clock set</b> command. Otherwise, the scheduled RTT operation does not run.
<b>rttMonHistoryCollectionTable</b>	HTTP and Jitter types are not supported.

## CISCO-SLB-EXT-MIB

The CISCO-SLB-EXT-MIB contains extensions to the Cisco server load-balancing (SLB) MIB (CISCO-SLB-MIB). Server load balancing enables the router to balance the processing of packets and connections from a number of other devices, such as real servers, firewalls, or caches. An SLB device determines how to handle incoming frames and connections according to the contents of the incoming data and various configuration options.

## CISCO-SLB-MIB

The CISCO-SLB-MIB contains objects to manage server load-balancing (SLB) managers, such as those provided by the Cisco IOS SLB product. The MIB includes objects for the manager-side implementation of the Dynamic Feedback Protocol (DFP), which is used to obtain information about servers.

## CISCO-SESS-BORDER-CTRLR-CALL-STATS-MIB

The CISCO-SESSION-BORDER-CONTROLLER-CALL-STATS-MIB defines the statistics information for Session Border Controller application. The statistic information is of two types:

- Call statistics
- Media statistics



## CISCO-SESS-BORDER-CTRLR-EVENT-MIB

The CISCO-SESS-BORDER-CTRLR-EVENT-MIB defines the SNMP notifications, events, and alarms generated by Session Border Controller application, and sends these notifications to SNMP manager application. The various notification, events, and alarms generated by a SBC application can be:

- Change in the state of a configured SBC service.
- Change in the connection state with an adjacency or a radius server or H.248 controller attached to SBC, CPU or memory congestion, due to a large number of ongoing SIP/H.248 calls.
- Violation in the call policies configured for the current ongoing SIP/H.248 calls, when SBC application receives media (RTP/RTCP) packets from an unknown IP address or port.

## CISCO-SESS-BORDER-CTRLR-STATS-MIB

The CISCO-SESS-BORDER-CTRLR-STATS-MIB contains objects to manage the statistics information for the Session Border Controller application. The statistics information is categorized into these types:

- RADIUS Messages Statistics—Represents the statistics of various RADIUS messages for the RADIUS servers with which the client (SBC) shares a secret.
- RF Billing Statistics—Represents the RF billing statistics information, which is used to monitor the messages sent per realm over the IMS Rx interface by the RF billing manager(SBC).

## MIB Tables

Table 3-58 lists the tables in CISCO-SESS-BORDER-CTRLR-STATS-MIB.

*Table 3-58 CISCO-SESS-BORDER-CTRLR-STATS-MIB Tables*

MIB Table	Description
csbRadiusStatsTable	Maintains the RADIUS messages for the RADIUS servers.
csbRfBillRealmStatsTable	Maintains the RF billing statistics information.
csbSIPMthdCurrentStatsTable	Contains the total number of SIP request and responses for each SIP method on a given adjacency for a specific interval.
csbSIPMthdHistoryStatsTable	Contains the historical count of SIP requests and responses for each SIP method on a SIP adjacency for the different intervals defined by the csbSIPMthdHistoryStatsInterval object.
csbSIPMthdRCCurrentStatsTable	Contains the SIP method request and response code statistics corresponding to the method and response code combination on a given adjacency for a specific interval.
csbSIPMthdRCHistoryStatsTable	Contains the historical data for the SIP method request and response code statistics corresponding to the method and response code on a given adjacency for a specific interval.

## CISCO-SIP-UA-MIB

The CISCO-SIP-UA-MIB manages the Session Initiation Protocol (SIP) User Agents (UA). SIP is an application-layer signalling protocol for creating, modifying, and terminating multimedia sessions with one or more participants. A UA is an application that contains both a User Agent Client (UAC) and a User Agent Server (UAS). A UAC is an application that initiates a SIP request. A UAS is an application that contacts the corresponding user when a SIP request is received and returns a response on behalf of the user.

## CISCO-SNMP-TARGET-EXT-MIB

The CISCO-SNMP-TARGET-EXT-MIB is an extension of the SNMP-TARGET-MIB specified in RFC2273.

## CISCO-SONET-MIB

The CISCO-SONET-MIB contains objects to describe SONET/SDH interfaces on the router. This MIB is an extension to the standard SONET-MIB (RFC 2558). The CISCO-SONET-MIB has objects that provide additional SONET-related information not found in the SONET-MIB.



Note

CISCO-SONET-MIB supports SONET traps that are seen when the linestatus, sectionstatus, pathstatus changes, and Notifications are enabled.

## CISCO-SUBSCRIBER-SESSION-MIB

The CISCO-SUBSCRIBER-SESSION-MIB contains objects that describe the subscriber sessions terminated by a Remote Access Service (RAS).

### MIB Tables

Table 3-59 lists the tables in CISCO-SUBSCRIBER-SESSION-MIB.

Table 3-59 CISCO-SUBSCRIBER-SESSION-MIB Tables

MIB Table	Description
<b>csubSessionTable</b>	Describes a list of subscriber sessions currently maintained by the system.
<b>csubSessionByTypeTable</b>	Sorts the subscriber sessions first by corresponding subscriber session type, and then by the ifIndex assigned to the corresponding subscriber session.
<b>csubAggStatsTable</b>	Contains sets of aggregated statistics pertaining to subscriber sessions, where each set has a unique scope of aggregation.

Table 3-59 CISCO-SUBSCRIBER-SESSION-MIB Tables

MIB Table	Description
<b>csubAggStatsIntTable</b>	Contains aggregated subscriber session performance data collected for every 15-minute measurement intervals.
<b>csubJobTable</b>	Contains the subscriber session jobs submitted by the element management system (EMS) and network management system (NMS).
<b>csubJobMatchParamsTable</b>	Contains subscriber session job parameters that describe the match criteria.
<b>csubJobQueryParamsTable</b>	Contains subscriber session job parameters that describe the query parameters.
<b>csubJobQueueTable</b>	Lists the subscriber session jobs pending in the subscriber session job queue.
<b>csubJobReportTable</b>	Contains the reports corresponding to subscriber session jobs that have <i>query</i> as the <i>csubJobType</i> , and <i>finished</i> as the <i>csubJobState</i> .

## MIB Constraints

Table 3-60 lists the constraints that the Cisco 1100 Series ISR place on the objects in the CISCO-SUBSCRIBER-SESSION-MIB. Any MIB object that is not listed in this table is implemented as defined in the MIB.

Table 3-60 CISCO-SUBSCRIBER-SESSION-MIB Constraints

MIB Object	Notes
<b>csubSessionByTypeTable</b>	Not implemented.
<b>csubAggStatsIntTable</b>	Not implemented.
<b>csubJobQueueTable</b>	Not implemented.
<b>csubSessionTable</b>	
<ul style="list-style-type: none"> <li>• <b>csubSessionType</b></li> </ul>	Read only. The <i>pppSubscriber</i> (3), <i>pppoeSubscriber</i> (4), <i>ipInterfaceSubscriber</i> (7), <i>ipPktSubscriber</i> (8), and <i>ipDhcpv4Subscriber</i> (9) types are supported.
<ul style="list-style-type: none"> <li>• <b>csubSessionAuthenticated</b></li> <li>• <b>csubSessionCreationTime</b></li> <li>• <b>csubSessionAvailableIdentities</b></li> <li>• <b>csubSessionSubscriberLabel</b></li> <li>• <b>csubSessionMacAddress</b></li> <li>• <b>csubSessionNativeVrf</b></li> <li>• <b>csubSessionNativeIpAddrType</b></li> <li>• <b>csubSessionNativeIpAddr</b></li> <li>• <b>csubSessionNativeIpMask</b></li> <li>• <b>csubSessionDomainVrf</b></li> </ul>	Read only. Read only. Read only. Read only. Read only. Read only. Read only. Read only. Read only. Read only.

Table 3-60 CISCO-SUBSCRIBER-SESSION-MIB Constraints (continued)

MIB Object	Notes
• csubSessionPbhc	Read only.
• csubSessionRemoteId	Read only.
• csubSessionCircuitId	Read only.
• csubSessionNasPort	Read only.
• csubSessionDomain	Read only.
• csubSessionUsername	Read only.
• csubSessionAcctSessionId	Read only.
• csubSessionProtocol	Read only. The IP(3) and PPP(5) values are supported.
• csubSessionLocationIdentifier	Read only.
• csubSessionServiceIdentifier	Read only.
• csubSessionLastChanged	Read only.
• csubSessionNativeIpAddrType2	Read only.
• csubSessionNativeIpAddr2	Read only.
• csubSessionNativeIpMask2	Read only.
• csubSessionIpAddrAssignment	Not implemented.
• csubSessionRedundancyMode	Not implemented.
• csubSessionDerivedCfg	Not implemented.
• csubSessionDnis	Not implemented.
• csubSessionMedia	Not implemented.
• csubSessionMlpNegotiated	Not implemented.
• csubSessionServiceName	Not implemented.
• csubSessionDhcpClass	Not implemented.
• csubSessionTunnelName	Not implemented.
<b>csubAggStatsTable</b>	Currently the scope of aggregation is limited to providing the statistics at the RAS level.
• csubAggStatsPendingSessions	Read only.
• csubAggStatsUpSessions	Read only.
• csubAggStatsAuthSessions	Read only.
• csubAggStatsUnAuthSessions	Read only.
• csubAggStatsLightWeightSessions	Read only.
• csubAggStatsHighUpSessions	Read only.
• csubAggStatsAvgSessionUptime	Read only.
• csubAggStatsAvgSessionRPM	Read only.
• csubAggStatsAvgSessionRPH	Read only.
• csubAggStatsTotalFailedSessions	Read only.
• csubAggStatsTotalUpSessions	Read only.

Table 3-60 CISCO-SUBSCRIBER-SESSION-MIB Constraints (continued)

MIB Object	Notes
• csubAggStatsTotalLightWeightSessions	Read only.
• csubAggStatsTotalFlowsUp	Read only.
• csubAggStatsCurrFlowsUp	Read only.
• csubAggStatsRedSessions	Not implemented.
• csubAggStatsThrottleEngagements	Not implemented.
• csubAggStatsTotalCreatedSessions	Not implemented.
• csubAggStatsTotalAuthSessions	Not implemented.
• csubAggStatsTotalDiscSessions	Not implemented.
• csubAggStatsDayCreatedSessions	Not implemented.
• csubAggStatsDayFailedSessions	Not implemented.
• csubAggStatsDayUpSessions	Not implemented.
• csubAggStatsDayAuthSessions	Not implemented.
• csubAggStatsDayDiscSessions	Not implemented.
• csubAggStatsCurrTimeElapsed	Not implemented.
• csubAggStatsCurrValidIntervals	Not implemented.
• csubAggStatsCurrInvalidIntervals	Not implemented.
• csubAggStatsCurrCreatedSessions	Not implemented.
• csubAggStatsCurrFailedSessions	Not implemented.
• csubAggStatsCurrUpSessions	Not implemented.
• csubAggStatsCurrAuthSessions	Not implemented.
• csubAggStatsCurrDiscSessions	Not implemented.
<b>csubJobTable</b>	
• csubJobId	Read only.
• csubJobStatus	The values, Not-In-Service and Not-Ready, are not supported.
• csubJobStorage	Read only.
• csubJobType	Read only.
• csubJobControl	If the job is executing, the <i>abort</i> action is ignored.
• csubJobState	Read only.
• csubJobStartedTime	The sysuptime at the time of job start is measured in timeticks.
• csubJobFinishedTime	The sysuptime at the time of job start is measured in timeticks.
• csubJobFinishedReason	The value <i>insufficientResources</i> is returned if a job query is started without sufficient job match parameters.
<b>csubJobMatchParamsTable</b>	

Table 3-60 CISCO-SUBSCRIBER-SESSION-MIB Constraints (continued)

MIB Object	Notes
• csubJobMatchParamsEntry	Read only.
• csubJobMatchIdentities	Read only.
• csubJobMatchSubscriberLabel	Read only.
• csubJobMatchMacAddress	Read only.
• csubJobMatchNativeVrf	Read only.
• csubJobMatchNativeIpAddrType	The job search based on IPv6 is not supported.
• csubJobMatchNativeIpAddr	Read only.
• csubJobMatchPbhk	Read only.
• csubJobMatchOtherParams	Not implemented.
• csubJobMatchDomainVrf	Not implemented.
• csubJobMatchRemoteId	Not implemented.
• csubJobMatchCircuitId	Not implemented.
• csubJobMatchNasPort	Not implemented.
• csubJobMatchUsername	Not implemented.
• csubJobMatchAccountingSid	Not implemented.
• csubJobMatchDomain	Not implemented.
• csubJobMatchDnis	Not implemented.
• csubJobMatchMedia	Not implemented.
• csubJobMatchMlpNegotiated	Not implemented.
• csubJobMatchProtocol	Not implemented.
• csubJobMatchServiceName	Not implemented.
• csubJobMatchDhcpClass	Not implemented.
• csubJobMatchTunnelName	Not implemented.
• csubJobMatchDanglingDuration	Not implemented.
<b>csubJobQueryParamsTable</b>	
• csubJobQueryResultingReportSize	<ul style="list-style-type: none"> <li>• When the EMS or NMS sets the <i>jobcontrol</i> value to <i>release</i>, the job and the csubJobQueryResultingReportSize object become invalid.</li> <li>• The csubJobQueryParamsTable is created only when the jobfinished value becomes <i>normal</i>.</li> </ul>
<b>csubJobReportTable</b>	
• csubJobReportId	Read only.
• csubJobReportSession	Read only.

Table 3-60 CISCO-SUBSCRIBER-SESSION-MIB Constraints (continued)

MIB Object	Notes
<code>csubJobFinishedNotifyEnable</code>	Read-write.
<code>csubJobIndexedAttributes</code>	The supported indexed attributes are: <ul style="list-style-type: none"> <li>Subscriber Label</li> <li>Mac Address</li> <li>IP Address (IPv4 only)</li> <li>Native VRF</li> <li>Port-bundle Host Key (PBHK)</li> </ul>

## CISCO-SYSLOG-MIB

The CISCO-SYSLOG-MIB contains all system log messages generated by the Cisco IOS software. The MIB provides a way to access these syslog messages through SNMP. All Cisco IOS syslog messages contain the message name and its severity, message text, the name of the entity generating the message, and an optional time stamp. The MIB also contains a history of syslog messages and counts related to syslog messages.



Note

You can configure the Cisco 1100 Series ISR to send syslog messages to a syslog server.



Note

The MIB does not keep track of messages generated from debug commands entered through the command-line interface (CLI).

## CISCO-UNIFIED-FIREWALL-MIB

The CISCO-UNIFIED-FIREWALL-MIB contains status and performance statistics for Cisco firewall implementation. The Cisco 1100 Series ISR platform only supports the statistics for the zone base firewall.



Note

Beginning with Cisco IOS Release 3.6, the CISCO-UNIFIED-FIREWALL-MIB is supported on IPv6 networks.

## MIB Tables

Table 3-60 lists the tables in CISCO-UNIFIED-FIREWALL-MIB.

*CISCO-UNIFIED-FIREWALL-MIB Tables*

<b>MIB Table</b>	<b>Description</b>
<b>cufwConnSummaryTable</b>	Contains information about the connection activity on the firewall for each layer3 and layer 4 protocols. Each entry in the table lists the connection summary of a distinct network protocol.
<b>cufwAppConnSummaryTable</b>	Contains firewall connections information for Layer 7 protocols. Each entry in the table lists the connection summary corresponding to a distinct application protocol.
<b>cufwPolicyConnSummaryTable</b>	Contains firewall connections information for layer3 and layer 4 protocols for each applied policy. Each entry in the table lists the connection summary of a distinct network protocol, configured on the specified target policy on the firewall.
<b>cufwPolicyAppConnSummaryTable</b>	Contains firewall connections information for Layer 7 protocols for each applied policy. Each entry in the table lists the connection summary of a distinct application protocol, configured on the specified target policy on the firewall.
<b>cufwInspectionTable</b>	Contains objects to identify whether or not an application protocol is configured for inspection. It also contains attributes to identify whether or not the specified protocol is currently being verified.
<b>cufwUrlfServerTable</b>	Lists the URL filtering servers configured on the managed devices and corresponding performance statistics.

## MIB Constraints

Table 3-61 lists the constraints that your router places on CISCO-UNIFIED-FIREWALL-MIB.

*Table 3-61 CISCO-UNIFIED-FIREWALL-MIB Constraints*

<b>MIB Object</b>	<b>Notes</b>
<b>cufwInspectionTable</b>	Not supported.
<b>cufwUrlfServerTable</b>	Not supported.
<b>cuFwConnectionGlobalsTable</b>	
• cufwConnGlobalNumSetupsAborted	Not supported, default value set to zero.
• cufwConnGlobalNumPolicyDeclined	Not supported, default value set to zero.
• cufwConnGlobalNumResDeclined	Not supported, default value set to zero.
• cufwConnGlobalNumExpired	Not supported, default value set to zero.
• cufwConnGlobalNumAborted	Not supported, default value set to zero.
• cufwConnGlobalNumEmbryonic	Not supported, default value set to zero.
• cufwConnGlobalNumRemoteAccess	Not supported, default value set to zero.
• cufwConnGlobalConnSetupRate1	The number of sessions created in the last minute.
• cufwConnGlobalConnSetupRate5	The number of sessions created in the last five minutes.



Table 3-61 CISCO-UNIFIED-FIREWALL-MIB Constraints (continued)

MIB Object	Notes
<b>cufwConnSummaryTable</b>	
• cufwConnNumSetupsAborted	Not supported, default value set to zero.
• cufwConnNumPolicyDeclined	Not supported, default value set to zero.
• cufwConnNumResDeclined	Not supported, default value set to zero.
• cufwConnNumAborted	Not supported, default value set to zero.
• cufwConnSetupRate1	The number of sessions created in the last minute.
• cufwConnSetupRate5	The number of sessions created in the last five minutes.
<b>cufwAppConnSummaryTable</b>	
• cufwAppConnNumSetupsAborted	Not supported, default value set to zero.
• cufwAppConnNumPolicyDeclined	Not supported, default value set to zero.
• cufwAppConnNumPolicyDeclined	Not supported, default value set to zero.
• cufwAppConnNumAborted	Not supported, default value set to zero.
• cufwAppConnSetupRate1	The number of sessions created in the last minute.
• cufwAppConnSetupRate5	The number of sessions created in the last five minutes.
<b>cufwPolicyConnSummaryTable</b>	
• cufwPolConnNumSetupsAborted	Not supported, default value set to zero.
• cufwPolConnNumPolicyDeclined	Not supported, default value set to zero.
• cufwPolConnNumResDeclined	Not supported, default value set to zero.
• cufwPolConnNumAborted	Not supported, default value set to zero.
<b>cufwPolicyAppConnSummaryTable</b>	
• cufwPolAppConnNumSetupsAborted	Not supported, default value set to zero.
• cufwPolAppConnNumPolicyDeclined	Not supported, default value set to zero.
• cufwPolAppConnNumResDeclined	Not supported, default value set to zero.
• cufwPolAppConnNumAborted	Not supported, default value set to zero.

## CISCO-TAP2-MIB

The CISCO-TAP2-MIB manages Cisco intercept feature. This MIB replaces CISCO-TAP-MIB. This MIB defines a generic stream table that contains fields common to all intercept types. Specific intercept filters are defined in the following extension MIBs:

- CISCO-IP-TAP-MIB for IP intercepts
- CISCO-802-TAP-MIB for IEEE 802 intercepts
- CISCO-USER-CONNECTION-TAP-MIB for RADIUS-based user connection intercepts.

## MIB Constraints

Table 3-62 lists the constraints that your router places on CISCO-TAP2-MIB.

Table 3-62 CISCO-TAP2-MIB Constraints

MIB Object	Notes
cTap2MediationRtcpPort	Not supported.
cTap2MediationRetransmitType	Not supported.
cTap2MediationTransport	Only udp(1) is supported.

## CISCO-TAP-MIB

The CISCO-TAP-MIB contains objects to manage Cisco intercept feature.

## CISCO-UBE-MIB

The CISCO-UBE-MIB contains objects to manage the Cisco Unified Border Element (CUBE), which is a Cisco IOS Session Border Controller (SBC) that interconnects independent voice over IP (VoIP) and video over IP networks for data, voice, and video transport.

## CISCO-USER-CONNECTION-TAP-MIB

The CISCO-USER-CONNECTION-TAP-MIB is a filter MIB that provides the functionality to manage the Cisco intercept feature for user connections. This MIB is used along with the CISCO-TAP2-MIB to intercept and filter user traffic. To create a user connection intercept, an entry named cuctapStreamEntry is created in the CISCO-USER-CONNECTION-TAP-MIB. This entry contains the filtering information.

## Cisco-VDSL2-LINE-MIB

This MIB defines a module for use with network management protocols in the Internet community for the purpose of managing VDSL2, ADSL, ADSL2, and ADSL2+ lines.

## MIB Constraints

Table 3-63 lists the constraint that the Cisco ISR Series Router places on the objects in the VDSL2-LINE-MIB.

Table 3-63 CISCO-VDSL-Line-MIB Constraints

MIB Object	Notes
<b>xdsl2LineTable</b>	
• xsdl2LineConfTemplate	Not Supported
• xsdl2LineConfFallbackTemplate	Not Supported
• xsdl2LineAlarmConfTemplate	Not Supported
• xsdl2LineCmndConfBpsc	Not Supported
• xsdl2LineCmndConfBpscFailReason	Not Supported
• xsdl2LineCmndConfBpscRequests	Not Supported
• xsdl2LineCmndAutomodeColdStart	Not Supported
• xsdl2LineStatusActTemplate	Not Supported
• xsdl2LineStatusLastStateDs	Not Supported
• xsdl2LineStatusLastStateUs	Not Supported
• xsdl2LineStatusXtur	Not Supported
• xsdl2LineStatusActLimitMask	Not Supported
• xsdl2LineStatusActUs0Mask	Not Supported
• xsdl2LineStatusElectricalLength	Not Supported
• xsdl2LineStatusTssiDs	Not Supported
• xsdl2LineStatusTssiUs	Not Supported
• xsdl2LineStatusMrefPsdDs	Not Supported
• xsdl2LineStatusMrefPsdUs	Not Supported
• xsdl2LineStatusActualCe	Not Supported
<b>xdsl2LineSegmentTable</b>	Not Supported
<b>xdsl2SCStatusTable</b>	Not Supported
• xsdl2SCStatusSnrMtime	Not Supported
• xsdl2SCStatusAttainableRate	Not Supported
• xsdl2SCStatusRowStatus	
<b>xdsl2SCStatusBandTable</b>	Not Supported
<b>xdsl2LineConfTemplateTable</b>	Not Supported
<b>xdsl2LineConfProfTable</b>	Not Supported
<b>xdsl2LineConfProfModeSpecTable</b>	Not Supported
<b>xdsl2LineConfProfModeSpecBandUsTable</b>	Not Supported
<b>xdsl2ChConfProfileTable</b>	Not Supported
<b>xdsl2LineAlarmConfTemplateTable</b>	Not Supported
<b>xdsl2LineAlarmConfProfileTable</b>	Not Supported
<b>xdsl2ChAlarmConfProfileTable</b>	Not Supported

## CISCO-VLAN-IFTABLE-RELATIONSHIP-MIB

The CISCO-VLAN-IFTABLE-RELATIONSHIP-MIB contains VLAN-ID and ifIndex information for each routed virtual LAN (VLAN) interface on the router. A routed VLAN interface is the router interface or subinterface to which you attach the IP address used by the router on the VLAN. The MIB maps each VLAN-ID to an ifIndex, which you can use to access the ipRouteTable to obtain the routing configuration for the routed VLAN interface.

## CISCO-VLAN-MEMBERSHIP-MIB

The CISCO-VLAN-MEMBERSHIP-MIB provides management functions for the VLAN membership within the framework of Cisco VLAN Architecture, Version 2.0. The MIB provides information on VLAN Membership Policy Servers used by a device and VLAN membership assignments of non-trunk bridge ports of the device.



Note

---

This MIB is not supported on Cisco 1100 Series ISR.

---

## CISCO-VPDN-MGMT-MIB

The CISCO-VPDN-MGMT-MIB provides operational information about the Virtual Private Dialup Network (VPDN) feature on the router. You can use the MIB to monitor VPDN tunnel information on the router, but you cannot use the MIB to configure VPDN.

VPDN enables the router to forward Point-to-Point Protocol (PPP) traffic between an Internet service provider (ISP) and a home gateway. The CISCO-VPDN-MGMT-MIB includes several tables that contain VPDN tunneling information:

- cvpdnSystemTable—Provides system-wide VPDN information.
- cvpdnTunnelAttrTable—Provides information about each active tunnel.
- cvpdnSessionAttrTable—Provides information about each active session within each tunnel.
- cvpdnUserToFailHistInfoTable—Provides information about the last failure that occurred for each tunnel user.
- cvpdnTemplateTable—Identifies each VPDN template and indicates the number of active sessions associated with the template. See [Table 3-64](#) for information about template name restrictions and their effect on SNMP.

## MIB Constraints

The CISCO-VPDN-MGMT-MIB contains read-only information. In addition, the MIB objects in [Table 3-64](#) have been deprecated. Although currently supported, their use is being phased out and we recommend that you use the replacement object instead.

Table 3-64 CISCO-VPDN-MGMT-MIB Constraints

MIB Object	Notes
<b>cvpdnTunnelTotal</b>	Replaced by cvpdnSystemTunnelTotal.
<b>cvpdnSessionTotal</b>	Replaced by cvpdnSystemSessionTotal.
<b>cvpdnDeniedUsersTotal</b>	Replaced by cvpdnSystemDeniedUsersTotal.
<b>cvpdnTunnelTable</b>	Replaced by cvpdnTunnelAttrTable.
<b>cvpdnTunnelSessionTable</b>	Replaced by cvpdnSessionAttrTable.
<b>cvpdnTemplateTable</b>	SNMP limits the size of VPDN template names to 128 characters. If any template name in the cvpdnTemplateTable exceeds this length, you cannot use an SNMP getmany request to retrieve any table entries. Instead, you must use individual getone requests to retrieve each template name (cvpdnTemplateName) that does not exceed 128 characters.



**Note** CISCO-VPDN-MGMT-MIB does not support L2TPv3.

## CISCO-VOICE-ANALOG-IF-MIB

The CISCO-VOICE-ANALOG-IF-MIB provides the standard configuration, timing parameters, telephony hook, and ring status information on the Cisco Analog Voice interface implementation. This MIB manages the following groups:

- Analog interface general group
- E&M (recEive and transMit) interface group
- FXO (Foreign Exchange Office) interface group
- FXS (Foreign Exchange Station) interface group



**Note** This MIB is not supported on Cisco 1100 Series ISR.

## CISCO-VOICE-COMMON-DIAL-CONTROL-MIB

The CISCO-VOICE-COMMON-DIAL-CONTROL-MIB contains voice-related objects that are common across more than one network encapsulation, such as VoIP, Voice over ATM (VoATM), and Voice over Frame Relay (VoFR).

## CISCO-VOICE-DIAL-CONTROL-MIB

The CISCO-VOICE-DIAL-CONTROL-MIB module enhances the IETF Dial Control MIB (RFC2128) by providing the management of voice telephony peers on both a circuit-switched telephony networks and IP data networks.

## CISCO-VOICE-IF-MIB

The CISCO-VOICE-IF-MIB manages the common voice-related parameters for both voice analog and Integrated Services Digital Network (ISDN) interfaces.



Note

---

This MIB is not supported on Cisco 1100 Series ISR.

---

## CISCO-VOIP-TAP-MIB

The CISCO-VOIP-TAP-MIB module defines the objects to manage the Intercept feature for Voice over IP (VoIP). This MIB is used along with CISCO-TAP2-MIB to intercept the VoIP control and data traffic.

## DIAL-CONTROL-MIB (RFC 2128)

The DIAL-CONTROL-MIB (RFC 2128) contains peer information for demand access.

## DS1-MIB (RFC 2495)

The DS1-MIB(RFC-2495) contains a description of the DS1, E1, DS2, and E2 interface objects.

## MIB Constraints

[Table 3-65](#) describes the constraints that your router places on the objects in the DS1-MIB. For detailed definitions of the MIB objects, see the corresponding MIB.

*Table 3-65 DS1-MIB Constraints*

MIB Object	Notes
<b>dsx1ConfigTable</b>	
<ul style="list-style-type: none"> <li>dsx1LineStatusChangeTrapEnable</li> </ul>	Read only. This MIB object cannot be set through SNMP. The <b>snmp-server enable traps ds1</b> command can be used to enable status change traps.
<ul style="list-style-type: none"> <li>dsx1Channelization</li> </ul>	Read only.
<ul style="list-style-type: none"> <li>dsx1LineLength</li> </ul>	Read only.

Table 3-65 DS1-MIB Constraints (continued)

MIB Object	Notes
• dsx1LineType	Read only.
• dsx1LineCoding	Read only.
• dsx1SendCode	Read only.
• dsx1CircuitIdentifier	Read only.
• dsx1LoopbackConfig	Read only.
• dsx1SignalMode	Read only or SPA-8XCHT1/E1 usage is always none(1).
• dsx1TransmitClockSource	Read only.
• dsx1Fdl	Read only.
• dsx1LoopbackStatus	SPA-8XCHT1/E1 usage: Payload loopbacks are not supported (dsx1NearEndPayloadLoopback, dsx1FarEndPayloadLoopback).
<b>dsx1FracTable</b>	Not implemented.
<b>dsx1FarEndIntervalTable</b>	Not implemented.

## DS3-MIB (RFC 2496)

The DS3-MIB(RFC-2496) contains a description of the DS3 and E3 interface objects.

### MIB Constraints

Table 3-66 lists the constraints that the Cisco 1100 Series ISR places on the objects in the RFC1407-MIB. Objects that are not listed in the table are implemented as defined in the RFC 1407-MIB.

Table 3-66 DS3-MIB Constraints

MIB Object	Notes
<b>dsx3ConfigTable</b>	
• dsx3LineType	Supported values are: <ul style="list-style-type: none"> <li>• T3 supports dsx3M23(2) and dsx3CbitParity(4).</li> <li>• E3 supports e3Framed(7) and e3Plcp(8).</li> </ul>
• dsx3LineCoding	Read only. Supported values are: <ul style="list-style-type: none"> <li>• T3 supports dsx3B3ZS(2).</li> <li>• E3 supports e3HDB3(3).</li> </ul>
• dsx3SendCode	Read only. Supports only dsx3SendNoCode
• dsx3TransmitClockSource	Supported values are loopTiming(1) and localTiming(2).
• dsx3CircuitIdentifier	Read only.
• dsx3LoopbackConfig	Read only.

Table 3-66 DS3-MIB Constraints (continued)

MIB Object	Notes
<b>dsx3FarEndConfigTable</b>	Not implemented.
<b>dsx3FarEndCurrentTable</b>	Not implemented.
<b>dsx3FarEndIntervalTable</b>	Not implemented.
<b>dsx3FarEndTotalTable</b>	Not implemented.
<b>dsx3FracTable</b>	Not implemented.

## Notes

All T3/ATM line cards only support read-only values on all variables.

Currently for the dsx3FracTable to operate, the DS1 layer must be implemented in the ifTable. In this release, this table is shown as not implemented because no rows are instantiated.

## ENTITY-MIB (RFC 4133)

The ENTITY-MIB (RFC 4133) allows functional component discovery. It is used to represent physical and logical entities (components) in the router and manages those entities. The current software release supports the RFC 4133 version of this MIB.

The following are the conformance groups contained in the ENTITY-MIB:

- **entityPhysical** group—Describes the physical entities managed by a single agent.
- **entityLogical** group—Describes the logical entities managed by a single agent.
- **entityMapping** group—Describes the associations between the physical entities, logical entities, interfaces, and non-interface ports managed by a single agent.
- **entityGeneral** group—Describes general system attributes shared by potentially all types of entities managed by a single agent.
- **entityNotifications** group—Contains status indication notifications.

The following groups are added from RFC 4133:

- **entityPhysical2** group—This group augments the **entityPhysical** group.
- **entityLogical2** group—Describes the logical entities managed by a single agent, and replaces **entityLogical** group.

The MIB table **entPhysicalTable** identifies the physical entities in the router. The **entPhysicalTable** contains a single row for the Cisco 1100 Series ISR chassis and a row for each entity in the chassis. A physical entity may contain other entities. For example:

```
entPhysicalDescr.7000 = Cisco C1117-4PM Route Processor
entPhysicalContainedIn.7000 = 1
entPhysicalDescr.7001 = Temp: Int1
entPhysicalContainedIn.7001 = 7000
entPhysicalDescr.7002 = Temp: Int2
entPhysicalContainedIn.7002 = 7000
entPhysicalDescr.7003 = Temp: Int3
entPhysicalContainedIn.7003 = 7000
entPhysicalDescr.7004 = Temp: Int4
entPhysicalContainedIn.7004 = 7000
entPhysicalDescr.7005 = Temp: CPU
entPhysicalContainedIn.7005 = 7000
entPhysicalDescr.7006 = Temp: Wifi
entPhysicalContainedIn.7006 = 7000
```



```

entPhysicalDescr.7035 = CPU 0 of module R0
entPhysicalContainedIn.7035 = 7000
entPhysicalDescr.7036 = USB Port
entPhysicalContainedIn.7036 = 7000
entPhysicalDescr.9000 = Cisco C1117-4PM Forwarding Processor
entPhysicalContainedIn.9000 = 1
entPhysicalDescr.9001 = QFP 0 of module F0
entPhysicalContainedIn.9001 = 9000

```

For the Cisco 1100 Series ISR, the entPhysicalParentRelPos are populated with the slot numbers (except for the RP, ESP, and PEM slot numbers) given in the external label. Table 3-67 lists the mapping between external label and entPhysicalParentRelPos.

**Table 3-67 Mapping the External Label to the entPhysicalParentRelPos Value**

Type	External Label	Value
RP	R0	6 for R0.
FP	F0	8 for F0
Power Supply		3 for Power Supply
CPU		Starts from 0.
QFP		Starts from 0.
Crypto ASIC Module of FP		Starts from 0.

Table 3-68 lists the values of the affected MIB table objects in the Cisco 1100 Series ISR:

**Table 3-68 Affected MIB Objects in a Cisco 1100 Series ISR**

Type	External Label	Value
entPhysicalContainedIn	RP Module	entPhysicalIndex of Chassis
	Built-In NIM Controller	entPhysicalIndex of Chassis
	Module x/y	entPhysicalIndex of NIM subslot
entPhysicalIsFRU	RP Module	false(2)
	Built-In NIM Controller	false(2)
	Module x/y	false(2)
entPhysicalParentRelPos	RP Module	6
	Built-In NIM Controller	from 0
	Module x/y	from 0

## MIB Constraints

Table 3-69 lists the constraints that your router places on the objects in the ENTITY-MIB.

Table 3-69 ENTITY-MIB Constraints

MIB Object	Notes
entPhysicalSoftwareRev	Supported for RP, FP, NIM Controller.
entPhysicalAssetId	Not supported
entPhysicalFirmwareRev	Not supported
entPhysicalHardwareRev	
entPhysicalSerialNum	Implemented as Read only.
entPhysicalModelName	Not implemented for USB.
entPhysicalMfgName	Not implemented for USB.
entPhysicalUris	Implemented as Read only.
entPhysicalAlias	Not supported for transceiver modules and USB. Implemented only as read-write for the following entPhysicalClass entities: <ul style="list-style-type: none"> <li>• Chassis</li> <li>• Power supply</li> <li>• Module</li> </ul>
entPhysicalMfgDate	Not implemented.

## ENTITY-SENSOR-MIB (RFC 3433)

The ENTITY-SENSOR-MIB (RFC 3433) contains objects that manage physical sensors, which are represented in the Entity-MIB with entPhysicalEntry and an entPhysicalClass value of sensor(8). The ENTITY-SENSOR-MIB contains a single table called the entPhySensorTable. The sensor support is provided for the following hardware

- RP
- Transceiver

## ENTITY-STATE-MIB

The ENTITY-STATE-MIB defines objects to extend the functionality provided by the ENTITY-MIB. This MIB supports the entities having these entPhysicalClass values:

- chassis
- Transceiver Container)
- module

- powerSupply

## MIB Constraints

Table 3-70 lists the constraints that your router places on the objects in the ENTITY-STATE-MIB.

Table 3-70 ENTITY-STATE-MIB Constraints

MIB Object	Notes
entStateAlarm	Valid values are: <ul style="list-style-type: none"> <li>• critical</li> <li>• major</li> <li>• minor</li> <li>• warning</li> </ul> These values indicate the CISCO-ENTITY-ALARM-MIB alarm types.
entStateAdmin	Read only.



Note

Power supply and fan alarms are generated on either the Power Entry Module or Fan Tray module. Therefore no alarm is generated on the entStateAlarm associated with either the power supply or the fan.

## ETHERLIKE-MIB (RFC 3635)

The ETHERLIKE-MIB contains objects to manage Ethernet-like interfaces.

## MIB Constraints

Table 3-71 lists the constraints that your router places on the objects in the ETHERLIKE-MIB. Any objects not listed in a table are implemented as defined in the MIB.

Table 3-71 ETHERLIKE-MIB Constraints

MIB Object	Notes
dot3CollTable	Not implemented.
dot3ControlTable	Not implemented.
dot3Control	Not implemented.
dot3PauseAdminMode	Read only.

## EVENT-MIB (RFC 2981)

The EVENT-MIB (RFC 2981) contains objects to define event triggers and actions for network management purposes.

## EXPRESSION-MIB

The EXPRESSION-MIB (RFC 2982) contains objects to define the expressions of MIB objects for network management purposes.

## FRAME-RELAY-DTE-MIB (RFC1315-MIB)

The FRAME-RELAY-DTE-MIB (RFC1315-MIB) contains objects to manage a Frame Relay data terminal equipment (DTE) interface, which consists of a single physical connection to the network with many virtual connections to other destinations and neighbors. The MIB contains the objects used to manage:

- The Data Link Connection Management Interface (DLCMI)
- Virtual circuits on each Frame Relay interface
- Errors detected on Frame Relay interfaces

## MIB Constraints

[Table 3-72](#) lists the constraints that the router places on the objects in the RFC1315-MIB.

*Table 3-72 FRAME-RELAY-DTE-MIB Constraints*

MIB Object	Notes
<b>frDlcmiTable</b> <ul style="list-style-type: none"> <li>• frDlcmiAddress</li> <li>• frDlcmiAddressLen</li> </ul>	Always q922November90(3), which indicates a 10-bit DLCI. Always two-octets(2).
<b>frCircuitTable</b>	

Table 3-72 *FRAME-RELAY-DTE-MIB Constraints (continued)*

MIB Object	Notes
<ul style="list-style-type: none"> <li>frCircuitCommittedBurst</li> <li>frCircuitExcessBurst</li> <li>frCircuitThroughput</li> </ul>	<p>Normally, the QoS configuration entered through the Modular QoS CLI (MQC) syntax does not appear in these frCircuitTable objects.</p> <p>However, when QoS is configured through the MQC and the following conditions are met, these frCircuitTable objects contain the QoS values as they are entered through the MQC:</p> <ul style="list-style-type: none"> <li>The default class is configured on the policy-map only.</li> <li>An output policy is attached to the Frame Relay (FR) Permanent Virtual Circuit (PVC).</li> <li>The Cisco class-based-QoS (CBQ) enhancement only supports two MQC actions: police cir and shape.</li> <li>If both police cir and shape actions exist, then the FR traffic-shaping QoS takes precedence before policing.</li> </ul>
<b>frCircuitState</b> <ul style="list-style-type: none"> <li>frErrTable</li> </ul>	Not supported.

## HC-ALARM-MIB

The HC-ALARM-MIB defines Remote Monitoring MIB extensions for High Capacity Alarms.

### MIB Tables

Table 3-72 lists the tables in HC-ALARM-MIB.

#### *HC-ALARM-MIB Tables*

MIB Table	Description
hcAlarmTable	A list of entries for the configuration of high capacity alarms.

## HC-RMON-MIB

The HC-RMON- MIB augments the original RMON MIB as specified in RFC 1757 and RFC 1513, and RMON2 MIB as specified in RFC 2021. It manages the remote monitoring device implementations.

## IEEE8023-LAG-MIB

The IEEE 8023-LAG- MIB is the Link Aggregation module for managing IEEE Std 802.3ad.

## IF-MIB (RFC 2863)

The IF-MIB (RFC 2863) describes the attributes of physical and logical interfaces (network interface sublayers). The router supports the ifGeneralGroup of MIB objects for all layers (ifIndex, ifDescr, ifType, ifSpeed, ifPhysAddress, ifAdminStatus, ifOperStatus, ifLastChange, ifName, ifLinkUpDownTrapEnable, ifHighSpeed, and ifConnectorPresent).

## MIB Constraints

Table 3-73 lists the constraints that your router places on the objects in the IF-MIB.

Table 3-73 IF-MIB Constraints

MIB Object	Notes
ifPromiscuousMode	Read only.
ifStackStatus	Read only.

## IGMP-STD-MIB (RFC 2933)

The IGMP-STD-MIB(RFC 2933) manages Internet Group Management Protocol (IGMP).

## IP-FORWARD-MIB (RFC 4292)

The IP-FORWARD-MIB (RFC 4292) contains objects to control the display of Classless Interdomain Routing (CIDR) multipath IP Routes.

## MIB Constraints

Table 3-74 lists the constraints that your router places on the objects in the IP-FORWARD-MIB.

Table 3-74 IP-FORWARD-MIB Constraints

MIB Object	Notes
inetCidrRouteTable	Implemented for IPv6 only.

## IP-MIB (RFC 4293)

The IP-MIB (RFC 4293) module contains objects for managing IP and Internet Control Message Protocol (ICMP) implementations, but excluding their management of IP routes.

## MIB Constraints

Table 3-75 lists the constraints that your router places on the objects in the IP-MIB.

Table 3-75 IP-MIB Constraints

MIB Object	Notes
ipDefaultRouterTable	Implemented for IPv6 only.
ipIfStatsTableLastChange	Implemented for IPv6 only.
ipIfStatsTable	Implemented for IPv6 only.

Table 3-75 IP-MIB Constraints (continued)

MIB Object	Notes
ipSystemStatsTable	Implemented for IPv6 only
ipv4InterfaceTableLastChange	Not Implemented.
ipv4InterfaceTable	Not Implemented.
ipAddressPrefixTable	Implemented for IPv6 only.
ipAddressTable	Implemented for IPv6 only.
ipNetToPhysicalTable	Implemented for IPv6 only.
icmpStatsTable	Implemented for IPv6 only.
icmpMsgStatsTable	Implemented for IPv6 only.

## IPMROUTE-STD-MIB (RFC 2932)

The IPMROUTE-STD-MIB (RFC 2932) contains objects to manage IP multicast routing, but independent of the specific multicast routing protocol in use.

### MIB Constraints

Table 3-76 lists the constraints that your router places on the objects in the IPMROUTE-STD-MIB.

Table 3-76 IPMROUTE-STD-MIB Constraints

MIB Object	Notes
ipMRouteScopeNameTable	Not implemented.
ipMRouteEnable	Read only.
ipMRouteInterfaceTtl	Read only.
ipMRouteInterfaceRateLimit	Read only.

## MPLS-L3VPN-STD-MIB (RFC 4382)

The MPLS-L3VPN-STD-MIB contains managed object definitions for the Layer-3 Multiprotocol Label Switching Virtual Private Networks. This MIB is based on RFC 4382 specification.

## MPLS-LDP-GENERIC-STD-MIB (RFC 3815)

The MPLS-LDP-GENERIC-STD-MIB (RFC 3815) contains managed object definitions for configuring and monitoring the Multiprotocol Label Switching (MPLS), Label Distribution Protocol (LDP), utilizing ethernet as the Layer 2 media.



## MPLS-LDP-STD-MIB (RFC 3815)

The MPLS-LDP-STD-MIB (RFC 3815) contains managed object definitions for the Multiprotocol Label Switching (MPLS) and Label Distribution Protocol (LDP) document.

## MPLS-LSR-STD-MIB (RFC 3813)

The MPLS-LSR-STD-MIB (RFC 3031) contains managed object definitions for the Multiprotocol Label Switching (MPLS) router.

## MPLS-TE-MIB

The MPLS-TE-MIB enables the Cisco 1100 Series ISR to perform traffic engineering for MPLS tunnels. The MIB is based on Revision 05 of the IETF MPLS-TE-MIB.

Traffic engineering support for MPLS tunnels requires the following configuration:

- Setting up MPLS tunnels with appropriate configuration parameters.
- Configuring tunnel loose and strict source routed hops.

## MIB Constraints

Table 3-76 lists the constraints that your router places on the objects in the MPLS-TE-MIB.

### *MPLS-TE-MIB Constraints*

MIB Object	Notes
<code>mplsTunnelIndexNext</code>	Read only. Always 0.
<b>mplsTunnelTable</b>	
• <code>mplsTunnelName</code>	Read only.
• <code>mplsTunnelDescr</code>	Read only.
• <code>mplsTunnelIsif</code>	Read only.
• <code>mplsTunnelXCPointer</code>	Read only.
• <code>mplsTunnelSignallingProto</code>	Read only.
• <code>mplsTunnelSetupPrio</code>	Read only. Always 7.
• <code>mplsTunnelHoldingPrio</code>	Read only. Always 7.
• <code>mplsTunnelSessionAttributes</code>	Read only.
• <code>mplsTunnelOwner</code>	Read only.
• <code>mplsTunnelLocalProtectInUse</code>	Read only. Always false(2).
• <code>mplsTunnelResourcePointer</code>	Read only.
• <code>mplsTunnelInstancePriority</code>	Read only. Always 0.
• <code>mplsTunnelHopTableIndex</code>	Read only.

*MPLS-TE-MIB Constraints (continued)*

<b>MIB Object</b>	<b>Notes</b>
<ul style="list-style-type: none"> <li>• mplsTunnelIncludeAnyAffinity</li> <li>• mplsTunnelIncludeAllAffinity</li> <li>• mplsTunnelExcludeAllAffinity</li> <li>• mplsTunnelPathInUse</li> <li>• mplsTunnelRole</li> <li>• mplsTunnelTotalUpTime</li> <li>• mplsTunnelInstanceUpTime</li> <li>• mplsTunnelAdminStatus</li> <li>• mplsTunnelRowStatus</li> <li>• mplsTunnelStorageType</li> </ul>	<p>Read only. Always 0.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only. Always 0.</p> <p>Read only.</p> <p>Read only. Always readOnly(5).</p> <p>Read only. Volatile(2). Always active.</p>
<b>mplsTunnelHopListIndexNext</b>	Read only. Always 0.
<b>mplsTunnelHopTable</b>	
<ul style="list-style-type: none"> <li>• mplsTunnelHopAddrType</li> <li>• mplsTunnelHopIpv4Addr</li> <li>• mplsTunnelHopIpv4PrefixLen</li> <li>• mplsTunnelHopIpv6Addr</li> <li>• mplsTunnelHopIpv6PrefixLen</li> <li>• mplsTunnelHopAsNumber</li> <li>• mplsTunnelHopLspId</li> <li>• mplsTunnelHopType</li> <li>• mplsTunnelHopRowStatus</li> <li>• mplsTunnelHopStorageType</li> </ul>	<p>Read only. Always ipv4(1).</p> <p>Read only.</p> <p>Read only. Always 32.</p> <p>Read only. NULL.</p> <p>Read only. Always 0.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only. Always strict(1).</p> <p>Read only. Always active(1).</p> <p>Read only. Value is readOnly(5).</p>
<b>mplsTunnelResourceIndexNext</b>	Read only. Always 0.
<b>mplsTunnelResourceTable</b>	
<ul style="list-style-type: none"> <li>• mplsTunnelResourceMaxRate</li> <li>• mplsTunnelResourceMeanRate</li> <li>• mplsTunnelResourceMaxBurstSize</li> <li>• mplsTunnelResourceRowStatus</li> </ul>	<p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only. Always active(1).</p>

*MPLS-TE-MIB Constraints (continued)*

MIB Object	Notes
<ul style="list-style-type: none"> <li>mplsTunnelResourceStorageType</li> </ul>	Read only. Value is readOnly(5).
Notes:	
<p>The mplsTunnelTable allows new MPLS tunnels to be created between an MPLS LSR and a remote endpoint and existing tunnels to be reconfigured or removed. The Cisco 1100 Series ISR support point-to-point tunnel segments, although multipoint-to-point and point-to-multipoint connections are supported by an LSR acting as a cross-connect. Each MPLS tunnel can have one out-segment originating at an LSR and one in-segment terminating at that LSR. The mplsTunnelTable is enhanced by the mplsTunnelPerfTable that provides several counters to measure the performance of the MPLS tunnels.</p>	
<p>The mplsTunnelResourceTable indicates the resources required for a tunnel. Multiple tunnels can share the same resources by pointing to the same entry in this table. Tunnels that do not share resources must point to separate entries in this table.</p>	
<p>The mplsTunnelHopTable indicates strict or loose hops for an MPLS tunnel defined in mplsTunnelTable when you establish the hop using signaling. Multiple tunnels share the same hops by pointing to the same entry in this table. Each row also has a secondary index, mplsTunnelHopIndex, corresponding to the next hop of this tunnel. The scalar mplsTunnelMaxHops indicates the maximum number of hops that you can specify on each tunnel supported by this LSR. The mplsTunnelARHopTable indicates the actual hops crossed by a tunnel as reported by the MPLS signaling protocol after the tunnel is set up.</p>	
<p>There are three notifications in this MIB. The notifications mplsTunnelUp and mplsTunnelDown indicate that the value of mplsTunnelOperStatus has transitioned to up(1) or down(2). The notification mplsTunnelRerouted is generated when a tunnel is rerouted or re-optimized.</p>	

## MPLS-TE-STD-MIB

The MPLS-TE-STD-MIB contains managed object definitions for Multiprotocol Label Switching Traffic Engineering (MPLS-TE).

## MPLS-VPN-MIB

The MPLS-VPN-MIB:

- Describes managed objects for modeling a Multiprotocol Label Switching/Border Gateway Protocol virtual private network
- Configures and monitors routes and route targets for each VRF instance on a router
- Facilitates provisioning VPN Routing and Forwarding (VRF) instances on MPLS interfaces
- Measures the performance of MPLS/BGP VPNs

The MIB is based on Revision 05 of the IETF MPLS-VPN-MIB.

## MIB Constraints

Table 3-77 lists the constraints that your router places on the objects in the MPLS-VPN-MIB.

Table 3-77 MPLS-VPN-MIB Constraints

MIB Object	Notes
<b>mplsNumVrfSecViolationThreshExceeded</b>	Not implemented.
<b>mplsVpnVrfSecTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnVrfSecIllegalLabelViolations</li> <li>mplsVpnVrfSecIllegalLabelRcvThresh</li> </ul>	<p>Read only. Always 0.</p> <p>Read only. Always 0.</p>
<b>mplsVpnVrfTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnVrfConfRowStatus</li> <li>mplsVpnVrfConfStorageType</li> <li>mplsVpnVrfConfMidRouteThreshold</li> <li>mplsVpnVrfConfHighRouteThreshold</li> <li>mplsVpnVrfConfMaxRoutes</li> <li>mplsVpnVrfConfMaxPossibleRoutes</li> <li>mplsVpnVrfDescription</li> <li>mplsVpnInterfaceVpnClassification</li> </ul>	<p>Read only.</p> <p>Read only. Volatile(2).</p> <p>Read only.</p> <p>Read only.</p> <p>Read only.</p> <p>Read only. Always 0.</p> <p>Read only.</p> <p>Read only.</p>
<b>mplsVpnInterfaceConfTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnInterfaceConfStorageType</li> <li>mplsVpnInterfaceConfRowStatus</li> <li>mplsVpnInterfaceLabelEdgeType</li> </ul>	<p>Read only. Volatile(2).</p> <p>Read only.</p> <p>Values: active(1), notInService(2).</p> <p>Read only. providerEdge(1).</p>
<b>mplsVpnVrfRouteTargetTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnVrfRouteTargetRowStatus</li> </ul>	Read only. Values: active(1), notInService(2).
<b>mplsVpnVrfBgpNbrAddrTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnVrfBgpNbrRowStatus</li> <li>mplsVpnVrfBgpNbrRole</li> <li>mplsVpnVrfBgpNbrType</li> <li>mplsVpnVrfBgpNbrAddr</li> <li>mplsVpnVrfBgpNbrStorageType</li> </ul>	<p>Read only. Values: active(1), notInService(2).</p> <p>Read only. providerEdge(1).</p> <p>Read only.</p> <p>Read only.</p> <p>Read only. Volatile(2).</p>
<b>mplsVpnVrfRouteTable</b>	
<ul style="list-style-type: none"> <li>mplsVpnVrfRouteInfo</li> <li>mplsVpnVrfRouteTarget</li> <li>mplsVpnVrfRouteTargetDescr</li> <li>mplsVpnVrfRouteDistinguisher</li> <li>mplsVpnVrfRouteNextHopAS</li> </ul>	<p>Read only. Value nullOID.</p> <p>Read only. Determines the route distinguisher for this target.</p> <p>Description of the route target. Currently this object is not supported in this Cisco IOS release. Therefore, the object is the same as mplsVpnVrfRouteTarget.</p> <p>Read only.</p> <p>Read only. Always 0.</p>

Table 3-77 MPLS-VPN-MIB Constraints (continued)

MIB Object	Notes
• mplsVpnVrfRouteRowStatus	Read only. This object normally reads active(1), but may read notInService(2), if a VRF was recently deleted.
• mplsVpnVrfRouteStorageType	Read only. Volatile(2).
• mplsVpnVrfRouteDestAddrType	Read only.
• mplsVpnVrfRouteMaskAddrType	Read only.
• mplsVpnVrfRouteTos	Read only. Always 0.
• mplsVpnVrfRouteNextHop	Read only.
• mplsVpnVrfRouteNextHopAddrType	Read only.
• mplsVpnVrfRouteifIndex	Read only.
• mplsVpnVrfRouteType	Read only.
• mplsVpnVrfRouteProto	Read only.
<b>mplsVpnVrfBgpNbrPrefixTable</b>	Not implemented.

## Notes:

The mplsVpnVrfConfTable represents all the MPLS/BGP VPNs configured. The NMS configures an entry in this table for each MPLS/BGP VPN configured to run in this MPLS domain. The mplsVPNInterfaceConfTable extends the interface MIB to provide specific MPLS/BGP VPN information on MPLS/BGP VPN-enabled interfaces. The mplsVPNPerfTable enhances the mplsVpnVrfConfTable to provide performance information.

The mplsVpnVrfRouteTable and the mplsVpnRouteTargetTable facilitate the configuration and monitoring of routes and route targets, respectively, for each VRF instance.

## MSDP-MIB

The MSDP-MIB contains objects to monitor the Multicast Source Discovery Protocol (MSDP). The MIB can be used with SNMPv3 to remotely monitor MSDP speakers.

For more information about this MIB, see its feature module description at the following URL:

[http://www.cisco.com/en/US/docs/ios/12\\_1t/12\\_1t5/feature/guide/dt5msdp.html](http://www.cisco.com/en/US/docs/ios/12_1t/12_1t5/feature/guide/dt5msdp.html)

## NHRP-MIB

The Cisco NHRP MIB feature introduces support for the NHRP MIB, which helps to manage and monitor the Next Hop Resolution Protocol (NHRP) through the Simple Network Management Protocol (SNMP). Statistics can be collected and monitored through standards-based SNMP techniques (get operations) to query objects defined in the NHRP MIB. The NHRP MIB is VRF-aware and supports VRF-aware queries.

For more information about this MIB, refer:

[http://www.cisco.com/en/US/docs/ios/sec\\_secure\\_connectivity/configuration/guide/sec\\_dmvpn\\_nhrp\\_mib.html](http://www.cisco.com/en/US/docs/ios/sec_secure_connectivity/configuration/guide/sec_dmvpn_nhrp_mib.html)

## MIB Constraints

Table 3-78 lists the constraints that your router places on the objects in the NHRP-MIB.

Table 3-78 NHRP-MIB Constraints

MIB Object	Notes
<code>nhrpClientNbmaSubaddr</code>	Not implemented.
<code>nhrpClientNhsNbmaSubaddr</code>	Not implemented.
<code>nhrpServerNbmaSubaddr</code>	Not implemented.
<code>nhrpServerNhcNbmaSubaddr</code>	Not implemented.
<code>nhrpCachePreference</code>	Not implemented.
<code>nhrpClientDefaultMtu</code>	Not implemented.
<code>nhrpCacheNegotiatedMtu</code>	Not implemented.
<code>nhrpPurgePrefixLength</code>	Not implemented.
<code>nhrpCacheNbmaSubaddr</code>	Not supported.
<code>nhrpCacheType</code>	
<ul style="list-style-type: none"> <li>• <code>atmarp(7)</code></li> <li>• <code>scsp(8)</code></li> </ul>	Not supported.
	Not supported.

## NOTIFICATION-LOG-MIB (RFC 3014)

The NOTIFICATION-LOG-MIB contains objects for logging SNMP notifications; that is, traps and informs types of notifications.

## OLD-CISCO-CHASSIS-MIB

The OLD-CISCO-CHASSIS-MIB describes chassis objects in a device running an old implementation of the Cisco IOS operating system. The chassis objects are now described in the ENTITY-MIB, and OLD-CISCO-CHASSIS-MIB is not supported for the Cisco 1100 Series ISR.

## OLD-CISCO-SYS-MIB

The OLD-CISCO-SYS-MIB defines objects to manage the system bootstrap description and the corresponding version identification.



Note

Currently, only the `whyReload` object is supported in this MIB.

## OSPF-MIB (RFC 1850)

The OSPF-MIB (RFC 1850) contains objects that describe the OSPF Version 2 Protocol. The RFC1253-MIB corresponds to the OSPF-MIB (Open Shortest Path First [OSPF] protocol).

## OSPF-TRAP-MIB (RFC 1850)

The OSPF-TRAP-MIB (RFC 1850) contains objects that describe traps for the OSPF Version 2 Protocol.

## PIM-MIB (RFC 2934)

The PIM-MIB (RFC 2934) contains objects to configure and manage Protocol Independent Multicast (PIM) on the router. The MIB is extracted from RFC 2934.

## MIB Constraints

Table 3-79 lists the constraints that your router place on the objects in the PIM-MIB.

Table 3-79 PIM-MIB Constraints

MIB Object	Notes
<b>pimIpMRouteTable</b>	Not implemented.
<b>pimIpMRouteNextHopTable</b>	Not implemented.
<b>pimInterfaceTable</b>	
• pimInterfaceMode	Read only.
• pimInterfaceHelloInterval	Read only.
• pimInterfaceStatus	Read only.
• pimInterfaceJoinPruneInterval	Read only.
• pimInterfaceCBSRPreference	Read only.
<b>pimJoinPruneInterval</b>	Read only.
<b>pimCandidateRPTTable</b>	
• pimCandidateRPAdressd	Read only.
• pimCandidateRPRowStatus	Read only.
<b>pimComponentTable</b>	
• pimComponentCRPHoldTime	Read only.
• pimComponentStatus	Read only.

## POWER-ETHERNET-MIB

The POWER-ETHERNET-MIB manages Power Source Equipment (PSE) working according to the IEEE 802.af Powered Ethernet (DTE Power via MDI) standard.

Table 3-50 lists the constraints that your router place on the objects in the POWER-ETHERNET-MIB.

#### *POWER-ETHERNET-MIB Constraints*

MIB Object	Constraints
pethMainPowerUsageOnNotification	Not implemented.
pethMainPowerUsageOffNotification	Not implemented.
pethPsePortPowerClassifications	Read Only.

## RFC1213-MIB

The RFC1213-MIB defines the second version of the Management Information Base (MIB-II) for use with network-management protocols in TCP-based internets. This RFC1213-MIB includes the following groups:

- system
- interfaces
- at
- ip
- icmp
- tcp
- udp
- igmp
- transmission
- snmp



**Note**

For more information, refer to the latest RFCs specified in the RFC-1213-MIB.

## RFC2982

The RFC2982-MIB defines expressions of MIB objects for management purposes.

## RMON-MIB (RFC 1757)

The RMON-MIB (RFC 1757) contains objects to remotely monitor devices in the network.

## MIB Constraints

Only alarm and event groups are supported in Cisco ISR 1100 Series Routers.



## RSVP-MIB

The RSVP-MIB contains objects to manage the Resource Reservation Protocol (RSVP).

### MIB Constraints

Table 3-80 lists the constraints that your router places on the objects in the RSVP-MIB.

*Table 3-80 RSVP-MIB Constraints*

MIB Object	Notes
<code>rsvpIfRefreshBlockadeMultiple</code>	Read only.
<code>rsvpIfRefreshMultiple</code>	Read only.
<code>rsvpIfTTL</code>	Read only.
<code>rsvpIfRefreshInterval</code>	Read only.
<code>rsvpIfRouteDelay</code>	Read only.
<code>rsvpIfUdpRequired</code>	Read only.

## SNMP-COMMUNITY-MIB (RFC 2576)

The SNMP-COMMUNITY-MIB (RFC 2576) contains objects that help support coexistence among SNMPv1, SNMPv2c, and SNMPv3.

## SNMP-FRAMEWORK-MIB (RFC 2571)

The SNMP-FRAMEWORK-MIB (RFC 2571) contains objects that describe the SNMP management architecture. There are no constraints on this MIB.

## SNMP-MPD-MIB (RFC 2572)

The SNMP-MPD-MIB (RFC 2572) contains objects for Message Processing and Dispatching (MPD).

## SNMP-NOTIFICATION-MIB (RFC 2573)

The SNMP-NOTIFICATION-MIB (RFC 2573) contains managed objects for SNMPv3 notifications. The MIB also defines a set of filters that limit the number of notifications generated by a particular entity (`snmpNotifyFilterProfileTable` and `snmpNotifyFilterTable`).

Objects in the `snmpNotifyTable` are used to select entities in the SNMP-TARGET-MIB `snmpTargetAddrTable` and specify the types of SNMP notifications those entities are to receive.

## SNMP-PROXY-MIB (RFC 2573)

The SNMP-PROXY-MIB (RFC 2573) contains managed objects to remotely configure the parameters used by an SNMP entity for proxy forwarding operations. The MIB contains a single table, `snmpProxyTable`, which defines the translations to use to forward messages between management targets.

## SNMP-TARGET-MIB (RFC 2573)

The SNMP-TARGET-MIB (RFC 2573) contains objects to remotely configure the parameters used by an entity to generate SNMP notifications. The MIB defines the addresses of entities to send SNMP notifications to, and contains a list of tag values that are used to filter the notifications sent to these entities (see the SNMP-NOTIFICATION-MIB).

## SNMP-USM-MIB (RFC 2574)

The SNMP-USM-MIB (RFC 2574) contains objects that describe the SNMP user-based security model.

## SNMPv2-MIB (RFC 1907)

The SNMPv2-MIB (RFC 1907) contains objects to manage SNMPv2 entities. The SNMPv2-MIB contains the following mandatory object groups:

- `SNMP group`—Collection of objects providing basic instrumentation and control of an SNMP entity.
- `System group`—Collection of objects common to all managed systems.
- `snmpSetGroup`—Collection of objects that allow several cooperating SNMPv2 entities, all acting in a manager role, to coordinate their use of the SNMPv2 set operation.
- `snmpBasicNotificationsGroup`—The two notifications are `coldStart` and `authenticationFailure`, which an SNMPv2 entity is required to implement.

## SNMP-VIEW-BASED-ACM-MIB (RFC 2575)

The SNMP-VIEW-BASED-ACM-MIB (RFC 2575) contains objects that describe the view-based access control model for SNMP.



Note

To access the SNMP-VIEW-BASED-ACM-MIB, you must create an SNMPv3 user with access to a view that includes all of the information from the Internet subtree. For example:

```
Router(config)# snmp-server view abcview internet included
Router(config)# snmp-server group abcgroup v3 noauth read abcview write abcview notify
abcview
Router(config)# snmp-server user abcuser abcgroup v3
```

## TCP-MIB (RFC 4022)

The TCP-MIB (RFC 4022) contains objects to manage the Transmission Control Protocol (TCP) implementations on the router.

## TUNNEL-MIB (RFC 4087)

The TUNNEL-MIB contains objects to manage IP Tunnels independent of the encapsulation scheme in use.

## UDP-MIB (RFC 4113)

The UDP-MIB (RFC4113) contains objects to manage the User Datagram Protocol (UDP) on the router. There are no constraints.

## VRRP-MIB

The VRRP-MIB contains objects to manage Virtual Router Redundancy Protocol (VRRP) routers.

## VRRPV3-MIB (RFC 6527)

The VRRPV3-MIB contains objects to configure, monitor, and control routers that use Virtual Router Redundancy Protocol version 3 (VRRPv3) for both IPv4 and IPv6 addresses. For more information about implementation of the MIB, see [RFC 6527](#).





## Monitoring Notifications

---

This chapter describes the Cisco 1100 Integrated Services Router (ISR) notifications supported by the MIB enhancements feature introduced in Cisco IOS XE Release 3.9S. SNMP uses notifications to report events on a managed device. The notifications are traps or informs for different events. The router also supports other notifications not listed.

This chapter contains the following sections:

- [SNMP Notification Overview, page 1](#)
- [Enabling Notifications, page 2](#)
- [Cisco SNMP Notifications, page 2](#)

### SNMP Notification Overview

An SNMP agent can notify the SNMP manager when important system events occur, such as the following:

- An interface or card starts or stops running
- Temperature thresholds are crossed
- Authentication failures occur

When an agent detects an alarm condition, the agent:

- Logs information about the time, type, and severity of the condition
- Generates a notification message, which it then sends to a designated IP host

SNMP notifications are sent as one of the following:

- Traps—Unreliable messages, which do not require receipt acknowledgement from the SNMP manager.
- Informs—Reliable messages, which are stored in memory until the SNMP manager issues a response. Informs use more system resources than traps.

To use SNMP notifications on your system, you must specify their recipients. These recipients indicate where Network Registrar notifications are directed. By default, all notifications are enabled, but no recipients are defined. Until you define the recipients, no notifications are sent.

Many commands use the key word **traps** in the command syntax. Unless there is an option in the command to select either **traps** or **informs**, the keyword **traps** refers to traps, informs, or both. Use the **snmp-server host** command to specify whether to send SNMP notifications as traps or informs. The types of traps can be specified in command.

**Note**

Most notification types are disabled by default. However, some notification types cannot be controlled with the **snmp** command. For example, some notification types are always enabled and other types are enabled by a different command. The linkUpDown notifications are controlled by the **snmp trap link-status** command. If you enter this command with no notification-type keywords, the default is to enable all notification types controlled by the command.

Specify the trap types if you do not want all traps to be sent. Then use multiple **snmp-server enable traps** commands, one for each of the trap types that you used in the **snmp host** command.

For detailed information about notifications and a list of notification types, go to the following URLs:

- [http://www.cisco.com/en/US/docs/ios/11\\_3/feature/guide/snmpinfm.html](http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/snmpinfm.html)
- [http://www.cisco.com/en/US/docs/ios/11\\_3/feature/guide/snmpprox.html](http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/snmpprox.html)
- [http://www.cisco.com/en/US/docs/ios/11\\_3/feature/guide/xdsl.html](http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/xdsl.html)
- [http://www.cisco.com/en/US/tech/tk648/tk362/technologies\\_tech\\_note09186a008021de3e.shtml](http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a008021de3e.shtml)
- [http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/configuration/guide/fc014.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/fc014.html)

## Enabling Notifications

You can enable MIB notifications using either of the following procedures:

- Using the command-line interface (CLI)—Specify the recipient of the trap message and specify the types of traps sent and the types of informs that are enabled. For detailed procedures, go to:
  - [http://www.cisco.com/en/US/tech/tk648/tk362/technologies\\_tech\\_note09186a008021de3e.shtml](http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a008021de3e.shtml)
  - [http://www.cisco.com/en/US/docs/ios/11\\_3/feature/guide/snmpinfm.html](http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/snmpinfm.html)
- Performing an SNMP SET operation with the **setany** command—To enable or disable MIB notifications, perform an SNMP SET operation on a specific object.
  - To enable the notifications set the object to true(1)
  - To disable the notifications, set the object to false(2)

**Note**

If you issue the **snmp-server enable traps** command without a notification-type argument, the router generates traps for all types of events, which might not be desirable. Some MIBs require the user to set additional objects to enable some notifications.

## Cisco SNMP Notifications

This section contains tables that describe a MIB event, why the event occurred, and a recommendation as to how to handle the event. Each table lists the following information:

- Events—The event display
- Description—What the event indicates
- Probable cause—What might have caused the notification
- Recommended action—Recommendation as to what should be done when the particular notification occurs

**Note**

In the following tables, where “No action is required.” appears in the Recommended Action column, there might be instances where an application, such as trouble ticketing occurs. Environmental or Functional Notifications

Table 4-1 lists notifications generated for events that might indicate the failure of the Cisco 1100 ISR or conditions that might affect router functionality.

**Table 4-1** Environmental or Functional Notifications

Event	Description	Probable Cause	Recommended Action
cefcModuleStatusChange	Indicates that the status of a module has changed.	Module has unknown state.	Enter the <b>show platform</b> command to view error message details. For syslog messages associated with this event, consult Messages and Recovery procedures.
		Module is operational.	No action is required.
		Module has failed due to some condition.	Enter the <b>show platform</b> command to view error message details. For syslog messages associated with this event, consult Messages and Recovery Procedures.
cefcPowerStatusChange	Indicates that the power status of a field replaceable unit has changed.	FRU is powered off because of an unknown problem.	Enter the <b>show power</b> command to check the actual power usage. For syslog messages associated with this event, consult Messages and Recovery Procedures
		FRU is powered on.	No action is required.
		FRU is administratively off.	No action is required.
		FRU is powered off because available system power is insufficient.	Enter the <b>show power</b> command to check the actual power usage.
cefcFRUInserted	Indicates that a FRU was inserted.	A new field-replaceable unit such as modules, fan, port, power supply, or redundant power supply was added.	No action is required.
cefcFRURemoved	Indicates that a FRU was removed.	A field-replaceable unit, such as RP1, modules, fan, ports, power supply, or redundant power supply was removed.	Replace the field-replaceable unit.

Table 4-1 Environmental or Functional Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<b>dsx1LineStatusChange</b>	The dsx1LineStatus is a bit map that contains loopback state and failure state information.	When a failure is detected, the corresponding dsx1LineStatus bit should change to reflect the failure. For example, when a Receiving LOS failure is detected, the corresponding bit (bit 64) should be set to indicate the failure and as a result the dsx1LineStatus changes.	When the dsx1LineStatus reports failures, the recommended action is correction of the conditions causing the error.
<b>cdcVFileCollectionError</b>	Indicates that data collection operations for a cdcVFileEntry has encountered an error.		
<b>cdcFileXferComplete</b>	A file transfer to the destination specified by the cdcVFileMgmtLastXferURL variable, has completed with the status specified by the cdcVFileMgmtLastXferStatus variable.	File transfer complete.	No action is required.
<b>ciscoSonetSectionStatusChange</b>	Indicates that the value of sonetSectionCurrentStatus has changed.	Section loss of: <ul style="list-style-type: none"> <li>• Frame failure</li> <li>• Signal failure</li> </ul>	Enter the <b>show controllers</b> command for the POS interface and check that the Alarm Defects are None and Active Alarms are Zero.
<b>ciscoSonetPathStatusChange</b>	Indicates that the value of sonetPathCurrentStatus has changed.	Caused due to: <ul style="list-style-type: none"> <li>• sonetPathSTSLOP</li> <li>• sonetPathSTSAIS</li> <li>• sonetPathSTSRDI</li> <li>• sonetPathUnequipped</li> <li>• sonetPathSignalLabelMismatch</li> </ul>	Enter the <b>show controllers</b> command for the POS interface and check that the Alarm Defects are None and Active Alarms are Zero.

Table 4-2 lists ENTITY-MIB notifications generated by Cisco 1100 ISR RPs, ESPs, SPAs and SIP Cards.



Table 4-2 RP, ESPs, SPAs, SIP Card Notifications

Event	Description	Probable Cause	Recommended Action
<b>entConfigChange</b>	An entry for the SIP/SPA/Transceiver module is removed from the entPhysicalTable (which causes the value of entLastchangeTime to change).	A SIP/SPA/Transceiver module was removed.	Replace the field-replaceable unit.
<b>entSensorThresholdNotification</b>	Indicates that the sensor value crossed the threshold. This variable reports the most recent measurement seen by the sensor and the threshold value.	<p>The sensor value in a module crossed the threshold listed in entSensorThresholdTable. This notification is generated once each time the sensor value crosses the threshold.</p> <p>The local CPU on the RP was unable to access the temperature sensor on the module. The module will attempt to recover by resetting itself.</p>	<p>Remove the configuration that bypasses the module shutdown due to sensor thresholds being exceeded. Shut down the module after removing the configuration. It exceeded major sensor thresholds.</p> <p><b>Note</b> The command that shuts down the module in the event of a major sensor alarm has been overridden, so the specified module will not be shut down. The command used to override the shutdown is <b>no environment-monitor shutdown</b>.</p> <p>Copy the error message exactly as it appears on the console or in the system log, contact your Cisco technical support representative, and provide the representative with the gathered information.</p>
<b>ceAlarmAsserted</b>	The agent generates this trap when a physical entity asserts an alarm.	You manually shut down the SPA, then you get the SPA error.	Check the entPhysicalDescr type and take the corresponding action; there are many types of asserted alarms.

Table 4-2 RP, ESPs, SPAs, SIP Card Notifications (continued)

Event	Description	Probable Cause	Recommended Action
ceAlarmCleared	The agent generates this trap when a physical entity clears a previously asserted alarm.	The agent generates this trap when a physical entity clears a previously asserted alarm.	No action is required.

## Notes:

Sensor entities are the physical entities whose entity class must be defined to type entity sensor(8) in the entPhysicalTable.

Notifications happen only if the particular entity has an entry in the entity table.

If ceAlarmNotifiesEnable is set to 0, it disables ceAlarmAsserted and ceAlarmCleared notifications. Similarly, when ceAlarmSyslogEnable is set to 0, it disables syslog messages corresponding to alarms.

If ceAlarmHistTableSize is set to 0, it prevents any history from being retained in the ceAlarmHistTable. In addition, whenever the ceAlarmHistTableSize is reset (either increased or decreased), the existing log is deleted.

When a new alarm condition is detected, the carrier alarm LEDs in the individual line cards are currently set by the line card software. The Cisco IOS alarm subsystem does not control the LEDs.

Starting with Release 3.1, alarm description field is added to the ceAlarmCleared and ceAlarmAsserted event notifications.

## Flash Device Notifications

Table 4-3 lists CISCO-FLASH-MIB notifications generated by Cisco 1100 ISR flash devices. These notifications indicate the failure of a flash device or error conditions on the device:

Table 4-3 Flash Device Notifications

Event	Description	Probable Cause	Recommended Action
ciscoFlashDeviceChangeTrap	Indicates a removable flash device was inserted into the router.	Status change occurred.	To determine which flash device was inserted, check the ciscoFlashDeviceTable.
	Indicates removable flash device was removed from the router.	Status change occurred.	To determine which flash device was removed, check the ciscoFlashDeviceTable.

## Interface Notifications

Table 4-4 lists notifications generated by the router for link-related (interface) events.

Table 4-4 *Interface Notifications*

Event	Description	Probable Cause	Recommended Action
<b>linkDown</b>	Indicates that a link is about to enter the down state, which means it cannot transmit or receive traffic. The ifOperStatus object shows the previous state. Value is down(2).	An internal software error might have occurred.	To see if link traps are enabled or disabled on an interface, check ifLinkUpDownTrapEnable (IF-MIB) for the interface. To enable link traps, set ifLinkUpDownTrapEnable to enabled(1).  Enable the IETF (RFC 2233) format of link traps by issuing the CLI command <b>snmp-server trap link ietf</b> .
<b>linkUp</b>	Indicates that a link is no longer down. The value of ifOperStatus indicates the link's new state. Value is up(1).	The port manager reactivated a port in the down state during a switchover.	No action is required.

## Cisco MPLS Notifications

Table 4-5 lists MPLS-VPN notifications that can occur when an environmental threshold is exceeded.

Table 4-5 *MPLS-VPN Notifications*

Event	Description	Probable Cause	Recommended Action
<b>mplsNumVrfRouteMidThreshExceeded</b>	Indicates that the warning threshold is exceeded.  Indicates that a threshold violation occurred.	The system limit of four Route Processors per VPN has been exceeded. The number of routes created has crossed the warning threshold. This warning is sent only at the time the warning threshold is exceeded.	The configured RPs are too large to fit in the DF table for one VPN. Try to configure the groups among existing RPs in the hardware, or configure the RP in another VPN.

Table 4-5 MPLS-VPN Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<b>mplsNumVrfRouteMaxThresholdExceeded</b>	Indicates that the maximum route limit was reached.	A route creation was unsuccessful because the maximum route limit was reached. Another notification is not sent until the number of routes falls below the maximum threshold and reaches the maximum threshold again.	Set the threshold value. The maximum-threshold value is determined by the <b>maximum routes</b> command in VRF configuration mode.
<b>mplsLdpFailedInitSessionThresholdExceeded</b>	Indicates that a local LSR and an adjacent LDP peer attempt to set up an LDP session between them, but fail to do so after a specified number of attempts.	<p>Eight failed attempts occurred to establish an LDP session between a local LSR and an LDP peer due to some type of incompatibility between the devices.</p> <p>Cisco routers support the same features across multiple platforms. Therefore, the most likely incompatibility to occur between Cisco LSRs is a mismatch of their respective ATM VPI/VCI label ranges.</p>	<p>If you specify a range of valid labels for an LSR that does not overlap the range of its adjacent LDP peer, the routers will try eight times to create an LDP session between themselves before the <b>mplsLdpFailedInitSessionThresholdExceeded</b> notification is generated and sent to the NMS as an informational message.</p> <p>Operationally, the LSRs with label ranges that do not overlap continue their attempts to create an LDP session between themselves after the eight retry threshold is exceeded.</p> <p>In such cases, the LDP threshold exceeded notification alerts the network administrator to the existence of a condition in the network that may warrant attention.</p>

## Service Notifications

Table 4-6 lists MPLS-Service notifications generated by the router to indicate conditions for services.

Table 4-6 MPLS Service Notifications

Event	Description	Probable Cause	Recommended Action
<b>mplsVrffUp</b>	Indicates that a VPN routing or forwarding instance (VRF) was assigned to an interface that is operational or for the transition of a VRF interface to the operationally up state.	A VPN routing or forwarding instance (VRF) was assigned to an interface that is operational or a VRF interface transitions to the up state.	No action is required.
<b>mplsVrffDown,</b>	Indicates that a VRF was removed from an interface or a VRF interface transitioned to the operationally down state.	A VRF was removed from an interface or a VRF of an interface transitioned to the down state.	Check the operation state of the interface Or the state of the connected interface on the adjacent router Or add the removed VRF.
<b>mplsLdpSessionUp</b>	Indicates that the MPLS LDP session is in the up state.	Trap generated when an LDP entity (a local LSR) establishes an LDP session with another LDP entity (an adjacent LDP peer in the network).	No action is required.
<b>mplsLdpSessionDown</b>	Indicates that the MPLS LDP session is in the down state.	Trap generated when an LDP session between a local LSR and its adjacent LDP peer is terminated.	Check if the LDP session exists between the local LSR and adjacent LDP peer.
<b>mplsLdpPVLMismatch</b>	Indicates that a local LSR establishes an LDP session with its adjacent peer LSR, but the two LSRs have dissimilar path vector limits.	An LDP session has two adjacent peer LSRs with dissimilar path vector limits.  The value of the path vector limit can range from 0 through 255; a value of “0” indicates that loop detection is off; any value other than zero up to 255 indicates that loop detection is on.	Configure all LDP-enabled routers in the network with the same path vector limit. Accordingly, the <code>mplsLdpPathVectorLimitMismatch</code> object exists in the MPLS-LDP-MIB to provide a warning message to the NMS when two routers engaged in LDP operations have a dissimilar path vector limit.
<b>mplsTunnelUp</b>	Indicates that a <code>mplsTunnelOperStatus</code> object for a configured tunnel is about to transition from the down state to any state except <code>NotPresent</code> .	A configured tunnel transitioned from the down state to any state except <code>NotPresent</code> .  May be caused by an administrative or operational status check of the tunnel.	No action is required.

Table 4-6 MPLS Service Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<b>mplsTunnelDown</b>	Indicates that the mplsTunnelOperStatus object for a configured MPLS traffic engineering tunnel is about to transition to the up(1) or the down(2) state respectively.	A configured tunnel is transitioning to the down state. May be caused by an administrative or operational status check of the tunnel.	
<b>mplsTunnelRerouted</b>	Indicates that the signalling path for an MPLS traffic engineering tunnel changed.	A tunnel was rerouted or reoptimized.	If you use the actual path, then write the new path to mplsTunnelRerouted after the notification is issued.

## Routing Protocol Notifications

Table 4-7 lists BGP4-MIB notifications that the Border Gateway Protocol (BGP) state changes generated by the Cisco 1100 ISR to indicate error conditions for routing protocols and services.

Table 4-7 Routing Protocol Notifications

Event	Description	Probable Cause	Recommended Action
<b>bgpEstablished</b>	The BGP FSM enters the Established state. It becomes active on the router.	BGP changed status.	No action is required.
<b>bgpBackwardTransition</b>	Indicates that BGP transitions from a higher-level state to a lower-level state. The prefix count for an address family on a BGP session exceeded the configured threshold value.	BGP changed status.	

## Cisco Routing Protocol Notifications

Table 4-8 lists the CISCO-BGP4-MIB notifications that occur during the state changes.

Table 4-8 Routing Protocol Notifications

Event	Description	Probable Cause	Recommended Action
<b>cbgpFsmStateChange</b>	This notification is generated for every BGP FSM state change.	BGP FSM state change.	
<b>cbgpBackwardTransition</b>	This notification is generated when the BGP FSM moves from a higher numbered state to a lower numbered state.	BGP FSM state changes from a higher to a lower numbered state.	This threshold value is configured using the CLI command <b>neighbor nbr_addr max_prefixes [threshold] [warning-only]</b> .
<b>cbgpPrefixThresholdExceeded</b>	This notification is generated when prefix count exceeds the configured warning threshold on a session for an address family.	The prefix count exceeds the configured warning threshold on a session.	
<b>cbgpPrefixThresholdClear</b>	This notification is generated when prefix count drops below the configured clear threshold on a session for an address family after the <b>cbgpPrefixThresholdExceeded</b> notification is generated.	The prefix count drops below the configured clear threshold on a session.	
<b>cbgpPeer2EstablishedNotification</b>	This notification is generated when the BGP FSM enters the established state.	BGP FSM enters the established state.	
<b>cbgpPeer2BackwardTransNotification</b>	This notification is generated when the BGP FSM moves from a higher numbered state to a lower numbered state.	BGP FSM moves from a higher numbered state to a lower numbered state.	
<b>cbgpPeer2FsmStateChange</b>	This notification is generated for every BGP FSM state change.	BGP FSM state change.	
<b>cbgpPeer2BackwardTransition</b>	This notification is generated when the BGP FSM moves from a higher numbered state to a lower numbered state.	BGP FSM moves from a higher numbered state to a lower numbered state.	

Table 4-8 Routing Protocol Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<b>cbgpPeer2PrefixThresholdExceeded</b>	This notification is generated when the prefix count exceeds the configured warning threshold in a session for an address family.	The prefix count exceeds the configured warning threshold in a session for an address family.	
<b>cbgpPeer2PrefixThresholdClear</b>	This notification is generated when the prefix count drops below the configured clear threshold in a session for an address family after the <b>cbgpPeer2PrefixThresholdExceeded</b> notification is generated. This notification is not generated if the peer session goes down after the <b>cbgpPrefixThresholdExceeded</b> notification.	The prefix count drops below the configured clear threshold in a session for an address family.	

## RTT Monitor Notifications

Table 4-9 lists CISCO-RTTMON-MIB notifications that can occur during round-trip time (RTT) monitoring.

Table 4-9 RTT Monitor Notifications

Event	Description	Probable Cause	Recommended Action
<b>rttMonConnectionChangeNotification</b>	Sent when the value of <b>rttMonCtrlOperConnectionLostOccurred</b> changes.	Occurs when the connection to a target has either failed to be established or was lost and then re-established.	Check for the connectivity to the target. There could be link problems to the target through different hops.
<b>rttMonTimeoutNotification</b>	A timeout occurred or was cleared.	An RTT probe occurred and the system sends the notice when the value of <b>rttMonCtrlOperTimeoutOccurred</b> changes.	Check for the end-to-end connectivity if <b>rttMonCtrlOperTimeoutOccurred</b> in the notification returns true.  No action is required if <b>rttMonCtrlOperTimeoutOccurred</b> is false.
<b>rttMonThresholdNotification</b>	Threshold violation occurred.	An RTT probe occurred or a previous violation has subsided in a subsequent RTT operation.	Check for the end-to-end connectivity if <b>rttMonCtrlOperOverThresholdOccurred</b> in the notification is true; otherwise, no action is required.



## Redundancy Framework Notifications

Table 4-10 lists CISCO-RF-MIB notifications that can occur in a redundant system. There are two types of notifications:

- Switch of Activity (SWACT)—Either a forced or automatic switch of active status from the active unit to the standby unit. The former standby unit is now referred to as the active unit.
- Progression—The process of making the redundancy state of the standby unit equivalent to that of the active unit. This includes transitioning the RF state machine through several states, which drives the RF clients on the active unit to synchronize any relevant data with their peer on the standby unit.

Table 4-10 Redundancy Framework Notifications

Event	Description	Probable Cause	Recommended Action
<code>ciscoRFSwactNotif</code>	Indicates that the RF state changed.  A switch of activity notification is sent by the newly active redundant unit.	A switch of activity occurs. If a SWACT event is indistinguishable from a reset event, then a network management station should use this notification to differentiate the activity.	If the switchover occurred because the active unit failed (indicated by <code>cRFStatusLastSwactReasonCode</code> ) see if there are any hardware failures; otherwise, no action is required.
<code>ciscoRFProgressionNotif</code>	Indicates that the RF state changed.	The active redundant unit RF state changed or the RF state of the peer unit changed.	To avoid an increase of notifications for all state transitions, send notifications for transitions to the following RF states: <ul style="list-style-type: none"> <li>• <code>standbyCold(5)</code></li> <li>• <code>standbyHot(9)</code></li> <li>• <code>active(14)</code></li> <li>• <code>activeExtraload(15)</code></li> </ul>

## CPU Usage Notifications

Table 4-11 lists CISCO-PROCESS-MIB notifications that can occur.

Table 4-11 CISCO-PROCESS-MIB Notifications

Event	Description	Probable Cause	Recommended Action
cpmCPURisingThreshold	Indicates the rising threshold for system-wide CPU utilization.	When the system-wide CPU utilization crosses (exceeds) the rising threshold, a notification (SNMP/Syslog) is generated.  After sending a rising threshold notification, a second rising threshold notification will be sent only if a falling threshold notification corresponding to the first rising threshold notification has been sent.	—
cpmCPUFallingThreshold	Indicates the falling threshold for system-wide CPU utilization.	If the system-wide CPU utilization falls below the falling threshold, a notification is generated.  The falling threshold notification is generated only if a rising threshold notification had been sent out previously.	—

## QFP Notifications

Table 4-12 lists CISCO-ENTITY-QFP-MIB notifications generated by the Cisco 1100 ISR.

Table 4-12 CISCO-ENTITY-QFP-MIB Notifications

Event	Description	Probable Cause	Recommended Action
ceqfpMemoryResRisingThreshNotif	Indicates that the QFP memory usage is equal to or greater than the rising threshold limit (ceqfpMemoryResRisingThreshold).	Occurs when the memory usage exceeds the upper threshold limit.	—
ceqfpMemoryResFallingThreshNotif	Indicates that the QFP memory usage is equal to or less than the falling threshold limit(ceqfpMemoryResFallingThreshold).	Occurs when the memory usage falls below the lower threshold limit.	—

## Unified Firewall Notifications

Table 4-13 lists CISCO-UNIFIED-FIREWALL-MIB notifications generated by firewall subsystem. Cisco 1100 ISR platform only supports the statistics for the zone base firewall in CISCO-UNIFIED-FIREWALL-MIB; notifications listed in Table 4-1 are now supported.

Table 4-13 CISCO-UNIFIED-FIREWALL-MIB Notifications

Event	Description	Probable Cause	Recommended Action
ciscoUFWurlfServerStateChange	Indicates that the firewall selected a new primary URL filtering server from the existing list of available servers.	Occurs when the current primary server becomes unavailable or when a server is explicitly nominated as primary filtering server.	—
ciscoUFWL2StaticMacAddressMoved	Indicates that the firewall detected change in a static MAC address to a new port.	Occurs when: <ul style="list-style-type: none"> <li>The device with the MAC Address is physically moved to a new port.</li> <li>MAC address is explicitly moved to a new location.</li> <li>MAC address spoofing is encountered in the system.</li> </ul>	—

## Image License Management Notifications

Table 4-14 lists the CISCO-IMAGE-LICENSE-MGMT-MIB notifications.

Table 4-14 CISCO-IMAGE-LICENSE-MGMT-MIB Notifications

Event	Description	Probable Cause	Recommended Action
cilmBootImageLevelChanged	Indicates that the boot image level is changed.	Occurs when the boot image level is changed in the management entity.	—

## License Management Notifications

Table 4-15 lists the CISCO-LICENSE-MGMT-MIB notifications.

Table 4-15 CISCO-LICENSE-MGMT-MIB Notifications

Event	Description	Probable Cause	Recommended Action
<b>clmgmtLicenseExpired</b>	Indicates that a license has expired.	Occurs when a license expires.	—
<b>clmgmtLicenseExpiryWarning</b>	Indicates that a license is about to expire.	Occurs when a license is about to expire.	—
<b>clmgmtLicenseUsageCountExceeded</b>	Indicates that the value of the <code>clmgmtLicenseUsageCountRemaining</code> attribute has reached the <code>clmgmtLicenseMaxUsageCount</code> threshold value for a counting license.	Occurs when the value of <code>clmgmtLicenseUsageCountRemaining</code> has reached <code>clmgmtLicenseMaxUsageCount</code> for a counting license.	—
<b>clmgmtLicenseUsageCountAboutToExceed</b>	Indicates that the value of the <code>clmgmtLicenseUsageCountRemaining</code> attribute has reached 80% of the <code>clmgmtLicenseMaxUsageCount</code> for a counting license.	Occurs when <code>clmgmtLicenseUsageCountRemaining</code> has reached 80% of <code>clmgmtLicenseMaxUsageCount</code> for a counting license.	—
<b>clmgmtLicenseInstalled</b>	Indicates that a license is installed successfully.	Occurs when a license is installed successfully.	—
<b>clmgmtLicenseCleared</b>	Indicates that a license is cleared successfully.	Occurs when a license is cleared successfully.	—
<b>clmgmtLicenseRevoked</b>	Indicates that a license is revoked successfully.	Occurs when a license is revoked successfully.	—
<b>clmgmtLicenseEULAAccepted</b>	Indicates that a user has accepted the End-User License Agreement (EULA) for a license.	Occurs when a user accepts the EULA for a license.	—
<b>clmgmtLicenseNotEnforced</b>	Indicates that a license does not exist for a mandatory feature.	Occurs when a license does not exist for a mandatory feature.	—
<b>clmgmtLicenseSubscriptionExpiryWarning</b>	Indicates that the subscription license of a feature is about to expire.	Occurs when the subscription license of a feature is about to expire.	—

Table 4-15 CISCO-LICENSE-MGMT-MIB Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<b>clmgmtLicenseSubscriptionExtExpiry Warning</b>	Indicates that the subscription license of a feature has expired but the extension period is available.	Occurs when that the subscription license of a feature has expired but the extension period is available.	—
<b>clmgmtLicenseSubscriptionExpired</b>	Indicates that the subscription license of a feature has expired.	Occurs when the subscription license of a feature has expired.	—
<b>clmgmtLicenseEvalRTUTransitionWarning</b>	Indicates that an evaluation license is about to be transitioned an a Right-to-Use (RTU) license.	Occurs when evaluation license is about to be transitioned as a RTU license.	—
<b>clmgmtLicenseEvalRTUTransition</b>	Indicates that a feature license has transitioned from an evaluation license to an RTU license.	Occurs when a feature license has transitioned from being an evaluation license to an RTU license.	—





# Using MIBs

---

This chapter describes how to perform tasks on the Cisco 1100 Series ISR

- [Cisco Unique Device Identifier Support, page 5-1](#)
- [Managing Physical Entities, page 5-2](#)
- [Monitoring Router Interfaces, page 5-29](#)
- [Billing Customers for Traffic, page 5-30](#)
- [Using IF-MIB Counters, page 5-34](#)

## Cisco Unique Device Identifier Support

The ENTITY-MIB now supports the Cisco compliance effort for a Cisco unique device identifier (UDI) standard which is stored in IDPROM.

The Cisco UDI provides a unique identity for every Cisco product. The UDI is composed of three separate data elements which must be stored in the entPhysicalTable:

- **Orderable product identifier (PID)—Product Identifier (PID).** PID is the alphanumeric identifier used by customers to order Cisco products. Two examples include NM-1FE-TX or CISCO3745. PID is limited to 18 characters and must be stored in the entPhysicalModelName object.
- **Version identifier (VID)—Version Identifier (VID).** VID is the version of the PID. The VID indicates the number of times a product has versioned in ways that are reported to a customer. For example, the product identifier NM-1FE-TX may have a VID of V04. VID is limited to three alphanumeric characters and must be stored in the entPhysicalHardwareRev object.
- **Serial number (SN)—Serial number** is the 11-character identifier used to identify a specific part within a product and must be stored in the entPhysicalSerialNum object. Serial number content is defined by manufacturing part number 7018060-0000. The SN is accessed at the following website by searching on the part number 701806-0000:

<https://sso.cisco.com/autho/forms/MCOlogin.html>

Serial number format is defined in four fields:

- Location (L)
- Year (Y)
- Workweek (W)
- Sequential serial ID (S)

The SN label is represented as: LLLYYWWSSS.

**Note**

The Version ID returns NULL for those old or existing cards whose IDPROMs do not have the Version ID field. Therefore, corresponding `entPhysicalHardwareRev` returns NULL for cards that do not have the Version ID field in IDPROM.

## Managing Physical Entities

This section describes how to use SNMP to manage the physical entities (components) in the router by:

- [Performing Inventory Management, page 5-3](#)
  - [Determining the ifIndex Value for a Physical Port, page 5-14](#)
  - [Monitoring and Configuring FRU Status, page 5-14](#)
- [Generating SNMP Notifications, page 5-28](#)

### Purpose and Benefits

The physical entity management feature of the Cisco 1100 Series ISR SNMP implementation does the following:

- Monitors and configures the status of field replaceable units (FRUs)
- Provides information about physical port to interface mappings
- Provides asset information for asset tagging
- Provides firmware and software information for chassis components

### MIBs Used for Physical Entity Management

- CISCO-ENTITY-FRU-CONTROL-MIB—Contains objects used to monitor and configure the administrative and operational status of field replaceable units (FRUs), such as power supplies and line cards, that are listed in the `entPhysicalTable` of the ENTITY-MIB.
- CISCO-ENTITY-EXT-MIB - Contains Cisco defined extensions to the `entPhysicalTable` of the ENTITY-MIB to provide information for entities with an `entPhysicalClass` value of 'module' that have a CPU, RAM/NVRAM, and/or a configuration register.
- CISCO-ENTITY-SENSOR-MIB and ENTITY-SENSOR-MIB—Contain information about entities in the `entPhysicalTable` with an `entPhysicalClass` value of 'sensor'.
- CISCO-ENTITY-VENDORTYPE-OID-MIB—Contains the object identifiers (OIDs) for all physical entities in the router.
- ENTITY-MIB—Contains information for managing physical entities on the router. It also organizes the entities into a containment tree that depicts their hierarchy and relationship to each other. The MIB contains the following tables:
  - The `entPhysicalTable` describes each physical component (entity) in the router. The table contains an entry for the top-level entity (the chassis) and for each entity in the chassis. Each entry provides information about that entity: its name, type, vendor, and a description, and describes how the entity fits into the hierarchy of chassis entities. Each entity is identified by a unique index (*entPhysicalIndex*) that is used to access information about the entity in this and other MIBs.
  - The `entAliasMappingTable` maps each physical port's `entPhysicalIndex` value to its corresponding `ifIndex` value in the IF-MIB `ifTable`.
  - The `entPhysicalContainsTable` shows the relationship between physical entities in the chassis. For each physical entity, the table lists the `entPhysicalIndex` for each of the entity's child objects.
  - The `entPhysicalIsFRU` indicates whether or not a physical entity is considered a Field Replaceable Unit (FRU). For an entity identified as FRU, the physical entity contains the following device-specific information:



- entPhysicalModelName- Product Identification (PID), same as orderable part number.
- entPhysicalHardwareRev- Version Identification (VID)
- entPhysicalSerialNum- Serial Number (SN)
- Cisco Unique Device Identifier (UDI)- Composed of PID, VID and SN, it provides a unique identity for all Cisco hardware products on which it has been enabled.

## Performing Inventory Management

To obtain information about entities in the router, perform a MIB walk on the ENTITY-MIB entPhysicalTable.

As you examine sample entries in the ENTITY-MIB entPhysicalTable, consider the following:

- entPhysicalIndex—Uniquely identifies each entity in the chassis. This index is also used to access information about the entity in other MIBs.
- entPhysicalContainedIn—Indicates the entPhysicalIndex of a component's parent entity.
- entPhysicalParentRelPos—Shows the relative position of same-type entities that have the same entPhysicalContainedIn value (for example, chassis slots, and line card ports).



**Note** The container is applicable if the physical entity class is capable of containing one or more removable physical entities. For example, each (empty or full) slot in a chassis is modeled as a container. All removable physical entities should be modeled within a container entity, such as field-replaceable modules, fans, or power supplies.

### Sample of ENTITY-MIB entPhysicalTable Entries

The samples in this section show how information is stored in the entPhysicalTable. You can perform asset inventory by examining entPhysicalTable entries.



**Note** The sample outputs and values that appear throughout this chapter are examples of data you can view when using MIBs.

The following output shows the ENTITY-MIB entPhysicalTable sample entries for RP card.

#### ENTITY-MIB entPhysicalTable Entries

```
entPhysicalDescr.7000 = Cisco ISR1100 Route Processor
entPhysicalDescr.7001 = Temp: Inlet 1
entPhysicalDescr.7002 = Temp: Inlet 2
entPhysicalDescr.7003 = Temp: Outlet 1
entPhysicalDescr.7004 = Temp: Outlet 2
entPhysicalDescr.7005 = Temp: core-A
entPhysicalDescr.7006 = Temp: core-B
entPhysicalDescr.7007 = Temp: core-C
entPhysicalDescr.7008 = V: 12v
entPhysicalDescr.7009 = V: 5v
entPhysicalDescr.7010 = V: 3.3v
entPhysicalDescr.7011 = V: 3.0v
entPhysicalDescr.7012 = V: 2.5v
entPhysicalDescr.7013 = V: 1.05v
entPhysicalDescr.7014 = V: 1.8v
entPhysicalDescr.7015 = V: 1.2v
entPhysicalDescr.7016 = V: Vcore-C
entPhysicalDescr.7017 = V: 1.1v
entPhysicalDescr.7018 = V: 1.0v
entPhysicalDescr.7019 = V: 1.8v-A
```

```

entPhysicalDescr.7020 = V: 1.5v-A
entPhysicalDescr.7021 = V: 1.5v-C1
entPhysicalDescr.7022 = V: 1.5v-B
entPhysicalDescr.7023 = V: Vcore-A
entPhysicalDescr.7024 = V: 1.5v-C2
entPhysicalDescr.7025 = V: Vcore-B1
entPhysicalDescr.7026 = V: Vcore-B2
entPhysicalDescr.7027 = V: 0.75v-B
entPhysicalDescr.7028 = V: 0.75v-C
entPhysicalDescr.7029 = I: 12v
entPhysicalDescr.7030 = P: pwr
entPhysicalDescr.7035 = CPU 0 of module R0
entPhysicalDescr.7036 = USB Port
entPhysicalDescr.7038 = USB Port
entPhysicalDescr.7040 = Network Management Ethernet

```

```

entPhysicalContainedIn.7000 = 1
entPhysicalContainedIn.7001 = 7000
entPhysicalContainedIn.7002 = 7000
entPhysicalContainedIn.7003 = 7000
entPhysicalContainedIn.7004 = 7000
entPhysicalContainedIn.7005 = 7000
entPhysicalContainedIn.7006 = 7000
entPhysicalContainedIn.7007 = 7000
entPhysicalContainedIn.7008 = 7000
entPhysicalContainedIn.7009 = 7000
entPhysicalContainedIn.7010 = 7000
entPhysicalContainedIn.7011 = 7000
entPhysicalContainedIn.7012 = 7000
entPhysicalContainedIn.7013 = 7000
entPhysicalContainedIn.7014 = 7000
entPhysicalContainedIn.7015 = 7000
entPhysicalContainedIn.7016 = 7000
entPhysicalContainedIn.7017 = 7000
entPhysicalContainedIn.7018 = 7000
entPhysicalContainedIn.7019 = 7000
entPhysicalContainedIn.7020 = 7000
entPhysicalContainedIn.7021 = 7000
entPhysicalContainedIn.7022 = 7000
entPhysicalContainedIn.7023 = 7000
entPhysicalContainedIn.7024 = 7000
entPhysicalContainedIn.7025 = 7000
entPhysicalContainedIn.7026 = 7000
entPhysicalContainedIn.7027 = 7000
entPhysicalContainedIn.7028 = 7000
entPhysicalContainedIn.7029 = 7000
entPhysicalContainedIn.7030 = 7000
entPhysicalContainedIn.7035 = 7000
entPhysicalContainedIn.7036 = 7000
entPhysicalContainedIn.7038 = 7000
entPhysicalContainedIn.7040 = 7000

```

where **entPhysicalContainedIn** indicates the entPhysicalIndex of a component's parent entity.

```

entPhysicalClass.7000 = module(9)
entPhysicalClass.7001 = sensor(8)
entPhysicalClass.7002 = sensor(8)
entPhysicalClass.7003 = sensor(8)
entPhysicalClass.7004 = sensor(8)

```

```
entPhysicalClass.7005 = sensor(8)
entPhysicalClass.7006 = sensor(8)
entPhysicalClass.7007 = sensor(8)
entPhysicalClass.7008 = sensor(8)
entPhysicalClass.7009 = sensor(8)
entPhysicalClass.7010 = sensor(8)
entPhysicalClass.7011 = sensor(8)
entPhysicalClass.7012 = sensor(8)
entPhysicalClass.7013 = sensor(8)
entPhysicalClass.7014 = sensor(8)
entPhysicalClass.7015 = sensor(8)
entPhysicalClass.7016 = sensor(8)
entPhysicalClass.7017 = sensor(8)
entPhysicalClass.7018 = sensor(8)
entPhysicalClass.7019 = sensor(8)
entPhysicalClass.7020 = sensor(8)
entPhysicalClass.7021 = sensor(8)
entPhysicalClass.7022 = sensor(8)
entPhysicalClass.7023 = sensor(8)
entPhysicalClass.7024 = sensor(8)
entPhysicalClass.7025 = sensor(8)
entPhysicalClass.7026 = sensor(8)
entPhysicalClass.7027 = sensor(8)
entPhysicalClass.7028 = sensor(8)
entPhysicalClass.7029 = sensor(8)
entPhysicalClass.7030 = sensor(8)
entPhysicalClass.7035 = cpu(12)
entPhysicalClass.7036 = port(10)
entPhysicalClass.7038 = port(10)
entPhysicalClass.7040 = port(10)
```

where **entPhysicalClass** indicates the general type of hardware device.

```
entPhysicalParentRelPos.7000 = 6
entPhysicalParentRelPos.7001 = 0
entPhysicalParentRelPos.7002 = 1
entPhysicalParentRelPos.7003 = 2
entPhysicalParentRelPos.7004 = 3
entPhysicalParentRelPos.7005 = 4
entPhysicalParentRelPos.7006 = 5
entPhysicalParentRelPos.7007 = 6
entPhysicalParentRelPos.7008 = 7
entPhysicalParentRelPos.7009 = 8
entPhysicalParentRelPos.7010 = 9
entPhysicalParentRelPos.7011 = 10
entPhysicalParentRelPos.7012 = 11
entPhysicalParentRelPos.7013 = 12
entPhysicalParentRelPos.7014 = 13
entPhysicalParentRelPos.7015 = 14
entPhysicalParentRelPos.7016 = 15
entPhysicalParentRelPos.7017 = 16
entPhysicalParentRelPos.7018 = 17
entPhysicalParentRelPos.7019 = 18
entPhysicalParentRelPos.7020 = 19
entPhysicalParentRelPos.7021 = 20
entPhysicalParentRelPos.7022 = 21
entPhysicalParentRelPos.7023 = 22
entPhysicalParentRelPos.7024 = 23
entPhysicalParentRelPos.7025 = 24
entPhysicalParentRelPos.7026 = 25
entPhysicalParentRelPos.7027 = 26
entPhysicalParentRelPos.7028 = 27
entPhysicalParentRelPos.7029 = 28
```

```

entPhysicalParentRelPos.7030 = 29
entPhysicalParentRelPos.7035 = 0
entPhysicalParentRelPos.7036 = 0
entPhysicalParentRelPos.7038 = 1
entPhysicalParentRelPos.7040 = 2

```

where **entPhysicalParentRelPos** indicates the relative position of this child among the other entities.

```

entPhysicalName.7000 = module R0
entPhysicalName.7001 = Temp: Inlet 1 R0/0
entPhysicalName.7002 = Temp: Inlet 2 R0/1
entPhysicalName.7003 = Temp: Outlet 1 R0/2
entPhysicalName.7004 = Temp: Outlet 2 R0/3
entPhysicalName.7005 = Temp: core-A R0/4
entPhysicalName.7006 = Temp: core-B R0/5
entPhysicalName.7007 = Temp: core-C R0/6
entPhysicalName.7008 = V: 12v R0/7
entPhysicalName.7009 = V: 5v R0/8
entPhysicalName.7010 = V: 3.3v R0/9
entPhysicalName.7011 = V: 3.0v R0/10
entPhysicalName.7012 = V: 2.5v R0/11
entPhysicalName.7013 = V: 1.05v R0/12
entPhysicalName.7014 = V: 1.8v R0/13
entPhysicalName.7015 = V: 1.2v R0/14
entPhysicalName.7016 = V: Vcore-C R0/15
entPhysicalName.7017 = V: 1.1v R0/16
entPhysicalName.7018 = V: 1.0v R0/17
entPhysicalName.7019 = V: 1.8v-A R0/18
entPhysicalName.7020 = V: 1.5v-A R0/19
entPhysicalName.7021 = V: 1.5v-C1 R0/20
entPhysicalName.7022 = V: 1.5v-B R0/21
entPhysicalName.7023 = V: Vcore-A R0/22
entPhysicalName.7024 = V: 1.5v-C2 R0/23
entPhysicalName.7025 = V: Vcore-B1 R0/24
entPhysicalName.7026 = V: Vcore-B2 R0/25
entPhysicalName.7027 = V: 0.75v-B R0/26
entPhysicalName.7028 = V: 0.75v-C R0/27
entPhysicalName.7029 = I: 12v R0/28
entPhysicalName.7030 = P: pwr R0/29
entPhysicalName.7035 = cpu R0/0
entPhysicalName.7036 = usb R0/0
entPhysicalName.7038 = usb R0/1
entPhysicalName.7040 = NME R0

```

where **entPhysicalName** provides the textual name of the physical entity.

```

entPhysicalHardwareRev.7000 = V01
entPhysicalHardwareRev.7001 =
entPhysicalHardwareRev.7002 =
entPhysicalHardwareRev.7003 =
entPhysicalHardwareRev.7004 =
entPhysicalHardwareRev.7005 =
entPhysicalHardwareRev.7006 =
entPhysicalHardwareRev.7007 =
entPhysicalHardwareRev.7008 =
entPhysicalHardwareRev.7009 =
entPhysicalHardwareRev.7010 =
entPhysicalHardwareRev.7011 =
entPhysicalHardwareRev.7012 =

```

```
entPhysicalHardwareRev.7013 =
entPhysicalHardwareRev.7014 =
entPhysicalHardwareRev.7015 =
entPhysicalHardwareRev.7016 =
entPhysicalHardwareRev.7017 =
entPhysicalHardwareRev.7018 =
entPhysicalHardwareRev.7019 =
entPhysicalHardwareRev.7020 =
entPhysicalHardwareRev.7021 =
entPhysicalHardwareRev.7022 =
entPhysicalHardwareRev.7023 =
entPhysicalHardwareRev.7024 =
entPhysicalHardwareRev.7025 =
entPhysicalHardwareRev.7026 =
entPhysicalHardwareRev.7027 =
entPhysicalHardwareRev.7028 =
entPhysicalHardwareRev.7029 =
entPhysicalHardwareRev.7030 =
entPhysicalHardwareRev.7035 =
entPhysicalHardwareRev.7036 =
entPhysicalHardwareRev.7038 =
entPhysicalHardwareRev.7040 =
```

where **entPhysicalHardware** provides the vendor-specific hardware revision number (string) for the physical entity.

```
entPhysicalSerialNum.7000 = FOC16150HB1
entPhysicalSerialNum.7001 =
entPhysicalSerialNum.7002 =
entPhysicalSerialNum.7003 =
entPhysicalSerialNum.7004 =
entPhysicalSerialNum.7005 =
entPhysicalSerialNum.7006 =
entPhysicalSerialNum.7007 =
entPhysicalSerialNum.7008 =
entPhysicalSerialNum.7009 =
entPhysicalSerialNum.7010 =
entPhysicalSerialNum.7011 =
entPhysicalSerialNum.7012 =
entPhysicalSerialNum.7013 =
entPhysicalSerialNum.7014 =
entPhysicalSerialNum.7015 =
entPhysicalSerialNum.7016 =
entPhysicalSerialNum.7017 =
entPhysicalSerialNum.7018 =
entPhysicalSerialNum.7019 =
entPhysicalSerialNum.7020 =
entPhysicalSerialNum.7021 =
entPhysicalSerialNum.7022 =
entPhysicalSerialNum.7023 =
entPhysicalSerialNum.7024 =
entPhysicalSerialNum.7025 =
entPhysicalSerialNum.7026 =
entPhysicalSerialNum.7027 =
entPhysicalSerialNum.7028 =
entPhysicalSerialNum.7029 =
entPhysicalSerialNum.7030 =
entPhysicalSerialNum.7035 =
entPhysicalSerialNum.7036 =
entPhysicalSerialNum.7038 =
entPhysicalSerialNum.7040 =
```

where **entPhysicalSerialNumber** provides the vendor-specific serial number (string) for the physical entity.

```
entPhysicalMfgName.7000 = Cisco Systems Inc
entPhysicalMfgName.7001 =
entPhysicalMfgName.7002 =
entPhysicalMfgName.7003 =
entPhysicalMfgName.7004 =
entPhysicalMfgName.7005 =
entPhysicalMfgName.7006 =
entPhysicalMfgName.7007 =
entPhysicalMfgName.7008 =
entPhysicalMfgName.7009 =
entPhysicalMfgName.7010 =
entPhysicalMfgName.7011 =
entPhysicalMfgName.7012 =
entPhysicalMfgName.7013 =
entPhysicalMfgName.7014 =
entPhysicalMfgName.7015 =
entPhysicalMfgName.7016 =
entPhysicalMfgName.7017 =
entPhysicalMfgName.7018 =
entPhysicalMfgName.7019 =
entPhysicalMfgName.7020 =
entPhysicalMfgName.7021 =
entPhysicalMfgName.7022 =
entPhysicalMfgName.7023 =
entPhysicalMfgName.7024 =
entPhysicalMfgName.7025 =
entPhysicalMfgName.7026 =
entPhysicalMfgName.7027 =
entPhysicalMfgName.7028 =
entPhysicalMfgName.7029 =
entPhysicalMfgName.7030 =
entPhysicalMfgName.7035 =
entPhysicalMfgName.7036 =
entPhysicalMfgName.7038 =
entPhysicalMfgName.7040 =
```

where **entPhysicalMfgName** provides the manufacturer's name for the physical component.

```
entPhysicalModelName.7000 = ISR4451/K9
entPhysicalModelName.7001 =
entPhysicalModelName.7002 =
entPhysicalModelName.7003 =
entPhysicalModelName.7004 =
entPhysicalModelName.7005 =
entPhysicalModelName.7006 =
entPhysicalModelName.7007 =
entPhysicalModelName.7008 =
entPhysicalModelName.7009 =
entPhysicalModelName.7010 =
entPhysicalModelName.7011 =
entPhysicalModelName.7012 =
entPhysicalModelName.7013 =
entPhysicalModelName.7014 =
entPhysicalModelName.7015 =
entPhysicalModelName.7016 =
entPhysicalModelName.7017 =
entPhysicalModelName.7018 =
entPhysicalModelName.7019 =
entPhysicalModelName.7020 =
entPhysicalModelName.7021 =
```

```
entPhysicalModelName.7022 =  
entPhysicalModelName.7023 =  
entPhysicalModelName.7024 =  
entPhysicalModelName.7025 =  
entPhysicalModelName.7026 =  
entPhysicalModelName.7027 =  
entPhysicalModelName.7028 =  
entPhysicalModelName.7029 =  
entPhysicalModelName.7030 =  
entPhysicalModelName.7035 =  
entPhysicalModelName.7036 =  
entPhysicalModelName.7038 =  
entPhysicalModelName.7040 =
```

where **entPhysicalModelName** provides the vendor-specific model name string for the physical component.

```
entPhysicalIsFRU.7000 = false(2)  
entPhysicalIsFRU.7001 = false(2)  
entPhysicalIsFRU.7002 = false(2)  
entPhysicalIsFRU.7003 = false(2)  
entPhysicalIsFRU.7004 = false(2)  
entPhysicalIsFRU.7005 = false(2)  
entPhysicalIsFRU.7006 = false(2)  
entPhysicalIsFRU.7007 = false(2)  
entPhysicalIsFRU.7008 = false(2)  
entPhysicalIsFRU.7009 = false(2)  
entPhysicalIsFRU.7010 = false(2)  
entPhysicalIsFRU.7011 = false(2)  
entPhysicalIsFRU.7012 = false(2)  
entPhysicalIsFRU.7013 = false(2)  
entPhysicalIsFRU.7014 = false(2)  
entPhysicalIsFRU.7015 = false(2)  
entPhysicalIsFRU.7016 = false(2)  
entPhysicalIsFRU.7017 = false(2)  
entPhysicalIsFRU.7018 = false(2)  
entPhysicalIsFRU.7019 = false(2)  
entPhysicalIsFRU.7020 = false(2)  
entPhysicalIsFRU.7021 = false(2)  
entPhysicalIsFRU.7022 = false(2)  
entPhysicalIsFRU.7023 = false(2)  
entPhysicalIsFRU.7024 = false(2)  
entPhysicalIsFRU.7025 = false(2)  
entPhysicalIsFRU.7026 = false(2)  
entPhysicalIsFRU.7027 = false(2)  
entPhysicalIsFRU.7028 = false(2)  
entPhysicalIsFRU.7029 = false(2)  
entPhysicalIsFRU.7030 = false(2)  
entPhysicalIsFRU.7035 = false(2)  
entPhysicalIsFRU.7036 = false(2)  
entPhysicalIsFRU.7038 = false(2)  
entPhysicalIsFRU.7040 = false(2)
```

where **entPhysicalIsFRU** indicates whether or not this physical entity is considered a field replaceable unit (FRU).

Note the following about the sample configuration:

- All chassis slots and line card ports have the same **entPhysicalContainedIn** value:
  - For chassis slots, **entPhysicalContainedIn** = 1 (the **entPhysicalIndex** of the chassis).
- Each chassis slot and line card port has a different **entPhysicalParentRelPos** to show its relative position within the parent object.

```

entPhysicalDescr.7000 = Cisco ISR1100 Route Processor
entPhysicalDescr.1 = Cisco C1117-4P Chassis
entPhysicalDescr.2 = Power Supply Bay
entPhysicalDescr.3 = External Power Supply Module
entPhysicalDescr.13 = Power Supply
entPhysicalDescr.14 = Fan
entPhysicalDescr.22 = POE Bay
entPhysicalDescr.42 = Internal POE Bay
entPhysicalDescr.1000 = Cisco C1117-4P Built-In NIM controller
entPhysicalDescr.1015 = Front Panel 1 port Gigabitethernet Module
entPhysicalDescr.1016 = C1117-1x1GE
entPhysicalDescr.1090 = subslot 0/0 transceiver container 0
entPhysicalDescr.1245 = C1117-ES-4
entPhysicalDescr.1246 = C1117-ES-4
entPhysicalDescr.1247 = C1117-ES-4
entPhysicalDescr.1248 = C1117-ES-4
entPhysicalDescr.1249 = C1117-ES-4
entPhysicalDescr.7000 = Cisco C1117-4P Route Processor
entPhysicalDescr.7001 = Temp: Int1
entPhysicalDescr.7002 = Temp: Int2
entPhysicalDescr.7003 = Temp: Int3
entPhysicalDescr.7004 = Temp: Int4
entPhysicalDescr.7005 = Temp: CPU
entPhysicalDescr.7006 = Temp: Wifi
entPhysicalDescr.7035 = CPU 0 of module R0
entPhysicalDescr.7036 = USB Port
entPhysicalDescr.7037 = USB Flash
entPhysicalDescr.7038 = Network Management Ethernet
entPhysicalDescr.9000 = Cisco C1117-4P Forwarding Processor
entPhysicalDescr.9001 = QFP 0 of module F0
entPhysicalContainedIn.1 = 0
entPhysicalContainedIn.2 = 1
entPhysicalContainedIn.3 = 2
entPhysicalContainedIn.13 = 3
entPhysicalContainedIn.14 = 3
entPhysicalContainedIn.22 = 1
entPhysicalContainedIn.42 = 1
entPhysicalContainedIn.1000 = 1
entPhysicalContainedIn.1015 = 1000
entPhysicalContainedIn.1016 = 1015
entPhysicalContainedIn.1090 = 1015
entPhysicalContainedIn.1245 = 1000
entPhysicalContainedIn.1246 = 1245
entPhysicalContainedIn.1247 = 1245
entPhysicalContainedIn.1248 = 1245
entPhysicalContainedIn.1249 = 1245
entPhysicalContainedIn.7000 = 1
entPhysicalContainedIn.7001 = 7000
entPhysicalContainedIn.7002 = 7000
entPhysicalContainedIn.7003 = 7000
entPhysicalContainedIn.7004 = 7000
entPhysicalContainedIn.7005 = 7000
entPhysicalContainedIn.7006 = 7000
entPhysicalContainedIn.7035 = 7000
entPhysicalContainedIn.7036 = 7000
entPhysicalContainedIn.7037 = 7036
entPhysicalContainedIn.7038 = 7000
entPhysicalContainedIn.9000 = 1
entPhysicalContainedIn.9001 = 9000

```

After the line: where entPhysicalContainedIn indicates the entPhysicalIndex of a component's parent entity.

```

entPhysicalClass.1 = chassis(3)
entPhysicalClass.2 = container(5)
entPhysicalClass.3 = powerSupply(6)
entPhysicalClass.13 = powerSupply(6)

```



```

entPhysicalClass.14 = fan(7)
entPhysicalClass.22 = container(5)
entPhysicalClass.42 = container(5)
entPhysicalClass.1000 = module(9)
entPhysicalClass.1015 = module(9)
entPhysicalClass.1016 = port(10)
entPhysicalClass.1090 = container(5)
entPhysicalClass.1245 = module(9)
entPhysicalClass.1246 = port(10)
entPhysicalClass.1247 = port(10)
entPhysicalClass.1248 = port(10)
entPhysicalClass.1249 = port(10)
entPhysicalClass.7000 = module(9)
entPhysicalClass.7001 = sensor(8)
entPhysicalClass.7002 = sensor(8)
entPhysicalClass.7003 = sensor(8)
entPhysicalClass.7004 = sensor(8)
entPhysicalClass.7005 = sensor(8)
entPhysicalClass.7006 = sensor(8)
entPhysicalClass.7035 = 12
entPhysicalClass.7036 = container(5)
entPhysicalClass.7037 = module(9)
entPhysicalClass.7038 = port(10)
entPhysicalClass.9000 = module(9)
entPhysicalClass.9001 = 12

```

After the line: where entPhysicalClass indicates.....

```

entPhysicalParentRelPos.1 = -1
entPhysicalParentRelPos.2 = 9
entPhysicalParentRelPos.3 = 0
entPhysicalParentRelPos.13 = 0
entPhysicalParentRelPos.14 = 0
entPhysicalParentRelPos.22 = 10
entPhysicalParentRelPos.42 = 11
entPhysicalParentRelPos.1000 = 0
entPhysicalParentRelPos.1015 = 0
entPhysicalParentRelPos.1016 = 0
entPhysicalParentRelPos.1090 = 0
entPhysicalParentRelPos.1245 = 1
entPhysicalParentRelPos.1246 = 0
entPhysicalParentRelPos.1247 = 1
entPhysicalParentRelPos.1248 = 2
entPhysicalParentRelPos.1249 = 3
entPhysicalParentRelPos.7000 = 6
entPhysicalParentRelPos.7001 = 0
entPhysicalParentRelPos.7002 = 1
entPhysicalParentRelPos.7003 = 2
entPhysicalParentRelPos.7004 = 3
entPhysicalParentRelPos.7005 = 4
entPhysicalParentRelPos.7006 = 5
entPhysicalParentRelPos.7035 = 0
entPhysicalParentRelPos.7036 = 0
entPhysicalParentRelPos.7037 = 0
entPhysicalParentRelPos.7038 = 1
entPhysicalParentRelPos.9000 = 8
entPhysicalParentRelPos.9001 = 0

```

After this line: where entPhysicalParentRelPos indicates the....

```

entPhysicalName.1 = Chassis
entPhysicalName.2 = Power Supply Bay 0
entPhysicalName.3 = Power Supply Module 0
entPhysicalName.13 = Power Supply 0
entPhysicalName.14 = Fan 0/0
entPhysicalName.22 = POE Bay 0
entPhysicalName.42 = Internal POE Bay 0
entPhysicalName.1000 = module 0

```

```

entPhysicalName.1015 = NIM subslot 0/0
entPhysicalName.1016 = GigabitEthernet0/0/0
entPhysicalName.1090 = subslot 0/0 transceiver container 0
entPhysicalName.1245 = NIM subslot 0/1
entPhysicalName.1246 = GigabitEthernet0/1/0
entPhysicalName.1247 = GigabitEthernet0/1/1
entPhysicalName.1248 = GigabitEthernet0/1/2
entPhysicalName.1249 = GigabitEthernet0/1/3
entPhysicalName.7000 = module R0
entPhysicalName.7001 = Temp: Int1 R0/0
entPhysicalName.7002 = Temp: Int2 R0/1
entPhysicalName.7003 = Temp: Int3 R0/2
entPhysicalName.7004 = Temp: Int4 R0/3
entPhysicalName.7005 = Temp: CPU R0/4
entPhysicalName.7006 = Temp: Wifi R0/5
entPhysicalName.7035 = cpu R0/0
entPhysicalName.7036 = usb R0/0
entPhysicalName.7037 = usb0
entPhysicalName.7038 = NME R0
entPhysicalName.9000 = module F0
entPhysicalName.9001 = qfp F0/0

```

After this line : where entPhysicalName provides the ....

```

entPhysicalHardwareRev.1 = V01
entPhysicalHardwareRev.2 =
entPhysicalHardwareRev.3 =
entPhysicalHardwareRev.13 =
entPhysicalHardwareRev.14 =
entPhysicalHardwareRev.22 =
entPhysicalHardwareRev.42 =
entPhysicalHardwareRev.1000 =
entPhysicalHardwareRev.1015 = V01
entPhysicalHardwareRev.1016 =
entPhysicalHardwareRev.1090 =
entPhysicalHardwareRev.1245 = V01
entPhysicalHardwareRev.1246 =
entPhysicalHardwareRev.1247 =
entPhysicalHardwareRev.1248 =
entPhysicalHardwareRev.1249 =
entPhysicalHardwareRev.7000 = V01
entPhysicalHardwareRev.7001 =
entPhysicalHardwareRev.7002 =
entPhysicalHardwareRev.7003 =
entPhysicalHardwareRev.7004 =
entPhysicalHardwareRev.7005 =
entPhysicalHardwareRev.7006 =
entPhysicalHardwareRev.7035 =
entPhysicalHardwareRev.7036 =
entPhysicalHardwareRev.7037 =
entPhysicalHardwareRev.7038 =
entPhysicalHardwareRev.9000 =
entPhysicalHardwareRev.9001 =

```

After this line : where entPhysicalHardwareRev provides the...

```

entPhysicalSerialNum.1 = FGL203820ED
entPhysicalSerialNum.2 =
entPhysicalSerialNum.3 =
entPhysicalSerialNum.13 =
entPhysicalSerialNum.14 =
entPhysicalSerialNum.22 =
entPhysicalSerialNum.42 =
entPhysicalSerialNum.1000 =
entPhysicalSerialNum.1015 =
entPhysicalSerialNum.1016 =
entPhysicalSerialNum.1090 =
entPhysicalSerialNum.1245 =

```

```

entPhysicalSerialNum.1246 =
entPhysicalSerialNum.1247 =
entPhysicalSerialNum.1248 =
entPhysicalSerialNum.1249 =
entPhysicalSerialNum.7000 = FOC20341XGM
entPhysicalSerialNum.7001 =
entPhysicalSerialNum.7002 =
entPhysicalSerialNum.7003 =
entPhysicalSerialNum.7004 =
entPhysicalSerialNum.7005 =
entPhysicalSerialNum.7006 =
entPhysicalSerialNum.7035 =
entPhysicalSerialNum.7036 =
entPhysicalSerialNum.7037 =
entPhysicalSerialNum.7038 =
entPhysicalSerialNum.9000 =
entPhysicalSerialNum.9001 =
After this line : where entPhysicalSerialNum provides the ....
entPhysicalMfgName.1 = Cisco Systems Inc
entPhysicalMfgName.2 =
entPhysicalMfgName.3 = Cisco Systems Inc
entPhysicalMfgName.13 =
entPhysicalMfgName.14 =
entPhysicalMfgName.22 =
entPhysicalMfgName.42 =
entPhysicalMfgName.1000 = Cisco Systems Inc
entPhysicalMfgName.1015 = Cisco Systems Inc
entPhysicalMfgName.1016 =
entPhysicalMfgName.1090 =
entPhysicalMfgName.1245 = Cisco Systems Inc
entPhysicalMfgName.1246 =
entPhysicalMfgName.1247 =
entPhysicalMfgName.1248 =
entPhysicalMfgName.1249 =
entPhysicalMfgName.7000 = Cisco Systems Inc
entPhysicalMfgName.7001 =
entPhysicalMfgName.7002 =
entPhysicalMfgName.7003 =
entPhysicalMfgName.7004 =
entPhysicalMfgName.7005 =
entPhysicalMfgName.7006 =
entPhysicalMfgName.7035 =
entPhysicalMfgName.7036 =
entPhysicalMfgName.7037 =
entPhysicalMfgName.7038 =
entPhysicalMfgName.9000 = Cisco Systems Inc
entPhysicalMfgName.9001 = Cisco Systems Inc
After this line: where entPhysicalMfgName provides the....
entPhysicalModelName.1 = C1117-4P
entPhysicalModelName.2 =
entPhysicalModelName.3 = PWR-12V
entPhysicalModelName.13 =
entPhysicalModelName.14 =
entPhysicalModelName.22 =
entPhysicalModelName.42 =
entPhysicalModelName.1000 = C1117-4P
entPhysicalModelName.1015 = C1117-1x1GE
entPhysicalModelName.1016 =
entPhysicalModelName.1090 =
entPhysicalModelName.1245 = C1117-ES-4
entPhysicalModelName.1246 =
entPhysicalModelName.1247 =
entPhysicalModelName.1248 =
entPhysicalModelName.1249 =

```

```

entPhysicalModelName.7000 = C1117-4P
entPhysicalModelName.7001 =
entPhysicalModelName.7002 =
entPhysicalModelName.7003 =
entPhysicalModelName.7004 =
entPhysicalModelName.7005 =
entPhysicalModelName.7006 =
entPhysicalModelName.7035 =
entPhysicalModelName.7036 =
entPhysicalModelName.7037 =
entPhysicalModelName.7038 =
entPhysicalModelName.9000 = C1117-4P
entPhysicalModelName.9001 =
After this line : where entPhysicalModelName provides the .....
entPhysicalIsFRU.1 = true(1)
entPhysicalIsFRU.2 = false(2)
entPhysicalIsFRU.3 = true(1)
entPhysicalIsFRU.13 = false(2)
entPhysicalIsFRU.14 = false(2)
entPhysicalIsFRU.22 = false(2)
entPhysicalIsFRU.42 = false(2)
entPhysicalIsFRU.1000 = false(2)
entPhysicalIsFRU.1015 = false(2)
entPhysicalIsFRU.1016 = false(2)
entPhysicalIsFRU.1090 = false(2)
entPhysicalIsFRU.1245 = false(2)
entPhysicalIsFRU.1246 = false(2)
entPhysicalIsFRU.1247 = false(2)
entPhysicalIsFRU.1248 = false(2)
entPhysicalIsFRU.1249 = false(2)
entPhysicalIsFRU.7000 = false(2)
entPhysicalIsFRU.7001 = false(2)
entPhysicalIsFRU.7002 = false(2)
entPhysicalIsFRU.7003 = false(2)
entPhysicalIsFRU.7004 = false(2)
entPhysicalIsFRU.7005 = false(2)
entPhysicalIsFRU.7006 = false(2)
entPhysicalIsFRU.7035 = false(2)
entPhysicalIsFRU.7036 = false(2)
entPhysicalIsFRU.7037 = true(1)
entPhysicalIsFRU.7038 = false(2)
entPhysicalIsFRU.9000 = false(2)
entPhysicalIsFRU.9001 = false(2)

```

## Determining the ifIndex Value for a Physical Port

The ENTITY-MIB **entAliasMappingIdentifier** maps a physical port to an interface by mapping the port's **entPhysicalIndex** to its corresponding **ifIndex** value in the IF-MIB **ifTable**. The following sample shows that the physical port whose **entPhysicalIndex** is 35 is associated with the interface whose **ifIndex** value is 4. (See the MIB for detailed descriptions of possible MIB values.)

```
entAliasMappingIdentifier.1813.0 = ifIndex.4
```

## Monitoring and Configuring FRU Status

View objects in the CISCO-ENTITY-FRU-CONTROL-MIB **cefcModuleTable** to determine the administrative and operational status of FRUs, such as power supplies and line cards:

- **cefcModuleAdminStatus**—The administrative state of the FRU. Use **cefcModuleAdminStatus** to enable or disable the FRU.

- `cefcModuleOperStatus`—The current operational state of the FRU.

Figure 5-1 shows a `cefcModuleTable` entry for a SIP card whose `entPhysicalIndex` is 1000.

Figure 5-1 Sample `cefcModuleTable` Entry

```

cefcModuleAd
minStatus.1000
= enabled(1)
cefcModuleOpe
rStatus.1000 =
ok(2)
cefcModuleRes

```

See the “[FRU Status Changes](#)” section on page 5-29 for information about how the router generates notifications to indicate changes in FRU status.

## Using ENTITY-ALARM-MIB to Monitor Entity Alarms

### ENTITY-MIB

The Entity physical table contains information for managing physical entities on the router. It also organizes the entities into a containment tree that depicts their hierarchy, and relationship with each other. Refer to the “[Entity Containment Tree](#)” section for the entity hierarchy. The following sample output contains the information for the ISR 4451-X power supply in power supply bay 0:

```

blr-srtg-tftp:95> getmany -v2c 10.104.45.236 public entityMIB | grep "\.3 "
entPhysicalDescr.3 = External Power Supply Module
entPhysicalVendorType.3 = cevPowerSupply.583
entPhysicalContainedIn.3 = 2
entPhysicalClass.3 = powerSupply(6
entPhysicalParentRelPos.3 = 0
entPhysicalName.3 = Power Supply Module 0
entPhysicalHardwareRev.3 = V01
entPhysicalFirmwareRev.3 =
entPhysicalSoftwareRev.3 =
entPhysicalSerialNum.3 = JAB0929092D
entPhysicalMfgName.3 = Cisco Systems Inc
entPhysicalModelName.3 = PWR-12V
entPhysicalAlias.3 =
entPhysicalAssetID.3 =
entPhysicalIsFRU.3 = true(1)
entPhysicalEntry.17.3 = 00 00 00 00 00 00 00 00
entPhysicalEntry.18.3 = URN:CLEI:IPUIAFMRAA
entPhysicalChildIndex.2.3 = 3

```

For more information on this MIB, refer to ENTITY-MIB (RFC 4133)

### CISCO-ENTITY-ALARM-MIB

CISCO-ENTITY-ALARM-MIB supports the monitoring of alarms generated by physical entities contained by the system, including chassis, slots, modules, ports, power supplies, etc. In order to monitor alarms generated by a physical entity, it must be represented by a row in the `entPhysicalTable`.

## Alarm Description Map Table

For each type of entity (represented by entPhysicalVendorType OID), this table contains a mapping between a unique ceAlarmDescrIndex and entPhysicalVendorType OID.

The ceAlarmDescrMapEntry is indexed by the CeAlarmDescrMapEntry.




---

**Note** The mapping between the ceAlarmDescrIndex and entPhysicalVendorType OID will exist only if the type of entity supports alarms monitoring, and it is in the device since device boot-up.

---

The following are the sample output:

```
blr-srtg-tftp:96> getmany -v2c 10.104.45.236 public ceAlarmDescrMapTable
ceAlarmDescrVendorType.1 = cevContainerSFP
ceAlarmDescrVendorType.2 = cevContainer.395
ceAlarmDescrVendorType.3 = cevContainer.396
ceAlarmDescrVendorType.4 = cevSensorModuleDeviceTemp
ceAlarmDescrVendorType.5 = cevSensorModuleDeviceVoltage
ceAlarmDescrVendorType.6 = cevSensorModuleDeviceCurrent
ceAlarmDescrVendorType.7 = cevSensor.133
ceAlarmDescrVendorType.8 = cevSensor.132
ceAlarmDescrVendorType.9 = cevSensor.134
ceAlarmDescrVendorType.10 = cevSensor
ceAlarmDescrVendorType.11 = cevModule.96.63
ceAlarmDescrVendorType.12 = cevContainer.333
ceAlarmDescrVendorType.13 = cevPortGe
ceAlarmDescrVendorType.14 = cevModule.96.64
ceAlarmDescrVendorType.15 = cevModule.96.65
ceAlarmDescrVendorType.16 = cevPowerSupply.583
ceAlarmDescrVendorType.17 = cevModule.96.37
ceAlarmDescrVendorType.18 = cevModule.96.56
ceAlarmDescrVendorType.19 = cevModule.96.38
ceAlarmDescrVendorType.20 = cevPortAdslAnnexA
```

The temperature sensor in ISR 1100 modules (RP) contains cevSensorModuleDeviceTemp as entPhysicalVendorType OID. From the above sample output, the index (ceAlarmDescrIndex) 5 is mapped to the RP sensor which has the cevSensorModuleDeviceTemp as the entPhysicalVendorType.




---

**Note** The generic vendor OID, cevSensor, is used in case the ISR 4451-X snmp agent is not able to determine the sensor type.

---

## Alarm Description Table

The Alarm Description Table contains a description for each alarm type, defined by each vendor type employed by the system. Each alarm description entry (ceAlarmDescrEntry) is indexed by ceAlarmDescrIndex and ceAlarmDescrAlarmType.

The following is the sample output for all alarm types defined for all temperature type of entity in the Cisco 1100 Series ISR modules. The index 5 is obtained from the ceAlarmDescrMapTable in the previous section:

```
blr-srtg-tftp:97> getmany -v2c 10.104.45.236 public ceAlarmDescrTable | grep "\.4\."
ceAlarmDescrSeverity.4.0 = 1
ceAlarmDescrSeverity.4.1 = 1
ceAlarmDescrSeverity.4.2 = 1
ceAlarmDescrSeverity.4.3 = 2
ceAlarmDescrSeverity.4.4 = 3
ceAlarmDescrSeverity.4.5 = 1
ceAlarmDescrSeverity.4.6 = 1
ceAlarmDescrSeverity.4.7 = 2
```

```

ceAlarmDescrSeverity.4.8 = 3
ceAlarmDescrSeverity.4.9 = 1
ceAlarmDescrText.4.0 = Faulty Temperature Sensor
ceAlarmDescrText.4.1 = Temp Above Normal (Shutdown)
ceAlarmDescrText.4.2 = Temp Above Normal
ceAlarmDescrText.4.3 = Temp Above Normal
ceAlarmDescrText.4.4 = Temp Above Normal
ceAlarmDescrText.4.5 = Temp Below Normal (Shutdown)
ceAlarmDescrText.4.6 = Temp Below Normal
ceAlarmDescrText.4.7 = Temp Below Normal
ceAlarmDescrText.4.8 = Temp Below Normal
ceAlarmDescrText.4.9 = CHECK FOR OPEN SLOTS & BLOCKED AIR INTAKE

```

Refer to the Bellcore Technical Reference TR-NWT-000474 Issue 4, December 1993, OTGR Section 4. Network Maintenance: Alarm and Control - Network Element. The severity is defined as follows:

- critical(1)
- major(2)
- minor(3)
- info(4)

The following is the list of alarms defined for the sensor:

```

Alarm type 0 is for faulty sensor
Alarm type 1 is for crossing the shutdown threshold (above normal range).
Alarm type 2 is for crossing the critical threshold (above normal range).
Alarm type 3 is for crossing the major threshold (above normal range).
Alarm type 4 is for crossing the minor threshold (above normal range).
Alarm type 5 is for crossing the shutdown threshold (below normal range).
Alarm type 6 is for crossing the critical threshold (below normal range).
Alarm type 7 is for crossing the major threshold (below normal range).
Alarm type 8 is for crossing the minor threshold (below normal range).

```

These alarm types are defined for all sensor physical entity type. The only difference is that different sensor physical type have different `ceAlarmDescrText`. The temperature sensor has "TEMP" and the voltage sensor has "Volt" in the alarm description text.

## Alarm Table

The Alarm Table specifies alarm control and status information related to each physical entity contained by the system. The table includes the alarms currently being asserted by each physical entity that is capable of generating alarms. Each physical entity in entity physical table that is capable of generating alarms has an entry in this table. The alarm entry (`ceAlarmEntry`) is indexed by the entity physical index (`entPhysicalIndex`). The following is a list of MIB objects in the alarm entry:

- **ceAlarmFilterProfile**  
The alarm filter profile object contains an integer value that uniquely identifies an alarm filter profile associated with the corresponding physical entity. An alarm filter profile controls which alarm types the agent will monitor and signal for the corresponding physical entity. The default value of this object is 0, the agent monitors and signals all alarms associated with the corresponding physical entity.
- **ceAlarmSeverity**  
This object specifies the highest severity alarm currently being asserted by the corresponding physical entity. A value of '0' indicates that the corresponding physical entity is not currently asserting any alarms.
- **ceAlarmList**  
This object specifies those alarms currently being asserted by the corresponding physical entity. If an alarm is being asserted by the physical entity, then the corresponding bit in the alarm list is set to a one. The alarm list is defined as octet string and its size ranges from 0 to 32.

- If the physical entity is not currently asserting any alarms, then the list will have a length of zero, otherwise it will have a length of 32.
- An OCTET STRING represents an alarm list, in which each bit represents an alarm type:

octet 1:

```

 7 6 5 4 3 2 1 0
+---+---+---+---+
|           |
+---+---+---+---+
| | | | | | | | +- Alarm type 0
| | | | | | | | +--- Alarm type 1
| | | | | | | | +----- Alarm type 2
| | | | | | | | +----- Alarm type 3
| | | | | | | | +----- Alarm type 4
| | | | | | | | +----- Alarm type 5
| | | | | | | | +----- Alarm type 6
+----- Alarm type 7

```

octet 2:

```

 7 6 5 4 3 2 1 0
+---+---+---+---+
|           |
+---+---+---+---+
| | | | | | | | +- Alarm type 8
| | | | | | | | +--- Alarm type 9
| | | | | | | | +----- Alarm type 10
| | | | | | | | +----- Alarm type 11
| | | | | | | | +----- Alarm type 12
| | | | | | | | +----- Alarm type 13
| | | | | | | | +----- Alarm type 14
+----- Alarm type 15

```

octet xx

octet 32:

```

 7 6 5 4 3 2 1 0
+---+---+---+---+
|           |
+---+---+---+---+
| | | | | | | | +- Alarm type 248
| | | | | | | | +--- Alarm type 249
| | | | | | | | +----- Alarm type 250
| | | | | | | | +----- Alarm type 251
| | | | | | | | +----- Alarm type 252
| | | | | | | | +----- Alarm type 253
| | | | | | | | +----- Alarm type 254
+----- Alarm type 255

```

From the entity physical table (entPhysicalTable in ENTITY-MIB), we understand that the Cisco 1100 Series ISR AC power supply in power supply bay 0 has 4 as entPhysicalIndex .

The following are the sample output of alarm list for the power supply in PS bay 0:

```

ciscouser-248->getone -v2c 9.0.0.56 public ceAlarmList.4
ceAlarmList.4 =

```



```
09 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00
```

octet 1: 09

```
 7 6 5 4 3 2 1 0
+-----+
 0 0 0 0 1 0 0 1
+-----+
| | | | | | | |
| | | | | | | +- Alarm type 0
| | | | | | | +--- Alarm type 1
| | | | | +----- Alarm type 2
| | | | +----- Alarm type 3
| | | +----- Alarm type 4
| | +----- Alarm type 5
| +----- Alarm type 6
+----- Alarm type 7
```

## Alarm History Table

The Alarm History Table, `ceAlarmHistTable`, contains history of alarms both asserted and cleared generated by the agent. The `ceAlarmHistTableSize` is used to control the size of the alarm history table. A value of 0 prevents any history from being retained in this table. If the capacity of the `ceAlarmHistTable` has reached the value specified by this object, then the agent deletes the oldest entity in order to accommodate a new entry.

The `ceAlarmHistLastIndex` object contains the last index corresponding to the last entry added to the table by the snmp agent in the device. If the management client uses notifications listed in the [Appendix 5, “Alarm Notifications”](#) defined in [CISCO-ENTITY-ALARM-MIB](#) module, then it can poll this object to determine whether it has missed a notification sent by the agent.

The following is a list of MIB objects defined in the `ceAlarmHistEntry`, which is indexed by the `ceAlarmHistIndex`:

- **ceAlarmHistIndex**  
This is an integer value uniquely identifying the entry in the table. The value of this object starts at '1' and monotonically increases for each alarm (asserted or cleared) added to the alarm history table. If the value of this object is '4294967295', it will be reset to '1', upon monitoring the next alarm condition transition.
- **ceAlarmHistType**  
This object indicates that the entry is added as a result of an alarm being asserted or cleared.
- **ceAlarmHistEntPhysicalIndex**  
This object contains the `entPhysicalIndex` of the physical entity that generated the alarm.
- **ceAlarmHistAlarmType**  
This object specifies the type of alarm generated.
- **ceAlarmHistSeverity**  
This object specifies the severity of the alarm generated.
- **ceAlarmHistTimeStamp**  
This object specifies the value of the `sysUpTime` object at the time the alarm is generated.

### Example 5-1 Displaying Sample Output for the Alarm History

```
ciscouser-257->getnext -v2c 9.0.0.56 public ceAlarmHistory
ceAlarmHistTableSize.0 = 200 → the size of alarm history table
ptolemy-258->getnext -v2c 9.0.0.56 public ceAlarmHistTableSize.0
ceAlarmHistLastIndex.0 = 21 → the index for the last alarm added
```

**Example 5-2** *Displaying the Last Alarm Action (asserted or cleared) Added to the Alarm History Table*

```
ptolemy-259->getmany -v2c 9.0.0.56 public ceAlarmHistTable | grep "\.21 "
ceAlarmHistType.21 = cleared(2) → alarm cleared
ceAlarmHistEntPhysicalIndex.21=4 → it is for physical entity indexed by 4
ceAlarmHistAlarmType.21 = 3 → alarm type is 3
ceAlarmHistSeverity.21 = major(2) → the alarm severity is major(2)
ceAlarmHistTimeStamp.21 = 7506193
```

At this point, the EMS application should already have all information regarding the physical entity and the entity alarm type defined for the physical entity.

**Example 5-3** *Displaying the Physical Entity That has Value 13 as entPhysicalIndex*

```
entPhysicalDescr.13 = Power Supply
entPhysicalVendorType.13 = cevPowerSupply.364
entPhysicalContainedIn.13 = 3
entPhysicalClass.13 = powerSupply(6)
entPhysicalParentRelPos.13 = 0
entPhysicalName.13 = Power Supply 0
entPhysicalHardwareRev.13 =
entPhysicalFirmwareRev.13 =
entPhysicalSoftwareRev.13 =
entPhysicalSerialNum.13 =
entPhysicalMfgName.13 =
entPhysicalModelName.13 =
entPhysicalAlias.13 = abcd
entPhysicalIsFRU.13 = false(2)
entPhysicalMfgDate.13 = 00 00 00 00 00 00 00 00
entPhysicalUris.13 =
```

**Alarm Notifications**

CISCO-ENTITY-ALARM-MIB supports the alarm asserted (ceAlarmAsserted) and alarm cleared (ceAlarmCleared) notifications. The notification can be enabled by setting the ceAlarmNotifiesEnable object through the snmp SET. The ceAlarmNotifiesEnable contains the severity level of the alarms notification or the value 0:

```
severity 1: critical      Service affecting Condition
severity 2: major        Immediate action needed
severity 3: minor        Minor warning conditions
severity 4: informational Informational messages
```

The severity 4 will enable notification for all severity level.

The severity 3 will enable notifications for severity 1, 2, and 3.

The severity 2 will enable notifications for severity 1 and 2.

The severity 1 will enable notifications for severity 1 only.

The value of 0 will disable the alarm notification.

The alarm notification can be enabled or disabled via the CLI command. Use the "NO" form to disable the alarm notification:

```
snmp-server enable traps alarm [critical, major, minor, information]
no snmp-server enable traps alarm [critical, major, minor, information]
```

The alarm notification contains exactly the same information described in alarm history entry. Refer to the Alarm History Table Section for the MIB objects and to interpret the alarm notifications received.

**Example 5-4** *Displaying the Sample Notification Received*

```

Received SNMPv2c Trap:
Community: public
From: 9.0.0.56
sysUpTimeInstance = 7500792
snmpTrapOID.0 = ceAlarmCleared
ceAlarmHistEntPhysicalIndex.19 = 4
ceAlarmHistAlarmType.19 = 0
ceAlarmHistSeverity.19 = critical(1)
ceAlarmHistTimeStamp.19 = 7500792

```

```

Received SNMPv2c Trap:
Community: public
From: 9.0.0.56
sysUpTimeInstance = 7504592
snmpTrapOID.0 = ceAlarmAsserted
ceAlarmHistEntPhysicalIndex.20 = 4
ceAlarmHistAlarmType.20 = 3
ceAlarmHistSeverity.20 = major(2)
ceAlarmHistTimeStamp.20 = 7504592

```

```

Received SNMPv2c Trap:
Community: public
From: 9.0.0.56
sysUpTimeInstance = 7506193
snmpTrapOID.0 = ceAlarmCleared
ceAlarmHistEntPhysicalIndex.21 = 4
ceAlarmHistAlarmType.21 = 3
ceAlarmHistSeverity.21 = major(2)
ceAlarmHistTimeStamp.21 = 7506193

```

**Entity Containment Tree**

The following is sample entity hierarchy for a Cisco 1100 Series ISR, MIB Variables printed : <entPhysicalName entPhysicalClass>

**ENTITY-MIB containment tree:**

```

starwin:35> /users/tiswanso/bin/entity_hier.pl -h 10.104.45.235 -c public
/users/tiswanso/bin/entity_hier.pl -h 10.104.45.235 -c public

```

```

Storing Parent to child relationships
  {parentIdx}{class}{relPos} = childIdx

```

```

-----
{1245}{port}{2} = 1248
{1}{container}{9} = 2
{0}{chassis}{-1} = 1
{7000}{sensor}{5} = 7006
{1245}{port}{0} = 1246
{1000}{module}{2} = 1475
{7000}{sensor}{4} = 7005
{1475}{module}{0} = 7007
{1245}{port}{3} = 1249
{7000}{container}{0} = 7036
{1245}{port}{7} = 1253
{1245}{port}{5} = 1251
{1}{module}{8} = 9000
{7000}{sensor}{3} = 7004
{1245}{port}{4} = 1250
{1475}{port}{1} = 1477

```

```

{1015}{container}{0} = 1090
{1}{module}{6} = 7000
{7000}{sensor}{2} = 7003
{7000}{12}{0} = 7035
{1245}{port}{1} = 1247
{1}{container}{11} = 42
{1}{container}{10} = 22
{9000}{12}{0} = 9001
{1475}{port}{0} = 1476
{3}{powerSupply}{0} = 13
{7000}{sensor}{0} = 7001
{1015}{container}{1} = 1100
{2}{powerSupply}{0} = 3
{1245}{port}{6} = 1252
{1000}{module}{0} = 1015
{7000}{port}{1} = 7038
{7000}{sensor}{1} = 7002
{1000}{module}{1} = 1245
{1}{module}{0} = 1000
{1015}{port}{1} = 1017

```

Entity Hierarchy Output Format:

```

|
<<entPhysicalClass>>
|
+-->[entPhysicalParentRelPos]   entPhysicalIndex : "entPhysicalName"
|
|                               "entPhysicalDescr"
|
|                               "entPhysicalVendorType"
|
... hierarchy of children (entPhysicalContainedIn == entPhysicalIndex)

|
<<chassis>>
|
+-->[ -1]   1 : "Chassis"
|
|           "Cisco C1111-8PLTEEA Chassis"
|
|           "cevChassis.1859"
|
<<container>>
|
+-->[ 9]   2 : "Power Supply Bay 0"
|
|           "Power Supply Bay"

```

```

| | "cevContainer.395"
| |
| <<powerSupply>>
| |
| +-->[ 0] 3 : "Power Supply Module 0"
| | "External Power Supply Module"
| | "cevPowerSupply.583"
| |
| <<powerSupply>>
| |
| +-->[ 0] 13 : "Power Supply 0"
| | "Power Supply"
| | "cevPowerSupply.364"
|
+-->[ 10] 22 : "POE Bay 0"
| | "POE Bay"
| | "cevContainer.396"
|
+-->[ 11] 42 : "Internal POE Bay 0"
| | "Internal POE Bay"
| | "cevContainer.397"
|
<<module>>
|
+-->[ 0] 1000 : "module 0"
| | "Cisco C1111-8PLTEEA Built-In NIM controller"
| | "cevModule.96.36"
| |
| <<module>>
| |
| +-->[ 0] 1015 : "NIM subslot 0/0"
| | | "Front Panel 2 port Gigabitethernet Module"

```

```

| | | "cevModule.96.20"
| | |
| | | <<container>>
| | |
| | | +-->[ 0] 1090 : "subslot 0/0 transceiver container 0"
| | | "subslot 0/0 transceiver container 0"
| | | "cevContainerSFP"
| | |
| | | +-->[ 1] 1100 : "subslot 0/0 transceiver container 1"
| | | "subslot 0/0 transceiver container 1"
| | | "cevContainersSFP"
| | |
| | | <<port>>
| | |
| | | +-->[ 1] 1017 : "GigabitEthernet0/0/1"
| | | "C1111-2x1GE"
| | | "cevPortGe"
| | |
| | +-->[ 1] 1245 : "NIM subslot 0/1"
| | | "C1111-ES-8"
| | | "cevModule.96.21"
| | |
| | | <<port>>
| | |
| | | +-->[ 0] 1246 : "GigabitEthernet0/1/0"
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | | +-->[ 1] 1247 : "GigabitEthernet0/1/1"
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |

```

```
| | +-->[ 2] 1248 : "GigabitEthernet0/1/2"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | +-->[ 3] 1249 : "GigabitEthernet0/1/3"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | +-->[ 4] 1250 : "GigabitEthernet0/1/4"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | +-->[ 5] 1251 : "GigabitEthernet0/1/5"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | +-->[ 6] 1252 : "GigabitEthernet0/1/6"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| | +-->[ 7] 1253 : "GigabitEthernet0/1/7"
| | |
| | | "C1111-ES-8"
| | | "cevPortGe"
| | |
| +-->[ 2] 1475 : "NIM subslot 0/2"
| |
| | "C1111-LTE Module"
| | "cevModule.96.22"
| |
| <<module>>
| |
| +-->[ 0] 7007 : "Modem 0 on Cellular0/2/0"
| |
| | "Sierra Wireless EM7455/EM7430"
```

```

|         |         "cevModuleDaughterCard.88"
|         |
|         <<port>>
|         |
|         +-->[ 0] 1476 : "Cellular0/2/0"
|         |
|         |         "LTE Adv CAT6 - Multimode LTE/DC-HSPA+/HSPA+/HSPA/UMTS/EDGE/GPRS"
|         |
|         |         "cevPortCBusSerial"
|         |
|         +-->[ 1] 1477 : "Cellular0/2/1"
|         |
|         |         "LTE Adv CAT6 - Multimode LTE/DC-HSPA+/HSPA+/HSPA/UMTS/EDGE/GPRS"
|         |
|         |         "cevPortCBusSerial"
|
+-->[ 6] 7000 : "module R0"
|         |
|         |         "Cisco C1111-8PLTEEA Route Processor"
|         |
|         |         "cevModule.96.34"
|         |
|         <<12>>
|         |
|         +-->[ 0] 7035 : "cpu R0/0"
|         |
|         |         "CPU 0 of module R0"
|         |
|         |         "cevModuleCpuType"
|         |
|         <<container>>
|         |
|         +-->[ 0] 7036 : "usb R0/0"
|         |
|         |         "USB Port"
|         |
|         |         "cevContainer.333"
|         |
|         <<port>>
|         |
|         +-->[ 1] 7038 : "NME R0"
|         |
|         |         "Network Management Ethernet"

```



```

| | "cevPortGe"
| |
| <<sensor>>
| |
| +-->[ 0] 7001 : "Temp: Int1 R0/0"
| | "Temp: Int1"
| | "cevSensorModuleDeviceTemp"
| |
| +-->[ 1] 7002 : "Temp: Int2 R0/1"
| | "Temp: Int2"
| | "cevSensorModuleDeviceTemp"
| |
| +-->[ 2] 7003 : "Temp: Int3 R0/2"
| | "Temp: Int3"
| | "cevSensorModuleDeviceTemp"
| |
| +-->[ 3] 7004 : "Temp: Int4 R0/3"
| | "Temp: Int4"
| | "cevSensorModuleDeviceTemp"
| |
| +-->[ 4] 7005 : "Temp: CPU R0/4"
| | "Temp: CPU"
| | "cevSensorModuleDeviceTemp"
| |
| +-->[ 5] 7006 : "Temp: Wifi R0/5"
| | "Temp: Wifi"
| | "cevSensorModuleDeviceTemp"
|
+-->[ 8] 9000 : "module F0"
| "Cisco C1111-8PLTEEA Forwarding Processor"
| "cevModule.96.35"
|
<<12>>
|
+-->[ 0] 9001 : "qfp F0/0"
| "QFP 0 of module F0"
| "cevModuleCpuType"

```

-----  
 Printing leftover entity relationships:  
 -----

## Generating SNMP Notifications

This section provides information about the SNMP notifications generated in response to events and conditions on the router, and describes how to identify the hosts that are to receive notifications.

- [Identifying Hosts to Receive Notifications](#)
- [Configuration Changes](#)
- [FRU Status Changes](#)

## Identifying Hosts to Receive Notifications

You can use the CLI or SNMP to identify hosts to receive SNMP notifications and to specify the types of notifications they are to receive (notifications or informs). For CLI instructions, see the [“Enabling Notifications” section on page 4-2](#). To use SNMP to configure this information, use the following MIB objects:

Use SNMP-NOTIFICATION-MIB objects, including the following, to select target hosts and specify the types of notifications to generate for those hosts:

- `snmpNotifyTable`—Contains objects to select hosts and notification types:
  - `snmpNotifyTag` is an arbitrary octet string (a tag value) used to identify the hosts to receive SNMP notifications. Information about target hosts is defined in the `snmpTargetAddrTable` (SNMP-TARGET-MIB), and each host has one or more tag values associated with it. If a host in `snmpTargetAddrTable` has a tag value that matches this `snmpNotifyTag` value, the host is selected to receive the types of notifications specified by `snmpNotifyType`.
  - `snmpNotifyType` is the type of SNMP notification to send: `notification(1)` or `inform(2)`.
- `snmpNotifyFilterProfileTable` and `snmpNotifyFilterTable`—Use objects in these tables to create notification filters to limit the types of notifications sent to target hosts.

Use SNMP-TARGET-MIB objects to configure information about the hosts to receive notifications:

- `snmpTargetAddrTable`—Transport addresses of hosts to receive SNMP notifications. Each entry provides information about a host address, including a list of tag values:
  - `snmpTargetAddrTagList`—A set of tag values associated with the host address. If a host’s tag value matches `snmpNotifyTag`, the host is selected to receive the types of notifications defined by `snmpNotifyType`.
- `snmpTargetParamsTable`—SNMP parameters to use when generating SNMP notifications.

Use the notification enable objects in appropriate MIBs to enable and disable specific SNMP notifications. For example, to generate `mplsLdpSessionUp` or `mplsLdpSessionDown` notifications, the MPLS-LDP-MIB object `mplsLdpSessionUpDownTrapEnable` must be set to `enabled(1)`.

## Configuration Changes

If entity notifications are enabled, the router generates an `entConfigChange` notification (ENTITY-MIB) when the information in any of the following tables changes (which indicates a change to the router configuration):

- `entPhysicalTable`
- `entAliasMappingTable`
- `entPhysicalContainsTable`



**Note** A management application that tracks configuration changes checks the value of the `entLastChangeTime` object to detect any `entConfigChange` notifications that were missed as a result of throttling or transmission loss.

### Enabling notifications for Configuration Changes

To configure the router to generate an `entConfigChange` notification each time its configuration changes, enter the following command from the CLI. Use the **no** form of the command to disable the notifications.

```
Router(config)# snmp-server enable traps entity
Router(config)# no snmp-server enable traps entity
```

## FRU Status Changes

If FRU notifications are enabled, the router generates the following notifications in response to changes in the status of an FRU:

- `cefcModuleStatusChange`—The operational status (`cefcModuleOperStatus`) of an FRU changes.
- `cefcFRUInserted`—An FRU is inserted in the chassis. The notification indicates the `entPhysicalIndex` of the FRU and the container it was inserted in.
- `cefcFRURemoved`—An FRU is removed from the chassis. The notification indicates the `entPhysicalIndex` of the FRU and the container it was removed from.



**Note** See the `CISCO-ENTITY-FRU-CONTROL-MIB` for more information about these notifications.

### Enabling FRU Notifications

To configure the router to generate notifications for FRU events, enter the following command from the CLI. Use the **no** form of the command to disable the notifications.

```
Router(config)# snmp-server enable traps fru-ctrl
Router(config)# no snmp-server enable traps fru-ctrl
```

To enable FRU notifications through SNMP, set `cefcMIBEnableStatusNotification` to `true(1)`. Disable the notifications by setting `cefcMIBEnableStatusNotification` to `false(2)`.

# Monitoring Router Interfaces

This section provides information about how to monitor the status of router interfaces to see if there is a problem or a condition that might affect service on the interface. To determine if an interface is Down or experiencing problems, you can:

### Check the Interface's Operational and Administrative Status

To check the status of an interface, view the following IF-MIB objects for the interface:

- `ifAdminStatus`—The administratively configured (desired) state of an interface. Use `ifAdminStatus` to enable or disable the interface.
- `ifOperStatus`—The current operational state of an interface.

### Monitor linkDown and linkUp Notifications

To determine if an interface has failed, you can monitor `linkDown` and `linkUp` notifications for the interface. See the [“Enabling Interface linkUp/linkDown Notifications” section on page 5-30](#) for instructions on how to enable these notifications.

- linkDown—Indicates that an interface failed or is about to fail.
- linkUp—Indicates that an interface is no longer in the Down state.

## Enabling Interface linkUp/linkDown Notifications

To configure SNMP to send a notification when a router interface changes state to Up (ready) or Down (not ready), perform the following steps to enable linkUp and linkDown notifications:

- 
- Step 1** Issue the following CLI command to enable linkUp and linkDown notifications for most, but not necessarily all, interfaces:

```
Router(config)# snmp-server enable traps snmp linkdown linkup
```

- Step 2** View the setting of the ifLinkUpDownTrapEnable object (IF-MIB ifXTable) for each interface to determine if linkUp and linkDown notifications are enabled or disabled for that interface.

- Step 3** To enable linkUp and linkDown notifications on an interface, set ifLinkUpDownTrapEnable to enabled(1). To configure the router to send linkDown notifications only for the lowest layer of an interface, see the “SNMP Notification Filtering for linkDown Notifications” section on page 5-30.

- Step 4** To enable the Internet Engineering Task Force (IETF) standard for linkUp and linkDown notifications, issue the following command. (The IETF standard is based on RFC 2233.)

```
Router(config)# snmp-server trap link ietf
```

- Step 5** To disable notifications, use the **no** form of the appropriate command.
- 

## SNMP Notification Filtering for linkDown Notifications

Use the SNMP notification filtering feature to filter linkDown notifications so that SNMP sends a linkDown notification only if the main interface goes down. If an interface goes down, all of its subinterfaces go down, which results in numerous linkDown notifications for each subinterface. This feature filters out those subinterface notifications.

This feature is turned off by default. To enable the SNMP notification filtering feature, issue the following CLI command. Use the **no** form of the command to disable the feature.

```
[no] snmp ifmib trap throttle
```

## Billing Customers for Traffic

This section describes how to use SNMP interface counters and QoS data information to determine the amount to bill customers for traffic. It also includes a scenario for demonstrating that a QoS service policy attached to an interface is policing traffic on that interface.

This section contains the following topics:

- [Input and Output Interface Counts, page 5-31](#)
- [Determining the Amount of Traffic to Bill to a Customer, page 5-31](#)
- [Scenario for Demonstrating QoS Traffic Policing, page 5-31](#)

## Input and Output Interface Counts

The router maintains information about the number of packets and bytes that are received on an input interface and transmitted on an output interface.

For detailed constraints about IF-MIB counter support, see the IF-MIBB (RFC 2863) section.

Read the following important information about the IF-MIB counter support:

- Unless noted, all IF-MIB counters are supported on Cisco 1100 Series ISR interfaces.
- For IF-MIB high capacity counter support, Cisco conforms to the RFC 2863 standard. The RFC 2863 standard states that for interfaces that operate:
  - At 20 million bits per second or less, 32-bit byte and packet counters *must* be supported.
  - Faster than 20 million bits per second and slower than 650,000,000 bits per second, 32-bit packet counters and 64-bit octet counters *must* be supported.
  - At 650,000,000 bits per second or faster, 64-bit packet counters *and* 64-bit octet counters *must* be supported.
- When a QoS service policy is attached to an interface, the router applies the rules of the policy to traffic on the interface and increments the packet and bytes counts on the interface.

The following CISCO-CLASS-BASED-QOS-MIB objects provide interface counts:

- `cbQosCMDropPkt` and `cbQosCMDropByte` (`cbQosCMStatsTable`)—Total number of packets and bytes that were dropped because they exceeded the limits set by the service policy. These counts include only those packets and bytes that were dropped because they exceeded service policy limits. The counts do not include packets and bytes dropped for other reasons.
- `cbQosPoliceConformedPkt` and `cbQosPoliceConformedByte` (`cbQosPoliceStatsTable`)—Total number of packets and bytes that conformed to the limits of the service policy and were transmitted.

## Determining the Amount of Traffic to Bill to a Customer

Perform these steps to determine how much traffic on an interface is billable to a particular customer:

- 
- |               |   |
|---------------|---|
| <b>Step 1</b> | Determine which service policy on the interface applies to the customer.  |
| <b>Step 2</b> | Determine the index values of the service policy and class map used to define the customer's traffic. You need this information in the following steps.   |
| <b>Step 3</b> | Generate traffic with the traffic generator. The data rate should be more than that is configured for Conform burst(bc)/Exceed burst(be) for the policy.  |
| <b>Step 4</b> | (Optional) Access the <code>cbQosCMDropPkt</code> object ( <code>cbQosCMStatsTable</code> ) for the customer to determine how much of the customer's traffic was dropped because it exceeded service policy limits. |
- 

## Scenario for Demonstrating QoS Traffic Policing

This section describes a scenario that demonstrates the use of SNMP QoS statistics to determine how much traffic on an interface is billable to a particular customer. It also shows how packet counts are affected when a service policy is applied to traffic on the interface.

To create the scenario, follow these steps, each of which is described in the sections that follow:

1. Create and attach a service policy to an interface.
2. View packet counts before the service policy is applied to traffic on the interface.
3. Issue a `ping` command to generate traffic on the interface. Note that the service policy is applied to the traffic.
4. View packet counts after the service policy is applied to determine how much traffic to bill the customer for:
  - Conformed packets—The number of packets within the range set by the service policy and for which you can charge the customer.
  - Exceeded or dropped packets—The number of packets that were not transmitted because they were outside the range of the service policy. These packets are not billable to the customer.



**Note** In the above scenario, the Cisco 1100 Series ISR is used as an interim device (that is, traffic originates elsewhere and is destined for another device).

## Service Policy Configuration

This scenario uses the following policy-map configuration. For information on how to create a policy map, see “Configuring Quality of Service” in the *QoS: Classification Configuration Guide, Cisco IOS XE Release 3.9S*.

```
Policy Map test-police
  Class class-default
    police cir 1000000 bc 10000 be 20000
      conform-action transmit
      exceed-action drop
      violate-action drop

interface GigabitEthernet1/1/5
  ip address 15.1.0.52 255.0.0.0
  no negotiation auto
  service-policy output test-police
end
```

## Packet Counts Before the Service Policy Is Applied

The following CLI and SNMP output shows the interface’s output traffic before the service policy is applied:

### CLI Command Output

```
Router# sh policy-map interface gi 1/1/5

GigabitEthernet1/1/5

Service-policy output: test-police

Class-map: class-default (match-any)
  0 packets, 0 bytes
  5 minute offered rate 0 bps, drop rate 0 bps
  Match: any
  police:
    cir 1000000 bps, bc 10000 bytes, be 20000 bytes
    conformed 0 packets, 0 bytes; actions:
      transmit
    exceeded 0 packets, 0 bytes; actions:
      drop
    violated 0 packets, 0 bytes; actions:
```

```

drop
conformed 0 bps, exceed 0 bps, violate 0 bps

```

### SNMP Output

```

ciscouser:4> getmany 9.0.0.52 cbQosIfIndex
cbQosIfIndex.290 = 18
ciscouser:5> getone 9.0.0.52 ifDescr.18
ifDescr.18 = GigabitEthernet1/1/5
ciscouser:6>

getmany 9.0.0.52 cbQosCMDropPkt cbQosCMDropByte
cbQosCMDropPkt.290.9756705 = 0
cbQosCMDropByte.290.9756705 = 0
ciscouser:77>

```

## Packet Counts After the Service Policy Is Applied

After you generate traffic using the traffic generator, look at the number of packets that exceeded and conformed to the committed information rate (CIR) set by the `police` command:

- 19351 packets conformed to the police rate and were transmitted
- 80 packets exceeded the police rate and were dropped
- 16066130 packets violated the police rate and were dropped

The following CLI and SNMP output show the counts on the interface after the service policy is applied. The object `cbQosCMDropPkt` refers to sum of exceeded and violated packets and `cbQosCMDropByte` refers to the sum of exceeded and violated bytes. (In the output, exceeded and violated packet counts are shown in boldface.)

### CLI Command Output

```

Router#sh show policy-map int gi 1/1/5

GigabitEthernet1/1/5

Service-policy output: test-police

Class-map: class-default (match-any)
  16085561 packets, 1994609369 bytes

5 minute offered rate 16051000 bps, drop rate 16032000 bps
Match: any
police:
  cir 1000000 bps, bc 10000 bytes, be 10000 bytes
  conformed 19351 packets, 2399329 bytes; actions:
    transmit
  exceeded 80 packets, 9920 bytes; actions:
    drop
  violated 16066130 packets, 1992200120 bytes; actions:
    drop
  conformed 0 bps, exceed 0 bps, violate 16032000 bps
Router#

```

### SNMP Output

```

getmany 9.0.0.52 cbQosCMDropPkt cbQosCMDropByte
cbQosCMDropPkt.290.9756705 = 16066210
cbQosCMDropByte.290.9756705 = 1992210040
ptolemy:77>

```

## Using IF-MIB Counters

This section describes the IF-MIB counters and how you can use them on various interfaces and subinterfaces. The subinterface counters are specific to the protocols. This section addresses the IF-MIB counters for ATM interfaces.

The IF-MIB counters are defined with respect to lower and upper layers:

- **ifInDiscards**—The number of inbound packets which were discarded, even though no errors were detected to prevent their being deliverable to a higher-layer protocol. One reason for discarding such a packet could be to free up buffer space.
- **IfInErrors**—The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol for packet-oriented interfaces.
- **ifInUnknownProtos**—The number of packets received through the interface which were discarded because of an unknown or unsupported protocol for packet-oriented interfaces.
- **ifOutDiscards**—The number of outbound packets which were discarded even though no errors were detected to prevent their being transmitted. One reason for discarding such a packet is to free up buffer space.
- **ifOutErrors**—The number of outbound packets that could not be transmitted because of errors for packet-oriented interfaces.

The logical flow for counters works as follows:

1. When a packet arrives on an interface, check for the following:
  - a. Error in packet—If any errors are detected, increment **ifInErrors** and drop the packet.
  - b. Protocol errors—If any errors are detected, increment **ifInUnknownProtos** and drop the packet.
  - c. Resources (buffers)—If unable to get resources, increment **ifInDiscards** and drop the packet.
  - d. Increment **ifInUcastPkts/ ifInNUcastPkts** and process the packet (At this point, increment the **ifInOctets** with the size of packet).
2. When a packet is to be sent out of an interface:
  - a. Increment **ifOutUcastPkts/ ifOutNUcastPkts** (Here we also increment **ifOutOctets** with the size of packet).
  - b. Check for error in packet and if there are any errors in packet, increment **ifOutErrors** and drop the packet.
  - c. Check for resources (buffers) and if you cannot get resources then increment **ifOutDiscards** and drop packet.

This following output is an example IF-MIB entries:

IfXEntry ::=

```
SEQUENCE {
    ifName                DisplayString,
    ifInMulticastPkts    Counter32,
    ifInBroadcastPkts   Counter32,
    ifOutMulticastPkts   Counter32,
    ifOutBroadcastPkts  Counter32,
    ifHCInOctets        Counter64,
    ifHCInUcastPkts     Counter64,
    ifHCInMulticastPkts Counter64,
    ifHCInBroadcastPkts Counter64,
    ifHCOutOctets       Counter64,
    ifHCOutUcastPkts    Counter64,
    ifHCOutMulticastPkts Counter64,
    ifHCOutBroadcastPkts Counter64,
    ifLinkUpDownTrapEnable INTEGER,
    ifHighSpeed          Gauge32,
```



```

ifPromiscuousMode      TruthValue,
ifConnectorPresent     TruthValue,
ifAlias                DisplayString,
ifCounterDiscontinuityTime TimeStamp

```

## Sample Counters

The high capacity counters are 64-bit versions of the basic ifTable counters. They have the same basic semantics as their 32-bit counterparts; their syntax is extended to 64 bits.

Table 5-1 lists capacity counter object identifiers (OIDs).

*Table 5-1 Capacity Counters Object Identifiers*

Name	Object Identifier (OID)
ifHCInOctets	::= { ifXEntry 6 }
ifHCInUcastPkts	::= { ifXEntry 7 }
ifHCInMulticastPkts	::= { ifXEntry 8 }
ifHCInBroadcastPkts	::= { ifXEntry 9 }
ifHCOctets	::= { ifXEntry 10 }
ifHCOUcastPkts	::= { ifXEntry 11 }
ifHCOMulticastPkts	::= { ifXEntry 12 }
ifHCOBroadcastPkts	::= { ifXEntry 13 }
ifLinkUpDownTrapEnable	::= { ifXEntry 14 }
ifHighSpeed	::= { ifXEntry 15 }
ifPromiscuousMode	::= { ifXEntry 16 }
ifConnectorPresent	::= { ifXEntry 17 }
ifAlias	::= { ifXEntry 18 }
ifCounterDiscontinuityTime	::= { ifXEntry 19 }

## Related Information and Useful Links

The following URLs provide access to helpful information about Cisco IF-MIB counters:

- Frequently asked questions about SNMP counters:  
[http://www.cisco.com/en/US/customer/tech/tk648/tk362/technologies\\_q\\_and\\_a\\_item09186a00800b69ac.shtml](http://www.cisco.com/en/US/customer/tech/tk648/tk362/technologies_q_and_a_item09186a00800b69ac.shtml)
- Access Cisco IOS MIB Tools from the following URL:  
<http://tools.cisco.com/ITDIT/MIBS/servlet/index>

## Displaying the Module Hardware Type

To verify the SIP hardware type that is installed in your Cisco 1100 Series ISR, you can use the show platform command. The example below shows some list of such commands.

**Example 5-5** Example of the *show platform* command

The following example shows the output of the **show platform** command on the Cisco 1100 Series ISR<sup>1</sup>:

```
Router#sh platform

Router#sh platform ?
  hardware  Show platform hardware information
  software  Show platform software information
  |         Output modifiers
  <cr>

Router#sh platform har
Router#sh platform hardware ?
backplaneswitch-manager  Backplane Switch Manager hardware
  crypto-device          crypto device information
  interface              Interface information
  network-clocks         Show network clock device
  port                   port information
  qfp                    Quantum Flow Processor
  raid                   raid information
  slot                   Slot information
  subslot                Subslot information
  throughput             Show throughput commands

Router#sh platform hardware slot 0 ?
  dram          CPU DRAM commands
  eobc          Show EOBC
  fan           Fan commands
  i95           i95 driver statistics
  io-port       IO Port information
  led           LED-related commands
  mcu           MCU related commands
  network-clocks Show network clock device
  pcie          PCIE-related commands
  plim          PLIM information
  rommon        Rommon commands
  sensor        Sensor information
  serdes        Serdes information
  spa           Module related information
```

1.



---

## B

- Bandwidth** The difference between the highest and lowest frequencies available for network signals. The term is also used to describe the rated throughput capacity of a given network medium or protocol.
- Broadcast storm** Undesirable network event in which many broadcasts are sent simultaneously across all network segments. A broadcast storm uses substantial network bandwidth and, typically, causes network time-outs.

---

## C

- CANA** Cisco Assigned Numbers Authority. The central clearing house for allocation of unique names and numbers that are embedded in Cisco software.
- CLI** Command Line Interface
- CNEM** Consistent Network Element Manageability
- Columnar object** One type of managed object that defines a MIB table that contains no rows or more than one row, and each row can contain one or more scalar objects, (for example, ifTable in the IF-MIB defines the interface).
- Community name** Defines an access environment for a group of NMSs. NMSs within the community are said to exist within the same administrative domain. Community names serve as a weak form of authentication because devices that do not know the proper community name are precluded from SNMP operations.
- Critical alarm severity type** Indicates a severe, service-affecting condition has occurred and that immediate corrective action is imperative, regardless of the time of day or day of the week. For example, online insertion and removal of line cards or loss of signal failure when a physical port link is down.
- CWDM** Coarse Wavelength Division Multiplexing

---

## D

- dBm** Decibel (milliwatts).  $10 * \log_{10}(\text{power in milliwatts})$ . For example, 2 milliwatts is  $10 * \log_{10}(2) = 10 * 0.3010 = 3.01 \text{ dBm}$
- DOM** Digital Optical Monitoring
- Display string** A printable ASCII string. It is typically a name or description. For example, the variable netConfigName provides the name of the network configuration file for a device.

=

<b>DS0</b>	Digital signal level 0. Framing specification used in transmitting digital signals at 64 Kbps. Twenty-four DS0s equal one DS1.
<b>DS1</b>	Digital signal level 1. Framing specification used in transmitting digital signals at 1.544 Mbps on a T1 facility.
<b>DS3</b>	Digital signal level 3. Framing specification used for transmitting digital signals at 44.736 Mbps on a T3 facility.
<b>DWDM</b>	Dense Wave Division Multiplexing

---

**E**

<b>EHSA</b>	Enhanced High System Availability.
<b>EMS</b>	Element Management System. An EMS manages a specific portion of the network. For example the SunNet Manager, an SNMP management application, is used to manage SNMP manageable elements. Element Managers may manage asynchronous lines, multiplexers, PABX's, proprietary systems or an application.
<b>Encapsulation</b>	The wrapping of data in a particular protocol header. For example, Ethernet data is wrapped in a specific Ethernet header before network transit. Also, when bridging dissimilar networks, the entire frame from one network is simply placed in the header used by the data link layer protocol of the other network.

---

**F**

<b>FRU</b>	Field Replaceable Unit. Term applied to the Cisco 6400 components that can be replaced in the field, including the NLC, NSP, NRP, and PEM units, plus the blower fans.
<b>Forwarding</b>	Process of sending a frame toward its ultimate destination by way of an internetworking device.
<b>Frame</b>	Logical grouping of information sent as a data link layer unit over a transmission medium. Often refers to the header and trailer, used for synchronization and error control, that surround the user data contained in the unit. The terms cell, datagram, message, packet, and segment are also used to describe logical information groupings at various layers of the OSI reference model and in various technology circles.

---

**G**

<b>Gb</b>	gigabit
<b>GBIC</b>	Gigabit Interface Converter —An optical transceiver (transmitter and receiver) housed in a small (30 mm x 65 mm), hot-pluggable, subenclosure. A GBIC converts electric currents (digital highs and lows) to optical signals and optical signals to digital electric currents.
<b>Gbps</b>	gigabits per second

<b>GB</b>	gigabyte
<b>GBps</b>	gigabytes per second
<b>10GE</b>	10 Gigabit per second Ethernet

---

## H

<b>HSRP</b>	Hot Standby Routing Protocol. Protocol used among a group of routers for selecting an active router and a standby router. (An active router is the router of choice for routing packets; a standby router is a router that takes over the routing duties when an active router fails, or when preset conditions are met.)
-------------	---

---

## I

<b>IEEE 802.2</b>	IEEE LAN protocol that specifies an implementation of the LLC sublayer of the data link layer. IEEE 802.2 handles errors, framing, flow control, and the network layer (Layer 3) service interface. Used in IEEE 802.3 and IEEE 802.5 LANs. See also IEEE 802.3 and IEEE 802.5.
<b>IEEE 802.3</b>	IEEE LAN protocol that specifies an implementation of the physical layer and the MAC sublayer of the data link layer. IEEE 802.3 uses CSMA/CD access at a variety of speeds over a variety of physical media. Extensions to the IEEE 802.3 standard specify implementations for Fast Ethernet.
<b>IEEE 802.5</b>	IEEE LAN protocol that specifies an implementation of the physical layer and MAC sublayer of the data link layer. IEEE 802.5 uses token passing access at 4 or 16 Mbps over STP cabling and is similar to IBM Token Ring. See also Token Ring.
<b>IETF</b>	The Internet Engineering Task Force
<b>Info</b>	Notification about a condition that could lead to an impending problem or notification of an event that improves operation.
<b>Informs</b>	Reliable messages, which are stored in memory until the SNMP manager issues a response. Informs use more system resources than traps.
<b>ifIndex</b>	Each row of the interfaces table has an associated number, called an ifIndex. You use the ifIndex number to get a specific instance of an interfaces group object. For example, ifInNUcastPkts.1 would find you the number of broadcast packets received on interface number one. You can then find the description of interface number one by looking at the object which holds the interface description (from MIB-II) ifDescr.
<b>Integer</b>	A numeric value that can be an actual number. For example, the number of lost IP packets on an interface. It also can be a number that represents a nonnumeric value. For example, the variable tsLineType returns the type of terminal services line to the SNMP manager.

=

<b>Interface counters</b>	<p>Interface management over SNMP is based on two tables: ifTable and its extension, ifXTable described in RFC1213/RFC2233. Interfaces can have several layers, depending on the media, and each sub-layer is represented by a separate row in the table. The relationship between the higher layer and lower layers is described in the ifStackTable.</p> <p>The ifTable defines 32-bit counters for inbound and outbound octets (ifInOctets / ifOutOctets), packets (ifInUcastPkts / ifOutUcastPkts, ifInNUcastPkts / ifOutNUcastPkts), errors, and discards.</p> <p>The ifXTable provides similar 64-bit counters, also called high capacity (HC) counters: ifHCInOctets / ifHCOutOctets, and ifHCInUcastPkts / ifHCOutUcastPkts.</p>
<b>Internetwork</b>	<p>Collection of networks interconnected by routers and other devices that functions as a single network. Sometimes called an internet, which is not to be confused with the Internet.</p>
<b>Interoperability</b>	<p>Ability of computing equipment manufactured by different vendors to communicate with one another successfully over a network.</p>
<b>IP Address</b>	<p>The variable hostConfigAddr indicates the IP address of the host that provided the host configuration file for a device.</p>

---

**J**

No terms

---

**K**

<b>Keepalive message</b>	<p>Message sent by one network device to inform another network device that the virtual circuit between the two is still active.</p>
--------------------------	--

---

**L**

<b>Label</b>	<p>A short, fixed-length identifier that is used to determine the forwarding of a packet.</p>
<b>LDP</b>	<p>Label Distribution Protocol.</p>
<b>LR</b>	<p>Long Reach.</p>
<b>LSR</b>	<p>Label Switching Router. A device that forwards MPLS packets based on the value of a fixed-length label encapsulated in each packet.</p>
<b>LSP</b>	<p>Label Switched Path.</p>
<b>LX/LH</b>	<p>Long wavelength/long haul</p>

---

**M**

<b>Major alarm severity type</b>	Used for hardware or software conditions. Indicates a serious disruption of service or the malfunctioning or failure of important hardware. Requires immediate attention and response of a technician to restore or maintain system stability. The urgency is less than in critical situations because of a lesser effect on service or system performance. For example, a minor alarm is generated if a secondary NSE-100 or NPE-G100 card fails or it is removed.
<b>Minor alarm severity type</b>	Used for troubles that do not have a serious effect on service to customers or for alarms in hardware that are not essential to the operation of the system.
<b>MIB</b>	Management Information Base. Database of network management information that is used and maintained by a network management protocol such as SNMP. The value of a MIB object can be changed or retrieved by means of SNMP commands, usually through a network management system. MIB objects are organized in a tree structure that includes public (standard) and private (proprietary) branches.
<b>MIB II</b>	MIB-II is the follow on to MIB-I which was the original standard SNMP MIB. MIB-II provided some much needed enhancements to MIB-I. MIB-II is very old, and most of it has been updated (that which has not is mostly obsolete). It includes objects that describe system related data, especially data related to a system's interfaces.
<b>MPLS</b>	Multiprotocol Label Switching. MPLS is a method for forwarding packets (frames) through a network. It enables routers at the edge of a network to apply labels to packets (frames). ATM switches or existing routers in the network core can switch packets according to the labels with minimal lookup overhead.
<b>MPLS interface</b>	An interface on which MPLS traffic is enabled. MPLS is the standardized version of Cisco original tag switching proposal. It uses a label forwarding paradigm (forward packets based on labels).
<b>MTU</b>	Maximum transmission unit. Maximum packet size, in bytes, that a particular interface can handle.

---

**N**

<b>NAS</b>	Network access server. Cisco platform or collection of platforms such as an AccessPath system which interfaces between the Internet and the circuit world (the PSTN).
<b>NMS</b>	Network management system. System responsible for managing at least part of a network. An NMS is generally a reasonably powerful and well-equipped computer, such as an engineering workstation. NMSs communicate with agents to help keep track of network statistics and resources.
<b>NHLFE</b>	Next Hop Label Forwarding Entry.

=

---

**O**

- OID** Object identifier. Values are defined in specific MIB modules. The Event MIB allows you or an NMS to watch over specified objects and to set event triggers based on existence, threshold, and Boolean tests. An event occurs when a trigger is fired; this means that a specified test on an object returns a value of true. To create a trigger, you or an NMS configures a trigger entry in the mteTriggerTable of the Event MIB. This trigger entry specifies the OID of the object to be watched. For each trigger entry type, corresponding tables (existence, threshold, and Boolean tables) are populated with the information required for carrying out the test. The MIB can be configured so that when triggers are activated (fired) either an SNMP Set is performed, a notification is sent out to the interested host, or both.
- OIR** Online Insertion and Removal.
- OSM** Optical Services Module

---

**P**

- PA** Port Adapter
- PAP** Password Authentication Protocol. Authentication protocol that allows PPP peers to authenticate one another. The remote router attempting to connect to the local router is required to send an authentication request. Unlike CHAP, PAP passes the password and host name or username in the clear (unencrypted). PAP does not itself prevent unauthorized access, but identifies the remote end. The router or access server determines if that user is allowed access. PAP is supported only on PPP lines.
- PEM** Power Entry Module.
- Polling** Access method in which a primary network device inquires, in an orderly fashion, whether secondaries have data to transmit. The inquiry occurs in the form of a message to each secondary that gives the secondary the right to transmit.
- POS** Packet Over SONET
- PPP** Point-to-Point Protocol. Provides router-to-router and host-to-network connections over synchronous and asynchronous circuits. PPP is designed to work with several network layer protocols, such as IP, IPX, and ARA. PPP also has built-in security mechanisms, such as CHAP and PAP. PPP relies on two protocols: LCP and NCP.

---

**Q**

- QoS** Quality of service. Measure of performance for a transmission system that reflects its transmission quality and service availability.

---

**R**

- RADIUS** Remote Authentication Dial-In User Service. RADIUS is a distributed client/server system that secures networks against unauthorized access. In the Cisco implementation, RADIUS clients run on Cisco routers and send authentication requests to a central RADIUS server that contains all user authentication and network service access information.



<b>Read-only</b>	This variable can be used to monitor information only. For example, the locIPUnreach variable, whose access is read-only, indicates whether Internet Control Message Protocol (ICMP) packets concerning an unreachable address will be sent.
<b>Read-write</b>	<p>This variable can be used to monitor information and to set a new value for the variable. For example, the tsMsgSend variable, whose access is read-write, determines what action to take after a message has been sent.</p> <p>The possible integer values for this variable follow:</p> <p>1 = nothing</p> <p>2 = reload</p> <p>3 = message done</p> <p>4 = abort</p>
<b>RFC</b>	<p>Requests for Comments, started in 1969, form a series of notes about the Internet (originally the ARPANET). The notes discuss many aspects of computer communication, focusing on networking protocols, procedures, programs, and concepts, but also include meeting notes, opinions, and sometimes humor.</p> <p>The RFC Editor is the publisher of RFCs and is responsible for the final editorial review of the documents. The RFC Editor also maintains a master file of RFCs, the RFC index, that you can search online here.</p> <p>The specification documents of the Internet protocol suite, as defined by the Internet Engineering Task Force (IETF) and its steering group, the Internet Engineering Steering Group (IESG), are published as RFCs. Thus, the RFC publication process plays an important role in the Internet standards process. Go to the following URL for details:</p> <p><a href="http://www.cisco.com/en/US/docs/ios/11_0/mib/quick/reference/mtext.html">http://www.cisco.com/en/US/docs/ios/11_0/mib/quick/reference/mtext.html</a></p>
<b>RMON</b>	The Remote Network Monitoring MIB is a SNMP MIB for remote management of networks. RMON is one of the many SNMP based MIBs that are IETF Standards. RMON allows network operators to monitor the health of the network with a Network Management System (NMS). RMON watches several variables, such as Ethernet collisions, and triggers an event when a variable crosses a threshold in the specified time interval.
<b>RSVP</b>	Resource Reservation Protocol. Protocol that supports the reservation of resources across an IP network. Applications running on IP end systems can use RSVP to indicate to other nodes the nature (bandwidth, jitter, maximum burst, and so forth) of the packet streams they want to receive. RSVP depends on IPv4. Also known as Resource Reservation Setup Protocol.

---

## S

<b>Scalar object</b>	One type of managed object which is a single object instance (for example, ifNumber in the IF-MIB and bgpVersion in the BGP4-MIB).
----------------------	--

=

<b>Security model</b>	A security model is an authentication strategy that is set up for a user and the group in which the user resides. A security level is the permitted level of security within a security model. A combination of a security model and a security level determines which security mechanism is employed when handling an SNMP packet.
<b>SEEPROM</b>	Serial Electrically Erasable Programmable Read Only Memory
<b>SR</b>	Short Reach
<b>SIP</b>	SPA Interface Processor. Line card that carries the SPAs. Also referred to as MSP (Modular Services Processor and functions as a carrier card for shared port adapters)
<b>SNMPv1</b>	The Simple Network Management Protocol: An Internet standard, defined in RFC 1157. Security is based on community strings. SNMPv1 uses a community-based form of security. The community of managers who are able to access the agent MIB is defined by an IP address Access Control List and password.
<b>SNMPv2</b>	<p>The community-string based administrative framework for SNMPv2. SNMPv2c is an update of the protocol operations and data types of SNMPv2p (SNMPv2 classic), and uses the community-based security model of SNMPv1.</p> <p>SNMPv2c support includes a bulk-retrieval mechanism and more detailed error message reporting to management stations. The bulk-retrieval mechanism supports the retrieval of tables and large quantities of information, minimizing the number of round-trip transmissions required. SNMPv2c improved error handling support includes expanded error codes that distinguish different kinds of error conditions; these conditions are reported through a single error code in SNMPv1. Error return codes now report the error type. Three kinds of exceptions are also reported:</p> <ul style="list-style-type: none"><li>• no such object exceptions</li><li>• no such instance exceptions</li><li>• end of MIB view exceptions</li></ul>
<b>SNMPv3</b>	<p>SNMPv3—Version 3 of SNMP. SNMPv3 uses the following security features to provide secure access to devices:</p> <ul style="list-style-type: none"><li>• Message integrity—Ensuring that a packet has not been tampered with in transit.</li><li>• Authentication—Determining that the message is from a valid source.</li><li>• Encryption—Scrambling the contents of a packet to prevent it from being learned by an unauthorized source.</li></ul>
<b>SNMP agent</b>	A software component in a managed device that maintains the data for the device and reports the data, as needed, to managing systems. The agent and MIB reside on the routing device (router, access server, or switch). To enable the SNMP agent on a managed device, you must define the relationship between the manager and the agent.
<b>SNMP manager</b>	A system used to control and monitor the activities of network hosts using SNMP. The most common managing system is called a Network Management System (NMS). The term NMS can be applied to either a dedicated device used for network management, or the applications used on a network-management device. A variety of network management applications are available for use with SNMP. These features range from simple command-line applications to feature-rich graphical user interfaces (such as the CiscoWorks2000 line of products).

<b>SONET</b>	Synchronous Optical Network. A physical layer interface standard for fiber optic transmission. High-speed synchronous network specification developed by Telcordia Technologies, Inc. and designed to run on optical fiber. STS-1 is the basic building block of SONET. Approved as an international standard in 1988.
<b>SPA</b>	Shared Port Adapter card
<b>SX</b>	Short wavelength
<hr/>	
<b>T</b>	
<b>TE</b>	Traffic Engineered
<b>Time stamp</b>	Provides the amount of time that has elapsed between the last network reinitialization and generation of the trap.
<b>TLV</b>	Type Length Value. Dynamic format for storing data in any order. Used by Cisco's Generic ID PROM for storing asset information.
<b>Traffic engineering tunnel</b>	A label-switched tunnel that is used for traffic engineering. Such a tunnel is set up through means other than normal Layer 3 routing; it is used to direct traffic over a path different from the one that Layer 3 routing could cause the tunnel to take.
<b>Trap</b>	An trap is an unsolicited (device initiated) message. The contents of the message might be simply informational, but it is mostly used to report real-time trap information. Since a trap is a UDP datagram, sole reliance upon them to inform you of network problems (i.e. passive network monitoring) is not wise. They can be used in conjunction with other SNMP mechanisms as in trap-directed polling or the SNMP inform mechanism can be used when a reliable fault reporting system is required.
<b>Tunnel</b>	A secure communication path between two peers, such as routers.
<hr/>	
<b>U</b>	
<b>UBR</b>	Unspecified bit rate. QOS class defined by the ATM Forum for ATM networks. UBR allows any amount of data up to a specified maximum to be sent across the network, but there are no guarantees in terms of cell loss rate and delay. Compare with ABR (available bit rate), CBR, and VBR.
<b>UDI</b>	Cisco Unique Device Identifier
<b>UDP</b>	User Datagram Protocol.
<hr/>	
<b>V</b>	
<b>VBR</b>	Variable bit rate. QOS class defined by the ATM Forum for ATM networks. VBR is subdivided into a real time (RT) class and non-real time (NRT) class. VBR (RT) is used for connections in which there is a fixed timing relationship between samples. VBR (NRT) is used for connections in which there is no fixed timing relationship between samples, but that still need a guaranteed QOS.

=

**VRF** VPN Routing and Forwarding Tables.

**VTP** VLAN Trunking Protocol

---

**W**

**WFQ** Weighted Fair Queueing

**Write-only** This variable can be used to set a new value for the variable only. For example, the writeMem variable, whose access is write-only, writes the current (running) router configuration into nonvolatile memory where it can be stored and retained even if the router is reloaded. If the value is set to 0, the writeMem variable erases the configuration memory.

**Write view** A view name (not to exceed 64 characters) for each group; the view name defines the list of object identifiers (OIDs) that can be created or modified by users of the group.

---

**X**

**XENPAK** Fiber transceiver module which conforms to the 10GbE

---

**Z**

**ZX** Extended reach GBIC