

Release Notes for Cisco IOS Release 15.5(1)T

The following release notes support Cisco IOS Releases 15.5(1)T and higher releases. These releases support the Cisco 5900 Embedded Services Routers (ESR) platforms. These release notes are updated to describe new features, limitations, troubleshooting, recommended configurations, caveats, and how to obtain support and documentation.

Contents

This publication consists of the following sections:

- Image Information and Supported Platforms, page 2
- Related Documentation, page 2
- Recommended Configuration Settings, page 3
- Caveats, page 6
- Obtaining Documentation and Submitting a Service Request, page 7



Image Information and Supported Platforms



You must have a Cisco.com account to download the software.

Cisco IOS Release 15.5(1)T includes the following Cisco IOS images:

• c5921i86-universalk9-ms.SPA

Related Documentation

The following documentation is available:

- Software Configuration Guide for the Cisco 5900 Embedded Services Routers
 http://www.cisco.com/c/en/us/td/docs/solutions/GGSG-Engineering/15-4-3M/config-guide/Configuration-Guide.html
- Cisco 5921 Embedded Services Router Integration Guide
 http://www.cisco.com/c/dam/en/us/td/docs/solutions/GGSG-Engineering/Cisco_5
 921/Cisco_5921_ESR_Integration.pdf

Recommended Configuration Settings

Use the following configuration guidelines when enabling class-based weighted fair-queuing:

• Enter the following command to turn off creation of virtual-template subinterfaces:

```
no virtual-template subinterface
```

• Enter the following commands to create a policy map with class-based weighted fair-queuing and apply the newly created policy-map to the virtual template:

```
class-map match-any chat
match dscp af11
class-map match-any voice
match dscp ef

policy-map mypolicy
class chat
bandwidth percent 40
class voice
bandwidth percent 40

interface virtual-template number
service-policy output mypolicy
```

• No additional configuration is supported on the policy-map.

Use the following configuration guidelines when disabling Point to Point Protocol (PPP) keepalives:

- You can turn off the PPP keepalive messages to decrease overhead when the radio alerts the router
 with a PPPoE Active Discovery Terminate (PADT) message that the layer-2 RF connection is no
 longer available. Turning off the PPP keepalive messages may also avoid the potential for the router
 to terminate the connection based on missed PPP keepalives over a poor radio frequency (RF) link.
- To turn off the PPP keepalive messages, enter the following command for the virtual-template:

```
interface virtual-template number
no keepalive
```

Use the following configuration guidelines for setting the recommended Open Shortest Path First (OSPF) values of radio link metrics:

- You may have to dampen the amount of changes in order to reduce network-wide churn because cost components may change rapidly.
- The following recommended values are intended as a starting point for optimizing an OSPFv3
 network and are based on network simulations that may reduce the rate of network changes. Each
 network may have unique characteristics that require different settings to optimize actual network
 performance.

You must configure these values for both OSPFv3 IPv4 and IPv6:

```
S1 = ipv6 ospf dynamic weight throughout
Recommended value = 0
Default=100
S2 = ipv6 ospf dynamic weight resources
Recommended value = 29
Default = 100
S3 = ipv6 ospf dynamic weight latency
Recommended value = 29
Default = 100
```

```
S4 = ipv6 ospf dynamic weight L2 factor
Recommended value = 29
Default = 100
```

The following is an example configuration for a VMI interface on the virtual template when running bypass mode:

```
interface vmi1
...
ipv6 ospf cost dynamic weight throughput 0
ipv6 ospf cost dynamic weight resources 29
ipv6 ospf cost dynamic weight latency 29
ipv6 ospf cost dynamic weight L2-factor 29
...
ospfv3 cost dynamic weight throughput 0
ospfv3 cost dynamic weight resources 29
ospfv3 cost dynamic weight latency 29
ospfv3 cost dynamic weight L2-factor 29
```

Use the following configuration guidelines for disabling split horizon in EIGRP:

• By default split horizon is enabled in EIGRP. You can disable split horizon by entering the **no ip** split-horizon eigrp command for the respective autonomous system number.

```
interface vmi number
no ip split-horizon eigrp as-number
```

• Enter the following command to disable the ip redirects on the vmi interface when you are configuring the vmi interface for EIGRP:

```
interface vmi number
no ip redirects
```

Use the following configuration guidelines for setting EIGRP values of radio link metrics:

• EIGRP monitors the following metrics on an interface allowing the tuning of the EIGRP metric calculations; use the metric weights router configuration command:

```
metric weights tos k1 k2 k3 k4 k5
```

where tos denotes type of service (currently, it must always be zero) and use the following default values for weights:

- k1 1
- k2 0
- k3 1
- k4 0
- k5 0



The **no metric weights** command restores the K-values to the defaults listed above.

- Most configurations use the Delay and Bandwidth metrics with Bandwidth taking precedence.
- You must set the weights identically on all routers in an autonomous system.



If you wish to use the default K-values you do not need to enter the **metric weights** command.

- To set the metric dampening value for EIGRP, enter the following commands for either change-based or interval-based dampening of metric updates received through VMI:
 - Change Based Dampening:

```
ip50-1(config) #int vmi 4
ip50-1(config-if) #eigrp 100 interface dampening-change 40
```

Default Value for Change Based Dampening:

50%

To enable change-based dampening using the default Value, enter the following command:

```
eigrp 100 interface dampening-change
```

To disable change-based dampening, enter the following command:

```
no eigrp 100 interface dampening-change
```

Interval-based Dampening:

```
ip50-1(config)#int vmi 4
ip50-1(config-if)#eigrp 100 interface dampening-interval 20
```

Default Timer value for Interval-based Dampening:

30 seconds

To enable interval-based dampening using the default Value, enter the following command:

```
eigrp 100 interface dampening-interval
```

To disable interval-based dampening, enter the following command:

```
no eigrp 100 interface dampening-interval
```

- The following exceptions will result in an immediate update:
 - a down interface
 - a down route
 - any change in a metric triggered outside the scope of the VMI metric update



No recommended values other than default are currently available.

For more information on EIGRP commands, refer to:

http://www.cisco.com/en/US/docs/ios/iproute_eigrp/command/reference/ire_book.html

Use the following configuration guidelines to enable Waas Express:

• Enter the following command to turn Waas Express on the Wan interface:

```
waas enable
```

• Enter the following commands to enable full optimizations:

```
parameter-map type waas waas_global
tfo optimize full
```

• Enter the following commands to enable application accelerators:

```
parameter-map type waas waas_global
accelerator http-express
enable
accelerator cifs-express
enable
```

accelerator ssl-express enable

For more information on Waas Express configuration, refer to the following URLs:

http://www.cisco.com/en/US/docs/ios/wan/configuration/guide/cfg_waas_exp.pdf
http://www.cisco.com/en/US/docs/ios-xml/ios/wan_waas/configuration/15-2mt/wan-cfg-waas-exp.html

Caveats

Caveats describe unexpected behavior in Cisco IOS releases. Caveats listed as open in a prior release are carried forward to the next release as either open or closed (resolved).

Cisco IOS Release 15.5(1)T

The following sections list caveats for Cisco IOS Release 15.5(1)T:

Open Caveats

• CSCuq45380

The Smart Licensing throughput level is not active after a reload.

Workaround: Reconfigure the throughput level.

• CSCur43562

Traceback message seen in c5921

Workaround: None

Closed Caveats

None

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see What's New in Cisco Product Documentation at: http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html.

Subscribe to What's New in Cisco Product Documentation, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2012-2015 Cisco Systems, Inc. All rights reserved.

Printed in the USA on recycled paper containing 10% postconsumer waste.