



CHAPTER 2

Using Troubleshooting Tools

This chapter describes the troubleshooting tools available for the Cisco Virtual Security Gateway (VSG).

This chapter includes the following sections:

- [Commands, page 2-1](#)
- [Ping, page 2-1](#)
- [Traceroute, page 2-2](#)
- [Monitoring Processes and CPUs, page 2-2](#)
- [Syslog, page 2-7](#)
- [CLI Configuration, page 2-8](#)
- [Show Commands, page 2-14](#)

Commands

Use the CLI from a local console or remotely use the CLI through a Telnet or Secure Shell (SSH) session. The CLI provides a command structure similar to the Cisco NX-OS software, with context-sensitive help, **show** commands, multi-user support, and role-based access control.

Each feature has **show** commands that provide information about the feature configuration, status, and performance. Additionally, you can use the following commands for more information:

- **show system**—Provides information on system-level components, including codes, errors, and exceptions. Use the **show system error-id** command to find details on error codes:

```
vsg# show system error-id 0x401e0008
Error Facility: sysmgr
Error Description: request was aborted, standby disk may be full
```

Ping

The ping utility generates a series of *echo* packets to a destination across a TCP/IP internetwork. When the echo packets arrive at the destination, they are rerouted and sent back to the source. Using ping, you can verify connectivity and latency to a particular destination across an IP routed network.

Ping allows you to ping a port or end device. By specifying the IPv4 address, you can send a series of frames to a target destination. Once these frames reach the target, they are looped back to the source and a time stamp is taken. Ping helps you to verify the connectivity and latency to a destination.

Send document comments to vsg-docfeedback@cisco.com.

Traceroute

Use traceroute to do the following tasks:

- Trace the route followed by the data traffic.
- Compute inter-switch (hop-to-hop) latency.

The **traceroute** command identifies the path taken on a hop-by-hop basis and includes a time stamp at each hop in both directions. This command tests the connectivity of ports along the path between the generating switch and the switch closest to the destination.

If the destination cannot be reached, the path discovery starts, which traces the path up to the point of failure.

Monitoring Processes and CPUs

You can monitor and the CPU status and utilization.

This section includes the following topics:

- [Identifying the Running Processes and their States, page 2-2](#)
- [Displaying CPU Utilization, page 2-5](#)
- [Displaying CPU and Memory Information, page 2-6](#)

Identifying the Running Processes and their States

The **show processes** command identifies the running processes and the status of each process as follows:

- PID—Process ID.
- State—Process state.
- PC—Current program counter in hex format.
- Start_cnt—How many times a process has been started (or restarted).
- TTY—Terminal that controls the process. A dash (-) usually means a daemon that is not running on any particular TTY.
- Process—Name of the process.

Process states are as follows:

- D—Uninterruptible sleep (usually I/O).
- R—Runnable (on run queue).
- S—Sleeping.
- T—Traced or stopped.
- Z—Defunct zombie process.
- NR—Not-running.
- ER—Should be running but is currently not running. The ER state typically designates a process that has been restarted too many times which causes the system to classify it as faulty and disable it.

This example shows how to identify the available options for the **show processes** command:

```
vsg# show processes ?
```

Send document comments to vsg-docfeedback@cisco.com.

```
<CR>
>      Redirect it to a file
>>     Redirect it to a file in append mode
cpu    Show processes CPU Info
log    Show information about process logs
memory Show processes Memory Info
vdc    Show processes in vdc
|      Pipe command output to filter
vsg#
```

This example shows the complete output from the Cisco VSG for the **show processes** command:

```
vsg# show processes
```

PID	State	PC	Start_cnt	TTY	Process
1	S	b7f8a468	1	-	init
2	S	0	1	-	ksoftirqd/0
3	S	0	1	-	desched/0
4	S	0	1	-	events/0
5	S	0	1	-	khelper
10	S	0	1	-	kthread
18	S	0	1	-	kblockd/0
35	S	0	1	-	khubd
188	S	0	1	-	pdflush
189	S	0	1	-	pdflush
190	S	0	1	-	kswapd0
191	S	0	1	-	aio/0
776	S	0	1	-	kseriod
823	S	0	1	-	kide/0
833	S	0	1	-	ata/0
837	S	0	1	-	scsi_eh_0
1175	S	0	1	-	kjournald
1180	S	0	1	-	kjournald
1743	S	0	1	-	kjournald
1750	S	0	1	-	kjournald
1979	S	b7f6c18e	1	-	portmap
1992	S	0	1	-	nfsd
1993	S	0	1	-	nfsd
1994	S	0	1	-	nfsd
1995	S	0	1	-	nfsd
1996	S	0	1	-	nfsd
1997	S	0	1	-	nfsd
1998	S	0	1	-	nfsd
1999	S	0	1	-	nfsd
2000	S	0	1	-	lockd
2001	S	0	1	-	rpciod
2006	S	b7f6e468	1	-	rpc.mountd
2012	S	b7f6e468	1	-	rpc.statd
2039	S	b7dd1468	1	-	sysmgr
2322	S	0	1	-	mping-thread
2323	S	0	1	-	mping-thread
2339	S	0	1	-	stun_kthread
2340	S	0	1	-	stun_arp_mts_kt
2341	S	0	1	-	stun_packets_re
2376	S	0	1	-	redun_kthread
2377	S	0	1	-	redun_timer_kth
2516	S	0	1	-	sf_rdn_kthread
2517	S	b7f37468	1	-	xinetd
2518	S	b7f6e468	1	-	tftpd
2519	S	b79371b6	1	-	syslogd
2520	S	b7ecb468	1	-	sdwrapd
2521	S	b7d6c468	1	-	platform
2526	S	0	1	-	ls-notify-mts-t

Send document comments to vsg-docfeedback@cisco.com.

```

2539      S b7eaabe4          1      - pfm_dummy
2548      S b7f836be          1      - klogd
2555      S b7c07be4          1      - vshd
2556      S b7e4e468          1      - stun
2557      S b7af2f43          1      - smm
2558      S b7ea0468          1      - session-mgr
2559      S b7cb2468          1      - psshelper
2560      S b7f75468          1      - lmgrd
2561      S b7e69be4          1      - licmgr
2562      S b7eb4468          1      - fs-daemon
2563      S b7e96468          1      - feature-mgr
2564      S b7e44468          1      - confcheck
2565      S b7ea8468          1      - capability
2566      S b7cb2468          1      - psshelper_gsvc
2577      S b7f75468          1      - cisco
2580      S b777d40d          1      - clis
2586      S b76a340d          1      - port-profile
2588      S b7cf9468          1      - xmlma
2589      S b7e59497          1      - vnm_pa_intf
2590      S b7e6c468          1      - vmm
2591      S b7b7d468          1      - vdc_mgr
2592      S b7e72468          1      - ttyd
2593      R b7eda5f5          1      - sysinfo
2594      S b7d06468          1      - sksd
2596      S b7e82468          1      - res_mgr
2597      S b7e48468          1      - plugin
2598      S b7bb7f43          1      - npacl
2599      S b7e93468          1      - mvsh
2600      S b7e01468          1      - module
2601      S b78fb40d          1      - fwm
2602      S b7e92468          1      - evms
2603      S b7e8c468          1      - evmc
2604      S b7ec3468          1      - core-dmon
2605      S b7e10468          1      - bootvar
2606      S b767040d          1      - ascii-cfg
2607      S b7ce4be4          1      - securityd
2608      S b77bf40d          1      - cert_enroll
2609      S b7ce1468          1      - aaa
2612      S b7aecf43          1      - l3vm
2613      S b7adff43          1      - u6rib
2614      S b7addf43          1      - urib
2615      S b7dce468          1      - ExceptionLog
2616      S b7da8468          1      - ifmgr
2617      S b7ea4468          1      - tcap
2621      S b75e140d          1      - snmpd
2637      S b7f03896          1      - PMon
2638      S b7be1468          1      - aclmgr
2662      S b7af0f43          1      - adjmgr
2670      S b7aecf43          1      - arp
2671      S b791c896          1      - icmpv6
2672      S b7993f43          1      - netstack
2746      S b778d40d          1      - radius
2747      S b7f3ebe4          1      - ip_dummy
2748      S b7f3ebe4          1      - ipv6_dummy
2749      S b789840d          1      - ntp
2750      S b7f3ebe4          1      - pktmgr_dummy
2751      S b7f3ebe4          1      - tcpudp_dummy
2755      S b782740d          1      - cdp
2756      S b7b6240d          1      - dcos-xinetd
2758      S b7b8d40d          1      - ntpd
2869      S b7dd9468          1      - vsim
2870      S b797440d          1      - ufdm
2871      S b796740d          1      - sal
2872      S b793840d          1      - pltfm_config

```

Send document comments to vsg-docfeedback@cisco.com.

```

2873      S  b782f40d          1    -  monitor
2874      S  b7d80468          1    -  ipqosmgr
2875      S  b7a2827b          1    -  igmp
2876      S  b7a4340d          1    -  eth-port-sec
2877      S  b7b29468          1    -  copp
2878      S  b7ad740d          1    -  eth_port_channel
2879      S  b7b05468          1    -  vlan_mgr
2880      S  b767240d          1    -  ethpm
2921      S  b7d1e468          1    -  msp
2924      S  b7e8c468          1    -  vsn_service_mgr
2925      S  b7e25497          1    -  sp
2926      S  b7832497          1    -  policy_engine
2927      S  b7e3d497          1    -  inspect
3064      S  b7f836be          1    1  getty
3066      S  b7f806be          1    S0  getty
3091      S  b7f1deee          1    -  pa-httpd.sh
3092      S  b73da4c7          1    -  svc_sam_vsnAG
3096      S  b7db7b49          1    -  httpd
3098      S  b7476be4          1    -  svc_sam_commonA
3103      S  b70254c7          1    -  svc_sam_dme
3108      S  b7f1deee          1    -  sam_cores_mon.s
3150      S  b7db6dcc          1    -  httpd
25835     S  b7b4f40d          1    -  dcos_sshd
25850     S  b78e7eee          1    0  vsh
26766     S  b7f5d468          1    -  sleep
26768     S  b7f5d468          1    -  sleep
26769     R  b7f426be          1    0  more
26770     R  b790ebe4          1    0  vsh
26771     R  b7f716be          1    -  ps
-         NR  -                  0    -  tacacs
-         NR  -                  0    -  dhcp_snoop
-         NR  -                  0    -  installer
-         NR  -                  0    -  private-vlan
-         NR  -                  0    -  scheduler
-         NR  -                  0    -  vbuilder
vsg#

```

Displaying CPU Utilization

The **show processes cpu** command displays CPU utilization. Command output includes:

- Runtime(ms)—CPU time the process has used, expressed in milliseconds
- Invoked—Number of times the process has been invoked
- uSecs—Microseconds of CPU time in average for each process invocation
- 1Sec—CPU utilization in percentage for the last one second

This example shows all of the CPU processes:

```
vsg# show processes cpu
```

PID	Runtime (ms)	Invoked	uSecs	1Sec	Process
1	1519	14917	101	0.0%	init
2	555	16391	33	0.0%	ksoftirqd/0
3	96	59084	1	0.0%	desched/0
4	1469	36858	39	0.0%	events/0
5	35	2901	12	0.0%	khelper
10	0	14	3	0.0%	kthread
18	1	193	9	0.0%	kblockd/0
35	0	1	3	0.0%	khubd

Send document comments to vsg-docfeedback@cisco.com.

```

188          0          3          0      0.0% pdflush
189         95      13678          6      0.0% pdflush
190          0          1          0      0.0% kswapd0
191          0          2          1      0.0% aio/0
776          0          1          3      0.0% kseriod
823          3          138         28      0.0% kide/0
833          0          2          2      0.0% ata/0
837          0          1          4      0.0% scsi_eh_0
1175         0          5          12      0.0% kjournald
1180         0          1          5      0.0% kjournald
1743         5          194         29      0.0% kjournald
1750         0          21         21      0.0% kjournald
1979         0          21         25      0.0% portmap
1992         0          32         23      0.0% nfsd
1993         0          20          4      0.0% nfsd
1994         0          20          2      0.0% nfsd
1995         0          20          2      0.0% nfsd
1996         0          20          1      0.0% nfsd
1997         0          20          9      0.0% nfsd
1998         0          22          3      0.0% nfsd
1999         0          22          3      0.0% nfsd
2000         0          2         18      0.0% lockd
2001         0          1          1      0.0% rpciod
2006         0          1         53      0.0% rpc.mountd
2012         1          5         341     0.0% rpc.statd
2039        906     148314          6      0.0% sysmgr
2322         0          1          9      0.0% mping-thread
2323         0          1          3      0.0% mping-thread
...
vsg#

```

Displaying CPU and Memory Information

The **show system resources** command displays system-related CPU and memory statistics as follows:

- The load is defined as the number of running processes. The average reflects the system load over the past 1, 5, and 15 minutes.
- Processes display the number of processes in the system and how many processes are actually running when the command is issued.
- The CPU states show the CPU usage percentage in the user mode, kernel mode, and idle time in the last one second.
- The memory usage provides the total memory, used memory, free memory, memory used for buffers, and memory used for cache in kilobytes. Buffers and cache are also included in the used memory statistics.

This example shows the results of available system resources:

```

vsg# show system resources
Load average:  1 minute: 0.00   5 minutes: 0.00   15 minutes: 0.02
Processes   :  321 total, 1 running
CPU states  :  0.0% user,   0.0% kernel,  100.0% idle
Memory usage: 1944668K total, 1114044K used,  830624K free
              62340K buffers,  479040K cache
vsg#

```

Send document comments to vsg-docfeedback@cisco.com.

Syslog

The system message logging software saves messages in a log file or directs messages to other devices. This feature provides the following capabilities:

- Logging information for monitoring and troubleshooting.
- Selecting the types of logging information for capture.
- Selecting the destination of the captured logging information.

A syslog can store a chronological log of system messages locally or send the messages to a central syslog server. Syslog messages can also be sent to the console for immediate use. These messages can vary in detail depending on the configuration.

Syslog messages are categorized into seven severity levels from *debug* to *critical* events. Severity levels that are reported can be limited for specific services within the switch.

Log messages are not saved across system reboots. However, a maximum of 100 log messages with a severity level of critical and below (levels 0, 1, and 2) can be logged and saved to a local file or server.

This section includes the following topics:

- [Logging Levels, page 2-7](#)
- [Enabling Logging for Telnet or SSH, page 2-7](#)

Logging Levels

The Cisco VSG supports the following logging levels:

- 0—Emergency
- 1—Alert
- 2—Critical
- 3—Error
- 4—Warning
- 5—Notification
- 6—Informational
- 7—Debugging

By default, the switch logs normal but significant system messages to a log file and sends these messages to the system console. Users can specify which system messages are saved, based on the type of facility and the severity level. Messages are time stamped to enhance real-time debugging and management.

Enabling Logging for Telnet or SSH

System logging messages are sent to the console based on the default or configured logging facility and severity values.

Users can disable logging to the console or enable logging to a given Telnet or Secure Shell (SSH) session.

- To disable console logging, use the **no logging console** command in interface CONFIG mode.
- To enable logging for telnet or SSH, use the **terminal monitor** command in EXEC mode.

Send document comments to vsg-docfeedback@cisco.com.



Note

When logging to a console session is disabled or enabled, that state is applied to all future console sessions. If you exit and log in again to a new session, the state is preserved. When logging to a Telnet or SSH session is enabled or disabled, that state applies only to that session. The state is not preserved after you exit the session.

The **no logging console** command is enabled by default. Use this command to disable console logging.

```
vsg(config)# no logging console
```

The **terminal monitor** command is disabled by default. Use this command to enable logging for telnet or SSH:

```
vsg(config)# terminal monitor
```

For more information about configuring syslog, see the *Cisco Virtual Network Management Center GUI Configuration Guide*.

CLI Configuration

This section contains the following topics:

- [Event Log, page 2-8](#)
- [Configuration and Restrictions, page 2-9](#)

Event Log

This section describes event logs.

This section includes the following topics:

- [Event Log Configuration Format, page 2-8](#)
- [Viewing the Event Log Configuration, page 2-8](#)
- [Viewing Event Logs, page 2-9](#)
- [Event Log Configuration Persistence, page 2-9](#)

Event Log Configuration Format

The configuration is displayed using this format:

```
[no] event-log inspect {{error | info} | {{ftp {error | info | warn | pkt_trace}} | {rsh {error | info | pkt_trace}} | {tftp {error | info }}} [terminal]
```

Event logs can be configured for either the inspect process or one of its modules. For example, use the **event-log inspect error terminal** command to enable error events for the inspection process and to display these messages on the terminal where the CLI was executed.

Viewing the Event Log Configuration

You can display the event log configuration by using the **show event-log all** command. Use this command to display the event logs for all the processes and their modules.

Send document comments to vsg-docfeedback@cisco.com.

```
vsg# show event-log all
event-log inspect tftp error
event-log inspect rsh error
event-log inspect ftp error terminal
event-log policy_engine attr-mgr error
event-log service-path sp pkt-error terminal
vsg#W
```

Viewing Event Logs

Event logs are always logged in a process that is specific to the message buffer. Process logging in the event log buffer does not incur any overhead. In addition to using the **show event-log** command, you can display messages on a terminal where the event logs are enabled by using the terminal option which is useful for reproducing a certain behavior.

The **show** command shows all the processes that are integrated with the event log Cisco VSG infrastructure. You can display inspection event logs using the **show system internal event-log inspect** command. The Cisco VSG event log infrastructure is a layer on top of the Cisco NX-OS event log infrastructure. Event logs can be redirected to a file and exported.

To display event logs on the terminal, use the **terminal** option while configuring the event. Different terminals can view different event logs. For example, use the **event-log inspect ftp info terminal** command to enable the information event logs for the inspection ftp module and to display the logs on the terminal. Use the **event-log inspect rsh error terminal** command to display only the error logs that are related to the RSH module. This command helps to debug various modules at the same time.

Event Log Configuration Persistence

You can save the event log configuration by using the **event-log save config** command. This command allows you to save all of the currently enabled event logs in a file. This file is read at the time of the module/process initialization with the event log infrastructure. The event log configuration that is relevant to the process is reapplied during initialization, which makes the event log configuration persistent across the process/system reboot. Some important things about the event log configuration are as follows:

- Terminal information is not reapplied for process or system restarts because that information might not be applicable.
- The event log configuration is independent of the other Cisco NX-OS configurations. The **copy running-config startup-config** and **show running-config** commands do not save and display the event log configuration.
- The event log configuration is specific to the individual system. In a high-availability setup, the configuration must be set up on both systems.

Configuration and Restrictions

Event logs CLIs for the Cisco VSG are classified based on the process and its modules. This section contains a listing and description of various event log CLIs.

This section includes the following topics:

- [VNS Agent, page 2-10](#)
- [Inspection Process, page 2-11](#)
- [Service Path Process, page 2-12](#)

Send document comments to vsg-docfeedback@cisco.com.

- [Policy Engine Process, page 2-14](#)
- [Restrictions, page 2-14](#)

VNS Agent

Virtual Network Service (VNS) agent-related event logs are maintained on the Virtual Supervisor Module (VSM), not on the Cisco VSG.

This section includes the following topics:

- [Core Module, page 2-10](#)
- [VPath Module, page 2-10](#)
- [License Module, page 2-10](#)

Core Module

The core events are those events that are related to port attach, port detach, Internet Protocol Database (IPDB), and to port-profile CLI such as the vn-service and org.

This example shows the command syntax to enable/disable error messages for the vns_agent core module:

```
vsm# event-log vns-agent core-error [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent core-error [terminal] ----->disable messages to the terminal
```

This example shows the command syntax to enable/disable informational messages for the vns_agent core module:

```
vsm# event-log vns-agent core-info [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent core-info [terminal] ----->disable messages to the terminal
```

VPath Module

VPath module works based on core-module events. You should always enable core module event logs before you enable the VPath module events.

This example shows the command syntax to enable/disable error messages for the vns_agent VPath module:

```
vsm# event-log vns-agent vpath-error [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent vpath-error [terminal] ----->disable messages to the terminal
```

This example shows the command syntax to enable/disable informational messages for the vns_agent VPath module:

```
vsm# event-log vns-agent vpath-info [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent vpath-info [terminal] ----->disable messages to the terminal
```

License Module

The license module works based on core-module events. You should always enable the core module event logs before enabling the license module.

This example shows the command syntax to enable/disable error messages for the vns_agent license module:

Send document comments to vsg-docfeedback@cisco.com.

```
vsm# event-log vns-agent license-error [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent license-error [terminal] ----->disable messages to the
terminal
```

This example shows the command syntax to enable/disable informational messages for the vns_agent license module:

```
vsm# event-log vns-agent license-info [terminal] ----->enable messages to the terminal
vsm# no event-log vns-agent license-info [terminal] ----->disable messages to the terminal
```

Inspection Process

The inspection process uses event log CLI commands for the inspection process and File Transfer Protocol (FTP), Remote Shell (RSH) and Trivial File Transfer Protocol (TFTP) modules. These processes are all done on the Cisco VSG.

This command can display CLI configuration errors, process initialization errors, and so forth. This example shows the command syntax to enable/disable error messages for the inspection process:

```
vsg# event-log inspect error [terminal] ----->enable messages to the terminal
vsg# no event-log inspect error [terminal] ----->disable messages to the terminal
```

This example shows the command syntax to enable/disable informational messages for the inspection process:

```
vsg# event-log inspect info [terminal] ----->enable messages to the terminal
vsg# no event-log inspect info [terminal] ----->disable messages to the terminal
```

This command can display FTP packet processing errors. This example shows the command syntax to enable/disable error messages for the inspection FTP module:

```
vsg# event-log inspect ftp error [terminal] ----->enable messages to the terminal
vsg# no event-log inspect ftp error [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:12:14 2010 ie_ftp: flow (->(ING), 6912), Bad ftp command.

Mon Oct 4 15:12:14 2010 ie_ftp: flow (->(ING), 6912), invalid PORT request / PASV reply.
```

This example shows the command syntax to enable/disable informational event log messages for the inspection FTP module:

```
vsg# event-log inspect ftp info [terminal] ----->enable messages to the terminal
vsg# no event-log inspect ftp info [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:12:18 2010 ie_ftp: embryonic connection request (ip, port, proto, pfid, cid,
action, offload) = (192.168.1.20, 40074, tcp, 13569, 6912, 3,1).

Mon Oct 4 15:17:11 2010 ie_ftp: flow (<-(ING), 6912), more reply expected in cmd-reply.
```

This example shows the command syntax to for enable/disable warning messages for the inspection FTP module:

```
vsg# event-log inspect ftp warn [terminal] ----->enable messages to the terminal
vsg# no event-log inspect ftp warn [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:19:03 2010 ie_ftp: flow (<-(ING), 8192), ftp reply not terminated properly.
```

Send document comments to vsg-docfeedback@cisco.com.

This example shows the command syntax to enable/disable packet trace messages for the inspection FTP module:

```
vsg# event-log inspect ftp pkt_trace [terminal] ----->enable messages to the terminal
vsg# no event-log inspect ftp pkt_trace [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:31:46 2010 ie_ftp: flow (->(ING), 17152), flags(S:)
Mon Oct 4 15:31:54 2010 ie_ftp: flow (->(ING), 17152), cmd (USER)
```

This example shows the command syntax to enable/disable error messages for the inspection RSH module:

```
vsg# event-log inspect rsh error [terminal] ----->enable messages to the terminal
vsg# no event-log inspect rsh error [terminal] ----->disable messages to the terminal
```

This example shows the command syntax to enable/disable informational messages for the inspection RSH module:

```
vsg# event-log inspect rsh info [terminal] ----->enable messages to the terminal
vsg# no event-log inspect rsh info [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:21:29 2010 ie_rsh: emryonic connection request (ip, port, proto, pfid, cid,
action, offload) = (192.168.1.10, 1021, tcp, 22529, 11264, 3, 1).
```

This example shows the command syntax to enable/disable packet trace messages for the inspection RSH module:

```
vsg# event-log inspect rsh pkt_trace [terminal] ----->enable messages to the terminal
vsg# no event-log inspect rsh pkt_trace [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:25:26 2010 ie_rsh: flow (->(ING), 15872), rsh inspect action stop punt
```

This example shows the command syntax to enable/disable error messages for the inspection TFTP module:

```
vsg# event-log inspect tftp error [terminal] ----->enable messages to the terminal
vsg# no event-log inspect tftp error [terminal] ----->disable messages to the terminal
```

This example shows how to enable/disable informational messages for the inspection TFTP module:

```
vsg# event-log inspect tftp info [terminal] ----->enable messages to the terminal
vsg# no event-log inspect tftp info [terminal] ----->disable messages to the terminal
```

The command response is:

```
Mon Oct 4 15:27:42 2010 ie_tftp: emryonic connection request (ip, port, proto, pfid, cid,
action, offload) = (192.168.1.10, 32771, udp, 33281, 16640, 3, 1)
```

Service Path Process

These processes are all done on the Cisco VSG.

This section includes the following topics:

- [Service Path Module, page 2-13](#)
- [Service Path Flow Manager, page 2-13](#)

Send document comments to vsg-docfeedback@cisco.com.

- [AC Module, page 2-13](#)

The service path process exposes event log CLIs for the VSN service path, flow manager, AC infrastructure modules.

Service Path Module

This command can display a failure to initialize the FE, and so forth. This example shows the command syntax to enable/disable error messages for the service path module:

```
vsg# event-log service-path sp error [terminal] ----->enable messages to the terminal
vsg# no event-log service-path sp error [terminal] ----->disable messages to the terminal
```

This command can display FE initialization messages, control path messages, and so forth. This example shows the command syntax to enable/disable informational messages for the service path module:

```
vsg# event-log service-path sp info [terminal] ----->enable messages to the terminal
vsg# no event-log service-path sp info [terminal] ----->disable messages to the terminal
```

This command can display failure to read or write a packet, a corrupted packet, and so forth. This example shows the command syntax to enable/disable packet error messages for the service path module:

```
vsg# event-log service-path sp pkt-error [terminal] ----->enable messages to the terminal
vsg# no event-log service-path sp pkt-error [terminal] ----->disable messages to the terminal
```

This command can display the field description of a packet, where the packet arrived from or going to, decisions taken on the packet, and so forth. This example shows the command syntax to enable/disable packet informational messages for the service path module:

```
vsg# event-log service-path sp pkt-info [terminal] ----->enable messages to the terminal
vsg# no event-log service-path sp pkt-info [terminal] ----->disable messages to the terminal
```

This command can display the first few 100 bytes of the incoming packets. This example shows the command syntax to enable/disable detailed packet messages for the service path module:

```
vsg# event-log service-path sp pkt-detail [terminal] ----->enable messages to the terminal
vsg# no event-log service-path sp pkt-detail [terminal] ----->disable messages to the terminal
```

Service Path Flow Manager

This example shows the command syntax to enable/disable the packet messages for the service path flow manager module:

```
vsg# event-log service-path fm error [terminal] ----->enable messages to the terminal
vsg# no event-log service-path fm error [terminal] ----->disable messages to the terminal
```

AC Module

This command can display failure to initialize the AC, timer, fd, pending queue, and so forth. This example shows the command syntax to enable/disable error messages for the AC module:

```
vsg# event-log service-path ac error [terminal] ----->enable messages to the terminal
vsg# no event-log service-path ac error [terminal] ----->disable messages to the terminal
```

This command can display AC initialization messages, control path messages, and so forth. This example shows the command syntax to enable/disable informational messages for the AC module:

Send document comments to vsg-docfeedback@cisco.com.

```
event-log service-path ac info [terminal] ----->enable messages to the terminal
no event-log service-path ac info [terminal] ----->disable messages to the terminal
```

Policy Engine Process

These processes are all done on the Cisco VSG.

This section contains the following topic:

- [Attribute Manager Module, page 2-14](#)

Attribute Manager Module

This section describes the attribute manager-related errors. This command can display the policy ID for PE evaluation lookup based on the VNSP ID, IP address, zone name resolution, attribute fetched, and so forth.

This example shows the command syntax to enable/disable error messages for the attribute manager module:

```
vsg# event-log policy-engine attr-mgr error [terminal] ----->enable messages to the
terminal
vsg# no event-log policy-engine attr-mgr error [terminal] ----->disable messages to the
terminal
```

This example shows the command syntax to enable/disable informational messages for the attribute manager module:

```
vsg# event-log policy-engine attr-mgr info [terminal] ----->enable messages to the
terminal
vsg# no event-log policy-engine attr-mgr info [terminal] ----->disable messages to the
terminal
```

Restrictions

The following restrictions for event log configuration:

- Terminal information is not reapplied in case of process restart/ system restart since it may or may not be applicable.
- Event log configuration is independent of the other NX-OS configurations. The NX-OS CLI commands **copy running-config startup-config** and **show running-config** will not save and display event log configuration.
- Event log configuration is specific to the individual system. In the HA setup, this configuration must be done on both of the systems.

Show Commands

This section includes the following topics:

- [VSM Show Commands, page 2-15](#)
- [Cisco VSG show Commands, page 2-20](#)

Send document comments to vsg-docfeedback@cisco.com.

VSM Show Commands

This section includes the following topics:

- [show vnm-pa status](#), page 2-15
- [show vsn brief](#), page 2-15
- [show vsn detail \[port\] \[vlan vlan-num ip ip-addr\] \[module module-num\]](#), page 2-16
- [show vsn port \[vethernet veth-num\]](#), page 2-16
- [show vsn connection](#), page 2-17
- [show vsn statistics \[vlan vlan-num ip ip-addr\] \[module module-num\]](#), page 2-17
- [clear vsn statistics \[vlan vlan-num ip ip-addr\] \[module module-num\]](#), page 2-19

show vnm-pa status

The **show vnm-pa status** command displays the status.

This example shows the output for the command:

```
vsm2# show vnm-pa status
VNM Policy-Agent status is - Installed Successfully. Version 1.0(1j)-vsm
vsm2#
```

show vsn brief

The **show vsn brief** command provides a brief consolidated display of all VSNs in use.

This example shows the output for the command:

```
vsm2# show vsn brief
VLAN          IP-ADDR          MAC-ADDR  FAIL-MODE  STATE  MODULE
  78          10.0.0.1    00:50:56:9c:04:28    Close    Up    3
vsm2#
```

FAIL-MODE specifies the behavior when the Virtual Ethernet Module (VEM) has no connectivity to the Cisco VSG. The default is **Close** (packets are dropped). **Open** means packets are forwarded.

The MAC-ADDR column lists the MAC address of the data0 interface that corresponds to that Cisco VSG (if the VEM can resolve it). If the VEM does not resolve the MAC address, it cannot redirect packets to the VSG. If a valid MAC address is not shown, check if the Cisco VSG data0 is reachable from the VEM. If there is no valid MAC-ADDR, these are possible reasons:

- The data0 interface on the Cisco VSG is not configured
- The VLAN is not up
- Mismatch in the Virtual Local Area Network (VLAN) specified in the **vn-service** command and the port-profile used for the Cisco VSG VM.

STATE can be Up, Down or No Licenses. If Down, the MAC-ADDR is not resolved or the module is not up. If multiple VEM modules inherit the same VM port profile, those interfaces must pass all checks before the state can be Up. If No Licenses appears, install the Cisco VSG license on the VSM.

The MODULE column lists the VEM numbers whose interfaces have inherited this configuration.

Send document comments to vsg-docfeedback@cisco.com.

show vsn detail [port] [vlan *vlan-num* ip *ip-addr*] [module *module-num*]

This **show vsn detail** command provides detailed information of all VSNs in use. Information is displayed for each of the associated VEM modules. It displays port profile, security profile, organization and list of Cisco Nexus 1000V ports that have inherited this configuration. Also displayed are any configuration mismatches between the VSM and VEM missing ports for a given port profile, all ports of a port-profile not configured with same security profile, and so forth.

This example shows the output for the command:

```
vsm# show vsn detail
#VSN VLAN: 756, IP-ADDR: 200.1.1.67
  MODULE      VSN-MAC-ADDR  FAIL-MODE  VSN-STATE
    3  00:50:56:83:03:1c  Close      Up
    4  00:50:56:83:03:1c  Close      Up

#VSN Ports, Port-Profile, Org and Security-Profile Association:
#VSN VLAN: 756, IP-ADDR: 200.1.1.67
  Port-Profile: profile-data, Security-Profile: sec-profile-stress1, Org:
  root/Tenant-Stress1
    Module  Vethernet
      3  9, 7, 8
      4  5, 6
vsm#
```

The Vethernet column shows the veth interfaces bound to the appropriate VEM listed in the Module column and that they inherit the correct port profile.

Possible red flags include notations (* or ??) against the security-profile or organization (the Org column).

show vsn port [vethernet *veth-num*]

The **show vsn port** command provides information for each Vethernet interface. By default, all attached vEths are listed. Use the vethernet option for output of a specific vEth interface.

This example shows the output for the command:

```
vsm2# show vsn port
Veth      : Veth4
VM Name   : win2k3
VM uuid   : 42 1c 5a e4 51 c3 5d d9-60 fa a5 0c b0 4e d0 ea
DV Port   : 576
DVS uuid  : bc aa 1c 50 87 47 8d 08-fe 7e a9 aa 89 24 bf 8e
Flags     : 0x48
VSN Data IP : 10.0.0.1
Security Profile : spcustom
Org       : orgroot
VNSP id   : 1
IP addresses:
  100.1.1.20
vsm2#
```

- Any field with a value of Not set—An improper port configuration.
- VM Name value—Make sure VM name matches name of the VM associated with this vNIC.
- VSN Data IP, Security Profile, and Org values—Ensure correct right values for this VM are displayed.
- VNSP ID—Should never be zero.

Send document comments to vsg-docfeedback@cisco.com.

IP Addresses—Ensure the list of IP addresses matches the IP addresses configured that are on that vNIC for that VM. If not, use the **vemcmd show learnt** command on all VEM modules to display the Internet Protocol Database (IPDB) table.

show vsn connection

The **show vsn connection** command displays VSN connections.

This example shows the output for the command:

```
scale# show vsn connection vlan 753 ip 30.1.248.12 module 10
#VSN VLAN: 753, IP-ADDR: 30.1.248.12
Module: 10
tcp vlan 760 src 100.1.31.104:52597 dst 100.1.31.3:80
tcp vlan 760 src 100.1.31.104:43108 dst 100.1.31.2:80
tcp vlan 760 src 100.1.31.104:52557 dst 100.1.31.3:80
tcp vlan 760 src 100.1.31.104:42828 dst 100.1.31.2:80
tcp vlan 760 src 100.1.31.109:4419 dst 100.1.31.103:80
tcp vlan 760 src 100.1.31.104:50486 dst 100.1.31.5:80
scale#
```

show vsn statistics [vlan *vlan-num* ip *ip-addr*] [module *module-num*]

The **show vsn statistics** command displays VSN statistics.

This example shows the output for the command:

```
vsm# show vsn statistics
#VSN VLAN: 756, IP-ADDR: 200.1.1.67
Module: 3
#VPath Packet Statistics
Total Seen                Ingress      Egress       Total
Policy Redirects          0            120681       120681
No-Policy Passthru        14830        14835        29665
Policy-Permits Rcvd       0            120681       120681
Policy-Denies Rcvd        0            0            0
Permit Hits                366465       487146       853611
Deny Hits                 0            0            0
Decapsulated              0            120681       120681
Fail-Open                 0            0            0
Badport Err               0            0            0
VSN Config Err            0            0            0
ARP Resolve Err           0            0            0
Encap Err                 0            0            0
All-Drops                 0            0            0
Total Rcvd From VSN      120681
Non-Cisco Encap Rcvd      0
VNS-Port Drops            0
Policy-Action Err         0
Decap Err                 0
L2-Frag Sent              0
L2-Frag Rcvd              0
L2-Frag Coalesced         0

#VPath Flow Statistics
Active Flows               0   Active Connections      0
Forward Flow Create       120681   Forward Flow Destroy     120681
Reverse Flow Create       120681   Reverse Flow Destroy     120681
Flow ID Alloc             241362   Flow ID Free              241362
Connection ID Alloc       120681   Connection ID Free        120681
L2 Flow Create            0   L2 Flow Destroy           0
```

Send document comments to vsg-docfeedback@cisco.com.

```

L3 Flow Create                0 L3 Flow Destroy                0
L4 TCP Flow Create            241362 L4 TCP Flow Destroy            241362
L4 UDP Flow Create            0 L4 UDP Flow Destroy            0
L4 Oth Flow Create            0 L4 Oth Flow Destroy            0
Embryonic Flow Create         0 Embryonic Flow Bloom          0
L2 Flow Timeout               0 L2 Flow Offload                0
L3 Flow Timeout               0 L3 Flow Offload                0
L4 TCP Flow Timeout           249934 L4 TCP Flow Offload           120681
L4 UDP Flow Timeout           0 L4 UDP Flow Offload            0
L4 Oth Flow Timeout           0 L4 Oth Flow Offload            0
Flow Lookup Hit               853611 Flow Lookup Miss               241362
Flow Dual Lookup              998732 L4 TCP Tuple-reuse            0
Flow Classify Err             0 Flow ID Alloc Err              0
Conn ID Alloc Err             0 Hash Alloc Err                 0
Flow Exist                    0 Flow Entry Exhaust            0
Flow Removal Err              0 Bad Flow ID Receive            0
Flow Entry Miss               0 Flow Full Match Err           0
Bad Action Receive            0 Invalid Flow Pair              0
Invalid Connection            0
Hash Alloc                    0 Hash Free                      0
InvalFID Lookup               0 InvalFID Lookup Err           0
Deferred Delete                0

Module: 4
#VPath Packet Statistics      Ingress      Egress      Total
Total Seen                    9886         9890        19776
Policy Redirects              0             0            0
No-Policy Passthru           9886         9890        19776
Policy-Permits Rcvd          0             0            0
Policy-Denies Rcvd           0             0            0
Permit Hits                   0             0            0
Deny Hits                    0             0            0
Decapsulated                  0             0            0
Fail-Open                     0             0            0
Badport Err                   0             0            0
VSN Config Err               0             0            0
ARP Resolve Err              0             0            0
Encap Err                     0             0            0
All-Drops                     0             0            0
Total Rcvd From VSN          0
Non-Cisco Encap Rcvd         0
VNS-Port Drops               0
Policy-Action Err            0
Decap Err                     0
L2-Frag Sent                  0
L2-Frag Rcvd                  0
L2-Frag Coalesced            0

#VPath Flow Statistics
Active Flows                   0 Active Connections             0
Forward Flow Create            0 Forward Flow Destroy           0
Reverse Flow Create            0 Reverse Flow Destroy           0
Flow ID Alloc                  0 Flow ID Free                    0
Connection ID Alloc            0 Connection ID Free              0
L2 Flow Create                 0 L2 Flow Destroy                 0
L3 Flow Create                 0 L3 Flow Destroy                 0
L4 TCP Flow Create             0 L4 TCP Flow Destroy             0
L4 UDP Flow Create             0 L4 UDP Flow Destroy             0
L4 Oth Flow Create             0 L4 Oth Flow Destroy             0
Embryonic Flow Create         0 Embryonic Flow Bloom           0
L2 Flow Timeout                0 L2 Flow Offload                 0
L3 Flow Timeout                0 L3 Flow Offload                 0
L4 TCP Flow Timeout            0 L4 TCP Flow Offload             0
L4 UDP Flow Timeout            0 L4 UDP Flow Offload             0
L4 Oth Flow Timeout            0 L4 Oth Flow Offload             0

```

Send document comments to vsg-docfeedback@cisco.com.

```

Flow Lookup Hit                0 Flow Lookup Miss                0
Flow Dual Lookup               0 L4 TCP Tuple-reuse              0
Flow Classify Err              0 Flow ID Alloc Err               0
Conn ID Alloc Err              0 Hash Alloc Err                  0
Flow Exist                     0 Flow Entry Exhaust              0
Flow Removal Err               0 Bad Flow ID Receive             0
Flow Entry Miss                0 Flow Full Match Err             0
Bad Action Receive             0 Invalid Flow Pair               0
Invalid Connection              0
Hash Alloc                     0 Hash Free                       0
InvalFID Lookup                0 InvalFID Lookup Err             0
Deferred Delete                 0
vsm#

```

clear vsn statistics [vlan *vlan-num* ip *ip-addr*] [module *module-num*]

The **clear vsn statistics** command clears VSN statistics.

This example shows the output for the command:

```

vsm# clear vsn statistics vlan 756 ip 200.1.1.67 module 3
Cleared statistics successfully for specified VSN in module 3
vsm-fcs# show vsn statistics vlan 756 ip 200.1.1.67 module 3
#VSN VLAN: 756, IP-ADDR: 200.1.1.67
Module: 3
#VPath Packet Statistics      Ingress      Egress      Total
Total Seen                   0             0            0
Policy Redirects              0             0            0
No-Policy Passthru            0             0            0
Policy-Permits Rcvd           0             0            0
Policy-Denies Rcvd            0             0            0
Permit Hits                   0             0            0
Deny Hits                     0             0            0
Decapsulated                  0             0            0
Fail-Open                     0             0            0
Badport Err                   0             0            0
VSN Config Err                0             0            0
ARP Resolve Err               0             0            0
Encap Err                     0             0            0
All-Drops                     0             0            0
Total Rcvd From VSN           0             0            0
Non-Cisco Encap Rcvd          0
VNS-Port Drops                0
Policy-Action Err              0
Decap Err                      0
L2-Frag Sent                   0
L2-Frag Rcvd                   0
L2-Frag Coalesced              0

#VPath Flow Statistics
Active Flows                   0 Active Connections              0
Forward Flow Create            0 Forward Flow Destroy            0
Reverse Flow Create            0 Reverse Flow Destroy            0
Flow ID Alloc                  0 Flow ID Free                     0
Connection ID Alloc            0 Connection ID Free              0
L2 Flow Create                 0 L2 Flow Destroy                  0
L3 Flow Create                 0 L3 Flow Destroy                  0
L4 TCP Flow Create             0 L4 TCP Flow Destroy              0
L4 UDP Flow Create             0 L4 UDP Flow Destroy              0
L4 Oth Flow Create             0 L4 Oth Flow Destroy              0
Embryonic Flow Create          0 Embryonic Flow Bloom             0
L2 Flow Timeout                0 L2 Flow Offload                  0
L3 Flow Timeout                0 L3 Flow Offload                  0

```

Send document comments to vsg-docfeedback@cisco.com.

```

L4 TCP Flow Timeout          0 L4 TCP Flow Offload          0
L4 UDP Flow Timeout          0 L4 UDP Flow Offload          0
L4 Oth Flow Timeout          0 L4 Oth Flow Offload          0
Flow Lookup Hit              0 Flow Lookup Miss             0
Flow Dual Lookup             0 L4 TCP Tuple-reuse           0
Flow Classify Err            0 Flow ID Alloc Err            0
Conn ID Alloc Err            0 Hash Alloc Err               0
Flow Exist                   0 Flow Entry Exhaust           0
Flow Removal Err             0 Bad Flow ID Receive          0
Flow Entry Miss              0 Flow Full Match Err          0
Bad Action Receive           0 Invalid Flow Pair            0
Invalid Connection           0
Hash Alloc                   0 Hash Free                     0
InvalFID Lookup              0 InvalFID Lookup Err          0
Deferred Delete              0
vsm#

```

Cisco VSG show Commands

The attribute manager maintains a set of tables and does a lookup that is based on the fields in the packet. There are three main tables: DV port table, VM table, and VNSP table. Use the **show vsg dvport** command to display runtime information for the DV port table. For the other two tables, use the **show vsg vm** and **show vsg vnsp** commands.

Hash tables are maintained based on IP addresses (IP address to DV port entry) and VNSP ID (VNSP ID to VNSP entry). An IP address is used when fetching attributes (custom and VM attributes) that are based on the source or destination IP address. It is also used to determine which policy set to evaluate for a given traffic. The VNSP ID is used (valid VNSP ID in the packet header) to determine which policy set to evaluate. Custom attributes can also be fetched.

This section includes the following topics:

- [show vnm-pa status, page 2-21](#)
- [show service-path statistics, page 2-21](#)
- [clear service-path statistics, page 2-22](#)
- [show service-path connection, page 2-22](#)
- [clear service-path connection, page 2-23](#)
- [show vsg ip-binding, page 2-23](#)
- [show vsg dvport {dvport id}, page 2-23](#)
- [show vsg vm {vm uuid}, page 2-24](#)
- [show vsg security-profile {vnsp-name | brief}, page 2-25](#)
- [show policy-engine stats, page 2-26](#)
- [clear policy-engine, page 2-27](#)
- [show ac-driver statistics, page 2-27](#)
- [clear ac-driver statistics, page 2-27](#)
- [show system internal ac ipc-stats fe \[process-name\], page 2-28](#)
- [clear system internal ac ipc-stats fe \[process-name\], page 2-28](#)
- [show inspect ftp statistics, page 2-29](#)
- [clear inspect ftp statistics, page 2-29](#)

Send document comments to vsg-docfeedback@cisco.com.

show vnm-pa status

The **show vnm-pa status** command displays the status.

This example shows the output for the command:

```
vsg# show vnm-pa status
VNM Policy-Agent status is - Installed Successfully. Version 1.0(1j)-vsg
vsg#
```

show service-path statistics

This command shows following statistics pertaining to one vPath:

- The packets seen by service path from the vPath.
- Flows created by service path due to these packets.
- Packets dropped in service path due to various errors.



Note

If no module is given, the command displays the aggregate statistics of all the modules in the given SVS domain.

This command provides the following filters and it can be used in various combinations:

- **svs-domain-id** *domain-id*—Displays only the Cisco VSG connections associated to the *svs-domain* specified in the *domain-id*.
- **module** *module-num*—Displays only the Cisco VSG connections associated to the *svs-domain* and VEM module specified in the *domain-id* and the *module-num*. Use this only with the **svs-domain-id** filter.

This example shows the output for the command:

```
vsg# show service-path statistics svs-domain-id 118 module 5
Input Packet          161359233  Output Packet          161359220
Vpath Ingress Packet  7608059   Vpath Egress Packet   153751174
Vpath Frag            0         VSN Offload Packet    0
ARP Packet            0         Unknown L2 Packet     0
802.3 Packet          0         Vpath Jumbo Frame     0
IPV4 Packet           161359233  IPV4 options Packet   0
IPV4 Frag             0         Unknown L3Proto Packet 0
ICMP Packet           66        IGMP Packet           0
TCP Packet            161359095  UDP Packet            72
Policy Lookup Packet  160669149  Inspect FTP Packet    0
Inspect RSH Packet    0         Inspect TFTP Packet   0
Policy Lookup Fail    0         Policy Lookup Drop    0
Inspect FTP Fail      0         Inspect FTP Drop      0
Inspect RSH Fail      0         Inspect RSH Drop      0
Inspect TFTP Fail     0         Inspect TFTP Drop     0
Malformed Packet      0         Output Fail           0
Active Flows          473278    Active Connections    379521
Forward Flow Create   8690219   Forward Flow Destroy  3008524
Reverse Flow Create   3362016   Reverse Flow Destroy  8570433
Flow ID Alloc         12052235  Flow ID Free          11578957
Connection ID Alloc   3362016   Connection ID Free    2982495
L2 Flow Create        0         L2 Flow Destroy       0
L3 Flow Create        66        L3 Flow Destroy       66
L4 TCP Flow Create    12052097  L4 TCP Flow Destroy   11578819
L4 UDP Flow Create    72        L4 UDP Flow Destroy   72
L4 Other Flow Create  0         L4 Other Flow Destroy 0
Embryonic Flow Create 0         Embryonic Flow Bloom  0
```

Send document comments to vsg-docfeedback@cisco.com.

```

L2 Flow Timeout                0 L2 Flow Offload                0
L3 Flow Timeout                99 L3 Flow Offload                66
L4 TCP Flow Timeout           25158984 L4 TCP Flow Offload          160668998
L4 UDP Flow Timeout           108 L4 UDP Flow Offload           72
L4 Other Flow Timeout          0 L4 Other Flow Offload         0
Flow Lookup Hit               157997217 Flow Lookup Miss             12052235
Flow Dual Lookup              138932556 L4 TCP Tuple-reuse           151978861
Flow Classify Err              0 Flow ID Alloc Err            0
Conn ID Alloc Err              0 Hash Alloc Err                0
Flow Exist                     0 Flow Entry Exhaust           0
Flow Removal Err               0 Bad Flow ID receive          0
Flow Entry Missing             0 Flow Full Match Err          0
Bad Action Received            0 Invalid Flow Pair            0
Invalid Connection             0
vsg#

```

clear service-path statistics

This command clears the service path statistics globally when no option is given. When the svcs domain id and the module are provided, the command clears the statistics of the specified module.

This command provides the following filters and it can be used in various combinations:

- **svcs-domain-id** *domain-id*—Displays only the Cisco VSG connections associated to the svcs-domain specified in the *domain-id*.
- **module** *module-num*—Displays only the Cisco VSG connections associated to the svcs-domain and VEM module specified in the *domain-id* and the *module-num*. Use this only with the **svcs-domain-id** filter.

This example shows the output for the command:

```

vsg# clear service-path statistics
vsg#

```

show service-path connection

This command shows the connections (flow-table) maintained in the Cisco VSG. These connections are provided per VEM module per svcs-domain.

This command provides the following filters and it can be used in various combinations:

- **svcs-domain-id** *domain-id*—Displays only the Cisco VSG connections associated to the svcs-domain specified in the *domain-id*.
- **module** *module-num*—Displays only VSG connections associated to the svcs-domain and VEM module specified in the *domain-id* and the *module-num*. Use this only with the **svcs-domain-id** filter.

This example shows the output for the command:

```

vsg# show service-path connection
SVS Domain 41 Module 3
udp vlan 53 src 100.1.1.90:138 dst 100.255.255.255:138
tcp vlan 53 src 100.1.1.70:33050 dst 100.1.1.80:80
tcp vlan 53 src 100.1.1.70:33068 dst 100.1.1.80:80
tcp vlan 53 src 100.1.1.80:33041 dst 100.1.1.70:80
tcp vlan 53 src 100.1.1.71:33028 dst 100.1.1.80:80
tcp vlan 53 src 100.1.1.72:33056 dst 100.1.1.80:80
tcp vlan 53 src 100.1.1.73:33023 dst 100.1.1.80:80
vsg#

```

Send document comments to vsg-docfeedback@cisco.com.

clear service-path connection

This command clears connections (flow-table) maintained in the Cisco VSG.

This example shows the output for the command:

```
vsg# clear service-path connection
vsg#
```

show vsg ip-binding

This command displays a list of VM IP addresses and associated Virtual Network Service Profiles (VNSPs) with the associated policy set. This information helps to troubleshoot data path issues. The attribute manager determines which policy set to evaluate for a given packet (source IP address is the key for the lookup).

When debugging issues (for example, the wrong policy set or no policy), use this command to ensure that IP bindings (IP address to VNSP association) are correct. This association can also affect VNSP and VM attributes fetched by the attribute manager.

This example shows the output for the command:

```
vsn# show vsg-ip-binding
-----
VM IP address      Security-Profile Name      Policy Name
-----
100.1.246.6       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.5       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.4       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.3       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.2       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.1       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.10      sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.9       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.8       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
100.1.246.7       sec-profile-one@root/Tenant-one  policysset-one@root/Tenant-one
vsn#
```

show vsg dvport {dvport id}

This command displays relevant information for a DV port. A DV port is a logical representation of a vNIC. By default, this displays information for all DV ports. Specify a particular DV port with the <dvport id> parameter.

This example shows the output for the command:

```
vsn# show vsg dvport dv port          : 576:bcaa1c50-8747-8d08-fe7e-a9aa8924bf8e Security
Profile : spcustom
VM uuid      : 421c5ae4-51c3-5dd9-60fa-a50cb04ed0ea Port Profile : vm_data IP
Addresses :
    100.1.1.20
    100.1.1.10
vsn#
```

Send document comments to vsg-docfeedback@cisco.com.

show vsg vm {vm uuid}

This command displays relevant information for a VM. The attribute manager looks up the VM attributes for a particular VM based on this association before doing a policy evaluation. By default, VM information is displayed for all VMs that are known to this Cisco VSG. You can display a particular VM using the *vm uuid* argument.

When debugging issues, such as the wrong VM attributes are fetched, check the output of this show command as well as the IP address to DV port mapping.

This example shows the output for the command:

```
firewall-1# show vsg vm
VM uuid      : 42031129-65af-976b-5c5c-509966ffdede
VM attributes :
  name       : gentoo-246-2
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
  tools-status : not-installed
  host-name  : 10.193.77.246
  cluster-name :

VM uuid      : 4203326d-91d1-2fba-838a-3a551e5bcce1
VM attributes :
  name       : gentoo-246-8
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
  tools-status : not-installed
  host-name  : 10.193.77.246
  cluster-name :

VM uuid      : 420392dd-1146-f8eb-f0cb-363fb999a02d
VM attributes :
  name       : gentoo-246-10
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
  tools-status : not-installed
  host-name  : 10.193.77.246
  cluster-name :

VM uuid      : 42036819-f763-342a-8833-c24f9c55261f
VM attributes :
  name       : gentoo-246-4
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
  tools-status : not-installed
  host-name  : 10.193.77.246
  cluster-name :

VM uuid      : 420374a0-a81d-fe72-1dd8-f7b4ece9194c
VM attributes :
  name       : gentoo-246-5
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
  tools-status : not-installed
  host-name  : 10.193.77.246
  cluster-name :

VM uuid      : 4203625c-d9d0-1dde-228e-a2aaa97ad7c2
VM attributes :
  name       : gentoo-246-1
  vapp-name  :
  os-fullname : other 2.6x linux (64-bit)
```


Send document comments to vsg-docfeedback@cisco.com.

```

tools-status          : not-installed
host-name             : 10.193.77.246
cluster-name         :

VM uuid               : 42034686-db79-478a-920f-2dd2cce07151
VM attributes :
  name                 : gentoo-246-7
  vapp-name            :
  os-fullname          : other 2.6x linux (64-bit)
  tools-status         : not-installed
  host-name            : 10.193.77.246
  cluster-name         :

VM uuid               : 4203ac4a-a7f6-3320-436d-29a49c1c73e8
VM attributes :
  name                 : gentoo-246-9
  vapp-name            :
  os-fullname          : other 2.6x linux (64-bit)
  tools-status         : not-installed
  host-name            : 10.193.77.246
  cluster-name         :

VM uuid               : 42033483-18b1-a89f-2f24-ae142365f061
VM attributes :
  name                 : gentoo-246-6
  vapp-name            :
  os-fullname          : other 2.6x linux (64-bit)
  tools-status         : not-installed
  host-name            : 10.193.77.246
  cluster-name         :

VM uuid               : 420360fb-cfcc-21f0-b3dd-f3650ff37a6d
VM attributes :
  name                 : gentoo-246-3
  vapp-name            :
  os-fullname          : other 2.6x linux (64-bit)
  tools-status         : not-installed
  host-name            : 10.193.77.246
  cluster-name         :
firewall-1#

```

show vsg security-profile {vnspp-name | brief}

This command displays information for a specific VNISP or all VNISPs. The attribute manager looks up custom attributes for a particular VNISP that is based on this association before doing a policy evaluation. By default, information is displayed for all VNISPs. You can specify a particular VNISP by using the *vnspp-name* argument.

When debugging issues, such as the wrong policy set, are evaluated, check if the right policy set is associated with the VNISP. If custom attribute values are not correct, this command displays some details.

This example shows the output for the command:

```

firewall-tenant-aa# show vsg security-profile
VNISP          : default@root
VNISP id       : 1
Policy Name    : default@root
Policy id      : 1
Custom attributes :
  vnsporg      : root

VNISP          : sec-profile-AA@root/Tenant-A/Data-Center-A

```

Send document comments to vsg-docfeedback@cisco.com.

```

VNSP id          : 31
Policy Name      : policyset-AA@root/Tenant-A/Data-Center-A
Policy id        : 2
Custom attributes :
  vnsporg        : root/tenant-a/data-center-a
  profile2       : mkt
  profile1       : eng

VNSP             : sec-profile-AB@root/Tenant-A/Data-Center-B
VNSP id          : 30
Policy Name      :
Policy id        : 0
Custom attributes :
  vnsporg        : root/tenant-a/data-center-b
  profile2       : mkt
  profile1       : eng

firewall-tenant-aa#

```

This command displays the associated VNSP ID and policy for all VNSPs. The attribute manager uses this association when looking up a VNSP, and associated policy, from the packet reaching the data0 interface of the Cisco VSG. When VPath redirects the packets to the Cisco VSG, the VNSP ID is added in the packet header.

This example shows the output for the command:

```

firewall-tenant-aa# show vsg security-profile brief
-----
Security-Profile Name      VNSP ID      Policy Name
-----
default@root              1            default@root
sec-profile-AB@root/Tenant-A/Data-Center-B 30
sec-profile-AA@root/Tenant-A/Data-Center-A 31
policyset-AA@root/Tenant-A/Data-Center-A
firewall-tenant-aa#

```

show policy-engine stats

This command displays statistics on the policy engine.

This example shows the output for the command:

```

firewall-1# show policy-engine stats

Policy Match Stats:

default@root          :          0
  default/default-rule@root :      0 (Drop)
  NOT_APPLICABLE       :      0 (Drop)

policyset-one@root/Tenant-one : 844935064
  policy-one/rule-z1@root/Tenant-one : 808288619 (Permit)
  policy-one/rule-one@root/Tenant-one : 36646445 (Permit)
  NOT_APPLICABLE       :              0 (Drop)

firewall-1#

```

This example shows the help (?) output for the command:

```

firewall-1# show policy-engine ?
WORD  Enter policy-name to show its stats
stats Show the Stats

```

Send document comments to vsg-docfeedback@cisco.com.

```
firewall-1# show policy-engine policysset-one@root/Tenant-one stats

Policy Match Stats:

policysset-one@root/Tenant-one      : 844935064
  policy-one/rule-z1@root/Tenant-one  : 808288619 (Permit)
  policy-one/rule-one@root/Tenant-one : 366464445 (Permit)
  NOT_APPLICABLE                      :           0 (Drop)
firewall-1#
```

clear policy-engine

This command clears the policy-engine statistics.

This example shows the output for the command:

```
firewall-1# clear policy-engine ?
WORD  Enter policy-name to clear its stats
stats Clear the Stats
```

When the **stats** argument is used, the statistics are cleared and the only response for a successful action is a return the prompt. This example shows the results:

```
firewall-1# clear policy-engine stats
firewall-1#
```

show ac-driver statistics

This command shows statistics collected in AC driver module. These statistics indicate how many packets are received, how many of those received are from vPath, how many are passed up to the service path, how many are passed as a response to the vPath and any error statistics, etc.

This example shows the output for the command:

```
firewall-1# show ac-driver statistics
#Packet Statistics:
Rcvd Total          852079858  Buffers in Use          3190
Rcvd VPath Pkts    848148272  Sent to VPath          846621771
Sent to Service-Path 848148272  Sent to Control-Path   3931586
All Drops          0  Invalid LLC            0
Invalid OUI        0  Invalid VNS Hdr       0
Invalid VNS PDU    1  Service-Path not Inited 0
Service-Path Down  0  Rcvd Bad Descriptor   0
Send to Service-Path Err 0  Packet Offset Err     0
Send Bad Descriptor 0  Send NIC Err          0
firewall-1#
```

clear ac-driver statistics

This command clears statistics collected in the AC driver module.

This example shows the output for the command:

```
vsg# clear ac-driver statistics
Cleared statistics successfully.
vsg#
```

Send document comments to vsg-docfeedback@cisco.com.

show system internal ac ipc-stats fe [*process-name*]

This command displays internal statistics of the following processes:

- attribute-manager
- inspection-ftp
- inspection-rsh
- inspection-tftp
- service-path

This example shows the output for the command using the inspection-ftp process:

```
firewall-1# show system internal ac ipc-stats fe inspection-ftp
=====
Instance:                1
IPC Type:                 MTS(SAP 1326)
  Async requests sent:   0
  Async responses received: 0
  Async requests received: 764364
  Async responses sent:  764364
  Sendto requests sent:  32485
  Sendto requests received: 32485
  Async send errors:     0
  Async receive errors:  0
  Async response errors: 0
  Sendto send errors:    0
  Sendto receive errors: 0
  Receive errors:       0
  Token errors :        0
  Destination not found errors: 0
  Sendto response errors: 0
  Timer Errors :        0
  Timouts :             0
  Recv Queue Len:       11
  Queue Length High:    0
  Reciever Busy Errors: 0
=====
firewall-1#
```

clear system internal ac ipc-stats fe [*process-name*]

This command clears the internal statistics for the following processes:

- attribute-manager
- inspection-ftp
- inspection-rsh
- inspection-tftp
- service-path

This example shows the output for the command using the inspection-ftp process:

```
firewall-1# clear system internal ac ipc-stats fe inspection-ftp
firewall-1#
```

Send document comments to vsg-docfeedback@cisco.com.

show inspect ftp statistics

This command shows the following inspect FTP statistics pertaining to one vPath:

- The packets seen by inspect FTP path from the vPath.
- Flows created by inspect FTP path due to these packets.
- Packets dropped in inspect FTP path due to various errors.

This example shows the output for the command:

```
firewall-1# show inspect ftp statistics
Input packets          764364
Dropped packets        0
Reset-drop packets    0
New connections        32485
Deleted connections    31064
IPC errors             0
IPC allocation errors  0

SVS Domain  131  Module  4
Input packets          764364
Dropped packets        0
Reset-drop packets    0
New connections        32485
Deleted connections    31064

firewall-1# show inspect ftp statistics svcs-domain-id 131 module 4
Input packets          764364
Dropped packets        0
Reset-drop packets    0
New connections        32485
Deleted connections    31064
Port zero drops        0
Invalid port drops     0
No port drops          0
Port command long drops 0
Rx port mismatch drops 0
Command not port command drops 0
Embryonic connections  32485
Embryonic connection failures 0
Memory allocations     64970
Memory de-allocations  63549
Memory allocation failures 0
Command in reply mode drops 0
Invalid command drops  0
Un-supported command drops 0
Command not terminated drops 0
Unexpected reply drops 0
Command too short drops 0
Reply code invalid drops 0
Reply length negative drops 0
Reply unexpected drops 0
Rx command in command mode drops 0

firewall-1#
```

clear inspect ftp statistics

This command clears the inspect FTP statistics globally when no option is given. When the svcs domain ID and the module are provided, the command clears the statistics of the specified module.

Send document comments to vsg-docfeedback@cisco.com.

This command provides the following filters and it can be used in various combinations:

- **svs-domain-id** *domain-id*—Displays only the Cisco VSG connections associated to the svcs-domain specified in the *domain-id*.
- **module** *module-num*—Displays only the Cisco VSG connections associated to the svcs-domain and VEM module specified in the *domain-id* and the *module-num*. Use this only with the **svs-domain-id** filter.

This example shows the output for the command:

```
firewall-1# clear inspect ftp statistics
firewall-1#
firewall-1# clear inspect ftp statistics svcs-domain-id 131 module 4
firewall-1#
```