



Configuring Firewall Profiles and Policy Objects

This chapter contains the following sections:

- [Information About Cisco VSG Firewall Policy Objects, page 1](#)
- [Configuring Service Firewall Logging, page 8](#)
- [Verifying the Cisco VSG Configuration, page 8](#)
- [Configuration Limits, page 9](#)

Information About Cisco VSG Firewall Policy Objects

This section describes how you can use the Cisco Prime Network Services Controller (Prime NSC) to configure and manage the firewall policy objects on the Cisco VSG.



Note

When the policy-agent (PA) is installed, the command-line interface (CLI) is unavailable for configuring policy-related objects on the Cisco VSG. When the PA is uninstalled (removed), you can again configure the policies (and policy objects) from the CLI; however, we recommend that you use the Cisco Prime NSC to configure and manage the Cisco VSG firewall policy objects

Cisco VSG Policy Object Configuration Prerequisites

Cisco VSG policy objects have the following prerequisites:

- Create port profiles for the service and HA interfaces of Cisco VSG on the Virtual Supervisor Module (VSM).
- You have the Cisco VSG software installed and the basic installation completed. For details, see the *Cisco VSG for Microsoft Hyper-V and Cisco Prime NSC Installation Guide*.
- The data IP address and management IP addresses must be configured. To configure the data IP address, see the *Cisco VSG for Microsoft Hyper-V and Cisco Prime NSC Installation Guide*.
- You have the attribute details required for your security policies.

- You are logged in to the Cisco VSG CLI in EXEC mode.

Cisco VSG Configuration Guidelines and Limitations

The Cisco VSG policy objects and firewall policies have the following configuration guidelines and limitations:

- The Management VLAN must be on the VM network Microsoft virtual Switch.
- Do not configure the same network IP address on the management and data interfaces (data0) of the Cisco VSG.

For any configuration and management tasks, the following requirements must be met:

- The Cisco VSG software must be operating with three network adapters. The network labels are as follows:
 - Service (Eth0) as the port-profile
 - Mgmt (Eth1) as the management VLAN
 - HA (Eth2) as the port-profile
- You have the Cisco VSG VM powered on and the data interface IP address (for data0) and management interface IP address configured.

See the *Cisco VSG for Microsoft Hyper-V and Cisco Prime NSC Installation Guide*, for details about assigning network labels to the network adapters.

Default Settings

Table 1: Default Parameter Settings for Cisco VSG

Parameters	Default
rule policy object	drop

Policies

A policy enforces network traffic on a Cisco VSG. A key component operating on the Cisco VSG is the policy engine. The policy engine takes the policy as a configuration and executes it when enforced against the network traffic that is received on the Cisco VSG. A policy is constructed by using the following set of policy objects:

- Rules
- Conditions
- Actions
- Objects groups

- Zones

A policy is bound to a Cisco VSG by using a set of indirect associations. The security administrator can configure a security profile and then refer to a policy name within the security profile. The security profile is associated with a port profile that has a reference to a Cisco VSG.

Policy Examples

This example shows how the policy is expressed in the **show running-config** command output:

```
vsg# show running-config policy p2@root/T1
policy p2@root/T1
  rule r2 order 10
```

This example shows how conditions are expressed in the **show running-config** command output:

```
condition 1 dst.net.ip-address eq 2.2.2.2
condition 2 src.net.ip-address eq 1.1.1.1
```

This example shows how an action is expressed in the **show running-config** command output:

```
action permit
```

Cisco Virtual Security Gateway Attributes

This section describes Cisco VSG attributes.

Attribute Name Notations

Directional Attributes

A firewall policy is direction sensitive with regard to incoming or outgoing packets. An attribute in a rule condition requires that you have specified if the attribute is relevant to a source or a destination. The prefixes `src.`, `dst.`, or an attribute name are used to provide the sense of direction.

Neutral Attributes

Because object groups and zones can be shared between various rules with different directions, the attributes used in a zone should not have a directional sense. Attributes without a directional sense (that do not provide a direction prefix such as `src.` or `dst.`) are called neutral attributes.

Two rule conditions with different directions can share the same object group definition. A neutral attribute and `net.ip-address` used in the object group can be associated with the directional attributes, such as `src.net.ip-address` and `dst.net.ip-address`, used in the different rules.

Attribute Classes

Attributes are used in configuring policy rules and conditions, or zone definitions.

Network Attributes

Table 2: Network Attributes Supported By Cisco VSG

Description	Name
Source IP address	src.net.ip-address
Source port	src.net.port
Destination IP address	dst.net.ip-address
Destination port	dst.net.port
IP address Note This is a neutral attribute.	net.ip-address
Port Note Neutral attribute.	net.port
IP Protocols 9 Note Neutral attribute.	net.protocol
EtherType of the frame Note Neutral attribute.	net.ethertype
Service running at a destination host Note This attributes allows the user to classify the traffic for a particular service. Net.service attribute is a combination of network protocol and the destination network port.	net.service

VM Attributes

The VM attributes are related to the VM infrastructure and include the following classes of VM attributes:

- Virtual infrastructure attributes—These attributes are obtained from the Microsoft HyperV and are mapped to names.
- Port profile attributes—These attributes are associated with port profiles.
- Custom attributes—These attributes can be configured under a service profile.

The following table describes the VM attributes that are supported by Cisco VSG.

Description	Name
Name of VM	src.vm.name dst.vm.name vm.name Note vm.name is a neutral attribute.
Name of host parent (host)	src.vm.host-name dst.vm.host-name vm.host-name Note vm.host-name is a neutral attribute.
Full name of OS guest (includes the version)	src.vm.os-fullname dst.vm.os-fullname vm.os-fullname Note vm.os-fullname is a neutral attribute.
Name of port profile associated with specific vNIC	src.vm.portprofile-name dst.vm.portprofile-name vm.portprofile-name Note vm.portprofile-name is a neutral attribute.
Custom attributes from security profile of associated port group. Note For every unique custom-attribute xxx, the synthesized attribute name is src.vm.custom.xxx or dst.vm.custom.xxx. The policy uses the synthesized attribute name.	src.vm.custom.xxx dst.vm.custom.xxx vm.custom.xxx Note vm.custom.xxx is a neutral attribute.

Custom VM attributes are user-defined attributes that can be configured under a service profile.

This example shows how to verify the VM attributes on a Cisco VSG:

```
firewall(config)# show vsg vm
VM uuid      : 852a1ff3-149d-4c75-adfa-c75e0d583d37
VM attributes :
  name                : vm
  os-fullname         : windows server 2012 r2 datacenter
  os-hostname        : vm
```

```
Zone(s) :
```

Inspect Action Model

The Inspect action model has an inspect action statement for each condition in a rule. You can have a maximum of one inspect action statement in the AND model. The OR model allows multiple inspect action statements in a rule corresponding to the multiple conditions in a rule.

During the rule evaluation, when a condition in an OR rule matches, the matching inspect action is determined using the inspect action table that is created for each rule.

This example shows an OR rule construct with an inspect action statement:

```
rule r1
cond-match-criteria: match-any
  service-attr
    condition 9 net.service eq protocol 6 port 514 inspect rsh
    condition 10 net.service eq protocol 6 port 21 inspect ftp
    condition 12 net.service eq protocol 17 port 69 inspect tftp
```

Sample table for an OR rule construct:

9	514/rsh
10	21/ftp
12	69/tftp

Zone Attributes

Table 3: Zone Attributes Supported by Cisco VSG

Description	Name
Zone name. This is a multi-valued attribute and can belong to multiple zones at the same time.	src.zone.name dst.zone.name zone.name Note zone.name is a neutral attribute.


Viewing Security Profiles and Policies on the Cisco Prime NSC and the Cisco VSG

The Cisco Prime NSC GUI provides a view of the Cisco VSG security policy objects. The policy objects shown in the Cisco Prime NSC GUI are not necessarily shown in the same organizational path location as they appear in the Cisco VSG CLI when you enter the **show running-config** command.

For example, in the Cisco Prime NSC GUI, if the virtual data center DC1 is under the tenant and the application APP1 is under DC1, the vnsp app1-sp in the APP1 level is pointing to the policy set ps1 at the DC level.

The following figure shows the Cisco Prime NSC GUI organization structure.

Figure 1: Cisco Prime NSC Organizational Hierarchy for a Tenant, Data Center, and Application



```

security-profile app1-sp@root/tenant4/DC1/APP1
policy ps1@root/tenant4/DC1/APP1
  
```

The output of the **show running-config** command shows that the policy set and its objects are resolved from the APP1 level where the security profile is defined. The actual location of the objects in the Cisco Prime NSC GUI is at the DC1 level.

```

policy ps1@root/tenant4/DC1/APP1
rule p1/r1@root/tenant4/DC1/APP1 order 101
  
```

The policy object DNs that are shown in the Cisco VSG **show running-config** command output are shown with a DN relative to where they are resolved from. The policy object DNs are not where the actual policy objects are in the Cisco Prime NSC organizational hierarchy.

However, security profiles are shown with the DN where the actual security profile is created on the Cisco Prime NSC organizational hierarchy.

Policy objects are resolved upwards from where the security profile is located in the Cisco Prime NSC organizational hierarchy.

In the following example, the Cisco VSG is configured with the following specifications:

- The security profile (VNSP) sp1 has policy-set ps1 in which there is a policy p1 that includes a rule, r1.
- The policy-set ps1 is located at root in the organization tree on the Cisco Prime NSC.
- The policy p1 is located at root in the organization tree on the Cisco Prime NSC.
- The rule r1 is placed in the policy p1 on the Cisco Prime NSC (the Cisco Prime NSC does not allow you to create a rule object in and of itself).
- The security profile sp1 is placed in tenant_d3337/dc1 on the Cisco Prime NSC.

All Cisco VSGs in the tenant_d3337 have the following **show running-config** command output (this configuration is replicated to all Cisco VSGs in the leaf path):

```

security-profile sp1@root/tenant_d3337/dc1
policy ps1@root/tenant_d3337/dc1

policy p1@root/tenant_d3337/dc1
rule p1/r1@root/tenant_d3337/dc1 order 101
  
```



Note

The policy objects above do not actually exist at the DC1 level of the organization tree on the Cisco Prime NSC but are resolved from that location in the Cisco Prime NSC organization tree.

Configuring Service Firewall Logging

See the “Enabling Global Policy-Engine Logging” section of the *Cisco VSG for Microsoft Hyper-V and Cisco Prime NSC Installation Guide*.

Verifying the Cisco VSG Configuration

To display the Cisco VSG configuration, use the **show running-config** command.

```
vsg# show running-config

!Command: show running-config
!Time: Wed Jan 15 15:39:57 201

version 5.2(1)VSG2(1.1a)
feature telnet
no feature http-server

username adminbackup password 5 $1$Oip/C5Ci$oOdx7oJS1BCFpNRmQK4na. role network-operator
username admin password 5 $1$CbPcXmpk$131YumYWi00X/EY1qYsFB. role network-admin
username vsnbetauser password 5 $1$mr/jBgON$hoJsm9ACdPHRWPM3KpI6/1 role network-admin

banner motd #Nexus VSN#

ssh key rsa 2048
ip domain-lookup
ip domain-lookup
hostname vsg
snmp-server user admin auth md5 0x0b4894684d52823092c7a7c0b87a853d priv
0x0b4894684d52823092c7a7c0b87a853d localizedkey engineID 128:0:0:9:
3:0:0:0:0:0:0
snmp-server user vsnbetauser auth md5 0x272e8099cab7365fd1649d351b953884 priv
0x272e8099cab7365fd1649d351b953884 localizedkey engineID 128:
0:0:9:3:0:0:0:0:0:0

vrf context management
  ip route 0.0.0.0/0 10.193.72.1
vlan 1
port-channel load-balance ethernet source-mac
port-profile default max-ports 32

vdc vsg id 1
limit-resource vlan minimum 16 maximum 2049
limit-resource monitor-session minimum 0 maximum 2
limit-resource vrf minimum 16 maximum 8192
limit-resource port-channel minimum 0 maximum 768
limit-resource u4route-mem minimum 32 maximum 32
limit-resource u6route-mem minimum 16 maximum 16
limit-resource m4route-mem minimum 58 maximum 58
limit-resource m6route-mem minimum 8 maximum 8
interface mgmt0
  ip address 10.193.73.185/21
interface data0
cli alias name ukickstart copy scp://user@<ip
address>/ws/sjc/baselard_latest/build/images/gdb/nexus-1000v-kickstart-mzg.VSG2.1.bin
bootflash:ukickstart
cli alias name udplug copy scp://user@<ip
address>/ws/sjc/baselard_latest/build/images/gdb/nexus-1000v-dplug-mzg.VSG2.1.bin
bootflash:ukickstart
cli alias name udplug copy scp://user@<ip
address>/ws/sjc/baselard_latest/build/images/gdb/nexus-1000v-dplug-mzg.VSG2.1.bin
bootflash:dplug
cli alias name uimage copy scp://user@<ip
address>/ws/sjc/baselard_latest/build/images/gdb/nexus-1000v-mzg.VSG2.1.bin
bootflash:user_bin
line console
```



```

boot kickstart bootflash:/ukickstart sup-1
boot system bootflash:/user_bin sup-1
boot kickstart bootflash:/ukickstart sup-2
boot system bootflash:/user_bin sup-2
mgmt-policy TCP permit protocol tcp
  ha-pair id 25
security-profile profile1
  policy p2
security-profile profile2
  policy p1
object-group g1 net.port
  match 1 eq 80
  match 2 eq 443
zone zone1
  condition 1 net.ip-address eq 1.1.1.1
  condition 2 net.port eq 80
  condition 2 net.port eq 80
rule r2
  condition 1 dst.net.ip-address eq 2.2.2.2
  condition 2 src.net.ip-address eq 1.1.1.1
  condition 3 src.net.port eq 100
  condition 4 dst.net.port eq 80
  condition 5 net.protocol eq 6
  action 1 permit
rule r5
  condition 1 net.ethertype eq 0x800
  action 1 inspect ftp
rule r6
rule r7
policy p2
  rule r2 order 10
policy p1
  rule r2 order 10

service firewall logging enable
nsc-policy-agent
  registration-ip 10.193.73.190
  shared-secret *****
  log-level info
vsg#

```

Configuration Limits

Table 4: Maximum Configuration Limits for Configuring the Cisco VSG

Feature	Maximum Limit
Zones in Cisco VSG	512
Rules per policy	1024
Policy set per Cisco VSG	64
Maximum rules per Cisco VSG	1024

