



## **Network Virtualization Configuration Guide, Cisco IOS XE Everest 3.18SP (Cisco NCS 4200 Series)**

[Overview](#) 2

[Limitations](#) 2

[Installing a Satellite Image](#) 2

[Removing a Satellite Image](#) 3

[Configuring Satellite Mode Sequence](#) 3

[Upgrading the Satellite Image](#) 3

Revised: May 19, 2022

## Overview

## Limitations

The following limitations apply when enabling nV satellite mode:

- An in-service software upgrade (ISSU) is not supported while the router is acting as an nV satellite device.
- RSP redundancy is not supported while the router is acting as a satellite nV device.
- Online Insertion and Removal (OIR) of interface modules (IMs) is not supported when the router is operating in nV satellite mode.
- Supported connections to the satellite host include
  - Gigabit Ethernet interfaces
  - Ethernet transported over optical interfaces
  - 10 Gigabit Ethernet interfaces (slots 1 and 2 only)Other connection types are not supported.
- Local switching on the satellite device is not supported. The packets are always sent to the host for layer 2 and layer 3 switching.
- Network clocking is not supported when the router is operating in nV satellite mode.
- Reverting from a satellite mode image to the base image requires that you download the original image using TFTP; an inband download is not supported. For more information, see .

## Installing a Satellite Image

Follow these steps to install a satellite nV image on the Cisco NCS 4200 Series Router:

### Procedure

---

- Step 1** Download a Cisco NCS 4200 Series satellite nV image from Cisco.com and copy the image to a TFTP server.
- Step 2** Create a console connection to the management port of the Cisco NCS 4200 Series. For more information about creating a console connection, see *Cisco NCS 4200 Series Router Hardware Installation Guide*.
- Step 3** Copy nV compatible binary image to flash or bootflash.

```
Router# copy tftp://10.10.10.10//tftpboot//ncs4200_sat-universalk9_npe.03.08.00.S.153-1.S.bin bootflash:
```

- Step 4** Set the configuration register to 0x2042.

```
Router(config)# config-register 0x2042
```

**Step 5** Erase the existing configuration.

```
Router# write erase
```

**Step 6** Specify the boot image.

```
Router(config)# boot system bootflash:ncs4200_sat-universalk9_npe.03.08.00.S.153-1.S.bin
```

**Step 7** Save the configuration.

```
Router# copy running-configuration startup-configuration
```

**Step 8** Reload the router

---

```
Router(config)# reload
```

The system boots in nV mode and is detectable by the nV host.



---

**Note** You can use the **show nv satellite status** command to verify the image version.

---

## Removing a Satellite Image

Restoring the Cisco NCS 4200 Series Router to a normal IOS XE image requires that you load an image in ROMmon mode using trivial file transfer protocol (TFTP). For instructions on how to remove a satellite image, please contact Cisco support.

## Configuring Satellite Mode Sequence

When booting to a satellite nV image, the router

- enables Ethernet ports in IEEE mode.
- enables inter-chassis links (IC links).
- uses Satellite Discovery and Control (SDAC) to establish a connection to the host nV device.
- establishes a control path between the host nV device and the router.

## Upgrading the Satellite Image

After you connect the satellite to the host, the host verifies the satellite software version. If there is a version mismatch, the host displays a syslog notification indicating that the satellite device requires an image upgrade. To upgrade the image using the host satellite device, see [Configuring the Satellite Network Virtualization \(nV\) System on the Cisco ASR 9000 Series Router](#).

Use the **show nv satellite status** command to verify the image version.



**Americas Headquarters**  
Cisco Systems, Inc.  
San Jose, CA 95134-1706  
USA

**Asia Pacific Headquarters**  
CiscoSystems(USA)Pte.Ltd.  
Singapore

**Europe Headquarters**  
CiscoSystemsInternationalBV  
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).