



P Commands

- [packet-size](#), on page 7
- [packet](#), on page 8
- [param-list param-list](#), on page 9
- [parity](#), on page 10
- [parity](#), on page 11
- [passive-interface default](#), on page 12
- [passive-interface default](#), on page 13
- [passive-interface default](#), on page 14
- [passive-interface default](#), on page 15
- [password](#), on page 16
- [password](#), on page 17
- [password](#), on page 18
- [password prompt username](#), on page 19
- [password secure-mode](#), on page 20
- [password strength-check](#), on page 21
- [path-option dynamic explicit identifier](#), on page 22
- [path-selection metric igr](#), on page 23
- [path-selection metric igr](#), on page 24
- [path-selection overload allow](#), on page 25
- [path](#), on page 26
- [path next-hop out-label-stack](#), on page 27
- [pathtrace nve](#), on page 28
- [pause](#), on page 30
- [pause](#), on page 31
- [pause buffer-size2 pause-threshold2 resume-threshold2](#), on page 32
- [pause priority](#), on page 33
- [payload](#), on page 34
- [payload test pattern-type pad](#), on page 35
- [peer-gateway](#), on page 36
- [peer-ip](#), on page 37
- [peer-keepalive destination](#), on page 38
- [peer-switch](#), on page 40
- [peer-type fabric](#), on page 41

- peer ip, on page 42
- peer ip, on page 43
- peer local service, on page 44
- peer local service, on page 45
- peer vdc service, on page 46
- peer vpc, on page 47
- perf, on page 48
- periodic-inventory notification, on page 49
- periodic-inventory notification interval, on page 50
- periodic to, on page 51
- periodic to, on page 52
- permit interface, on page 53
- permit vlan, on page 54
- permit vrf, on page 55
- permit vsan, on page 56
- personality, on page 57
- personality backup, on page 58
- personality restore, on page 59
- phone-contact, on page 60
- ping, on page 61
- ping6, on page 63
- ping mpls, on page 64
- ping nve, on page 67
- pktmgr cache disable, on page 69
- pktmgr discard, on page 70
- platform access-list capture, on page 71
- platform access-list fp_dnl, on page 72
- platform access-list update, on page 73
- platform fabricpath mac-learning module, on page 74
- platform forwarding interface statistics mode mpls, on page 75
- platform forwarding layer-2 fl exclude supervisor, on page 76
- platform ip verify, on page 77
- platform ipv6 verify, on page 79
- platform qos, on page 80
- platform qos, on page 82
- platform qos, on page 83
- platform qos, on page 84
- platform qos, on page 85
- platform qos include ipg, on page 86
- platform qos ing, on page 87
- platform qos ing, on page 88
- platform rate-limiter, on page 89
- platform rate-limiter span-egress, on page 91
- plb, on page 92
- plb analytics, on page 93
- plb device-group, on page 94

- plb session device-group, on page 95
- plugin-test load, on page 96
- plugin-test unload, on page 97
- police, on page 98
- police, on page 102
- police police pps, on page 104
- policy-map, on page 106
- policy-map type control-plane, on page 107
- policy-map type network-qos, on page 108
- policy-map type psp, on page 109
- policy-map type queuing, on page 110
- policy, on page 111
- policy, on page 112
- pop, on page 113
- port-channel limit, on page 114
- port-channel load-balance, on page 115
- port-channel load-balance1 ethernet, on page 116
- port-channel load-balance2 resilient, on page 117
- port-channel load-balance ethernet, on page 118
- port-channel load-balance hash-modulo-f2, on page 119
- port-channel load-balance hash enable, on page 120
- port-group, on page 121
- port-group, on page 122
- port-profile, on page 123
- port-profile dump, on page 124
- port-profile no-redirection, on page 125
- port-security stop learning, on page 126
- port, on page 127
- port, on page 128
- port control, on page 129
- port control, on page 130
- port destination, on page 131
- port type ethernet, on page 132
- power efficient-ethernet auto, on page 133
- power efficient-ethernet sleep threshold aggressive, on page 134
- power inline, on page 135
- power inline default_consumption, on page 136
- power inline police action, on page 137
- power inline port priority, on page 138
- power redundancy-mode combined, on page 139
- power redundancy-mode combined force, on page 140
- power redundancy-mode insrc-redundant, on page 141
- power redundancy-mode ps-redundant, on page 142
- pps, on page 143
- pps, on page 144
- precision milliseconds, on page 145

- preempt, on page 146
- preempt, on page 147
- preempt, on page 148
- preempt delay minimum, on page 149
- preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt, on page 150
- preference max, on page 152
- preference min, on page 153
- prefix out, on page 154
- priority-flow-control auto-restore multiplier, on page 155
- priority-flow-control fixed-restore multiplier, on page 156
- priority-flow-control mode, on page 157
- priority-flow-control override-interface mode off, on page 158
- priority-flow-control recover interface, on page 159
- priority-flow-control watch-dog-interval on, on page 160
- priority-flow-control watch-dog-interval on, on page 161
- priority-flow-control watch-dog forced on, on page 162
- priority-flow-control watch-dog interval, on page 163
- priority-flow-control watch-dog shutdown-multiplier, on page 164
- priority, on page 165
- priority2, on page 166
- priority, on page 167
- priority, on page 168
- priority, on page 169
- priority, on page 170
- priority, on page 171
- priority, on page 172
- priority, on page 173
- private-vlan, on page 174
- private-vlan association, on page 175
- private-vlan mapping, on page 176
- private-vlan release resource, on page 177
- private-vlan synchronize, on page 178
- probe-interval, on page 179
- probe-interval, on page 180
- probe, on page 181
- probe, on page 182
- probe, on page 183
- probe, on page 184
- probe, on page 185
- probe, on page 186
- probe, on page 187
- probe get, on page 188

- probe get, on page 189
- probe get, on page 190
- probe host, on page 191
- probe host, on page 192
- probe host, on page 193
- probe host, on page 194
- probe host, on page 195
- probe host, on page 196
- probe port, on page 197
- probe port, on page 198
- probe port, on page 199
- probe port, on page 200
- probe port, on page 201
- probe port, on page 202
- profile, on page 203
- promiscuous-mode off, on page 204
- propagate-sgt, on page 205
- protection, on page 206
- proto, on page 207
- protocol-version, on page 208
- protocol-version, on page 209
- protocol, on page 210
- protocol, on page 211
- protocol shutdown, on page 212
- protocol shutdown, on page 213
- ptp, on page 214
- ptp announce timeout, on page 215
- ptp bad_correction, on page 216
- ptp bad_correction logging, on page 217
- ptp clock-sync auto, on page 218
- ptp correction hardware, on page 219
- ptp domain, on page 220
- ptp multicast master-only, on page 221
- ptp offload, on page 222
- ptp priority1, on page 223
- ptp priority2, on page 224
- ptp send announce, on page 225
- ptp source, on page 226
- ptp time-sync, on page 227
- ptp transport ipv4 ucast master, on page 228
- ptp transport ipv4 ucast slave, on page 229
- ptp ucast-source, on page 230
- ptp vlan, on page 231
- publish-event sub-system type, on page 232
- purge ip route, on page 233
- purge ipv6 route, on page 234

- [push](#), on page 235
- [pwd](#), on page 236
- [python](#), on page 237
- [python instance](#), on page 238

packet-size

{ packet-size <packetsize> }

Syntax Description

packet-size	Packet
<i>packetsize</i>	Size

Command Mode

- /exec/configure/configngamconnectcheck

packet

{ packet <hex-string> } | { no packet }

Syntax Description

no	Negate a command or set its defaults
packet	Provide flow details starting with ethernet header in hex-string format: 0A1B ..
<i>hex-string</i>	Specify flow and payload in hex string format: 0A1B..

Command Mode

- /exec/configure/confignogoamprofileflow

param-list param-list

[no] param-list <plistname> [cross-check] | param-list <plistname>

Syntax Description

no	(Optional) Negate a command or set its defaults
param-list	Configure a parameter list
<i>plistname</i>	Enter the name of the parameter list
cross-check	(Optional) Explicitly search for referencing config profile

Command Mode

- /exec/configure

parity

[no] parity { even | none | odd }

Syntax Description

no	(Optional) Negate a command or set its defaults
parity	Set terminal parity
even	Even parity
none	No parity
odd	Odd parity

Command Mode

- /exec/configure/com1

parity

[no] parity <parity-value>

Syntax Description

no	(Optional) Negate a command or set its defaults
parity	Set terminal parity
<i>parity-value</i>	terminal parity value

Command Mode

- /exec/configure/console

passive-interface default

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

passive-interface default

passive-interface default

[no] passive-interface default <level>

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress IS-IS PDU
default	Undo a command
<i>level</i>	IS-IS level

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

password

password <password-string> | { no | default } password [<password-string>]

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
password	Configure a password for neighbor
<i>password-string</i>	Neighbor password

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor /exec/configure/router-bgp/router-bgp-neighbor-stmp
 /exec/configure/router-bgp/router-bgp-vrf-neighbor
 /exec/configure/router-bgp/router-bgp-template-neighbor
 /exec/configure/router-bgp/router-bgp-prefixneighbor
 /exec/configure/router-bgp/router-bgp-vrf-prefixneighbor

password

password [vrf { <vrf-name> | <vrf-known-name> }] { required [req-for <req-pfx-list>] | { fallback | option <seq-num> opt-for <opt-pfx-list> } { key-chain <name> } } | no password [vrf { <vrf-name> | <vrf-known-name> }] { required | fallback | option <seq-num> }

Syntax Description

no	Negate a command or set its defaults
password	Configure LDP password
vrf	(Optional) VRF Routing/Forwarding instance information
<i>vrf-name</i>	(Optional) VPN Routing/Forwarding instance name
<i>vrf-known-name</i>	(Optional) Known VRF name
required	Password is required for the peer
req-for	(Optional) Prefix list specifying control on LDP peers
<i>req-pfx-list</i>	(Optional) Prefix list for LDP peers
fallback	Specifies a fallback password will follow
option	LDP password option
<i>seq-num</i>	Sequence number of the LDP password option
opt-for	Prefix list specifying control on LDP peers
<i>opt-pfx-list</i>	Prefix list for LDP peers
key-chain	Specifies a key-chain name will follow
<i>name</i>	Key-chain name

Command Mode

- /exec/configure/ldp

password

{ [no] password <passwd> }

Syntax Description

password	password
<i>passwd</i>	password

Command Mode

- /exec/configure/dot1x-cred

password prompt username

[no] password prompt username

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
prompt	Enable prompt for password
username	Enable prompt for password on username command

Command Mode

- /exec/configure

password secure-mode

password secure-mode

[no] password secure-mode

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
secure-mode	Enable secure mode for changing password

Command Mode

- /exec/configure

password strength-check

[no] password strength-check

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
strength-check	Strength check of password

Command Mode

- /exec/configure

path-option dynamic explicit identifier

[no] path-option [protect] <pref> | path-option <pref> dynamic [attributes <attr-name> | { bandwidth <kbps> | lockdown } +] | path-option [protect] <pref> explicit { identifier <id-num> | name <name> } [{ attributes <attr-name> [verbatim] | { bandwidth <kbps> | lockdown | verbatim } + }]

Syntax Description

no	Negate a command or set its defaults
path-option	a primary or fallback path setup option
protect	(Optional) a path protection setup option
<i>pref</i>	preference for this path option
dynamic	setup based on dynamically calculated path
explicit	setup based on preconfigured path
identifier	Specify an IP explicit path by number
<i>id-num</i>	Number of ip explicit path
name	Specify an IP explicit path by name
<i>name</i>	Name of ip explicit path
attributes	(Optional) Specify an LSP attribute list
<i>attr-name</i>	(Optional) Name of LSP attribute list
verbatim	(Optional) send out path as is, with no checking
bandwidth	(Optional) override the bandwidth configured on the tunnel
<i>kbps</i>	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization
<i>kbps</i>	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection metric igp

[no] path-selection metric | path-selection metric { igp | te }

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
metric	Metric type for path calculation
igp	Use IGP Metric
te	Use TE Metric

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection metric igp

path-selection metric igp

path-selection metric { igp | te } | no path-selection metric

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
metric	Metric Type Configuration
igp	Use IGP metric
te	Use TE metric (*Default)

Command Mode

- /exec/configure/te

path-selection overload allow

[no] path-selection overload allow | path-selection overload allow { head [middle] [tail] | middle [tail] | tail }

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
overload	Overload Node Configuration
allow	Allow overloaded nodes in CSPFs
head	Allow overloaded head node in TE SPF
middle	(Optional) Allow overloaded middle node in TE SPF
tail	(Optional) Allow overloaded tail node in TE SPF

Command Mode

- /exec/configure/te

path

path <dn> [depth { <level> | unbounded }] [query-condition <query>] [filter-condition <filter>] | no path <dn>

Syntax Description

no	Negate a command or set its defaults
path	Create a sensor path
<i>dn</i>	Distinguished Name
unbounded	(Optional) Retrieve entire tree
<i>level</i>	(Optional) Retrieval depth
<i>query</i>	(Optional) query condition
<i>filter</i>	(Optional) Filter Condition

Command Mode

- /exec/configure/telemetry/sensor-group

path next-hop out-label-stack

{ no path <path-num> | path <path-num> next-hop <next-hop> out-label-stack { <static-outlabel> + | implicit-null } }

Syntax Description

no	Negate a command or set its defaults
path	Configure an outgoing path for the LSP
<i>path-num</i>	Path identifier
next-hop	Nexthop
<i>next-hop</i>	Destination IPv4 next hop
out-label-stack	Series of output labels
<i>static-outlabel</i>	Label Value
implicit-null	IETF MPLS implicit null label (3)

Command Mode

- /exec/configure/mpls_static/ipv4/lsp/inlabel/forw

pathtrace nve

```
pathtrace nve { { { { ip { <numeric10> | unknown } } [ vrf { <vrf-name> | <vrf-known-name> } | { <dot1qid1>
} ] } | mac <dmac> <dot1qid> [ <intfid> ] } [ profile <pid> ] [ payload { [ mac-addr <dstmac> <smac> ] [
dot1q <dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstipv6> <srcipv6> ] [ port <sport> <dport> ] [ proto <proto-id>
] [ src-intf <src_if> ] } payload-end ] [ copy-to <copy-to-ip> [ ext-id <ext_id> ] ] [
```

Syntax Description

pathtrace	Test
nve	network virtualization edge
<i>numeric10</i>	Peer vtep ip address
unknown	Peer vtep ip is unknown, will be derived from payload
<i>intfid</i>	(Optional) Name of the interface for ngoam pathtrace on which dot1q is configured
payload	(Optional) Enter customer payload
mac-addr	(Optional) Mac
<i>dstmac</i>	(Optional) Destination mac address
<i>smac</i>	(Optional) Source mac address
<i>dot1q</i>	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
ip	ip address
<i>dstip</i>	(Optional) Destination ipv4 address
<i>srcip</i>	(Optional) source ipv4 address
ipv6	(Optional) ipv6 address
port	(Optional) L4 port info
<i>sport</i>	(Optional) Source port
<i>dport</i>	(Optional) Destination port
proto	(Optional) Protocol
<i>proto-id</i>	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
<i>src_if</i>	(Optional) Interface

<code>payload-end</code>	(Optional) End payload info input
<code>profile</code>	(Optional) NGOAM profile to use
<code>pid</code>	(Optional) NGOAM profile id
<code>mac</code>	Mac
<code>dmac</code>	Destination mac address
<code>dot1qid</code>	Encapsulation dot1q/bd on which the mac is learnt
<code>dot1qid1</code>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<code>vrf</code>	(Optional) Display per-VRF information
<code>vrf-name</code>	(Optional) VRF name
<code>vrf-known-name</code>	(Optional) Known VRF name
<code>copy-to</code>	(Optional) Send responses to this IP over mgmt vrf instead
<code>copy-to-ip</code>	(Optional) IPv4 addr to send responses to
<code>ext-id</code>	(Optional) Identifier passed from caller
<code>ext_id</code>	(Optional) 32-bit identifier

Command Mode

- /exec

pause

[no] pause { buffer-size <size-in-bytes> pause-threshold <xoff-bytes> resume-threshold <xon-bytes> }

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
buffer-size	Ingress buffer size in bytes
pause-threshold	Buffer limit for pausing in bytes
resume-threshold	Buffer limit at which to resume in bytes

Command Mode

- /exec/configure/policy-map/type/queuing/class

pause

[no] pause { no-drop | receive1 | { delayed-drop <timeout> } | { [buffer-size <size-in-bytes> pause-threshold <xoff-bytes> resume-threshold <xon-bytes>] pfc-cos <pfc-cos-list> [receive] } }

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
no-drop	NO-DROP
delayed-drop	Enable delayed-drop for the CoS
<i>timeout</i>	Timer value for delayed drop
buffer-size	(Optional) Ingress buffer size in bytes
pause-threshold	(Optional) Buffer limit for pausing in bytes
resume-threshold	(Optional) Buffer limit at which to resume in bytes
pfc-cos	CoS values to assert PFC on
receive	(Optional) Enable only PFC receive for the list of pfc-cos values
receive1	Enable only PFC receive
<i>pfc-cos-list</i>	List of class-of-service values

Command Mode

- /exec/configure/policy-map/type/uf/class

■ pause buffer-size2 pause-threshold2 resume-threshold2

pause buffer-size2 pause-threshold2 resume-threshold2

[no] pause buffer-size2 <size-in-bytes> pause-threshold2 <xoff-bytes> resume-threshold2 <xon-bytes>

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
buffer-size2	Ingress buffer size in bytes
pause-threshold2	Buffer limit for pausing in bytes
resume-threshold2	Buffer limit at which to resume in bytes

Command Mode

- /exec/configure/policy-map/type/queuing/class

pause priority

[no] pause { priority-group <priority-group-number> }

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
priority-group	ingress priority-group to which the traffic is mapped and pause limits are applied
<i>priority-group-number</i>	Priority group value

Command Mode

- /exec/configure/policy-map/type/queuing/class

payload

[no] payload

Syntax Description

no	(Optional) Negate a command or set its defaults
payload	Configure ngoam connectivity check payload

Command Mode

- /exec/configure/configngoamconnectcheck

payload test pattern-type pad

{ payload { test pattern-type <test-id> | pad <pad-val> } } | { no payload { test pattern-type | pad } }

Syntax Description

no	Negate a command or set its defaults
payload	Configure ngoam payload
test	Configure ngoam payload test
pattern-type	Configure ngoam payload test pattern
<i>test-id</i>	Configure ngoam payload test pattern id
pad	Configure ngoam payload test pattern pad
<i>pad-val</i>	Configure ngoam payload test pad value

Command Mode

- /exec/configure/configngoamprofile

peer-gateway

```
peer-gateway [ exclude-vlan <vlan-list> ] | no peer-gateway
```

Syntax Description

no	Negate a command or set its defaults
peer-gateway	Enable L3 forwarding for packets destined to peer's gateway mac-address
exclude-vlan	(Optional) Specify VLANs to be excluded from peer-gateway functionality
<i>vlan-list</i>	(Optional) Specify the list of vlans

Command Mode

- /exec/configure/vpc-domain

peer-ip

[no] peer-ip <addr>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer-ip	Static IP Address Configuration
<i>addr</i>	Remote Peer IP Address

Command Mode

- /exec/configure/if-nve/vni/ingrrep

peer-keepalive destination

peer-keepalive destination

```
peer-keepalive destination <dst-ip> [ [ source <src-ip> | udp-port <udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } | tos-byte <tos-byte-value> | hold-timeout <hold-time-out> ] + | [ source <src-ip> | udp-port <udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } | tos { <tos-value> | min-delay | max-throughput | max-reliability | min-monetary-cost | normal } | hold-timeout <hold-time-out> ] + | [ source <src-ip> | udp-port <udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } | precedence { <prec-vlaue> | network | internet | critical | flash-override | flash | immediate | priority | routine } | hold-timeout <hold-time-out> ] + ]
```

Syntax Description

peer-keepalive	Keepalive/Hello with peer switch
destination	specify destination ip address of peer switch
<i>dst-ip</i>	IPv4 address (A.B.C.D) of destination
source	(Optional) source interface for hello
<i>src-ip</i>	(Optional) IPv4 address (A.B.C.D) of source
udp-port	(Optional) enter UDP port number used for hello
<i>udp-port-num</i>	(Optional) udp port number for hellos
vrf	(Optional) vrf to be used for hello messages
<i>vrf-name</i>	(Optional) vrf to be used for hellos
<i>vrf-known-name</i>	(Optional) Known VRF name
interval	(Optional) enter interval in millesconds
<i>interval-ms</i>	(Optional) Enter interval in millesconds
timeout	(Optional) enter timeout in seconds
<i>time-out</i>	(Optional) enter timeout in seconds
precedence	(Optional) Precedence
<i>prec-vlaue</i>	(Optional) Precedence value
network	(Optional) network (7)
internet	(Optional) internet (6)
critical	(Optional) critical (5)
flash-override	(Optional) flash-override (4)
flash	(Optional) flash (3)

immediate	(Optional) immediate (2)
priority	(Optional) priority (1)
routine	(Optional) routine (0)
tos	(Optional) Type of Service
<i>tos-value</i>	(Optional) Enter 4-bit TOS value
min-delay	(Optional) min-delay (8)
max-throughput	(Optional) max-throughput (4)
max-reliability	(Optional) max-reliability (2)
min-monetary-cost	(Optional) min-monetary-cost (1)
normal	(Optional) normal (0)
tos-byte	(Optional) Type of Service Byte
<i>tos-byte-value</i>	(Optional) Enter 8-bit TOS value
hold-timeout	(Optional) hold timeout to ignore stale peer alive messages
<i>hold-time-out</i>	(Optional) Enter hold-timeout in seconds

Command Mode

- /exec/configure/vpc-domain

peer-switch

[no] peer-switch

Syntax Description

no	(Optional) Negate a command or set its defaults
peer-switch	Enable peer switch on vPC pair switches

Command Mode

- /exec/configure/vpc-domain

peer-type fabric

peer-type { fabric-external | fabric-border-leaf } | { no | default } peer-type

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
peer-type	Neighbor facing
fabric-external	Fabric external
fabric-border-leaf	Fabric Border Leaf

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

peer ip

[no] peer ip <ip-addr>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	ITD peer
ip	ITD peer ip
<i>ip-addr</i>	NICE node IP prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-inout

peer ip

[no] peer ip <ip-addr>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	PLB peer
ip	PLB peer ip
<i>ip-addr</i>	NICE node IPv4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-inout

peer local service

[no] peer local service <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	Peer cli for sandwich mode failure notification
local	Peer involved in sandwich mode
service	Peer service involved in sandwich mode
<i>service-name</i>	Peer service name string

Command Mode

- /exec/configure/itd

peer local service

[no] peer local service <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	Peer cli for sandwich mode failure notification
local	Peer involved in sandwich mode
service	Peer service involved in sandwich mode
<i>service-name</i>	Peer service name

Command Mode

- /exec/configure/plb

peer vdc service

[no] peer vdc <vdc-id> service <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	Peer cli for sandwich mode failure notification
vdc	Peer VDC involved in sandwich mode
service	Peer service involved in sandwich mode
<i>vdc-id</i>	VDC name of peer VDC
<i>service-name</i>	Peer service name string

Command Mode

- /exec/configure/itd

peer vpc

[no] peer <svc-name> vpc <num>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	smart channel peer
vpc	vpc
<i>svc-name</i>	peer smart channel name
<i>num</i>	VPC number to assign to smart-channel

Command Mode

- /exec/configure/smartz

perf

```
perf [ { record { context-switch | profile } { system | process <i0> } [ <s1> ] } | { stop { all | <s0> } } | { list } | { create-archive <s2> } | { remove { all | <s3> } } ]
```

Syntax Description

perf	Run perf tool to collect or process event data
record	(Optional) Record events to a file for later analysis
stop	(Optional) Stop a perf record.
list	(Optional) List recorded datasets
create-archive	(Optional) Create an archive of dataset for download
remove	(Optional) Remove recorded dataset(s)
all	(Optional) Act on all recorded datasets
context-switch	(Optional) Record context-switch events
profile	(Optional) Record periodic runtime samples
system	(Optional) Record events for all processes on all CPUS
process	(Optional) Record events for a specific process with the given pid
<i>i0</i>	(Optional) pid of process to record events
<i>s0</i>	(Optional) id of perf record session to stop
<i>s1</i>	(Optional) id to use for perf record session
<i>s2</i>	(Optional) id of perf dataset to create an archive
<i>s3</i>	(Optional) id of perf dataset to remove

Command Mode

- /exec

periodic-inventory notification

[no] periodic-inventory notification

Syntax Description

no	(Optional) Negate a command or set its defaults
periodic-inventory	Configure periodic software inventory message dispatch
notification	Enable periodic software inventory message dispatch

Command Mode

- /exec/configure/callhome

periodic-inventory notification interval

periodic-inventory notification { interval <i0> | timeofday <s0> }

Syntax Description

periodic-inventory	Configure periodic software inventory message dispatch
notification	Enable periodic software inventory message dispatch
interval	Configure the time period for periodic inventory
<i>i0</i>	Time period in days (default is 7 days)
timeofday	Configure the timeofday for periodic inventory in HH:MM format
<i>s0</i>	Time period in HH:MM format

Command Mode

- /exec/configure/callhome

periodic to

{ [<seqno>] | no } periodic { { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday } +
| daily | weekdays | weekend } <stime> to <etime>

Syntax Description

<i>seqno</i>	(Optional) Sequence number
no	Negate a command or set its defaults
periodic	Periodic time and date
Monday	Monday
Tuesday	Tuesday
Wednesday	Wednesday
Thursday	Thursday
Friday	Friday
Saturday	Saturday
Sunday	Sunday
daily	Every day of the week
weekdays	Monday thru Friday
weekend	Saturday and Sunday
<i>stime</i>	Starting time
to	Ending day and time
<i>etime</i>	Ending time

Command Mode

- /exec/configure/timerange

periodic to

periodic to

{ [<seqno>] | no } periodic { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday }
 <stime> to { <eday> } <etime>

Syntax Description

<i>seqno</i>	(Optional) Sequence number
no	Negate a command or set its defaults
periodic	Periodic time and date
Monday	Monday
Tuesday	Tuesday
Wednesday	Wednesday
Thursday	Thursday
Friday	Friday
Saturday	Saturday
Sunday	Sunday
<i>eday</i>	Day of the week
<i>stime</i>	Starting time
to	Ending day and time
<i>etime</i>	Ending time

Command Mode

- /exec/configure/timerange

permit interface

[no] permit interface <if0>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to interfaces (applicable if interface policy is 'deny')
interface	Enter the range of interfaces accessible the role
<i>if0</i>	Enter the interface range

Command Mode

- /exec/configure/role/interface

permit vlan

permit vlan

[no] permit vlan <vlan-mrange>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vlans (applicable if vlan policy is 'deny')
vlan	Enter the range of vlans accessible the role
<i>vlan-mrange</i>	Enter the vlan range

Command Mode

- /exec/configure/role/vlan

permit vrf

[no] permit vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vrf (applicable if vrf policy is 'deny')
vrf	Enter the range of vrf accessible the role
<i>vrf-name</i>	Enter the vrf name

Command Mode

- /exec/configure/role/vrf

permit vsan

permit vsan

[no] permit vsan <vsan-mrange>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vsans (applicable if vsan policy is 'deny')
vsan	Enter the range of vsans accessible the role
<i>vsan-mrange</i>	Enter the vsan range

Command Mode

- /exec/configure/role/vsan

personality

[no] personality

Syntax Description

no	(Optional) Negate a mode
personality	Config Personality

Command Mode

- /exec/configure

personality backup

personality backup { <uri_local> | <uri_remote> [password <password>] [vrf <vrf-known-name>] }

Syntax Description

personality	personality
backup	backup personality
password	(Optional) The password for personality backups
vrf	(Optional) The VRF for personality backups
<i>uri_local</i>	Personality backup local destination
<i>uri_remote</i>	Personality backup remote destination
<i>password</i>	(Optional) Password for SCP username
<i>vrf-known-name</i>	(Optional) VRF name

Command Mode

- /exec

personality restore

```
personality restore <uri> [ user-name <user> ] [ password <password> ] [ hostname <hostname> ] [ vrf <vrf_name> ]
```

Syntax Description

personality	Personality
restore	Restore the personality file
<i>uri</i>	Personality file
user-name	(Optional) The username for downloads
<i>user</i>	(Optional) The username
password	(Optional) The password for downloads
<i>password</i>	(Optional) The password
hostname	(Optional) The hostname for downloads
<i>hostname</i>	(Optional) The hostname
vrf	(Optional) The VRF for downloads
<i>vrf_name</i>	(Optional) The VRF name

Command Mode

- /exec

phone-contact

{ phone-contact <s0> | no phone-contact }

Syntax Description

no	Negate a command or set its defaults
phone-contact	Contact person's phone number
s0	Phone number in international format(such as +1-800-123-4567)

Command Mode

- /exec/configure/callhome

ping

```
ping [ { { <alpha> | <numeric> [ loopback interface <interface> ] } | { multicast <group> interface <interface> [ loopback ] } } [ [ source-interface <src-intf> | vrf { <vrf-name> | <vrf-known-name> } ] [ count { <count> | unlimited } | packet-size <packetsize> | vrf { <vrf-name> | <vrf-known-name> } | interval <interval> | source { <alpha> | <numeric1> } | df-bit | timeout <timeout> ] + | [ count { <count> | unlimited } | packet-size <packetsize> | source-interface <src-intf> | interval <interval> | df-bit | timeout <timeout> ] + ] ]
```

Syntax Description

ping	Test
count	(Optional) Number
unlimited	(Optional) Unlimited
<i>count</i>	(Optional) Number
packet-size	(Optional) Packet
<i>packetsize</i>	(Optional) Size
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface
interval	(Optional) Wait
<i>interval</i>	(Optional) Interval
<i>numeric</i>	(Optional) IP address of remote system
<i>numeric1</i>	(Optional) IP
<i>alpha</i>	(Optional) Enter
multicast	(Optional) Multicast
<i>group</i>	(Optional) Multicast
interface	(Optional) Interface
<i>interface</i>	(Optional) Interface
loopback	(Optional) Receive
source	(Optional) Source
df-bit	(Optional) Enable
timeout	(Optional) Specify
<i>timeout</i>	(Optional) Timeout
vrf	(Optional) Display per-VRF information

ping

<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

ping6

```
ping6 { { <host> | <hostname> } | { multicast <group> } } [ [ { count { <count> | unlimited } } | { packet-size <packetsize> } | [ source { <host1> | <hostname> } ] | vrf { <vrf-name> | <vrf-known-name> } | timeout <timeout> | { interval <interval> } ] + | [ { count { <count> | unlimited } } | { packet-size <packetsize> } | { source-interface <src-intf> } | timeout <timeout> | { interval <interval> } ] + ]
```

Syntax Description

ping6	Test
count	(Optional) Number
<i>count</i>	(Optional) Number
unlimited	(Optional) unlimited
packet-size	(Optional) Packet
<i>packetsize</i>	(Optional) Size
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface
interval	(Optional) Wait
<i>interval</i>	(Optional) Interval
<i>hostname</i>	Enter
multicast	Multicast
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
source	(Optional) Source
timeout	(Optional) Specify
<i>timeout</i>	(Optional) Timeout

Command Mode

- /exec

ping mpls

```
ping mpls { nil-fec labels <comma-separated-labels> } { output { ointerface <tx-interface> } nexthop
<nexthop-ip-addr> [ { repeat <count> } | { { size <size> } | { sweep <min-size> <max-size> <increment>
} } | { timeout <seconds> } | { interval <milliseconds> } | { destination <addr-start> [ <addr-end> [
<addr-incr-mask> | <addr-incr> ] ] } | { source <addr> } | { exp <exp-value> } | { pad <pattern> } | { ttl <ttl>
} | { verbose } | { reply { { mode { <reply-mode-ipv4> | router-alert | control-channel | no-reply } } | { dscp
{ <dscp-bits> | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4
| cs5 | cs6 | cs7 | default | ef } } | { pad-tlv } } } } + | { force-explicit-null } | { dsmap [ hashkey { none | {
hash-ipv4 { bitmap <bitmap-size> } } } ] } | { flags { fec } } } ] } +
```

Syntax Description

ping	need
mpls	Test
nil-fec	Target
labels	A
<i>comma-separated-labels</i>	A
repeat	(Optional) Repeat
<i>count</i>	(Optional) Repeat
size	(Optional) Packet
<i>size</i>	(Optional) Datagram
sweep	(Optional) Sweep
<i>min-size</i>	(Optional)
<i>max-size</i>	(Optional)
<i>increment</i>	(Optional) Sweep
timeout	(Optional) Timeout
<i>seconds</i>	(Optional) Timeout
interval	(Optional) Send
<i>milliseconds</i>	(Optional) Send
destination	(Optional) Destination
<i>addr-start</i>	(Optional) Destination
<i>addr-end</i>	(Optional) Destination
<i>addr-incr-mask</i>	(Optional) Destination

<i>addr-incr</i>	(Optional) Destination
<i>source</i>	(Optional) Source
<i>addr</i>	(Optional) Source
<i>exp</i>	(Optional) EXP
<i>exp-value</i>	(Optional) EXP
<i>pad</i>	(Optional) Pad
<i>pattern</i>	(Optional) Pad
<i>ttl</i>	(Optional) Time
<i>ttl</i>	(Optional) TTL
<i>verbose</i>	(Optional) verbose
<i>reply</i>	(Optional) Reply
<i>mode</i>	(Optional) Reply
<i>reply-mode-ipv4</i>	(Optional) Send
<i>router-alert</i>	(Optional) Send
<i>control-channel</i>	(Optional) Send
<i>no-reply</i>	(Optional) Send
<i>dscp</i>	(Optional) DSCP
<i>dscp-bits</i>	(Optional) Differentiated
<i>af11</i>	(Optional) Match
<i>af12</i>	(Optional) Match
<i>af13</i>	(Optional) Match
<i>af21</i>	(Optional) Match
<i>af22</i>	(Optional) Match
<i>af23</i>	(Optional) Match
<i>af31</i>	(Optional) Match
<i>af32</i>	(Optional) Match
<i>af33</i>	(Optional) Match
<i>af41</i>	(Optional) Match
<i>af42</i>	(Optional) Match

af43	(Optional) Match
cs1	(Optional) Match
cs2	(Optional) Match
cs3	(Optional) Match
cs4	(Optional) Match
cs5	(Optional) Match
cs6	(Optional) Match
cs7	(Optional) Match
default	(Optional) Match
ef	(Optional) Match
pad-tlv	(Optional) Reply
force-explicit-null	(Optional) Force
output	Output
ointerface	Echo
<i>tx-interface</i>	Echo
nexthop	Next
<i>nexthop-ip-addr</i>	Next
dsmap	(Optional) Request
hashkey	(Optional) Downstream
none	(Optional) Hash
hash-ipv4	(Optional) IPv4
bitmap	(Optional) Hash
<i>bitmap-size</i>	(Optional) Multipath
flags	(Optional) Flag
fec	(Optional) Request

Command Mode

- /exec

ping nve

```
ping nve { { { { ip { <numeric10> | <numeric11> | unknown } } [ vrf { <vrf-name> | <vrf-known-name> } | { <dot1qid1> } ] } | mac <dmac> <dot1qid> [ <intfid> ] } [ profile <pid> ] } [ payload { [ mac-addr <dstmac> <smac> ] [ dot1q <dot1q-id> ] [ ip <dstrip> <srcip> | ipv6 <dstipv6> <srcipv6> ] [ port <sport> <dport> ] [ proto <proto-id> ] [ src-intf <src_if> ] } payload-end ] [ source { <numeric1> | <numeric2> } ] }
```

Syntax Description

{	<count>
ping	Test
nve	network virtualization edge
<i>numeric10</i>	Ipv4 address of remote host / VTEP
unknown	Peer vtep ip is unknown, Applicable only for channel Nv03
<i>dot1qid</i>	Encapsulation dot1q/bd on which the mac is learnt
<i>intfid</i>	(Optional) Name of the interface for ngoam ping on which dot1q is configured
payload	(Optional) Enter customer payload
port	(Optional) L4 port info
<i>sport</i>	(Optional) Source port
<i>dport</i>	(Optional) Destination port
proto	(Optional) Protocol
<i>proto-id</i>	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
<i>src_if</i>	(Optional) Interface
payload-end	(Optional) End of payload info
profile	(Optional) NGOAM profile to use
<i>pid</i>	(Optional) NGOAM profile id
mac	Mac
mac-addr	(Optional) Mac
ip	ip address
<i>dstrip</i>	(Optional) Destination ipv4 address

ping nve

<i>srcip</i>	(Optional) source ipv4 address
<i>ipv6</i>	(Optional) ipv6 address
<i>dmac</i>	Destination mac address
<i>dstmac</i>	(Optional) Destination mac address
<i>smac</i>	(Optional) Source mac address
<i>dot1q</i>	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<i>dot1qid1</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<i>vrf</i>	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>source</i>	(Optional) Source
<i>numeric1</i>	(Optional) IP

Command Mode

- /exec

pktnmgr cache disable

{ [no] pktnmgr cache disable }

Syntax Description

no	(Optional) Negate a command or set its defaults
pktnmgr	packet manager
cache	Disable cache
disable	Disable cache

Command Mode

- /exec/configure

pktmgr discard

pktmgr discard

{ [no] pktmgr discard [type <type>] [direction <direction>] [detail] }

Syntax Description

no	(Optional) Negate a command or set its defaults
pktmgr	packet manager
discard	discard CPI-bound output packets
detail	(Optional) detailed discard info
direction	(Optional) pm debug-filter direction
<i>direction</i>	(Optional) pm direction
type	(Optional) Driver type
<i>type</i>	(Optional) Driver type

Command Mode

- /exec

platform access-list capture

[no] { platform | hardware } access-list capture

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
access-list	Access Control List
capture	Configure ACL capture

Command Mode

- /exec/configure

```
platform access-list fp_dnl
```

platform access-list fp_dnl

[no] { platform | hardware } access-list fp_dnl

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
access-list	Access control list
fp_dnl	Fabric path - do not learn mac from broadcast

Command Mode

- /exec/configure

platform access-list update

[no] { platform | hardware } access-list update { { atomic [strict] } | { default-result permit } }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
access-list	Access Control List
update	Configure atomic/non-atomic update and default-result
atomic	Enable atomic update of access-list in hardware
strict	(Optional) Strict check on TCAM size for using multiple features
default-result	Default access-list result during non-atomic hardware update
permit	Permit all packets during non-atomic update

Command Mode

- /exec/configure

platform fabricpath mac-learning module

platform fabricpath mac-learning module

[no] { platform | hardware } fabricpath mac-learning module <module> [port-group { 1-4 | 5-8 | 9-12 | 13-16 | 17-20 | 21-24 | 25-28 | 29-32 | 33-36 | 37-40 | 41-44 | 45-48 } +]

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
fabricpath	Fabric Path
mac-learning	MAC Learning
module	Specify a module number
<i>module</i>	Specify a module number
port-group	(Optional) Port Group

Command Mode

- /exec/configure

platform forwarding interface statistics mode mpls

[no] { platform | hardware } forwarding interface statistics mode { mpls | default } [module <module-num>]

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
forwarding	Hardware forwarding
interface	Interface
statistics	Statistics
mode	Statistics mode
mpls	Mpls mode
default	Default mode
module	(Optional) Specify a module number
<i>module-num</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform forwarding layer-2 f1 exclude supervisor

platform forwarding layer-2 f1 exclude supervisor

[no] { platform | hardware } forwarding layer-2 f1 exclude supervisor

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
forwarding	Forwarding information
layer-2	L2 only mode
f1	N7K-F132XP-15 module
exclude	Exclude supervisor from getting copies of ARP and multicast packets
supervisor	Supervisor module

Command Mode

- /exec/configure

platform ip verify

[no] { platform | hardware } ip verify { address { source { broadcast | multicast } | class-e | destination { zero } | identical | reserved } | checksum | protocol | fragment | length { minimum | consistent | maximum { max-frag | udp | max-tcp } } | tcp { tiny-frag } | version | syslog }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
ip	IP
verify	Enable IPv4 and some IPv6 packet validation checks in hardware
address	IPv4 Source and destination address validation
source	Check source address
broadcast	Source address is 255.255.255.255
multicast	Source address is 224.x.x.x
destination	Check destination address
zero	Destination address is 0.0.0.0
class-e	Class E IDS check
identical	Same IP SA and DA
reserved	Source address is 127.x.x.x
checksum	Verify IPv4 and IPv6 packet checksum
protocol	Verify IP protocol
fragment	Check IPv4 and IPv6 fragment with non-zero offset and DF bit active
length	Validate IPv4 packet header and payload length
minimum	Minimum IPv4 header length
consistent	Actual frame size is equal to or more than IPv4 length plus ethernet header
maximum	Check max fragment offset and payload length
max-frag	Fragment offset field value
udp	Maximum UDP length has to be less than IPv4 payload length

platform ip verify

max-tcp	Maximum TCP length has to be less than IPv4 payload length
tcp	Validate TCP packet header
tiny-frag	Check TCP tiny fragment
version	Must be 4 for an ethertype of IPv4 (0x0800)
syslog	Syslog Messages logging configuration for IDS check drops

Command Mode

- /exec/configure

platform ipv6 verify

[no] { platform | hardware } ipv6 verify { length { consistent | maximum { max-frag | udp | max-tcp } } | tcp { tiny-frag } | version }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
ipv6	IPv6
verify	Enable IPv6 packet validation checks in hardware
length	Validate IPv6 packet header and payload length
consistent	Actual frame size is equal to or more than IPv6 length plus ethernet header
maximum	Check max fragment offset and payload length
max-frag	Fragment offset field value
udp	Maximum UDP length has to be less than IPv6 payload length
max-tcp	Maximum TCP length has to be less than IPv6 payload length
tcp	Validate TCP packet header
tiny-frag	Check TCP tiny fragment
version	Must be 6 for an ethertype of IPv6 (0x86DD)

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { oq-stats [{ q0 | q1 | q2 | q3 | q4 | q5 | q6 | q7 | q8 | q9 }] [{ counter0 | counter1 | counter2 | counter3 | counter4 | counter5 | counter6 | counter7 | counter8 | counter9 }] type { all | <sel1> [<sel2>] } [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
oq-stats	per output queue statistics
q0	(Optional) queueing statistics for qos-group q0 (default)
q1	(Optional) queueing statistics for qos-group q1
q2	(Optional) queueing statistics for qos-group q2
q3	(Optional) queueing statistics for qos-group q3
q4	(Optional) queueing statistics for qos-group q4
q5	(Optional) queueing statistics for qos-group q5
q6	(Optional) queueing statistics for qos-group q6
q7	(Optional) queueing statistics for qos-group q7
q8	(Optional) queueing statistics for qos-group q8 (cpu)
q9	(Optional) queueing statistics for qos-group q9 (span)
counter0	(Optional) use per-port counter 0
counter1	(Optional) use per-port counter 1
counter2	(Optional) use per-port counter 2
counter3	(Optional) use per-port counter 3
counter4	(Optional) use per-port counter 4
counter5	(Optional) use per-port counter 5
counter6	(Optional) use per-port counter 6
counter7	(Optional) use per-port counter 7
counter8	(Optional) use per-port counter 8

counter9	(Optional) use per-port counter 9
type	type of statistics
all	aggregated occ-drops + wred-drops + ecn-stats
<i>sel1</i>	
<i>sel2</i>	(Optional)
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { min-buffer qos-group <buff-prof-opt> [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
min-buffer	minimum/reserved buffer selection
qos-group	Qos Group
<i>buff-prof-opt</i>	
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { ing-pg-hdrm-reserve percent <percent-val> [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
ing-pg-hdrm-reserve	Set Ingress PG Headroom reservation
percent	PG Headroom reservation percent
<i>percent-val</i>	percent of PG Headroom to reserve
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { oq-drops type <sel> [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
oq-drops	per output queue drops
type	type of drops - occ/wred/both
<i>sel</i>	
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { [cpu-pg-size <cpu-size>] [lcpu-pg-size <lcpu-size>] [span-pg-size <span-size>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
cpu-pg-size	(Optional) Configure CPU Pool Group thresholds
<i>cpu-size</i>	(Optional) Pool Group size
lcpu-pg-size	(Optional) Configure LCPU Pool Group thresholds
<i>lcpu-size</i>	(Optional) Pool Group size
span-pg-size	(Optional) Configure SPAN Pool Group thresholds
<i>span-size</i>	(Optional) Pool Group size

Command Mode

- /exec/configure

platform qos include ipg

platform qos include ipg

[no] { platform | hardware } qos include { ipg [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
include	include specific configaration param
ipg	Select whether to include IPG in Shaping/Policing
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos ing

[no] { platform | hardware } qos { ing-pg-share [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
ing-pg-share	Select Ingress PG Shared Buffer Usage
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos ing

platform qos ing

[no] { platform | hardware } qos { ing-pg-no-min [pgmin <pgmin>] [module <module>] }

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
ing-pg-no-min	Enable PG Min
pgmin	(Optional) Set PG Min Value
<i>pgmin</i>	(Optional) PG Min Value
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform rate-limiter

```
{ platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | f1 <f1-opts> } { <pps> [ burst <burst> ] | disable } [ module <module> [ port <start> <end> ] ] | no { platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | f1 <f1-opts> } [ disable ] [ <pps> [ burst <burst> ] [ module <module> [ port <start> <end> ] ] ]
```

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
layer-3	Layer-3 control and Routed packets
<i>l3-opts</i>	
multicast	Multicast data packets
<i>mcast-opts</i>	
layer-2	Layer-2 control and Bridged packets
<i>l2-opts</i>	
<i>opts</i>	
<i>pps</i>	value in packets per sec
f1	Control packets from F1 modules to supervisor
<i>f1-opts</i>	
disable	Disable the rate-limiter
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
port	(Optional) Port range
<i>start</i>	(Optional) Port start index
<i>end</i>	(Optional) Port end index
burst	(Optional) Modify burst parameter
<i>burst</i>	(Optional) value of burst size

Command Mode

platform rate-limiter

- /exec/configure

platform rate-limiter span-egress

```
{ platform | hardware } rate-limiter span-egress <rate> [ module <module> ] | no { platform | hardware }  
rate-limiter span-egress [ <rate> ] [ module <module> ]
```

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
span-egress	SPAN/ERSPAN egress packets
<i>rate</i>	value in kbit per sec
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

plb

[no] plb [<svc-name>] [service <service-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
<i>svc-name</i>	(Optional) Specify PLB service name [Deprecated]
service	(Optional) Configure PLB service [Preferred]
<i>service-name</i>	(Optional) Specify PLB service name

Command Mode

- /exec/configure

plb analytics

[no] plb analytics <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
analytics	Enable PLB service analytics
<i>service-name</i>	PLB service name

Command Mode

- /exec/configure

plb device-group

plb device-group

[no] plb device-group <group-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
device-group	Configure PLB device group
<i>group-name</i>	Specify device-group name

Command Mode

- /exec/configure

plb session device-group

{ plb session device-group <group-name> } | { no plb session device-group <group-name> }

Syntax Description

no	Negate a command or set its defaults
plb	Configure PLB
session	Configure PLB session
device-group	Configure PLB device group
<i>group-name</i>	Specify device-group name

Command Mode

- /exec/configure

plugin-test load

plugin-test load

```
plugin-test load <uri0> [ [ <uri1> ] [ <uri2> ] ]
```

Syntax Description

plugin-test	PLUGIN test
load	PLUGIN test load
<i>uri0</i>	Enter image name
<i>uri1</i>	(Optional) Enter image name
<i>uri2</i>	(Optional) Enter image name

Command Mode

- /exec

plugin-test unload

plugin-test unload <s0> [[<s1>] [<s2>]]

Syntax Description

plugin-test	PLUGIN test
unload	plugin test unload
<i>s0</i>	Enter swid
<i>s1</i>	(Optional) Enter swid
<i>s2</i>	(Optional) Enter swid

Command Mode

- /exec

police

```
[no] police { { [ cir ] { <cir-val> [ bps | kbps | mbps | gbps | pps ] | percent <cir-perc> } [ [ bc ] { <committed-burst> [ bytes | kbytes | mbytes | ms | us | packets ] } ] [ pir { <pir-val> [ bps2 | kbps2 | mbps2 | gbps2 | pps2 ] | percent <pir-perc> } [ [ be ] { <extended-burst> [ bytes2 | kbytes2 | mbytes2 | ms2 | us2 | packets2 ] } ] ] [ conform { transmit | set-prec-transmit { <prec-val> | <prec-enum> } | set-dscp-transmit { <dscp-val> | <dscp-enum> } | set-cos-transmit <cos-val> | set-discard-class-transmit <disc-class-val> | set-qos-transmit <qos-grp-val> | set-mpls-exp-imposition-transmit <exp-value-imp> | set-mpls-exp-topmost-transmit <exp-value-top> } [ exceed { transmit1 | drop1 | set <exc-frm-field> <exc-to-field> table cir-markdown-map | set-prec-transmit1 { <prec-val1> | <prec-enum1> } | set-dscp-transmit1 { <dscp-val1> | <dscp-enum1> } | set-cos-transmit1 <cos-val1> | set-discard-class-transmit1 <disc-class-val1> | set-qos-transmit1 <qos-grp-val1> | set-mpls-exp-imposition-transmit1 <exp-value-imp1> | set-mpls-exp-topmost-transmit1 <exp-value-top1> } ] [ violate { drop2 | set <vio-frm-field> <vio-to-field> table2 pir-markdown-map | set-prec-transmit2 { <prec-val2> | <prec-enum2> } | set-dscp-transmit2 { <dscp-val2> | <dscp-enum2> } | set-cos-transmit2 <cos-val2> | set-discard-class-transmit2 <disc-class-val2> | set-qos-transmit2 <qos-grp-val2> | set-mpls-exp-imposition-transmit2 <exp-value-imp2> | set-mpls-exp-topmost-transmit2 <exp-value-top2> } ] ] } | aggregate <policer-name> }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
police	police
cir	(Optional) Specify committed information rate
bc	(Optional) Specify committed burst
percent	Specify rate as percentage of interface data-rate
<i>cir-perc</i>	Percentage
<i>pir-perc</i>	(Optional) Percentage
pir	(Optional) Specify peak information rate
be	(Optional) Specify extended burst (for 1R3C meter)
bps	(Optional) Bits per second
kbps	(Optional) Kilo bits per second
mbps	(Optional) Mega bits per second
gbps	(Optional) Giga bits per second
pps	(Optional) Packets per second
bps2	(Optional) Bits per second
kbps2	(Optional) Kilo Bits per second
mbps2	(Optional) Mega Bits per second

gbps2	(Optional) Giga Bits per second
pps2	(Optional) Packets per second
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
us	(Optional) Micro second(s)
ms	(Optional) Milli second(s)
packets	(Optional) Packets
bytes2	(Optional) Bytes
kbytes2	(Optional) Kilo Bytes
mbytes2	(Optional) Mega Bytes
ms2	(Optional) Milli seconds
us2	(Optional) Micro seconds
packets2	(Optional) Packets
conform	(Optional) Specify a conform action
exceed	(Optional) Specify a exceed action
violate	(Optional) Specify a violate action
transmit	(Optional) Transmit packet
transmit1	(Optional) Transmit packet
drop1	(Optional) Drop packet
drop2	(Optional) Drop packet
set-prec-transmit	(Optional) Set precedence and send it
set-prec-transmit1	(Optional) Set precedence and send it
set-prec-transmit2	(Optional) Set precedence and send it
<i>prec-val</i>	(Optional) Precedence value
<i>prec-val1</i>	(Optional) Precedence value
<i>prec-val2</i>	(Optional) Precedence value
<i>prec-enum</i>	(Optional)
<i>prec-enum1</i>	(Optional)

<i>prec-enum2</i>	(Optional)
<i>set-dscp-transmit</i>	(Optional) Set dscp and send it
<i>set-dscp-transmit1</i>	(Optional) Set dscp and send it
<i>set-dscp-transmit2</i>	(Optional) Set dscp and send it
<i>dscp-val</i>	(Optional) DSCP value
<i>dscp-val1</i>	(Optional) DSCP value
<i>dscp-val2</i>	(Optional) DSCP value
<i>dscp-enum</i>	(Optional)
<i>dscp-enum1</i>	(Optional)
<i>dscp-enum2</i>	(Optional)
<i>set-cos-transmit</i>	(Optional) Set cos and send it
<i>set-cos-transmit1</i>	(Optional) Set cos and send it
<i>set-cos-transmit2</i>	(Optional) Set cos and send it
<i>cos-val</i>	(Optional) new cos value
<i>cos-val1</i>	(Optional) new cos value
<i>cos-val2</i>	(Optional) new cos value
<i>set-discard-class-transmit</i>	(Optional) Set discard class and send it
<i>set-discard-class-transmit1</i>	(Optional) Set discard class and send it
<i>set-discard-class-transmit2</i>	(Optional) Set discard class and send it
<i>disc-class-val</i>	(Optional) new discard-class value
<i>disc-class-val1</i>	(Optional) new discard-class value
<i>disc-class-val2</i>	(Optional) new discard-class value
<i>set-qos-transmit</i>	(Optional) Set qos-group and send it
<i>set-qos-transmit1</i>	(Optional) Set qos-group and send it
<i>set-qos-transmit2</i>	(Optional) Set qos-group and send it
<i>qos-grp-val</i>	(Optional) QoS group value
<i>qos-grp-val1</i>	(Optional) QoS group value
<i>qos-grp-val2</i>	(Optional) QoS group value
<i>set-mpls-exp-imposition-transmit</i>	(Optional) set-mpls-exp-imposition-transmit

set-mpls-exp-imposition-transmit1	(Optional) set-mpls-exp-imposition-transmit
set-mpls-exp-imposition-transmit2	(Optional) set-mpls-exp-imposition-transmit
<i>exp-value-imp</i>	(Optional) MPLS imposition value
<i>exp-value-imp1</i>	(Optional) MPLS imposition value
<i>exp-value-imp2</i>	(Optional) MPLS imposition value
set-mpls-exp-topmost-transmit	(Optional) Set MPLS topmost label
set-mpls-exp-topmost-transmit1	(Optional) Set MPLS topmost label
set-mpls-exp-topmost-transmit2	(Optional) Set MPLS topmost label
<i>exp-value-top</i>	(Optional) MPLS topmost value
<i>exp-value-top1</i>	(Optional) MPLS topmost value
<i>exp-value-top2</i>	(Optional) MPLS topmost value
set	(Optional) Set a particular value using table or markdown map
<i>exc-frm-field</i>	(Optional)
<i>exc-to-field</i>	(Optional)
<i>vio-frm-field</i>	(Optional)
<i>vio-to-field</i>	(Optional)
table	(Optional) Set using the table-map
table2	(Optional) Set using the table-map
cir-markdown-map	(Optional) Markdown map table name for exceed action
pir-markdown-map	(Optional) Markdown map table name for violate action
aggregate	Choose aggregate policer for current class
<i>policer-name</i>	Enter aggregate-policer name

Command Mode

- /exec/configure/policy-map/class

police

```
[no] police [ { { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } { [ { [ bc ]
<bc-val> [ <opt_kbytes_mbytes_gbytes_bc> ] } ] } { [ { pir { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] |
percent1 <pir-perc> } } { [ { be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] } ] } { [ { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } } { [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dsep3 dsep4 table1 pir-markdown-map } } } ] } } ] ] }
```

Syntax Description

no	Negate a command or set its defaults
police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional) Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value
<i>opt_set_prec</i>	(Optional)

exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map

Command Mode

- /exec/configure/pmap/class

police police pps

police police pps

```
police { [ cir ] { <cir-val> [ <opt_kbps_mbps_gb_ps_pps_cir> ] | percent <cir-perc> } } { [ { [ bc ] <bc-val> [ <opt_kbytes_mbytes_gbytes_bc> ] } ] } { [ { pir { <pir> [ <opt_kbps_mbps_gb_ps_pps_pir> ] | percent1 <pir-perc> } } [ { [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] } ] } { [ { conform { <opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> | <opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } } [ { exceed { <opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate { <opt_drop_transmit_violate> | { set1 dsep3 dsep4 table1 pir-markdown-map } } } ] ] } | police { pps { <pps-val> } }
```

Syntax Description

police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gb_ps_pps_cir</i>	(Optional) Units
percent	Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gb_ps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value
<i>opt_set_prec</i>	(Optional)

exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map
pps	Specify PPS rate limit

Command Mode

- /exec/configure/pmap/class

policy-map

[no] policy-map [type qos] [match-first] <pmap-name-qos>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	(Optional) Specify the type of this policy-map
qos	(Optional) Qos policy
match-first	(Optional) Take the action for the first class that matches
<i>pmap-name-qos</i>	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy-map type control-plane

[no] policy-map type control-plane <pmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
control-plane	Control-Plane
<i>pmap-name</i>	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

```
■ policy-map type network-qos
```

policy-map type network-qos

[no] policy-map type network-qos <pmap-name-nq>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
network-qos	Network QoS policy
<i>pmap-name-nq</i>	Policy-map name

Command Mode

- /exec/configure

policy-map type psp

[no] policy-map type psp { <pmap-name-plc> | { handle <ppf_id> } } [table <table_type>] [client <clienttype> <clientID>]

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
psp	PSP policy
<i>pmap-name-plc</i>	Policy-map name (alphanumeric)
handle	Handle
<i>ppf_id</i>	PPF ID
table	(Optional) table
<i>table_type</i>	(Optional) Table Type
client	(Optional) set client type
<i>clienttype</i>	(Optional) cli/onep
<i>clientID</i>	(Optional) client appID

Command Mode

- /exec/configure

policy-map type queuing

policy-map type queuing

[no] policy-map type queuing [match-first] <pmap-name-que>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
queuing	Queueing policy
match-first	(Optional) Take the action for the first class that matches
<i>pmap-name-que</i>	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy

```
policy { { dynamic identity <device-id> } | { static sgt <sgt> [ trusted ] } } | no policy static | no policy dynamic
```

Syntax Description

policy	Enable and define policy to be applied
dynamic	apply to authorization server for policy
identity	specify identity of peer for authorization request
<i>device-id</i>	peer's device-id
static	configure static policy
sgt	SGT tag for pkts from this device
<i>sgt</i>	sgt value
trusted	(Optional) specify trust state of the link

Command Mode

- /exec/configure/cts-manual

policy

[no] policy <name>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy	NBM Flow policy
<i>name</i>	Policy name

Command Mode

- /exec/configure/nbm-flow-policy

pop

pop [<name>]

Syntax Description

pop	pop mode from stack or restore from name
<i>name</i>	(Optional) name

Command Mode

- /global

port-channel limit

port-channel limit | no port-channel limit

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure the maximum number of supported vPCs
limit	limit to 244 vPCs

Command Mode

- /exec/configure/vpc-domain

port-channel load-balance

```
port-channel load-balance <bndl_hash> <bndl_sel> [ rotate <po-lb-rotate-range> ] [ concatenation ] [ module <module> | fex all ] [ symmetric ] | no port-channel load-balance [ <bndl_hash> <bndl_sel> [ rotate <po-lb-rotate-range> ] [ concatenation ] [ module <module> | fex all ] [ symmetric ] ]
```

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
<i>bndl_hash</i>	bundle hash
<i>bndl_sel</i>	bundle select
rotate	(Optional) offset the hash-input
<i>po-lb-rotate-range</i>	(Optional) offset the hash-input
concatenation	(Optional) enable/disable concatenation
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
fex	(Optional) FEX devices
all	(Optional) Permit all FEX to configure port-channel LB
symmetric	(Optional) symmetric load balancing

Command Mode

- /exec/configure

port-channel load-balance1 ethernet

port-channel load-balance1 ethernet

port-channel load-balance1 ethernet <algorithm> [symmetric] | no port-channel load-balance1 ethernet [<algorithm> [symmetric]]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance1	Configure port-channel load balance
ethernet	Ethernet port-channel
<i>algorithm</i>	Configure port-channel load balance
symmetric	(Optional) symmetric load balancing

Command Mode

- /exec/configure

port-channel load-balance2 resilient

port-channel load-balance2 resilient | no port-channel load-balance2 resilient

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance2	Configure port-channel load balance
resilient	Configure port-channel load balance resilient mode

Command Mode

- /exec/configure

port-channel load-balance ethernet

port-channel load-balance ethernet

port-channel load-balance ethernet <algorithm> [module <module>] | no port-channel load-balance ethernet
[<algorithm> [module <module>]]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
ethernet	Ethernet port-channel
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>algorithm</i>	Configure port-channel load balance

Command Mode

- /exec/configure

port-channel load-balance hash-modulo-f2

[no] port-channel load-balance hash-modulo-f2

Syntax Description

no	(Optional) Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
hash-modulo-f2	Enable/disable modulo hash for N7K-F248XP cards

Command Mode

- /exec/configure

port-channel load-balance hash enable

port-channel load-balance hash enable

[no] port-channel load-balance hash enable

Syntax Description

no	(Optional) Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
hash	hash enhancement
enable	enable

Command Mode

- /exec/configure

port-group

{ port-group <name> } | { no port-group <name> }

Syntax Description

no	Negate a command or set its defaults
port-group	smart channel port group
<i>name</i>	smart channel port group name

Command Mode

- /exec/configure/smarte

port-group

{ port-group <name> } | { no port-group <name> }

Syntax Description

no	Negate a command or set its defaults
port-group	catena port group
<i>name</i>	catena port group name

Command Mode

- /exec/configure/catena

port-profile

[no] port-profile [type <typeval>] { <profilename> | <s0> }

Syntax Description

no	(Optional) Negate a command or set its defaults
port-profile	Configure a port-profile
<i>profilename</i>	Enter the name of the profile
<i>s0</i>	Enter the name of the profile
type	(Optional) configure type of the profile
<i>typeval</i>	(Optional)

Command Mode

- /exec/configure

port-profile dump

port-profile dump

[no] port-profile dump

Syntax Description

no	(Optional) Negate a command or set its defaults
port-profile	Dump port-profile
dump	Dump all additional information from database

Command Mode

- /exec

port-profile no-redirection

[no] port-profile no-redirection

Syntax Description

no	(Optional) Negate a command or set its defaults
port-profile	Show port-profile information
no-redirection	Disable port-profile redirection

Command Mode

- /exec

port-security stop learning

[no] port-security stop learning

Syntax Description

no	(Optional) Negate a command or set its defaults
port-security	Port security related command
stop	stop
learning	learning

Command Mode

- /exec

port

{ port <sport> <dport> }

Syntax Description

port	L4 port info
<i>sport</i>	Source port
<i>dport</i>	Destination port

Command Mode

- /exec/configure/configngamccpayload

port

{ port <tportnum> } | { no port [<tportnum-ignore>] }

Syntax Description

no	Negate a command or set its defaults
port	Port number
<i>tportnum</i>	Port number, default: 15002
<i>tportnum-ignore</i>	(Optional) Port number, default: 15002

Command Mode

- /exe/configure/onep/tls

port control

[no] port control <port-control-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
port	ITD port
control	control
<i>port-control-name</i>	Port control name

Command Mode

- /exec/configure/itd-inout

port control

[no] port control <port-control-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
port	Configure PLB port control
control	control
<i>port-control-name</i>	Port control name

Command Mode

- /exec/configure/plb-inout

port destination

{ port { destination | source } <port> } | { no port { destination | source } }

Syntax Description

no	Negate a command or set its defaults
port	specify flow port address
source	specify flow source port address
destination	specify flow destination port address
<i>port</i>	port number

Command Mode

- /exec/configure/configngoaamprofileflow

port type ethernet

[no] port <port-range> type { ethernet | fc }

Syntax Description

no	(Optional) Negate a command or set its defaults
port	Configure a port
<i>port-range</i>	Enter a port range
type	Configure a port type
ethernet	Ethernet Port
fc	FC Port

Command Mode

- /exec/configure/slot

power efficient-ethernet auto

[no] power efficient-ethernet auto

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure EEE for the port
efficient-ethernet	Configure Energy Efficient Ethernet (EEE)
auto	Auto negotiate EEE

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

power efficient-ethernet sleep threshold aggressive

power efficient-ethernet sleep threshold aggressive

[no] power efficient-ethernet sleep threshold aggressive

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure EEE for the port
efficient-ethernet	Configure Energy Efficient Ethernet (EEE)
sleep	EEE LPI sleep configuration
threshold	EEE LPI sleep threshold
aggressive	Enable/ Disable EEE LPI aggressive sleep mode

Command Mode

- /exec/configure/if-ether-all /exec/configure/if-eth-base

power inline

```
{ power inline { <port-mode-never> | <port-mode> [ max <wattage> ] } } | { no power inline { <port-mode-never> | <port-mode> } }
```

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
<i>port-mode-never</i>	configure POE port mode
<i>port-mode</i>	configure POE port mode
max	(Optional) Configure the max power per interface
<i>wattage</i>	(Optional) milli-watts

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-etherent-all

power inline default_consumption

power inline default_consumption

{ power inline default_consumption <wattage> } | { no power inline default_consumption }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
default_consumption	POE port default consumption
wattage	milli-watts

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

power inline police action

{ power inline police action <police-action> } | { no power inline police action }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
police	Configure POE port police parameters
action	Configure action in port when power allocation exceeds
<i>police-action</i>	configure POE port action

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ether-all

power inline port priority

power inline port priority

{ power inline port priority <port-priority> } | { no power inline port priority <port-priority> }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
port	Configure POE port parameters
priority	Configure the priority for the port
<i>port-priority</i>	configure POE port priority

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ether-all

power redundancy-mode combined

[no] power redundancy-mode combined

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
combined	Configure power supply redundancy mode as combined

Command Mode

- /exec/configure

power redundancy-mode combined force

power redundancy-mode combined force

[no] power redundancy-mode combined force

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
combined	Configure power supply redundancy mode as combined
force	Force combined mode without prompting

Command Mode

- /exec/configure

power redundancy-mode insrc-redundant

[no] power redundancy-mode insrc-redundant

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
insrc-redundant	Configure power supply redundancy mode as grid/AC input source redundant

Command Mode

- /exec/configure

power redundancy-mode ps-redundant

power redundancy-mode ps-redundant

[no] power redundancy-mode ps-redundant

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
ps-redundant	Configure power supply redundancy mode as PS redundant

Command Mode

- /exec/configure

pps

pps <pps> <burst> | no pps [<pps>] [<burst>]

Syntax Description

no	Negate a command or set its defaults
pps	OSPF packets per second
<i>pps</i>	Packets per second value
<i>burst</i>	Burst value

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

pps

pps <pps> <burst> | no pps [<pps>] [<burst>]

Syntax Description

no	Negate a command or set its defaults
pps	OSPFv3 packets per second
<i>pps</i>	Packets per second value
<i>burst</i>	Burst value

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

precision milliseconds

{ { no | default } precision | precision { milliseconds | microseconds } }

Syntax Description

no	
<i>precision</i>	milliseconds
default	Set a command to its defaults
precision	Set precision of measurement
microseconds	Precision microseconds
milliseconds	Precision milliseconds

Command Mode

- /exec/configure/ip-sla/jitter

preempt

[no] preempt [delay { minimum <min-delay> }]

Syntax Description

no	(Optional) Negate a command or set its defaults
preempt	Overthrow lower priority designated routers
delay	(Optional) Wait before preempting
minimum	(Optional) Delay atleast this long
<i>min-delay</i>	(Optional) Number of seconds for minimum delay

Command Mode

- /exec/configure/if-eth-any/glbp

preempt

[no] preempt | preempt

Syntax Description

no	Negate a command or set its defaults
preempt	Enable preemption of lower priority Master

Command Mode

- /exec/configure/if-eth-any/vrrpv3

preempt

[no] preempt

Syntax Description

no	(Optional) Negate a command or set its defaults
preempt	Enable preemption of lower priority master

Command Mode

- /exec/configure/if-eth-any/vrrp

preempt delay minimum

[no] preempt delay | preempt delay minimum <secs>

Syntax Description

no	Negate a command or set its defaults
preempt	Enable preemption of lower priority Master
delay	Wait before preempting
minimum	Delay at least this long
<i>secs</i>	Seconds to delay

Command Mode

- /exec/configure/if-eth-any/vrrpv3

```
preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt
delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload minimum preempt delay minimum preempt
delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt
```

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

preempt delay minimum <min-delay> reload <rel-delay> sync <sync-delay> | preempt delay reload <rel-delay>
minimum <min-delay> sync <sync-delay> | preempt delay sync <sync-delay> minimum <min-delay> reload
<rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> minimum <min-delay> | preempt delay
sync <sync-delay> reload <rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> | preempt delay sync
<sync-delay> reload <rel-delay> | preempt delay minimum <min-delay> sync <sync-delay> | preempt delay
sync <sync-delay> minimum <min-delay> | preempt delay minimum <min-delay> reload <rel-delay> | preempt
delay reload <rel-delay> minimum <min-delay> | preempt delay minimum <min-delay> | preempt delay
reload <rel-delay> | preempt delay sync <sync-delay> | preempt | no preempt | no preempt delay [{ minimum
[<min-delay>] [[reload [<rel-delay>] [sync [<sync-delay>]]] [sync [<sync-delay>]] [reload [
<rel-delay>]]] | reload [<rel-delay>] [[minimum [<min-delay>]] [sync [<sync-delay>]]] [sync [
<sync-delay>]] [minimum [<min-delay>]]] | sync [<sync-delay>] [[reload [<rel-delay>]] [minimum
[<min-delay>]] [minimum [<min-delay>] [reload [<rel-delay>]]]] }]

Syntax Description

no	Negate a command or set its defaults
preempt	Overthrow lower priority Active routers
delay	Wait before preempting
minimum	Delay at least this long
<i>min-delay</i>	Number of seconds for minimum delay
reload	Delay after reload
<i>rel-delay</i>	Number of seconds for reload delay
sync	Wait for IP redundancy clients
<i>sync-delay</i>	Number of seconds for sync delay

Command Mode

P Commands

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay sync preempt delay sync minimum preempt delay reload minimum preempt delay sync minimum preempt delay sync preempt

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

preference max

preference max

[no] preference max <pref-val>

Syntax Description

no	(Optional) Negate a command or set its defaults
<i>pref-val</i>	maximum value

Command Mode

- /exec/configure/config-dhcp-guard

preference min

[no] preference min <pref-val>

Syntax Description

no	(Optional) Negate a command or set its defaults
<i>pref-val</i>	maximum value

Command Mode

- /exec/configure/config-dhcp-guard

prefix out

[no | default] { prefix-list <prfxlist-name> } { out | in }

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
prefix-list	Apply prefix-list
<i>prfxlist-name</i>	Name of prefix-list
out	Apply policy to outgoing routes
in	Apply policy to incoming routes

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-link-state
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

priority-flow-control auto-restore multiplier

[no] priority-flow-control auto-restore multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
auto-restore	auto restore
multiplier	Auto restore multiplier
<i>val</i>	Auto multiplier value

Command Mode

- /exec/configure

priority-flow-control fixed-restore multiplier

priority-flow-control fixed-restore multiplier

[no] priority-flow-control fixed-restore multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
fixed-restore	fixed restore
multiplier	Fixed restore multiplier
<i>val</i>	Fixed multiplier value

Command Mode

- /exec/configure

priority-flow-control mode

[no] priority-flow-control mode { auto | on | off } [force]

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Enable/Disable PFC
mode	PFC Mode
auto	Set Auto Mode
on	Force PFC to On
off	Force PFC to Off
force	(Optional) Force apply PFC config

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel
/exec/configure/if-port-channel-sub

```
priority-flow-control override-interface mode off
```

priority-flow-control override-interface mode off

[no] priority-flow-control override-interface mode off

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Global priority-flow-control settings
override-interface	Overrides interface priority-flow-control mode
mode	Priority-flow-control mode
off	Off

Command Mode

- /exec/configure

priority-flow-control recover interface

priority-flow-control recover interface <if_list> [qos-group <qgrp-num>] [module <module_idx>] [instance <inst>]

Syntax Description

priority-flow-control	Change PFC settings
recover	Recover PFC queue from stuck state
interface	Interface
<i>if_list</i>	List of interfaces
qos-group	(Optional) No-drop class to be recovered
<i>qgrp-num</i>	(Optional) qos-group number of the no-drop class
module	(Optional) Slot/module
<i>module_idx</i>	(Optional) Slot/module number
instance	(Optional) ASIC Instance Number
<i>inst</i>	(Optional) ASIC Instance Number in Decimal

Command Mode

- /exec

```
priority-flow-control watch-dog-interval on
```

priority-flow-control watch-dog-interval on

[no] priority-flow-control watch-dog-interval { on | off }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	Enable/Disable PFC
watch-dog-interval	Watch dog interval
on	Enable PFC watch-dog interval globally
off	Disable PFC watch-dog interval globally

Command Mode

- /exec/configure

priority-flow-control watch-dog-interval on

[no] priority-flow-control watch-dog-interval { on [disable-action] [interface-multiplier <multiplier-val>] | off }

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Enable/Disable PFC
watch-dog-interval	Watch dog interval
on	PFC watch-dog interval to On
disable-action	(Optional) Only generate syslog for stuck queue, no action
interface-multiplier	(Optional) Shutdown multiplier value
<i>multiplier-val</i>	(Optional) Shutdown mutlipler value
off	PFC watch-dog interval to Off

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel
 /exec/configure/if-port-channel-sub

priority-flow-control watch-dog forced on

priority-flow-control watch-dog forced on

[no] priority-flow-control watch-dog forced { on | off }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
forced	Force enable watch-dog behaviour globally
on	Enable PFC watch-dog globally
off	Disable PFC watch-dog globally

Command Mode

- /exec/configure

priority-flow-control watch-dog interval

[no] priority-flow-control watch-dog interval <interval-val>

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
interval	Poll interval
<i>interval-val</i>	Watch dog interval value in ms

Command Mode

- /exec/configure

```
priority-flow-control watch-dog shutdown-multiplier
```

priority-flow-control watch-dog shutdown-multiplier

[no] priority-flow-control watch-dog shutdown-multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
shutdown-multiplier	Shutdown multiplier
<i>val</i>	Shutdown multiplier

Command Mode

- /exec/configure

priority

[no] priority | priority <val>

Syntax Description

no	Negate a command or set its defaults
priority	Priority of this VRRP group
<i>val</i>	Priority level

Command Mode

- /exec/configure/if-eth-any/vrrpv3

priority2

[no] priority2 [level2 <value>]

Syntax Description

no	(Optional) Negate a command or set its defaults
priority2	Configure traffic class priority
level2	(Optional) Specify level of priority
<i>value</i>	(Optional) Strict-priority level (1=hi 2=med 3=lo)

Command Mode

- /exec/configure/policy-map/type/queuing/class

priority

[no] priority | priority <setup_prio> [<hold_prio>]

Syntax Description

no	Negate a command or set its defaults
priority	Specify LSP priority
<i>setup_prio</i>	setup priority
<i>hold_prio</i>	(Optional) hold priority

Command Mode

- /exec/configure/te/lsp-attr

priority

[no] priority | priority <setup_pri> [<hold_pri>]

Syntax Description

no	Negate a command or set its defaults
priority	tunnel priority
<i>setup_pri</i>	setup priority
<i>hold_pri</i>	(Optional) hold priority

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

priority

priority <priority> [forwarding-threshold lower <lower-value> upper <upper-value>] | no priority [forwarding-threshold]

Syntax Description

no	Negate a command or set its defaults
priority	Priority level
<i>priority</i>	Priority value
forwarding-threshold	(Optional) Set forwarding threshold
lower	(Optional) Set lower threshold value
<i>lower-value</i>	(Optional) Lower threshold value
upper	(Optional) Set upper threshold value
<i>upper-value</i>	(Optional) Upper threshold value

Command Mode

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

priority

priority <value> | no priority

Syntax Description

no	Negate a command or set its defaults
priority	Configure Bundle priority
<i>value</i>	Priority value

Command Mode

- /exec/configure/anycast

priority

[no] priority [level <value>]

Syntax Description

no	(Optional) Negate a command or set its defaults
priority	Configure traffic class priority
level	(Optional) Specify level of priority
<i>value</i>	(Optional) Value of level, lower the number higher the priority

Command Mode

- /exec/configure/policy-map/type/queuing/class

priority

{ priority <pri-value> } | { no priority }

Syntax Description

no	Negate a command or set its defaults
priority	Priority level
<i>pri-value</i>	Priority Value

Command Mode

- /exec/configure/if-eth-any/glbp

priority

{ priority <priority_value> [forwarding-threshold lower <lower-value> upper <upper-value>] | no priority [forwarding-threshold] }

Syntax Description

no	Negate a command or set its defaults
priority	Configure the vr priority
<i>priority_value</i>	Configure the vr priority
forwarding-threshold	(Optional) Set forwarding threshold
lower	(Optional) Set lower threshold value
<i>lower-value</i>	(Optional) Lower threshold value
upper	(Optional) Set upper threshold value
<i>upper-value</i>	(Optional) Upper threshold value

Command Mode

- /exec/configure/if-eth-any/vrrp

private-vlan

[no] private-vlan <pvlan-type>

Syntax Description

no	(Optional) Negate a command or set its defaults
private-vlan	Configure a private VLAN
<i>pvlan-type</i>	PVLAN Type

Command Mode

- /exec/configure/vlan

private-vlan association

```
{ private-vlan association [ { add | remove } ] <secondary_vlans> } | { no private-vlan association [ <secondary_vlans> ] }
```

Syntax Description

private-vlan	Configure a private VLAN
association	Add association between private VLANs
add	(Optional) Add a VLAN to private VLAN list
remove	(Optional) Remove a VLAN from private VLAN list
no	Negate a command or set its defaults
<i>secondary_vlans</i>	VLAN IDs of the private VLANs to be configured

Command Mode

- /exec/configure/vlan

private-vlan mapping

{ private-vlan mapping [{ add | remove }] <secondary_vlans> } | { no private-vlan mapping [<secondary_vlans>] }

Syntax Description

private-vlan	Configure a private VLAN
mapping	Set the private VLAN interface mapping
add	(Optional) Add a VLAN to private VLAN list
remove	(Optional) Remove a VLAN from private VLAN list
no	Negate a command or set its defaults
<i>secondary_vlans</i>	Secondary VLAN IDs of the private VLAN interface mapping

Command Mode

- /exec/configure/if-vlan

private-vlan release resource

```
private-vlan release resource { [ vlan <vlan-id> ] | global }
```

Syntax Description

private-vlan	Show information about private VLAN
release	release
resource	resource
vlan	(Optional) VLAN status
global	global rid
<i>vlan-id</i>	(Optional) VLAN IDs of the private VLANs to be configured

Command Mode

- /exec

private-vlan synchronize

private-vlan synchronize

private-vlan synchronize

Syntax Description

private-vlan	Set private-vlan synchronization
synchronize	Synchronize vlans

Command Mode

- /exec/configure/spanning-tree/mst/configuration

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

no	Negate a command or set its defaults
probe-interval	OpenFlow controller probe interval timer (default is 180 seconds)
<i>probeinterval-val</i>	probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch

probe-interval

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

no	Negate a command or set its defaults
probe-interval	OpenFlow controller probe interval timer (default is 180 seconds)
<i>probeinterval-val</i>	probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch/sub-switch

probe

[no] probe <probe-id> [control <status>] [host <host-name>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>]

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Catena device-group node probe
<i>probe-id</i>	Probe mode
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
host	(Optional) Host name/Target address
<i>host-name</i>	(Optional) DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count
ip	(Optional) Configure ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count
ip	(Optional) Configure ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id-icmp</i>	Service mode
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/plb-device-group

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	PLB probe
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared down
<i>up-count</i>	(Optional) Count
ip	(Optional) Configure ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	PLB probe
<i>probe-id-dns</i>	Service mode
host	Host name/Target address
<i>host-name</i>	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/plb-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	TCP/UDP Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/plb-device-group

probe port

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for PLB device group node
<i>probe-id</i>	Service mode
port	TCP/UDP Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count
ip	(Optional) Configure ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe port

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
<i>probe-id</i>	Service mode
port	TCP/UDP Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Configure probe frequency for a node
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
<i>up-count</i>	(Optional) Count
ip	(Optional) Configure ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

profile

{ profile <pid> | no profile }

Syntax Description

no	Negate a command or set its defaults
profile	NGOAM profile to use
<i>pid</i>	NGOAM profile id

Command Mode

- /exec/configure/configngoamconnectcheck

promiscuous-mode off

promiscuous-mode off

promiscuous-mode { off | on } | no promiscuous-mode [{ off | on }]

Syntax Description

no	Negate a command or set its defaults
promiscuous-mode	Configure promiscuous mode for the port
off	Disable promiscuous mode
on	Enable promiscuous mode

Command Mode

- /exec/configure/if-port-channel /exec/configure/if-ethernet-all /exec/configure/if-eth-base

propagate-sgt

[no] propagate-sgt

Syntax Description

propagate-sgt	Enable SGT propagation from this port (the default use the no form to disable)
---------------	--

Command Mode

- /exec/configure/cts-dot1x /exec/configure/cts-manual

protection

[no] protection | protection [fast-reroute [bw-protect]]

Syntax Description

no	Negate a command or set its defaults
protection	Enable failure protection
fast-reroute	(Optional) Enable fast-reroute failure protection
bw-protect	(Optional) Enable BW protection

Command Mode

- /exec/configure/te/lsp-attr

proto

```
{ proto <proto-id> }
```

Syntax Description

proto	Protocol
<i>proto-id</i>	IANA Protocol id

Command Mode

- /exec/configure/configngamccpayload

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

no	Negate a command or set its defaults
protocol-version	Set OpenFlow protocol version
10	Use only OF 1.0 protocol to connect to controller
13	Use only OF 1.3 protocol to connect to controller
negotiate	Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch/sub-switch

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

no	Negate a command or set its defaults
protocol-version	Set OpenFlow protocol version
10	Use only OF 1.0 protocol to connect to controller
13	Use only OF 1.3 protocol to connect to controller
negotiate	Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch

protocol

[no] protocol <proto> [prefix-list <pplist-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
<i>proto</i>	
<i>pplist-name</i>	(Optional) Name of the prefix-list to be matched

Command Mode

- /exec/configure/config-snoop-policy

protocol

{ protocol <num> } | { no protocol }

Syntax Description

no	Negate a command or set its defaults
protocol	specify flow protocol number
<i>num</i>	flow protocol number

Command Mode

- /exec/configure/configngoaamprofileflow

protocol shutdown

[no] protocol shutdown

Syntax Description

no	(Optional) Negate a command or set its defaults
protocol	OSPF protocol
shutdown	Shutdown the OSPF protocol instance

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

protocol shutdown

[no] protocol shutdown

Syntax Description

no	(Optional) Negate a command or set its defaults
protocol	OSPF protocol
shutdown	shutdown the OSPF protocol instance

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

ptp

[no] ptp

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp announce timeout

[no] ptp announce timeout { <val> | smpte-2059-2 <smpte-val> | aes67 <aes-val> }

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
announce	announce
timeout	timeout
smpte-2059-2	SMPTE-2059-2
aes67	AES67-2015
<i>val</i>	
<i>smpte-val</i>	SMPTE-2059-2 val
<i>aes-val</i>	AES67-2015 val

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-etherent-all

ptp bad_correction

ptp bad_correction

[no] ptp bad_correction <value>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
bad_correction	set bad correction threshold value
<i>value</i>	correction threshold (ns) [-value, +value] when exceeding would trigger syslog message, default 100000

Command Mode

- /exec/configure

ptp bad_correction logging

[no] ptp bad_correction logging

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
bad_correction	set bad correction threshold value
logging	enable logging for bad corrections

Command Mode

- /exec/configure

ptp clock-sync auto

[no] ptp clock-sync auto

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
clock-sync	clock-sync
auto	auto adjust frequency

Command Mode

- /exec/configure

ptp correction hardware

[no] ptp correction hardware

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem
correction	Corrections for PTP
hardware	Frequency correction from hardware or software

Command Mode

- /exec/configure

ptp domain

[no] ptp domain <domain-val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
domain	ptp clock domain
<i>domain-val</i>	Enter domain value

Command Mode

- /exec/configure

ptp multicast master-only

[no] ptp multicast master-only

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
multicast	multicast
master-only	master only

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp offload

[no] ptp offload

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
offload	Allows increasing number of PTP sessions per system by offloading some timers to linecard

Command Mode

- /exec/configure

ptp priority1

[no] ptp priority1 <val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
priority1	priority1
<i>val</i>	priority1

Command Mode

- /exec/configure

ptp priority2

ptp priority2

[no] ptp priority2 <val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
priority2	priority1
<i>val</i>	priority2

Command Mode

- /exec/configure

ptp send announce

ptp send announce

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
send	Sending announce packets
announce	Sending announce packets

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp source

[no] ptp source <src-ip> [vrf { <vrf-name> | <vrf-cfg-name> }]

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
source	source IP address
<i>src-ip</i>	IPv4 address (A.B.C.D) of source
vrf	(Optional) vrf to be used for hello messages
<i>vrf-name</i>	(Optional) vrf to be used for hellos
<i>vrf-cfg-name</i>	(Optional) Configurable VRF name

Command Mode

- /exec/configure

ptp time-sync

[no] ptp time-sync <value>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
time-sync	ptp time sync register
<i>value</i>	default reg value 0x40000000

Command Mode

- /exec/configure

```
ptp transport ipv4 ucast master
```

ptp transport ipv4 ucast master

[no] ptp transport ipv4 ucast master

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem
transport	unicast support
ipv4	ipv4
ucast	ipv4 unicast
master	master mode

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp transport ipv4 ucast slave

[no] ptp transport ipv4 ucast slave

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem
transport	unicast support
ipv4	ipv4
ucast	ipv4 unicast
slave	slave mode

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp ucast-source

ptp ucast-source

[no] ptp ucast-source <src-ip> [vrf { <vrf-name> | <vrf-cfg-name> }]

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
ucast-source	source IP address for ucast messages
<i>src-ip</i>	IPv4 address (A.B.C.D) of source
vrf	(Optional) vrf to be used for hello messages
<i>vrf-name</i>	(Optional) vrf to be used for hellos
<i>vrf-cfg-name</i>	(Optional) Configurable VRF name

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp vlan

[no] ptp vlan <vlan>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
vlan	vlan
<i>vlan</i>	vlan

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

publish-event sub-system type

publish-event sub-system <sub-system-id> type <event-type> { [arg1 <data1>] [arg2 <data2>] [arg3 <data3>] [arg4 <data4>] }

Syntax Description

publish-event	Publish an application specific event
sub-system	Sub-system ID to which the application event belongs
<i>sub-system-id</i>	Sub-system ID value
type	Event type value
<i>event-type</i>	Event type value
arg1	(Optional) User specified data to be passed when the event is published
<i>data1</i>	(Optional) User specified data value
arg2	(Optional) User specified data to be passed when the event is published
<i>data2</i>	(Optional) User specified data value
arg3	(Optional) User specified data to be passed when the event is published
<i>data3</i>	(Optional) User specified data value
arg4	(Optional) User specified data to be passed when the event is published
<i>data4</i>	(Optional) User specified data value

Command Mode

- /exec

purge ip route

```
purge ip route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

purge	Purge
ip	IPv4
route	Purge routing information
vrf	(Optional) VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
all	Purge all routes

Command Mode

- /exec

purge ipv6 route

purge ipv6 route

purge ipv6 route [vrf { <vrf-name> | <vrf-known-name> | <vrf-all> }] <all>

Syntax Description

purge	Purge
ipv6	IPv6
route	Purge routing information
vrf	(Optional) VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
all	Purge all routes

Command Mode

- /exec

push

push [<name>]

Syntax Description

push	push current mode to stack or save it under name
<i>name</i>	(Optional) name

Command Mode

- /global

```
pwd
```

Syntax Description

pwd	View current directory
-----	------------------------

Command Mode

- /exec

python

python [<uri> [<pyargs>] +]

Syntax Description

python	run a python command/script, or enter python mode (if no arg)
<i>uri</i>	(Optional) path to a python file
<i>pyargs</i>	(Optional) python command line arguments (maximum 32)

Command Mode

- /exec

python instance

python instance

[no] python instance <inst> [<uri> [<pyargs>] +] | python instance <inst> <uri> [<pyargs>] +

Syntax Description

no	Negate a command or set its defaults
python	run a python command/script, or enter python mode (if no arg)
instance	label with an instance number
<i>inst</i>	instance number
<i>uri</i>	(Optional) path to a python file
<i>pyargs</i>	(Optional) python command line arguments (maximum 32)

Command Mode

- /exec/configure