



V Commands

- [validate-xml](#), on page 4
- [validate-xml](#), on page 5
- [variance](#), on page 6
- [vdc](#), on page 7
- [vdc](#), on page 8
- [vdc combined-hostname](#), on page 9
- [vdc_id](#), on page 10
- [vdc resource template](#), on page 11
- [vdc suspend](#), on page 12
- [vdc suspend](#), on page 13
- [vdp dot1q default static](#), on page 14
- [vdp dot1q static](#), on page 15
- [vdp vni default static](#), on page 16
- [vdp vni static](#), on page 17
- [vendor controller interop](#), on page 18
- [verify-data](#), on page 19
- [verify-host](#), on page 20
- [verify](#), on page 21
- [verify profile](#), on page 22
- [verify verbose](#), on page 23
- [version](#), on page 24
- [version 9](#), on page 25
- [virtual-service](#), on page 26
- [virtual-service](#), on page 27
- [virtual-service](#), on page 28
- [virtual-service connect name console](#), on page 29
- [virtual-service move name log to](#), on page 30
- [virtual-service reset force](#), on page 31
- [virtual IPv6](#), on page 32
- [virtual IPv6](#), on page 33
- [virtual ip](#), on page 34
- [virtual ip](#), on page 35
- [vlan-consistency-check](#), on page 36

- [vlan](#), on page 37
- [vlan](#), on page 38
- [vlan](#), on page 39
- [vlan access-map](#), on page 40
- [vlan designated priority](#), on page 41
- [vlan filter vlan](#), on page 42
- [vlan root priority](#), on page 43
- [vmtracker connection](#), on page 44
- [vmtracker connection refresh](#), on page 45
- [vmtracker enable](#), on page 46
- [vmtracker fabric auto-config](#), on page 47
- [vmtracker set device-id](#), on page 48
- [vn-segment](#), on page 49
- [vni](#), on page 50
- [vni](#), on page 51
- [vni](#), on page 52
- [vni default dynamic](#), on page 53
- [vni l2](#), on page 54
- [vpc](#), on page 55
- [vpc domain](#), on page 56
- [vpc orphan-port suspend](#), on page 57
- [vpc peer-link](#), on page 58
- [vpc role preempt](#), on page 59
- [vpc suspend](#), on page 60
- [vpc upgrade-done](#), on page 61
- [vpn](#), on page 62
- [vpn id](#), on page 63
- [vrf](#), on page 64
- [vrf](#), on page 65
- [vrf](#), on page 66
- [vrf](#), on page 67
- [vrf](#), on page 68
- [vrf](#), on page 69
- [vrf](#), on page 70
- [vrf](#), on page 71
- [vrf](#), on page 72
- [vrf](#), on page 73
- [vrf](#), on page 74
- [vrf](#), on page 75
- [vrf context](#), on page 76
- [vrf default static](#), on page 77
- [vrf member](#), on page 78
- [vrf member](#), on page 79
- [vrf static](#), on page 80
- [vrrp](#), on page 81
- [vrrp bfd](#), on page 82

- [vrrpv2](#), on page 83
- [vrrpv3](#), on page 84
- [vrrpv3 address-family](#), on page 85
- [vrrpv3 address-family](#), on page 86
- [vrrs leader](#), on page 87
- [vrrs pathway](#), on page 88
- [vsh](#), on page 89
- [vtp](#), on page 90
- [vtp domain](#), on page 91
- [vtp file](#), on page 92
- [vtp mode](#), on page 93
- [vtp password](#), on page 94
- [vtp pruning](#), on page 95
- [vtp version](#), on page 96

validate-xml

| validate-xml

Syntax Description

	Pipe command output to filter
validate-xml	validate an xml output according to .xsd definitions

Command Mode

- /output

validate-xml

| validate-xml

Syntax Description

	Pipe command output to filter
validate-xml	validate an xml output according to .xsd definitions

Command Mode

- /output

variance

{ { variance <variance> } | { no variance [<variance>] } }

Syntax Description

no	Negate a command or set its defaults
variance	Control load balancing variance
<i>variance</i>	Metric variance multiplier

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

vdc

[no] vdc <e-vdc> [force]

Syntax Description

no	Negate a command or set its defaults
vdc	Manage Virtual Device Context
<i>e-vdc</i>	Enter Virtual Device Context <vdc-id>
force	(Optional) Force ungraceful cleanup

Command Mode

- /exec/configure

vdc

```
vdc <e-vdc> [ id <new_id> ] [ type <vtype> ]
```

Syntax Description

vdc	Manage Virtual Device Context
<i>e-vdc</i>	Enter Virtual Device Context <vdc-id>
id	(Optional) force this vdc into a specific id
<i>new_id</i>	(Optional) force this vdc into a specific id
type	(Optional) Create vdc with a special set of services
<i>vtype</i>	(Optional) type of vdc

Command Mode

- /exec/configure

vdc combined-hostname

[no] vdc combined-hostname

Syntax Description

no	(Optional) Negate a command or set its defaults
vdc	Manage Virtual Device Context
combined-hostname	The hostname of non-default vdcs will be <default vdc name>-<nondefault vdc name>

Command Mode

- /exec/configure

vdc_id

[no] vdc_id <id>

Syntax Description

no	Negate a command or set its defaults
vdc_id	Manage Virtual Device Context
<i>id</i>	Enter Virtual Device Context <vdc-id>

Command Mode

- /exec/configure

vdc resource template

[no] vdc resource template { <name> | <res-mgr-template-known-name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
vdc	Manage Virtual Device Context
resource	Configure resource template
template	Configure resource template
<i>name</i>	Resource template name
<i>res-mgr-template-known-name</i>	Resource template name

Command Mode

- /exec/configure

vdc suspend

vdc suspend

[no] vdc <en-vdc> suspend

Syntax Description

vdc	Manage Virtual Device Context
<i>en-vdc</i>	Enter Virtual Device Context <vdc-id>
suspend	Put the vdc in a paused stated. When resumed vdc will use its startup config

Command Mode

- /exec/configure

vdc suspend

vdc <en-vdc> suspend

Syntax Description

vdc	Manage Virtual Device Context
<i>en-vdc</i>	Enter Virtual Device Context <vdc-id>
suspend	Put the vdc in a paused state. When resumed vdc will come up with its startup config

Command Mode

- /exec/configure

vdp dot1q default static

vdp dot1q default static

{ vdp dot1q default { static <profile-name> | dynamic } } | { no vdp dot1q default }

Syntax Description

no	Negate a command or set its defaults
vdp	VDP protocol triggers
static	Static Profile Map: Configure profile name via CLI
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server
dot1q	Dot1Q Encapsulation
default	Default (wildcard). Match any dot1q when there is no specific dot1q mapping configured

Command Mode

- /exec/configure/profile-map /exec/configure/profile-map-global

vdp dot1q static

{ vdp dot1q <vlan-id> { static <profile-name> | dynamic } } | { no vdp dot1q <vlan-id> }

Syntax Description

no	Negate a command or set its defaults
vdp	VDP protocol triggers
static	Static Profile Map: Configure profile name via CLI
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server
dot1q	Dot1Q Encapsulation
<i>vlan-id</i>	

Command Mode

- /exec/configure/profile-map /exec/configure/profile-map-global

vdp vni default static

vdp vni default static

{ vdp vni default { static <profile-name> | dynamic } } | { no vdp vni default }

Syntax Description

no	Negate a command or set its defaults
vdp	VDP protocol triggers
vni	Virtual Network Identifier
static	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI
default	Default (wildcard). Match any vni when there is no specific vni mapping configured

Command Mode

- /exec/configure/profile-map /exec/configure/profile-map-global

vdp vni static

```
{ vdp vni <vni-id> { static <profile-name> | dynamic } } | { no vdp vni <vni-id> }
```

Syntax Description

no	Negate a command or set its defaults
vdp	VDP protocol triggers
vni	Virtual Network Identifier
<i>vni-id</i>	
static	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI

Command Mode

- /exec/configure/profile-map /exec/configure/profile-map-global

vendor controller interop

[no] vendor controller interop

Syntax Description

no	(Optional) Negate a command or set its defaults
vendor	vendor
controller	controller
interop	interop

Command Mode

- /exec/configure

verify-data

{ { no | default } verify-data | verify-data }

Syntax Description

no	
default	Set a command to its defaults
verify-data	Verify data

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/icmpEcho

verify-host

{ verify-host | no verify-host }

Syntax Description

no	Negate a command or set its defaults
verify-host	Verify host reachability - payload info mandatory

Command Mode

- /exec/configure/configngamconnectcheck

verify

verify

Syntax Description

verify	Verify the current configuration session
--------	--

Command Mode

- /exec/configure

verify profile

```
verify profile <all_conf_profile_name> [ __readonly__ TABLE_profile_name <missing_param> ]
```

Syntax Description

verify	Verify the instance with a configuration profile
profile	Name of the configuration profile
<i>all_conf_profile_name</i>	Enter the name of configuration profile
<u>__readonly__</u>	(Optional)
TABLE_profile_name	(Optional)
<i>missing_param</i>	(Optional)

Command Mode

- /exec/configure/param-inst

verify verbose

verify verbose

Syntax Description

verify	Verify the current configuration session
verbose	Verify the current configuration session with more details

Command Mode

- /exec/configure

version

[no] version <s0>

Syntax Description

no	(Optional) Negate a command or set its defaults
version	Version info
s0	Version

Command Mode

- /exec/configure

version 9

version 9

Syntax Description

version	Specify the export version
9	Version 9 Export

Command Mode

- /exec/configure/nfm-exporter

virtual-service

[no] virtual-service

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual-service	Virtual service global settings

Command Mode

- /exec/configure

virtual-service

[no] virtual-service <virt_serv_name>

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual-service	Configure a virtual service
<i>virt_serv_name</i>	Virtual service name

Command Mode

- /exec/configure

virtual-service

```
virtual-service { { install name <virt_serv_name> package <file_uri> [ media <target_media> ] } | { upgrade name <virt_serv_name> package <file_uri> } | { uninstall name <virt_serv_name> } }
```

Syntax Description

virtual-service	Virtualization manager actions
install	Add a virtual service to install database
upgrade	Upgrade a virtual service package to a different version
name	Name of the virtual service
<i>virt_serv_name</i>	Virtual service name
package	Package location
<i>file_uri</i>	File name (with .ova extension) for the virtual service
media	(Optional) Target media to use to explode the virtual service package
<i>target_media</i>	(Optional) Target media
uninstall	Remove a virtual service from the install database

Command Mode

- /exec

virtual-service connect name console

virtual-service connect name <virt_serv_name> { console | aux }

Syntax Description

virtual-service	Virtualization service actions
connect	Request a virtual service shell
name	Name of the virtual service
<i>virt_serv_name</i>	Name of existing virtual service
console	Request a virtual service console shell
aux	Request a virtual service auxiliary console shell

Command Mode

- /exec

virtual-service move name log to

virtual-service move name log to

virtual-service move name <virt_serv_name> { log | core } to <dir_uri>

Syntax Description

virtual-service	Virtualization service actions
move	Move a virtual service log or core files
name	Name of the virtual service
<i>virt_serv_name</i>	Name of existing virtual service
log	Move log files
core	Move core files
to	Destination directory to move log or core files to
<i>dir_uri</i>	Destination directory name

Command Mode

- /exec

virtual-service reset force

virtual-service reset force

Syntax Description

virtual-service	Virtualization service actions
reset	Virtualization reset commands
force	Force a non-recoverable reset of all virtualization files

Command Mode

- /exec

virtual IPv6

[no] virtual IPv6 { <ip-addr> { <prefix> | <netmask> } } [ip | { { udp | tcp } { <port_num> | any } }] [{ advertise } { enable | disable } [active]] [device-group <dgrp_name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual	ITD virtual ip configuration
IPv6	ITD virtual IPv6
<i>prefix</i>	IPV6 prefix length
ip	(Optional) IP Protocol
udp	(Optional) UDP Protocol
tcp	(Optional) TCP Protocol
<i>port_num</i>	(Optional) Port Number
any	(Optional) Any Port Number
advertise	(Optional) advertise
enable	(Optional) Enable
disable	(Optional) Disable
active	(Optional) Advertise route on at least one node active
device-group	(Optional) device-group
<i>dgrp_name</i>	(Optional) VIP device-group name

Command Mode

- /exec/configure/itd

virtual IPv6

[no] virtual IPv6 { <ip-addr> { <prefix> | <netmask> } } [ip | { { udp | tcp } { <port_num> | any } }] [{ arp | advertise } { enable | disable }] [device-group <group-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual	Configure Virtual IP of server nodes for redirection
IPv6	IPv6 address
<i>prefix</i>	IPV6 prefix length
ip	(Optional) IP address
udp	(Optional) UDP port
tcp	(Optional) TCP port
<i>port_num</i>	(Optional) Port Number
any	(Optional) Any Port Number
arp	(Optional) ARP
advertise	(Optional) advertise
enable	(Optional) Enable
disable	(Optional) Disable
device-group	(Optional) Specify device group mapped to VIP
<i>group-name</i>	(Optional) Device-group name mapped to VIP

Command Mode

- /exec/configure/plb

virtual ip

[no] virtual ip { <ip-addr> <ip-mask> } [ip | { { udp | tcp } { <port_num> | any } }] [{ advertise } { enable | disable } [active]] [device-group <dgrp_name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual	ITD virtual ip configuration
ip	ITD virtual ip
<i>ip-addr</i>	IP address in format i.i.i.i
<i>ip-mask</i>	IP network mask in format m.m.m.m
ip	(Optional) IP Protocol
udp	(Optional) UDP Protocol
tcp	(Optional) TCP Protocol
<i>port_num</i>	(Optional) Port Number
any	(Optional) Any Port Number
advertise	(Optional) advertise
enable	(Optional) Enable
disable	(Optional) Disable
active	(Optional) Advertise route on at least one node active
device-group	(Optional) device-group
<i>dgrp_name</i>	(Optional) VIP device-group name

Command Mode

- /exec/configure/itd

virtual ip

[no] virtual ip { <ip-addr> <ip-mask> } [ip | { { udp | tcp } { <port_num> | any } }] [{ arp | advertise } { enable | disable }] [device-group <group-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
virtual	Configure Virtual IP of server nodes for redirection
ip	IPv4 address
<i>ip-addr</i>	IPv4 prefix in format i.i.i.i
<i>ip-mask</i>	IPv4 prefix mask in format m.m.m.m
ip	(Optional) IPv4 address
udp	(Optional) UDP port
tcp	(Optional) TCP port
<i>port_num</i>	(Optional) Port Number
any	(Optional) Any Port Number
arp	(Optional) ARP
advertise	(Optional) advertise
enable	(Optional) Enable
disable	(Optional) Disable
device-group	(Optional) Specify device group mapped to VIP
<i>group-name</i>	(Optional) Device-group name mapped to VIP

Command Mode

- /exec/configure/plb

vlan-consistency-check

[no] vlan-consistency-check

Syntax Description

no	(Optional) Negate a command or set its defaults
vlan-consistency-check	enable vlan consistency check

Command Mode

- /exec/configure/evpn-esi-mh

vlan

[no] vlan <vlan-range>

Syntax Description

no	(Optional) Negate a command or set its defaults
vlan	add vlan to vlan group
<i>vlan-range</i>	range of vlans

Command Mode

- /exec/configure/itd-vlan-grp

vlan

vlan <vlans> | no vlan

Syntax Description

no	Negate a command or set its defaults
vlan	Set allowed fabricpath VLANs for a given anycast bundle
<i>vlans</i>	VLAN IDs of the allowed fabricpath VLANs in the anycast bundle

Command Mode

- /exec/configure/anycast

vlan

[no] vlan <vlan-range>

Syntax Description

no	(Optional) Negate a command or set its defaults
vlan	vlan
<i>vlan-range</i>	range of vlans

Command Mode

- /exec/configure/smartzc /exec/configure/smartz

vlan access-map

vlan access-map

[no] vlan access-map <name> [<seqno>]

Syntax Description

no	(Optional) Negate a command or set its defaults
vlan	Vlan commands
<i>name</i>	List name
access-map	Configure a VLAN access map
<i>seqno</i>	(Optional) Sequence number

Command Mode

- /exec/configure

vlan designated priority

{ vlan <vlan-id> | bridge-domain <bd-id> } designated priority <prio> | no { vlan <vlan-id> | bridge-domain <bd-id> } designated priority [<prio>]

Syntax Description

no	Negate a command or set its defaults
vlan	VLAN Switch Spanning Trees
bridge-domain	Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	Bridge-Domain range, Example: 2,4-5,7,9-11
designated	Set the designated bridge priority for the spanning tree
priority	Set the bridge priority for the spanning tree
<i>prio</i>	bridge priority in increments of 4096

Command Mode

- /exec/configure/spanning-tree/pseudo

vlan filter vlan

vlan filter vlan

[no] vlan filter <name> { vlan-list <vlans> | vlan-list-include-reserved <vlans-include-reserved> }

Syntax Description

no	(Optional) Negate a command or set its defaults
vlan	Vlan commands
filter	Specify access control for packets
<i>name</i>	List name
vlan-list	Specify list of VLANs to apply access control
<i>vlans</i>	List of VLANs
vlan-list-include-reserved	Specify list of VLANs to apply access control
<i>vlans-include-reserved</i>	List of VLANs

Command Mode

- /exec/configure

vlan root priority

{ vlan <vlan-id> | bridge-domain <bd-id> } root priority <prio> | no { vlan <vlan-id> | bridge-domain <bd-id> } root priority [<prio>]

Syntax Description

no	Negate a command or set its defaults
vlan	VLAN Switch Spanning Trees
bridge-domain	Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	Bridge-Domain range, Example: 2,4-5,7,9-11
root	Set the root bridge priority for the spanning tree
priority	Set the bridge priority for the spanning tree
<i>prio</i>	bridge priority in increments of 4096

Command Mode

- /exec/configure/spanning-tree/pseudo

vmtracker connection

[no] vmtracker connection <connection-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vmtracker	Configure vmtracker parameters
connection	Specify a host to connect
<i>connection-name</i>	VM host name

Command Mode

- /exec/configure

vmtracker connection refresh

[no] vmtracker connection <connection-name> refresh

Syntax Description

no	(Optional) Negate a command or set its defaults
vmtracker	Configure vmtracker parameters
connection	Specify a host to connect
<i>connection-name</i>	VM host name
refresh	Refresh all host related information

Command Mode

- /exec/configure

vmtracker enable

[no] vmtracker enable

Syntax Description

no	(Optional) Negate a command or set its defaults
vmtracker	Configure vmtracker feature
enable	Enable vmtracker feature on interface

Command Mode

- /exec/configure/if-switching

vmtracker fabric auto-config

[no] vmtracker fabric auto-config

Syntax Description

no	(Optional) Negate a command or set its defaults
vmtracker	Configure vmtracker parameters
fabric	Enable VM Tracker Fabric paramters
auto-config	Enable VM Tracker Fabric AutoConfiguration

Command Mode

- /exec/configure

vmtracker set device-id

vmtracker set device-id

[no] vmtracker set device-id <dev-id>

Syntax Description

no	(Optional) Negate a command or set its defaults
vmtracker	Configure vmtracker parameters
set	Set vmtracker options
device-id	Set the device-id
<i>dev-id</i>	Device id

Command Mode

- /exec/configure

vn-segment

```
vn-segment { <segment-id> | <zero-segment-id> } | no vn-segment
```

Syntax Description

no	Negate a command or set its defaults
vn-segment	VN Segment id of the VLAN
<i>segment-id</i>	segment-id
<i>zero-segment-id</i>	segment-id

Command Mode

- /exec/configure/vlan

vni

{ vni <id> } | { no vni [<id>] }

Syntax Description

no	Negate a command or set its defaults
vni	Virtual Network Identifier
<i>id</i>	vni, Example: 4096,6099

Command Mode

- /exec/configure/vrf

vni

{ vni <vni-id> | no vni }

Syntax Description

no	Negate a command or set its defaults
vni	Vni
<i>vni-id</i>	Configure vni id

Command Mode

- /exec/configure/configngoaamconnectcheck

vni

[no] vni <vnid-sh>

Syntax Description

no	(Optional) Negate a command or set its defaults
vni	Configure a vni-based static host
<i>vni-id-sh</i>	

Command Mode

- /exec/configure/static-host

vni default dynamic

{ vni default dynamic } | { no vni default }

Syntax Description

no	Negate a command or set its defaults
dynamic	Dynamic Profile Map: Retrieve profile name from the external server
vni	Virtual Network Identifier
default	Default (wildcard). Match any vni when there is no specific vni mapping configured

Command Mode

- /exec/configure/profile-map /exec/configure/profile-map-global

vni l2

[no] vni <vni_id> l2

Syntax Description

no	(Optional) Negate a command or set its defaults
vni	Configure Ethernet VPN ID
<i>vni_id</i>	Specify VNI ID
l2	Layer-2 VNI

Command Mode

- /exec/configure/evpn

vpc

vpc [<vpc_num>] | no vpc [<vpc_num>]

Syntax Description

no	Negate a command or set its defaults
vpc	Virtual Port Channel configuration
<i>vpc_num</i>	(Optional) specify a Virtual Port Channel number

Command Mode

- /exec/configure/if-eth-port-channel-switch

vpc domain

vpc domain <domain_id> | no vpc domain <domain_id>

Syntax Description

no	Negate a command or set its defaults
vpc	Virtual Port Channel configuration
domain	Specify domain
<i>domain_id</i>	domain id

Command Mode

- /exec/configure

vpc orphan-port suspend

[no] vpc orphan-port suspend

Syntax Description

no	(Optional) Negate a command or set its defaults
vpc	Virtual Port Channel configuration
orphan-port	orphan-port (non-vpc port)
suspend	suspend - when vPC secondary peerlink goes down

Command Mode

- /exec/configure/if-eth-phy /exec/configure/if-eth-port-channel-switch /exec/configure/if-eth-port-channel

vpc peer-link

vpc peer-link | no vpc peer-link

Syntax Description

no	Negate a command or set its defaults
vpc	Virtual Port Channel configuration
peer-link	specify if this link is used for peer communication

Command Mode

- /exec/configure/if-eth-port-channel-switch

vpc role preempt

vpc role preempt

Syntax Description

vpc	Virtual Port Channel configuration
role	vPC role related command
preempt	Enable/Trigger preemption of lower priority master

Command Mode

- /exec

vpc suspend

vpc suspend [<n-secs>]

Syntax Description

vpc	Virtual Port Channel configuration
suspend	Suspend the vPC on primary
<i>n-secs</i>	(Optional) Suspension duration in seconds

Command Mode

- /exec/configure/vpc-domain

vpc upgrade-done

vpc upgrade-done

Syntax Description

vpc	Virtual Port Channel configuration
upgrade-done	Unlock the cli and remove ISSU state

Command Mode

- /exec

vpn

[no] vpn <otv-isis-vpn-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vpn	Configure IS-IS VPN name eg: Overlay<x>
<i>otv-isis-vpn-name</i>	Overlay name

Command Mode

- /exec/configure/otv-isis

vpn id

vpn id <vpn-id> | no vpn id [<vpn-id>]

Syntax Description

no	Negate a command or set its defaults
vpn	Configure VPN ID in rfc2685 format
id	Configure VPN ID in rfc2685 format
<i>vpn-id</i>	OUI:VPN-Index, format (hex) <3 bytes OUI:4 bytes VPN-Index>

Command Mode

- /exec/configure/vrf

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Configure RIP VRF information
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-rip

vrf

[no] vrf <vrf-cfg-name>

Syntax Description

<i>vrf-cfg-name</i>	VRF name
vrf	Virtual Router Context
no	(Optional) Negate a command or set its defaults

Command Mode

- /exec/configure/router-bgp/router-bgp-bmp-server

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Virtual Router Context
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-bgp

vrf

{ { no | default } vrf |

Syntax Description

no	
default	Set a command to its defaults
vrf	Configure IP SLAs for a VPN Routing/Forwarding instance

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/dns /exec/configure/ip-sla/http

vrf

{ { vrf { <vrf-name> | <vrf-known-name> } } | no vrf }

Syntax Description

no	Negate a command or set its defaults
vrf	Display per-VRF information
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name

Command Mode

- /exec/configure/configngamconnectcheck

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Display per-VRF information
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-ospf

vrf

[no] vrf [<name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Catena service vrf
<i>name</i>	(Optional) Catena Service VRF name

Command Mode

- /exec/configure/catena-device-grp

vrf

{ vrf <name> } | { no vrf <name> }

Syntax Description

no	Negate a command or set its defaults
vrf	ITD service vrf
<i>name</i>	ITD Service VRF name

Command Mode

- /exec/configure/itd

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Display per-VRF information
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-ospf3

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Configure ISIS VRF information
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-isis

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Configure vrf for PLB service
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/plb

vrf

[no] vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrf	Configure VRF information
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/router-eigrp

vrf context

vrf context <vrf-name> | no vrf context { <vrf-name> | <vrf-name> }

Syntax Description

no	Negate a command or set its defaults
vrf	Configure VRF parameters
context	Create VRF and enter VRF mode
<i>vrf-name</i>	VRF name
<i>vrf-name</i>	VRF name
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure

vrf default static

```
{ vrf default { static <profile-name> | dynamic } } | { no vrf default }
```

Syntax Description

no	Negate a command or set its defaults
vrf	VRF name
default	Default (wildcard). Match any vrf when there is no specific vrf mapping configured
static	Static Profile Map: Configure profile name via CLI
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server

Command Mode

- /exec/configure/profile-map-global

vrf member

vrf member { <vrf_name> | <vrf-known-name> } | no vrf member [<vrf_name> | <vrf-known-name>]

Syntax Description

no	Negate a command or set its defaults
vrf	Configure VPN Routing/Forwarding table
member	Set route's VRF membership
<i>vrf_name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name

Command Mode

- /exec/configure/track

vrf member

vrf member <vrf-name> | no vrf member [<vrf-name>]

Syntax Description

no	Negate a command or set its defaults
vrf	Configure VRF parameters
member	Set interface's VRF membership
<i>vrf-name</i>	VRF name

Command Mode

- /exec/configure/if-igp /exec/configure/if-mgmt-ether

vrf static

{ vrf <vrf-name> { static <profile-name> | dynamic } } | { no vrf <vrf-name> }

Syntax Description

no	Negate a command or set its defaults
vrf	VRF name
<i>vrf-name</i>	VRF name
static	Static Profile Map: Configure profile name via CLI
<i>profile-name</i>	Static Profile Map: Configure profile name via CLI
dynamic	Dynamic Profile Map: Retrieve profile name from the external server

Command Mode

- /exec/configure/profile-map-global

vrrp

[no] vrrp <vr_id>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrrp	VRRP configuration commands
<i>vr_id</i>	IPv4 VR group number

Command Mode

- /exec/configure/if-legacy-eth /exec/configure/if-ethernet /exec/configure/if-port-channel
/exec/configure/if-vlan-common /exec/configure/if-eth-any

vrrp bfd

{ vrrp bfd <peer_intf_ip> | no vrrp bfd [<peer_intf_ip>] }

Syntax Description

vrrp	VRRP configuration commands
bfd	BFD protocol
<i>peer_intf_ip</i>	Neighbor IP address
no	Negate a command or set its defaults

Command Mode

- /exec/configure/if-eth-any/vrrp

vrrpv2

[no] vrrpv2

Syntax Description

no	(Optional) Negate a command or set its defaults
vrrpv2	Enable VRRPv2 compatibility mode

Command Mode

- /exec/configure/if-eth-any/vrrpv3

vrrpv3

[no] vrrpv3

Syntax Description

no	(Optional) Negate a command or set its defaults
vrrpv3	VRRPv3 configuration commands

Command Mode

- /exec/configure

vrrpv3 address-family

[no] vrrpv3 <group_id> address-family <opt_v4>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrrpv3	Configure VRRPv3 group parameters
address-family	IPV4 address family
<i>opt_v4</i>	Enter ipv4
<i>group_id</i>	VRRP Group ID

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan

vrrpv3 address-family

vrrpv3 address-family

[no] vrrpv3 <group_id> address-family <opt_v6>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrrpv3	Configure VRRPv3 group parameters
address-family	IPV6 address family
<i>opt_v6</i>	Enter ipv6
<i>group_id</i>	VRRP Group ID

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan

vrss leader

[no] vrss leader <tag>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrss	VRSS-related commands
leader	Name of VRSS tag for which this group is the leader
<i>tag</i>	VRSS tag to lead

Command Mode

- /exec/configure/if-eth-any/vrrpv3

vrss pathway

[no] vrss pathway <name>

Syntax Description

no	(Optional) Negate a command or set its defaults
vrss	VRSS Interface configuration commands
pathway	Configure a VRSS pathway
<i>name</i>	Name of the VRSS tag to associate with pathway

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan

vsh

| vsh

Syntax Description

	Pipe command output to filter
vsh	the shell that understands cli command

Command Mode

- /output

vtp

[no] vtp

Syntax Description

no	(Optional) Negate a command or set its defaults
vtp	Enable VTP on this interface

Command Mode

- /exec/configure/if-switching

vtp domain

vtp domain <domain_name>

Syntax Description

vtp	Configure global VTP state
domain	Set the name of the VTP administrative domain
<i>domain_name</i>	The ascii name for the VTP administrative domain

Command Mode

- /exec/configure

vtp file

vtp file <file_name> | no vtp file

Syntax Description

no	Negate a command or set its defaults
vtp	Configure global VTP state
file	Set the name of the VTP file name
<i>file_name</i>	URI for vlan.dat

Command Mode

- /exec/configure

vtp mode

vtp mode <mode-name> | no vtp mode

Syntax Description

no	Negate a command or set its defaults
vtp	Configure global VTP state
mode	Configure VTP device mode
<i>mode-name</i>	

Command Mode

- /exec/configure

vtp password

vtp password <password_name> | no vtp password

Syntax Description

no	Negate a command or set its defaults
vtp	Configure global VTP state
password	Set the password for the VTP administrative domain
<i>password_name</i>	The ascii password for the VTP administrative domain

Command Mode

- /exec/configure

vtp pruning

vtp pruning | no vtp pruning

Syntax Description

no	Negate a command or set its defaults
vtp	Configure global VTP state
pruning	Set the administrative domain to permit pruning

Command Mode

- /exec/configure

vtp version

vtp version

vtp version <version_num> | no vtp version

Syntax Description

no	Negate a command or set its defaults
vtp	Configure global VTP state
version	Set the administrative domain to VTP version
<i>version_num</i>	Set the administrative domain to VTP version

Command Mode

- /exec/configure