



## INDEX

---

### Numerics

- 4-port 10-Gbps Fibre Channel switching modules
  - description [1-15](#)
  - figure [1-15](#)
- 12-port 4-Gbps Fibre Channel switching modules
  - description [1-14](#)
  - figure [1-14](#)
- 16-port switching modules
  - description [1-17](#)
  - figure [1-17](#)
  - LEDs (table) [1-16, 1-19](#)
- 18/4-Port Multiservice Module [1-20](#)
- 18/4-port Multiservice module [1-20](#)
- 24-port 4-Gbps Fibre Channel switching modules
  - description [1-14](#)
  - figure [1-14](#)
- 32-port Fibre Channel Advanced Services Module. See ASM
- 32-port Fibre Channel Storage Services Module. See SSM
- 32-port switching modules
  - description [1-16](#)
  - figure [1-17](#)
  - LEDs (table) [1-16, 1-19](#)
- 48-port 4-Gbps Fibre Channel switching modules
  - connectors [1-13](#)
  - description [1-13](#)
  - figure [1-13](#)
  - LEDs (figure) [1-13](#)

---

### A

- airflow specifications [B-2](#)
- alarm
  - front panel LEDs [1-27](#)
- ASM
  - description [1-28](#)
  - LEDs (table) [1-29](#)
  - power and heat specification [B-5](#)
- audience of this guide [1-13](#)

---

### B

- batteries, CSM [2-35](#)
- binary images
  - downloading [1-27, 1-29](#)
- brackets
  - C brackets [2-7](#)
  - front rack-mount [2-7](#)

---

### C

- cabinet installation guidelines [2-2](#)
- cabinets
  - perforated (requirements) [A-2](#)
  - solid-walled (requirements) [A-3](#)
- cabling
  - COM1 port [C-3](#)
  - console port [C-2](#)
  - MGMT 10/100/1000 Ethernet port [C-5](#)
  - MGMT 10/100 Ethernet port [C-6](#)
  - requirements [3-1](#)
  - SFP transceivers [3-11, 3-12](#)

Caching Services Module. See CSM

chassis

- description [1-2](#)
- grounding [2-24](#)
- grounding (figure) [2-25](#)
- removing from rack (procedure) [2-40](#)

Cisco MDS 9200 Series product overview [1-1](#)

Cisco MDS 9222i Multiservice Modular Switch [1-1](#)

clock modules

- MTBF [1-10](#)
- replacing [1-10](#)

COM1 port

- cabling [C-3](#)
- connecting (figure) [3-4](#)
- connecting (procedure) [3-4](#)
- pinouts (table) [C-4](#)

connecting

- console port (figure) [3-2](#)
- console port (procedure) [3-2](#)
- Fibre Channel ports [3-5](#)
- MGMT 10/100 [3-5](#)

console port

- cabling [C-2](#)
- connecting (figure) [3-2](#)
- connecting (procedure) [3-3](#)
- pinouts [C-2](#)

contact and site information

- records [D-3](#)
- worksheet [D-3](#)

CSM

- batteries [2-35](#)
- battery specifications (table) [B-3](#)
- description [1-30](#)
- figure [1-30](#)
- installing (procedure) [2-33](#)
- internal view (figure) [1-30](#)
- LEDs (table) [1-32](#)
- maintaining [2-35](#)
- power and heat specification [B-5](#)
- removing [2-31](#)

CUP [1-20](#)

CWDM transceivers

- description [1-36](#)
- SFP transceiver specifications [B-15](#)

---

## D

documentation

- additional publications [1-15](#)

downloading software images

- ASM-SFN image [1-29](#)
- SSM [1-27](#)

DWDM Fibre Channel SFP Transceivers [1-36](#)

---

## E

electrostatic discharge (ESD) [2-21](#)

encryption [1-22](#)

environmental specifications [B-1](#)

equipment required, installing [2-4](#)

**F**

## fan modules

- description [1-34](#)
- figure [2-39](#)
- installing (procedure) [2-39](#)
- LEDs [1-34](#)
- removing (procedure) [2-39](#)

Fiber Connectivity [1-20](#)

## fiber optic cables

- maintaining [3-13](#)

Fibre Channel/Gigabit Ethernet SFP transceivers [1-35](#)

## Fibre Channel ports

- connecting [3-5](#)
- connecting with LC-type cable (figure) [3-12](#)

**G**Generation 1 modules [1-12](#)Generation 2 modules [1-12](#)Gigabit Ethernet/Fibre Channel SFP transceiver specifications [B-13](#)

## grounding

- attaching the ESD wrist strap [2-21](#)
- best practices [2-19](#)
- chassis [2-24](#)
- chassis (figure) [2-25](#)
- establishing the system ground [2-23](#)
- tools and equipment [2-23](#)

**H**heat dissipation specifications [B-4](#)**I**

## installing

- equipment required [2-4](#)
- rack-mount (front-facing) [2-7](#)
- rack-mount (rear-facing) [2-16](#)
- rack-mount (rotated brackets) [2-14](#)
- rack-mount front-facing (figure) [2-9](#)
- rack-mount rear-facing (figure) [2-17](#)
- SFP transceiver cables [3-11](#)
- SFP transceivers (note) [3-10](#)
- X2 transceivers [3-8](#)

## interface module

- description [1-10](#)
- figure [1-10](#)
- LEDs (table) [1-11](#)

## IPS modules

- description [1-24](#)
- IPS-4 (figure) [1-25](#)
- IPS-8 (figure) [1-24](#)
- LEDs (table) [1-25](#)
- power and heat specification [B-5](#)

IP Storage Services modules. See IPS modules

**L**

## LC-type cables

- connecting to Fibre Channel ports [3-12](#)
- figure [3-12](#)

## LEDs

- ASM (table) [1-29](#)
- CSM (table) [1-32](#)
- fan module [1-34](#)
- interface module (table) [1-11](#)
- IPS modules (table) [1-25](#)
- MPS-14/2 (table) [1-23](#)
- supervisor module (table) [1-9](#)
- switching modules (table) [1-16, 1-19](#)

---

**M**

## maintaining

- fiber optic cables [3-13](#)

- SFP transceivers [3-13](#)

maintenance records [D-1](#)

## MGMT 10/100/1000 Ethernet port

- cabling [C-5](#)

- pinouts [C-5](#)

## MGMT 10/100 Ethernet port

- cabling [C-6](#)

- connecting (figure) [3-5](#)

- connecting (procedure) [3-5](#)

- pinouts [C-6](#)

## MPS-14/2

- figure [1-23](#)

- LEDs (table) [1-23](#)

---

**N**
network connections, preparing [3-2](#)new and changed information (table) [1-9](#)


---

**O**
open racks, standard (requirements) [A-3](#)


---

**P**
physical specifications (table) [B-2](#)

## pinouts

- COM 1 port [C-4](#)

- console port [C-2](#)

- MGMT 10/100/1000 Ethernet port [C-5](#)

- MGMT 10/100 Ethernet port [C-6](#)

plugs supported for power supplies [C-8](#)

## ports

- COM1 [3-4](#)

- console [3-2](#)

- Fibre Channel [3-5](#)

- MGMT 10/100 [3-5](#)

potting [1-20](#)power cord, jumper [C-12](#)power cords, length [C-8](#)

## power-on

- front panel LEDs [1-27](#)

## power supplies

- description [1-33](#)

- figure [1-33](#)

- installing (procedure) [2-36](#)

- LED (table) [1-33](#)

- removing (procedure) [2-36](#)

- specifications [B-4](#)

- supported plugs [C-8](#)

Preface [1-13](#)

## pre-installation

- guidelines [2-2](#)

- options [2-2](#)

- required equipment [2-4](#)

- unpacking the switch [2-4](#)

---

**R**

## rack-mount installation

- guidelines [A-4](#)

- kit [2-5](#)

- procedures [2-5](#)

- specifications [A-4](#)

## ready

- front panel LEDs [1-27](#)

## records

- chassis and module information [D-4](#)

- contact and site information [D-3](#)

- site planning and maintenance [D-1](#)

## removing

- chassis from rack [2-40](#)
- SFP transceiver cables [3-12](#)
- SFP transceivers [3-10](#)
- X2 transceivers [3-8](#)

**S**

## self-test passed

- front panel LEDs [1-27](#)

## self-test running

- front panel LEDs [1-27](#)

## services modules

- ASM [1-28](#)
- downloading binary image [1-29](#)
- installing (procedure) [2-33](#)
- IPS-4 [1-24](#)
- IPS-8 [1-24](#)
- MPS-14/2 [1-22](#)
- MSFM-18/4 [1-20](#)
- MSM-18/4 [1-20](#)
- removing (procedure) [2-32](#)
- specifications [B-2](#)
- SSM [1-26](#)

## SFP transceivers

- cabling [3-11, 3-12](#)
  - CWDM [1-36, B-15](#)
  - description [1-35, 1-36, 3-8, B-9](#)
  - Fibre Channel [1-35](#)
  - Fibre Channel/Gigabit Ethernet [1-35](#)
  - Fibre Channel/Gigabit Ethernet supported [B-13](#)
  - Fibre Channel specifications [B-10](#)
  - Fibre Channel supported [B-10](#)
  - Gigabit Ethernet [1-36](#)
  - installing [3-9](#)
  - installing a cable [3-11](#)
  - latches supported [3-9](#)
  - maintaining fiber optic cables [3-13](#)
  - maintaining fiber optic cables (procedures) [3-13](#)
  - removing [3-10](#)
  - removing a cable (procedure) [3-12](#)
  - specifications [B-9](#)
  - supported [1-34](#)
- shelf bracket
- installation (four-post EIA rack) [A-7](#)
  - installation (telco/IEA) [A-6](#)
  - installing switch [A-8](#)
  - removing kit [A-9](#)
  - telco/EIA kit (note) [A-4](#)
- site planning, preparation checklist [D-1](#)
- software release requirement [1-2](#)
- specifications
- airflow [B-2](#)
  - cables [C-1](#)
  - environmental [B-1](#)
  - heat dissipation [B-4](#)
  - modules [B-2](#)
  - physical [B-2](#)
  - pinouts [C-1](#)
  - power [B-4](#)
  - power requirements [B-4](#)
  - SFP transceivers [B-9](#)

## SSM

description [1-26](#)

figure [1-26](#)

starting up the switch [2-26](#)

supervisor modules

Cisco MDS 9216A [1-7](#)

Cisco MDS 9216i [1-7](#)

installing [2-28](#)

LEDs (table) [1-9](#)

power and heat specification [B-5](#)

removing [2-31, 2-32](#)

specifications [B-2](#)

switching modules

12-port 4-Gbps Fibre Channel switching modules [1-14](#)

16-port 2-Gbps Fibre Channel (figure) [1-17](#)

24-port 4-Gbps Fibre Channel switching modules [1-14](#)

32-port 1-Gbps/2-Gbps Fibre Channel (figure) [1-17](#)

48-port 4-Gbps Fibre Channel switching modules [1-13](#)

4-port 10-Gbps Fibre Channel switching modules [1-15](#)

description [1-12](#)

downloading binary image [1-27](#)

features [1-18](#)

installing (procedure) [2-33](#)

LEDs (table) [1-16, 1-19](#)

positioning in chassis (figure) [2-30](#)

power and heat specification [B-5](#)

removing [2-31, 2-32](#)

removing (procedure) [2-32](#)

specifications [B-2](#)

verifying installation [2-34](#)

switch specifications (table) [B-1](#)

system grounding [2-19](#)

---

**T**

Table [B-1](#)

telco racks (requirements) [A-4](#)

transceivers, supported SFPs. See SFP transceivers

---

**W**

weight of modules (table) [B-3](#)

---

**X**

X2 transceivers

description [1-35, B-6](#)

figure [3-7](#)

installing [3-8](#)

removing [3-8](#)

supported (table) [B-7](#)