



VRF Lite

- [VRF Lite, on page 1](#)
- [Prerequisites and Guidelines, on page 1](#)
- [Sample Scenarios, on page 2](#)
- [Automatic VRF Lite \(IFC\) Configuration, on page 3](#)
- [VRF Lite Between Cisco Nexus 9000 Based Border and Cisco Nexus 9000 Based Edge Router, on page 4](#)
- [VRF Lite Between Cisco Nexus 9000 Based Border and Non-Cisco Device, on page 9](#)
- [VRF Lite Between Cisco Nexus 9000 Based Border and Non-Nexus Device, on page 12](#)
- [Appendix , on page 13](#)

VRF Lite

External connectivity from data centers is a prime requirement where workloads that are part of a data center fabric can communicate with an outside fabric over WAN or Backbone services. To enable Layer-3 for north-south traffic flow, use virtual routing and forwarding instances (VRF) Lite peering between data center border devices and the external fabric edge routers.

In a Virtual Extensible Local Area Network (VXLAN) Ethernet Virtual Private Network (EVPN) fabric, it can be a border router or a border gateway router. You can enable VRF Lite on the following devices:

- Border
- Border Spine
- Border Gateway
- Border Gateway Spine
- Border Super Spine

Prerequisites and Guidelines

- VRF Lite requires Cisco Nexus 9000 Series Cisco Nexus Operating System (NX-OS) Release 7.0(3)I6(2) or later.

- Familiarity with VXLAN BGP EVPN data center fabric architecture and VXLAN Overlays provisioning through NDFC.
- Fully configured VXLAN BGP EVPN fabrics including underlay and overlay configurations for the various leafs and spine devices, external fabric configuration through NDFC, and relevant external fabric device configuration (edge routers, for example).

- You can configure VXLAN BGP EVPN fabric (and its connectivity to an external Layer 3 domain for north-south traffic flow) manually or using NDFC.

This document explains the process to connect the fabric to an edge router (outside the fabric, toward the external fabric) through NDFC. So, you must know how to configure and deploy VXLAN BGP EVPN and external fabrics through NDFC.

- VRF Lite can be enabled on physical Ethernet interface or Layer 3 port-channel. Subinterface over physical interface or Layer 3 port-channel interface that is created in NDFC at the VRF extension moment for each VRF lite link that the VRF is extended over.
- To delete a VRF Lite IFC, remove all VRF extensions that are enabled on the IFC. Else, an error message is reported. After you remove the VRF Lite attachments, recalculate and deploy the fabric to remove any pending Layer-3 extension configurations. It removes the per-VRF subinterface and per-VRF External Border Gateway Protocol configuration on the devices.
- When you create a VXLAN VRF, ensure that you check the following 3 fields:
 - **Advertise Host Routes** – By default, over the VRF Lite peering session, only nonhost (/32 or /128) prefixes are advertised. If host routes (/32 or /128) must be enabled and advertised from the border device to the edge/WAN router, check the **Advertise Host Routes** check box. Route-map does outbound filtering. By default, this check box is disabled.
 - **Advertise Default Route** – This field controls whether a network statement 0/0 will be enabled under the VRF. This in turn advertises 0/0 route in BGP. By default, this field is enabled. When you choose this check box, this ensures that a 0/0 route is advertised inside the fabric over EVPN Route-type 5 to the leafs, there by providing a default route out of the Leafs toward the border devices.
 - **Config Static 0/0 Route** –This field controls whether a static 0/0 route to the edge/WAN router, must be configured under the VRF on the border device. By default, this field is enabled. If WAN/edge routers are advertising a default route over the VRF Lite peering, to the border device in the fabric, then this field must be disabled.

In addition, the **Advertise Default Route** field must be disabled. The 0/0 route that is advertised over External Border Gateway Protocol sends over EVPN to the leafs without requirement of more configuration. The clean iBGP EVPN separation inside the fabric with eBGP for external out-of-fabric peering provides required. By default, this check box is checked.

Sample Scenarios

The following sections explain different use-cases for configuring VRF Lite:

- Automatic VRF Lite (IFC) Configuration
- VRF Lite between Cisco Nexus 9000 based Border and Cisco Nexus 9000 based Edge Router

- VRF Lite between Cisco Nexus 9000 based Border and Non-Cisco device
 - VRF Lite between Cisco Nexus 9000 based Border and Non-Nexus device
- This is a typical use-case of Cisco ASR 9000 based Edge Router in Managed mode

Automatic VRF Lite (IFC) Configuration

Guidelines

- Auto IFC is supported on Cisco Nexus devices only.
- You can configure Cisco ASR 1000 Series routers and Cisco Catalyst 9000 Series switches as edge routers.
To configure, set up a VRF Lite IFC, and connect it as a border device with easy fabric.
- You can configure Cisco ASR 9000 Series routers as edge routers in managed mode.
- If the device in the External fabric is non-Nexus, you must create IFC manually.
- Ensure that no user policy is enabled on the interface that connects to the edge router. If a policy exists, then the interface will not be configured.
- Autoconfiguration is supported for the following cases:
 - **Border** role in the VXLAN fabric and **Edge Router** role in the connected external fabric device
 - **Border Gateway** role in the VXLAN fabric and **Edge Router** role in the connected external fabric device
 - **Border** role to another **Border** role directly



Note Autoconfiguration is not provided between two Border Gateways (BGWs).

If VRF Lite is required between other roles, you must deploy it manually on the NDFC Web UI.

- To deploy configurations in the external fabric, you must uncheck **Fabric Monitor Mode** check box in the external fabric settings. When an external fabric is set to **Fabric Monitor Mode Only**, you cannot deploy configurations on the switches.

Easy Fabric Settings

There are 4 modes to deploy VRF Lite. By default, VRF Lite deployment is set to Manual. You can change the settings based on the requirement, below mentioned different modes:

- **Manual** - To deploy the VRF Lite IFCs manually between source and destination device.
- **To External Only** - Configure VRF Lite IFC on each physical interface of a border leaf device in the VXLAN fabric that is connected to a device with the **Edge Router** role in the external fabric.
- **Back-to-Back Only** - Configure VRF Lite IFCs between directly connected border leaf device interfaces of different VXLAN fabrics.

- **Back2Back&ToExternal** - Use this option to configure IFCs for the modes **To External Only** and **Back-to-Back Only**.



Note Though VRF Lite mode is set to **Manual** for NDFC resource handling, Data Center Interconnectivity (DCI) subnet is required.

The **Manual** mode is the default mode in fabric settings. To change the default mode to other mode, click **Edit** fabric settings. On **Resource** tab, modify VRF Lite deployment field to above mentioned auto configuration modes. Here in the example, **To External Only** check box is checked.

Auto Deploy Both - This check box is applicable for the symmetric VRF Lite deployment. When you check this check box, the **Auto Deploy Flag** is set to true for auto created IFCs to turn on symmetric VRF Lite configuration. You can check or uncheck this check box when the **VRF Lite Deployment** field is not set to **Manual**. The value you choose takes priority. This flag only affects the new auto created IFC and it does not affect the existing IFCs.

VRF Lite Subnet IP Range: The IP address for VRF Lite IFC deployment is chosen from this range. The default value is 10.33.0.0/16. Ensure that each fabric has its own unique range and is distinct from any underlay range to avoid possible duplication. These addresses are reserved with the Resource Manager.

VRF Lite Subnet Mask: By default, it is set to /30, which is best practice for point-to-point (P2P) links.

VRF Lite Between Cisco Nexus 9000 Based Border and Cisco Nexus 9000 Based Edge Router

DC-Vxlan VXLAN EVPN Fabric is connected to WAN-Vxlan cloud. In the following topology, you can view WAN-Vxlan.

The easy fabric has border leaf role and WAN-Vxlan cloud has a device with role edge router. NDFC shows physical and logical representation of the topology with CDP/LLDP Link discovery.

In this example, you can enable VRF Lite connections between DC-Vxlan border leaf and WAN-Vxlan edge router.

For VRF Lite configuration, you must enable External Border Gateway Protocol (EBGP) peering between the fabric's border interfaces and the edge router's interfaces, through point-to-point (P2P) connections.

The border physical interfaces are:

- **eth1/1** on **border1-Vxlan**, toward **eth1/1** on **WAN1-Vxlan**.
- **eth1/2** on **border2-Vxlan**, toward **eth1/2** on **WAN1-Vxlan**.

1. Verify the links between the Border and the edge router. Navigate **LAN > Fabrics**, double-click on **DC-Vxlan** fabric.

On **Fabric Overview** window, click **Links** tab. You can view the links that are detected by NDFC and **ext_fabric_setup** policy is assigned automatically.

| Fabric Name | Name | Policy | Info | Admin State | Oper State |
|-------------------------|--|------------------|--------------|-------------|------------|
| WAN-Vxlan<->-> DC-Vxlan | WAN1-Vxlan-Ethernet1/2---border2-Vxlan-Ethernet1/2 | ext_fabric_setup | Link Present | ↑ Up | ↑ Up |
| WAN-Vxlan<->-> DC-Vxlan | WAN1-Vxlan-Ethernet1/1---border1-Vxlan-Ethernet1/1 | ext_fabric_setup | Link Present | ↑ Up | ↑ Up |

2. To verify the VRF Lite configurations, choose fabric name and choose **Actions > Edit**.
Click appropriate **Links**, choose **Actions > Edit**.

| | |
|------------------------|--------------------|
| Link Type* | Inter-Fabric |
| Link Sub-Type* | VRF_LITE |
| Link Template* | ext_fabric_setup > |
| Source Fabric | WAN-Vxlan |
| Destination Fabric | DC-Vxlan |
| Source Device* | WAN1-Vxlan |
| Destination Device* | border1-vxlan |
| Source Interface* | Ethernet1/1 |
| Destination Interface* | Ethernet1/1 |

| General Parameters | Advanced |
|--|-------------------------------------|
| Source BGP ASN* | 200 |
| BGP Autonomous System Number in Source Fabric | |
| Source IP Address/Mask* | 10.33.0.1/30 |
| IP address for sub-interface in each VRF in Source Fabric | |
| Destination IP* | 10.33.0.2 |
| IP address for sub-interface in each VRF in Destination Fabric | |
| Destination BGP ASN* | 100 |
| BGP Autonomous System Number in Destination Fabric | |
| Link MTU | 9216 |
| Interface MTU on both ends of VRF Lite IFC | |
| Auto Deploy Flag | <input checked="" type="checkbox"/> |
| Flag that controls auto generation of neighbor VRF Lite configuration for managed neighbor devices | |

Link Type – Specifies the Interfabric link between two different fabrics within NDFC.

Link Sub-Type – Specifies the subtype of link. By default, the **VRF_LITE** option is displayed.

Link Template – Specifies the template for the link. The default template for a VRF Lite IFC is **ext_fabric_setup** is displayed. The template enables the source and destination interfaces as Layer 3 interfaces, figures the **no shutdown** command, and sets their MTU to 9216.

The Source and Destination Fabric, Device, and Interfaces are autodetected and chosen by NDFC based on CDP/LLDP discovery.

On the **General Parameters** tabs, the fields in this tab are:

Source BGP ASN – BGP ASN of selected source fabric

Source IP Address/Mask - NDFC auto allocated IP pool from Resource Manager Pool of VRF Lite subnet Pool for the **Ethernet1/1** subinterfaces, the source interface of the IFC. A subinterface is created for each VRF extended over this IFC, and a unique 802.1Q ID is assigned to it. The IP address/Mask entered here, along with the BGP Neighbor IP field (explained below) will be used as the default values for the subinterface that is created at VRF extension and can be overwritten.

For example, an 802.1Q ID of 2 is associated with subinterface Eth 1/1.2 for VRF CORP traffic, and 802.1Q ID of 3 is associated with Eth 1/1.3 and VRF ENG, and so on.

The IP prefix is reserved with the NDFC resource manager. Ensure that we use a unique IP address prefix for each IFC we create in the topology.

Destination IP - NDFC auto allocated IP pool from resource manager pool of VRF Lite subnet pool. This is a BGP neighbor IP on the device.

Interfabric traffic from different VRFs for an IFC 's the same source IP address (10.33.0.1/30) and destination IP address (10.33.0.2) as an example.

Destination BGP ASN – BGP ASN of selected Destination fabric

Link MTU – Default 9216

Auto Deploy Flag – Default Auto selected based on fabric settings. This knob autoconfigures the neighbor VRF on neighboring managed device. For example, it will automatically create VRF on the edge router inside WAN-Vxlan External fabric.

The **Advanced** tab is added in the **Link Profile** section. The fields in this tab are:

- **Source Interface Description**
- **Destination Interface Description**
- **Source Interface Freeform Config**
- **Destination Interface Freeform Config**

Click **Save** to save the configuration.

3. To attach VRF and VRF Lite extensions on the border devices:
 - a. Click **VRFs > VRF Attachments** tab.
 - b. Choose **VRF Name**, click **Actions > Edit**.
The **Edit** window appears.
 - c. You can edit details in **Extension** field as mentioned below:

The screenshot shows the VRF Lite configuration interface. At the top, there are two panels for 'border1-Vxlan(9Y8GIO6038U)' and 'border2-Vxlan(9RQ237GWFTT)'. Each panel has a 'Detach' button and an 'Attach' button. Below these are fields for 'VLAN*' (set to 99) and 'Extend*' (set to VRF_LITE). Each panel also has a 'CLI Freeform Config' section with an 'Edit >' button and a warning message: 'All configs should strictly match the "show run" output, including cases and new line. Any mismatches will yield unexpected diffs during deploy.' Below this are fields for 'Loopback Id', 'Loopback IPv4 Address', 'Loopback IPv6 Address', 'Import EVPN Route Target', and 'Export EVPN Route Target'. At the bottom, there is an 'Extension' section with a table and 'Attach-All' and 'Detach-All' buttons.

| Action | Attached | Source Switch | Type | IF_NAME | Dest. Switch | Dest. Interface | DOT1Q_ID | IP_MASK | IP_TAG | NEIGHB... | NEIGHB... | IPV6_MA... | IPV6_NEL... | MTU | ENABLE... |
|--------|----------|---------------|----------|-------------|--------------|-----------------|----------|--------------|--------|-----------|-----------|------------|-------------|------|-----------|
| Edit | Detached | border1-Vxlan | VRF_LITE | Ethernet1/1 | WAN1-Vxlan | Ethernet1/1 | 2 | 10.33.0.2/30 | | 10.33.0.1 | 200 | | | 9216 | ▼ |
| Edit | Detached | border2 | VRF_LITE | Ethernet1/2 | WAN1 | Ethernet1/2 | 2 | 10.33.0.6/30 | | 10.33.0.5 | 200 | | | 9216 | |

- Toggle the knob to **Attach**.
- In **Extend**, choose **VRF_LITE** from the drop-down list.
- On **Extension** card, choose one switch at a time, click **Edit**, enter details for **PEER_VRF_NAME**. This auto deploys the VRF on the neighboring device.

When you extend VRF Lite consecutive scenario, the VRF must be in the peer fabric and VRF name must be same. If the VRF is not in the peer fabric and if you try to extend VRF Lite, an error message is generated displaying the issue.

When you extend VRF Lite between an easy fabric and an external fabric, the VRF name can be same as name of source fabric, or default name, or another VRF name. Enter required VRF name in **PEER_VRF_NAME** field. The child PTIs for subinterface, VRF creation and BGP peering on external fabric have source values that are populated in it, hence the policies cannot be edited or deleted.

Follow above procedure for other links.

On **Edit** window, click **Attach-All**, to attach the required VRF Extension on the border devices, and then click **Save**.

4. To Recalculate and deploy configurations on VXLAN EVPN Easy Fabric:

On **Fabric** windows double-click on appropriate fabric to navigate to **Fabric Overview** window. Click **Actions > Recalculate & Deploy**.

Similarly, you can also perform operation, choose required **VRF Name** on **VRF attachments** tab, click **Actions > Deploy** to initiate VRF and VRF Lite configurations on the border devices.

5. To Recalculate and Deploy VXLAN EVPN Easy fabric:

On **Fabric** window, click **Action > Recalculate and Deploy**.

Similarly, you can choose the VRF attachments, edit, and click **Deploy**. It pushes VRF and VRF Lite configurations the border devices.

6. To recalculate and deploy configurations on external fabric, choose external fabric and follow the above procedure.

VRF Lite Between Cisco Nexus 9000 Based Border and Non-Cisco Device

This example displays the procedure to enable VRF Lite connections between the DC-Vxlan Border leaf and a non-Cisco device in external fabric.

Cisco recommends using meta definition of a device instead of importing devices in external fabric. This allows VRF Lite configurations to extend Cisco Nexus 9000 managed border devices in easy fabric. NDFC will not manage destination noncisco device. You must configure a relevant VRF Lite configuration on the destination device.

1. To create new IFC links between border and edge router.
 - a. On **Fabrics** window, double click the fabric.
The **Fabric Overview** window appears.
 - b. Navigate to **Links** tab. On **Links** tab, click **Actions > Create a new link**.
The **Create New link** window appears.

The screenshot displays the configuration page for a VRF Lite link. The top section contains dropdown menus for Link Type (Inter-Fabric), Link Sub-Type (VRF_LITE), Link Template (ext_fabric_setup), Source Fabric (DC-Vxlan), Destination Fabric (WAN-Vxlan), Source Device (border 1-Vxlan), Destination Device (Non-Cisco), Source Interface (Ethernet1/5), and Destination Interface (Gig1). Below this, the 'General Parameters' tab is active, showing fields for Source BGP ASN (100), Source IP Address/Mask (10.33.0.9/30), Destination IP (10.33.0.10), Destination BGP ASN (200), and Link MTU (9216). Each field has a small explanatory text to its right.

c. Enter the following required parameters in the window:

- **Link Type** – Select the Interfabric link. This is the IFC between two different fabrics within NDFC.
- **Link Sub-Type** - By default, the **VRF_LITE** option is displayed.
- **Link Template** – The default template for a VRF Lite IFC, **ext_fabric_setup**, is displayed. The template enables the source and destination interfaces as Layer 3 interfaces, configures the **no shutdown** command, and sets their MTU to 9216.
- **Source Fabric** – Select the Source Fabric. This is the Easy fabric where Cisco Nexus 9000 based border device resides.
- **Destination Fabric** – Select any External or Classic LAN fabric. It can be monitor mode as well.
- **Source Device** – Select the Source Device. This is the Cisco Nexus 9000 based border device.
- **Destination Device** – Now, you can create a “meta device definition”. Type any name and click create. For example, non-cisco.
- **Source Interface** – Select the interface on the border device where the non-cisco device is connected.

- **Destination Interface** – Now, you can create a “meta device interface”. Type any interface name and click create. For example, gig1, tengig1/10, eth1/1 are the valid interface names.

The **General Parameters** tab has the following fields:

- **Source BGP ASN** – BGP ASN of selected Source fabric.
- **Source IP Address/Mask** - Provide IP address and mask for the **Ethernet1/5** subinterfaces, the source interface of the IFC. Subinterface is created for each VRF extended over this IFC, and a unique 802.1Q ID is assigned to it. The IP address/Mask entered here, along with the BGP Neighbor IP field (explained below) used as the default values for the subinterface that is created at VRF extension and can be overwritten.

For example, an 802.1Q ID of 2 is associated with subinterface Eth 1/5.2 for VRF CORP traffic, and 802.1Q ID of 3 is associated with Eth 1/5.3 and VRF ENG, and so on.

The IP prefix is reserved with the NDFC resource manager. Ensure that we use a unique IP address prefix for each IFC we create in the topology.

- **Destination IP** - NDFC auto allocated IP pool from Resource Manager Pool of VRF Lite subnet Pool. It is a BGP neighbor IP on the device.

Interfabric traffic from different VRFs for an IFCs the same source IP address (10.33.0.1/30) and destination IP address (10.33.0.2) as an example.

- **Destination BGP ASN** – BGP ASN of selected Destination fabric
- **Link MTU** – Default 9216
- **Auto Deploy Flag** – Not applicable as the destination device is Non-Nexus and Non-Cisco.

Enter the appropriate details in the **Advanced** tab. The following mentioned fields are in the tab:

- **Source Interface Description**
- **Destination Interface Description**
- **Source Interface Freeform Config**
- **Destination Interface Freeform Config**

2. Click **Save** to create new link with parameters mentioned.
3. To attach VRF and VRF Lite extensions on the border devices, double-click on **DC-Vxlan** fabric. On **Fabric Overview** window, navigate to **VRFs > VRF Attachments** and edit the details as shown in the following image.

border1-Vxlan(9Y8GIO6O38U) - border2-Vxlan(9RQ237GWFTT)

Detach Attach

VLAN*
99

Extend*
VRF_LITE

border1-Vxlan(9Y8GIO6O38U)
CLI Freeform Config
Edit >
All configs should strictly match the 'show run' output, including cases and new line
Any mismatches will yield unexpected diffs during deploy

Loopback Id
Loopback IPv4 Address
Loopback IPv6 Address
Import EVPN Route Target
Export EVPN Route Target

border2-Vxlan(9RQ237GWFTT)
CLI Freeform Config
Edit >
All configs should strictly match the 'show run' output, including cases and new line
Any mismatches will yield unexpected diffs during deploy

Loopback Id
Loopback IPv4 Address
Loopback IPv6 Address
Import EVPN Route Target
Export EVPN Route Target

Extension
Dest. Interface == TenGigabitEthernet1/10 x Attached == Detached

| Action | Attached | Source Switch | Type | IF_NAME | Dest. Switch | Dest. Interface | DOT1Q_ID | IP_MASK | IP_TAG | NEIGHB... | NEIGHB... | IPV6_MA... | IPV6_NEL... | MT |
|--------|--|---------------|----------|-------------|--------------|------------------------|----------|--------------|--------|------------|-----------|------------|-------------|----|
| Edit | <input checked="" type="checkbox"/> Attached | border1-Vxlan | VRF_LITE | Ethernet1/5 | non-cisco | TenGigabitEthernet1/10 | | 10.33.0.9/30 | | 10.33.0.10 | 200 | | | 92 |

Attach-All Detach-All

Click **Attach-all** to attach the required VRF Extension on the border devices and then click **Save**.

- To recalculate and deploy configurations on VXLAN EVPN Easy fabric, click appropriate fabric on **Fabric** window.

On **Fabric Overview** window, click **Actions > Recalculate & Deploy**, or navigate to **VRF > VRF attachments**, choose the VRF attachments, edit, and then click **Deploy**. This initiates the VRF and VRF Lite configurations on the border devices.

VRF Lite Between Cisco Nexus 9000 Based Border and Non-Nexus Device

In this example, you can enable VRF Lite connections between DC-Vxlan border leaf and a non-Nexus device in an external fabric.

Before Cisco NDFC Release 12.0.1a, ASR 9000 was supported for external fabric in monitor mode only. From Release 12.0.1a, ASR 9000 is supported in managed mode with an edge router role.

The following are the supported platforms:

- ASR 9000
- NCS 5500
- ASR 8000

Configuration compliance is enabled for IOS-XR switches in external fabric, similar to Cisco Nexus switches configured on external fabric. NDFC pushes configuration at the end of deployment



Note Ensure that the VXLAN BGP EVPN border device is active.

Procedure

- Step 1** Navigate to **LAN > Fabrics** to create external fabric.
- Step 2** On **Create Fabric** window, enter appropriate ASN number, uncheck **monitor mode** check box, and then click **Save**.
- Step 3** Navigate to **Switches** window, click **Actions > Add switches**.
- Note** Ensure that the IOS-XR device has the IP address reachability to NDFC with SNMP configurations for discovery.
- To add non-Nexus devices to external fabrics, see [Adding Non-Nexus Devices to External Fabrics](#).
- Step 4** On **Add Switches** window, choose **Discover** check box, and **IOS-XR** from drop-down list for **Device Type** field.
- Step 5** After the router is discovered, you can view the switch name in the **Discovery Results** field.
- Step 6** Choose the discovered router and add to fabric. Ensure that the **Discovery Status** displays **OK** in the status column. Edge router role is supported.
- After successful discovery, you can view the links between the devices in the **Links** tab.
- Step 7** To create VRF Lite IFC for external fabric with Cisco Nexus 9000 border leaf, choose the link and click **Actions > Edit**.
- Step 8** On **Edit Link** window, fill the required details for IFC creation. Few fields are auto-populated.
- Note** For non-NX-OS device auto, deploy flag is not applicable.
- Step 9** To extend VRF Lite configurations on VXLAN border device, navigate to **VRF > VRF Attachment** tab, choose the VRF name, click **Actions > Edit** and then extend it as VRF Lite.
- Step 10** Deploy the configuration on VXLAN border device.
- Step 11** Navigate to the fabrics window, ensure that the external fabric has the router, click **Apply** to VRF Lite BGP policies.
- Step 12** Navigate to **Policies** tab, and add policies **ios_xr_base_bgp** and enter required details and click **Save**.
- Step 13** Add another policy **ios_xr_Ext_VRF_Lite_Jython** and enter required details and click **Save**
- Step 14** Deploy the configurations on the IOS-XR router.
-

Appendix

Nexus 9000 Border device configurations

Border-Vxlan (base border configurations) generated by template ext_base_border_vrflite_11_1

```

switch configure terminal
switch(config)#
ip prefix-list default-route seq 5 permit 0.0.0.0/0 le 1
ip prefix-list host-route seq 5 permit 0.0.0.0/0 eq 32
route-map extcon-rmap-filter deny 10
    match ip address prefix-list default-route
route-map extcon-rmap-filter deny 20
    match ip address prefix-list host-route
route-map extcon-rmap-filter permit 1000
route-map extcon-rmap-filter-allow-host deny 10
    match ip address prefix-list default-route
route-map extcon-rmap-filter-allow-host permit 1000
ipv6 prefix-list default-route-v6 seq 5 permit 0::/0
ipv6 prefix-list host-route-v6 seq 5 permit 0::/0 eq 128
route-map extcon-rmap-filter-v6 deny 10
    match ipv6 address prefix-list default-route-v6
route-map extcon-rmap-filter-v6 deny 20
    match ip address prefix-list host-route-v6
route-map extcon-rmap-filter-v6 permit 1000
route-map extcon-rmap-filter-v6-allow-host deny 10
    match ipv6 address prefix-list default-route-v6
route-map extcon-rmap-filter-v6-allow-host permit 1000

```

Border-Vxlan VRF Lite Extension configuration

```

switch configure terminal
vrf context CORP
    ip route 0.0.0.0/0 2.2.2.2
exit
router bgp 100
    vrf CORP
        address-family ipv4 unicast
            network 0.0.0.0/0
            exit
        neighbor 2.2.2.2
            remote-as 200
            address-family ipv4 unicast
                send-community both
            route-map extcon-rmap-filter out
configure terminal
interface ethernet1/1.2
    encapsulation dot1q 2
    mtu 9216
    vrf member CORP
    ip address 2.2.2.22/24
    no shutdown
configure terminal

```

WAN-Vxlan (External fabric Edge Router) VRF Lite Extension configuration

```

switch configure terminal
vrf context CORP
    address-family ipv4 unicast
exit
router bgp 200
    vrf CORP
        address-family ipv4 unicast
            neighbor 10.33.0.2
            remote-as 100
            address-family ipv4 unicast

```

```
        send-community both
    exit
  exit
  neighbor 10.33.0.6
    remote-as 100
    address-family ipv4 unicast
      send-community both
configure terminal
interface ethernet1/1.2
  mtu 9216
  vrf member CORP
  encapsulation dot1q 2
  ip address 10.33.0.1/30
  no shutdown
interface ethernet1/2.2
  vrf member CORP
  mtu 9216
  encapsulation dot1q 2
  ip address 10.33.0.5/30
  no shutdown
configure terminal
```

