



**Preface** vii

Audience vii

Product Documentation vii

Related Documentation vii

Obtaining Documentation and Submitting a Service Request viii

---

**CHAPTER 1**

**Introduction** 1-1

Overview 1-1

API Functions 1-2

PWS Functions 1-3

---

**CHAPTER 2**

**Prime Cable Provisioning Architecture** 2-1

Regional Distribution Unit 2-1

Device Provisioning Engine 2-1

Provisioning Group 2-2

Client API 2-3

Cisco Prime Network Registrar 2-4

Key Distribution Center 2-4

Prime Cable Provisioning Process Watchdog 2-4

SNMP Agent 2-5

Provisioning Web Services (PWS) 2-5

Web User Interface 2-5

---

**CHAPTER 3**

**Client and RDU Communication** 3-1

Overview 3-1

Establishing a Connection 3-2

Maintaining a Connection 3-2

Connection Concurrency 3-2

Closing a Connection 3-2

---

**CHAPTER 4**

**Batches and Commands** 4-1

Overview 4-1

- Batch Rules 4-2
- Identifying a Batch 4-2
- Batch Processing Flags 4-3
  - Setting the Reliable Flag 4-4
  - Setting the Activation Flag 4-5
  - Setting the Confirmation Flag 4-6
  - Setting the Publishing Flag 4-6
  - Setting the Optimistic Locking Flag 4-7
- Submitting the Batch 4-8
  - Submitting in Synchronous Mode 4-8
  - Submitting in Asynchronous Mode 4-9
- Batch Processing Modes 4-9
- Batch Results 4-10
- Queuing a Batch 4-13
- Retrying a Batch 4-14
- Handling Errors 4-16
  - Types of Errors 4-16
    - Connection Errors 4-16
    - Batch and Command Errors 4-16
  - Batch Warnings 4-16

---

**CHAPTER 5**

- Events 5-1**
  - Overview 5-1
  - Event Registration 5-1
  - Event Handling 5-3
  - Event Reliability 5-3

---

**CHAPTER 6**

- Getting Started with the Prime Cable Provisioning API 6-1**
  - Startup Process for API Client 6-1
    - Configuring the System 6-1
    - Executing the API Client 6-2
  - Processing a Batch 6-2

---

**CHAPTER 7**

- Java API Client Use Cases 7-1**
  - Provisioning Operations 7-1
  - Provisioning API Use Cases 7-3
    - How to Create an API Client 7-3

Use Cases	7-6
Self-Provisioned Modem and Computer in Fixed Standard Mode	7-7
Adding a New Computer in Fixed Standard Mode	7-10
Disabling a Subscriber	7-13
Preprovisioning Modems/Self-Provisioned Computers	7-15
Modifying an Existing Modem	7-17
Unregistering and Deleting a Subscriber's Devices	7-18
Self-Provisioning First-Time Activation in Promiscuous Mode	7-22
Bulk Provisioning 100 Modems in Promiscuous Mode	7-25
Preprovisioning First-Time Activation in Promiscuous Mode	7-27
Replacing an Existing Modem	7-29
Adding a Second Computer in Promiscuous Mode	7-31
Self-Provisioning First-Time Activation with NAT	7-31
Adding a New Computer Behind a Modem with NAT	7-32
Move Device to Another DHCP Scope	7-32
Log Device Deletions Using Events	7-33
Monitoring an RDU Connection Using Events	7-34
Logging Batch Completions Using Events	7-35
Getting Detailed Device Information	7-35
Searching Using the Device Type	7-40
Searching for Devices Using Vendor Prefix or Class of Service	7-41
Preprovisioning PacketCable eMTA/eDVA	7-42
SNMP Cloning on PacketCable eMTA/eDVA	7-44
Incremental Provisioning of PacketCable eMTA/eDVA	7-45
Preprovisioning DOCSIS Modems with Dynamic Configuration Files	7-48
Optimistic Locking	7-49
Temporarily Throttling a Subscriber's Bandwidth	7-51
Preprovisioning CableHome WAN-MAN	7-53
CableHome with Firewall Configuration	7-54
Retrieving Device Capabilities for CableHome WAN-MAN	7-56
Self-Provisioning CableHome WAN-MAN	7-57
RBAC Administration and Operational Access Control	7-59
Update Protection for Properties at Device Level	7-65
Domain Administration and Instance Level Access Control	7-68
CRS Management	7-74

**CHAPTER 8****Provisioning Web Services (PWS) 8-1**

Overview 8-1

PWS Concepts 8-2

- PWS Data Types 8-2
- PWS Operations 8-6
  - Session Operations 8-6
  - Device Provisioning Operations 8-7
  - DeviceType Operations 8-17
  - Generic Device Operation 8-19
  - Class Of Service Operations 8-20
  - DHCP Criteria Operations 8-22
  - File Operations 8-25
  - Group Operations 8-28
  - Custom Property Operations 8-30
  - pollOperation Status 8-31
  - Search Operation 8-32
- PWS Use Cases - SOAP 8-33
  - Registering a New Device 8-34
  - Unregistering a Device 8-39
  - Getting DHCP Lease Information of a Device 8-41
  - Updating Device Details 8-46
  - Searching a Device 8-50
  - Supported Query Elements 8-53
  - Deleting a Device 8-55
  - Multiple Devices Operations in a Single Request 8-57
  - Reboot of Device or Devices 8-77
- PWS Use Cases - RESTful 8-79
  - Registering a New Device 8-80
  - Unregistering a Device 8-84
  - Getting DHCP Lease Information of a Device 8-86
  - Updating Device Details 8-89
  - Searching a Device 8-93
  - Supported Query Elements 8-97
  - Deleting a Device 8-100
  - Multiple Devices Operations in a Single Request 8-102
  - Reboot of Device or Devices 8-108

---

**GLOSSARY**

---

**INDEX**