



## Fiber and Connector Losses in Raman Link Configuration

[Fiber and Connector Losses in Raman Link Configuration](#) 2

[Limit for Connector Losses](#) 2

[Additional References](#) 3

[Short Description](#) 3

[Communications, Services, and Additional Information](#) 3

# Fiber and Connector Losses in Raman Link Configuration

This document provides important guidelines to be followed when configuring a Raman link regardless of whether you are configuring the Raman link using the Raman installation wizard or the Cisco Transport Planner (CTP) XML file. Ensuring the desired gain and gain flatness is critical to the success of the configuration.

The Raman installation wizard automatically addresses any deviation in connector and fiber splice loss values by displaying warning messages appropriately, provided they are within the limits detailed in [Table 1: Limit for Connector Losses, on page 2](#). However, configuration of the Raman link using the CTP XML file is based on the algorithms within CTP. Any deviation in the connector and fiber splice losses values leads to unpredictable behavior of the entire system, in terms of Raman tilt and optical signal-to-noise ratio (OSNR). For these reasons, configuring the Raman link using the Raman installation wizard is preferred than configuring using the CTP XML file.

[Table 1: Limit for Connector Losses, on page 2](#) contains the following fields:

- Conditions—Limit for connector losses were measured under the following conditions:
  - No splice losses—Ideal conditions.
  - Splice 0.1 dB every 2 km or 0.2 dB splice every 4 km—The maximum acceptable values that can be considered when configuring Raman link.
  - Splice 0.1 dB every 4 km—The limit for connector losses values shows a realistic situation.
- Fiber type—The various fiber types used are:
  - Single Mode Fiber (SMF)
  - Enhanced large effective area fiber (ELEAF)
  - TrueWave RS (TW-RS)
- Target Gain—Expected Raman gain.
- Minimum Span [dB]-For the Raman link configuration to be successful, the span loss should be equal or greater than the value shown in [Table 1: Limit for Connector Losses, on page 2](#).
- Limit for Connector Losses—Connector losses values that must not exceed for configuration to be successful.

## Limit for Connector Losses



**Note** [Table 1: Limit for Connector Losses, on page 2](#) shows values that were estimated under ideal test condition and may differ depending on the actual fiber type used, distance, etc.

**Table 1: Limit for Connector Losses**

Conditions	Fiber Type	Minimum Span Loss [dB]		Target Gain [dB]		Limit for Connector Losses (dB)
		OPT-RAMP-C	OPT-RAMP-CE	Min	Max	

No splice loss	SMF	21	15	7	8.5	1.6
	ELEAF	21	15	7	10	1.3
	TW-RS	24	18	9	13.5	1.1
Splice 0.1 dB every 2 km or 0.2 dB splice every 4 km	SMF	21	15	7	8.5	0.7
	ELEAF	21	15	7	10	0.5
	TW-RS	24	18	9	13.5	0.2
Splice 0.1 dB every 4 km	SMF	21	15	7	8.5	1.2
	ELEAF	21	15	7	10	0.9
	TW-RS	24	18	9	13.5	0.6

## Additional References

### Related Documents

Use this document in conjunction with the other release-specific documentation listed in this table:

### Technical Assistance

Link	Description
<a href="http://www.cisco.com/support">http://www.cisco.com/support</a>	<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>

## Short Description

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).

- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### **Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



**Americas Headquarters**  
Cisco Systems, Inc.  
San Jose, CA 95134-1706  
USA

**Asia Pacific Headquarters**  
CiscoSystems(USA)Pte.Ltd.  
Singapore

**Europe Headquarters**  
CiscoSystemsInternationalBV  
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).