



CHAPTER 7

CONN Commands

This chapter provides connect (CONN) commands for the Cisco ONS 15310-MA, Cisco ONS 15454, Cisco ONS 15454 M2, and Cisco ONS 15454 M6.



Note

All commands supported on the Cisco ONS 15454 platform are also supported on Cisco ONS 15454 M2 and Cisco ONS 15454 M6 platforms.

7.1 CONN-TACC-<MOD_TACC>

(Cisco ONS 15310-MA and Cisco ONS 15454) The Connect Test Access for DS1, DS3I, E1, E3, STS1, STS12C, STS18C, STS192C, STS24C, STS3C, STS48C, STS96C, STS6C, STS9C, T1, T3, VT1, or VT2 (CONN-TACC-<MOD_TACC> command connects the synchronous transport signal (STS) or Virtual Tributary (VT) defined by the access identifier (AID) to the STS specified by the test access point (TAP) number.

See [Table 28-1 on page 28-1](#) for supported modifiers by platform. For more information about TACC, refer to the *Cisco ONS SDH and Cisco ONS 15600 SDH TL1 Reference Guide*.

Usage Guidelines

For this command to be applicable, you must first create the TAP using the ED-<VC_PATH> or ED-VC12 command. Intrusive test access modes are traffic-affecting. If a facility/path is connected to a TAP in an intrusive test access mode, it is forced to go into the Locked-Maintenance state. The forced transition could be traffic-affecting. The present state of the facility/path is stored by the NE and is restored when the TAP connection is brought down. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

The following actions will return error messages:

- If all TAPs are busy, a RABY error message is returned.
- If a requested TAP is busy, a RTBY error message is returned.
- If a requested TAP does not exist, a RTEN error message is returned.
- If a circuit is already connected to another TAP, a SCAT error message is returned.
- If a requested condition already exists, a SRCN error message is returned.
- An invalid AID will return an Input, Invalid Access Identifier (IIAC) error message.
- If an access is not supported, an EANS error message is returned.
- If a requested access configuration is invalid, a SRAC error message is returned.

- You cannot connect a TACC to a cross-connect that is in pending roll.
- A connection can be made to a cross-connection, in which case all modes of access are supported. A connection to an Unmapped AID (an AID without a cross-connect on it) will allow only MONE, SPLTE, and LOOPE modes.
- A connection to the protect path of a 1+1, 1:1, or 1:N is not allowed; however, connecting to the PCA path of a two-fiber or four-fiber multiplex section-shared protection ring (MS-SPRing) is supported. This will be preempted when a MS-SPRing switch occurs.
- When you connect a TACC to a protect subnetwork connection protection (SNCP) trunk, you will always be connected to the working trunk instead.

Category

Troubleshooting and Test Access

Security

Maintenance

Input Format

CONN-TACC-<MOD_TACC>:[<TID>]:<SRC>:<CTAG>::<TAP>:MD=<MD>;

Input Example

CONN-TACC-ST51:CISCO:STS-2-1-4:123::8:MD=MONE;

Input Parameters

<SRC>	Source AID from the “26.1 ALL” section on page 26-1 . SRC must not be null.
<TAP>	The test access point number. The TAP number is used to identify all messages between the TSC and the NE until the access point is released. The TAP number must be an integer with a range of 1 to 999. The TAP must not be null.
<MD>	The test access mode. (SPLTE, SPLTF, LOOPE, and LOOPF require an external quasi-random signal [QRS] input signal.) Single facility access digroup (FAD) test access does not support MONEF, SPLTEF, and SPLTAB modes. MD must not be null. The parameter type is test access mode (TACC_MODE).
• LOOPE	Splits both the A and B paths. Connect the line incoming from E direction to the line outgoing in the E direction, and connect this looped configuration to the FAD. The line outgoing in the F direction will have a QRS connected, and the line incoming from the F direction will be terminated by the nominal characteristic impedance of the line. Intrusive test access mode.
• LOOPF	Splits both the A and B paths. Connects the line incoming from F direction to the line outgoing in the F direction, and connects this looped configuration to the FAD. The line outgoing in the E direction will have a QRS connected, and the line incoming from the E direction will be terminated by the nominal characteristic impedance of the line. Intrusive test access mode.
• MONE	Indicates that a monitor connection is to be provided from the FAD to the A transmission path of the accessed circuit.

• MONEF	Indicates that a monitor connection is to be provided from the FAD1 to a dual FAD (DFAD), or the odd pair of a facility access path (FAP), to the A transmission path, and from FAD2 of the same DFAD, or the even pair of a FAP, to the B transmission path of the accessed circuit.
• MONF	Indicates that a monitor connection is to be provided from the FAD to the B transmission path of the accessed circuit.
• SPLTA	Indicates that a connection is to be provided from both the E and F sides of the A transmission path of the circuit under test to the FAD and split the A transmission path. Intrusive test access mode.
• SPLTB	Indicates that a connection is to be provided from both the E and F sides of the B transmission path of the circuit under test to the FAD and split the B transmission path. Intrusive test access mode.
• SPLTE	Splits both the A and B paths and connects the E side of the accessed circuit to the FAD. The line outgoing in the F direction will have a QRS connected, the line incoming from the F direction will have a QRS connected, and the line incoming from the E direction will be terminated by the nominal characteristic impedance of the line. Intrusive test access mode.
• SPLTEF	Splits both the A and B paths, and connects the E side of the accessed circuit to FAD1 and the F side to FAD2. Intrusive test access mode.
• SPLTF	Splits both the A and B paths and connects the F side of the accessed circuit to the FAD. The line outgoing in the E direction will have a QRS connected, and the line incoming in the E direction will have a QRS connected. The line incoming from the E direction will be terminated by the nominal characteristic impedance of the line. Intrusive test access mode.

Output Format

```
SID DATE TIME
M CTAG COMPLD
"<TAP>"
;
```

Output Example

```
TID-000 1998-06-20 14:30:00
M 001 COMPLD
"8"
;
```

Output Parameters

<TAP>	The test access point number. The TAP number is used to identify all messages between TSC and NE until the access point is released. The TAP number must be an integer with a range of 1 to 999.
-------	--

