



# Performance Monitoring

This chapter describes the procedures to configure and view the performance monitoring parameters.

- [Performance Monitoring, on page 1](#)
- [Performance Monitoring for NCS1K14-2.4T-X-K9 Card, on page 21](#)
- [Performance Monitoring for NCS1K14-CCMD-16-C and NCS1K14-CCMD-16-L Cards, on page 21](#)
- [Configuring PM Parameters for NCS1K14-CCMD-16-C and NCS1K14-CCMD-16-L Cards, on page 22](#)

## Performance Monitoring

**Table 1: Feature History**

Feature Name	Release Information	Feature Description
Performance Monitoring Enhancements	Cisco IOS XR Release 24.4.1	<p>You can now view historical Performance Monitoring (PM) parameters for the past 1 to 7 days for the 24-hour interval on these controllers:</p> <ul style="list-style-type: none"> <li>• CoherentDSP</li> <li>• Ethernet</li> <li>• ODU-layer</li> </ul> <p>This feature enhances data collection directly from the equipment, providing a comprehensive view of performance over time.</p> <p>Parameter added:</p> <ul style="list-style-type: none"> <li>• <b>bucket</b> <i>value</i></li> </ul>

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of network issues. You can configure and retrieve PM counters for the various controllers in 30 second, 15-minute, or 24-hour flex-bin intervals. These parameters simplify troubleshooting operations and enhance data that can be collected directly from the equipment.



**Note** Downgrade to 7.11.1 or earlier releases from 24.1.1 can lead to a restart of the pm\_collector process. To avoid this, clear the PM historical data before the downgrade using the following commands:

```
process shutdown pm_collector
run
cd /misc/config
rm chkpt_pm_collector_*
exit
```

Use the following commands if you are already experiencing a continuous pm\_collector restart.

```
process shutdown pm_collector
run
cd /misc/config
rm chkpt_pm_collector_*
exit
process start pm_collector
```

## Configuring PM Parameters

You can configure and view the performance monitoring parameters for the Optics, Ethernet, odu-flex, and coherent DSP controllers.

To configure PM parameters, use the following commands.

### configure

**show controller** *controllertype R/S/I/P* { **pm** { **current** | **history** } { **30-sec 15-min** | | **24-hour** } { **optics** | **ether** | **fec** | **otn** | **prbs** } **linenumber** }

### commit

### Examples

The following is a sample in which the performance monitoring parameters of Optics controller are configured for 24-hour intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller optics 0/0/1/5 pm 24-hour optics threshold osnr max
345
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the performance monitoring parameters of the Ethernet controller are configured for 15-minute intervals.

```
RP/0/RP0/CPU0:chassisA164(config)#controller fourHundredGigECtrlr 0/1/0/4 pm 15-min ether
threshold rx-pkt 1
```

The following is a sample in which performance monitoring parameters of Coherent DSP controller are configured for 30-second intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/0/7 pm 30-sec fec threshold post-fec-ber
max OE-15
RP/0/RP0/CPU0:ios(config)#commit
```

## Viewing PM Parameters

To view the performance monitoring parameters for Optics, Ethernet, and Coherent DSP controllers, use the following command:

```
show controllers controllertype R/S/I/P { pm { current | history } { 30 sec | 15-min | 24-hour } { optics | ether | fec | otn | prbs} linenumber }
```

**Example 1:** The following command displays the current performance monitoring parameters of the Optics controller with 15-minute intervals:

```
RP/0/RP0/CPU0:ios#show controller optics 0/1/0/3 pm current 15-min optics 3
Fri Sep 22 13:53:37.120 IST
```

```
Optics in the current interval [13:45:00 - 13:53:37 Fri Sep 22 2023]
```

```
Optics current bucket type : Valid
      MIN      AVG      MAX      Operational      Configured      TCA      Operational
      Configured      TCA
      Threshold(max) (max)
      Threshold(min)      Threshold(min) (min) Threshold(max)
LBC[% ]      : 56.8      56.8      56.8      0.0      NA      NO      100.0
      NA      NO
OPT[dBm]      : -40.00      -40.00      -40.00      -30.00      NA      NO      63.32
      NA      NO
OPR[dBm]      : -40.00      -40.00      -40.00      -30.00      NA      NO      63.32
      NA      NO
```

**Example 2:** The following command displays the current performance monitoring parameters of the client Optics controller with 15-minute intervals:

```
RP/0/RP0/CPU0:ios#show controller optics 0/2/0/1 pm current 15-min optics 1
Fri Sep 22 13:56:52.123 IST
```

```
Optics in the current interval [13:45:00 - 13:56:52 Fri Sep 22 2023]
```

```
Optics current bucket type : Valid
      MIN      AVG      MAX      Operational      Configured      TCA      Operational
      Configured      TCA
      Threshold(max) (max)
      Threshold(min)      Threshold(min) (min) Threshold(max)
LBC[% ]      : 24.8      25.7      26.7      0.0      NA      NO      100.0
      NA      NO
OPT[dBm]      : -0.12      -0.00      0.11      -30.00      NA      NO      63.32
      NA      NO
OPR[dBm]      : -0.67      -0.46      -0.24      -30.00      NA      NO      63.32
      NA      NO
```

**Example 3:** The following command displays the current performance monitoring parameters of the client Ethernet controller with 15-minute intervals:

```
RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctr1r 0/0/0/4 pm current 15-min ether
ETHER in the current interval [16:15:00 - 16:18:44 Fri Nov 17 2023]
ETHER current bucket type : Valid
  RX-UTIL[%]      : 0.00      Threshold : 0.00      TCA(enable) :
NO
  TX-UTIL[%]      : 0.00      Threshold : 0.00      TCA(enable) :
NO
  RX-PKT      : 0      Threshold : 0      TCA(enable) :
NO
  STAT-PKT      : 0      Threshold : 0      TCA(enable) :
NO
  OCTET-STAT      : 0      Threshold : 0      TCA(enable) :
NO
  OVERSIZE-PKT      : 0      Threshold : 0      TCA(enable) :
```

NO				
FCS-ERR	: 0	Threshold : 0	TCA(enable) :	
NO				
LONG-FRAME	: 0	Threshold : 0	TCA(enable) :	
NO				
JABBER-STATS	: 0	Threshold : 0	TCA(enable) :	
NO				
64-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
65-127-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
128-255-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
256-511-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
512-1023-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
1024-1518-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
IN-UCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
IN-MCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
IN-BCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT-UCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT-BCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT-MCAST	: 0	Threshold : 0	TCA(enable) :	
NO				
TX-PKT	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT-OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
IFIN-ERRORS	: 0	Threshold : 0	TCA(enable) :	
NO				
IFIN-OCTETS	: 0	Threshold : 0	TCA(enable) :	
NO				
STAT-MULTICAST-PKT	: 0	Threshold : 0	TCA(enable) :	
NO				
STAT-BROADCAST-PKT	: 0	Threshold : 0	TCA(enable) :	
NO				
STAT-UNDERSIZED-PKT	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_GOOD_BYTES	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_GOOD_PKTS	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_DROP_OTHER	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT_GOOD_BYTES	: 0	Threshold : 0	TCA(enable) :	
NO				
OUT_GOOD_PKTS	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_PKT_64_OCTET	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_PKTS_65_127_OCTETS	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_PKTS_128_255_OCTETS	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_PKTS_256_511_OCTETS	: 0	Threshold : 0	TCA(enable) :	
NO				
IN_PKTS_512_1023_OCTETS	: 0	Threshold : 0	TCA(enable) :	

```

NO
  IN_PKTS_1024_1518_OCTETS : 0          Threshold : 0          TCA(enable) :
NO
  OUT_PKT_64_OCTET         : 0          Threshold : 0          TCA(enable) :
NO
  OUT_PKTS_65_127_OCTETS  : 0          Threshold : 0          TCA(enable) :
NO
  OUT_PKTS_128_255_OCTETS : 0          Threshold : 0          TCA(enable) :
NO
  OUT_PKTS_256_511_OCTETS : 0          Threshold : 0          TCA(enable) :
NO
  OUT_PKTS_512_1023_OCTETS : 0         Threshold : 0          TCA(enable) :
NO
  OUT_PKTS_1024_1518_OCTETS : 0         Threshold : 0          TCA(enable) :
NO
  TX_UNDERSIZED_PKT       : 0          Threshold : 0          TCA(enable) :
NO
  TX_OVERSIZED_PKT       : 0          Threshold : 0          TCA(enable) :
NO
  TX_JABBER               : 0          Threshold : 0          TCA(enable) :
NO
  TX_BAD_FCS              : 0          Threshold : 0          TCA(enable) :
NO
  
```

**Example 4:** The following command displays the current performance monitoring for FEC for the Coherent DSP controller for FEC 15-minute intervals:

```

RP/0/RP0/CPU0:ios#show controller coherentDSP 0/2/0/0 pm current 15-min fec
Fri Sep 22 14:02:19.236 IST

g709 FEC in the current interval [14:00:00 - 14:02:19 Fri Sep 22 2023]

FEC current bucket type : Valid
  EC-BITS : 545156378205          Threshold : 5400000000000    TCA(enable) :
YES
  UC-WORDS : 0                    Threshold : 5                TCA(enable) :
YES

Threshold      TCA          MIN      AVG      MAX      Threshold      TCA
(max)          (enable)          (min)      (enable)
PreFEC BER    : 5.19E-03  5.36E-03  6.09E-03  0E-15          NO
  0E-15      NO
PostFEC BER   : 0E-15    0E-15    0E-15    0E-15          NO
  0E-15      NO
Q[dB]         : 8.10     8.10     8.10     0.00          NO
  0.00       NO
Q_Margin[dB]  : 2.10     2.10     2.10     0.00          NO
  0.00       NO
Instantaneous Q_Margin [dB] : 1.70     1.77     1.80     0.00          NO
  0.00       NO
  
```

**Example 5:** The following command displays the current performance monitoring parameters for PRBS of the Coherent DSP controller with 15-minute intervals:

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/7 pm current 15-min prbs
Mon Feb 13 00:58:48.327 UTC
PRBS in the current interval [00:45:00 - 00:58:48 Mon Feb 13 2019]
PRBS current bucket type : Valid
EBC : 40437528165
FOUND-COUNT : 1 FOUND-AT-TS : 00:51:22 Mon Feb 13 2019
LOST-COUNT : 1 LOST-AT-TS : 00:52:52 Mon Feb 13 2019
CONFIG-PTRN : PRBS_PATTERN_PN31
Last clearing of "show controllers OTU" counters never
  
```

**Example 6:** The following command displays the current performance monitoring of PCS of the Ethernet controller with 30-second intervals:

```
RP/0/RP0/CPU0:ios#show controllers hundredGigEctrlr 0/1/0/2/1 pm current 30-sec pcs
Fri Sep 22 14:04:33.676 IST
```

```
Ethernet PCS in the current interval [14:04:30 - 14:04:33 Fri Sep 22 2023]
```

```
Ethernet PCS current bucket type : Valid
BIP[00] : 0 Threshold : 0
  TCA(enable) : NO
BIP[01] : 0 Threshold : 0
  TCA(enable) : NO
BIP[02] : 0 Threshold : 0
  TCA(enable) : NO
BIP[03] : 0 Threshold : 0
  TCA(enable) : NO
BIP[04] : 0 Threshold : 0
  TCA(enable) : NO
BIP[05] : 0 Threshold : 0
  TCA(enable) : NO
BIP[06] : 0 Threshold : 0
  TCA(enable) : NO
BIP[07] : 0 Threshold : 0
  TCA(enable) : NO
BIP[08] : 0 Threshold : 0
  TCA(enable) : NO
BIP[09] : 0 Threshold : 0
  TCA(enable) : NO
BIP[10] : 0 Threshold : 0
  TCA(enable) : NO
BIP[11] : 0 Threshold : 0
  TCA(enable) : NO
BIP[12] : 0 Threshold : 0
  TCA(enable) : NO
BIP[13] : 0 Threshold : 0
  TCA(enable) : NO
BIP[14] : 0 Threshold : 0
  TCA(enable) : NO
BIP[15] : 0 Threshold : 0
  TCA(enable) : NO
BIP[16] : 0 Threshold : 0
  TCA(enable) : NO
BIP[17] : 0 Threshold : 0
  TCA(enable) : NO
BIP[18] : 0 Threshold : 0
  TCA(enable) : NO
BIP[19] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[00] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[01] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[02] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[03] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[04] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[05] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[06] : 0 Threshold : 0
  TCA(enable) : NO
FRM-ERR[07] : 0 Threshold : 0
```

TCA(enable) : NO		
FRM-ERR[08]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[09]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[10]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[11]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[12]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[13]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[14]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[15]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[16]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[17]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[18]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[19]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[00]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[01]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[02]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[03]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[04]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[05]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[06]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[07]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[08]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[09]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[10]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[11]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[12]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[13]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[14]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[15]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[16]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[17]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[18]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[19]	: 0	Threshold : 0

```

TCA(enable) : NO
ES : 0 Threshold : 0
TCA(enable) : NO
SES : 0 Threshold : 0
TCA(enable) : NO
UAS : 0 Threshold : 0
TCA(enable) : NO
ES-FE : 0 Threshold : 0
TCA(enable) : NO
SES-FE : 0 Threshold : 0
TCA(enable) : NO
UAS-FE : 0 Threshold : 0
TCA(enable) : NO

```

**Example 7:** The following command displays the history performance monitoring of PCS of the Ethernet controller with 30-second intervals:

```
RP/0/RP0/CPU0:ios#show controllers hundredGigECtrlr 0/1/0/2/1 pm history 30-sec pcs 1
Fri Sep 22 14:06:14.193 IST
```

```
Ethernet PCS in the current interval [14:05:30 - 14:06:00 Fri Sep 22 2023]
```

```
Ethernet PCS current bucket type : Valid
```

```

BIP[00] : 0
BIP[01] : 0
BIP[02] : 0
BIP[03] : 0
BIP[04] : 0
BIP[05] : 0
BIP[06] : 0
BIP[07] : 0
BIP[08] : 0
BIP[09] : 0
BIP[10] : 0
BIP[11] : 0
BIP[12] : 0
BIP[13] : 0
BIP[14] : 0
BIP[15] : 0
BIP[16] : 0
BIP[17] : 0
BIP[18] : 0
BIP[19] : 0
FRM-ERR[00] : 0
FRM-ERR[01] : 0
FRM-ERR[02] : 0
FRM-ERR[03] : 0
FRM-ERR[04] : 0
FRM-ERR[05] : 0
FRM-ERR[06] : 0
FRM-ERR[07] : 0
FRM-ERR[08] : 0
FRM-ERR[09] : 0
FRM-ERR[10] : 0
FRM-ERR[11] : 0
FRM-ERR[12] : 0
FRM-ERR[13] : 0
FRM-ERR[14] : 0
FRM-ERR[15] : 0
FRM-ERR[16] : 0
FRM-ERR[17] : 0
FRM-ERR[18] : 0
FRM-ERR[19] : 0
BAD-SH[00] : 0
BAD-SH[01] : 0

```



```

BAD-SH[02]          : 0
BAD-SH[03]          : 0
BAD-SH[04]          : 0
BAD-SH[05]          : 0
BAD-SH[06]          : 0
BAD-SH[07]          : 0
BAD-SH[08]          : 0
BAD-SH[09]          : 0
BAD-SH[10]          : 0
BAD-SH[11]          : 0
BAD-SH[12]          : 0
BAD-SH[13]          : 0
BAD-SH[14]          : 0
BAD-SH[15]          : 0
BAD-SH[16]          : 0
BAD-SH[17]          : 0
BAD-SH[18]          : 0
BAD-SH[19]          : 0
ES                  : 0
SES                 : 0
UAS                 : 0
ES-FE               : 0
SES-FE              : 0
UAS-FE              : 0

```

**Example 8:** The following command displays the current performance monitoring parameters of the trunk optics controller with 10-second intervals as flexi-bin:

```

RP/0/RP0/CPU0:ios#show controllers optics 0/1/0/0 pm current flex-bin optics 1
Fri Sep 22 14:08:37.001 IST

```

Optics in the current interval [14:08:30 - 14:08:36 Fri Sep 22 2023]

Flexible bin interval size: 10 seconds

Optics current bucket type : Valid

	MIN	AVG	MAX	Operational	Configured	TCA	Operational
	Configured	TCA		Threshold(min)	Threshold(min)	(min)	Threshold(max)
LBC[%]	: 0.0	0.0	0.0	0.0	NA	NO	0.0
	NA	NO					
OPT[dBm]	: -1.53	-1.49	-1.45	0.00	NA	NO	0.00
	NA	NO					
OPR[dBm]	: -1.62	-1.61	-1.57	0.00	NA	NO	0.00
	NA	NO					
CD[ps/nm]	: 2	2	3	0	NA	NO	0
	NA	NO					
DGD[ps]	: 3.00	3.00	3.00	0.00	NA	NO	0.00
	NA	NO					
SOPMD[ps^2]	: 9.00	21.57	40.00	0.00	NA	NO	0.00
	NA	NO					
OSNR[dB]	: 37.90	37.90	37.90	0.00	NA	NO	0.00
	NA	NO					
PDL[dB]	: 1.10	1.10	1.10	0.00	NA	NO	0.00
	NA	NO					
PCR[rad/s]	: 0.00	26.29	93.00	0.00	NA	NO	0.00
	NA	NO					
RX_SIG[dBm]	: -2.14	-2.09	-2.05	0.00	NA	NO	0.00
	NA	NO					
FREQ_OFF[Mhz]	: 873	902	938	0	NA	NO	0
	NA	NO					
SNR[dB]	: 20.90	20.97	21.10	0.00	NA	NO	0.00
	NA	NO					
SNR-AX[dB]	: 20.90	21.00	21.10	0.00	NA	NO	0.00

```

          NA          NO
SNR-AY[dB] : 20.90    20.99    21.00    0.00          NA          NO    0.00
          NA          NO
SNR-BX[dB] : 19.20    19.40    19.60    0.00          NA          NO    0.00
          NA          NO
SNR-BY[dB] : 19.30    19.40    19.50    0.00          NA          NO    0.00
          NA          NO
SOP-S1     : 0.00     1.09     2.55     0.00          NA          NO    0.00
          NA          NO
SOP-S2     : 0.31     0.32     0.33     0.00          NA          NO    0.00
          NA          NO
SOP-S3     : 0.94     0.94     0.94     0.00          NA          NO    0.00
          NA          NO

```

**Example 9:** The following command displays the history performance monitoring parameters of the trunk optics controller with 10-second intervals as flexi-bin.

```
RP/0/RP0/CPU0:ios#show controllers optics 0/1/0/0 pm history flex-bin optics 1 bucket 1
Fri Sep 22 14:09:54.425 IST
```

```
Optics in interval 1 [14:09:40 - 14:09:50 Fri Sep 22 2023]
```

```
Flexible bin interval size: 10 seconds
```

```
Optics history bucket type : Valid
```

	MIN	AVG	MAX
LBC[% ]	0.0	0.0	0.0
OPT[dBm]	-1.52	-1.49	-1.47
OPR[dBm]	-1.63	-1.59	-1.55
CD[ps/nm]	1	1	2
DGD[ps ]	2.00	2.70	3.00
SOPMD[ps^2]	4.00	14.00	27.00
OSNR[dB]	37.90	37.90	37.90
PDL[dB]	1.10	1.10	1.10
PCR[rad/s]	0.00	16.00	96.00
RX_SIG[dBm]	-2.13	-2.08	-2.02
FREQ_OFF[Mhz]	833	870	916
SNR[dB]	20.80	20.94	21.10
SNR-AX[dB]	20.80	20.97	21.10
SNR-AY[dB]	20.90	20.93	21.10
SNR-BX[dB]	19.30	19.42	19.50
SNR-BY[dB]	19.20	19.42	19.50
SOP-S1	0.00	1.53	2.55
SOP-S2	0.30	0.32	0.33
SOP-S3	0.94	0.94	0.95

**Example 10:** The following command displays the current performance monitoring parameters of the coherentDSP controller as flexi-bin:

```
RP/0/0/CPU0:ios#show controllers coherentDSP 0/1/0/0 pm current flex-bin fec
Fri Sep 22 14:11:11.213 IST
```

```
g709 FEC in the current interval [14:11:10 - 14:11:10 Fri Sep 22 2023]
```

```
Flexible bin interval size: 10 seconds
```

```
FEC current bucket type : Valid
```

EC-BITS	: 2532544513	Threshold : 0	TCA(enable) :
NO			
UC-WORDS	: 0	Threshold : 0	TCA(enable) :
NO			

Threshold	TCA	MIN	AVG	MAX	Threshold	TCA
					(min)	(enable)

	(max)	(enable)					
PreFEC BER			:	3.39E-03	3.44E-03	3.59E-03	0E-15 NO
0E-15		NO					
PostFEC BER			:	0E-15	0E-15	0E-15	0E-15 NO
0E-15		NO					
Q[dB]			:	8.60	8.60	8.60	0.00 NO
0.00		NO					
Q_Margin[dB]			:	2.60	2.60	2.60	0.00 NO
0.00		NO					
Instantaneous Q_Margin [dB]			:	2.30	2.30	2.30	0.00 NO
0.00		NO					

**Example 11:** The following command displays the current performance monitoring FEC parameters of the coherentDSP OTN with 15-minute intervals:

```
show controllers coherentDSP 0/0/0/7 pm current 15-min otn
Fri Nov 17 16:33:50.820 UTC
g709 OTN in the current interval [16:30:00 - 16:33:50 Fri Nov 17 2023]
OTN current bucket type : Valid
ES-NE : 0 Threshold : 500 TCA(enable) : YES
ESR-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
SES-NE : 0 Threshold : 500 TCA(enable) : YES
SESR-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
UAS-NE : 0 Threshold : 500 TCA(enable) : YES
BBE-NE : 0 Threshold : 10000 TCA(enable) : YES
BBER-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
FC-NE : 0 Threshold : 10 TCA(enable) : YES

ES-FE : 0 Threshold : 500 TCA(enable) : YES
ESR-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
SES-FE : 0 Threshold : 500 TCA(enable) : YES
SESR-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
UAS-FE : 0 Threshold : 500 TCA(enable) : YES
BBE-FE : 0 Threshold : 10000 TCA(enable) : YES
BBER-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
FC-FE : 0 Threshold : 10 TCA(enable) : YES
```

**Example 12:** The following command displays the current performance monitoring for OTN parameters of the ODU-Flex with 15-minute intervals:

```
RP/0/RP0/CPU0:ios#show controllers odu-flex 0/0/0/7/4 pm current 15-min otn pathmonitor
Fri Nov 17 16:44:34.849 UTC
g709 OTN in the current interval [16:30:00 - 16:44:34 Fri Nov 17 2023]
OTN current bucket type : Valid
ES-NE : 0 Threshold : 87 TCA(enable) : YES
ESR-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
SES-NE : 0 Threshold : 1 TCA(enable) : YES
SESR-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
UAS-NE : 0 Threshold : 3 TCA(enable) : YES
BBE-NE : 0 Threshold : 85040 TCA(enable) : YES
BBER-NE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
FC-NE : 0 Threshold : 10 TCA(enable) : YES

ES-FE : 0 Threshold : 87 TCA(enable) : YES
ESR-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
SES-FE : 0 Threshold : 1 TCA(enable) : YES
SESR-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
UAS-FE : 0 Threshold : 3 TCA(enable) : YES
BBE-FE : 0 Threshold : 85040 TCA(enable) : YES
BBER-FE : 0.00000 Threshold : 0.00000 TCA(enable) : NO
FC-FE : 0 Threshold : 10 TCA(enable) : YES
```

**Example 13:** Displays the current performance monitoring parameters of the coherentDSP with 15-minute intervals FEC:

```
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/7 pm current 15-min fec
Fri Nov 17 16:16:05.276 UTC

g709 FEC in the current interval [16:15:00 - 16:16:05 Fri Nov 17 2023]

FEC current bucket type : Valid
  EC-BITS   : 19795040790          Threshold : 5400000000000          TCA(enable) :
YES
  UC-WORDS  : 0                   Threshold : 5                          TCA(enable) :
YES

Threshold      TCA                MIN      AVG      MAX      Threshold      TCA
(max)          (enable)                (min)    (min)    (min)    (min)    (enable)
PreFEC BER    : 2.70E-04  2.79E-04  2.88E-04  0E-15          NO
  0E-15      NO
PostFEC BER   : 0E-15    0E-15    0E-15    0E-15          NO
  0E-15      NO
Q[dB]         : 10.70   10.70   10.70    0.00          NO
  0.00       NO
Q_Margin[dB]  : 4.40    4.45   4.50    0.00          NO
  0.00       NO
Instantaneous Q_Margin [dB] : 4.40   4.45   4.50    0.00          NO
  0.00       NO
```

**Example 14:** The following command displays the current performance monitoring parameters of the Ethernet controller with 15-minute intervals for FEC.

```
RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctr1r 0/0/0/1 pm current 15-min fec

Ethernet FEC in the current interval [11:30:00 - 11:31:00 Mon Oct 30 2023]

FEC current bucket type : Valid
  EC-WORDS   : 8406          Threshold : 0                          TCA(enable) :
NO
  UC-WORDS   : 0            Threshold : 0                          TCA(enable) :
NO
```

**Example 15:** The following command displays the current performance monitoring parameters of the trunk optics with 15-minute intervals.

```
RP/0/RP0/CPU0:ios#show controllers optics 0/0/0/7 pm current 15-min optics 1
Optics in the current interval [16:00:00 - 16:11:43 Fri Nov 17 2023]
Optics current bucket type : Valid

MIN      AVG      MAX      Operational      Configured      TCA      Operational
Configured      TCA                Threshold(min)  Threshold(min)  (min)  Threshold(max)
Threshold(max) (max)
LBC[% ]      : 0.0      0.0      0.0      5.0              NA              NO      85.0
  NA          NO
OPT[dBm]     : 1.96     2.01     2.04     -12.01           NA              NO      4.00
  NA          NO
OPR[dBm]     : -0.55    -0.46    -0.35    -14.09           NA              NO      11.00
  NA          NO
CD[ps/nm]    : -1       0        0        -9700            NA              NO      46560
  NA          NO
DGD[ps ]     : 0.00     1.00     1.00     0.00             NA              NO      81.00
  NA          NO
SOPMD[ps^2]  : 2.00     24.45    93.00    0.00             NA              NO      60000.00
  NA          NO
OSNR[dB]     : 37.90    39.11    40.70    21.50            NA              NO      99.00
  NA          NO
PDL[dB]      : 1.70     1.91     2.10     0.00             NA              NO      3.00
  NA          NO
```

```

PCR[rad/s] : 0.00      0.00      0.00      0.00      NA      NO      2500000.00
  NA      NO
RX_SIG[dBm] : -1.07     -0.78     -0.64     -15.09     NA      NO      3.00
  NA      NO
FREQ_OFF[Mhz]: -112      -51       14       -3200     NA      NO      3200
  NA      NO
SNR[dB] : 17.20      17.48     17.70     0.00     NA      NO      100.00
  NA      NO
SNR-X[dB] : 17.40      17.67     18.00     0.00     NA      NO      300.00
  NA      NO
SNR-Y[dB] : 17.00      17.31     17.60     0.00     NA      NO      300.00
  NA      NO
SOP-S1 : 0.00      0.00      0.00     -1.00     NA      NO      1.00
  NA      NO
SOP-S2 : 0.00      0.00      0.00     -1.00     NA      NO      1.00
  NA      NO
SOP-S3 : 0.00      0.00      0.00     -1.00     NA      NO      1.00
  NA      NO

```

**Example 16:** Displays the current performance monitoring parameters of the client optics with 15-minute intervals.

```

RP/0/RP0/CPU0:ios#show controllers optics 0/0/0/4 pm current 15-min optics 1
Fri Nov 17 16:13:38.671 UTC

```

```

Optics in the current interval [16:00:00 - 16:13:38 Fri Nov 17 2023]

```

```

Optics current bucket type : Valid

```

	MIN Configured	AVG TCA	MAX	Operational Threshold(min)	Configured Threshold(min)	TCA (min)	Operational Threshold(max)
LBC[%]	83.3	83.3	83.3	0.0	NA	NO	100.0
OPT[dBm]	1.23	1.23	1.23	-2.01	NA	NO	4.00
OPR[dBm]	1.19	1.21	1.24	-5.00	NA	NO	4.00

**Example 17:** Displays the current performance monitoring parameters of the client with 15-minute intervals PCS.

```

RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctrlr 0/0/0/4 pm current 15-min pcs
Ethernet PCS in the current interval [16:15:00 - 16:26:15 Fri Nov 17 2023]

```

```

Ethernet PCS current bucket type : Valid

```

```

BIP[00] : 0      Threshold : 0
  TCA(enable) : NO
BIP[01] : 0      Threshold : 0
  TCA(enable) : NO
BIP[02] : 0      Threshold : 0
  TCA(enable) : NO
BIP[03] : 0      Threshold : 0
  TCA(enable) : NO
BIP[04] : 0      Threshold : 0
  TCA(enable) : NO
BIP[05] : 0      Threshold : 0
  TCA(enable) : NO
BIP[06] : 0      Threshold : 0
  TCA(enable) : NO
BIP[07] : 0      Threshold : 0
  TCA(enable) : NO
BIP[08] : 0      Threshold : 0
  TCA(enable) : NO
BIP[09] : 0      Threshold : 0
  TCA(enable) : NO

```

BIP[10]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[11]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[12]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[13]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[14]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[15]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[16]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[17]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[18]	: 0	Threshold : 0
TCA(enable) : NO		
BIP[19]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[00]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[01]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[02]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[03]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[04]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[05]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[06]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[07]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[08]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[09]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[10]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[11]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[12]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[13]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[14]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[15]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[16]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[17]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[18]	: 0	Threshold : 0
TCA(enable) : NO		
FRM-ERR[19]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[00]	: 0	Threshold : 0
TCA(enable) : NO		
BAD-SH[01]	: 0	Threshold : 0
TCA(enable) : NO		

```

BAD-SH[02]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[03]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[04]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[05]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[06]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[07]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[08]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[09]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[10]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[11]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[12]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[13]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[14]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[15]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[16]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[17]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[18]           : 0           Threshold : 0
  TCA(enable) : NO
BAD-SH[19]           : 0           Threshold : 0
  TCA(enable) : NO
ES                   : 0           Threshold : 0
  TCA(enable) : NO
SES                 : 0           Threshold : 0
  TCA(enable) : NO
UAS                 : 0           Threshold : 0
  TCA(enable) : NO
ES-FE               : 0           Threshold : 0
  TCA(enable) : NO
SES-FE              : 0           Threshold : 0
  TCA(enable) : NO
UAS-FE              : 0           Threshold : 0
  TCA(enable) : NO

```

**Example 18:** Displays the FEC performance monitoring parameters of the Ethernet controllers for various time intervals.

From Release 24.2.11, the **show controllers** command output displays post FEC BER and pre FEC BER for the Ethernet controllers of the 2.4T and 2.4TX cards.

```

RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctr1r 0/1/0/4 pm current flex-bin fec
Mon Dec 18 11:30:29.101 UTC

Ethernet FEC in the current interval [11:30:20 - 11:30:28 Mon Dec 18 2023]

Flexible bin interval size: 10 seconds

FEC current bucket type : Valid
  EC-WORDS   : 11174           Threshold : 0           TCA(enable) : NO

```

```

UC-WORDS : 0
Threshold : 0
TCA(enable) : NO

MIN AVG MAX Threshold TCA Threshold TCA
(min) (enable) (max) (enable)
PreFEC BER: 2.8E-09 2.9E-09 3.1E-09 0E-15 NO 0E-15 NO
PostFEC BER: 0E-15 0E-15 0E-15 0E-15 NO 0E-15 NO

```

```

RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctrlr 0/1/0/4 pm history flex-bin fec 1
Mon Dec 18 11:48:04.229 UTC

```

```

Ethernet FEC in interval 1 [11:47:50 - 11:48:00 Mon Dec 18 2023]

```

```

Flexible bin interval size: 10 seconds

```

```

FEC history bucket type : Valid

```

```

EC-WORDS : 12128

```

```

UC-WORDS : 0

```

```

MIN AVG MAX
PreFEC BER : 2.6E-09 2.9E-09 3.0E-09
PostFEC BER: 0E-15 0E-15 0E-15

```

## Instantaneous Q-Margin

### Scenarios on Instantaneous Q-margin

In the following scenarios, the initial few PM buckets are displayed as valid although the instantaneous Q-margin values are displayed as invalid in those buckets. The PM is performed for 30 sec, 15 mins, and 24 hours, respectively.

- Shutdown or no shutdown on optics
- Trunk rate change
- Fiber cut

To overcome such situations, avoid the initial PM bucket readings while monitoring the instantaneous Q-margin values for these scenarios.

The following sample illustrates that the initial PM bucket readings for specified scenarios are invalid and at a later point the PM buckets readings are valid although the instantaneous Q-margin value is invalid.

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/0 pm history flex-bin fec 1
Fri Sep 22 14:17:01.008 IST

```

```

g709 FEC in interval 1 [14:16:50 - 14:17:00 Fri Sep 22 2023]

```

```

Flexible bin interval size: 10 seconds

```

```

FEC history bucket type : Valid

```

```

EC-BITS : 25615718133

```

```

UC-WORDS : 0

```

```

MIN AVG MAX
PreFEC BER : 3.37E-03 3.49E-03 3.90E-03
PostFEC BER : 0E-15 0E-15 0E-15
Q : 8.60 8.60 8.60
Q_margin : 2.50 2.56 2.60
Instantaneous Q_margin : 2.20 2.20 2.20

```



Now, the PM buckets are valid although the instantaneous Q-margin value is invalid.

```
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/0 pm history 30-sec fec 1
Sep 22 08:52:03.750 UTC
```

```
g709 FEC in interval 1 [08:51:50 - 08:52:00 Fri Sep 22 2023]
```

```
FEC history bucket type : Invlid
EC-BITS : 35072302421 UC-WORDS : 0
```

	MIN	AVG	MAX
PreFEC BER	5.20E-03	5.30E-03	5.64E-03
PostFEC BER	0E-15	0E-15	0E-15
Q	8.10	8.10	8.10
Q_margin	2.10	2.10	2.10
Instantaneous Q_margin	1.80	1.80	1.80

### Clearing PM Parameters

To clear the performance monitoring parameters for Ethernet and Coherent DSP controllers, use this command:

**clear controller *controllertype* R/S/I/P pm**

**Example 1:** Clears the PM parameters on the Coherent DSP controller.

```
RP/0/RP0/CPU0:ios#show controller coherentDSP 0/0/0/0 pm current 15-min fec
Fri Sep 22 14:28:12.100 IST
```

```
g709 FEC in the current interval [14:15:00 - 14:28:12 Fri Sep 22 2023]
```

```
FEC current bucket type : Valid
EC-BITS : 1159814176244 Threshold : 5400000000000 TCA(enable) :
YES
UC-WORDS : 0 Threshold : 5 TCA(enable) :
YES
```

Threshold	TCA	MIN	AVG	MAX	Threshold	TCA
(max)	(enable)				(min)	(enable)
PreFEC BER		0E-15	2.14E-03	2.28E-02	0E-15	NO
0E-15	NO					
PostFEC BER		0E-15	1.37E-10	6.59E-08	0E-15	NO
0E-15	NO					
Q[dB]		0.00	4.14	8.60	0.00	NO
0.00	NO					
Q_Margin[dB]		-6.00	-1.89	2.60	0.00	NO
0.00	NO					
Instantaneous Q_Margin [dB]		-21474836.48	-28144.25	2.30	0.00	
NO	0.00	NO				

```
Last clearing of "show controllers OTU" counters never
RP/0/RP0/CPU0:ios#clear controller coherentDSP 0/0/0/0 pm
Mon Jun 10 11:44:31.650 UTC
```

```
RP/0/RP0/CPU0:ios#show controller coherentDSP 0/0/0/0 pm current 15-min fec
Fri Sep 22 14:30:06.833 IST
```

```
g709 FEC in the current interval [14:30:00 - 14:30:06 Fri Sep 22 2023]
```

```
FEC current bucket type : Valid
EC-BITS : 17889249955 Threshold : 5400000000000 TCA(enable) :
YES
```

```

UC-WORDS : 0
Threshold : 5
TCA(enable) :
YES

Threshold TCA MIN AVG MAX Threshold TCA
(max) (enable) (min) (enable)
PreFEC BER : 3.38E-03 3.49E-03 3.85E-03 0E-15 NO
0E-15 NO
PostFEC BER : 0E-15 0E-15 0E-15 0E-15 NO
0E-15 NO
Q[dB] : 8.60 8.60 8.60 0.00 NO
0.00 NO
Q_Margin[dB] : 2.50 2.50 2.60 0.00 NO
0.00 NO
Instantaneous Q_Margin [dB] : 2.20 2.20 2.20 0.00 NO
0.00 NO

```

Last clearing of "show controllers OTU" counters 00:00:07

**Example 2:** To clear the PM parameters on the Ethernet controller, use the following command:

```
RP/0/RP0/CPU0:ios#clear controller HundredGigEctrlr 0/0/0/2/1 pm
```

### Viewing Ethernet Statistics

To view the PM statistics for the Ethernet controllers, use the following command:

```

RP/0/RP0/CPU0:ios#show controllers fourHundredGigEctrlr 0/0/0/4 stats
Fri Nov 17 16:28:34.138 UTC
Statistics for interface FourHundredGigEctrlr0/0/0/4 (cached values):
Ingress:
  Input total bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input good bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input total packets = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input 802.1Q frames = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pause frames = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 64 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 65-127 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 128-255 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 256-511 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 512-1023 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 1024-1518 bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input pkts 1519-Max bytes = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input good pkts = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input unicast pkts = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input multicast pkts = 0 Valid = False Start time =
13:12:29 Fri Nov 17 2023
  Input broadcast pkts = 0 Valid = False Start time =

```

```

13:12:29 Fri Nov 17 2023
  Input drop overrun          = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input drop abort           = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input drop invalid VLAN    = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input drop invalid DMAC    = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input drop invalid encap   = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input drop other           = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error giant          = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error runt           = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error jabbers        = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error fragments      = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error CRC            = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error collisions     = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error symbol         = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input error other          = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input MIB giant            = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input MIB jabber           = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Input MIB CRC              = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
Egress:
  Output total bytes         = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output good bytes          = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output total packets       = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output 802.1Q frames       = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pause frames        = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 64 bytes       = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 65-127 bytes   = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 128-255 bytes  = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 256-511 bytes  = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 512-1023 bytes = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 1024-1518 bytes = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output pkts 1519-Max bytes = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output good pkts           = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023
  Output unicast pkts        = 0          Valid = False   Start time =
13:12:29 Fri Nov 17 2023

```

```

Output multicast pkts      = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023
Output broadcast pkts     = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023
Output drop underrun      = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023
Output drop abort         = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023
Output drop other         = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023
Output error other        = 0          Valid = False      Start time =
13:12:29 Fri Nov 17 2023

```



**Note** Performance monitoring statistics are not supported for the input unicast packets, output unicast packets, and input error fragments counters for Ethernet clients.

### PM History Persistence

PM history parameters for Optics, Ethernet, and coherent DSP controllers are retained even after a line card cold reload, line card warm reload, XR reload, Calvados reload, RP reload, Hw-module all reload, power cycle, or upgrade of the NCS 1014 chassis.

After a software upgrade to the latest release, you can view the history performance monitoring parameters from the previous release. The PM history persistence is supported for 30-second, 15-minute, and 24-hour bucket types.

However, the following list describes the time that is required to fill all historical buckets of each bucket type, later while fetching PM historical data, no error appears.

- For 30-second bucket type, 15 minutes is required to fill 30 historical buckets.
- For 15-minute bucket type, 8 hours is required to fill 32 historical buckets.
- For 24-hour bucket type, 24 hours is required to fill 7 historical bucket.

PM counters are updated continuously in current bucket for all bucket types (flex, 30-second, 15-minute, and 24-hour). After the timer expires for the respective bucket type, the current PM data is moved to the historical PM bucket. This process of moving PM data to the historical bucket is called Rollover. After rollover, you can access the current PM data as historical PM data.

In case of deletion or removal of the controller, the PM data is persistent for 3 hours. Unless the controller is brought up within 3 hours, the PM data is cleared because the controller is considered to be not in use.

### Limitations

If NCS 1014 reload happens during the rollover time, one of the following scenarios occurs:

- Complete PM bucket is missing and the next PM bucket is marked as *Invalid*.
- PM bucket expiry message appears as follows:

```

RP/0/RP0/CPU0:ios#show controllers hundredGigECtrlr 0/3/0/2/2 pm history 30-sec ether
29
Fri Apr  1 01:32:20.646 UTC
History data is empty, Verify at least one collection period is expired

```

- PM bucket interval is marked as *Invalid* and counters are updated as zero.

- PM bucket interval is marked as *Invalid* and counters are updated as nonzero.

## Performance Monitoring for NCS1K14-2.4T-X-K9 Card

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of network issues. You can configure and retrieve PM counters for 30-second, 15-minute, or 24-hour intervals. These parameters simplify troubleshooting operations and enhance data that can be collected directly from the equipment.

### Limitations

On the 2.4TX card in the muxponder mode, PM parameters do not show the Runt and invalid Start Frame Delimiter (SFD) values for the split ports 2 and 3 for 600G and 1000G trunk rates respectively.

## Performance Monitoring for NCS1K14-CCMD-16-C and NCS1K14-CCMD-16-L Cards

Table 2: Feature History

Feature Name	Release Information	Feature Description
Supported Functionalities of CCMD-16-C and CCMD-16-L Line Cards	Cisco IOS XR Release 7.11.1	Supported Functionalities of CCMD-16-C and CCMD-16-L Line Cards: The software supports Variable Optical Attenuator (VoA), power monitoring and reporting of parameters to the controllers at the OCH and OMS level. It helps in configuring the amplifier parameters for optimizing signal transmissions.  The software also supports in-band and out-of-band tone detection and monitoring and reporting of alarms.

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of network issues. You can configure and retrieve PM counters for the OCH and OMS controllers in 30-second, 15-minute, 24-hour intervals or in 10-second flexible bin interval. These parameters simplify troubleshooting operations and enhance data that can be collected directly from the equipment.

### PM Parameters Supported on OMS Controller

The PM parameters that are supported on OMS controller are given below.

Table 3: PM Parameters Supported on OMS Controller

Controller	Supported PM Parameters	Description
------------	-------------------------	-------------

OMS	OPT (dBm)	Transmitted power
	OPR (dBm)	Received Power
	OPBR (dBm)	Back Reflection Power
	OPBRR (dB)	Back Reflection Ratio
	EAGN (dB)	Egress Ampli Gain
	EATL (dB)	Egress Ampli Tilt
	IAGN (dB)	Ingress Ampli Gain
IATL (dB)	Ingress Ampli Tilt	

### PM Parameters Supported on OCH Controller

The PM parameters that are supported on OCH controller are given below.

Controller	Supported PM Parameters	Description
OCH	OPT (dBm)	Transmitted Power
	OPR (dBm)	Received Power

## Configuring PM Parameters for NCS1K14-CCMD-16-C and NCS1K14-CCMD-16-L Cards

You can configure and view the performance monitoring parameters for the OMS and OCH controllers.

To configure minimum and maximum threshold for individual parameters, use the following commands.

### configure

```
controller controllertype R/S/I/P pm {30-sec | 15-min | 24-hour} optics threshold { parameter-name }
{max|min} {value}
```

### commit

To enable reporting of threshold crossing alarms for individual parameters, use the following commands.

### configure

```
controller controllertype R/S/I/P pm {30-sec | 15-min | 24-hour} optics report { parameter-name }
{min-tca|max-tca}
```

### commit

### Examples

The following is a sample with the performance monitoring parameters of OMS controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:(config)#controller oms 0/1/0/0 pm 30-sec optics threshold opt min < value >
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample with the performance monitoring parameters of OCH controller

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:(config)#controller och 0/1/0/1 pm 30-sec optics threshold opt min < value >
RP/0/RP0/CPU0:ios(config)#commit
```

### Viewing PM Parameters

To view the performance monitoring parameters for OMS and OCH controllers, use this command:

**show controllers *controllertype R/S/I/P* pm { current | history } { 30 sec | 15-min | 24-hour | flex-bin } optics { *linenumber* } *bucketvalue***

This example shows how to view PM parameters for OMS controller.

### Example

```
RP/0/RP0/CPU0:Tethys_P2A_DT_03#show controllers oms 0/1/0/0 pm current 30-sec optics 1
Optics in the current interval [15:02:30 - 15:02:36 Mon Nov 20 2023]

Optics current bucket type : Valid
      MIN      AVG      MAX      Operational      Configured      TCA      Operational
      Configured      TCA      Threshold(min)      Threshold(min)      (min)      Threshold(max)
      Threshold(max) (max)
OPT[dBm] : -8.30      -8.24      -8.20      -50.00      NA      NO      30.00
      NA      NO
OPR[dBm] : -1.80      -1.76      -1.60      -50.00      NA      NO      30.00
      NA      NO
OPBR[dBm] : -11.61      -11.61      -11.61      -50.00      NA      NO      -10.00
      NA      NO
OPBRR[dB] : -3.30      -3.30      -3.30      -50.00      NA      NO      0.00
      NA      NO
EAGN[dB] : 2.00      2.00      2.00      -3.00      NA      NO      22.00
      NA      NO
EATL[dB] : 0.00      0.00      0.00      -6.50      NA      NO      6.50
      NA      NO
IAGN[dB] : 5.00      5.00      5.00      0.00      NA      NO      10.00
      NA      NO
IATL[dB] : 0.00      0.00      0.00      -6.50      NA      NO      6.50
      NA      NO
```

Last clearing of "show controllers OPTICS" counters never

### View PM Parameters for OCH Controller

Examples for viewing PM parameters for OCH controller are given below:

#### Example 1

```
RP/0/RP0/CPU0:Tethys_P2A_DT_03#show controllers och 0/1/0/2 pm current 30-sec optics 1
Optics in the current interval [15:04:30 - 15:04:39 Mon Nov 20 2023]

Optics current bucket type : Valid
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
OPT[dBm] : -1.40 -1.36 -1.30 -50.00 NA NO 30.00 NA NO
OPR[dBm] : -5.80 -5.71 -5.70 -50.00 NA NO 30.00 NA NO
```

#### Example 2

```
RP/0/RP0/CPU0:Tethys_P2A_DT_03#show controllers och 0/1/0/2 pm current 15-min optics 1

Optics in the current interval [15:00:00 - 15:05:03 Mon Nov 20 2023]

Optics current bucket type : Valid
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
OPT[dBm] : -1.80 -1.50 -1.30 -50.00 NA NO 30.00 NA NO
OPR[dBm] : -5.80 -5.75 -5.70 -50.00 NA NO 30.00 NA NO

Last clearing of "show controllers OPTICS" counters never
```

## Viewing PM History Parameters

To view the performance monitoring parameters for OMS and OCH controllers, use this command:

```
show controllers controllertype R/S/I/P pm history { 30 sec | 15-min | 24-hour } [optics { lanenumber
}]bucket value
```

### Example 1

The following example shows how you can view the historical PM parameters on a Coherent DSP controller for the past 2 day for 24-hour interval.

```
RP/0/RP0/CPU0:Node164#show controllers coherentDSP 0/3/0/0 pm history 24-hour fec bucket 2
Sat Oct 19 13:55:13.872 IST

g709 FEC in interval 2 [00:00:00 - 24:00:00 Thu Oct 17 2024]

FEC history bucket type : valid
EC-BITS : 10121314105194 UC-WORDS : 0

                MIN                AVG                MAX
PreFEC BER      : 1.43E-04          1.51E-04          1.59E-04
PostFEC BER     : 0E-15              0E-15              0E-15
Q                : 11.10             11.19              11.20
Q_margin        : 4.70                4.79                4.80
Instantaneous Q_margin : 4.69          4.79                4.80

Last clearing of "show controllers OTU" counters never
```

### Example 2

The following example shows how you can view the historical PM parameters on a OMS controller for the 30 seconds interval.

```
RP/0/RP0/CPU0:Tethys_P2A_DT_02#show controllers oms 0/3/0/0 pm history 30-sec optics 1
bucket 1
Wed Dec 6 11:04:50.821 UTC

Optics in interval 1 [11:04:00 - 11:04:30 Wed Dec 6 2023]

Optics history bucket type : Valid
MIN AVG MAX
OPT[dBm] : -8.30 -8.27 -8.20
OPR[dBm] : -3.00 -1.62 -0.20
OPBR[dBm] : -11.61 -11.61 -11.51
OPBRR[dB] : -3.40 -3.31 -3.30
EAGN[dB] : 2.00 2.00 2.00
```



EATL [dB]	:	0.00	0.00	0.10
IAGN [dB]	:	5.00	5.00	5.00
IATL [dB]	:	0.00	0.00	0.00

