



Provider Backbone Bridge Commands

The IEEE 802.1ah standard (Ref [4]) provides a means for interconnecting multiple provider bridged networks in order to build a large scale end-to-end Layer 2 provider bridged network.

For detailed information about PBB concepts, configuration tasks, and examples, see the *L2VPN and Ethernet Services Configuration Guide for Cisco ASR 9000 Series Routers*.

- [backbone-source-mac](#), on page 3
- [bgp \(EVPN\)](#), on page 5
- [clear mmrp-flood-optimization statistics](#), on page 7
- [clear l2vpn forwarding counters bridge-domain mmrp location](#), on page 8
- [debug mmrp-flood-optimization packets](#), on page 9
- [debug mmrp-flood-optimization protocol](#), on page 10
- [ethernet-segment](#), on page 11
- [ethernet-segment \(evpn\)](#), on page 13
- [evi](#), on page 14
- [evpn](#), on page 15
- [evpn evi](#), on page 17
- [flushagain](#), on page 18
- [flood-time](#), on page 20
- [force single-homed](#), on page 21
- [identifier](#), on page 22
- [join-time \(PBB\)](#), on page 24
- [interface \(EVPN\)](#), on page 25
- [leaveall-time \(PBB\)](#), on page 27
- [leave-time \(PBB\)](#), on page 28
- [load-balancing-mode](#), on page 29
- [mmrp-flood-optimization](#), on page 31
- [mac-flush mvrp](#), on page 32
- [mode singleton](#), on page 33
- [pbb](#), on page 34
- [peering](#), on page 36
- [periodic transmit \(PBB\)](#), on page 38
- [programming](#), on page 39
- [recovery](#), on page 41
- [rewrite ingress tag push](#), on page 43

- [service-carving](#), on page 45
- [show evpn ethernet-segment](#), on page 47
- [show evpn evi](#), on page 50
- [show evpn summary](#), on page 54
- [show l2vpn bridge-domain pbb](#), on page 56
- [show l2vpn forwarding bridge pbb](#), on page 63
- [show l2vpn forwarding pbb backbone-source-mac](#), on page 65
- [show l2vpn pbb backbone-source-mac](#), on page 66
- [show mmrp-flood-optimization](#), on page 67
- [static-mac-address](#), on page 69
- [timers](#), on page 71
- [unknown-unicast-bmac](#), on page 73

backbone-source-mac

To configure the backbone source MAC address, use the **backbone-source-mac** command in pbb configuration mode or in the EVPN Interface Ethernet segment configuration mode. To return to the default behavior, use the **no** form of this command.



Note If the backbone source MAC address is not configured then one of the reserved addresses from the Chassis MAC pool is chosen automatically. To view the reserved address, use the **show l2vpn pbb backbone-source-mac** command.

backbone-source-mac *mac-address*
no backbone-source-mac *mac-address*

Syntax Description *mac address* Backbone source MAC address in hexadecimal format.

Command Default None

Command Modes PBB configuration
 EVPN Interface Ethernet segment configuration

Command History	Release	Modification
	Release 3.9.1	This command was introduced.
	Release 4.3.2	Support for this command in the EVPN Interface Ethernet segment configuration was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The command default in the EVPN Interface Ethernet segment configuration is the CE system-id with administrative bit flip. Use this command to overwrite the CE-system id of an Ethernet Segment. The backbone source MAC can be configured only on a bundle interface.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples In the following example, the backbone source MAC address is set to 0045.1200.04:

```
config
l2vpn
```

```

pbb
  backbone-source-mac 0045.1200.0400
!
!

```

This example shows how to set the backbone source MAC address in the EVPN Interface Ethernet segment configuration mode:

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# ethernet segment
RP/0/RSP0/CPU0:router(config-evpn-ac-es)# backbone-source-mac 0045.1200.0400
RP/0/RSP0/CPU0:router(config-evpn-ac-es)#

```

Related Commands	Command	Description
	pbb, on page 34	Configures the provider backbone bridge core or edge.
	evpn, on page 15	Enters EVPN configuration mode.
	interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
	ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.

bgp (EVPN)

To enable Border Gateway Protocol (BGP) in the PBB EVPN configuration, use the **bgp** command in the EVPN configuration or EVPN EVI configuration mode. To disable the BGP configuration, use the **no** form of this command.

```

bgp [rd]
bgp [{rd | route-target }]
no bgp
    
```

Syntax Description	rd	Sets the Route Distinguisher.
	route-target	Sets the Route Target.

Command Default None.

Command Modes EVPN configuration
EVPN EVI configuration

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The keyword **route-target** is supported only in the EVPN EVI BGP configuration.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to enable BGP in the EVPN configuration mode:

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# bgp
RP/0/RSP0/CPU0:router(config-evpn-bgp)#
    
```

This example shows how to enable BGP in the EVPN EVI configuration mode:

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# evi 2
    
```

```
RP/0/RSP0/CPU0:router(config-evpn-evi)# bgp  
RP/0/RSP0/CPU0:router(config-evpn-evi-bgp)#
```

Related Commands

Command	Description
evpn, on page 15	Enters EVPN configuration mode.
evi, on page 14	Enters the EVPN EVI configuration mode to configure optional BGP settings for a bridge domain or EVI.
route-target	Specifies a route target for the VFI, PBB EVPN or EVPN bridge domain.
rd	

clear mmrp-flood-optimization statistics

To clear the stored MRP protocol statistics on all the pseudowires or a specific pseudowire, use the **clear mmrp-flood-optimization statistics** command in the EXEC mode.

```
clear mmrp-flood-optimization statistics {all | pw pw-ID neighbor}
```

Syntax Description		
	all	Clear the stored MRP protocol statistics on all the pseudowires.
	pw	Indicates a specific pseudowire.
	<i>neighbor</i>	Indicates the IP address of the neighbor.
	<i>pw-id</i>	Indicates the pseudowire ID.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following command shows how to clear the MMRP flood optimization statistics:

```
RP/0/RSP0/CPU0:router#clear mmrp-flood-optimization statistics all
```

clear l2vpn forwarding counters bridge-domain mmrp location

To clear the MMRP flood statistics on a given bridge-domain on a specified location, use the **clear l2vpn forwarding counters bridge-domain mmrp location** command in the EXEC command.

clear l2vpn forwarding counters bridge-domain mmrp location *location*

Syntax Description	<i>location</i> Specifies the location in rack/slot/module notation.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operation
	ethernet-services	read, write

The following command shows how to clear the mmrp flood statistics on a given bridge-domain on a specified location:

```
RP/0/RSP0/CPU0:router#clear l2vpn forwarding counters bridge-domain mmrp location 0/1/1
```


debug mmrp-flood-optimization packets

To debug the flood optimization for PBB VPLS feature at the packet level, use the **debug mmrp-flood-optimization packets** command in the EXEC mode.

debug mmrp-flood-optimization packets {**brief** | **full** | **hexdump**} [**direction** {**received** | **sent**}] [**pw neighbor pw-id**]

Syntax Description		
brief		Brief packet debug.
full		Full packet debug.
hexdump		Raw packet output.
direction		Restricts output to a packet direction.
received		Packets received.
sent		Packets sent.
pw		Specifies a pseudowire to filter.
<i>neighbor</i>		IP address of the neighbor
<i>pw-id</i>		Pseudowire ID.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following command shows how to use the **debug mmrp-flood-optimization packets** command:

```
RP/0/RSP0/CPU0:router#debug mmrp-flood-optimization packets brief
```

debug mmrp-flood-optimization protocol

To debug the flood optimization for PBB VPLS feature at the protocol level, use the **debug mmrp-flood-optimization protocol** command in the EXEC mode.

debug mmrp-flood-optimization protocol [*isid isid*]

Syntax Description	isid Specifies the service instance identifier.
	<i>isid</i> Service instance identifier.

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operation
	ethernet-services	read, write

The following command shows how to use the debug mmrp-flood-optimization protocol command:

```
RP/0/RSP0/CPU0:router#debug mmrp-flood-optimization protocol isid 3
```

ethernet-segment

To enter the EVPN interface ethernet segment configuration mode, use the **ethernet-segment** command in the EVPN interface configuration mode. To disable the Ethernet segment configuration, use the **no** form of this command.

```
ethernet-segment [{backbone-source-mac | identifier | load-balancing-mode | service-carving}]
no ethernet-segment [{backbone-source-mac | identifier | load-balancing-mode | service-carving}]
```

Syntax Description	Parameter	Description
	backbone-source-mac	Specifies Backbone Source MAC.
	identifier	Specifies Ethernet Segment Identifier.
	load-balancing-mode	Specifies load balancing mode.
	service-carving	Specifies service carving.

Command Default None.

Command Modes EVPN interface configuration

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to enter the EVPN interface ethernet segment configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# ethernet-segment
RP/0/RSP0/CPU0:router(config-evpn-ac-es)#
```

Related Commands	Command	Description
	interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
	backbone-source-mac, on page 3	Configures the backbone source MAC address.

Command	Description
load-balancing-mode, on page 29	Sets the load balancing mode of a physical port or bundle to active-active.
service-carving, on page 45	Specifies the list of service identifiers as active and standby services.

ethernet-segment (evpn)

To disable ESI auto-generation value for LACP ESI type 1, use the **ethernet-segment** command in the EVPN configuration mode. To enable ESI auto-generation, use the **no** form of this command.

ethernet-segment type 1 auto-generation-disable
no ethernet-segment type 1 auto-generation-disable

Syntax Description	<table border="1"> <tr> <td>type 1</td> <td>Specifies LACP ESI-auto-generation for ESI type 1.</td> </tr> <tr> <td>auto-generation-disable</td> <td>Disables ESI auto-generation.</td> </tr> </table>	type 1	Specifies LACP ESI-auto-generation for ESI type 1.	auto-generation-disable	Disables ESI auto-generation.
type 1	Specifies LACP ESI-auto-generation for ESI type 1.				
auto-generation-disable	Disables ESI auto-generation.				
Command Default	By default, EVPN auto-generates an ESI value for the bundle interfaces by retrieving LACP information.				
Command Modes	EVPN configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.3.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.3.2	This command was introduced.
Release	Modification				
Release 6.3.2	This command was introduced.				
Usage Guidelines	This command allows mLACP to decide to either forward or stop EVPN multipath resolution on remote ESI.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

Example

This example shows how to disable auto-generation ESI type 1:

```
Router# configure
Router(config)# evpn
Router(config-evpn)#ethernet-segment
Router(config-evpn-es)#type 1 auto-generation-disable
```

evi

To enter the EVPN EVI configuration mode and configure optional BGP settings for a bridge domain or EVI, use the **evi** command in the EVPN configuration mode. To return to the EVPN configuration mode, use the **no** form of this command.

evi *evi-id*
no evi *evi-id*

Syntax Description	<i>evi-id</i> Specifies the Ethernet VPN ID to set. The range is from 1 to 65534.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	EVPN configuration mode
----------------------	-------------------------

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use this command to configure static BGP route distinguisher or BGP route target for an EVI.

Task ID	Task ID	Operation
	l2vpn	read, write

Example

This example shows how to enter the EVPN EVI configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# evi 2
RP/0/RSP0/CPU0:router(config-evpn-evi)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	bgp (EVPN), on page 5	Enables BGP in the PBB EVPN configuration.

evpn

To enter EVPN configuration mode, use the **evpn** command in the global configuration mode. To return to the global configuration mode, use the **no** form of this command.

```
evpn [{bgp | evi | interface | timers}]
no evpn [{bgp | evi | interface | timers}]
```

Syntax Description	bgp Configures BGP.						
	evi Configures Ethernet VPN ID (EVI).						
	interface Assigns an interface to EVPN.						
	timers Configures global EVPN timers.						
Command Default	None.						
Command Modes	Global configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.2	This command was introduced.		
Release	Modification						
Release 4.3.2	This command was introduced.						
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write		
Task ID	Operation						
l2vpn	read, write						
Example	<p>This example shows how to enter the EVPN configuration mode:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# evpn RP/0/RSP0/CPU0:router(config-evpn)#</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>evi, on page 14</td> <td>Enters the EVPN EVI configuration mode to configure optional BGP settings for a bridge domain or EVI.</td> </tr> <tr> <td>bgp (EVPN), on page 5</td> <td>Enables BGP in the PBB EVPN configuration.</td> </tr> </tbody> </table>	Command	Description	evi, on page 14	Enters the EVPN EVI configuration mode to configure optional BGP settings for a bridge domain or EVI.	bgp (EVPN), on page 5	Enables BGP in the PBB EVPN configuration.
Command	Description						
evi, on page 14	Enters the EVPN EVI configuration mode to configure optional BGP settings for a bridge domain or EVI.						
bgp (EVPN), on page 5	Enables BGP in the PBB EVPN configuration.						

Command	Description
interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.

evpn evi

To enable PBB EVPN and set the EVI for the bridge, use the **evpn evi** command in the L2VPN bridge group bridge domain PBB-core configuration mode. To disable PBB EVPN and reset the EVI, use the **no** form of this command.

evpn evi *evi-id*
no evpn evi *evi-id*

Syntax Description *evi-id* Specifies the Ethernet VPN ID to set. The range is from 1 to 65534.

Command Default None.

Command Modes L2VPN bridge group bridge domain PBB core configuration

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The VPN ID must be unique globally per network.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to enable PBB EVPN and set the EVI for the bridge:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# pbb core
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-pbb-core)# evpn evi 2
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-pbb-core)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	l2vpn	Enters L2VPN configuration mode.
	pbb, on page 34	Configures the provider backbone bridge core or edge.

flushagain

To configure the MAC flush again timer, use the **flushagain** command in the EVPN Interface Timers configuration or in the EVPN Timers configuration mode. To reset the MAC flushagain timer, use the **no** form of this command.

flushagain *seconds*
no flushagain *seconds*

Syntax Description	<i>seconds</i> Specifies the value in seconds ranging from 0 to 120 seconds. The default value is 60 seconds.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	EVPN Interface Timers configuration EVPN Timers configuration
----------------------	--

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to configure the MAC flushagain timer in the EVPN Interface Timers configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# timers
RP/0/RSP0/CPU0:router(config-evpn-ac-timers)# flushagain 20
RP/0/RSP0/CPU0:router(config-evpn-ac-timers)#
```

This example shows how to configure the MAC flushagain timer in the EVPN Timers configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# timers
```

```
RP/0/RSP0/CPU0:router(config-evpn-timers)# flushagain 30
RP/0/RSP0/CPU0:router(config-evpn-timers)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
	timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.
	recovery, on page 41	Configures the recovery timer.
	peering, on page 36	Configures the peering timer.
	programming, on page 39	Configures the programming timer.

flood-time

To enable flooding of traffic to the entire core bridge when the PBB-VPLS Flood Optimization feature is enabled on the core bridge, use the **flood-time** command in the flood optimization for PBB over VPLS global configuration submode.

flood-time *seconds*

Syntax Description	<i>seconds</i> Specifies the flood-time in seconds. Range is from 3 to 600 seconds.
---------------------------	---

Command Default	Flooding is disabled during convergence events.
------------------------	---

Command Modes	Flood optimization for PBB over VPLS global configuration submode.
----------------------	--

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Enables flooding of traffic on the entire core bridge when flood-time is enabled on the core bridge. This provides time for MMRP to converge with the affected peer(s) before pruning the traffic. Flooding will be disabled and the core bridge will start pruning the traffic when the flood-time has expired.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to set the flood-time:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mmrp-flood-optimization
RP/0/RSP0/CPU0:router(config-mmrp-flood-opt)# flood-time 80
```

force single-homed

To configure force single-homed, use **force single-homed** command in the global configuration mode. To return to the default behavior, use the **no** form of this command.

force single-homed
no force single-homed

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Release 4.3.2	This command was introduced.

Usage Guidelines

All EVPN-based access redundancy (EVLAG) designated forwarder elections are disregarded in favor of the legacy MLAG access protection protocol.

When CE is directly connected to a PE through a physical or bundle port and the redundant connection to another PE is operating an MLAG redundancy group.

Specifically, the ESI assignment to the interface is no longer used for EVPN-based access redundancy and protection mechanisms and the MLAG redundancy protocol will control the state of this interface.

With this command only the access protection is relinquished, and EVPN core mechanisms remain operational including any core functionality requiring the use of an ESI. This command is different than assigning ESI-0 to the interface, and functions also with an assigned ESI. With MLAG control of the interface state, those EVPN core procedures that depend on interface state remain the same.

Use this command to force the interface into single homed EVPN mode and interoperate with MLAG access protection.

The following example shows how to configure force single-homed.

```
Router# configure
Router(config)# evpn
Router(config-evpn)# interface GigabitEthernet0/0/0/0
Router(config-evpn-ac)# ethernet-segment force single-homed
```

identifier

To set the Ethernet segment identifier value of an interface, use the **identifier** command in the EVPN interface Ethernet-segment configuration mode. To delete the Ethernet segment identifier value, use the **no** form of this command.

identifier system-priority *priority-value* **system-id** *system-id*
no identifier system-priority *priority-value* **system-id** *system-id*

Syntax Description	
system-priority	Specifies the CE system priority (LACP) .
<i>priority-value</i>	Specifies the LACP system-priority value. The range is from 0 to ffff.
system-id	Specifies the CE system ID (LACP).
<i>system-id</i>	Specifies the LACP system ID in the H.H.H format.

Command Default None.

Command Modes EVPN interface Ethernet segment configuration mode

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use this command to overwrite computed Ethernet segment identifier value or to set Ethernet segment identifier value of an interface which is not a bundle. The concatenated value is unique per PE.

Task ID	Task ID	Operation
	l2vpn	read, write

Example

This example shows how to set the Ethernet segment identifier value of an interface in the EVPN interface Ethernet segment configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
```

```
RP/0/RSP0/CPU0:router(config-evpn-ac)# ethernet segment  
RP/0/RSP0/CPU0:router(config-evpn-ac-es)# identifier system-priority 2 system-id 1.1.1
```

Related Commands	Command	Description
	ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.
	load-balancing-mode, on page 29	Sets the load balancing mode of a physical port or bundle to active-active.
	service-carving, on page 45	Specifies the list of service identifiers as active and standby services.
	backbone-source-mac, on page 3	Configures the backbone source MAC address.

join-time (PBB)

To set the join-time for all active ports, use the **join-time** command in the flood optimization for PBB over VPLS global configuration submode.

join-time *milliseconds*

Syntax Description	<i>milliseconds</i> Specifies the maximum time for the join timer parameter for all active ports in milliseconds. Range is from 100 to 1000 milliseconds.
---------------------------	---

Command Default	200 milliseconds
------------------------	------------------

Command Modes	Flood optimization for PBB over VPLS global configuration submode.
----------------------	--

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The join-time parameter is used to jitter the sending of MMRPDUs on multi-point LANs, allowing any transmitted messages to take into account received MMRPDUs from multiple peers if they arrive close together. Transmit opportunities are actually uniformly jittered within the range of 0 to join-time.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to set the join time on all active ports:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mmrp-flood-optimization
RP/0/RSP0/CPU0:router(config-mmrrp-flood-opt)# join-time 300
```


interface (EVPN)

To enter the physical port interface or the bundle name interface configuration mode, use the **interface** command in the EVPN configuration mode. To return to the EVPN configuration mode, use the **no** form of this command.

```
interface type interface path-id
no interface type interface path-id
```

Syntax Description		
<i>type</i>		Specifies the physical ethernet interface or bundle ethernet Interface type connected to the CE device. For more information about the syntax for the router, use the question mark (?) online help function.
<i>interface path-id</i>		Physical port name or main bundle name. The range for the bundle name is from 1 to 65535. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default None.

Command Modes EVPN configuration mode

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To specify a physical interface, the notation for the *interface-path-id* is *rack/slot/module/port*. The slash between values is required as part of the notation. An explanation of each component of the naming notation is as follows:

- *rack*: Chassis number of the rack.
- *slot*: Physical slot number of the line card.
- *module*: Module number. A physical layer interface module (PLIM) is always 0.
- *port*: Physical port number of the interface.

Task ID	Task ID	Operation
	l2vpn	read, write

Example

This example shows how to enter the EVPN Interface configuration mode for bundle-ether 1:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.
	mac-flush mvrp, on page 32	Performs a MAC flush on an Ethernet-segment.
	timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.

leaveall-time (PBB)

To set the leave-all-time for all active ports, use the **leaveall-time** command in the flood optimization for PBB over VPLS global configuration submode.

leaveall-time *seconds*

Syntax Description	<i>seconds</i> Sets the minimum time in seconds for the leave-all timer parameter for all active ports. Range is from 5 to 30 seconds.
---------------------------	--

Command Default	10 seconds
------------------------	------------

Command Modes	Flood optimization for PBB over VPLS global configuration submode.
----------------------	--

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The leave-all timer parameter controls how often the leave-all messages are sent. This forces all the peers to re-declare all the attributes, thereby replaying any registrations or deregistrations that may be lost.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to set the leave-all time on all active ports:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mmp-flood-optimization
RP/0/RSP0/CPU0:router(config-mmp-flood-opt)# leaveall-time 20
```

leave-time (PBB)

To set the leave-time for all active ports, use the **leave-time** command in the flood optimization for PBB over VPLS global configuration submode.

leave-time *seconds*

Syntax Description	<i>seconds</i> Sets the leave time for all active ports. Range is from 1 to 90 seconds.
---------------------------	---

Command Default	30 seconds
------------------------	------------

Command Modes	Flood optimization for PBB over VPLS global configuration submode.
----------------------	--

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The **leave-time** command controls how long registrations stay in the leaving state before being removed; that is, it controls when the garbage collection of stale registrations is performed after unregistration.

The **leaveall-time** and the **leave-time** commands together control the garbage collection.

The IEEE specification states that the value of the **leave-time** command must be less than the value of the **leaveall-time** command.

However, in Cisco IOS-XR, processing outages of several seconds can occur during a process restart or Router Processor Fail-Over (RPFO) leading to a loss of messages.

Therefore, a greater default **leave-time** *value* (thrice that of the **leaveall-time** *value* command) increases the robustness of the Multiple MAC Registration Protocol (MMRP) during packet loss or system outage.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to set the leave-time on all active ports:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mmrp-flood-optimization
RP/0/RSP0/CPU0:router(config-mmrp-flood-opt)# leave-time 80
```

load-balancing-mode

To set the load balancing mode of a physical port or bundle to active-active, use the **load-balancing-mode** command in the EVPN Interface Ethernet segment configuration mode. To disable the load balancing mode from active-active, use the **no** form of this command.

load-balancing-mode per-service
no load-balancing-mode per-service

Syntax Description	per-service Specifies the per-service load balancing.
---------------------------	--

Command Default	Active-active per-flow
------------------------	------------------------

Command Modes	EVPN interface Ethernet segment configuration mode
----------------------	--

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use this command in a multi-homing configuration to set the redundancy mode to active-active per service.

In this mode, services that are active on one PoA are not active on the other PoA. Services can be represented by an ISID in case of PBB EVPN.

Task ID	Task ID	Operation
	l2vpn	read, write

Example

This example shows how to set the load balancing mode of a physical port or bundle to active-active:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# ethernet segment
RP/0/RSP0/CPU0:router(config-evpn-ac-es)# load-balancing-mode per-service
RP/0/RSP0/CPU0:router(config-evpn-ac-es)#
```

Related Commands	Command	Description
	ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.

Command	Description
service-carving, on page 45	Specifies the list of service identifiers as active and standby services.
backbone-source-mac, on page 3	Configures the backbone source MAC address.

mmrp-flood-optimization

To enable flood optimization for PBB over VPLS, use the **mmrp-flood-optimization** command on the core bridge in the PBB core configuration submode. To disable the flood optimization for PBB over VPLS, use the **no** form of this command.

mmrp-flood-optimization
no mmrp-flood-optimization

Syntax Description	This command has no keywords or arguments.	
Command Default	Disabled.	
Command Modes	PBB core configuration	
Command History	Release	Modification
	Release 5.1.2	This command was introduced.
Usage Guidelines	Flood optimization is enabled on all the pseudo-wires in the VFI associated with the core bridge domain. This feature is supported only in the standard full mesh topology of a VPLS network.	
Task ID	Task ID	Operation
	l2vpn	read, write

The following example shows how to enable flood optimization for PBB over VPLS:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group pbb
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain pbb-core
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# pbb core
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-pbb-core)# mmrp-flood-optimization
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-pbb-core)# end
```

mac-flush mvrp

To perform a MAC flush on an Ethernet-segment, use the **mac-flush** command in the EVPN interface configuration mode. To disable the MAC flush setting, use the **no** form of this command.

mac-flush mvrp
no mac-flush mvrp

Syntax Description	mvrp Specifies the MAC flush over MVRP.
---------------------------	--

Command Default	STP-TCN
------------------------	---------

Command Modes	EVPN interface configuration
----------------------	------------------------------

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to perform the MAC flush over MVRP on an Ethernet segment:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# mac-flush mvrp
RP/0/RSP0/CPU0:router(config-evpn-ac)#
```

Related Commands	Command	Description
	interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.

mode singleton

To enable singleton ICCP mode, use the **mode singleton** command in the Redundancy ICCP group configuration mode. To disable singleton ICCP mode, use the **no** form of this command.

mode singleton
no mode singleton

Syntax Description This command has no arguments or keywords.

Command Default None.

Command Modes Redundancy ICCP group configuration

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to enable singleton ICCP mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# redundancy
RP/0/RSP0/CPU0:router(config-redundancy)# iccp
RP/0/RSP0/CPU0:router(config-redundancy-iccp)# group 1
RP/0/RSP0/CPU0:router(config-redundancy-iccp-group)# mode singleton
RP/0/RSP0/CPU0:router(config-redundancy-iccp-group)#
```

pbb

To configure the provider backbone bridge core or edge, use the **pbb** command in the bridge domain configuration submode. To return to the default behavior, use the **no** form of this command.

pbb {**edge** **i-sid** *service-id* **core-bridge** *core-bridge-domain-name* | **core**}

no pbb {**edge** **i-sid** *service-id* **core-bridge** *core-bridge-domain-name* | **core**}

Syntax Description

edge	Configures the PBB edge.
i-sid	Specifies the service instance identifier. The ranges is from 256 to 16777214. Note The 16777215 (0xFFFFFFFF) service instance identifier is reserved for wildcard.
<i>service-id</i>	Service instance identifier.
core-bridge	Specifies the name of the core-bridge domain connected to that edge-bridge domain.
<i>core-bridge-domain-name</i>	Core bridge domain name.
core	Configures the PBB core.

Command Default

None

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.9.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command allows you to enter pbb edge configuration mode or pbb core configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the PBB edge component:

```
config
l2vpn
```

```

bridge group PBB
  bridge-domain PBB-EDGE
    interface GigabitEthernet0/0/0/38.100
    !
    interface GigabitEthernet0/2/0/30.150
    !
  pbb edge i-sid 1000 core-bridge PBB-CORE
!
!
!

```

The following example shows how to configure the PBB core component:

```

config
l2vpn
  bridge group PBB
    bridge-domain PBB-CORE
      interface G0/5/0/10.100
      !
      interface G0/2/0/20.200
      !
    pbb core
  !
!
!

```

Related Commands	Command	Description
	bridge-domain (VPLS)	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS)	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn	Enters L2VPN configuration mode.

peering

To configure the peering timer, use the **peering** command in the EVPN Timers configuration mode. To delete the peering timer, use the **no** form of this command.

peering *seconds*
no peering *seconds*

Syntax Description	<i>seconds</i> Specifies the value in seconds ranging from 0 to 300 seconds. The default value is 45 seconds.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	EVPN Timers configuration
----------------------	---------------------------

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

In a single homed Ethernet segment, wait for this timer to expire before advertising BGP route target, Ethernet segment identifier (ESI), and local MAC.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to configure the peering timer in the EVPN Timers configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# evpn
RP/0/RSP0/CPU0:router (config-evpn)# timers
RP/0/RSP0/CPU0:router (config-evpn-timers)# peering 30
RP/0/RSP0/CPU0:router (config-evpn-timers)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.
	flushagain, on page 18	Configures the MAC flushagain timer.
	recovery, on page 41	Configures the recovery timer.

Command	Description
programming, on page 39	Configures the programming timer.

periodic transmit (PBB)

To enable periodic Multiple MAC Registration Protocol Data Units (MMRPDUs), use the **periodic transmit** command in the flood optimization for PBB over VPLS global configuration submode.

periodic transmit [**interval** *seconds*]

Syntax Description	interval <i>seconds</i> Specifies the periodic transmit interval in seconds. Range is from 2 to 10. If the interval keyword is not specified, then the value defaults to 3 seconds.
---------------------------	---

Command Default	Periodic MMRPDUs are disabled.
------------------------	--------------------------------

Command Modes	Flood optimization for PBB over VPLS global configuration submode.
----------------------	--

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

This command can optionally be used to configure the protocol to replay data periodically. This is in addition to the periodic replay triggered by the leave-all timer. The use of this command will not be necessary in the vast majority of deployments and enabling it can cause a significant increase in CPU usage.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows how to enable periodic MMRPDUs transmitted on all active ports:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mmrp-flood-optimization
RP/0/RSP0/CPU0:router(config-mmrip-flood-opt)# periodic transmit interval 3
```

programming

To configure the programming timer, use the **programming** command in the EVPN Timers configuration mode. To delete the programming timer, use the **no** form of this command.

programming *microseconds*
no programming *microseconds*

Syntax Description	<i>microseconds</i> Specifies the value in microseconds ranging from 0 to 100000 seconds. The default value is 1500 microseconds.						
Command Default	None.						
Command Modes	EVPN Timers configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.2	This command was introduced.		
Release	Modification						
Release 4.3.2	This command was introduced.						
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Every time the ES Manager runs DF election, it starts a programming timer to account for the time needed by the hardware to apply the new carving. At the expiry time, the next ES route object is processed or carved, restarting the timer.</p>						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table> <p>This example shows how to configure the programming timer in the EVPN Timers configuration mode:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# evpn RP/0/RSP0/CPU0:router(config-evpn)# timers RP/0/RSP0/CPU0:router(config-evpn-timers)# programming 5000 RP/0/RSP0/CPU0:router(config-evpn-timers)#</pre>	Task ID	Operation	l2vpn	read, write		
Task ID	Operation						
l2vpn	read, write						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>evpn, on page 15</td> <td>Enters EVPN configuration mode.</td> </tr> <tr> <td>timers, on page 71</td> <td>Configures timers that affect the convergence of PBB EVPN in failure scenarios.</td> </tr> </tbody> </table>	Command	Description	evpn, on page 15	Enters EVPN configuration mode.	timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.
Command	Description						
evpn, on page 15	Enters EVPN configuration mode.						
timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.						

Command	Description
flushagain, on page 18	Configures the MAC flushagain timer.
recovery, on page 41	Configures the recovery timer.
peering, on page 36	Configures the peering timer.

recovery

To configure the recovery timer, use the **recovery** command in the EVPN Interface Timers configuration or in the EVPN Timers configuration mode. To delete the recovery timer, use the **no** form of this command.

recovery *seconds*
no recovery *seconds*

Syntax Description	<i>seconds</i> Specifies the value in seconds ranging from 20 to 3600 seconds. The default value is 20 seconds.				
Command Default	None.				
Command Modes	EVPN Interface Timers configuration EVPN Timers configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.2	This command was introduced.
Release	Modification				
Release 4.3.2	This command was introduced.				
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>This timer is used to wait before processing the port state UP event in order to give the CE running STP to converge. If the interface is up and all conditions are already met, this timer is skipped to not add any more delays.</p>				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

This example shows how to configure the recovery timer in the EVPN Interface Timers configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# timers
RP/0/RSP0/CPU0:router(config-evpn-ac-timers)# recovery 50
RP/0/RSP0/CPU0:router(config-evpn-ac-timers)#
```

This example shows how to configure the recovery timer in the EVPN Timers configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# timers
```

```
RP/0/RSP0/CPU0:router(config-evpn-timers)# recovery 300
RP/0/RSP0/CPU0:router(config-evpn-timers)#
```

Related Commands

Command	Description
evpn, on page 15	Enters EVPN configuration mode.
interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
timers, on page 71	Configures timers that affect the convergence of PBB EVPN in failure scenarios.
flushagain, on page 18	Configures the MAC flushagain timer.
peering, on page 36	Configures the peering timer.
programming, on page 39	Configures the programming timer.

rewrite ingress tag push

To configure the backbone VLAN ID for a PBB core bridge, use the **rewrite ingress tag push** command in the PBB core configuration mode. To return to the default behavior, use the **no** form of this command.

rewrite ingress tag push dot1ad *vlan-id* **symmetric**

Syntax Description	dot1ad Indicates that the IEEE 802.1ad provider bridges encapsulation type is used.				
	<i>vlan-id</i> VLAN ID. Range is from 1 to 4094.				
	symmetric Specifies that all rewrites must be symmetric.				
Command Default	None				
Command Modes	PBB core configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.1	This command was introduced.
Release	Modification				
Release 3.9.1	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				

Examples

The following example shows how to configure the backbone VLAN ID for the PBB core bridge:

```

config
l2vpn
  bridge group PBB
    bridge-domain PBB-CORE
    interface G0/5/0/10.100
    !
    interface G0/2/0/20.200
    !
  pbb core
    rewrite ingress tag push dot1ad 100 symmetric
  !

```

rewrite ingress tag push

!
!

Related Commands	Command	Description
	bridge-domain (VPLS)	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS)	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn	Enters L2VPN configuration mode.
	pbb, on page 34	Configures the provider backbone bridge core or edge.

service-carving

To specify a list of service identifiers as active and standby services, use the **service-carving** command in the EVPN Interface Ethernet segment configuration mode. To delete service carving of a list of service identifiers, use the **no** form of this command.

service-carving manual[primary *service-id-range* **secondary** *service-id-range*]
no service-carving manual[primary *service-id-range* **secondary** *service-id-range*]

Syntax Description	Parameter	Description
	manual	Specifies service identifiers or EVI-list services manually.
	primary	Specifies the primary services list.
	secondary	Specifies the secondary services list.
	<i>service-id-range</i>	Specifies the services list notation in the range 100, 201-300, 401. The range is within 256 to 16777214.

Command Default Automatic service carving

Command Modes EVPN interface Ethernet segment configuration mode

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

Example

This example shows how to specify a list of service identifiers as active and standby services:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# ethernet segment
RP/0/RSP0/CPU0:router(config-evpn-ac-es)# service-carving manual primary 201-300 secondary
```

400-500

RP/0/RSP0/CPU0:router(config-evpn-ac-es)#

Related Commands

Command	Description
ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.
load-balancing-mode, on page 29	Sets the load balancing mode of a physical port or bundle to active-active.
backbone-source-mac, on page 3	Configures the backbone source MAC address.

show evpn ethernet-segment

To display the EVPN Ethernet segment information, use the **show evpn ethernet-segment** command in the EXEC mode.

```
show evpn ethernet-segment[ {detail | esi | interface | location | private | standby } ]
```

Syntax Description	Option	Description
	detail	Displays detailed information.
	esi	Filters by Ethernet Segment identifier.
	interface	Filters by interface name.
	location	Displays location specific information.
	private	Displays private information.
	standby	Displays standby node specific information.

Command Default None.

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

Example

This sample output shows the EVPN Ethernet segment with interface filter:

```
RP/0/RSP0/CPU0:router#show evpn ethernet-segment interface gigabitethernet 0/3/0/0 detail
Ethernet Segment Id      Interface      Nexthops
-----
0210.0300.9e00.0210.0000 Gi0/3/0/0    1.100.100.100
                               2.100.100.100
be01.0300.be01.ce00.0001 BE1           1.100.100.100
                               2.100.100.100
be02.0300.be02.0101.0002 BE2           1.100.100.100
                               2.100.100.100
```



```
Service Carving Results:
  Bridge ports      : 3
  Elected          : 3
    I-Sid E        : 1450102, 1650206, 1850310
  Not Elected      : 0
MAC Flushing mode  : STP-TCN
Peering timer      : 45 sec [not running]
Recovery timer     : 20 sec [not running]
Flushagain timer   : 60 sec
```

Related Commands

Command	Description
evpn, on page 15	Enters EVPN configuration mode.
ethernet-segment, on page 11	Enters EVPN interface ethernet segment configuration mode.

show evpn evi

To display the EVPN E-VPN ID information, use the **show evpn evi** command in the EXEC mode.

```
show evpn evi ac-id [{bridge-domain | detail | inclusive-multicast | location | mac | standby | vpn-id
}]
```

Syntax Description		
	<i>ac-id</i>	Specifies the attachment circuit id.
	bridge-domain	Displays information for a specified bridge-domain..
	detail	Displays detailed information.
	inclusive-multicast	Displays EVPN Inclusive Multicast information.
	location	Displays location specific information.
	mac	Displays EVI MAC route associated configuration information.
	standby	Displays standby node specific information.
	vpn-id	Displays information for a specified E-VPN Identifier.

Command Default None.

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.2	This command was introduced.
	Release 6.0.0	The variable <i>ac-id</i> was added
	Release 6.1.2	The show command output is enhanced to display the Service Path Preference parameters.

Usage Guidelines To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

Example

This sample output shows the EVPN EVI information with the VPN-ID and MAC address filter:

```
RP/0/RSP0/CPU0:router#show evpn evi vpn-id 185 mac 0024.be03.ce01
MAC address      Nexthop                               Label    vpn-id
-----
0024.be03.ce01  3.100.100.100                         16004    185
                  4.100.100.100                         16004    185
  ESI port key : 0x0000
  Source       : Remote
  Flush Count  : 0
```

This sample output shows the EVPN EVI information with the VPN-ID and inclusive-multicast filter:

```
RP/0/RSP0/CPU0:router#show evpn evi vpn-id 185 inclusive-multicast service-id 1850312 orig-ip
1.100.100.100
ISID              Originating IP                          vpn-id
-----
1850312           1.100.100.100                          185
1850312           2.100.100.100                          185
1850312           3.100.100.100                          185
1850312           4.100.100.100                          185
```

This sample output shows the EVPN EVI inclusive-multicast information:

```
RP/0/RSP0/CPU0:router#show evpn evi inclusive-multicast detail
ISID: 1850312, Originating IP: 1.100.100.100                               185
  Nexthop: ::
  Label   : 16005
  Source  : Local
ISID: 1850312, Originating IP: 2.100.100.100                               185
  Nexthop: 2.100.100.100
  Label   : 16005
  Source  : Remote
ISID: 1850312, Originating IP: 3.100.100.100                               185
  Nexthop: 3.100.100.100
  Label   : 16005
  Source  : Remote
ISID: 1850312, Originating IP: 4.100.100.100                               185
  Nexthop: 4.100.100.100
  Label   : 16005
  Source  : Remote
```

This sample output shows the EVPN EVI information with the bridge-domain filter:

```
RP/0/RSP0/CPU0:router#show evpn evi bridge-domain tb1-core1 detail
EVI              Bridge Domain                          Type
-----
145              tb1-core1                                PBB
165              tb1-core2                                PBB
185              tb1-core3                                PBB
65535            ES:GLOBAL                                BD
```

This sample output shows the EVPN EVI detailed information:

```
RP/0/RSP0/CPU0:router#show evpn evi detail
EVI              Bridge Domain                          Type
-----
145              tb1-core1                                PBB
```

```

Unicast Label : 16000
Multicast Label: 16001
RD Config: none
RD Auto : (auto) 1.100.100.100:145
RT Auto : 100:145
Route Targets in Use          Type
-----
100:145                        Import
100:145                        Export

165          tbl-core2                PBB
Unicast Label : 16002
Multicast Label: 16003
RD Config: none
RD Auto : (auto) 1.100.100.100:165
RT Auto : 100:165
Route Targets in Use          Type
-----
100:165                        Import
100:165                        Export

185          tbl-core3                PBB
Unicast Label : 16004
Multicast Label: 16005
RD Config: none
RD Auto : (auto) 1.100.100.100:185
RT Auto : 100:185
Route Targets in Use          Type
-----
100:185                        Import
100:185                        Export

65535       ES:GLOBAL                 BD
Unicast Label : 0
Multicast Label: 0
RD Config: none
RD Auto : (auto) 1.100.100.100:0
RT Auto : none
Route Targets in Use          Type
-----
0100.9e00.0210                Import
0100.be01.ce00                Import
0100.be02.0101                Import

```

This example displays the detailed information about **show evpn evi** command. The output provides an overview of the state of the globally configured features.

```

RP/0/RSP0/CPU0:router# show evpn evi ac-id detail
Mon Apr 18 13:16:46.597 EDT

```

VPN ID	Source AC ID	Target AC ID
110	10	30
200	1	3
200	4	6
200	11	13

This sample output shows the EVPN EVI detailed information with service path preference parameters:

```

RP/0/RSP0/CPU0:router#show evpn evi vpn-id 1 detail
Mon Jun 20 21:28:42.413 EDT

```

```

EVI          Bridge Domain          Type
-----
1            core1                    PBB
Unicast Label : 24000
Multicast Label: 24001
Flow Label: N
Control-Word: Enabled
Table-policy Name: fwd2
Forward-class: 2
RD Config: none
RD Auto  : none
RT Auto  : none
Route Targets in Use          Type
-----
    
```

Related Commands

Command	Description
evpn, on page 15	Enters EVPN configuration mode.
evi, on page 14	Enters the EVPN EVI configuration mode to configure optional BGP settings for a bridge domain or EVI.

show evpn summary

To display the EVPN summary, use the **show evpn summary** command in the EXEC mode.

show evpn summary[{**location** | **private** | **standby**}]

Syntax Description	
location	Displays location specific information.
private	Displays private information.
standby	Displays standby node specific information.

Command Default None.

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

Example

This sample output shows the EVPN summary:

```
RP/0/RSP0/CPU0:router#show evpn summary
Thu Jul  4 01:34:58.838 DST
-----
Global Information
-----
Number of EVIs                : 1
Number of Local MAC Routes    : 1
Number of Remote MAC Routes   : 0
Number of Local IMCAST Routes : 0
Number of Remote IMCAST Routes: 0
Number of Internal Labels     : 0
Number of ES Entries          : 0
BGP Router ID                  : ::
BGP ASN                         : Invalid
PBB BSA MAC address            : f866.f214.abd7
Global peering timer           : 45 seconds
Global recovery timer          : 20 seconds
```

```
Global programming timer      : 1500 microseconds
Global flushagain timer      :    60 seconds
```

```
-----
High Availability Information
-----
```

```
BGP EOD                       : N
Number of Marked MAC Routes    : 0
Number of Swept MAC Routes    : 0
Number of Marked IMCAST Routes: 0
Number of Swept IMCAST Routes : 0
```

Related Commands

Command	Description
evpn, on page 15	Enters EVPN configuration mode.

show l2vpn bridge-domain pbb

To display the provider backbone bridge details, use the **show l2vpn bridge-domain pbb** command in EXEC mode.

show l2vpn bridge-domain pbb {**core** [{**brief**|**detail**|**hardware**|**private**}]|**edge** [{**brief**|**core-bridge**|**detail**|**hardware**|**private**}]|**i-sid** *service-id* [{**brief**|**detail**|**hardware**|**private**}]}

Syntax Description

core	Displays the PBB core.
edge	Displays the PBB edge.
i-sid	Displays the service instance identifier.
<i>service-id</i>	Service ID.
brief	Displays brief information about the PBB core, edge or service instance identifier.
detail	Displays detailed information about the PBB core, edge or service instance identifier.
hardware	Displays hardware information.
private	Displays private information about the PBB core, edge or service instance identifier.
core-bridge	Displays the name of the core-bridge domain connected to the edge-bridge domain.

Command Default

None

Command Modes

l2vpn

Command History

Release	Modification
Release 3.9.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following examples shows the output from the **show l2vpn bridge-domain pbb** command:

```
#show l2vpn bridge-domain isid 1234
Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 1234
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
```



```

Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 0
  List of ACs:
    Gi0/2/0/0, state: up, Static MAC addresses: 2, MSTi: 0

```

For IOS-XR 5.3.1 and earlier releases.

```

#show l2vpn bridge-domain detail isid 1234
Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
  Type: pbb-edge, I-SID: 1234
  Core-bridge: pbb-bd2
  MAC learning: enabled
  MAC withdraw: disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  MTU: 1500
  Filter MAC addresses:
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state is up
    XC ID 0x2000001
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled
      Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: yes
    Split Horizon Group: none
    DHCPv4 snooping: disabled
    IGMP Snooping profile:
    Storm Control: disabled
    Unknown-unicast-bmac: 666.777.888
    CMAC to BMAC Mapping Table:
      CMAC          |          BMAC
      -----
      222.333.444   |    777.888.999
      333.444.555   |    888.999.111
    Statistics:
      packet totals: receive 3919680,send 9328
      byte totals:  receive 305735040,send 15022146

List of ACs:
  AC: GigabitEthernet0/1/0/0, state is up
  Type Ethernet
  MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  Static MAC addresses:

```

show l2vpn bridge-domain pbb

```

0000.0000.0000
0001.0002.0003
Statistics:
  packet totals: receive 3919680,send 9328
  byte totals: receive 305735040,send 15022146

```

For IOS-XR 5.3.2 release.

```

#show l2vpn bridge-domain detail isid 1234
Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 1234
Core-bridge: pbb-bd2
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state is up
  XC ID 0x2000001
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Split Horizon Group: none
  DHCPv4 snooping: disabled
  IGMP Snooping profile:
  Storm Control: disabled
  Unknown-unicast-bmac: 666.777.888
  CMAC to BMAC Mapping Table:
    CMAC          |      BMAC
    -----
    222.333.444   |    777.888.999
    333.444.555   |    888.999.111
  Statistics:
    packets: received 1000 (unicast 1000), sent 0
    bytes: received 128000 (unicast 128000), sent 0
    MAC move: 10

List of ACs:
AC: GigabitEthernet0/1/0/0, state is up
Type Ethernet
MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
Static MAC addresses:

```

```
0000.0000.0000
0001.0002.0003
```

```
Statistics:
  packets: received 3919680, (multicast 0, broadcast 0, unknown unicast 0, unicast
3919680,), sent 9328
  bytes: received 305735040 (multicast 0, broadcast 0, unknown unicast 0, unicast
0), sent 15022146
  MAC move: 0
```

```
#show l2vpn bridge-domain pbb edge
Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
  Type: pbb-edge, I-SID: 1234
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 2
List of ACs:
  Gi0/2/0/0, state: up, Static MAC addresses: 2, MSTi: 0

Bridge group: g2, bridge-domain: pbb-bd3, id: 3, state: up, ShgId: 0, MSTi: 0
  Type: pbb-edge, I-SID: 2345
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  EDGE, state: up, Static MAC addresses: 2
List of ACs:
  Gi0/2/0/0, state: up, Static MAC addresses: 2, MSTi: 0

Bridge group: g2, bridge-domain: pbb-bd4, id: 4, state: up, ShgId: 0, MSTi: 0
  Type: pbb-edge, I-SID: 3456
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 2
List of ACs:
  Gi0/2/0/0, state: up, Static MAC addresses: 2, MSTi: 0
```

For IOS-XR 5.3.2 release.

```
#show l2vpn bridge-domain pbb-edge detail
Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
  Type: pbb-edge, I-SID: 1234
  Core-bridge: pbb-bd2
  MAC learning: enabled
  MAC withdraw: disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  MTU: 1500
  Filter MAC addresses:
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
```

show l2vpn bridge-domain pbb

```
PBB Edge, state is up
XC ID 0x2000001
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Split Horizon Group: none
DHCPv4 snooping: disabled
IGMP Snooping profile:
Storm Control: disabled
Unknown-unicast-bmac: 666.777.888
```

CMAC to BMAC Mapping Table:

CMAC	BMAC
222.333.444	777.888.999
333.444.555	888.999.111

Statistics:

```
packets: received 1000 (unicast 1000), sent 0
bytes: received 128000 (unicast 128000), sent 0
MAC move: 10
```

List of ACs:

```
AC: GigabitEthernet0/1/0/0, state is up
Type Ethernet
MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
Static MAC addresses:
  0000.0000.0000
  0001.0002.0003
Statistics:
  packets: received 1000 (unicast 1000), sent 0
  bytes: received 128000 (unicast 128000), sent 0
  MAC move: 10
```

#show l2vpn bridge-domain pbb-core

```
Bridge group: g2, bridge-domain: pbb-bd2, id: 2, state: up, ShgId: 0, MSTi: 0
Type: pbb-core
Number of associated pbb-edge BDs: 1
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Core, state: up
List of ACs:
  Gi0/2/0/0, state: up, Static MAC addresses: 2, MSTi: 0
```

#show l2vpn bridge-domain pbb-core detail

```
Bridge group: g2, bridge-domain: pbb-bd2, id: 2, state: up, ShgId: 0, MSTi: 0
Type: pbb-core
Number of associated pbb-edge BDs: 1
MAC learning: enabled
```

```

MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), PBB: 1
List of PBBs:
  PBB Core, state is up
  Vlan-id: 1; XC ID 0x2000001
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 600, Action: none, Notification: syslog
    MAC limit reached: no
    Security: disabled
    Split Horizon Group: none
    DHCPv4 snooping: profile foo
    IGMP Snooping profile:
    Storm Control: disabled
List of ACs:
  AC: GigabitEthernet0/1/0/0, state is up
  Type Ethernet
  MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: yes
    Security: disabled
    DHCPv4 snooping: disabled
  Static MAC addresses:
    0000.0000.0000
    0001.0002.0003
  Statistics:
    packet totals: receive 3919680,send 9328
    byte totals: receive 305735040,send 15022146

```

```

#show l2vpn bridge-domain pbb-edge core-bridge core-bd brief
Bridge Group/???????????????????? ID      State      Num ACs/up  Num PWs/up
Bridge-Domain Name
-----
bg/pbb-bd1 ?????????????????????????????1    up          0/0 ??????????0/0
bg/pbb-bd2 ?????????????????????????????2    up          0/0 ??????????0/0
bg/pbb-bd3 ?????????????????????????????3    up          0/0 ??????????0/0

```

```

RP/0/0/CPU0:ios#show l2vpn bridge-domain pbb edge core-bridge bd
Bridge group: bg, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 4001
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 0 (0 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 2

```

```
show l2vpn bridge-domain pbb
```

```

...
Bridge group: bg, bridge-domain: pbb-bd2, id: 2, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 4002
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 0 (0 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 1
...
Bridge group: bg, bridge-domain: pbb-bd3, id: 3, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 4003
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 0 (0 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)
List of PBBs:
  PBB Edge, state: up, Static MAC addresses: 0
...

```

Related Commands

Command	Description
pbb, on page 34	Configures the provider backbone bridge core or edge.

show l2vpn forwarding bridge pbb

To display the PBB bridge forwarding information, use the **show l2vpn forwarding bridge pbb** command in EXEC mode.

```
show l2vpn forwarding bridge pbb core [{debug | detail | hardware | location | private}] | edge
[{{core-bridge | debug | detail | hardware | location | private}}] | i-sid service-id [{debug | detail | hardware
| location | private}]
```

Syntax Description	Option	Description
	debug	Displays the debug information.
	core	Displays the PBB core.
	edge	Displays the PBB edge.
	i-sid <i>service-id</i>	Displays the service instance identifier.
	brief	Displays brief information about the PBB core, edge or service instance identifier.
	detail	Displays detailed information about the PBB core, edge or service instance identifier.
	hardware	Displays hardware information.
	private	Displays private information about the PBB core, edge or service instance identifier.
	core-bridge	Displays the name of the core-bridge domain connected to the edge-bridge domain.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following example shows the output from the **show l2vpn forwarding pbb backbone-source-mac** command:

show l2vpn forwarding bridge pbb

```
#show l2vpn forwarding backbone-source-mac location 0/1/CPU0
333.444.555
```

The following example shows the output from the **show l2vpn forwarding bridge-domain pbb edge location** command:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain pbb edge location 0/1/CPU0
```

Bridge-Domain Name	Bridge		MAC		Flooding	Learning	State
	ID	Ports	addr				
bg1:bd2	1	1	0		Enabled	Enabled	UP
bg1:bd4	3	1	0		Enabled	Enabled	UP
bg1:bd5	4	1	0		Enabled	Enabled	UP

The following example shows the output from the **show l2vpn forwarding bridge-domain pbb edge core-bridge bg1:bd3 location** command:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain pbb edge core-bridge bg1:bd3 location 0/1/CPU0
```

Bridge-Domain Name	Bridge		MAC		Flooding	Learning	State
	ID	Ports	addr				
bg1:bd2	1	1	0		Enabled	Enabled	UP
bg1:bd4	3	1	0		Enabled	Enabled	UP
bg1:bd5	4	1	0		Enabled	Enabled	UP

The following example shows the output from the **show l2vpn forwarding bridge-domain pbb core location** command:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain pbb core location 0/1/CPU0
```

Bridge-Domain Name	Bridge		MAC		Flooding	Learning	State
	ID	Ports	addr				
bg1:bd3	1	1	0		Enabled	Enabled	UP

The following example shows the output from the **show l2vpn forwarding bridge-domain pbb i-sid 1000 location** command:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain pbb i-sid 1000 location 0/0/CPU0
Thu Aug 13 12:08:16.492 EDT
```

Bridge-Domain Name	Bridge		MAC		Flooding	Learning	State
	ID	Ports	addr				
PBB:PBB-EDGE	1	4	2		Enabled	Enabled	UP

Related Commands

Command	Description
pbb, on page 34	Configures the provider backbone bridge core or edge.

show l2vpn forwarding pbb backbone-source-mac

To display the provider backbone source MAC forwarding information, use the **show l2vpn forwarding pbb backbone-source-mac** command in EXEC mode.

```
show l2vpn forwarding pbb backbone-source-mac {debug [{detail | location | private}] | detail
[ {debug | location node-id} ] | location node-id | private}
```

Syntax Description

debug	Displays the debug information.
detail	Displays the detailed PBB forwarding information.
location	Specifies the location.
<i>node-id</i>	Node ID.
private	Displays private information.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.9.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

The following example shows the output from the **show l2vpn forwarding pbb backbone-source-mac** command:

```
#show l2vpn forwarding backbone-source-mac location 0/1/CPU0
333.444.555
```

Related Commands

Command	Description
pbb, on page 34	Configures the provider backbone bridge core or edge.

show l2vpn pbb backbone-source-mac

To display the provider backbone source MAC information, use the **show l2vpn pbb backbone-source-mac** command in EXEC mode.

show l2vpn pbb backbone-source-mac

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples The following example shows the output from the **show l2vpn pbb backbone-source-mac** command:

```
#show l2vpn pbb backbone-source-mac
0111.0222.0333
```

Related Commands	Command	Description
	pbb, on page 34	Configures the provider backbone bridge core or edge.

show mmrp-flood-optimization

To display the MMRP flood optimization information, use the **show mmrp-flood-optimization** command in the EXEC mode.

```
show mmrp-flood-optimization [{summary | mad [pw neighbor pw-id] | statistics [pw neighbor pw-id] | registrations [received] [core-bridge bridge-domain-name : group-name] [isid isid]}]
```

Syntax Description		
summary		Displays the summary of the current timer values, total number of core bridges, pseudowires, I-SIDs configured, declarations, and registrations.
mad		Displays the current state of the MRP Attribute Declaration (MAD) component on a pseudowire, for each active attribute value (that is, group B-MAC).
pw		Indicates the pseudowire.
<i>neighbor</i>		Indicates the IP address of the neighbor.
<i>pw-id</i>		Indicates the pseudowire ID.
statistics		Displays the packet statistics per pseudowire.
registrations		Displays the I-SIDs that are declared and a list of peers that have made registrations for those I-SIDs
received		Displays all the I-SIDs where registrations have been received, even if those I-SIDs are not configured locally.
core-bridge		Displays the information about a specific core-bridge.
<i>bridge-domain-name</i>		Core bridge domain name.
<i>group-name</i>		Group name.
isid		Displays information of a specific service instance identifier.
<i>isid</i>		Service instance identifier.
Command Default	None	
Command Modes	EXEC	

Command History	Release	Modification
	Release 5.1.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	ethernet-services	read, write

The following example shows the output from the **show mmrp-flood-optimization summary** command.

```
RP/0/RSP0/CPU0:router#show mmrp-flood-optimization summary
Core Bridges:          4
Pseudowires:          100
I-SIDs configured:    2000
Total MMRP declarations: 200000
Registrations received: 220000

Flood Time:           disabled
Leaveall Time:         10000 ms
Leave Time:            30000 ms
Join Time:            200 ms
Transmit Period:     1000 ms
```

The following example shows the output from the **show mmrp-flood-optimization mad** command.

```
RP/0/RSP0/CPU0:router#show mmrp-flood-optimization mad
Core-Bridge: PBB-VPLS-Core1 PW: neighbor 1.2.3.4, pwid 87
Participant Type: Full; Point-to-Point: Yes
Admin Control: Applicant Normal; Registrar Normal

LeaveAll Passive (next in 5.92s); periodic disabled
Leave in 25.70s; Join not running
Last peer 0293.6926.9585; failed registrations: 0

I-SID      B-MAC          Applicant          Registrar
-----
          1 001E.8300.0001 Very Anxious Observer Leaving
16777216 001E.83FF.FFFF Quiet Passive      Empty
```

static-mac-address

To map a customer destination MAC address to backbone destination MAC address, use the **static-mac-address** command in the PBB edge configuration mode. To return to the default behavior, use the **no** form of this command.

static-mac-address *cust-mac-address* **bmac** *bmac-mac-address*
no static-mac-address *cust-mac-address* **bmac** *bmac-mac-address*

Syntax Description	
<i>cust-mac-address</i>	Customer destination MAC address in hexadecimal format.
bmac	Specifies that the static backbone MAC address must be mapped with the customer MAC address.
<i>bmac-mac-address</i>	Static backbone MAC address in hexadecimal format.

Command Default None

Command Modes PBB edge configuration mode

Command History	Release	Modification
	Release 3.9.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to map the customer MAC address with the backbone MAC address:

```
interface GigabitEthernet0/0/0/0.1 l2transport encapsulation dot1q 10 !
interface GigabitEthernet0/0/0/0.2 l2transport encapsulation dot1q 2 !
interface GigabitEthernet0/0/0/1
 shutdown
 !
interface GigabitEthernet0/0/0/2
 shutdown
 !
interface GigabitEthernet0/0/0/3
 shutdown
 !
interface GigabitEthernet0/0/0/4
```

```

shutdown
!
l2vpn
bridge group bg12
  bridge-domain bd1
    interface GigabitEthernet0/0/0/0.1
      static-mac-address 0002.0003.0004
    !
    interface GigabitEthernet0/0/0/0.2
    !
  pbb edge i-sid 1000 core-bridge bd2
    static-mac-address 0006.0007.0008 bmac 0004.0005.0006
  !
!
!
end
!

```

The following example shows the output of the **show l2vpn bridge-domain** command:

```
##sh l2vpn bridge-domain m mac-address mroute
```

Mac Address	Type	Learned from/ Filtered on	LC learned Resync Age	Mapped to	
0002.0003.0004	static	Gi0/0/0/0.1	N/A	N/A	N/A
0006.0007.0008	static	BD id: 0	N/A	N/A	0004.0005.0006



Note To resynchronize the MAC table from the network processors, use the **l2vpn resynchronize forwarding mac-address-table location** `<r/s/i>` command.

Related Commands

Command	Description
bridge-domain (VPLS)	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS)	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
pbb, on page 34	Configures the provider backbone bridge core or edge.
l2vpn	Enters L2VPN configuration mode.

timers

To configure timers that affect the convergence of PBB EVPN in failure scenarios, use the **timers** command in the EVPN interface configuration or in the EVPN configuration mode. To delete the timer configuration, use the **no** form of this command.

timers [{flushagain | recovery | peering | programming}]
no timers [{flushagain | recovery | peering | programming}]

Syntax Description	flushagain	Specifies the MAC flush again timer.
	recovery	Specifies the recovery timer.
	peering	Specifies the peering timer.
	programming	Specifies the programming timer.

Command Default None.

Command Modes EVPN interface configuration
 EVPN configuration

Command History	Release	Modification
	Release 4.3.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The timers are configured globally in the EVPN configuration mode whereas in the EVPN interface configuration mode, the timers are configured per Ethernet.

The keywords **peering** and **programming** are supported only in the EVPN configuration mode.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to configure timers in the EVPN Interface configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# evpn
RP/0/RSP0/CPU0:router(config-evpn)# interface bundle-ether 1
RP/0/RSP0/CPU0:router(config-evpn-ac)# timers
RP/0/RSP0/CPU0:router(config-evpn-ac-timers)#
```

This example shows how to configure timers in the EVPN configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# evpn
RP/0/RSP0/CPU0:router (config-evpn)# timers
RP/0/RSP0/CPU0:router (config-evpn-timers)#
```

Related Commands	Command	Description
	evpn, on page 15	Enters EVPN configuration mode.
	interface (EVPN), on page 25	Enters the EVPN Interface configuration mode.
	recovery, on page 41	Configures the recovery timer.
	flushagain, on page 18	Configures the MAC flushagain timer.
	peering, on page 36	Configures the peering timer.
	programming, on page 39	Configures the programming timer.

unknown-unicast-bmac

To configure the unknown unicast backbone MAC address for a PBB edge bridge, use the **unknown-unicast-bmac** command in the PBB edge configuration mode. To return to the default behavior, use the **no** form of this command.

unknown-unicast-bmac *mac-address*
no unknown-unicast-bmac *mac-address*

Syntax Description	<i>mac-address</i> Unknown unicast backbone MAC address in hexadecimal format.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	PBB edge configuration
----------------------	------------------------

Command History	Release	Modification
	Release 3.9.1	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows how to configure the unknown unicast backbone MAC address for a PBB edge bridge:
-----------------	--

```

config
l2vpn
  bridge group PBB
    bridge-domain PBB-EDGE
      interface GigabitEthernet0/0/0/38.100
      !
      interface GigabitEthernet0/2/0/30.150
      !
    pbb edge i-sid 1000 core-bridge PBB-CORE
      unknown-unicast-bmac 0123.8888.8888
  !

```

!
!

Related Commands	Command	Description
	bridge-domain (VPLS)	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS)	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn	Enters L2VPN configuration mode.
	pbb, on page 34	Configures the provider backbone bridge core or edge.