



Release Notes for Cisco Compute Module for CGR 1000 Series Routers

First Published: April 3, 2017

This release note contains the latest information about the Cisco Compute Module for the CGR 1000 Series routers.

Organization

This guide includes the following sections:

Conventions	Conventions used in this document
About the Cisco Compute Module	Overview of the Compute Module.
Software Requirements	Software requirements for Compute Module.
Installation Notes	Procedures for downloading software
Limitations and Restrictions	Known limitations in Compute Module and supporting software.
Caveats	Open Caveats in CGR 1000 Compute Release 1.2.5.1
Related Documentation	Links to the documentation associated with this release

Conventions

This document uses the following conventions.

Conventions	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
courier font	Terminal sessions and information the system displays appear in courier font.

Conventions

Conventions	Indication
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Note: Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Caution: Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

Warning: IMPORTANT SAFETY INSTRUCTIONS

Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Regulatory: Provided for additional information and to comply with regulatory and customer requirements.

About the Cisco Compute Module

The CGR Compute Module is a modular, hardened server that can be installed in CGR 1000 routers. The compute module functions as a fog computing node at the edge of the network.

The x86-based multi-core compute module hardware incorporates the industry standard COM Express (COMe) module, referred to in this document as COMe sub-module. The sub-module fits inside the compute module enclosure, which occupies one slot of the host CGR. The CGR1120 and CGR1240 can each host one compute module.

Table 1 lists product options for the Compute Module.

Table 1 Compute Module Product SKUs

Product ID	Bulk Memory	DDR memory	CPU on COM-E
CGM-SRV-64	50 GB (Approximate)	4 GB	AMD GX-410VC, 4-Core 800 MHz
CGM-SRV-128	100 GB (Approximate)	4 GB	AMD GX-410VC, 4-Core 800 MHz

Software Requirements

To install and support the Cisco CGR 1000 Compute Module software on the CGR 1000 Series routers, ensure the software requirements in Table 2 are met.

Table 2 System Requirements

Software Requirements	Minimum Requirement	Software Bundle
Cisco IOS	Cisco IOS Release 15.6(3)M2	cgr1000-universalk9-bundle.SSA.156-3.M2
Cisco CGR 1000 Compute Module	CGR 1000 Compute Module 1.2.5.1	cgr1000-compute-1.2.5.1.SPA

Installation Notes

Please read this section and the [Limitations and Restrictions](#) section **before** installing the compute module.

Note: Cisco IOS Release 15.6(3)M2 must be installed in the CGR 1000 Series router to allow installation of a Compute Module. You can find those release notes at the following link:

<http://www.cisco.com/c/en/us/td/docs/routers/access/800/829/15-6-3M2-Release-Notes.html>

Limitations and Restrictions

- Only one compute module can be installed in a CGR 1240 or CGR 1120.
 - In a CGR 1240, you **must** install the compute module in slot 5 **and** Slot 6 **must** remain empty to dissipate heat.
 - In a CGR 1120, you can install the compute module in any slot.
- You cannot insert or remove a compute module from a CGR system that is up and running.
- Install only one Application Hosting Image per compute module.
 - Recommended Virtual Machines: Windows 7, Windows 10 or Linux (Ubuntu14.04LTS)
- When installing a 3G/4G module and/or WPAN module in the CGR 1240, reserve the following slots in that system:
 - Slot 3 with either the 3G or 4G module
 - Slot 4 for the WPAN module

Note: For complete installation details, refer to the [Cisco CGR 1000 Compute Module Installation and Configuration Guide](#)

Caveats

There are currently no open caveats for this software release.

Accessing the Bug Search Tool

You can use the Bug Search Tool to find information about caveats for this release, including a description of the problems and available workarounds. The Bug Search Tool lists both open and resolved caveats.

To access the Bug Search Tool, you need the following items:

- Internet connection
- Web browser
- Cisco.com user ID and password

To access the Bug Search Tool, use the following URL: <https://tools.cisco.com/bugsearch/search>

To search using a specific bug ID, use the following URL: <https://tools.cisco.com/bugsearch/bug/<BUGID>>

Related Documentation

[Cisco 1240 Connected Grid Router Hardware Installation Guide](#)

[Cisco 1120 Connected Grid Router Hardware Installation Guide](#)

[Attaching Ferrite Clamp on CGR 1000 Series Alarm Cables for Noise Suppression](#)

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies are considered un-Controlled copies and the original on-line version should be referred to for latest version.

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

© 2017 Cisco Systems, Inc. All rights reserved.

Related Documentation

Related Documentation