



Configuring Ethernet-over-MPLS (EoMPLS) and Pseudowire Redundancy (PWR)

- [Finding Feature Information](#), on page 1
- [Configuring EoMPLS](#), on page 1
- [Configuring Pseudowire Redundancy](#), on page 11

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Configuring EoMPLS

Information About EoMPLS

EoMPLS is one of the AToM transport types. EoMPLS works by encapsulating Ethernet PDUs in MPLS packets and forwarding them across the MPLS network. Each PDU is transported as a single packet.

Only the following mode is supported:

- Port mode—Allows all traffic on a port to share a single VC across an MPLS network. Port mode uses VC type 5.

For scale information related to this feature, see [Cisco Catalyst 3850 Series Switches Data Sheet](#).

Prerequisites for EoMPLS

Before you configure EoMPLS, ensure that the network is configured as follows:

Restrictions for EoMPLS

- Configure IP routing in the core so that the PE routers can reach each other through IP.
- Configure MPLS in the core so that a label switched path (LSP) exists between the PE routers.
- Configure **no switchport**, **no keepalive** and **no ip address** before configuring xconnect on the attachment circuit.
- For load-balancing, **port-channel load-balance** command is mandatory to be configured.

Restrictions for EoMPLS

- This feature is not supported on the C9500-32C, C9500-32QC, C9500-48Y4C, and C9500-24Y4C models of the Cisco Catalyst 9500 Series Switches.
- VLAN mode is not supported. Ethernet Flow Point is not supported.
- Port-channel as attachment circuit is not supported
- QoS : Customer DSCP Re-marking is not supported with VPWS and EoMPLS.
- VCCV Ping with explicit null is not supported.
- L2 VPN Interworking is not supported.
- L2 Protocol Tunneling CLI is not supported.
- Untagged, tagged and 802.1Q in 802.1Q are supported as incoming traffic.
- Flow Aware Transport Pseudowire Redundancy (FAT PW) is supported only in Protocol-CLI mode. Supported load balancing parameters are Source IP, Source MAC address, Destination IP and Destination MAC address.
- Enabling or disabling Control word is supported.
- MPLS QoS is supported in Pipe and Uniform Mode. Default mode is Pipe Mode.
- Both – the legacy xconnect and Protocol-CLI (interface pseudowire configuration) modes are supported.

By default, EoMPLS PW tunnels all protocols like CDP, STP. EoMPLS PW cannot perform selective protocol tunneling as part of L2 Protocol Tunneling CLI.

Configuring Port-Mode EoMPLS

Port-Mode EoMPLS can be configured in two modes :

- Xconnect Mode
- Protocol CLI Method

Xconnect Mode

To configure port-mode EoMPLS in xconnect mode, perform the following task :

SUMMARY STEPS

1. **enable**

2. **configure terminal**
3. **interface *interface-id***
4. **no switchport**
5. **no ip address**
6. **no keepalive**
7. **xconnect peer-device-id *vc-id* encapsulation mpls**
8. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	interface <i>interface-id</i> Example: Device(config)# interface TenGigabitEthernet1/0/36	Defines the interface to be configured as a trunk, and enters interface configuration mode.
Step 4	no switchport Example: Device(config-if)# no switchport	For physical ports only, enters Layer 3 mode..
Step 5	no ip address Example: Device(config-if)# no ip address	Ensures that there is no IP address assigned to the physical port.
Step 6	no keepalive Example: Device(config-if)# no keepalive	Ensures that the device does not send keepalive messages.

Protocol CLI Method

	Command or Action	Purpose
Step 7	xconnect <i>peer-device-id vc-id encapsulation mpls</i> Example: <pre>Device(config-if)# xconnect 1.1.1.1 962 encapsulation mpls</pre>	Binds the attachment circuit to a pseudowire VC. The syntax for this command is the same as for all other Layer 2 transports.
Step 8	end Example: <pre>Device(config)# end</pre>	Returns to privileged EXEC mode.

Protocol CLI Method

To configure port-mode EoMPLS in protocol-CLI mode, perform the following task :

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **port-channel load-balance dst-ip**
4. **interface** *interface-id*
5. **no switchport**
6. **no ip address**
7. **no keepalive**
8. **exit**
9. **interface pseudowire** *number*
10. **encapsulation mpls**
11. **neighbor** *peer-device-id vc-id*
12. **load-balance** *dst-ip*
13. **load-balance flow-label both**
14. **l2vpn xconnect context** *context-name*
15. **member** *interface-id*
16. **member pseudowire** *number*
17. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example:	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.


	Command or Action	Purpose
	Device> enable	
Step 2	configure terminal Example: <pre>Device# configure terminal</pre>	Enters global configuration mode.
Step 3	port-channel load-balance dst-ip Example: <pre>Device(config)# port-channel load-balance 192.168.2.25</pre>	Sets the load-distribution method to the destination IP address. <ul style="list-style-type: none"> • <i>dst-ip</i>— Destination IP address
Step 4	interface <i>interface-id</i> Example: <pre>Device(config)# interface TenGigabitEthernet1/0/21</pre>	Defines the interface to be configured as a trunk, and enters interface configuration mode.
Step 5	no switchport Example: <pre>Device(config-if)# no switchport</pre>	For physical ports only, enters Layer 3 mode..
Step 6	no ip address Example: <pre>Device(config-if)# no ip address</pre>	Ensures that there is no IP address assigned to the physical port.
Step 7	no keepalive Example: <pre>Device(config-if)# no keepalive</pre>	Ensures that the device does not send keepalive messages.
Step 8	exit Example: <pre>Device(config-if)# exit</pre>	Exits interface configuration mode.

	Command or Action	Purpose
Step 9	interface pseudowire <i>number</i> Example: Device(config-if)# interface pseudowire 17	Establishes an interface pseudowire with a value that you specify and enters pseudowire configuration mode. • <i>number</i> — Specifies the number of the pseudowire to be configured.
Step 10	encapsulation mpls Example: Device(config-if)# encapsulation mpls	Specifies the tunneling encapsulation.
Step 11	neighbor <i>peer-device-id</i> vc-<i>id</i> Example: Device(config-if)# neighbor 4.4.4.4 17	Specifies the peer IP address and virtual circuit (VC) ID value of a Layer 2 VPN (L2VPN) pseudowire.
Step 12	load-balance <i>dst-ip</i> Example: Device(config-if)# load-balance 192.168.2.25	Enables edge load balancing of traffic across multiple core facing interfaces using equal cost multipaths (ECMP). • <i>dst-ip</i> — Destination IP address
Step 13	load-balance flow-label both Example: Device(config-if)# load-balance flow-label both	Enables core load balancing based on flow-labels.
Step 14	l2vpn xconnect context <i>context-name</i> Example: Device(config-if)# l2vpn xconnect context vpws17	Creates a Layer 2 VPN (L2VPN) cross connect context and enters xconnect context configuration mode.
Step 15	member <i>interface-id</i> Example: Device(config-if)# member TenGigabitEthernet1/0/21	Specifies interface that forms a Layer 2 VPN (L2VPN) cross connect.

	Command or Action	Purpose
Step 16	member pseudowire <i>number</i> Example: Device(config-if)# member pseudowire 17	Specifies pseudowire interface that forms a Layer 2 VPN (L2VPN) cross connect.
Step 17	end Example: Device(config)# end	Returns to privileged EXEC mode.

Configuration Examples for EoMPLS

Figure 1: EoMPLS Topology



Configuration Examples for EoMPLS

PE Configuration	CE Configuration
<pre> mpls ip mpls label protocol ldp mpls ldp graceful-restart mpls ldp router-id loopback 1 force interface Loopback1 ip address 1.1.1.1 255.255.255.255 ip ospf 100 area 0 router ospf 100 router-id 1.1.1.1 nsf system mtu 9198 port-channel load-balance dst-ip ! interface GigabitEthernet2/0/39 no switchport no ip address no keepalive ! interface pseudowire101 encapsulation mpls neighbor 4.4.4.4 101 load-balance flow ip dst-ip load-balance flow-label both l2vpn xconnect context pw101 member pseudowire101 member GigabitEthernet2/0/39 ! interface TenGigabitEthernet3/0/10 switchport trunk allowed vlan 142 switchport mode trunk channel-group 42 mode active ! interface Port-channel42 switchport trunk allowed vlan 142 switchport mode trunk ! interface Vlan142 ip address 142.1.1.1 255.255.255.0 ip ospf 100 area 0 mpls ip mpls label protocol ldp !</pre>	<pre> interface GigabitEthernet1/0/33 switchport trunk allowed vlan 912 switchport mode trunk spanning-tree portfast trunk ! interface Vlan912 ip address 10.91.2.3 255.255.255.0 !</pre>

The following is a sample output of **show mpls l2 vc vcid vc-id detail** command :

```

Local interface: Gi1/0/1 up, line protocol up, Ethernet up
Destination address: 1.1.1.1, VC ID: 101, VC status: up
Output interface: V1182, imposed label stack {17 16}
Preferred path: not configured
Default path: active
Next hop: 182.1.1.1
Load Balance: ECMP
flow classification: ip dst-ip
Create time: 06:22:11, last status change time: 05:58:42
```

```

Last label FSM state change time: 05:58:42  Signaling protocol:
LDP, peer 1.1.1.1:0 up
Targeted Hello: 4.4.4.4(LDP Id) -> 1.1.1.1, LDP is UP
Graceful restart: not configured and not enabled
Non stop routing: not configured and not enabled
Status TLV support (local/remote) : enabled/supported
LDP route watch : enabled
Label/status state machine : established, LruRru
Last local dataplane status rcvd: No fault
Last BFD dataplane status rcvd: Not sent
Last BFD peer monitor status rcvd: No fault
Last local AC circuit status rcvd: No fault
Last local AC circuit status sent: No fault
Last local PW i/f circ status rcvd: No fault
Last local LDP TLV status sent: No fault
Last remote LDP TLV status rcvd: No fault
Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 512, remote 16
Group ID: local n/a, remote 0
MTU: local 9198, remote 9198
Remote interface description: Sequencing: receive disabled, send disabled

Control Word: On (configured: autosense)
SSO Descriptor: 1.1.1.1/101, local label: 512
Dataplane:
SSM segment/switch IDs: 4096/4096 (used), PWID: 1
VC statistics: transit packet totals: receive 172116845, send 172105364

transit byte totals: receive 176837217071, send 172103349728
transit packet drops: receive 0, seq error 0, send 0

```

The following is a sample output of **show l2vpn atom vc vcid vc-id detail** command :

```

pseudowire101 is up, VC status is up PW type: Ethernet
Create time: 06:30:41, last status change time: 06:07:12
Last label FSM state change time: 06:07:12
Destination address: 1.1.1.1 VC ID: 101
Output interface: Vl182, imposed label stack {17 16}
Preferred path: not configured
Default path: active Next hop: 182.1.1.1
Load Balance: ECMP Flow classification: ip dst-ip
Member of xconnect service pw101
Associated member Gi1/0/1 is up, status is up
Interworking type is Like2Like Service id: 0xe5000001
Signaling protocol: LDP, peer 1.1.1.1:0 up
Targeted Hello: 4.4.4.4(LDP Id) -> 1.1.1.1, LDP is UP
Graceful restart: not configured and not enabled
Non stop routing: not configured and not enabled
PWid FEC (128), VC ID: 101 Status TLV support (local/remote)
: enabled/supported
LDP route watch : enabled
Label/status state machine : established, LruRru

```

Configuration Examples for EoMPLS

Local dataplane status received		: No fault
BFD dataplane status received		: Not sent
BFD peer monitor status received		: No fault
Status received from access circuit		: No fault
Status sent to access circuit		: No fault
Status received from pseudowire i/f		: No fault
Status sent to network peer		: No fault
Status received from network peer		: No fault
Adjacency status of remote peer		: No fault
Sequencing: receive disabled, send disabled	Bindings	
Parameter Local		Remote
<hr/>		
Label	512	16
Group ID	n/a	0
Interface		
MTU	9198	9198
Control word on (configured: autosense)		on
PW type	Ethernet	Ethernet
VCCV CV type	0x02	0x02
	LSPV [2]	LSPV [2]
VCCV CC type	0x06	0x06
	RA [2], TTL [3]	RA [2], TTL [3]
Status TLV enabled		supported
Flow Label T=1, R=1		T=1, R=1
SSO Descriptor: 1.1.1.1/101, local label: 512		
Dataplane:		
SSM segment/switch IDs: 4096/4096 (used), PWID: 1		
Rx Counters 176196691 input transit packets, 181028952597 bytes		
0 drops, 0 seq err		
Tx Counters 176184928 output transit packets, 176182865992 bytes		
0 drops		

The following is a sample output of show mpls forwarding-table network mask command.

Local	Outgoing	Prefix	Bytes	Label	Outgoing	Next Hop
Label	Label	or Tunnel Id		Switched	interface	
57	No Label	1.1.1.1/32	0		Po45	145.1.1.1
	No Label	1.1.1.1/32	0		Te1/0/2	147.1.1.1
	No Label	1.1.1.1/32	0		Te1/0/11	149.1.1.1
	No Label	1.1.1.1/32	0		Te1/0/40	155.1.1.1

Configuring Pseudowire Redundancy

Information About Pseudowire Redundancy

The L2VPN Pseudowire Redundancy feature enables you to configure your network to detect a failure in the network and reroute the Layer 2 (L2) service to another endpoint that can continue to provide service. This feature provides the ability to recover from a failure either of the remote provider edge (PE) router or of the link between the PE and customer edge (CE) routers.

Pseudowire Redundancy (PWR) can be configured using both – the xconnect and the protocol-CLI method.

For scale information related to this feature, see [Cisco Catalyst 3850 Series Switches Data Sheet](#).

Prerequisites for Pseudowire Redundancy

- Configure **no switchport**, **no keepalive** and **no ip address** before configuring xconnect mode to connect the attachment circuit.
- For load-balancing, **port-channel load-balance** command is mandatory to be configured.

Restrictions for Pseudowire Redundancy

- This feature is not supported on the C9500-32C, C9500-32QC, C9500-48Y4C, and C9500-24Y4C models of the Cisco Catalyst 9500 Series Switches.
- VLAN mode, EFP (Ethernet Flow Point) and IGMP Snooping is not supported.
- PWR is supported with port mode EoMPLS only.
- Untagged, tagged and 802.1Q in 802.1Q are supported as incoming traffic.
- Flow Label for ECMP Load balancing in core network based on customer's source IP, destination IP, source MAC and destination MAC.
- Enabling or disabling Control word is supported.
- MPLS QoS is supported in Pipe and Uniform Mode. Default mode is Pipe Mode.
- Port-channel as attachment circuit is not supported.
- QoS : Customer DSCP Re-marking is not supported with VPWS and EoMPLS.
- VCCV Ping with explicit null is not supported.
- L2 VPN Interworking is not supported.
- Not more than one backup pseudowire supported.
- PW redundancy group switchover is not supported

Configuring Pseudowire Redundancy

Pseudowire Redundancy can be configured in two modes :

- Xconnect Mode
- Protocol CLI Method

Xconnect Mode

To configure pseudowire redundancy in xconnect mode, perform the following task :


Note

To enable load balance, use the corresponding load-balance commands from [Xconnect Mode, on page 2](#) section of Configuring Port-Mode EoMPLS.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface *interface-id***
4. **no switchport**
5. **no ip address**
6. **no keepalive**
7. **xconnect *peer-device-id vc-id encapsulation mpls***
8. **backup peer *peer-router-ip-addr vcid vc-id [priority value]***
9. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: <pre>Device> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: <pre>Device# configure terminal</pre>	Enters global configuration mode.
Step 3	interface <i>interface-id</i> Example: <pre>Device(config)# interface GigabitEthernet1/0/44</pre>	Defines the interface to be configured as a trunk, and enters interface configuration mode.

	Command or Action	Purpose
Step 4	no switchport Example: Device(config-if)# no switchport	For physical ports only, enters Layer 3 mode..
Step 5	no ip address Example: Device(config-if)# no ip address	Ensures that there is no IP address assigned to the physical port.
Step 6	no keepalive Example: Device(config-if)# no keepalive	Ensures that the device does not send keepalive messages.
Step 7	xconnect peer-device-id vc-id encapsulation mpls Example: Device(config-if)# xconnect 1.1.1.1 117 encapsulation mpls	Binds the attachment circuit to a pseudowire VC. The syntax for this command is the same as for all other Layer 2 transports.
Step 8	backup peer peer-router-ip-addr vcid vc-id [priority value] Example: Device(config-if)# backup peer 6.6.6.6 118 priority 9	Specifies a redundant peer for a pseudowire virtual circuit (VC).
Step 9	end Example: Device(config)# end	Returns to privileged EXEC mode.

Protocol CLI Method

To configure pseudowire redundancy in protocol-CLI mode, perform the following task :

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface *interface-id***
4. **no switchport**
5. **no ip address**
6. **no keepalive**
7. **exit**
8. **interface pseudowire *number***
9. **encapsulation mpls**
10. **neighbor *peer-device-id vc-id***
11. **exit**
12. **interface pseudowire *number***
13. **encapsulation mpls**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	interface <i>interface-id</i> Example: Device(config)# interface GigabitEthernet2/0/39	Defines the interface to be configured as a trunk, and enters interface configuration mode.
Step 4	no switchport Example: Device(config-if)# no switchport	For physical ports only, enters Layer 3 mode..
Step 5	no ip address Example: Device(config-if)# no ip address	Ensures that there is no IP address assigned to the physical port.

	Command or Action	Purpose
Step 6	no keepalive Example: Device(config-if)# no keepalive	Ensures that the device does not send keepalive messages.
Step 7	exit Example: Device(config-if)# exit	Exits interface configuration mode.
Step 8	interface pseudowire number Example: Device(config)# interface pseudowire 101	Establishes an interface pseudowire with a value that you specify and enters pseudowire configuration mode.
Step 9	encapsulation mpls Example: Device(config-if)# encapsulation mpls	Specifies the tunneling encapsulation.
Step 10	neighbor peer-device-id vc-id Example: Device(config-if)# neighbor 4.4.4.4 101	Specifies the peer IP address and virtual circuit (VC) ID value of a Layer 2 VPN (L2VPN) pseudowire.
Step 11	exit Example: Device(config-if)# exit	Exits interface configuration mode.
Step 12	interface pseudowire number Example: Device(config)# interface pseudowire 102	Establishes an interface pseudowire with a value that you specify and enters pseudowire configuration mode.

■ Configuration Examples for Pseudowire Redundancy

	Command or Action	Purpose
Step 13	encapsulation mpls Example:	

Configuration Examples for Pseudowire Redundancy

PE Configuration	CE Configuration
<pre> mpls ip mpls label protocol ldp mpls ldp graceful-restart mpls ldp router-id loopback 1 force ! interface Loopback1 ip address 1.1.1.1 255.255.255.255 ip ospf 100 area 0 router ospf 100 router-id 1.1.1.1 nsf ! interface GigabitEthernet2/0/39 no switchport no ip address no keepalive ! interface pseudowire101 encapsulation mpls neighbor 4.4.4.4 101 ! interface pseudowire102 encapsulation mpls neighbor 3.3.3.3 101 l2vpn xconnect context pw101 member pseudowire101 group pwgrp1 priority 1 member pseudowire102 group pwgrp1 priority 15 member GigabitEthernet2/0/39 ! interface TenGigabitEthernet3/0/10 switchport trunk allowed vlan 142 switchport mode trunk channel-group 42 mode active ! interface Port-channel42 switchport trunk allowed vlan 142 switchport mode trunk ! interface Vlan142 ip address 142.1.1.1 255.255.255.0 ip ospf 100 area 0 mpls ip mpls label protocol ldp !</pre>	<pre> interface GigabitEthernet1/0/33 switchport trunk allowed vlan 912 switchport mode trunk spanning-tree portfast trunk ! interface Vlan912 ip address 10.91.2.3 255.255.255.0 !</pre>

The following is sample output of the **show mpls l2transport vc vc-id** command :

```
Device# show mpls l2transport vc 101
Local intf      Local circuit          Dest address      VC ID      Status
-----  -----
Gi2/0/39        Ethernet             4.4.4.4           101        UP

Device# show mpls l2transport vc 102
Local intf      Local circuit          Dest address      VC ID      Status
-----  -----
Gi2/0/39        Ethernet             3.3.3.3           102        STANDBY
```

■ Configuration Examples for Pseudowire Redundancy