



# Cisco Unified Customer Voice Portal

---

- [Unified CVP, on page 1](#)
- [Operations Console, on page 3](#)
- [Error Handling, on page 14](#)
- [Control Center Operation, on page 14](#)
- [Device Pools, on page 41](#)
- [Import System Configuration, on page 44](#)
- [Export System Configuration, on page 45](#)
- [Location Feature, on page 46](#)
- [SIP Server Groups, on page 57](#)
- [Behavior, on page 67](#)
- [Dialed Number Pattern, on page 68](#)
- [Web Services, on page 76](#)
- [IOS Setup, on page 77](#)
- [Cisco VVB Setup, on page 84](#)
- [Perform Courtesy Callback, on page 92](#)
- [SIP Error Reason Code Mapping, on page 95](#)
- [Cloud Services, on page 97](#)

## Unified CVP

Unified CVP provides Voice over IP (VoIP) routing services for the Cisco Unified Intelligent Contact Management Enterprise (Unified ICME) and Cisco Unified Contact Center Express (UCCX) products. Unified ICME provides the services necessary to determine where calls should be routed, whether to ACDs, specific agents, or to VRUs, but the routing services themselves must be provided by an external routing client.

Traditionally, ICM routing clients were various Public Switch Telephone Network (PSTN) network switches, or customer-provided ACDs. Unified CVP makes it possible for Unified ICME to use VoIP gateways as routing clients as well. This functionality carries a number of advantages, not the least of which is that call traffic can be handled over the IP network rather than by the PSTN carrier, which reduces costs and provides greater network bandwidth.

Unified CVP supports all the features of existing PSTNs and adds additional features. For example, Unified CVP provides a Voice Response Unit (VRU) platform, which includes the ability to prompt for and collect basic data from the caller before delivering the call. Unified CVP enhances this traditional PSTN feature with the use of its own VXML Interactive Voice Response (IVR) application platform. Also, Unified CVP can

"park" calls by providing voice prompts or hold music to callers who are waiting in queue for an agent in Unified ICME.

A typical deployment of the Unified CVP solution requires operating, administering, managing, and provisioning multiple servers and IOS components. The Operations Console is a web-based console that enables users to centrally operate, administer, maintain, and provision the Unified CVP solution.

#### Related Topics

[Operations Console](#), on page 3

[Control Center Operation](#), on page 14

## Key Features and Benefits

Unified CVP is a web-based platform that provides carrier-class Interactive Voice Response (IVR) and Internet Protocol (IP) switching services over Voice Over IP (VoIP) networks.

Unified CVP includes these features:

- **IP-based services:**
  - **Switching** - Unified CVP can transfer calls over an IP network.
  - **Takeback** - Unified CVP can take back a transferred call for further IVR treatment or transfer.
  - **IVR Services** - The classic prompt-and-collect functions: "Press 1 for Sales, 2 for Service," for example.
  - **Queuing** - Calls can be "parked" on Unified CVP for prompting or music on hold, while waiting for a call center agent to be available.
  - **Voice Enabled IVR Services** - Unified CVP provides for sophisticated self-service applications, such as banking, brokerage, or airline reservations.
- **Compatibility with Other Cisco Call Routing and VoIP Products** - Specifically, Cisco Unified Intelligent Contact Management Hosted (Unified ICMH) or Unified ICME, Cisco Gateways, and Cisco IP Contact Center (IPCC).
- **Compatibility with Cisco Unified Communications Manager (Unified CM)** - Unified CM manages and switches VoIP calls among IP phones. When combined with Unified ICME, Unified CM becomes the IPCC product.
- **Compatibility with the PSTN** - Calls can be moved onto an IP-based network for Unified CVP treatment and then moved back out to a PSTN for further call routing to a call center.
- **Carrier-Class Platform** - Unified CVP is a reliable, redundant, and scalable platform, which allows it to work with service provider and large enterprise networks.
- **Reporting** - Unified CVP stores detailed call records in a reporting database using a well-documented schema. You can design and run custom reports using the ODBC-compliant reporting tool of your choice.
- **Operations Console** - A web-based console from which you can centrally operate, administer, maintain, and provision the Unified CVP solution.
- **Call Routing Support** - Unified CVP provides call routing services for SIP (RFC 3261).
- **VXML Services** - Unified CVP provides a platform for developing powerful, speech-driven interactive applications accessible from any phone.

The VXML platform includes:

- The Cisco Unified CVP VXML Server, a J2EE- and J2SE-compliant application server that dynamically drives the caller experience.
- The Cisco Unified Call Studio, a drag-and-drop graphical user interface (GUI) for the rapid creation of advanced voice applications.

## Operations Console

The Operations Console is a web-based interface from which you can configure the Unified CVP components in the Unified CVP solution. You can monitor and manage the following Unified CVP components directly from the Operations Console:

- Unified CVP Call Server
- Unified CVP Reporting Server
- Unified CVP VXML Server
- Unified CVP VXML Server (standalone)

The Operations Console manages component configurations. It also provides the ability to distribute Call Studio applications to Unified CVP VXML Servers, perform Reporting DB administration, and deploy licenses to all of the CVP devices listed above. Finally, the Operations Console provides basic visual indications as to which managed components are functioning properly and which are having problems.

Use the buttons and menus in the Operations Console to navigate through the web pages. The browser buttons are not supported.



---

**Note** Do not use the Back button in your browser to navigate back to the pages that you have visited previously.

---

The Operations Console provides access to the following operations:

- **Health Monitoring** - You can use any SNMP-standard monitoring tool to get a detailed visual and tabular representation of the health of the solution network. All Unified CVP product components and most Unified CVP solution components also issue SNMP traps and statistics which can be delivered to any standard SNMP management station or monitoring tool.
- **Direct administration of individual IOS-based components** - Administrators can select an individual gateway for direct administration using secure shell (ssh). Configurations which are modified in this way, or which are modified by directly accessing those components without using the Operations Server, can be uploaded to the Operations Server backup for later use.

You can perform the following tasks to get started with the Operations Console:

- Logging in to the Operations Console
- Using the Cisco Unified Customer Voice Portal Page
- Getting Acquainted with the Operations Console Menus

- Where to Find More Information
- Logging out from the Operations Console
- Viewing System-Level Operation States
- Transferring Script and Media Files
- Using the Control Center

## Sign In to Operations Console

To log in to the Operations Console, perform the following procedure.

### Before You Begin

If this is the first time you are logging in to the Operations Console after installing the Unified CVP software, you will need the password for the default Administrator account that was created during installation.

The inactivity session timeout for the Operations Console (when no activity is performed in the browser) is set to 60 minutes. If the browser is inactive for more than 60 minutes, you are required to login again.

## Procedure

To log in to the Operations Console:

- 
- Step 1** From the web browser, enter `https://ServerIP:9443/oamp`, where ServerIP is the IP address or hostname of the machine on which the Operations Console is installed.
- The main Unified CVP window opens.
- Step 2** Enter your user ID in the Username field.
- The first time you log in after installing the Unified CVP software, enter **Administrator**, the default user account.
- Step 3** In the Password field, enter your password.
- If you are logging in to the default Administrator account, enter the password that was set for this account during installation.
- If the user ID or password is invalid, the Operations server displays the message, "Invalid Username or password." Enter your user ID and password again and click **OK**.
- The main Cisco Unified Customer Voice Portal window opens.
- Step 4** Default security settings can prevent users from using the Operations Console. Check your security policy and, if needed, change the settings to a less restrictive level.
- 

### Related Topics

[Sign Out of Operations Console](#), on page 12

## My Account Screen

The My Account screen displays the settings for the account of the user who is currently logged in.

You can view the device pools and user groups to which you are assigned.

### Related Topics

[User Information](#), on page 5

[User Group Assignment](#), on page 6

[Device Pool Selection](#), on page 6

## User Information

**Table 1: User Information Configuration Settings**

Field	Description	Default	Range	Restart Required
<b>User Information</b>				
Username	Name of the user account. The user logs in to the Operations Console using this name. After logging in, the username is displayed in the upper right portion of the screen. You cannot change the username when editing a user account.	None	Valid names include uppercase and lowercase letters in the alphabet, the numbers 0 through 9, a dash, and an underscore.	No
Old Password	Old password for the user account.	None	Any text that follows the <a href="#">guidelines for choosing secure passwords</a>	No
Password	New password for the user account. User must type this password to log into the Operations Console.	None	Any text that follows the <a href="#">guidelines for choosing secure passwords</a>	No
Reconfirm Password	Retype the password for this user account to verify that you typed the password correctly.	None	Text must match the text entered in the Password field.	No
Firstname	(Optional) First name of the user.	None	Valid names include uppercase and lowercase letters in the alphabet, the numbers 0 through 9, a dash, and an underscore.	No
Lastname	(Optional) Last name of the user.	None	Valid names include uppercase and lowercase letters in the alphabet, the numbers 0 through 9, a dash, and an underscore.	No
E-mail	(Optional) e-mail address of the user.	None	Valid e-mail address	No

## User Group Assignment

To add/remove a user to/from a user group:

- 
- Step 1** To add a user to a group, select the user group from the **Available** pane, and then click the right arrow to move the user group to the **Selected** pane.
- Step 2** To remove a user from a group, select the user from the **Selected** pane, and then click the left arrow to move the user group to the **Available** pane.
- Step 3** Click **Save**.
- 

## Device Pool Selection

To add a user to or remove a user from a device pool:

- 
- Step 1** Select **User Management > User**.  
The Find, Add, Delete, Edit Users window opens.
- Step 2** Perform one of the following steps:
- Select a user by clicking on the name in the Username list.
  - Select the radio button preceding the name.
- Step 3** Select **Edit**.  
The Edit User window opens to the General tab.
- Step 4** Select the **Device Pools** tab.
- Step 5** Select the device pool from the **Available** pane, and then click the right arrow to move the pool to the **Selected** pane.
- Step 6** To remove a user from a device pool, perform the following steps:
- a) Select the device pool from the **Selected** pane.
  - b) Select the left arrow to move the device pool to the **Available** pane.
- Note** A user must always be associated with at least one device pool.
- Step 7** Select **Save**.
- 

## Cisco Unified Customer Voice Portal Page

The main Cisco Unified Customer Voice Portal page is displayed when you log in to the Operations Console. Navigation to the entire website is provided with the menu bar at the top of the screen.

### Related Topics

[Operations Console Menu Options](#), on page 7

[More Information About Unified CVP](#), on page 11

## Window Header

The window header, which displays at the top of each Operations Console window, contains the following fields:

Window header fields:

- Logged in as - User account for the user who is currently logged in.
- My Account- User who is currently logged in. See [My Account Screen, on page 4](#).
- Logout- Logs you out from the console. See [Sign Out of Operations Console, on page 12](#).
- About - Displays the Welcome window.
- Documentation Search - Searches the Ops Console documentation for a keyword.

## Operations Console Menu Options

Use the Operations Console menu options to configure Unified CVP components and users.



---

**Note** Selecting an item from the menu bar launches the respective page.

---

Menu	Options	Use To
System	Control Center	View the status of Cisco Unified Customer Voice Portal environment in a network control center. View the status and statistics by Device Type or Device Pools, logical groups of devices in Cisco Unified Customer Voice Portal solution. Initiate Start, Shutdown, or Graceful Shutdown actions on devices in the control center.
	Device Pool	Create, modify, and delete device pool names and descriptions for logical groups of devices (for example, all devices located in a geographical region).
	Import System Configuration	Import a previously-saved Operations Console Server configuration file and apply it to the current system.
	Export System Configuration	Save and export all configuration information for the Operations Console Server to a single file on your local computer.  You can later use this file to restore an Operations Console Server during disaster recovery.
	Location	Add, edit, synchronize, and delete Unified CM location information.
	SIP Server Groups	Configure server groups for SIP and view Call Server deployment status.
	Dialed Number Pattern	Configure the Dialed Number Patterns for a destination. You can define the dialed numbers for the Error Tone, Ring Tone, and other destinations.
	Web Services	Configure Diagnostic Portal servlet credentials.
	IOS Configuration	IOS Template Management - Add, Delete, Edit, Copy, and View an IOS template configuration pushed to an IOS gateway. The template contains the IOS commands required for use in a Unified CVP deployment.  IOS Template Deployment - Deploy a gateway configuration template to an IOS gateway. The template provisions the gateway and substitutes any variables in the template with the source devices that are chosen when it is deployed.
	VVB Configuration	Configure Virtualized Voice Browser and associate it with device pools.
Courtesy Callback	Courtesy Callback reduces the time callers have to wait on hold/in queue and allows the system to offer callers who meet certain criteria.	
SIP Error Reason Code Mapping	Configure SIP reason code to ISUP cause code mapping.	



Menu	Options	Use To
Device Management	Unified CVP Call Server	Configure Unified CVP Call Server general and infrastructure settings; specify call services settings for each deployment model; associate Unified CVP Call Servers with device pools and the SIP Proxy Server; and apply licenses to a Unified CVP Call Server.
	Unified CVP Reporting Server	Configure Unified CVP Reporting Server general and infrastructure settings, associate Unified CVP Reporting Servers with Unified CVP Servers, specify reporting properties, and associate Unified CVP Reporting Servers with device pools.  Perform Reporting database administration: schedule database backups and purges; manage database and reporting user names and passwords; apply licenses to a Unified CVP Reporting Server.
	Unified CVP VXML Server	Configure Unified CVP VXML Server general and infrastructure settings; specify primary and backup Unified CVP Call Servers; enable Unified CVP VXML Server reporting and specify VoiceXML data filters; associate Unified CVP VXML Servers with device pools; and apply licenses and transfer scripts to a VXML Server.
	Unified CVP VXML Server (standalone)	Configure Unified CVP VXML Server (standalone) general settings; associate Unified CVP VXML Server (standalone) with device pools; and apply licenses and transfer scripts to a Unified CVP VXML Server (standalone).  <b>Note</b> A Unified CVP VXML Server (standalone) handles calls that arrive through a VoiceXML gateway. (No statistics are provided when the Unified CVP VXML Server is configured this way.) Also, you cannot configure a database to and capture data from Unified CVP VXML Server (standalone) applications.
	Gateway	Configure Gateway general settings; associate Gateways with device pools; execute a subset of IOS commands; view gateway statistics; and transfer files.
	Virtualized Voice Browser	Configure Virtualized Voice Browser and associate it with device pools.
	Speech Server	Speech Server provides speech recognition and synthesis services. You can add a pre-configured Speech Server to the Operations Console.
	Media Server	Configure Media Server general settings and associate a Media Server with device pools.  <b>Note</b> Media Server administers the media files that contain messages and prompts callers hear.
	Unified CM	Configure Unified CM general settings; specify the URL to the Unified CM Device Administration page; and associate the Unified CM with device pools.

Menu	Options	Use To
	Unified ICM	Configure ICM Server general settings and associate the ICM Server with device pools.
	SIP Proxy Server	Configure SIP Proxy Server general settings; specify the URL to the SIP Proxy Server Device Administration page; and associate the SIP Proxy Server with device pools.
	Unified IC	Configure CUIS Server general settings and associate the CUIS Server with device pools.
	Device Past Configuration	Allows you to view the past 10 saved configurations of a selected device that are currently stored in the Operations Console database.
	Device Versions	View version information for the Unified CVP Call Server, Unified CVP Reporting Server, Unified CVP VXML Server, and Unified CVP VXML Server (standalone).
User Management	User Roles	Create, modify, and delete user roles. Assign SuperUser, Administrator, or Read Only access privileges to roles.
	User Groups	Create, modify, and delete user groups. Assign roles to user groups.
	Users	Manage Unified CVP users, and assign them to groups and roles.
Bulk Administration	File Transfer	Transfer license files, script files, and VXML applications to multiple devices at a time.
SNMP	V1/V2c	Configure the SNMP agent that runs on the Unified CVP device to use the V1/V2 SNMP protocol to communicate with an SNMP management station; add and delete SNMP V1/V2c community strings; configure a destination to receive SNMP notifications from an SNMP management station; and associate community strings with the device.
	V3	Configure the SNMP agent that runs on the Unified CVP device to use the V3 SNMP protocol to communicate with an SNMP management station; add and delete SNMP users and set their access privileges; configure a destination to receive SNMP notifications from an SNMP management station; and associate SNMP users with devices.
	System Group	Configure the MIB2 System Group system contact and location settings, and associate the MIB2 System Group with devices.
Tools	SNMP Monitor	Launch the SNMP Monitor application in a new browser window.
Help	Configure	Specify the URLs that launch the SNMP Monitor.
	Contents	Display the table of contents for the help system.
	This Page	Displays help on the current screen.

## More Information About Unified CVP

The Operations Console Online Help describes how to use the Operations Console to configure and perform basic monitoring of the components that make up the Unified CVP solution. For design considerations and guidelines for deploying enterprise network solutions that incorporate Cisco Unified Customer Voice Portal software, see the *Design Guide for Cisco Unified Customer Voice Portal* at <https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-implementation-design-guides-list.html>.

The following table lists the documents available in the Unified CVP documentation set.

For More Information on...	Refer to...
The versions of software and hardware that are required and compatible with the Unified CVP solution	<i>Hardware and System Software Specification for Cisco Unified Customer Voice Portal</i> at <a href="#">Hardware and Software System Specification for Cisco Unified Customer Voice Portal Software Compatibility Matrix for UCCE</a> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-contact-center-enterprise/products-device-support-tables-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-contact-center-enterprise/products-device-support-tables-list.html</a> .
System requirements, features of the release, packaging information, limitations and restrictions, and a list of known defects	<i>Release Notes for Cisco Unified Contact Center Enterprise Solution</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-release-notes-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-release-notes-list.html</a> .
Installing Unified CVP software, performing an initial configuration, and upgrading from earlier versions of Unified CVP software	<i>Installation and Upgrade Guide for Cisco Unified Customer Voice Portal</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-installation-guides-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-installation-guides-list.html</a> .
Setting up, running, and administering the Unified CVP product, including associated configuration	<i>Configuration Guide for Cisco Unified Customer Voice Portal</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/tsd-products-support-series-home.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/tsd-products-support-series-home.html</a>
Configuring the Reporting Server and Reporting Database and using report templates to generate reports	<i>Reporting Guide for Cisco Unified Customer Voice Portal</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-installation-and-configuration-guides-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-installation-and-configuration-guides-list.html</a> .
Using the Call Studio environment and deploying applications to the Cisco Unified CVP VXML Server	<i>User Guide for Cisco Unified CVP VXML Server and Cisco Unified Call Studio</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-user-guide-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-user-guide-list.html</a> .
Configuration options for all Say It Smart plugins	<i>Say It Smart Specifications for Cisco Unified CVP VXML Server and Cisco Unified Call Studio</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-user-guide-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-user-guide-list.html</a> .
Building components that run on the Cisco Unified CVP VXML Server	<i>Programming Guide for Cisco Unified CVP VXML Server and Cisco Unified Call Studio</i> at <a href="https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-programming-reference-guides-list.html">https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-programming-reference-guides-list.html</a> .

For More Information on...	Refer to...
The ports used by Unified CVP software components.	<i>Solution Port Utilization Guide for Cisco Unified Contact Center Solutions</i> at <a href="#">Port Utilization Guide for Cisco Unified Contact Center Solutions</a>

## Sign Out of Operations Console

To log out from the Operations Console, perform the following procedure.

### Procedure

To log out from the Operations Console:

---

Click **Logout** in the screen header at the top of the screen.

You are logged out and the main Cisco Customer Voice Portal window opens.

---

#### Related Topics

[Sign In to Operations Console](#), on page 4

## View System-Level Operation States

The Operations Console provides status information for each device. Each device can be in one of the states listed in the following table.

**Table 2: Description of States Displayed in the Status Window**

State	Reasons
Success	Indicates that the operation was successful.
Pending	Indicates that the operation has not yet been executed.
In Progress	Indicates that the operation is in progress.

State	Reasons
Failed	<p>The reasons for a <b>failed deployment</b> state are listed below:</p> <ul style="list-style-type: none"> <li>• Unable to locate IP address in the database</li> <li>• General database failure</li> <li>• The call server was not deployed</li> <li>• Unknown error</li> <li>• Notification error: Contact administrator</li> <li>• Could not write to properties file</li> <li>• The Call Server device is using an unknown version of the Unified CVP software</li> <li>• The Call Server device is using an older version of the Unified CVP software</li> <li>• Configuration not removed from the database</li> </ul> <p>This failure has multiple reasons:</p> <ul style="list-style-type: none"> <li>• Could not write to properties file</li> <li>• Device has not been deployed</li> <li>• General failure</li> <li>• Unable to access the Database</li> </ul>
	<p>The reasons for a <b>failed synchronization</b> state are listed below:</p> <ul style="list-style-type: none"> <li>• Device not accessible</li> <li>• Authentication failure</li> <li>• Web service is not available on the device</li> <li>• General database error</li> <li>• General error</li> <li>• Unknown host address</li> <li>• SOAP service error</li> </ul>



**Note** If you make any configuration changes after your initial deployment of any System-level configuration tasks, you must deploy the changed configuration again.

## Transfer Script and Media Files

You can transfer a single script or media file at a time from the Operations Console.

### Procedure

To transfer a script or media file:

- 
- Step 1** From the Device Management menu, select the type of server to which to transfer the script file. For example, to transfer a script or media file to a Gateway, select **Device Management > Gateway**.
- The Find, Add, Delete, Edit window lists any servers that have been added to the Operations Console.
- Step 2** Select a server by clicking on the link in its Hostname field or by clicking the radio button preceding it and then clicking **Edit**.
- Step 3** Select **File Transfer** in the toolbar and then click **Scripts and Media**.
- The Scripts and Media File Transfer page opens, listing the host name and IP address for the selected device. Script and Media files currently stored in the Operations Server database are listed in the Select From available Script Files box.
- Step 4** If the script or media file is not listed in the Select From Available Script Files box:
- Click **Select a Script or Media File from Your Local PC**.
  - Enter the file name in the text box or click **Browse** to search for the script or media file on the local file system.
- Step 5** If the script or media file is listed in the Select From Available Script and media Files box, select the script or media file.
- Step 6** Click **Transfer** to send the file to the device.
- The script or media file is transferred to the selected server.
- 

## Error Handling

The Operations Console performs two types of validations:

- **Client Side** - Validations using Javascript, which runs within the web browser. You must enable Javascript in the browser.
- **Server Side** - Validations that are run on the server side. These are extensive validations that include the client side validations and any business validations.

Client side validation errors display at the top of the page just below the Menu bar.

## Control Center Operation

Use the control center to view and manage the devices in the Unified CVP solution from a central place. You can view the status of an individual device or all the devices that belong to a group of devices. You can also shut down and start VXML, Reporting, and Call Servers; and view detailed statistics for each of these devices.

You can perform the following tasks from the Control Center:

- [View Devices by Type](#)
- [View Devices by Device Pool](#)
- [View Device Status](#)
- [View Pool Statistics](#)
- [View Device Associations](#)
- [View Infrastructure Statistics](#)
- [Unified ICM Service Call Statistics](#)
- [IVR Service Call Statistics](#)
- [SIP Service Call Statistics](#)
- [View Gateway Statistics](#)
- [Unified CVP VXML Server Statistics](#)
- [Standalone Unified CVP VXML Server Statistics](#)
- [View Pool Statistics](#)
- [Unified CVP Reporting Server Statistics](#)
- [Pool Statistics Tab](#)
- [Sort Servers](#)
- [Edit Device Setup](#)
- [View System-Level Operation States](#)
- [Start Server](#)
- [Shut Down Server](#)

## View Devices by Type

You can view groups of devices by type (for example, Call Server, or Reporting Server). Devices of the selected device type are listed in the right pane of the Control Center.

### Related Topics

[Start Server](#), on page 40

[Shut Down Server](#), on page 40

[Edit Device Setup](#), on page 39

[View Device Status](#), on page 16

## Procedure

To view devices by type:

- 
- Step 1** Select **System > Control Center**.

The Control Center window opens.

- Step 2** Select the Device Type tab.  
Devices types are listed in the Device Type tab.
- Step 3** Select the type of device to display.  
Only devices of the selected type are listed in the Devices tab in the right pane.
- 

## View Devices by Device Pool

You can view groups of devices by device pool (for example, the devices in the San Jose pool). If a device belongs to more than one device pool, that device is listed in each device pool.

### Related Topics

- [Start Server](#), on page 40
- [Shut Down Server](#), on page 40
- [Edit Device Setup](#), on page 39
- [View Device Status](#), on page 16

## Procedure

To view devices by device pool:

---

- Step 1** Select **System > Control Center**.
- Step 2** Select the **Device Pool** tab and then select a device pool from the list.  
Devices that belong to the selected device pool display on the **General** tab.
- Step 3** Sort the devices by Hostname, IP Address, Device Type, Status, or Active Calls by clicking the desired column header.  
Only the devices listed on the current page are sorted. For example, if you select a Call Server device pool and then click the **IP Address** column header, the call servers displayed on the current screen are sorted by the IP address.
- Step 4** Select the desired refresh interval from the **Refresh** drop-down menu.  
By default, pool statistics are not refreshed.
- Step 5** Click individual device in a device pool to display or edit the device configuration.
- 

## View Device Status

You can view the devices in a particular device pool by selecting Control Center from the System menu and then selecting the Device Pool tab and selecting a device pool. You can also view a particular type of device by selecting the Device Type tab and selecting a device type.

All CVP devices, Unified CVP Call Servers, Unified CVP Reporting Servers, and Unified CVP VXML Servers, report current operating status. The status of some devices, such as IOS devices, Unified CM, ICM



servers, SIP proxy servers display as N/A (Not Applicable) because the Operations Console does not monitor these device types.

The following tables describes the fields in the Control Center.

**Table 3: Device Status Fields in the Control Center**

Field	Description
Hostname	The hostname assigned to the device.
IP Address	IP address for the server.
Device Type	The category of the device, for example: Unified CVP Call Servers, Unified CVP Reporting Servers, or Unified CVP VXML Servers.
Actions	<p>Icons that indicate operations that you can perform on a selected device. Not all actions are available for all devices.</p> <p>Available actions include:</p> <ul style="list-style-type: none"> <li>• <b>Statistics</b> - Data on current activities and activities that occur during an interval.</li> <li>• <b>Unapplied Changes</b> - Indicates that configuration changes that have been saved to the Operations Console database have not yet been applied to the device.</li> <li>• <b>Link to an External Administration Page</b> - Displays a web-based administration page from which you can administer a server. Available for Unified CM, SIP proxy servers, and ICM Servers.</li> </ul>

Field	Description
Status	<p>The current operating status for a selected device.</p> <ul style="list-style-type: none"> <li>• The Device is up and running.</li> </ul> <p>CVP Service Internal States:</p> <ul style="list-style-type: none"> <li>• <b>In Service</b> - The service is running.</li> <li>• <b>In Service (Warning Threshold Reached)</b> - The service is running and the warning threshold has been reached.</li> <li>• <b>In Service (Critical Threshold Reached)</b> - The service is running and the critical threshold has been reached.</li> </ul> <ul style="list-style-type: none"> <li>• Device is not running or has no communication with local WebServicesManager service.</li> </ul> <p>CVP Service Internal States:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b> - The service has not been configured.</li> <li>• <b>Stopped</b> - The service is not running.</li> <li>• <b>Error Scenario (not an internal state)</b> - Where local WebServicesManager service has no message bus communication with device.</li> </ul> <ul style="list-style-type: none"> <li>• One or more of the device services are functioning partially.</li> </ul> <p>CVP Service Internal States:</p> <ul style="list-style-type: none"> <li>• <b>Starting</b> - The service is starting.</li> <li>• <b>Partial Service</b> - The service has been configured and started, but is not running at full service.</li> </ul> <p>Partial service may be attributed to waiting on a dependency (such as the IVR and SIP service waiting for ICM to connect to the VRU PIM), not licensed, or license usage critical.</p> <ul style="list-style-type: none"> <li>• <b>Stopping</b> - The service is stopping.</li> <li>• <b>Not Reachable</b></li> </ul> <ul style="list-style-type: none"> <li>• The device could not be reached from Operations Console.</li> </ul> <p>Common reasons for not reachable status are:</p> <ul style="list-style-type: none"> <li>• Machine shutdown.</li> <li>• WebServicesManager service on the device is down.</li> <li>• Security is enabled for device but invalid certificate configuration.</li> </ul>

Field	Description
Active Calls	<p>The total number of calls currently running in the device.</p> <ul style="list-style-type: none"> <li>• <b>&lt;Integer Value&gt;</b> - The number of calls for devices such as Unified CVP Call Server, Unified CVP Reporting Server, and Unified CVP VXML Server.</li> <li>• <b>N/A</b> - Not applicable for device type such as gateway, Unified CM Server, Virtualized Voice Browser and so on.</li> </ul>
Context Service Status	<p>Context service connectivity status for the selected device.</p> <ul style="list-style-type: none"> <li>• <b>Context Service States:</b> <ul style="list-style-type: none"> <li>• <b>N/A</b> - Device is not registered or context service not applicable for the device type.</li> <li>• <b>Up</b> - Device is registered with Context Service and no issues.</li> <li>• <b>Down</b> - Device is registered with Context Service and has connectivity issue.</li> </ul> </li> </ul>

Sometimes, the actual device status can be resultant of more than one CVP service state for the corresponding device. For example, the Unified CVP Call Service device status in Control Center is actually an aggregation of SIP, ICM, and IVR service states.

The following table describes device status that is specific to each CVP device type.

**Table 4: CVP Device Status**

CVP Device	Description
Unified CVP Call Server	<ul style="list-style-type: none"> <li>• <b>Up</b> All configured services (ICM/IVR/SIP) are in the In Service state and report the same to the Operations Console.</li> <li>• <b>Down</b> At least one of the configured services (ICM/IVR/SIP) is deemed stopped (or disabled), and none of these services are in the Not Reachable state.</li> <li>• <b>Partial</b> At least one of the configured services (ICM/IVR/SIP) is running at Partial Service, and neither of these services are in the Down or Not Reachable state. <b>Note</b> If the device status is Partial, the status of the individual services are shown in the Partial state Details. Click the Partial status in Control Center to view the tool tip; it describes each service state.</li> <li>• <b>Not Reachable</b> At least one of the configured services (ICM/IVR/SIP) is deemed Not Reachable. If the Unified CVP Call Server is configured with no services (SIP/IVR/ICM) active, its status in Control Center will always be Not Reachable.</li> </ul>

CVP Device	Description
Unified CVP Reporting Server	<ul style="list-style-type: none"> <li data-bbox="630 296 683 323">• <b>Up</b></li> <li data-bbox="646 338 1484 401">The reporting service is running as reported by Central Controller on the Unified CVP Call Server machine.</li> <li data-bbox="630 426 716 453">• <b>Down</b></li> <li data-bbox="646 468 1484 594">If the reporting service is deemed Stopped (or disabled) as reported by Central Controller on the Unified CVP Call Server machine or the WebServicesManager, an associated Unified CVP Call Server machine has no communication with Central Controller. <ul style="list-style-type: none"> <li data-bbox="683 615 1484 678">• The WebServicesManager on the Unified CVP Call Server has not received state events from the Controller for the reporting subsystem.</li> <li data-bbox="683 699 1484 825">• The Unified CVP Reporting Server is unable to communicate with Central Controller on the Unified CVP Call Server machine; Central Controller has no knowledge of state events and, therefore, cannot communicate state events to Operations Console.</li> </ul> </li> <li data-bbox="646 856 1484 1014">In either scenario, even if the Unified CVP Reporting Server is up and running and the WebServicesManager on the Unified CVP Reporting Server is up and running, the Operations Console still shows the status of the Unified CVP Reporting Server as Down when there is no communication with Control Controller.</li> <li data-bbox="630 1035 727 1062">• <b>Partial</b></li> <li data-bbox="646 1077 1484 1203">The reporting service is not in the Up, Down, or Not Reachable state. Unified CVP Reporting Server indicates a partial status when, for example, the reporting data buffer file is full and all new messages are written in memory in a buffer queue.</li> <li data-bbox="630 1224 813 1251">• <b>Not Reachable</b></li> <li data-bbox="646 1266 1484 1371">The Operations Console is unable to communicate to the WebServicesManager co-located with the associated Unified CVP Call Server (for example, the WebServicesManager service on the device is down).</li> </ul>

CVP Device	Description
Unified CVP VXML Server and Unified CVP VXML Server (standalone)	<p>In both cases, the Operations Console communicates with the WebServicesManager co-located on the Unified CVP VXML Server (or standalone) server machine. The WebServicesManager on the device runs the Unified CVP VXML Server status script to retrieve device status and the number of active calls.</p> <ul style="list-style-type: none"> <li>• <b>Up</b> If the WebServicesManager gets a valid number for the number of active calls after running the status script. Zero (0) is a valid number.</li> <li>• <b>Not Reachable</b> In addition to other reasons for the Not Reachable state, the Unified CVP VXML Server (or standalone) goes into this state if WebServicesManager does not get a valid number for active calls after running the status.</li> </ul> <p>There is no Partial or Down status for Unified CVP VXML Servers and Unified CVP VXML Server (standalone).</p>

## View Device Statistics

You can view realtime, interval, and aggregate data for Unified CVP devices.

### Related Topics

- [Infrastructure Statistics](#), on page 23
- [Unified ICM Service Call Statistics](#), on page 25
- [IVR Service Call Statistics](#), on page 28
- [SIP Service Call Statistics](#), on page 30
- [View Gateway Statistics](#), on page 33
- [Unified CVP VXML Server Statistics](#), on page 33
- [Standalone Unified CVP VXML Server Statistics](#), on page 36
- [Unified CVP Reporting Server Statistics](#), on page 37

## Procedure

To view device statistics:

- 
- Step 1** Select **System > Control Center**.
  - Step 2** From the Device Type tab in the left pane, select the type of device for which you want to view statistics.
  - Step 3** From the Devices tab, select a device by checking the radio button preceding it.
  - Step 4** Select **Statistics** either in the Actions column or in the toolbar.

Statistics for the selected device are reported in a new statistics result window. All event statistics are sent to an SNMP manager, if one is configured. The log messages XML file, `CVPLogMessages.xml`, defines the severity, destination (SNMP management station or Syslog server), and possible resolution for Unified CVP log messages.

---

## View Device Associations

The Operations Console supports the association of CVP Call Servers with Unified CVP VXML Servers and/or CVP Reporting Servers.

### Procedure

To view devices associated with a Call Server:

- 
- Step 1** Select **System > Control Center**.  
The Control Center window opens.
- Step 2** Click the hostname of a Call Server.  
The Edit CVP Call Server Configuration window opens.
- Step 3** From the toolbar, click **Device Associations**.  
The Device Association page lists the VXML Server, Reporting Server, and Courtesy Callback Reporting Server associated with this Call Server.
- 

## View Infrastructure Statistics

You can view realtime, interval, and aggregate data for Unified CVP devices.

### Related Topics

[Edit Log Messages XML File](#)

### Procedure

To view infrastructure statistics:

- 
- Step 1** Select **System > Control Center**.
- Step 2** Select the **Device Type** tab.
- Step 3** Select the type of device for which you want infrastructure statistics.  
Devices of the selected type display in the Devices tab.
- Step 4** Select the device by checking the radio button preceding it.
- Step 5** Select **Statistics** in the toolbar.
- Step 6** Select the **Infrastructure** tab.
- Statistics for the selected device are reported in a new window. All event statistics are sent to an SNMP manager, if one is configured. The log messages XML file, `CVPLogMessages.xml`, defines the severity, destination (SNMP management station or Syslog server), and possible resolution for Unified CVP log messages.
-

## Infrastructure Statistics

Unified CVP infrastructure statistics include realtime and interval data on the Java Virtual Machine (JVM), threading, and licensing.

You can access these statistics by selecting Control Center from the System menu and then selecting a device.

See [View Infrastructure Statistics](#) for more information.

Access infrastructure statistics either by:

- Selecting **System > Control Center**, selecting a device, clicking the **Statistics** icon in the toolbar, and then selecting the **Infrastructure** tab.
- Selecting a device type from the **Device Management** menu, selecting a device. Click **Edit > Statistics > Infrastructure**.

The following table describes infrastructure statistics.

**Table 5: Infrastructure Statistics**

Statistic	Description
<b>Realtime Statistics</b>	
Ports Available	The number of ports available for the processing of new calls. Exactly one port license is used per call, independent of the call's traversal through the individual call server services.
Current Port Usage	The number of port usage currently in use on the call server. Exactly one port usage is used per call, independent of the call's traversal of the individual call server services.
Current Port Usage State	The threshold level of port usage. There are four levels: safe, warning, critical, and failure. An administrator may set the required percentage of port licenses in use needed to reach a given threshold level, with the exception of the failure level which is reached when the number of ports checked out is equal to the total number of ports.
<b>Interval</b>	
Start Time	The time the system started collecting statistics for the current interval.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
Total New Port Usage Requests	The number of port usage checkout requests made in the current interval. For each port license checkout request, whether it checks out a new port license or not, this metric is increased by one.

Statistic	Description
Average Port Usage Requests/Minute	The average number of port usage checkout requests made per minute in the current interval. This metric is calculated by dividing the port license requests metric by the number of minutes elapsed in the current interval.
Maximum Port Usage	The maximum number of ports used during this time interval.
<b>Aggregate Statistics</b>	
Start Time	The time the service started collecting statistics.
Duration Elapsed	The amount of time that has elapsed since the service start time.
Total New Port Usage Requests	The number of port checkout requests made since the system was started. For each port checkout request, whether it checks out a new port or not, this metric is increased by one.
Average Port Usage Requests/Minute	The average number of port checkout requests made per minute since the system was started. This metric is calculated by dividing the aggregate port license requests metric by the number of minutes elapsed since the system was started.
Peak Port Usage	The peak number of simultaneous ports used since the start of the system. When a port checkout occurs, this metric is set to the current ports in use metric if that value is greater than this metric's current peak value.
Total Denied Port Usage Requests	The number of port checkout requests that were denied since the start of the system. The only reason a port checkout request would be denied is if the number of port licenses checked out at the time of the request is equal to the total number of ports available. When a port checkout is denied, the call does not receive regular treatment (the caller may hear a busy tone or an error message).

The following table describes thread pool system statistics. The thread pool is a cache of threads, used by Unified CVP components only, for processing of relatively short tasks. Using a thread pool eliminates the waste of resources encountered when rapidly creating and destroying threads for these types of tasks.

**Table 6: Thread Pool Realtime Statistics**

Statistic	Description
<b>Realtime Statistics</b>	
Idle Threads	The number of idle threads waiting for some work.
Active Threads	The number of running thread pool threads currently processing some work.
Core Pool Size	The number of thread pool threads that are never destroyed, regardless of their idle period.



Statistic	Description
Maximum Pool Size	The maximum number of thread pool threads that can exist simultaneously.
Largest Pool Size	The peak number of thread pool threads simultaneously tasks with some work to process.

The following table describes Java Virtual Machine statistics.

**Table 7: Java Virtual Machine (JVM) Realtime Statistics**

Statistic	Description
<b>Realtime Statistics</b>	
Peak Memory Usage	The greatest amount of memory used by the Java Virtual machine since startup. The number reported is in megabytes and indicates the peak amount of memory ever used simultaneously by this Java Virtual Machine.
Current Memory Usage	The current number of megabytes of memory used by the Java Virtual Machine.
Total Memory	The total amount of memory in megabytes available to the Java Virtual Machine. The number reported is in megabytes and indicates the how much of the system memory is available for use by the Java Virtual Machine.
Available Memory	The amount of available memory in the Java Virtual Machine. The number reported is in megabytes and indicates how much of the current system memory claimed by the Java Virtual Machine is not currently being used.
Threads in Use	The number of threads currently in use in the Java Virtual Machine. This number includes all of the Unified CVP standalone and thread pool threads, as well as those threads created by the Web Application Server running within the same JVM.
Peak Threads in Use	The greatest amount of threads ever used simultaneously in the Java Virtual Machine since startup. The peak number of threads ever used by the Java Virtual Machine includes all Unified CVP standalone and thread pool threads, as well as threads created by the Web Application Server running within the same JVM.
Uptime	The length of time that the Java Virtual Machine has been running. This time is measured in hh:mm:ss and shows the amount of elapsed time since the Java Virtual Machine process began executing.

## Unified ICM Service Call Statistics

The ICM Service call statistics include data on calls currently being processed by the ICM service, new calls received during a specified interval, and total calls processed since start time.

Access ICM Service statistics either by:

- Selecting **System > Control Center**, selecting a Unified CVP Call Server, clicking the **Statistics** icon in the toolbar, and then selecting the **ICM** tab.
- Selecting **Device Management > Unified CVP Call Server**, selecting a Unified CVP Call Server, clicking the **Statistics** icon in the toolbar, and then selecting the **ICM** tab.

The following table describes ICM Service call statistics.

**Table 8: ICM Service Call Statistics**

Statistic	Description
<b>Realtime Statistics</b>	
Active Calls	The current number of calls being serviced by the Unified ICM Server for a Unified CVP Call Server. This value represents a count of calls currently being serviced by the ICM for the Unified CVP Call Server for follow-on routing to a Contact Center agent.
Active SIP Call Legs	The Unified ICM Server can accept Voice over IP (VoIP) calls that originate using the Session Initiation Protocol (SIP). Active SIP Call Legs indicates the current number of calls received by the Unified ICM Server from the Unified CVP Call Server using the SIP protocol.
Active VRU Call Legs	The current number of calls receiving Voice Response Unit (VRU) treatment from the Unified ICM Server. The VRU treatment includes playing pre-recorded messages, asking for Caller Entered Digits (CED), or Speech Recognition Techniques to understand the customer request.
Active ICM Lookup Requests	Calls originating from an external Unified CVP VXML Server need call routing instructions from the Unified ICM Server. Active Lookup Requests indicates the current number of external Unified CVP VXML Server call routing requests sent to the ICM Server.
Active Basic Service Video Calls Offered	The current number of simultaneous basic service video calls being processed by the ICM service where video capability was offered.
Active Basic Service Video Calls Accepted	The current number of simultaneous calls that were accepted as basic service video calls and are being processed by the ICM service.
<b>Interval Statistics</b>	
Start Time	The time at which the current interval has begun.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
New Calls	The number of new calls received by the Intelligent Contact Management (ICM) application for follow-on Voice Response Unit (VRU) treatment and routing to a Contact Center agent during the current interval.

<b>Statistic</b>	<b>Description</b>
SIP Call Legs	The Intelligent Contact Management (ICM) application has the ability to accept Voice over IP (VoIP) calls that originate via the Session Initiation Protocol (SIP). Interval SIP Call Legs is an interval specific snapshot metric indicating the number of calls received by the ICM application via SIP during the current interval.
VRU Call Legs	The number of calls receiving Voice Response Unit (VRU) treatment from the Intelligent Contact Management (ICM) application. The VRU treatment includes playing pre-recorded messages, asking for Caller Entered Digits (CED), or speech recognition techniques to understand the customer request during the current interval.
ICM Lookup Requests	Calls originating in an external Unified CVP VXML Server need call routing instructions from the Intelligent Contact Management (ICM) application. Interval Lookup Requests is an interval specific metric indicating the number of external Unified CVP VXML Server call routing requests sent to the ICM application during the current interval.
Basic Service Video Calls Offered	The number of offered basic service video calls processed by the ICM service during the current interval.
Basic Service Video Calls Accepted	The number of basic service video calls accepted and processed by the ICM service during the current interval.
<b>Aggregate Statistics</b>	
Start Time	The time the service started collecting statistics.
Duration Elapsed	The amount of time that has elapsed since the service start time.
Total Calls	The total number of new calls received by the ICM application for follow-on VRU treatment and routing to a Contact Center agent since system start time.
Total SIP Call Legs	The ICM application has the ability to accept VoIP calls that originate via the SIP. Total SIP Switch Legs is a metric indicating the total number of calls received by the ICM application via SIP since system start time.
Total VRU Call Legs	The total number of calls that have received VRU treatment from the ICM application since system start time. The VRU treatment includes playing pre-recorded messages, asking for CED or Speech Recognition Techniques to understand the customer request.
Total ICM Lookup Requests	Calls originating in an external Unified CVP VXML Server need call routing instructions from the ICM application. Total Lookup Requests is a metric indicating the total number of external Unified CVP VXML Server call routing requests sent to the ICM application since system start time.
Total Basic Service Video Calls Offered	The total number of newly offered basic service video calls processed by the ICM service since system start time.

Statistic	Description
Total Basic Service Video Calls Accepted	The total number of new basic service video calls accepted and processed by the ICM service since system start time.

## IVR Service Call Statistics

The IVR service call statistics include data on calls currently being processed by the IVR service, new calls received during a specified interval, and total calls processed since the IVR service started.

Access IVR Service statistics either by:

- Selecting **System > Control Center**, selecting a Call Server, clicking the **Statistics** icon in the toolbar, and then selecting the **IVR** tab.
- Selecting **Device Management > Unified CVP Call Server**, and selecting a Unified CVP Call Server. Click **Edit > Statistics > IVR**.

The following table describes the IVR Service call statistics.

**Table 9: IVR Service Call Statistics**

Statistic	Description
<b>Realtime Call Statistics</b>	
Active Calls	The number of active calls being serviced by the IVR service.
Active HTTP Requests	The number of active HTTP requests being serviced by the IVR service.
<b>Interval Statistics</b>	
Start Time	The time the system started collecting statistics for the current interval.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
Peak Active Calls	Maximum number of active calls handled by the IVR service at the same time during this interval.
New Calls	New Calls is a metric that counts the number of New Call requests received from the IOS Gateway Service. A New Call includes the Switch leg of the call and the IVR leg of the call. This metric counts the total number of New Call Requests received by the IVR Service during this interval.

<b>Statistic</b>	<b>Description</b>
Calls Finished	A Call is a metric that represents the Switch leg of the CVP call and the IVR leg of the CVP call. When both legs of the call are finished, this metric increases. Calls Finished is a metric that counts the number of CVP Calls that have finished during this interval.
Average Call Latency	The average amount of time in milliseconds it took the IVR Service to process a New Call or Call Result Request during this interval.
Maximum Call Latency	The maximum amount of time in milliseconds it has taken for the IVR Service to complete the processing of a New Call Request or a Request Instruction Request during this time interval.
Minimum Call Latency	The minimum amount of time in milliseconds it took for the IVR Service to complete the processing of a New Call Request or a Request Instruction Request during this time interval.
Peak Active HTTP Requests	Active HTTP Requests is a metric that indicates the current number of simultaneous HTTP requests being processed by the IVR Service. Peak Active Requests is a metric that represents the maximum simultaneous HTTP requests being processed by the IVR Service during this time interval.
Total HTTP Requests	The total number of HTTP Requests received from a client by the IVR Service during this time interval.
Average HTTP Requests/second	The average number of HTTP Requests the IVR Service receives per second during this time interval.
Peak Active HTTP Requests/second	HTTP Requests per Second is a metric that represents the number of HTTP Requests the IVR Service receives each second from all clients. Peak HTTP Requests per Second is the maximum number of HTTP Requests that were processed by the IVR Service in any given second. This is also known as high water marking.
<b>Aggregate Statistics</b>	
Start Time	The time the service started collecting statistics.
Duration Elapsed	The amount of time that has elapsed since the service start time.
Total New Calls	New Calls is a metric that counts the number of New Call requests received from the IOS Gateway Service. A New Call includes the Switch leg of the call and the IVR leg of the call. Total New Calls is a metric that represents the total number of new calls received by the IVR Service since system startup.
Peak Active Calls	The maximum number of simultaneous calls processed by the IVR Service since the service started.

Statistic	Description
Total HTTP Requests	Total HTTP Requests is a metric that represents the total number of HTTP Requests received from all clients. This metric is the total number of HTTP Requests received by the IVR Service since system startup.
Peak Active HTTP Requests	Active HTTP Requests is a metric that indicates the current number of simultaneous HTTP requests processed by the IVR Service. Maximum number of active HTTP requests processed at the same time since the IVR service started. This is also known as high water marking.

## SIP Service Call Statistics

The SIP service call statistics include data on calls currently being processed by the SIP service, new calls received during a specified interval, and total calls processed since the SIP service started.

Access SIP service statistics either by:

- Selecting **System > Control Center**, selecting a Unified CVP Call Server, clicking the **Statistics** icon in the toolbar, and then selecting the **SIP** tab.
- Selecting **Device Management > Unified CVP Call Server** and selecting a Call Server. Click **Edit > Statistics > SIP**.

The following table describes the SIP Service call statistics.

**Table 10: SIP Service Call Statistics**

Statistic	Description
<b>Realtime Statistics</b>	
Active Calls	A real time snapshot metric indicating the count of the number of current calls being handled by the SIP service.
Total Call Legs	The total number of SIP call legs being handled by the SIP service. A call leg is also known as a SIP dialog. The metric includes incoming, outgoing, and ringtone type call legs. For each active call in the SIP service, there will be an incoming call leg, and an outgoing call leg to the destination of the transfer label.
Active Basic Service Video Calls Offered	The number of basic service video calls in progress where video capability was offered.
Active Basic Service Video Calls Answered	The number of basic service video calls in progress where video capability was answered.
Active Agent Whisper Calls	The number of active whisper call legs.
Active Agent Greeting Calls	The number of active greeting call legs.
<b>Interval Statistics</b>	

<b>Statistic</b>	<b>Description</b>
Start Time	The time the system started collecting statistics for the current interval.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
New Calls	The number of SIP Invite messages received by Unified CVP in the current interval. It includes the failed calls as well as calls rejected due to the SIP service being out of service.
Connects Received	The number of CONNECT messages received by SIP service in order to perform a call Transfer, in the last statistics aggregation interval. Connects Received includes the regular Unified CVP transfers as well as Refer transfers. Any label coming from the ICM service is considered a CONNECT message, whether it is a label to send to the VRU or a label to transfer to an agent.
Avg Latency Connect to Answer	The period of time between the CONNECT from ICM and when the call is answered. The metric includes the average latency computation for all the calls that have been answered in the last statistics aggregation interval.
Failed SIP Transfers (Pre-Dialog)	The total number of failed SIP transfers since system start time. When Unified CVP attempts to make a transfer to the first destination of the call, it sends the initial INVITE request to set up the caller with the ICM routed destination label. The metric does not include rejections due to the SIP Service not running. The metric includes failed transfers that were made after a label was returned from the ICM Server in a CONNECT message.
Failed SIP Transfers (Post-Dialog)	The number of failed re-invite requests on either the inbound or outbound legs of the call during the interval. After a SIP dialog is established, re-INVITE messages are used to perform transfers. Re-invite requests can originate from the endpoints or else be initiated by a Unified CVP transfer from the Unified ICME script. This counter includes failures for both kinds of re-invite requests.
Basic Service Video Calls Offered	The number of basic service video calls offered in the current interval.
Basic Service Video Calls Answered	The number of basic service video calls answered in the current interval.
Whisper Announce Answered	The number of calls for which whisper announcement was successful during the interval.
Whisper Announce Failed	The number of calls for which whisper announcement was failed during the interval.

<b>Statistic</b>	<b>Description</b>
Agent Greeting Answered	The number of calls for which agent greeting was successful during the interval.
Agent Greeting Failed	The number of calls for which agent greeting was failed during the interval.
<b>Aggregate Statistics</b>	
Start Time	The time the service started collecting statistics.
Duration Elapsed	The amount of time that has elapsed since the service start time.
Total New Calls	The number of SIP Invite messages received by Unified CVP since system start time. It includes the failed calls as well as calls rejected due to the SIP service being out of service.
Connects Received	The number of CONNECT messages received by SIP service in order to perform a Unified CVP Transfer, since system start time. Connects Received includes the regular Unified CVP transfers as well as Refer transfers. Any label coming from the ICM service is considered a CONNECT message, whether it is a label to send to the VRU or a label to transfer to an agent.
Avg Latency Connect to Answer	The period of time between the CONNECT from ICM and when the call is answered. The metric includes the average latency computation for all the calls that have been answered since system start up time.
Failed SIP Transfers (Pre-Dialog)	The total number of failed transfers on the first CVP transfer since system start time. A SIP dialog is established after the first CVP transfer is completed. The metric does not include rejections due to SIP being out of service. The metric includes failed transfers that were made after a label was returned from the ICM in a CONNECT message.
Failed SIP Transfers (Post-Dialog)	The number of failed re-invite requests on either the inbound or outbound legs of the call since start time. After a SIP dialog is established, re-INVITE messages are used to perform transfers. Re-invite requests can originate from the endpoints or else be initiated by a Unified CVP transfer from the Unified ICME script. This counter includes failures for both kinds of re-invite requests.
Total Basic Service Video Calls Offered	The total number of basic service video calls offered since system start time.
Total Basic Service Video Calls Answered	The total number of basic service video calls answered since system start time.
Total Whisper Announce Answered	The total number of call for which whisper announce was successful since the system start time.



Statistic	Description
Total Whisper Announce Failed	The total number of calls for which whisper announce failed since the system start time.
Total Agent Greeting Answered	The total number of calls for which agent greeting was successful since the system start time.
Total Agent Greeting Failed	The total number of calls for which agent greeting failed since the system start time.

## View Gateway Statistics

Gateway statistics include the number of active calls, available memory, and CPU utilization.

Access Gateway statistics either by:

### Procedure

- Selecting **System > Control Center**, selecting a Gateway, and then clicking the **Statistics** icon in the toolbar.
- Selecting **Device Management > Gateway**, selecting a Gateway, and then clicking the **Statistics** icon in the toolbar.

## Gateway Statistics

The following table describes Gateway statistics.

**Table 11: Gateway Statistics**

Statistic	Description
Active Calls	Number of currently active calls handled by the gateway. For example, Total call-legs: 0 no active calls
Free Memory	Free memory, for example:  Processor memory free: 82% I/O memory free: 79%
CPU Utilization	CPU utilization, for example:  CPU utilization for five seconds: 1%/0%; one minute: 1%; five minutes: 1%

## Unified CVP VXML Server Statistics

The Operations Console displays realtime, interval, and aggregate Unified CVP VXML Server statistics.

- VXML Statistics are not available if the Unified CVP VXML Server is deployed as standalone.

- To view VXML Statistics, at least one deployed Unified CVP VXML Server application must be configured with the CVPDataFeed logger.

Access Unified CVP VXML Server statistics either by:

- Selecting **System > Control Center**, selecting a VXML Server, and then clicking the **Statistics** icon in the toolbar.
- Selecting **Device Management > Unified CVP VXML Server**, and selecting a Unified CVP VXML Server. Click **Edit > Statistics**.

The following table describes the statistics reported by the Unified CVP VXML Server.

**Table 12: VXML Server Statistics**

Statistic	Description
<b>Port Usage Statistics</b>	
Total Ports	The total number of licensed ports for this Unified CVP VXML standalone server.
Port Usage Expiration Date	The date when the licensed ports expires for this Unified CVP VXML standalone server.
Available Ports	The number of port licenses available for this Unified CVP VXML standalone server.
Total Concurrent Callers	The number of callers currently interacting with this Unified CVP VXML standalone server.  <b>Note</b> The Total Concurrent Callers statistics is not applicable for applications having only audio elements.
<b>Real Time Statistics</b>	
Active Sessions	The number of current sessions being handled by the Unified CVP VXML Server.
Active ICM Lookup Requests	The number of current ICM requests being handled by the Unified CVP VXML Server.
<b>Interval Statistics</b>	
Start Time	The time at which the current interval begins.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
Sessions	The total number of sessions in the Unified CVP VXML Server in the current interval.

<b>Statistic</b>	<b>Description</b>
Reporting Events	The number of events sent to the Unified CVP Reporting Server from the Unified CVP VXML Server in the current interval.
ICM Lookup Requests	The number of requests from the Unified CVP VXML Server to the ICM Service in the current interval.
ICM Lookup Responses	The number of responses to both failed and successful ICM Lookup Requests that the ICM Service has sent to the Unified CVP VXML Server in the current interval. In the case that multiple response messages are sent back to the Unified CVP VXML Server to a single request, this metric will increment per response message from the ICM Service.
ICM Lookup Successes	The number of successful requests from the Unified CVP VXML Server to the ICM Service in the current interval.
ICM Lookup Failures	The number of requests from the Unified CVP VXML Server to the ICM Service in the current interval. This metric will be incremented in the case an ICM failed message was received or in the case the Unified CVP VXML Server generates the failed message.
<b>Aggregate Statistics</b>	
Start Time	The time at which the current interval has begun.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Total Sessions	The total number of sessions in the Unified CVP VXML Server since startup.
Total Reporting Events	The total number of reporting events sent from the Unified CVP VXML Server since startup.
Total ICM Lookup Requests	The total number of requests from the Unified CVP VXML Server to the ICM Service. For each ICM lookup request, whether the request succeeded or failed, this metric will be increased by one.
Total ICM Lookup Responses	The total number of responses the ICM Service has sent to the Unified CVP VXML Server since startup. For each ICM lookup response, whether the response is to a succeeded or failed request, this metric will be increased by one. In the case that multiple response messages are sent back to the Unified CVP VXML Server to a single request, this metric will increment per response message from the ICM Service.
Total ICM Lookup Successes	The total number of requests from the Unified CVP VXML Server to the ICM Service since startup. For each ICM lookup request that succeeded, this metric will be increased by one.

Statistic	Description
Total ICM Lookup Failures	The total number of requests from the Unified CVP VXML Server to the ICM Service since startup. For each ICM lookup request that failed, this metric will be increased by one. This metric will be incremented if an ICM failed message was received or if the Unified CVP VXML Server generates a failed message.

## Standalone Unified CVP VXML Server Statistics

The Operations Console displays realtime, interval, and aggregate Unified CVP VXML (Standalone) Server statistics.

Access Unified CVP VXML (Standalone) Server statistics either by:

- Selecting **System > Control Center**, selecting a Unified CVP VXML (Standalone) sever, and then clicking the icon in the toolbar.
- Selecting **Device Management > Unified CVP VXML (Standalone) Server**, and selecting a Unified CVP VXML (Standalone) server. Click **Edit > Statistics**.

The following table describes the statistics reported by the Unified CVP VXML (Standalone) Server.

**Table 13: Unified CVP VXML (Standalone) Server Statistics**

Statistic	Description
<b>Port Usage Statistics</b>	
Total Ports	The total number of licensed ports for this Unified CVP VXML standalone server.
Port Usage Expiration Date	The date when the licensed ports expires for this Unified CVP VXML standalone server.
Available Ports	The number of port licenses available for this Unified CVP VXML standalone server.
Total Concurrent Callers	The number of callers currently interacting with this VXML standalone server.  <b>Note</b> The Total Concurrent Callers statistics is not applicable for applications having only audio elements.

## View Pool Statistics

Device Pool statistics summarize the statistics for the devices that belong to the currently selected device pool.

### Procedure

To view device pool statistics:

- 
- Step 1** Select **System > Control Center**.
- The Control Center Network Map window opens.
- Step 2** Select **Pool Statistics**.
- Step 3** Select **Refresh** to update the data on the Pool Statistics tab.
- 

#### Related Topics

[Pool Statistics Tab](#), on page 38

## Unified CVP Reporting Server Statistics

Unified CVP Reporting Server statistics include the total number of events received from the IVR, SIP, and VXML services.

Access Reporting Server statistics either by:

- Choosing **System > Control Center**, selecting a Unified CVP Reporting Server, and then clicking the **Statistics** icon in the toolbar.
- Choosing **Device Management > Unified CVP Reporting Server**, and selecting a Unified CVP Reporting Server. Click **Edit > Statistics**.

The following table describes the Unified CVP Reporting Server statistics.

**Table 14: Unified CVP Reporting Server Statistics**

Statistic	Description
<b>Interval Statistics</b>	
Start Time	The time the system started collecting statistics for the current interval.
Duration Elapsed	The amount of time that has elapsed since the start time in the current interval.
Interval Duration	The interval at which statistics are collected. The default value is 30 minutes.
VXML Events Received	The total number of reporting events received from the VXML Service during this interval. For each reporting event received from the VXML Service, this metric will be increased by one.
SIP Events Received	The total number of reporting events received from the SIP Service during this interval. For each reporting event received from the SIP Service, this metric will be increased by one.
IVR Events Received	The total number of reporting events received from the IVR service in the interval. For each reporting event received from the IVR service, this metric will be increased by one.

Statistic	Description
Database Writes	The total number of writes to the database made by the Unified CVP Reporting Server during the interval. For each write to the database by the Unified CVP Reporting Server, this metric will be increased by one.
<b>Aggregate Statistics</b>	
Start Time	The time the service started collecting statistics.
Duration Elapsed	The amount of time that has elapsed since the service start time.
VXML Events Received	The total number of reporting events received from the VXML Service since the service started. For each reporting event received from the VXML Service, this metric will be increased by one.
SIP Events Received	The total number of reporting events received from the SIP Service since the service started. For each reporting event received from the SIP Service, this metric will be increased by one.
IVR Events Received	The total number of reporting events received from the IVR Service since the service started. For each reporting event received from the IVR Service, this metric will be increased by one.
Database Writes	The total number of writes to the database made by the Unified CVP Reporting Server since startup. For each write to the database by the Unified CVP Reporting Server, this metric will be increased by one.

## Pool Statistics Tab

Device pool statistics report data on the devices contained within a device pool as described in the following table.

**Table 15: Pool Statistics**

Field	Description
<b>Number of Servers in Different States</b>	
Server Type	Unified CVP servers include: Call Servers, Unified CVP VXML Servers, Unified CVP VXML Servers (standalone), and Reporting Servers.
Total Devices	Total number of devices for each server type.
Up	Number of servers of each type that are up and running.
Down	Number of servers of each type that have down status.
Partial	Number of servers of each type that have partial status.
Not Reachable	Number of servers of each type that have a Not Reachable status.

Field	Description
<b>Percentage of Servers in Different States</b>	
Server Type	Unified CVP servers include: Call Servers, Unified CVP VXML Servers, Unified CVP VXML Servers (standalone), and Reporting Servers.
Total Devices	Total number of devices for each server type.
Up	Percentage of servers of each type that are up and running.
Down	Percentage of servers of each type that have down status.
Partial	Percentage of servers of each type that have partial status.
Not Reachable	Percentage of servers of each type that have an Unreachable status.

**Related Topics**

[View Pool Statistics](#), on page 36

## Sort Servers

You can choose to sort the servers in ascending and descending sort sequences: by their network status (up, down, partial, unreachable), hostname, IP address, device type, and by the number of active calls.

### Procedure

To sort servers:

- 
- Step 1** Select **System > Control Center**.
- Step 2** Select **Device Pool** and then select a device pool from the list.  
Devices that belong to the selected device pool display on the General tab.
- Step 3** To sort the list of servers, click the heading for the column you want to sort by. After you sort the column, up/down arrows appear in the column headings. Click the arrows to specify the sort order for the column.
- 

## Edit Device Setup

You can edit the configuration of a device that has been added to the Operations Console.

### Procedure

To edit the configuration of a device:

- 
- Step 1** Select **System > Control Center**.  
The Control Center Network Map window opens to the General tab.

- Step 2** Click on the device hostname or select the radio button preceding the hostname and then click **Edit** on the toolbar.
- 

The Edit Configuration window for the selected device opens.

**Related Topics**

[Device Properties](#)

[Find Device](#)

[Past Device Setups in Operations Console Database](#)

## Start Server

You can start a Unified CVP Call Server, Unified CVP Reporting Server, or Unified CVP VXML Server from the Control Center.

**Related Topics**

[View Device Status](#), on page 16

[View Devices by Type](#), on page 15

[Shut Down Server](#), on page 40

## Procedure

To start a server:

---

- Step 1** Select **System > Control Center**.

The Control Center window opens to the General tab.

- Step 2** Select the Unified CVP Call Server, Unified CVP Reporting Server, or Unified CVP VXML Server to restart by clicking the radio button next to the server.

- Step 3** Select **Start**.

The server starts; its state displays in the Status column on the General tab.

**Note** By default, the device status is not refreshed. To set a refresh interval, select the desired interval from the Refresh drop-down menu.

---

## Shut Down Server

You can shut down a Unified CVP Call Server, Unified CVP Reporting Server, or Unified CVP VXML Server from the Control Center. A server instance enters the shutdown state as a result of a graceful shutdown or forced shutdown process.

During a graceful shutdown, running processes complete before the server is shut down. For example, if you want to stop the Unified CVP Call Server but want to complete the processing of calls in progress, you must choose Graceful Shutdown.

In a forceful shutdown, all processes are suspended immediately. If you were to shut down the Unified CVP Call Server forcefully, calls in progress will be immediately dropped.



### Related Topics

[Start Server](#), on page 40

## Procedure

To shut down a server:

---

**Step 1** Select **System > Control Center**.

The Control Center window opens to the General tab.

**Step 2** Select the Unified CVP Call Server, Unified CVP Reporting Server, or Unified CVP VXML Server to shut down by clicking the radio button next to the server.

**Step 3** To shut down a server immediately, select **Shutdown**. To shut down a server gracefully, select **Graceful Shutdown**.

---

The selected server shuts down, and its status shows as Down in the Devices tab in the right pane of the Control Center window.



---

**Note** Graceful Shutdown is not supported by Unified CVP VXML Server.

---

## Device Pools

A device pool is a logical group of devices. Device pools provide a convenient way to define a set of common characteristics that can be assigned to devices, for example, the region in which the devices are located. You can create device pools and assign devices to the device pools you created.

Every device you create is automatically assigned to a default device pool, which you can never remove from the selected device pool list. The Administrator account is also automatically assigned to the default device pool, which ensures that the Administrator can view and manage all devices. You cannot remove the Administrator from the default device pool.

When you create a user account, you can assign the user to one or more device pools, which allows the user to view the devices in that pool from the Control Center. Subsequently, you can remove the user from any associated device pools, which prevents that user from viewing the pool devices in the Control Center. Removing a user from the default device pool prevents the user from viewing all devices.

You can perform the following tasks using device pools:

- Adding a Device Pool
- Editing a Device Pool
- Deleting a Device Pool
- Adding or Removing a Device from a Device Pool
- Finding a Device Pool

## Add Device Pool to Operations Console

This section describes how to add a device pool to the Operations Console.

### Procedure

To add a device pool to the Operations Console:

- 
- Step 1** Select **System > Device Pool**.  
The Find, Add, Edit, Delete Device Pools window opens.
- Step 2** Select **Add New**.
- Step 3** In the General tab, fill in a unique name for the device pool and add a description.
- Note** Device pool names must be valid DNS names, which can include letters in the alphabet, the numbers 0 through 9, and a dash.
- Step 4** Select **Save** to save the device pool.

---

#### Related Topics

- [Device Pools](#), on page 41
- [Delete Device Pool](#), on page 43
- [Edit Device Pool](#), on page 42
- [Add or Remove Device From Device Pool](#), on page 43
- [Find Device Pool](#), on page 44

## Edit Device Pool

You can change the name and description of any device pool, except the default device pool.

### Procedure

To edit a device pool:

- 
- Step 1** Select **System > Device Pool**.  
The Find, Add, Delete, Edit Device Pools window opens.
- Step 2** Select the device pool by clicking on its name in the device pool list or selecting the radio button preceding it and clicking **Edit**.  
The Edit Device Pool Configuration window opens to the General tab.
- Step 3** You can change the description. You cannot change the name of a device pool.
- Step 4** Select **Save**.

---

#### Related Topics

- [Device Pools](#), on page 41

[Delete Device Pool](#), on page 43

[Add Device Pool to Operations Console](#), on page 42

[Add or Remove Device From Device Pool](#), on page 43

[Find Device Pool](#), on page 44

## Delete Device Pool

This section describes how to delete a device pool from the Operations Console.

### Procedure

To delete a device pool:

- 
- Step 1** Select **System > Device Pool**.  
The Find, Add, Edit, Delete Device Pools window opens.
- Step 2** Find the device pool by using the procedure in the Finding a Device Pool topic.
- Step 3** From the list of matching records, select the device pool that you want to delete.
- Step 4** Select **Delete**.
- Step 5** When prompted to confirm the delete operation, Select **OK** to delete or select **Cancel** to cancel the delete operation.
- 

#### Related Topics

[Device Pools](#), on page 41

[Edit Device Pool](#), on page 42

[Add Device Pool to Operations Console](#), on page 42

[Add or Remove Device From Device Pool](#), on page 43

[Find Device Pool](#), on page 44

## Add or Remove Device From Device Pool

This section describes how to delete a device pool from the device pool.

### Procedure

To add or remove a device from a device pool:

- 
- Step 1** From the Device Management menu, select the type of device you want to add to a device pool. For example, to add a Call Server to a device pool, select Unified CVP Call Server from the menu.  
A window listing known devices of the type you selected appears. For example, if you selected Call Server, known Unified CVP Call Servers are listed.
- Step 2** Select the device pool by clicking on its name in the device pool list or by selecting the radio button preceding it and clicking **Edit**.
- Step 3** Select the **Device Pool** tab.

- Step 4** To add a device to a device pool, select the device pool from the **Available** pane, and then click the right arrow to move the pool to the **Selected** pane.
- Step 5** To remove a device from a device pool, select the device pool from the **Selected** pane, and then click the left arrow to move the device pool to the **Available** pane.
- Step 6** Click **Save** to save the changes to the Operations Console database. Some edit device screens have an **Apply** button. Click **Apply** to copy the configuration to the device.
- 

## Find Device Pool

Because you might have several device pools in your network, the Operations Console lets you locate specific device pools on the basis of specific criteria. Use the following procedure to locate device pools.

### Procedure

To find a device pool:

- 
- Step 1** Select **System > Device Pool**.
- The Find, Add, Delete, Edit Device Pools window lists the available device pools 10 at a time, sorted by name.
- Step 2** If the list is long, you can click the first page, previous page, next page, and last page icons on the bottom right of the screen to page through the list. Or, you can enter a page number in the **Page** field and press **enter** to go directly to the numbered page.
- Step 3** You can also filter the list by selecting an attribute such as **Name**; selecting a modifier such as **begins with**; entering your search term; and clicking **Find**.

**Note** The filter is not case-sensitive, and wildcard characters are not allowed.

---

## Import System Configuration

In the event of disaster recovery, you can import a system configuration and apply a previously saved configuration.

The Unified CVP Operations Console supports the import of system-level configuration data.

When you import a database which was exported from an older version, the imported database is automatically upgraded to the latest version as indicated in the confirmation message.




---

**Note** The Unified CVP import operation does not back up or restore the CVP configuration of the VoiceBrowser or the sip.properties files. If a complete restore of Unified CVP server is required, you will need to manually restore some of the content of the sip.properties file as well as the VoiceBrowser configuration in addition to importing the system configuration using the Operations Console.

---

## Procedure

To import a system configuration:

- 
- Step 1** Stop the Cisco CVP WebServicesManager Service:
- Select **Start > All Programs > Administrative Tools > Services**.
  - Select **Cisco CVP WebServicesManager**.
  - Select **Stop**.
- Step 2** Select **System > Import System Configuration**.
- The Import System Configuration window opens.
- Step 3** If you know the file name, enter it in the Enter Configuration File text box. Otherwise, select **Browse to** and search for the configuration to import.
- Step 4** Select **Import**.
- Step 5** Restart the Cisco CVP OPSConsoleServer and Cisco CVP WebServicesManager Services on the machine and then log in to the Operations Console again:
- Select **Start > All Programs > Administrative Tools > Services**.
  - Select **Cisco CVP OPSConsoleServer**.
  - Select **Restart**.
  - Select **Cisco CVP WebServicesManager**.
  - Select **Restart**.
- 



**Note** All data in the Operations Console that is importing the configuration will be lost and replaced with the imported data.

---

### Related Topics

[Export System Configuration](#), on page 45

## Export System Configuration

Using Export System Configuration on the System menu, you can save and export all the configurations of the Operations Console to a single file on your local computer. This is particularly useful in a back up scenario. For example, if the Operations Console configuration file were to become corrupt, you can import the file and restore the Operations Console configuration without having to individually reconfigure each module. Consider exporting the database on a regular basis and also when you make major configuration changes to a device.

All Operations Console configuration data is exported, except for any files you have uploaded, including licenses and application scripts. The Operations Console supports the export of system-level configuration data.




---

**Note** The Unified CVP import and export operations do not back up or restore the CVP configuration of VoiceBrowser, sip.properties files, and Context Service data connection. If you must do a complete backup and record of the Unified CVP configuration, then you must manually back up the sip.properties file and the result of the VoiceBrowser **save** command in addition to exporting the system configuration using the Operations Console.

---

## Procedure

To export a system configuration:

- 
- Step 1** Select **System > Export System Configuration**.
- The Export System Configuration window displays.
- Step 2** Select **Export**.
- Step 3** In the Save As dialog box, select the location to store the file.
- 




---

**Note** You will probably save the configuration multiple times. Choose a naming convention that helps you identify the configuration, for example, include the current date and time in the file name.

---

### Related Topics

[Import System Configuration](#), on page 44

## Location Feature

Use the Location feature to route calls locally to the agent available in the branch office, rather than routing calls to centralized or non-geographical numbers. This system-level feature allows you to select a Unified CM server and extract the Unified CM location information (location provider). Once the administrator initiates the synchronization, the system retrieves the location information for all available Unified CM servers which have been identified as sources for location information.

After you have enabled synchronization for a Unified CM server, information can be retrieved from any of the Unified CM servers that have been identified as sources for location information.

Prerequisites:

- Ensure that the device type (Gateway / Virtualized Voice Browser) is already configured.
- The device Location ID information, if configured in the Location configuration page, is displayed as a read-only field.
- Any configurable fields remain empty if they were not configured by the user.



**Note** If a location is associated with more than one Gateway / Virtualized Voice Browser, the system displays multiple rows of the same location information for each associated device.



**Note** All Unified CM servers enabled for synchronization are used during the synchronization task. If you do not want a particular Unified CM to be used when the synchronization task is performed, then disable synchronization for that Unified CM.

The following table describes the settings used to configure the Location feature.

**Table 16: Location Configuration Settings**

Property	Description	Default	Value	Restart Required
<b>General</b>				
	Three options are available to identify the site information: <ul style="list-style-type: none"> <li>• Insert site identifier between the Network VRU label and the correlation ID</li> <li>• Insert site identifier at the beginning of the Network VRU label</li> <li>• Do not insert site identifier</li> </ul>	Insert site identifier between the Network VRU label and the correlation ID	Not applicable	No
<b>Locations</b>				
Location Name (required)	This is a user defined field.	Not applicable	a-z, A-Z, 0-9, - Max length 128 characters	No
Site ID (required)	The Site ID is a unique user-defined field.	Null	0-9, # Max length 128 characters	No
Location ID (required)	The Location ID is a unique user-defined field.	Null	a-z, A-Z, 0-9 Max length 128 characters	No

Property	Description	Default	Value	Restart Required
Unified CM IP Address  This field is not available for manually-configured locations.	Ensure to check the Enable Synchronization check box in the Unified CM Server Configuration screen's General Tab to select Unified CM as a Unified CM location information provider.  If a Unified CM server is removed from the Operations Console configuration, or if the Unified CM server is unreachable, or if the synchronization check box is deselected, all locations stored in the Operations Console are automatically marked as invalid.	Not applicable	Not applicable	No
Associated Gateway	You can select Gateways from the Available list to deploy location information.  You can configure multiple Gateways per location. An instance of a Gateway can only be assigned to one location.  When a Gateway is associated with a location, the Gateway configuration window displays the location as a read-only field.	Not applicable	Not applicable	No
Associated Virtualized Voice Browser	You can select Virtualized Voice Browsers from the available list to deploy location information.  You can configure multiple Virtualized Voice Browsers per location. An instance of a Voice Browser can only be assigned to one location.  When a Virtualized Voice Browser is associated with a location, the Virtualized Voice Browser configuration window displays the location as a read-only field.	Not applicable	Not applicable	No



Property	Description	Default	Value	Restart Required
Status	<p>The status indicates that the validity of the location information is valid or invalid:</p> <ul style="list-style-type: none"> <li> <b>Invalid:</b> The location is invalid if any of the following scenarios apply: <ul style="list-style-type: none"> <li>- the location was previously synchronized with a Unified CM server. Later, you delete this location from the Unified CM server. When you perform the next synchronization with the Unified CM server, this location becomes invalid.</li> <li>- the Unified CM server's Enable Synchronization check box remains unchecked. You can select and remove "Invalid" locations at any time. If a unified CM is deselected from the synchronization list after synchronizing with that Unified CM server, then all the locations synchronized from this Unified CM server become invalid.</li> <li>- If a Unified CM server is not reachable when the next synchronization occurs, then all the locations associated with that Unified CM become invalid.</li> </ul> </li> <li> <b>Valid:</b> The location is valid if any of the following scenarios apply: <ul style="list-style-type: none"> <li>- the Enable Synchronization check box is checked</li> <li>- the location is exists in a Unified CM server configuration, the last synchronization was successful with the Unified CM, and if that Unified CM is still selected.</li> </ul> </li> </ul>	Not applicable	Valid or Invalid	No
<b>Call Server Deployment</b>				
	<p>You can select call servers from the Available list to deploy location information.</p> <p>One or more call servers can be selected and designated as Selected/Available.</p>	Configuration is deployed to all selected call servers	Not applicable	No

You can perform the following tasks:

- [View Location Information](#)
- [Insert Site Identifiers](#)

- [Deploy Location Information](#)
- [Add Locations](#)
- [Edit Location Information](#)
- [Delete Location](#)
- [Synchronize Location Information](#)
- [View Location Deployment or Synchronization Status](#)
- [Find Location](#)

## View Location Information

### Procedure

To view location-based information:

---

**Step 1** Select **System > Location**.

Location information is listed on the Location tab. The Location tab displays the retrieved location information where you can edit and configure additional information.

If a location is associated with more than one Gateway / Virtualized Voice Browser, the same location information is presented in multiple rows. Only the associated device column differs.

**Step 2** Click the required device to launch the device configuration window.

---

#### Related Topics

- [Location Feature](#), on page 46
- [Insert Site Identifiers](#), on page 50
- [Deploy Location Information](#), on page 51
- [Add Locations](#), on page 53
- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [Synchronize Location Information](#), on page 55
- [View Location Deployment or Synchronization Status](#), on page 56
- [Find Location](#), on page 57

## Insert Site Identifiers

The Site Identifier insert applies to all selected call servers using the Location configuration.

#### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Deploy Location Information](#), on page 51
- [Add Locations](#), on page 53

- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [Synchronize Location Information](#), on page 55
- [View Location Deployment or Synchronization Status](#), on page 56
- [Find Location](#), on page 57

## Procedure

To insert site identifiers:

---

Select **System > Location**.

Site identifier information is listed on the General tab.

Three options are available to identify the site information:

- Insert site identifier between the Network VRU label and the correlation ID
  - Insert site identifier at the beginning of the Network VRU label
  - Do not insert site identifier
- 

## Deploy Location Information

By default, location information is deployed to all associated Call Servers. You can choose to deploy location information to one or more Call Servers.

### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Insert Site Identifiers](#), on page 50
- [Add Locations](#), on page 53
- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [Synchronize Location Information](#), on page 55
- [View Location Deployment or Synchronization Status](#), on page 56
- [Find Location](#), on page 57

## Procedure

To deploy location information:

---

**Step 1** Selects **System > Location**.

**Step 2** After making the required configuration changes, you have two options to save the configuration:

- Selects **Save & Deploy** in the bottom right corner of this page (or the **Save & Deploy** button in the toolbar above) to save the location information and initiate a deployment request to the selected Call Servers.

See [View Location Deployment or Synchronization Status, on page 56](#) for details on viewing the status information.

- Selects **Save** to save three components to the database: the location information, information in the General tab, and the associated Call Servers.

**Caution** In the following cases, the Deployment Status displays a warning message:

- If you have only saved the configuration details and have not deployed them.
- If you have edited or deleted an existing configuration and have not deployed the changes.
- If you changed the call server association.

## Error Scenario Deployment

The following table provides the status, and workaround for the deployment error scenarios.

Status	Workaround
Unable to access the database.	Restart the Operations Console service. Try again. Contact your administrator.
General failure.	There is an unknown error in deployment. Contact your administrator.
The device was not deployed.	Deploy the device first. Try again.
The device was not deployed.	Cannot remove from the database.
The device could not be reached.	Check the network connection by pinging the device. Check the firewall setting. Turn off the firewall if the firewall is on. If it is available, check if WebServicesManager service is on. Try again later.
The device is using an unknown version of the Unified CVP software.	Upgrade to the compatible version, then deploy again.
The device is using an unknown version of the Unified CVP software.	Cannot remove.

Status	Workaround
Device has no SIP Subsystem	If OAMP has deployed SIP Server Group to the call server, delete the call server, and re-create the call server with a SIP Subsystem; or, do not select Call Servers with No SIP when deploying SIP Server Group configuration.

## Add Locations

You can manually add location information for locations that do not exist in the Unified CM database.

### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Insert Site Identifiers](#), on page 50
- [Deploy Location Information](#), on page 51
- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [Synchronize Location Information](#), on page 55
- [View Location Deployment or Synchronization Status](#), on page 56
- [Find Location](#), on page 57

## Procedure

To add locations:

- 
- Step 1** Select **System** > **Location**.
  - Step 2** On the **Location** tab, select **Add New**.  
The Location Configuration window opens.
  - Step 3** Assign the Location, Site ID, Location ID, and the Unified CM IP Address as applicable to your configuration.
  - Step 4** Optionally, select the required Gateway / Voice Browser by moving it/them to the Selected column.
  - Step 5** Select **Save** or **Cancel**.
- 

## Edit Location Information

You can only select a single location for this operation.

### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Insert Site Identifiers](#), on page 50
- [Deploy Location Information](#), on page 51
- [Add Locations](#), on page 53
- [Delete Location](#), on page 54

[Synchronize Location Information](#), on page 55  
[View Location Deployment or Synchronization Status](#), on page 56  
[Find Location](#), on page 57

## Procedure

To edit the required location:

---

- Step 1** Select **System > Location**.
- Step 2** On the **Location** tab, select the required location in one of two ways:
- Select the check box for the required location and click **Edit**.
  - Select the required location in the Location tab.
- Step 3** Make the required changes and click **Save** or **Cancel** as applicable.
- 

## Delete Location

You can delete one or more locations at the same time.  
Only manually-configured and invalid locations can be deleted.

### Related Topics

[Location Feature](#), on page 46  
[View Location Information](#), on page 50  
[Insert Site Identifiers](#), on page 50  
[Deploy Location Information](#), on page 51  
[Add Locations](#), on page 53  
[Edit Location Information](#), on page 53  
[Synchronize Location Information](#), on page 55  
[View Location Deployment or Synchronization Status](#), on page 56  
[Find Location](#), on page 57

## Procedure

To delete a location:

---

- Step 1** Select **System > Location**.
- Step 2** Select the required locations.
- Step 3** On the **Location** tab, select **Delete**.  
A prompt window appears to confirm your intention.
- Step 4** Respond to the prompt (Proceed with Delete? OK | Cancel).  
This prompt may differ if you select a location which cannot be deleted.

When you make your selection, the Location tab refreshes to display the results of your deletion in the message bar.

---

## Synchronize Location Information

Location synchronization is a user-initiated task in the Operations Console. A single synchronization task runs in the background when initiated. When initiated, the system synchronizes and merges the location information for all Unified CM servers selected during the configuration. There are two sub-tasks to complete a synchronizing operation:

### Procedure

- Synchronization: The system retrieves the location data from Unified CM database.
- Merge: The system merges the retrieved data with existing location data in the Operations Console database.

### What to do next



---

**Note** The Location synchronization feature in the Operations Console only works with Unified CM.

---

### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Insert Site Identifiers](#), on page 50
- [Deploy Location Information](#), on page 51
- [Add Locations](#), on page 53
- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [View Location Deployment or Synchronization Status](#), on page 56
- [Find Location](#), on page 57

## Procedure

To synchronize and refresh the location information with the Unified CM server and merge the information with the Operations Console database:

---

**Step 1** Configure and save one or more Unified CM devices with synchronization enabled.

**Step 2** Select **System > Location**.

**Step 3** Select **Synchronize**.

The synchronization process is initiated.

**Note** Only one synchronization or deployment process can run at any given time. If one process is already running, you receive an error message stating the same.

**Step 4** Click **Refresh** to view the retrieved location information after the synchronization process is completed.

## Synchronize Error Scenarios

The following table provides the status, cause, and workaround for the synchronization error scenarios.

Status	Workaround
Not able to connect with the device.	Check the network connection by pinging the device. If the device is connected, try again.
User credentials are not correct. User can't be authenticated.	Check the user credentials.
Host name is unknown. Check the host name.	The host name is not correct. Verify the host name.
Web Service is not available on the device.	Determine if the AXL Web Service is available on the device. Enable the AXL Web Service on the device.
General database failure.	Restart your Operations Console service. Try again. If the problem persists, contact your administrator.
General failure.	There is an unknown error in synchronization. Contact your administrator.

## View Location Deployment or Synchronization Status

Deployment and Synchronization operations can be time consuming depending on the number of Call Servers or Unified CMs. When either process is running, you can select a status report to view the progress of the last initialized deployment or synchronization request.



**Note** The Deployment and Synchronization operations are mutually exclusive. Only one synchronization or deployment process can run at any given time. If one process is already running, you cannot initiate another process and you receive an error message.

The following information applies to the Status window:

### Procedure

- Unapplied changes (deployment status only) indicate that a Save operation took place since the last deployment operation.
- Only one call server can be deployed at any given time. The other call servers are either in the queue or in an already successful/failed state.



### Related Topics

- [Location Feature](#), on page 46
- [View Location Information](#), on page 50
- [Insert Site Identifiers](#), on page 50
- [Deploy Location Information](#), on page 51
- [Add Locations](#), on page 53
- [Edit Location Information](#), on page 53
- [Delete Location](#), on page 54
- [Synchronize Location Information](#), on page 55
- [Find Location](#), on page 57

## Procedure

To show deployment or synchronization results:

- 
- Step 1** Select **System > Location**.
  - Step 2** From the toolbar, select **Status**.
    - To view synchronization results, select **Synchronization Status**.
    - To view deployment results, select **Deployment Status**.
  - Step 3** Select **Refresh** to view the updated status information.  
See [View System-Level Operation States, on page 12](#) for more details on each state.
- 

## Find Location

### Procedure

To show deployment and/or synchronization results:

- 
- Step 1** Select **System > Location**.
  - Step 2** To scroll through multiple pages of the list, select the first, previous, next, and last page icons on the bottom left to view the next group of available notification destinations.
  - Step 3** You can filter the list by using the filter at the top right of the list. Select a field to search, a modifier (such as *Starts with*), and then select **Find**. The filter is not case-sensitive and wildcards are not allowed.
- 

## SIP Server Groups

In Unified CVP, you can add server groups at the system level to perform SIP dynamic routing.

A Server Group consists of one or more destination addresses (endpoints) and is identified by a Server Group domain name. This domain name is also known as the SRV cluster name, or Fully Qualified Domain Name (FQDN). Server Groups contain Server Group Elements.

## View SIP Server Groups

### SIP Server Groups

- General tab
- Heartbeat Properties tab
- Call Server Deployment tab

### General tab

The General tab displays the list of SIP Server Groups and SIP Server Group Elements

**Table 17: General Tab**

Column	Description
Name	The name of the SIP Server Group. Nested under the SIP Server Group are the SIP Server Group Elements.  Clicking the +/- icon next to the SIP Server Group name expands and collapses the elements within the group. Additionally, you can use <b>Collapse all</b> and <b>Expand all</b> to collapse/expand all the elements within the server groups listed on the page.
Number of Elements	The number of elements contained in the group.
Port	Port number of the element in the server group.
Secure Port	The listening port for secure connection.
Priority	Priority of the element in relation to the other elements in the server group. Specifies whether the server is a primary or backup server. Primary servers are specified as 1.
Weight	Weight of the element in relation to the other elements in the server group. Specifies the frequency with which requests are sent to servers in that priority group.



**Note** Clicking any of the column headers on this list sorts the list.

### Heartbeat Properties tab



**Note** The Up and Down Endpoint Heartbeat Interval is between any two heartbeats; however, it is not between heartbeats to the same endpoint. The SIP Server Group does not wake up at specific interval and send a heartbeat for all elements since this approach can result in CPU utilization issues. It also takes more resources to track heartbeats for many endpoints. For example, for 3 total elements across all SIP Server Groups, to proactively send a heartbeat to each element at 30000ms (30 seconds) intervals, you have to set the Endpoint Heartbeat Interval to 10000ms (10 seconds). It is less deterministic for reactive mode since elements that are currently down can fluctuate so the heartbeat interval fluctuates with it. To turn off pinging when the element is UP, set the UP interval to zero (reactive pinging). To turn off pinging when the element is down, set the DOWN interval to zero (proactive pinging). To ping when the element is either UP or DOWN, set both the intervals to greater than zero (adaptive pinging).

**Table 18: Heartbeat Properties Tab**

Property	Description	Default	Value
Use Heartbeats to Endpoints	Select to enable the heartbeat mechanism.  Heartbeat properties are editable only when this option is enabled.  <b>Note</b> Endpoints that are not in a Server Group can not use the heartbeat mechanism.	Disabled (unchecked)	Enabled or Disabled
Number of failed Heartbeats for unreachable status	The number of failed heartbeats before marking the destination as unreachable.	3	1 through 5
Heartbeat Timeout (ms)	The amount of time, in milliseconds, before timing out the heartbeat.	800 milliseconds	100 through 3000
Up Endpoint Heartbeat Interval (ms)	The ping interval for heart beating an endpoint (status) that is up.	5000 milliseconds	5000 through 3600000

Property	Description	Default	Value
Down Endpoint Heartbeat Interval (ms)	The ping interval for heart beating an endpoint (status) that is down.	5000 milliseconds	5000 through 3600000
Heartbeat Local Listen Port	The heartbeat local socket listen port. Responses to heartbeats are sent to this port on CVP by endpoints.	5067	0 through 65000
Heartbeat SIP Method	The heartbeat SIP method.  <b>Note</b> PING is an alternate method; however, some SIP endpoints do not recognize PING and will not respond at all.	OPTIONS	OPTIONS or PING

Property	Description	Default	Value
Heartbeat Transport Type	<p>During transportation, Server Group heartbeats are performed with a UDP or TCP socket connection. If the Operations Console encounters unreachable or overloaded callbacks invoked in the Server Group, that element is marked as being down for both UDP and TCP transports. When the element is up again, it is routable for both UDP and TCP.</p> <p><b>Note</b> TLS transport is not supported.</p>	UDP	UDP or TCP
Overloaded Response Codes	<p>The response codes are used to mark an element as <i>overloaded</i> when received. If more than one code is present, it is presented as a comma delimited list. An OPTIONS message is sent to an element and if it receives any of those response codes, then this element is marked as overloaded.</p>	503,480,600	<p>1 through 128 characters.</p> <p>Accepts numbers 0 through 9 and/or commas (,).</p>

Property	Description	Default	Value
Options Override Host	The contact header hostname to be used for a heartbeat request (SIP OPTIONS). The given value is added to the name of the contact header of a heartbeat message. Thus, a response to a heartbeat would contain gateway trunk utilization information.	cvp.cisco.com	Valid hostname, limited to 128 characters.

The **Heartbeats Estimation** section displays the Total Server Groups and Elements, and the Estimated Heartbeat interval for the current configuration.

The **Call Server Deployment** tab allows you to select to which Unified CVP Call Servers to deploy the SIP Server Groups.

You can perform the following tasks:

- [Add SIP Server Group, on page 62](#)
- [Delete SIP Server Group, on page 64](#)
- [Edit SIP Server Group, on page 64](#) (including adding, deleting, or editing SIP Server Group Elements)
- [Find SIP Server Groups, on page 65](#)
- [Deploy SIP Server Group Configurations, on page 66](#)
- [View SIP Server Groups Deployment Status, on page 67](#)

## Add SIP Server Group

### Procedure

To add a SIP Server Group:

- 
- Step 1** In the Operations Console, select **System > SIP Server Groups**.  
The SIP Server Groups window opens.
- Step 2** Select **Add New**.
- Step 3** Fill in the appropriate configuration settings:

Table 19: SIP Server Group Configuration Settings

Property	Description	Default	Value
<b>SIP Server Group Configuration</b>			
Server Domain Name FQDN	The Server Group Fully Qualified Domain Name (FQDN).	None	Up to 128 characters Must be unique. Must be a Fully Qualified Domain Name.
<b>SIP Server Group Elements</b>			
Enter the properties below and click <b>Add</b> to add the element to the SIP Server Group. Highlight any of the configured SIP Server Group Elements in the box below the property fields and;			
<ul style="list-style-type: none"> <li>• To remove the element from the group, highlight the element and click <b>Remove</b></li> <li>• To replace a selected element with the new element, edit the SIP Server Group Elements properties, highlight an existing element in the text box, and then click <b>Replace</b>.</li> </ul>			
IP Address/Hostname	IP address or hostname of the Server Group Element.	None	Valid IP address or hostname
Port	Port number of the element.	5060	1 through 65535
Secure Port	The listening port for secure connection.	None	5061
Priority	Priority of the element in relation to the other elements in the server group. Specifies whether the server is a primary or backup server. Primary servers are specified as 1.	10	1 through 2147483647
Weight	Weight of the element in relation to the other elements in the server group. Specifies the frequency with which requests are sent to servers in that priority group.	10	10 through 2147483647

**Step 4** Select **Save** to save the SIP Server Group.

You are returned to the **SIP Server Groups** page. To deploy the SIP Server Groups, you must associate a Unified CVP Call Server. Select the **Call Server Deployment** tab, select a Unified CVP Call Server and then click **Save & Deploy**. See [Deploy SIP Server Group Configurations, on page 66](#).

---

#### Related Topics

[View SIP Server Groups](#)

## Delete SIP Server Group



**Note** If you only want to delete elements within the group, see [Edit SIP Server Group, on page 64](#).

To delete a SIP Server Group:

- 
- Step 1** Select **System > SIP Server Groups**.  
The SIP Server Group page opens.
- Step 2** Find the SIP Server Group by using the procedure in [Find SIP Server Groups, on page 65](#).
- Step 3** Select the radio button next to the SIP Server Group that you want to delete and click **Delete**.
- Step 4** When prompted to confirm the delete operation, click **OK** to delete or click **Cancel** to cancel the delete operation.
- 

## Edit SIP Server Group

To configure a SIP Server Group, you must first define a FQDN and add it to the list.

### Procedure

To edit a SIP Server Group:

- 
- Step 1** In the Operations Console, select **System > SIP Server Groups**.  
The SIP Server Groups Configuration window opens.
- Step 2** On the **Server Groups Configuration** tab, define a FQDN for the server and select **Add** to add it to the list box.
- Step 3** Fill in the appropriate configuration settings, as shown in the following table:

*Table 20: SIP Server Group Configuration Settings*

Property	Description	Default	Value
<b>SIP Server Group Configuration</b>			
Server Domain Name FQDN	The Server Group Fully Qualified Domain Name (FQDN). <b>Note</b> This field is not editable	None	Up to 128 characters Must be unique. Must be a Fully Qualified Domain Name.



Property	Description	Default	Value
<b>SIP Server Group Elements</b>			
Enter the properties below and click <b>Add</b> to add the element to the SIP Server Group.			
Highlight any of the configured SIP Server Group Elements in the box below the property fields and;			
<ul style="list-style-type: none"> <li>• To remove the element from the group, highlight the element and click <b>Remove</b>, or</li> <li>• To replace a selected element with the new element, edit the SIP Server Group Elements properties, highlight an existing element in the text box, and then click <b>Replace</b>.</li> </ul>			
IP Address/Hostname	IP address or hostname of the Server Group Element.	None	Valid IP address or hostname
Port	Port number of the element.	5060	1 through 65535
Secure Port	The listening port for secure connection.	None	5061
Priority	Priority of the element in relation to the other elements in the server group. Specifies whether the server is a primary or backup server. Primary servers are specified as 1.	1	1 through 2147483647
Weight	Weight of the element in relation to the other elements in the server group. Specifies the frequency with which requests are sent to servers in that priority group.	10	10 through 2147483647

**Step 4** Click **Save** to save the SIP Server Group.

You are returned to the **SIP Server Groups** page. To deploy the SIP Server Groups, click **Save & Deploy** to save and deploy the edited configuration.

## Find SIP Server Groups

To find a SIP Server Group:

**Step 1** Select **System > SIP Server Groups**.

The SIP Server Groups Configuration window displays.

**Step 2** If the list is long, you can click the first page, previous page, next page, and last page icons on the bottom right of the screen to page through the list. Or, you can enter a page number in the **Page** field and press *enter* to go directly to the numbered page.

**Step 3** You can also filter the list by selecting an attribute such as **SIP Server Group Name** then selecting a modifier, such as **begins with**, and entering your search term then clicking **Find**.

**Note** The filter is not case-sensitive, and wildcard characters are not allowed.

---

## Deploy SIP Server Group Configurations

The Operations Console displays all configured SIP Server Groups. This section identifies the procedure to deploy a SIP Server Group.

### Procedure

To deploy SIP Server Group configurations:

---

**Step 1** In the Operations Console, select **System > SIP Server Groups**.

The SIP Server Groups Configuration window opens.

**Step 2** Click the **Call Server Deployment** tab.

**Step 3** From the **Available** list box, select one or more Call Servers and use the arrow button to move your selection to the **Selected** list box.

**Step 4** After making the required configuration changes, you have two options to save the configuration:

- Click **Save & Deploy** in the bottom right corner of this page (or the **Save & Deploy** button in the toolbar above) to save the SIP server information and initiate a deployment request to the selected devices.

See [View SIP Server Groups Deployment Status, on page 67](#) for details on viewing the status information.

- Click **Save** to save the configuration to the Operations Console database.

**Note** In the following cases, the Deployment Status displays a warning message:

- If you have only saved the SIP server details and have not deployed them.
  - If you have edited or deleted an existing configuration and have not deployed the changes.
  - If you changed the call server association.
  
  - Only one deployment process can run at any given time. If one process is already running, you will not be able to initiate another process and you receive an error message stating the same.
- A message displays to indicate the successful start of deployment process. The Operations Console saves the Call Server configuration to the Operations Console database and returns to display the new configuration in the list page.
- While deploying SIP Server Groups only the selected servers will be deployed. Any previous Call Servers deployed will be removed.
- 

See [View System-Level Operation States, on page 12](#) for more details on each state.

## View SIP Server Groups Deployment Status

The Operations Console displays all configured SIP Server Groups. If a deployment fails because the call server is not accessible (either not deployed or off line) or is not upgraded to the current version, the Operations Console issues a descriptive message.

Deployment operations can be time consuming, depending on the number of Call Servers. When either process is running, you can select a status report to view the progress of the last initialized deployment request.



**Note** The Deployment operations are mutually exclusive. Only one deployment process can run at any given time. If one process is already running, you will not be able to initiate another process and you will receive an error message stating the same.

The following information applies to the Status window:

### Procedure

- Unapplied changes (deployment status only) indicate that a Save operation took place since the last deployment operation.
- Only one call server can be deployed at any given time. The other call servers are either in the queue or in an already successful/failed state.

## Procedure

To view Call Server deployment status:

**Step 1** In the Operations Console, select **System > SIP Server Groups**.

The SIP Server Groups Configuration window opens.

**Step 2** From the toolbar, click **Deployment Status**.

**Step 3** Optionally, instead of Step 2, you can also click **Deployment Status** at the bottom right corner of the window.

The Operations Console provides status information for SIP Server Group (including the Operation Console's server time stamp). In case of a failure, the Operations Console provides a reason for the failure.

See [View System-Level Operation States, on page 12](#) for more details on each state.

## Behavior

**Table 21: When will CVP add SIP Element to UnreachableDestinationTable**

Scenario	UDP	TCP
After exhausting retry count for outgoing SIP Invite message (No response to outgoing SIP invite)	No	Yes

Scenario	UDP	TCP
In cases of SIP error response to outbound SIP Invite - 503, 480, 600	Yes	Yes
In Proactive Options Ping Mode - no response to SIP Options ping	Yes	Yes
TCP/UDP socket establishment mode	No	Yes

**Table 22: When will CVP remove SIP Element from UnreachableDestinationTable**

Scenario	UDP	TCP
After 180 seconds timer expiry (if Options Ping is not enabled)	Yes	Yes
With Reactive/Proactive/Adaptive options ping method - A valid response from SIP element for outbound SIP Options	Yes	Yes

## Dialed Number Pattern

You can perform the following tasks on Dialed Number Patterns:

- [Add Dialed Number Pattern](#)
- [Delete Dialed Number Pattern](#)
- [Edit Dialed Number Pattern](#)
- **Collapse All** - Collapse all hierarchical table entries to display root entries only.
- **Expand All** - Expand all hierarchical table entries to display all entries.
- **Pagination** - The bottom of the list display contains pagination fields to go to a specific page, go to the first page, go to the previous page, go to the next page, and go to the last page in the table list.
- [View Dialed Number Pattern Deployment Status](#) The Call Server(s) do not require a restart for the changes to take affect after clicking the **Deploy** button.
- [View Dialed Number Pattern Deployment Status](#) Display the deployment status for the previous deployment to configured Call Servers.

You can select the **Display Pattern Type** to display all configured Dialed Number Patterns in a tree-hierarchy view. Available selections are:

- Display All (default)
- Local Static Route
- Send Calls to Originator
- RNA Timeout for Outbound Calls
- Custom Ringtone

- Post Call Survey for Incoming Calls

Once the view is selected, a table containing the Dialed Number Patterns for the respective, selected type displays. The current view for the dialed number system-level configuration list page is maintained until the user session expires, either by timeout or by signing out from the Operations Console, or until the dialed number pattern view type selection changes.

Each dialed number pattern is displayed as a row. Each dialed number pattern column type can be sorted alphabetically in ascending or descending order. The Dialed Number list is in hierarchical format which lets you collapse or expand individual entries. One or more root hierarchical rows can be selected using the check-boxes. All table entries are expanded by default or after certain operations like sorting, filtering, or pagination.

The column types are as follows:

**Dialed Number Pattern** - The actual dialed number pattern.

**Description** - The dialed number pattern description.

You may also use the filtering function to filter for specific Dialed Number Patterns. Only the Dialed Number Pattern itself is filterable by the standard constraint criteria (that is, begins with, contains, ends with, is exactly, is empty). The Dialed Number Pattern list also has sortable columns.

## Add Dialed Number Pattern

### Procedure

To add a new Dialed Number Pattern:

**Step 1** In the Operations Console, select **System > Dialed Number Pattern**.

The Dialed Number Pattern window opens.

**Step 2** Select **Add New**.

**Step 3** Fill in the appropriate configuration settings:

*Table 23: Dialed Number Pattern Configuration Settings*

Property	Description	Default	Value
<b>General Configuration</b>			

Property	Description	Default	Value
Dialed Number Pattern	The actual Dialed Number Pattern.	None	<p>Must be unique.</p> <p>Maximum length of 24 characters.</p> <p>Can contain alphanumeric characters, wildcard characters such as exclamation point (!) or asterisk (*), single digit matches such as the letter X or period (.).</p> <p>Can end with an optional greater than (&gt;) wildcard character.</p>
Description	Information about the Dialed Number Pattern.	None	Maximum length of 1024 characters.
<b>Dialed Number Pattern Types</b>			
Enable Local Static Route	<p>Enable local static routes on this Dialed Number Pattern.</p> <p>If Local Static Routes are enabled:</p> <ul style="list-style-type: none"> <li>• <b>Route to Device</b> - Select the device from the drop-down list which contains a list of configured, supported devices. Once a selection is made, the IP Address/Hostname/Server Group Name field is automatically updated with the IP Address of the selected device.</li> <li>• <b>Route to SIP Server Group</b> - Select the device from the drop-down list which contains a list of configured, support devices. Once a selection is made, the IP Address/Hostname/Server Group Name field is automatically updated with the IP Address of the selected device.</li> <li>• <b>IP Address/Hostname/Server Group Name</b> - If you have not selected a <b>Route to Device</b> or <b>Route to SIP Server Group</b>, enter the IP address, hostname, or the server group name of the route.</li> </ul>	Disabled	<p>Maximum length of 128 characters.</p> <p>Must be a valid IP address, hostname, or fully qualified domain name.</p>

Property	Description	Default	Value
Enable Send Calls to Originator	Enables calls to be sent to originator.	Disabled	n/a
Enable RNA Timeout for Outbound Calls	Enables Ring No Answer (RNA) timer for outbound calls. <ul style="list-style-type: none"> <li>• <b>Timeout</b> - Enter the timeout value in seconds.</li> </ul>	Disabled none	n/a Valid integer in the inclusive range from 5 to 60.
Enable Custom Ringtone	Enables customized ring tone. <ul style="list-style-type: none"> <li>• <b>Ringtone media filename</b> - Enter the name of the file that contains the ringtone.</li> </ul>	Disabled none	Maximum length of 256 characters. Cannot contain whitespace characters.
Enable Post Call Survey for Incoming Calls	Enables post call survey for incoming calls. <ul style="list-style-type: none"> <li>• <b>Survey Dialed Number Pattern</b> - Enter the survey dialed number pattern.</li> </ul>	Disabled none	n/a Maximum length of 24 characters Accepts only alphanumeric characters

**Step 4** Click **Save** to save the Dialed Number Pattern.

You are returned to the **Dialed Number Pattern** page. To deploy the Dialed Number Pattern configuration, click **Deploy** to deploy the configuration to all Unified CVP Call Server devices.

## Delete Dialed Number Pattern

### Procedure

Deleting a dialed number pattern deletes the entire dialed number pattern and all dialed number pattern types associated with that dialed number pattern. You can check one or more dialed number pattern check boxes and select **Delete**.

To delete a Dialed Number Pattern:

**Step 1** Select **System > Dialed Number Pattern**.

The Dialed Number Pattern window opens.

**Step 2** Find the Dialed Number Pattern.

- Step 3** Select the radio button next to the Dialed Number Pattern that you want to delete and click **Delete**.
- Step 4** When prompted to confirm the delete operation, click **OK** to delete or click **Cancel** to cancel the delete operation. If confirmed, the delete operation proceeds and a message displays the results. If canceled, no operation will occur. The end-user will be presented with an error message if the delete button is selected and no check boxes are checked.

## Edit Dialed Number Pattern

To edit a Dialed Number Pattern, you must first define a Dialed Number Pattern.

### Procedure

To edit a Dialed Number Pattern:

- Step 1** In the Operations Console, select **System > Dialed Number Pattern**.  
The Dialed Number Pattern Configuration window opens.
- Step 2** Select the Dialed Number Pattern and click **Edit**.
- Step 3** Modify the appropriate configuration settings:

**Table 24: Dialed Number Pattern Configuration Settings**

Property	Description	Default	Value
General Configuration			
Dialed Number Pattern	The actual Dialed Number Pattern. This field is read-only.	n/a	n/a
Description	Information about the Dialed Number Pattern.	None	Maximum length of 1024 characters



Property	Description	Default	Value
Enable Local Static Route	<p>Enable local static routes on this Dialed Number Pattern.</p> <p>If Local Static Routes are enabled:</p> <ul style="list-style-type: none"> <li>• <b>Route to Device</b> - Select the device from the drop down list which contains a list of configured, supported devices. Once a selection is made, the IP Address/Hostname/Server Group Name field is automatically updated with the IP Address of the selected device.</li> <li>• <b>Route to SIP Server Group</b> - Select the device from the drop down list which contains a list of configured, support devices. Once a selection is made, the IP Address/Hostname/Server Group Name field is automatically updated with the IP Address of the selected device.</li> <li>• <b>IP Address/Hostname/Server Group Name</b> - If you have not selected a <b>Route to Device</b> or <b>Route to SIP Server Group</b>, enter the IP address, hostname, or the server group name of the route.</li> </ul>	Disabled	<p>Maximum length of 128 characters</p> <p>Must be a valid IP address, hostname, or fully qualified domain name</p>
Enable Send Calls to Originator	Enables calls to be sent to originator.	Disabled	n/a
Enable RNA Timeout for Outbound Calls	<p>Enables Ring No Answer (RNA) timer for outbound calls.</p> <ul style="list-style-type: none"> <li>• <b>Timeout</b> - Enter the timeout value in seconds.</li> </ul>	Disabled none	<p>n/a</p> <p>Valid integer in the inclusive range from 5 to 60.</p>
Enable Custom Ringtone	<p>Enables customized ring tone.</p> <ul style="list-style-type: none"> <li>• <b>Ringtone media filename</b> - Enter the name of the file that contains the ringtone.</li> </ul>	Disabled none	<p>Maximum length of 256 characters</p> <p>Cannot contain whitespace characters</p>
Enable Post Call Survey for Incoming Calls	<p>Enables post call survey for incoming calls.</p> <ul style="list-style-type: none"> <li>• <b>Survey Dialed Number Pattern</b> - Enter the survey dialed number pattern.</li> </ul>	Disabled none	<p>n/a</p> <p>Maximum length of 24 characters</p> <p>Accepts only alphanumeric characters</p>

**Step 4** Click **Save** to save changes to the Dialed Number Pattern.

You are returned to the **Dialed Number Pattern** page. To deploy the Dialed Number Pattern configuration, click **Deploy** to deploy the configuration to all Unified CVP Call Server devices.

---

## Find Dialed Number Patterns

### Procedure

To find a Dialed Number Pattern:

---

- Step 1** Select **System > Dialed Number Pattern** from the Main menu.  
The Dialed Number Pattern Configuration window opens.
- Step 2** If the list is long, you can click the first page, previous page, next page, and last page icons on the bottom right of the screen to page through the list. Or, you can enter a page number in the **Page** field and press **enter** to go directly to the numbered page.
- Step 3** You can also filter the list by selecting an attribute such as **Dialed Number Pattern Name** then selecting a modifier, such as **begins with**, and entering your search term then clicking **Find**.
- Note** The filter is not case-sensitive, and wildcard characters are not allowed.
- 

## Deploy Dialed Number Pattern

You can deploy all configured dialed number patterns to all configured Unified CVP Call Server devices.

### Procedure

To deploy Dialed Number Pattern configurations:

---

- Step 1** In the Operations Console select **System > Dialed Number Pattern**.  
The Dialed Number Pattern Configuration window opens.
- Step 2** Select one or more Dialed Number Patterns. Use the check box to the left of the Dialed Number Pattern column header to select all Dialed Number Patterns.
- Step 3** Click **Deploy** in the in the bottom right corner of this page to initiate a deployment request to the Unified CVP Call Servers.
- Note** In the following cases, the Deployment Status displays a warning message:
- No Unified CVP Call Server devices are configured
  - A Dialed Number Pattern deployment is already in progress

You will receive a success message if at least one Unified CVP Call Server is configured, using the system-level configuration, and no dialed number pattern deployment task is currently in progress. No restart is required on a successful deployment to each Unified CVP Call Server device.

**Note** Only one deployment process can run at any given time. If one process is already running, you will not be able to initiate another process and you will receive an error message.

A message displays to indicate the successful start of deployment process. The Operations Console saves the Call Server configuration to the Operations Console database and returns to display the new configuration in the list page.

---

## View Dialed Number Pattern Deployment Status

The Operations Console displays all configured Dialed Number Patterns. If a deployment fails because the Unified CVP Call Server is not accessible (either not deployed or off line) or is not upgraded to the current version, the Operations Console issues a descriptive message.

The Dialed Number Pattern Deployment Status page displays the last recorded deployment status per configured Unified CVP Call Server. You may refresh the page, view online help, or go back to the dialed number pattern list page. You may also sort (in alternating ascending and descending order) the Deployment Status table contents by the following column fields: Hostname, IP Address, Device Type Status, or Last Updated.

Deployment operations can be time consuming, depending on the number of Unified CVP Call Servers. When either process is running, you can select a status report to view the progress of the last initialized deployment request.



---

**Note** The Deployment operations are mutually exclusive. Only one deployment process can run at any given time. If one process is already running, you will not be able to initiate another process and you will receive an error message.

---

The following information applies to the Status window:

### Procedure

- Unapplied changes (deployment status only) indicate that a Save operation took place since the last deployment operation.
- Only one Unified CVP Call Server can be deployed at any given time. The other call servers are either in the queue or in an already successful/failed state.

## Procedure

To view Call Server deployment status:

- 
- Step 1** In the Operations Console, select **System > Dialed Number Pattern**.  
The Dialed Number Pattern Configuration window opens.
- Step 2** Select **Deployment Status** at the bottom right corner of the window.

The Operations Console provides status information for Dialed Number Pattern. In case of a failure, the Operations Console provides a reason for the failure.

---

## Web Services

Unified CVP offers a Web Services-based framework to deliver a common user experience across all Cisco Unified Communications applications for features such as setting preferences, directories, and communication logs; setting serviceability parameters; and collecting, analyzing, and reporting on information necessary to manage and troubleshoot Cisco Unified Communications solution. This centralized framework enables consistency between Cisco Unified Communications applications and ensures a unified view of common serviceability operations.

The Web Services application handles API queries from external clients for CVP diagnostic information.

The Operations Console interfaces with the Web Services application in two ways:

- **Web Services User Management:** The Operation Console administrator can configure new Web Services users (users with the Web Services user role type). The Operations Console administrator can also manually push any configured Web Services users using the procedure identified in [Set Up Web Services, on page 76](#).

When you make Web Services user information changes and when you successfully deploy a device, all Web Services users are *automatically* pushed to the deployed Unified CVP devices listed below:

- Unified CVP Call Server
- Unified CVP Reporting Server
- Unified CVP VXML Server
- Unified CVP VXML Server (standalone)
- CVP Remote Operations device

External clients may connect to the Web Services application and authenticate themselves with these credentials.

- **List Application Servers:** The Operations Console currently stores configuration details for all devices in the database. The Operations Console writes this information to a device file which the Web Services application uses to reply to queries from external clients.

To configure Web Services, see [Set Up Web Services, on page 76](#).

To view deployed Web Services configuration, see [View Web Services Deployment Status, on page 77](#).

## Set Up Web Services

You can manually deploy configured Web Services users to Unified CVP devices.

### Procedure

To manually deploy Web Services configurations:

- 
- Step 1** Select **System > Web Services**.  
The Web Services Configuration window opens.
- Step 2** There is no configuration on the general tab. Optionally, select the **Remote Operations Deployment** tab to configure remote operations deployment.
- Step 3** To associate Unified CVP Remote Operations with a third-party device, on the remote applications deployment tab:  
Provide the IP Address and Hostname, and optionally a description, of the third-party device.  
Click **Add** to add the device to the list of devices associated with this Unified CVP deployment's web services.
- Note** The third-party device must have CVP Remote Operations installed.
- Step 4** Click **Save & Deploy** in the bottom right corner of this page (or the **Save & Deploy** button in the toolbar above) to save and deploy the configuration to the impacted devices in the Operations Console database.  
See [View Web Services Deployment Status, on page 77](#) for details on viewing the status information.
- 

## View Web Services Deployment Status

You can verify the latest deployment status of the Web Services configuration. The deployment status is listed for each Unified CVP device.

### Procedure

To view the deployment status of Web Services configurations:

- 
- Step 1** Select **System > Web Services**.  
The Web Services Configuration window opens.
- Step 2** From the toolbar, click **Deployment Status**.  
The Web Services Deployment Status window displays the device IP address and current status.  
See [View System-Level Operation States, on page 12](#) for more details on each state.
- 

## IOS Setup

The Operations Console supports the ability to configure IOS gateways using templates. Templates are text files that contain the IOS commands required for use in a Unified CVP deployment. You can deploy the configuration defined in the template to a gateway right from the Operations Console. You can also rollback the configuration on the gateway to the point immediately before the template was deployed.



---

**Note** There is only one level of rollback. If you deploy a template (Template A) and then deploy another template (Template B), you can only roll back to Template A.

---

You can use the included default templates or create custom templates. The templates are text files that can be edited locally and then uploaded to the Operations Console.

The templates contain variables that are placeholders for configuration data. The variables can reference data that is in the Operations Console database as well as reference data that is outside of the Operations Console database, if it is accessible to the Operations Console (such as some portions of the Unified ICM database). The variables are replaced with the actual values of the data when the template is sent to the IOS Gateway.

Templates are located in the following directories on the Operations Console server:

- **Default Templates** - %CVP\_HOME%\OpsConsoleServer\IOSTemplates\default
- **Custom Templates** - %CVP\_HOME%\OpsConsoleServer\IOSTemplates\custom

IOS Configuration consists of :

- Template Management - Add, Delete, Edit, Copy, and View details about templates.
- Template Deployment - preview & deploy, view deployment status, and rollback template deployments.

See Also :

- IOS Template Format
- IOS Template Management
- IOS Template Deployment

## IOS Template Format

The IOS template must have a specific format to be accepted by the Operations Console:

- The second should be a configure terminal command, such as:  
`conf t`

See [View Template Details](#) for examples of the remaining configuration. With the exception of variables, all of the commands use standard IOS syntax.

The variables that can be used are detailed below:

Component	Variables
Unified CVP Call Server	<ul style="list-style-type: none"> <li>• %CVP.Device.CallServer.General.IP Address%</li> <li>• %CVP.Device.CallServer.ICM.Maximum Length of DNIS%</li> <li>• %CVP.Device.CallServer.ICM.New Call Trunk Group ID%</li> <li>• %CVP.Device.CallServer.ICM.Pre-routed Call Trunk Group ID%</li> <li>• %CVP.Device.CallServer.SIP.Outbound SRV Domain Name/Server Group Domain Name (FQDN)%</li> <li>• %CVP.Device.CallServer.SIP.Outbound Proxy Port%</li> <li>• %CVP.Device.CallServer.SIP.Port number for Incoming SIP Requests%</li> <li>• %CVP.Device.CallServer.SIP.DN on the Gateway to play the ringtone%</li> <li>• %CVP.Device.CallServer.SIP.DN on the Gateway to play the error tone%</li> <li>• %CVP.Device.CallServer.SIP.Generic Type Descriptor (GTD) Parameter Forwarding%</li> <li>• %CVP.Device.CallServer.SIP.PrependDigits - Number of Digits to Strip and Prepend%</li> <li>• %CVP.Device.CallServer.SIP.UDP Retransmission Count%</li> <li>• %CVP.Device.CallServer.IVR.Media Server Retry Attempts%</li> <li>• %CVP.Device.CallServer.IVR.IVR Service Timeout%</li> <li>• %CVP.Device.CallServer.IVR.Call Timeout%</li> <li>• %CVP.Device.CallServer.IVR.Media Server Timeout%</li> <li>• %CVP.Device.CallServer.IVR.ASR/TTS Server Retry Attempts%</li> <li>• %CVP.Device.CallServer.IVR.IVR Service Retry Attempts%</li> </ul>
Unified CVP Reporting Server	%CVP.Device.ReportingServer.General.IP Address%
Unified CVP VXML Server	%CVP.Device.VXMLServer.General.IP Address%
Gateway	<ul style="list-style-type: none"> <li>• %CVP.Device.Gateway.Target.IP Address%</li> <li>• %CVP.Device.Gateway.Target.Trunk Group ID%</li> <li>• %CVP.Device.Gateway.Target.Location ID%</li> </ul>
SIP Proxy Server	%CVP.Device.SIPProxyServer.General.IP Address%

Component	Variables
Speech Server	%CVP.Device.Speech Server.General.IP Address%
Unified Communications Manager	%CVP.Device.Unified CM.General.IP Address%
Media Server	%CVP.Device.Media Server.General.IP Address%

## IOS Template Management

You use this page to manage IOS templates.

You can perform the following tasks:

### Add New Template

To add a new template:

---

**Step 1** Select **System > IOS Configuration > IOS Template Management**.

The IOS Template Management page opens.

**Step 2** From the toolbar, select **Add New**.

The IOS Template Configuration page opens.

**Step 3** Click **Browse** to browse to a template file on your local computer. Provide a name for the template and an optional description. Click **Save** to upload the template file to the Operations Console.

**Note** The file you select to upload must be of a valid file format or the upload fails. See [IOS Template Format, on page 78](#) for details on the format required and the variables that you can use in your template.

A message is displayed confirming successful upload if the file is valid.

### Delete Templates




---

**Note** You cannot delete default templates. Only custom templates can be deleted.

To delete templates:

---

**Step 1** Select **System > IOS Configuration > IOS Template Management**.

The IOS Template Management page opens.

**Step 2** Select the checkboxes next to the templates you want to delete.

**Step 3** From the toolbar, select **Delete**.



A confirmation appears. Select **OK** to proceed and delete any custom templates selected.

---

## Edit Templates

You can edit templates. You can change the description of any template. You can edit the body of custom templates from within the browser. You cannot edit the body of default templates.

---

- Step 1** Select **System > IOS Configuration > IOS Template Management**.  
The IOS Template Management window opens.
- Step 2** Select the check box next to the template you want to Edit.
- Step 3** From the toolbar, select **Edit**.  
The IOS Template Configuration page appears.
- Step 4** Optionally, edit the description field.
- Step 5** If this is a custom template, then you can check the *Enable template modification* check box to allow for editing of the template body. See [IOS Template Format, on page 78](#) for details about template syntax. You can undo any unsaved changes you made to the body by clicking **Undo Template Body Changes**.
- Step 6** Select **Save** to save the template when you complete your changes.
- 

## Copy Templates

You can copy templates to create a new template to which you can make modifications. For instance, it is not possible to edit the body of a default template, however, you can copy a default template and then edit the body of the copy.

---

- Step 1** Select **System > IOS Configuration > IOS Template Management**.  
The IOS Template Management window opens.
- Step 2** Select the checkbox next to the template that you want to copy
- Step 3** From the toolbar, select **Copy**.  
The Copy IOS Template screen opens.
- Step 4** Edit the Name and Description for the copy.
- Step 5** Optionally, check the box entitled *Enable template modification* and make changes to the copy. You can also make changes later. See [Edit Templates, on page 81](#).
- Step 6** Select **Save** to create the copy with the changes you made.
- 

## View Template Details

To view the details of a template:

---

**Step 1** Select **System > IOS Configuration > IOS Template Management**.

The IOS Template Management page opens.

**Step 2** Select **Details** in the details column for the template you want to view.

The IOS Template Details page opens.

The name and the template body of the template is displayed. See [IOS Template Format, on page 78](#) for details about template syntax.

---

## IOS Template Deployment

The IOS Template Deployment pages allow you to deploy a gateway configuration template to a gateway. The template provisions the gateway and substitutes any variables in the template with source devices that you choose when you deploy.

From this page you can:

- Preview the body of the template (and validate the template) and deploy to a gateway.
- Check the status of the template deployment.
- Rollback the configuration sent to a gateway to its previous state.

### Preview and Deploy Template

To preview (validate) and deploy a template:

---

**Step 1** Select **System > IOS Configuration > IOS Template Deployment**.

The IOS Template Deployment page opens.

**Step 2** In the **Select Template** panel, select the template that you want to deploy.

**Step 3** In the **Associate Source Device(s)** panel, select the devices to be replaced with device variables in the template.

**Step 4** In the **Associated Gateways** panel, deselect any of the gateways that will not receive the template deployment. By default, all gateways are selected.

**Step 5** Click **Preview and Deploy** to validate and preview the template to the selected gateways with the selected settings.

After clicking **Preview and Deploy**, the script is validated. If there is an error in the script, or there is a variable in the script for which a device is required, but no device was selected from the **Associate Source Device(s)** panel, then errors are listed on the IOS Template Preview Page. Even if you click **Deploy** at this point, the template is not deployed, and the status page shows a failure due to an invalid template.

Once the preview screen appears, you can perform one of three actions:

- If the template is valid or invalid, click **enable template modification** and edit the template on this screen. Click **Verify** to verify your changes as valid, or click **Undo All Changes** to revert the template to the way it was before you began editing.
- If the template is valid, click **Deploy** to deploy the template to the selected gateways,

- If the template is valid, click **Save and Deploy** to save the template and deploy the template to the selected gateways. If this is an existing custom template, then any changes you made are saved to this custom template. If this is a default template, then the template is copied to a new custom template and saved.

---

## Check Deployment Status

To check the status of a template deployment:

---

**Step 1** Select **System > IOS Configuration > IOS Template Deployment**.

The IOS Template Deployment window opens.

**Step 2** From the toolbar, select **Deployment Status**.

The IOS Template Deployment - Deployment Status window opens.

The status page lists information about the attempted deployment. Click on the status message for any deployment for additional details.

---

## Roll Back Deployment



---

**Note** There is only one level of rollback. If you deploy a template (Template A) and then deploy another template (Template B), you can only roll back to Template A.

---

To Rollback a deployment:

---

**Step 1** Select **System > IOS Configuration > IOS Template Deployment**.

The IOS Template Deployment window opens.

**Step 2** From the toolbar, click **Deployment Status**.

The IOS Template Deployment - Deployment Status window opens.

**Step 3** Check the check box next to the deployment you want to rollback and click **Rollback**.

A confirmation dialog opens. Read the warning and click **OK** to continue the rollback.

A status message is displayed stating that the rollback is in progress. You can refresh the status page by clicking **Refresh** to see the status of the rollback.

---

# Cisco VVB Setup

The Operations Console supports the ability to configure Cisco Virtualized Voice Browser using templates. Templates are text files that contain the VVB settings required for deployment. You can deploy the configurations defined in the template to a VVB from the Operations Console.

You can use the included default templates or create custom templates. The templates are text files that can be copied and edited on the Operations Console.

You can use this page to manage VVB templates.

## Add New Template

---

**Step 1** Select **System > VVB Configuration**.

**Step 2** From the toolbar, click **Add New**.

**Step 3** In the **General** tab, enter a unique template name and description.

**Step 4** Select the **ASR Servers** tab and configure server, port.

For configuration details, see [ASR and TTS Servers Setup, on page 84](#).

**Note** All ASR Servers selected must have the same port number to access.

**Step 5** Select the **TTS Servers** tab and configure server, port.

For configuration details, see [ASR and TTS Servers Setup, on page 84](#).

**Note** All TTS Servers selected must have the same port number to access.

**Step 6** Select the **Applications** tab and add new applications.

For configuration details, see [Application Setup, on page 85](#).

**Step 7** Select the **Triggers** tab and associate triggers for newly created applications.

For configuration details, see [Triggers Setup, on page 89](#).

**Step 8** Click **Save** to save the template file to the Operations Console.

---

## ASR and TTS Servers Setup

You can configure ASR and TTS Servers using the following settings.

**Table 25: ASR Servers Tab Configuration Settings**

Field	Description	Default	Range
ASR / TTS Server Selection	<p>Servers configured in Speech Servers page are listed in the Available Servers drop-down menu. Select the server from the drop-down list and click <b>Add</b> to select the server.</p> <p>To add a custom server which is not listed in the Speech Servers, you can type the hostname (FQDN) in the drop-down field and click <b>Add</b> to select the server.</p> <p>Cisco VVB uses the hostname to connect to these servers and VVB should be able to perform a DNS resolution for the hostname.</p>	None	None
Port Number	Provide the port number that is configured for communication.		1 to 65535

## Application Setup

You can configure Applications using these settings.

**Table 26: Application Tab Configuration Settings**

Field	Description	Default	Range	Base Type
Application Name	Provide an application name.	None	None	Alphanumeric .
Application Type	Select the application script type from the drop-down menu.	SelfService	SelfService, Comprehensive, VRUComprehensive, Error, Ringtone	None

Script	Description	Parameters	Default	Base Type
SelfService	The standalone call flow runs this scripting application.	<i>VXML Application Name</i> —Application name that is present on the VXML server. Mandatory field to enter.	None	Alphanumeric
		<i>Port</i> —Port on which the VXML server or load balancer is running.	7000	Numeric
		<i>Primary VXML Server</i> —VXML server or load balancer IP address. Mandatory field.	None	IP Address or Domain Name
		<i>Backup VXML Server</i> —VXML server backup server IP address.	None	IP Address or Domain Name
		<i>Maximum Sessions</i> —Provide number of sessions you like to associate with this application.  <b>Note</b> The number of sessions must be less or equal to the license provided by Cisco VVB.	25	Numeric
		<i>Secured</i> —Select the check box to encrypt the communication between Cisco VVB and VXML server.  <b>Note</b> If you have enabled secure communication, then ensure to:  <ol style="list-style-type: none"> <li>1. Change the port number in the above field to 7443.</li> <li>2. Upload the relevant certificate. To upload certificate, see <i>Upload certificate or certificate trust list</i> topic in <i>Cisco Unified Communications Operating System Administration Guide</i>.</li> <li>3. Restart Tomcat server and Engine from command line.</li> </ol>	None	Boolean

Script	Description	Parameters	Default	Base Type
Comprehensive	The comprehensive call flow runs this scripting application.	<p><i>Sigdigit</i>—Enable this parameter to use Significant Digits feature. Enter the number of digits that are used as sigdigit. When Cisco VVB receives a call, the CVP comprehensive service is configured to strip the digits, so that when the IVR leg of the call is set up, the original label is used on the incoming VoiceXML request.</p>	None	Numeric
		<p><i>Maximum Sessions</i>—Provide number of sessions you like to associate with this application.</p> <p><b>Note</b> The number of sessions must be less or equal to the license provided by Cisco VVB.</p>	25	Numeric
		<p><i>Secured</i>—Select the check box to encrypt the communication between Cisco VVB and VXML server. By default it is disabled.</p> <p><b>Note</b> If you have enabled secure communication, then ensure to:</p> <ol style="list-style-type: none"> <li>1. Upload the relevant certificate. To upload certificate, see <i>Upload certificate or certificate trust list</i> topic in <i>Cisco Unified Communications Operating System Administration Guide</i></li> <li>2. Restart Tomcat server and Engine from command line.</li> </ol> <p>If you are using a coresident VXML and Call Server, use CA-signed certificate.</p>	None	Boolean

Script	Description	Parameters	Default	Base Type
VRUComprehensive	The non-reference VRU call flow and VRU-only call flow runs this scripting application.	<i>PrimaryVXMLServer</i> —VXML server or load balancer IP address.	""	Alphanumeric
		<i>BackupVXMLServer</i> —VXML backup server or load balancer IP address.	""	Alphanumeric
		<i>Port</i> —Port on which VXML server or load balancer is running. <b>Note</b> Ports 7000/7443 must be configured for interworking with CVP Release 11.5 and later. For earlier versions of CVP, configure ports 8000/8443.	"7000"	Numeric
		<i>Secured</i> —Select the check box to encrypt the communication between Cisco VVB and VXML server. <b>Note</b> If you have enabled secure communication, then ensure to: <ol style="list-style-type: none"> <li>1. Change the port number in the above field to 7443.</li> <li>2. Upload the relevant certificate. To upload certificate, see <i>Upload certificate or certificate trust list</i> topic in <i>Cisco Unified Communications Operating System Administration Guide</i>.</li> <li>3. Restart Tomcat server and Engine from command line.</li> </ol>	false	Boolean
		<i>Sigdigit</i> —Enable this parameter to use Significant Digits feature. Enter the number of digits that are used as sigdigit. When Cisco VVB receives a call, the CVP comprehensive service is configured to strip the digits, so that when the IVR leg of the call is set up, the original label is used on the incoming VoiceXML request.	0	Numeric



Script	Description	Parameters	Default	Base Type
Error	This script is used to play error tone.	<p><i>Maximum Sessions</i>—Provide number of sessions you like to associate with this application.</p> <p><b>Note</b> The number of sessions must be less or equal to the license provided by Cisco VVB.</p>	25	Numeric
		<p><i>Custom Error Prompt</i>—Provide the custom error .wav file to play.</p> <p><b>Note</b> Prompt name field is case-sensitive. The prompt file must be uploaded to Cisco VVB. If custom prompts are not uploaded or found, the default prompt is played.</p>	None	Numeric
Ringtone	This script is used to play ringtone.	<p><i>Maximum Sessions</i>—Provide number of sessions you like to associate with this application.</p> <p><b>Note</b> The number of sessions must be less or equal to the license provided by Cisco VVB.</p>	25	Numeric

## Triggers Setup

You can associate trigger with the applications added in Applications tab.

Table 27: Trigger Tab Configuration Settings

Field	Description	Default
Dial Number Pattern	<p>A unique phone number. The value includes numeric characters, preceded or followed by the special character: *</p> <p>Examples of <b>valid</b> Directory Numbers: *12* or 12*23</p> <p>Examples of <b>invalid</b> Directory Numbers: 91X+, 91X?, 91!, 813510[^0-5] because this number contains a character other than numerical and allowed special characters, or 8]90[-, because this number does not conform with the rule that the square bracket ( [ ] ) characters enclose a range of values.</p> <p><b>Note</b> For more information, see <i>Wildcards and Special Characters in Route Patterns and Hunt Pilots</i> section in the <i>Cisco Unified Communications Manager System Guide</i>.</p>	None
Application Name	Select the application from the drop-down menu to associate trigger with the application and click <b>Add</b> .	None

## Delete Template



**Note** You cannot delete default templates. Only custom templates can be deleted.

**Step 1** Select **System > VVB Configuration**.

**Step 2** Select the templates you want to delete.

**Step 3** From the toolbar, select **Delete**.

A confirmation appears. Select **OK** to proceed and delete any custom templates selected.

## Edit Templates

You can edit and change description of any template. You can also edit custom templates within a browser, but you cannot edit the default templates.

**Step 1** Select **System > VVB Configuration**.

- Step 2** Select the check box next to the template you want to edit and click **Edit**.
  - Step 3** For details on other tabs, see [Add New Template, on page 84](#).
  - Step 4** Select **Save** to save the template when you complete your changes.
- 

## Copy Templates

You can copy templates to create a new template to which you can modify. For instance, it is not possible to edit the body of a default template, however, you can copy a default template and then edit the body of the copy.

---

- Step 1** Select **System > VVB Configuration**.
  - Step 2** Select the check box next to the template that you want to copy
  - Step 3** From the toolbar, select **Copy**.  
The Copy VVB Template screen is displayed.
  - Step 4** Edit the Name and Description, and for modifying other settings, see [Add New Template, on page 84](#).
  - Step 5** Select **Save** to create the copy with the changes you made.
- 

## Deploy Template

To preview and deploy a template:

---

- Step 1** Select **System > VVB Configuration**.
- Step 2** From the **List of Template**, select the template that you want to deploy.
- Step 3** Click **Deploy** to deploy the selected template. You can verify the template body of the selected template.
- Step 4** In the **Associated Virtualized Voice Browsers** panel, move VVBs to **Selected** pane to deploy.
- Step 5** Click **Deploy** to deploy the template to the selected Voice Browsers.

If there is an error in the script, or there is a variable in the script for which a device is required, but no device was selected from the **Associate Source Device(s)** panel, then errors are listed on the VVB Template Preview page.

At this point, even if you attempt to deploy the template by clicking the **Deploy** button, the template will not be deployed, and the status page displays “Failure due to an invalid template”.

---

## Check Deployment Status

- Step 1** Select **System > VVB Configuration**.
- Step 2** From the toolbar, select **Deployment Status**.  
The VVB Template Deployment - Deployment Status page is displayed.

The status page lists information about the attempted deployment. Click the status message for more details on deployment status.

## Perform Courtesy Callback

The Courtesy Callback feature is available in Unified CVP. Courtesy Callback reduces the time callers have to wait on hold/in queue. The feature allows the system to offer callers who meet certain criteria, for example, callers with the possibility of being in queue for more than X minutes, the option to be called back by the system when the wait time would be considerably shorter.

If the caller decides to be called back by the system, then they leave their name and phone number. When the system determines that an agent is available (or will be available soon), then a call is placed back to the caller. The caller must answer the call and indicate that they are the caller. The caller is connected to the agent after a short wait.

## Procedure

To configure Courtesy Callback:

**Step 1** Select **System > Courtesy Callback**.

The Courtesy Callback Configuration window opens.

**Step 2** Select the required Unified CVP Reporting Server (if configured) from the drop-down list.

**Note** If you leave the selection blank, no Reporting Server is associated with the Courtesy Callback deployment.

**Step 3** Optionally, enable the check box (default is disabled) next to the label *Enable secure communication with the Courtesy Callback database* to secure the communication between the Unified CVP Call Server and Unified CVP Reporting Server used for Courtesy Callback.

**Step 4** In the **Dialed Number Configuration** section:

The Dialed Number Configuration of Courtesy Callback allows you to restrict the dialed numbers that callers can enter when they are requesting a callback. For example, it can stop a malicious caller from having Courtesy Callback dial 911. The table below lists the configuration options for the **Dialed Number Configuration**:

Field	Description	Default
Allow Unmatched Dialed Numbers	This checkbox controls whether or not dialed numbers that do not exist in the <b>Allowed Dialed Numbers</b> field can be used for a callback.  By default, this is unchecked. If no dialed numbers are present in the <b>Allowed Dialed Numbers</b> list box, then <b>Courtesy Callback does not allow any callbacks</b> .	Unchecked - Callbacks can only be sent to dialed numbers listed in the <b>Allowed Dialed Numbers</b> list.

Field	Description	Default
Allowed Dialed Numbers	<p>The list of allowed dialed numbers to which callbacks can be sent. You can use dialed number patterns; for example, 978&gt; allows callbacks to all phone numbers in the area code 978.</p> <p>To Add/Remove Dialed Numbers:</p> <ul style="list-style-type: none"> <li>• To Add a number to the list of allowed dialed numbers - Enter the dialed number pattern in the <b>Dialed Number (DN):</b> field and click <b>Add</b>.</li> <li>• To remove a number from the list - Highlight the number and click <b>Remove</b>.</li> </ul>	Empty - If <b>Allow Unmatched Dialed Numbers</b> is <i>not</i> checked, and this list remained empty, then no callbacks can be made.
Denied Dialed Numbers	<p>The list of denied dialed numbers to which callbacks are never sent. You can use dialed number patterns; for example, 555&gt; allows callbacks to all phone numbers in the area code 555.</p> <p>To Add/Remove Dialed Numbers:</p> <ul style="list-style-type: none"> <li>• To Add a number to the list of denied dialed numbers - Enter the dialed number pattern in the <b>Dialed Number (DN):</b> field and click <b>Add</b>.</li> <li>• To remove a number from the list - Highlight the number and click <b>Remove</b>.</li> </ul> <p>Denied numbers takes precedence over allowed numbers.</p> <ul style="list-style-type: none"> <li>• Wildcarded DN patterns can contain "." and "X" in any position to match a single wildcard character.</li> <li>• Any of the wildcard characters in the set "&gt;!*T" match multiple characters but can only be used as trailing values because they always match all remaining characters in the string.</li> <li>• The highest precedence of pattern matching is an exact match, followed by the most specific wildcard match.</li> <li>• When the number of characters are matched equally by wildcarded patterns in both the Allowed Dialed Numbers and Denied Dialed Numbers lists, precedence is given to the one in the Denied Dialed Numbers list.</li> </ul>	The Denied Dialed Numbers window is prepopulated if your local language is "en-us"(United States, English). Be sure to add any additional numbers you want to deny.

Field	Description	Default
Maximum Callbacks Per Calling Number	<p>The default value is 0, which is equivalent to an unlimited number of callbacks offered per calling number. The maximum value is 1000.</p> <p>This setting allows you to limit the number of calls, from the same calling number that are eligible to receive a callback. If this field is set to a positive number (X), then the courtesy callback “Validate” element only allows X callbacks per calling number to go through the “preemptive” exit state at any time. If there are already X callbacks offered for a calling number, new calls go through the “none” exit state of the “Validate” element. In addition, if no calling number is available for a call, the call always goes through the “none” exit state of the “Validate” element.</p>	0

**Step 5** Click the **Call Server Deployment** tab to view a list of available call servers and to select a Unified CVP Call Server to associated with Courtesy Callback.

**Step 6** After making the required configuration changes, you have two options to save the configuration:

- Click **Save & Deploy** in the bottom right corner of this page (or the **Save & Deploy** button in the toolbar above) to save the Call Server information and initiate a deployment request to the selected devices.  
See the [View Courtesy Callback Deployment Status](#) section for details on viewing the status information.
- Click **Save** to save the configuration to the Operations Console database

## View Courtesy Callback Deployment Status

You can verify the latest deployment status of the Courtesy Callback configuration using the Unified CVP Operations console. The deployment status is listed for each Unified CVP Call Server.

### Procedure

To view the deployment status of Courtesy Callback configurations:

**Step 1** Select **System > Courtesy Callback**.

The configuration window opens.

**Step 2** From the toolbar, click **Deployment Status**.

The Courtesy Callback Deployment Status window displays the device IP address and current status. Note that you can click **Refresh** to view the latest status.

In the following cases, the Deployment Status displays a warning message:

- If you have only saved the configuration details and have not deployed them.
- If you have edited or deleted an existing configuration and have not deployed the changes.

- If you changed the call server association.
- 

## SIP Error Reason Code Mapping

In a REFER label transfer scenario, a call comes from the network to Cisco Unified Border Element (CUBE). The CUBE receives a REFER from Cisco Unified Customer Voice Portal (CVP) and starts a new INVITE toward refer-to number. If the call fails, CUBE receives a status message with q.850 Reason header which includes ISDN User Part (ISUP) cause codes. CUBE then starts a NOTIFY to Unified CVP with the Session Initiation Protocol(SIP) error string. Unified CVP maps the SIP code to ISUP cause code and sends back to CUBE in a BYE message and in-turn to network. This result is achieved by configuring the SIP reason code to ISUP cause code mapping under SIP Error Reason Code Mapping menu.

## Configure SIP Error Reason Code Mapping

### Before you begin

- Install Call Server 12.0(1).
  - Ensure that the Call server is up and running.
  - Check the **SIP Subsystem** check box to enable this service in the Call Server.
- 

**Step 1** In the Operations console, select **System > SIP Error Reason Code Mapping**.

**Step 2** Enter the value of the error reason code in the **Error Reason Code(SIP)** field.

- Note**
- The value of Error Reason Code (SIP) must be unique and it can be a three-digit positive integer.
  - The SIP Error Reason Code field must not be blank.

**Step 3** Enter the value of ISUP cause code in the **Cause Code (ISUP)** field.

- Note**
- The ISUP cause code value must be two or three digit positive integers.
  - The ISUP cause code field must not be blank.

**Step 4** Perform one of the following options:

- Click **Add** to add the entries to the **Reason to Cause Code Mapping** list.

**Note** A maximum of ten mapping entries are allowed.

- Click **Remove** to remove an entry from the **Reason to Cause Code Mapping** list. Click **OK**.

**Step 5** After changing the Error Reason Code Mapping configurations, you have two options to save the configuration:

- Click **Save** to save the configuration to the Operations Console derby database.
- Click **Save & Deploy** to deploy the configurations to all the Call Servers.

**Step 6** Click **Deployment Status** to view the deployment status.  
The SIP Error Reason Code Mapping - Deployment Status window displays the device IP address and the deployment status.

**Step 7** Click **Refresh** to view the latest status.

**Caution** The Deployment Status page displays a warning message, in the following cases:

- If you have saved the configuration details and have not deployed them.
- If you have edited or deleted an existing configuration detail, and have not deployed the changes.

## View SIP Error Reason Code Mapping Deployment Status

The Operations Console displays the Unified CVP Call Server IP address and the deployment status. If a deployment fails because the Unified CVP Call Server is not accessible (either not deployed or off line) or is not upgraded to the current version, the Operations Console issues a descriptive message.

The **SIP Error Reason Code Mapping Deployment Status** page displays the last recorded deployment status per configured Unified CVP Call Server. You can refresh the page, view online help, or go back to the **SIP Error Reason Code Mapping Configuration** page. You can also sort (in either ascending and descending order) the Deployment Status table contents by the following column fields: **Hostname**, **IP Address**, **Device Type**, **Status**, or **Last Updated**.

Deployment operations can be time-consuming, depending on the number of Unified CVP Call Servers. When either process is running, you can select a status report to view the progress of the last initialized deployment request.



**Note** Deployment operations are mutually exclusive. Only one deployment process can run at any given time. If a process is already running, you cannot start another process. You will receive an error message.

The following information applies to the Status window:

### Procedure

- Unapplied changes (deployment status only) indicate that a Save operation took place since the last deployment operation.
- Only one Unified CVP Call Server can be deployed at any given time. The other call servers are either in queue or in a successful or failed state.

## Procedure

To view the SIP error code mapping deployment status:

- Step 1** From the Operations Console, select **System > SIP Error Reason Code Mapping**.  
The Operations Console displays the **SIP Error Reason Code Mapping Configuration** page.
- Step 2** Click **Deployment Status** at the bottom right corner of the window.



The Operations Console displays the Call Server IP address and the deployment status. If there is a failure, the Operations Console provides a reason for the failure.

---

# Cloud Services

## Proxy Settings

### Prerequisite

- Install CVP 12.0(1).
- Ensure that the VXML servers are up and running.

### Enabling Proxy Settings

---

**Step 1** From the Operations Console, select **System > Cloud Services > Proxy Settings**.

**Step 2** Enter the value of the Context Service Proxy.

- The proxy hostname must be in the format: *hostname:port* or *IP\_address:port*.
- Leave the proxy setting column blank for a deployment that does not require a proxy for access.

**Step 3** After changing the proxy configurations, save it. There are two options to save the configuration:

- Click **Save** to save the configuration to the Operations Console derby database.
- OR-
- Click **Save & Deploy** to save and deploy the configurations to all the VXML servers.

**Step 4** Click **Deployment Status** to view the current deployment status. The **Proxy Settings - Deployment Status** window displays the device IP address and the deployment status.

**Step 5** Click **Refresh** to view the latest status.

**Note** The **Deployment Status** page displays a warning message, in the following cases:

- If you have saved the configuration details and not deployed the changes.
  - If you have edited or deleted an existing configuration and not deployed the changes.
- 

### What to do next

Restart VXML service and Ops Console service.

## View Proxy Settings Deployment Status

The Operations Console displays the Unified CVP VXML Server IP address and the deployment status. If a deployment fails because of any of the following reasons, then a descriptive message is displayed.

- Unified CVP VXML Server is not accessible (either not deployed or offline)
- Unified CVP VXML Server is not upgraded to the current version

The **Proxy Settings Deployment Status** page displays the last recorded deployment status per configured Unified CVP VXML Server. You can refresh the page, view online help, or go back to the Proxy Settings Configuration page. Display of records can be sorted (in either ascending and descending order) by column fields: **Hostname**, **IP Address**, **Device Type**, **Status**, or **Last Updated**.

Deployment operations can be time-consuming, depending on the number of Unified CVP VXML Servers. When a deployment process is running, you can select the status report.



---

**Note** Deployment operations are mutually exclusive. Only one deployment process can run at any given time. If a process is already running, you cannot start another process. You will receive an error message.

---

The following information applies to the Status window:

- Unapplied changes (only deployment status) indicate that a Save operation took place since the last deployment operation.
- Only one Unified CVP VXML server can be deployed at any given time. The other VXML servers are either in queue or in a successful or failed deployment state.

## Context Service Setup

### Context Service

Cisco Context Service is a cloud-based omnichannel solution for Cisco Contact Center Express and Contact Center Enterprise. It enables you to capture your customer's interaction history by providing flexible storage of customer-interaction data across any channel.

Context Service works with Cisco Customer Collaboration products. Context Service also provides an SDK interface for integration with your own applications or third-party applications to capture end-to-end customer-interaction data.

For more information about Context Service and to check service availability, see <https://cisco.com/go/contextservice>.

### Context Service Network Connectivity Requirements

Context Service is a cloud-based service and requires that call center components using Context Service to be able to connect to the public Internet.

Context Service uses port 443 (HTTPS).

The following URLs must be whitelisted in your firewall so that your contact center components can connect to, and receive data from Context Service.

- \*.webex.com
- \*.wbx2.com
- \*.ciscoccservice.com



**Note** Use wildcard URLs in your allowed list because Context Service is accessed through multiple subdomains. Context Service subdomain names can dynamically change.

If you register Context Service by enabling the proxy setting option, configure the browser proxy with the URL specified in the Context Service Management Gadget. Refer to the following links to configure the proxy settings for the related browsers.

Chrome	<a href="https://support.google.com/chrome/answer/96815?hl=en">https://support.google.com/chrome/answer/96815?hl=en</a>
Firefox	<a href="https://support.mozilla.org/en-US/kb/advanced-panel-settings-in-firefox">https://support.mozilla.org/en-US/kb/advanced-panel-settings-in-firefox</a>
Internet Explorer	<a href="https://windows.microsoft.com/en-in/windows/change-internet-explorer-proxy-server-settings#ITC=windows-7">https://windows.microsoft.com/en-in/windows/change-internet-explorer-proxy-server-settings#ITC=windows-7</a>

## Register Unified CVP with Context Service

You can register Unified CVP with Context Service.



**Note** The inactive session timeout for the registration activity is set to 10 minutes. If the browser is inactive for more than 10 minutes, you must sign in again.

### Before you begin

Ensure that your web browser allows pop-ups.

If you are using Microsoft Internet Explorer, add a registry key **TabProcGrowth** with type of value String or DWORD (32-bit) and value set to **0** at:

```
HKEY_CURRENT_USER\Software\Microsoft\Internet Explorer\Main
```

- Step 1** From the Operations Console, select **System > Cloud Services > Context Service**.
- Step 2** Click **Save**.
- Step 3** Click **Register**.  
The Sign In Cisco WebEx page is displayed in a new browser tab or a new window based on your local browser settings.
- Step 4** Enter your registered email address and click **Next**.
- Step 5** Enter the Context Service username and password, and click **Sign In**.  
The **Cloud Services** page is displayed.
- Step 6** Click **Confirm**.

The **Context Service Management** page is displayed. If the registration is successful, the connection data is deployed on all running VXML servers in the pool.

- Note**
- If you add a VXML Server after registration, the connection data is automatically available on the VXML Server after you save and deploy the server settings. For more information about adding a VXML Server, see [Add Unified CVP VXML Server](#).
  - The status of the deployment can be checked by clicking **Deployment status** button.
  - Context Service is not supported in a VXML Server that is deployed in a standalone mode.
  - The connection data expires after a predefined period. The Operations Console automatically generates a new connection data and deploys the connection data on all the VXML Servers in the pool.

If the registration is unsuccessful retry the registration process.

**Step 7** Restart VXML service and Ops Console service.

---

### Related Topics

- [Configure Context Service Connection Data in Call Studio](#), on page 100
- [Deregister Context Service from Context Service](#), on page 101

## Configure Context Service Connection Data in Call Studio

You can configure Context Service connection data property to debug applications that interact with Context Service.

To debug a solution that uses Context Service, Call Studio requires your Context Service credentials and connection details.

### Before you begin

Register Unified CVP with Context Service by using the Operations Console.

---

**Step 1** From the Operations Console, select **System > Cloud Services > Context Service**.

**Step 2** Click **Connection Data**.

The system displays the credential information in the Connection Data area below the **Connection Data** button. The connection data is selected by default.

**Note** Carefully store the connection data. This data is the key to open your organization's data in the cloud.

**Step 3** Copy the credentials onto the clipboard.

**Step 4** Click **OK**.

**Step 5** Launch Cisco Unified Call Studio.

**Step 6** Choose **Window > Preferences**.

**Step 7** On the **Preferences** window, choose **Call Studio > Debug Preferences**.

**Step 8** In the Context Service area, paste the connection data from the clipboard into the **Connection Data** field.

**Step 9** Click **OK**.

**Step 10** Restart VXML service and Ops Console service.

---

## Deregister Context Service from Context Service

---

**Step 1** From the Operations Console, select **System > Cloud Services > Context Service**.

**Step 2** Click **Deregister**.

The Sign In Cisco WebEx page is displayed in a new browser tab or a new window based on your local browser settings.

**Step 3** Enter your registered email address and click **Next**.

**Step 4** Enter the Context Service username and password, and click **Sign In**.

The **Enable Collaboration Cloud Extensions** page opens.

**Step 5** Click **Confirm**.

If deregistration is successful, the credential information is automatically removed from the running VXML Servers in the pool. If deregistration is unsuccessful, retry the deregistration process.

**Step 6** Restart all the running VXML Servers in the pool.

---

## Context Service Connection Timeouts and Retries

The Context Service client provides two connection properties that significantly affect the user experience for your customers and agents.

- **TIMEOUT** defines how long the client waits for a response from Context Service. Defaults to 1200 ms.
- **RETRIES** defines how many times the client retries the request when a timeout is reached. Set values based on factors specific to your deployment; the location relative to your Context Service instance, Internet latency, and quality metrics for your organization. Defaults to 1.

Ideally, you set `REQUEST_TIMEOUT` to a value that is long enough that the client does not frequently hit this limit before receiving a reply from Context Service, but not so long that callers hear long periods of silence from the IVR. Context Service is a cloud service that runs over the Internet, and the latency of the Internet can be highly variable. However, latency generally has a floor value based on your physical proximity to the data center on which your Context Service instance is hosted. You can roughly determine your floor value by pinging your Context Service instance at the times you experience the lowest call volume. Your `REQUEST_TIMEOUT` must never be lower than this floor value. Setting `REQUEST_TIMEOUT` lower than this value typically triggers timeouts and initiates a retry.

The `RETRIES` property is used to retry the request after a timeout is reached. For instance, if you set `RETRIES` to 1, then when a timeout is reached the request is resent and the timeout timer restarts. If Context Service does not respond on that first retry, then the request fails. If there is an issue with your connection, then you are potentially doubling the wait defined in `REQUEST_TIMEOUT` when `RETRIES` is set to 1. The effect increases as you increase `RETRIES`. The default `REQUEST_TIMEOUT` is 1200 ms (1.2 seconds) and the default `RETRIES` is set to 1. This combination results in a 2.4 second wait ( $\text{wait time} = \text{REQUEST\_TIMEOUT} + \text{RETRIES} * \text{REQUEST\_TIMEOUT}$ ). In a worst-case scenario, wait time can be significant if there are network issues between your client and Context Service and your timeouts or retries are set too high. The `RETRIES` property is intended to be used to handle network hiccups that infrequently occur. The default setting of 1 assumes that your `REQUEST_TIMEOUT` is sufficiently high enough that the request is normally serviced on the first request. If the first 1.2 seconds is not enough, then the request is retried once and another 1.2 seconds allotted to wait for a response.

Retries are not attempted for "create" or "update" operations. If these operations fail due to a timeout, then your app or script could potentially request the "create" or "update" operation again, return a failure, or perform some other operation.

In general, typical requests within the same geographical area take from 100ms to 300ms; however, your network environment, switching latency, and location in relation to Context Service instance can increase the response time from Context Service.

Your service quality target ultimately defines how high `REQUEST_TIMEOUT` is set above the floor latency value. Setting the value too high results in extended waits for the caller or agent when Internet latency is high. Setting the value too low initiates retry requests that increase the wait in an attempt that can ultimately fail during times of high latency.

You can improve the customer experience of waiting while the client is accessing Context Service by notifying the customer that you are looking up information. For example, you can play prompts such as "Wait a moment while I access your account details". If a timeout occurs and a retry is attempted you can play a prompt, such as "I'm still accessing your account details." You could also opt to play MoH during the wait times to prevent silence on the line.

Inevitably connections to Context Service can fail, possibly due to high Internet latency or connections issues to the Internet itself. In those cases, your IVR scripting must account for a failed connection attempt to the Context Service. Your scripts must be able to route to an agent (or continue with self-service) without the benefit of Context Service data.

## Editing the `vxml.properties` File

You can change the default value of `VXML.ContextService.requestTimeout` and `VXML.ContextService.maxRetries` connection properties in the `vxml.properties` file.

- 
- Step 1** Browse to the `vxml.properties` file available in the following locations:
- If you are using comprehensive call flow:  
C:\Cisco\CVP\conf
  - If you are using Call Studio debugger:  
C:\Cisco\CallStudio\eclipse\plugins\com.audiumcorp.studio.debug.runtime\AUDIUM\_HOME\conf
- Step 2** Open the `vxml.properties` file by using any plain-text editor.
- Step 3** Change the value of `VXML.ContextService.requestTimeout` and `VXML.ContextService.maxRetries` connection properties.
- Step 4** Save the `vxml.properties` file.
- Step 5** Restart the VXML Server.
-