



Post Deployment Operations

- Deactivating the USP Deployment, on page 1
- Terminating the AutoDeploy VM, on page 2
- Terminating the AutoIT VM, on page 2
- Deploy and Undeploy the Card with the NCS CLI, on page 3
- Monitoring and Troubleshooting the Deployment, on page 4
- Monitoring AutoDeploy Operations, on page 32
- Monitoring AutoIT Operations, on page 36
- Monitoring AutoVNF Operations, on page 41
- Monitoring VNFM Operations, on page 58
- Monitoring VNF Operations, on page 61
- Monitoring and Recovering AutoVNF Through AutoIT, on page 64
- Monitoring and Recovering VNFC Through AutoVNF, on page 66
- Troubleshooting Deactivation Process and Issues, on page 68
- Troubleshooting UEM Issues, on page 72

Deactivating the USP Deployment



Caution

It is recommended that you perform the checks identified in [Pre-Deactivation/Post-Activation Health Check Summary, on page 4](#) before performing any deactivations. It is also recommended that you back up relevant data before proceeding. Refer to [Backing Up Deployment Information](#) for more information.

Execute the following command to deactivate the entire USP deployment:

```
deactivate nsd <nsd_name>
```

The output of this command is a transaction-id which can be used to monitor the deactivation progress using the following command

```
show log <transaction_id> | display xml
```

Example output for a successful USP deactivation:

Terminating the AutoDeploy VM

Terminating the AutoDeploy VM leverages the same *boot_uas.py* script used to instantiate the AutoDeploy VM.


Important

- Ensure that no changes have been made to this file since it was used to deploy AutoDeploy.
- Be sure to take a backup of the VM content if you are terminating the VM in order to upgrade with a new ISO.
- If AutoDeploy was deployed with HA support, this process terminates both VMs.

To terminate the AutoDeploy VM:

1. Log on to the Ultra M Manager Node.
2. Terminate the AutoDeploy VM.

```
./boot_uas.py --kvm --autodeploy --ha --delete-uas
```

Example command output:

```
2018-01-24 16:30:23,821 - Removing old deployment 'AutoDeploy_instance_0', if it exists
2018-01-24 16:30:24,176 - Removing old deployment 'AutoDeploy_instance_1', if it exists
```

3. View the status.

```
show uas
```

Example command output:

| Id | Name | State |
|----|------|-------|
| | | |

Terminating the AutoIT VM

Terminating the AutoIT VM leverages the same *boot_uas.py* script used to instantiate the AutoIT-VNF VM.


Important

- Ensure that no changes have been made to this file since it was used to deploy AutoIT.
- Be sure to take a backup of the VM content if you are terminating the VM in order to upgrade with a new ISO.
- If AutoIT was deployed with HA support, this process terminates both VMs.

To terminate the AutoIT VM:

1. Log on to the Ultra M Manager Node.
2. Terminate the AutoIT VM.

```
./boot_uas.py --kvm --autoit --ha --delete-uas
```

Example command output:

```
2018-01-24 16:25:23,734 - Removing old deployment 'AutoIT_instance_0', if it exists
2018-01-24 16:25:24,056 - Removing old deployment 'AutoIT_instance_1', if it exists
```

3. View the status.

```
show uas
```

Example command output:

| Id | Name | State |
|----|------|-------|
|----|------|-------|

Deploy and Undeploy the Card with the NCS CLI

To undeploy and redeploy the card (service or session function) using the NCS CLI:

1. Log on to the master UEM VM.
2. Access the NCS CLI.

```
sudo -i
```

```
ncs_cli -u admin -C
```

3. Undeploy or suspend the card.

```
suspend-vnfci vnfid <name> vdu <VDU> vnfci <VNFCI Instance>
```

For example:

```
suspend-vnfci vnfid abc vdu sf vnfci sf1 success true
```

4. Verify the operational status of VNF, card, VDUs. Suspending card removes the card, e.g. from CF.

```
show vnf-state
```

```
vnf-state running
```

```
vnf-state running
```

```
show card table
```

| Slot | Card Type | Oper State | SPOF | Attach |
|--------|--------------------------------------|------------|------|--------|
| 1: CFC | Control Function Virtual Card | Active | No | |
| 2: CFC | Control Function Virtual Card | Standby | - | |
| 4: FC | 1-Port Service Function Virtual Card | Standby | - | |

```
show vdus
```

| ID | CARD | TYPE | ID | NAME | DEVICE | MEMORY | CONSTITUENT | IS | INFRA | INITIALIZED | VIM |
|----|------------------|------|-----------|-----------|--------|--------|-------------|------|-------|-------------|-----|
| | | | | | CPU | UTILS | ELEMENT | | | | |
| | | | | | UTILS | BYTES | USAGE | | | | |
| cf | control-function | cf1 | scm-cf-nc | scm-cf-nc | ugp | | | true | true | | |

Monitoring and Troubleshooting the Deployment

```

76e2f28a-4427-4b1d-9c44-72ff51e0d124 - - - true true
          cf2 scm-cf-nc scm-cf-nc ugp      true true
b1155c6e-26f1-44c1-8832-0e9a02f7acd3 - - - true false
sf session-function sf1 - - ugp      true false
7822cea9-1707-4790-abb3-33bb4d26b567 - - - true false
          sf2 - - ugp      true false
7fd8f37f-59cf-4c9a-811f-faa0abd30b58 - - - -

```

UEM changes the status of suspended card to *undeployed*. For example, UEM Zookeeper:

```

[zk: localhost:2181(CONNECTED) 0] get /config/vnf
{"state":"run","name":"abcabc-autovnf-vpc-abcabc"}

[zk: localhost:2181(CONNECTED) 1] get /config/vnfd
{"name":"abcabc-autovnf-vpc-abcabc","version":"6.0","deployment-flavor-id":["generic"], "anti-affinity-cards":["control-function","session-function"],"card-type-to-vdu":{"control-function":["cf"],"session-function":["sf"]}}
```

```

[zk: localhost:2181(CONNECTED) 2] get /config/vdus/sf/sf1
{"cpts": [{"vnfc": "sf-vnfc-ugp", "cpid": null, "vl": null}], "affinity": null, "initvars": [{"dest_path": "staros_paran.cfg", "path_vars": [{"name": "CARD_TYPE_NUM", "val": "0x42020100"}, {"name": "SLOT_CARD_NUMBER", "val": "3"}, {"name": "VNFM_PROXY_ADDRS", "val": "101.101.14.9,101.101.14.16,101.101.14.13"}]}, {"operation": "create", "cpid": "ugp", "vnfc_id": "sf1", "context-vars": null, "nat_pool": null, "vim_id": "abcabc-autovnf-vpc-abcabc-sf-1", "volume": null}}
```

```

[zk: localhost:2181(CONNECTED) 3] get /oper/vdus/sf/sf1
{"id": "sf1", "state": "undeployed", "vnfcId": "sf-vnfc-ugp", "uuid": "sf1", "host": "tblano-osd-compute-2.localdomain", "vimId": "7822cea9-1707-4790-abb3-33bb4d26b567", "cpts": [{"cpid": "eth0", "state": "undeployed", "subnet": "94c4ea79-e81-4a7d-b726-4f780a05436f", "netmask": "255.255.255.0", "dhcp": true, "vl": "vl-di-internall", "vnfc": "sf-vnfc-ugp", "port_id": "0x5dd23-5c43-463b-a14-f1f0b94f90dc", "ip_address": "192.168.1.124", "mac_address": "fa:16:3e:b6:26:da", "network": "55d41c29-f8ed-4006-b29c-5ad3bf73bf42"}, {"cpid": "eth1", "state": "undeployed", "nicid": 1, "subnet": "472e0423-a908-4eb6-9782-a741afe5b93a", "netmask": "255.255.255.0", "dhcp": true, "vl": "vl-autoit-abcabc_orch", "vnfc": "sf-vnfc-ugp", "port_id": "0x5dd23-5c43-463b-a14-f1f0b94f90dc", "ip_address": "192.168.1.125", "mac_address": "fa:16:3e:b6:26:da", "network": "55d41c29-f8ed-4006-b29c-5ad3bf73bf42"}]}
```

```

[zk: localhost:2181(CONNECTED) 4] get /oper/vnf
{"state": "running", "name": "abcabc-autovnf-vpc-abcabc"}
```

```

[zk: localhost:2181(CONNECTED) 5] get /oper/vdrs/sf1

```

- Redeploy or resume the card by executing the following command:

```
resume-vnfc vnfid <name> vdu <VDU> vnfc <VNFC Instance>
```

Monitoring and Troubleshooting the Deployment

Pre-Deactivation/Post-Activation Health Check Summary

Table 1: Pre-deactivation/Post-activation Health Checks, on page 4 contains a summary of items to check/verify before performing a deactivation and/or after an activation.

Table 1: Pre-deactivation/Post-activation Health Checks

| Item to Check | Notes |
|-----------------------------------|--------------------------------|
| Checking OSP-D Server Health | Perform all identified checks. |
| Checking Controller Server Health | Perform all identified checks. |

| Item to Check | Notes |
|--|--|
| Checking OSD Compute Server Health | Perform all identified checks. |
| Viewing AutoVNF Operational Data | In particular, check the outputs of the following commands: <ul style="list-style-type: none"> • show uas • In releases prior to 6.0: show autovnf-oper:vip-port In 6.0 and later releases: show vnfr • In releases prior to 6.0: show autovnf-oper:vnf-em In 6.0 and later releases: show vnfr • In releases prior to 6.0: show autovnf-oper:vnfm In 6.0 and later releases: show vnfr |
| Viewing ESC Status | Perform all identified checks. |
| Viewing ESC Health | Perform all identified checks. |
| Viewing UEM Service Status | Perform all identified checks. |
| Viewing VNF Information through the Control Function | Perform all identified checks. |

Checking OSP-D Server Health

Viewing Stack Status

Log on to the server on which OSP-D is running to view the stack status by executing the following command:

openstack stack list

Example output:

| ID | Updated Time | Stack Name | Stack Status | Creation Time |
|--------------------------------------|--------------|------------|-----------------|----------------------|
| db229d67-212d-4086-a266-e635b2902708 | None | tb3-ultram | CREATE_COMPLETE | 2017-06-20T02:31:31Z |



Note

Prior to an update, the stack status may be “CREATE_COMPLETE” at the beginning of the update procedure. The stack status should read “UPDATE_COMPLETE” and list and update time at the successful completion of the update procedure.

Viewing the Bare Metal Node List

Log on to the server on which OSP-D is running to view the node list by executing the following command:

Viewing the OpenStack Server List

openstack baremetal node list

Example command output:

| UUID | State | Provisioning State | Maintenance | Name | Instance UUID | Power |
|--------------------------------------|----------|--------------------|-------------|------|--------------------------------------|-------|
| 6725bb18-2895-4a8a-86ad-96b00cc9df4d | power on | active | False | | bc903f51-8483-4522-bcd7-ac396ac626b1 | power |
| f1aa6356-40a0-41de-be1b-fa6033c9affb | power on | active | False | | 05fbfb44-ccd9-475d-b263-58b2deaf8554 | power |
| f02357a3-6f9b-46ae-b31f-1a21f6d33543 | power on | active | False | | dd0596b1-bd35-451a-85bc-c635e7fa6d14 | power |
| ca1153d6-ffaf-481a-ac9b-bc2afc450152 | power on | active | False | | 96d2725c-9c70-4a66-9d3c-4a0356faf1c0 | power |
| 8f338102-c114-4a7a-94f0-9ela54494519 | power on | active | False | | 85a9a708-5eae-4ea2-8b29-dc2acd6e515d | power |
| 5d3d3525-2528-4801-b885-6c4b340393a6 | power on | active | False | | 315c7aea-acef-4341-aa9e-bcd594cae592 | power |
| ac21208b-36fd-4404-8e68-53a90df3a29f | power on | active | False | | 9f0b2ff3-5234-42e9-81dd-c0ef5e454137 | power |
| a6d92bfc-0136-4c22-9988-0108df775a03 | power on | active | False | | 2a3e2086-3516-40ac-a584-3714e91858f5 | power |
| 5f0593b7-31de-4291-b43f-a549699cd470 | power on | active | False | | f4cc50d4-441e-4728-9984-53df29f0b7f7 | power |
| 99225e1b-085e-4ef7-8173-4687900b741a | power on | active | False | | 200a918e-abb3-4539-a1c4-7e30f2d8ebc2 | power |
| c6ec143b-a522-4d69-ab31-5b4934ad3c42 | power on | active | False | | 7c675ed5-17d9-47ad-a2ef-592353e27713 | power |
| e1026c43-f2a3-44ad-a385-4d4462552977 | power on | active | False | | 45b45041-656f-4ee1-8be2-976c71a35b1f | power |
| 122188ea-09ae-486c-b225-17cf0defe025 | power on | active | False | | bd38818e-36ca-4fd9-a65f-c4b0e5b34977 | power |
| f6ecf896-6e5e-4735-8727-942478dee58a | power on | active | False | | 82a79351-5520-4e89-ae19-48c7b6f6b39f | power |
| e6db159e-008e-4186-8967-92a9faeee368 | power on | active | False | | 986affe6-23ba-48ba-ae4e-0d2226aabf55 | power |
| 44f3a434-eaf8-4b1a-97e5-6340d277fa4e | power on | active | False | | 1f385454-3ddb-40bd-bc6e-a55ad69fff47 | power |
| 7ab70571-64ea-439b-a0f4-34147d01dfbf | power on | active | False | | 6f9f76ac-3cf7-4002-94ba-39bc6f0b4c40 | power |
| 6d478a22-874c-4611-834d-21f4809f90ce | power on | active | False | | 8e37407f-c784-4f5f-942f-2e2c36aa3fa4 | power |
| 0a57a5ad-d160-477e-807f-11997307bc9c | power on | active | False | | 25b53356-9f02-4810-b722-efb6fd887879 | power |
| 6fff3d83-ed37-4934-89e0-d632aeb37b15 | power on | active | False | | 0ea048c0-6f4b-460d-99b2-796dd694c226 | power |
| 5496919c-c269-4860-b49a-e0d103a6a460 | power on | active | False | | 6a8e05aa-26fe-43bb-b464-ede86b9f4639 | power |
| 513b936d-1c52-4b0a-9ac4-4101fe812f07 | power on | active | False | | b92c5720-7db9-417b-b3d5-023046788c8e | power |

Viewing the OpenStack Server List

Log on to the server on which OSP-D is running to ensure that stack components and verify they are active and running the same image by executing the following command:

openstack server list

Example command output:

| ID | Name | Status | Networks |
|--|--------|--------|----------|
| Image Name | | | |
| 9f0b2ff3-5234-42e9-81dd-c0ef5e454137 tb3-ultram-compute-3 | ACTIVE | | |
| ctlplane=192.200.0.133 overcloud-full_20170620T011048 | | | |
| 25b53356-9f02-4810-b722-efb6fd887879 tb3-ultram-compute-15 | ACTIVE | | |
| ctlplane=192.200.0.131 overcloud-full_20170620T011048 | | | |
| 986affe6-23ba-48ba-ae4e-0d2226aabf55 tb3-ultram-compute-11 | ACTIVE | | |
| ctlplane=192.200.0.128 overcloud-full_20170620T011048 | | | |
| 45b45041-656f-4ee1-8be2-976c71a35b1f tb3-ultram-compute-8 | ACTIVE | | |
| ctlplane=192.200.0.130 overcloud-full_20170620T011048 | | | |
| bd38818e-36ca-4fd9-a65f-c4b0e5b34977 tb3-ultram-compute-9 | ACTIVE | | |
| ctlplane=192.200.0.127 overcloud-full_20170620T011048 | | | |
| 82a79351-5520-4e89-ae19-48c7b6f6b39f tb3-ultram-compute-10 | ACTIVE | | |
| ctlplane=192.200.0.126 overcloud-full_20170620T011048 | | | |
| 1f385454-3ddb-40bd-bc6e-a55ad69fff47 tb3-ultram-compute-12 | ACTIVE | | |
| ctlplane=192.200.0.118 overcloud-full_20170620T011048 | | | |
| 8e37407f-c784-4f5f-942f-2e2c36aa3fa4 tb3-ultram-compute-14 | ACTIVE | | |
| ctlplane=192.200.0.117 overcloud-full_20170620T011048 | | | |
| 315c7aea-acef-4341-aa9e-bcd594cae592 tb3-ultram-compute-2 | ACTIVE | | |
| ctlplane=192.200.0.114 overcloud-full_20170620T011048 | | | |
| 2a3e2086-3516-40ac-a584-3714e91858f5 tb3-ultram-compute-4 | ACTIVE | | |
| ctlplane=192.200.0.120 overcloud-full_20170620T011048 | | | |
| b92c5720-7db9-417b-b3d5-023046788c8e tb3-ultram-osd-compute-2 | ACTIVE | | |
| ctlplane=192.200.0.110 overcloud-full_20170620T011048 | | | |
| 7c675ed5-17d9-47ad-a2ef-592353e27713 tb3-ultram-compute-7 | ACTIVE | | |
| ctlplane=192.200.0.111 overcloud-full_20170620T011048 | | | |
| 0ea048c0-6f4b-460d-99b2-796dd694c226 tb3-ultram-osd-compute-0 | ACTIVE | | |
| ctlplane=192.200.0.112 overcloud-full_20170620T011048 | | | |
| f4cc50d4-441e-4728-9984-53df29f0b7f7 tb3-ultram-compute-5 | ACTIVE | | |
| ctlplane=192.200.0.108 overcloud-full_20170620T011048 | | | |
| dd0596b1-bd35-451a-85bc-c635e7fa6d14 tb3-ultram-controller-2 | ACTIVE | | |
| ctlplane=192.200.0.115 overcloud-full_20170620T011048 | | | |
| 85a9a708-5eae-4ea2-8b29-dc2acd6e515d tb3-ultram-compute-1 | ACTIVE | | |
| ctlplane=192.200.0.102 overcloud-full_20170620T011048 | | | |
| bc903f51-8483-4522-bcd7-ac396ac626b1 tb3-ultram-controller-0 | ACTIVE | | |
| ctlplane=192.200.0.105 overcloud-full_20170620T011048 | | | |
| 6a8e05aa-26fe-43bb-b464-edeb86b9f4639 tb3-ultram-osd-compute-1 | ACTIVE | | |
| ctlplane=192.200.0.106 overcloud-full_20170620T011048 | | | |
| 200a918e-abbd3-4539-a1c4-7e30f2d8ebc2 tb3-ultram-compute-6 | ACTIVE | | |
| ctlplane=192.200.0.109 overcloud-full_20170620T011048 | | | |
| 05fbfb44-cccd9-475d-b263-58b2deaf8554 tb3-ultram-controller-1 | ACTIVE | | |
| ctlplane=192.200.0.113 overcloud-full_20170620T011048 | | | |
| 96d2725c-9c70-4a66-9d3c-4a0356faf1c0 tb3-ultram-compute-0 | ACTIVE | | |
| ctlplane=192.200.0.107 overcloud-full_20170620T011048 | | | |
| 6f9f76ac-3cf7-4002-94ba-39bc6f0b4c40 tb3-ultram-compute-13 | ACTIVE | | |
| ctlplane=192.200.0.103 overcloud-full_20170620T011048 | | | |

Viewing the OpenStack Stack Resource List

Log on to the server on which OSP-D is running to view the stack resources and their status by executing the following command:

```
openstack stack resource list name
```

Example command output:

| resource_name | physical_resource_id | | |
|---------------|----------------------|--------------|--|
| resource_type | resource_status | updated_time | |
| | | | |

Verifying Node Reachability

```

| UpdateWorkflow
OS::TripleO::Tasks::UpdateWorkflow
| CephStorageHostsDeployment
OS::Heat::StructuredDeployments
| OsdComputeAllNodesDeployment
OS::Heat::StructuredDeployments
| BlockStorageHostsDeployment
OS::Heat::StructuredDeployments
| CephStorage
OS::Heat::ResourceGroup
| AllNodesDeploySteps
OS::TripleO::PostDeploySteps
| CephStorageAllNodesDeployment
OS::Heat::StructuredDeployments
| 94270702-cd8b-4441-a09e-5c9da0c2d02b |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| 196dbba7-5d66-4a9c-9308-f47ff4ddbe2d |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| 6a5775c0-03d8-453f-92d8-be6ea5aed853 |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| 97b2f70a-c295-4437-9222-8248ec30badf |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| 1bc20bb0-516a-4eb5-85e2-be9d30e2f6e8 |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| da9ead69-b83e-4cc9-86e8-8d823c02843b |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |
| e5ee9df8-fae1-4641-9cfb-038c8f4eca85 |
| CREATE_COMPLETE | 2017-06-27T22:04:00Z |

```

Verifying Node Reachability

Log on to the server on which OSP-D is running to ensure the node reachability and availability by executing the following command:

```
for i in $(nova list| grep ACTIVE| awk '{print $12}' | sed 's\ctlplane=\\\g'
) ; do ssh heat-admin@$i uptime ; done
```

This command establishes an SSH session with each node and report the system uptime. Investigate any node that does not reply or has an unexpected uptime.

Example command output:

```

14:47:10 up 18:15, 0 users, load average: 0.01, 0.02, 0.05
14:47:11 up 18:14, 0 users, load average: 9.50, 9.15, 12.32
14:47:11 up 18:14, 0 users, load average: 9.41, 9.09, 12.26
14:47:11 up 18:14, 0 users, load average: 10.41, 10.28, 10.49
14:47:12 up 18:15, 0 users, load average: 0.00, 0.02, 0.05
14:47:12 up 18:14, 0 users, load average: 0.18, 0.06, 0.06
14:47:12 up 18:15, 0 users, load average: 0.00, 0.03, 0.05
14:47:12 up 18:15, 0 users, load average: 0.00, 0.01, 0.05
14:47:13 up 18:14, 0 users, load average: 0.02, 0.02, 0.05
14:47:13 up 18:14, 0 users, load average: 8.23, 8.66, 12.29
14:47:13 up 18:14, 0 users, load average: 8.76, 8.87, 12.14
14:47:14 up 18:15, 0 users, load average: 0.01, 0.04, 0.05
14:47:14 up 18:15, 0 users, load average: 9.30, 9.08, 10.12
14:47:14 up 18:15, 0 users, load average: 0.01, 0.06, 0.05
14:47:14 up 18:14, 0 users, load average: 8.31, 8.61, 11.96
14:47:15 up 18:14, 0 users, load average: 17.08, 12.09, 11.06
14:47:15 up 17:09, 0 users, load average: 1.64, 1.33, 1.10
14:47:15 up 17:04, 0 users, load average: 1.02, 0.77, 0.79
14:47:16 up 16:58, 0 users, load average: 0.55, 0.63, 0.72
14:47:16 up 23:46, 0 users, load average: 2.68, 3.46, 3.89
14:47:16 up 1 day, 5 min, 0 users, load average: 4.10, 4.27, 4.44
14:47:17 up 23:53, 0 users, load average: 1.90, 2.32, 2.24

```

Verify NTP is running

To verify the operational status of NTP server:

1. Log on to the server on which OSP-D is running to ensure that NTP is running on all nodes in the cluster by executing the following command:

```
for i in $(nova list| grep ACTIVE| awk '{print $12}' | sed
's\ctlplane=\\\g' ) ; do ssh heat-admin@$i systemctl status ntpd |grep
Active; done
```

This command establishes an SSH session with each node and lists the ntpd status.

Example command output:

```
Active: active (running) since Tue 2017-07-11 20:32:25 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:28 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:50 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:28 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:14 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:30 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:22 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:16 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:35 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:31 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:30 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:25 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:19 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:14 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:41 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 20:32:30 UTC; 18h ago
Active: active (running) since Tue 2017-07-11 21:37:32 UTC; 17h ago
Active: active (running) since Tue 2017-07-11 21:43:16 UTC; 17h ago
Active: active (running) since Tue 2017-07-11 21:48:57 UTC; 17h ago
Active: active (running) since Tue 2017-07-11 15:01:30 UTC; 23h ago
Active: active (running) since Tue 2017-07-11 14:42:10 UTC; 24h ago
Active: active (running) since Tue 2017-07-11 14:54:06 UTC; 23h ago
```

2. Verify that all the Overcloud nodes are synced to NTP server.

```
for i in $(nova list | grep -i overc- | awk '{print $12}' | sed
's/ctlplane==//g') ; do (ssh -o StrictHostKeyChecking=no heat-admin@$i
sudo ntpstat | grep NTP) ; done

[stack@j19bxr-ospd ~]$ for i in $(nova list | grep -i overc- | awk '{print $12}' | sed
's/ctlplane==//g') ; do (ssh -o StrictHostKeyChecking=no heat-admin@$i sudo ntpstat |
grep NTP) ; done
synchronised to NTP server (10.84.96.130) at stratum 3
```

3. Check the NTP status on the server on which OSP-D is running by executing the following command:

```
systemctl status ntpd |grep Active
```

Checking OSP-D Server Health

Investigate any node that is not actively running NTP.

Checking OSP-D Server Health**Verifying VM and Other Service Status and Quotas**

Log on to the server on which OSP-D is running to verify that Overcloud VMs are active and running by executing the following commands:

```
cd /home/stack
source ~/<stack_name>rc-core
nova list
```



Note Overcloud VM status can also be checked through the Horizon GUI.

Example command output:

| ID | Status | Task State | Power State | Networks |
|--------------------------------------|--------|------------|-------------|--|
| 407891a2-85bb-4b84-a023-bca4ff304fc5 | ACTIVE | - | Running | mgmt=172.16.181.21, 10.84.123.13 |
| bb4c06c5-b328-47bd-ac57-a72a9b4bb496 | ACTIVE | - | Running | mgmt=172.16.181.19, 10.84.123.12 |
| fc0e47d3-e59e-41a3-9d8d-99371de1c4c5 | ACTIVE | - | Running | tb3-bxb-autovnf1-uas-0 tb3-bxb-autovnf1-uas-orchestration=172.17.180.10; tb3-bxb-autovnf1-uas-management=172.17.181.8 |
| 8056eff1-913e-479a-ac44-22eba42ceee1 | ACTIVE | - | Running | tb3-bxb-autovnf1-uas-1 tb3-bxb-autovnf1-uas-orchestration=172.17.180.6; tb3-bxb-autovnf1-uas-management=172.17.181.12 |
| 4e9fab14-dad0-4789-bc52-1fac3e40b7cc | ACTIVE | - | Running | tb3-bxb-autovnf1-uas-2 tb3-bxb-autovnf1-uas-orchestration=172.17.180.13; tb3-bxb-autovnf1-uas-management=172.17.181.3 |
| 1a4e65e3-9f9d-429f-a604-6dfb45ef2a45 | ACTIVE | - | Running | tb3-bxb-vnfm1-ESC-0 tb3-bxb-autovnf1-uas-orchestration=172.17.180.3; tb3-bxb-autovnf1-uas-management=172.17.181.4 |
| 7f4ec2dc-e8a8-4f6c-bfce-8f29735e9fca | ACTIVE | - | Running | tb3-bxb-vnfm1-ESC-1 tb3-bxb-autovnf1-uas-orchestration=172.17.180.14; tb3-bxb-autovnf1-uas-management=172.17.181.5 |

```

| 1c9fc0bd-dc16-426f-b387-c2b75b3a1c16 |
tb3-bxb-vnfm1-em_tb3-bx_0_190729a1-c703-4e15-b0b3-795e2e876f55 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.4;
tb3-bxb-autovnf1-uas-management=172.17.181.9

|
| 9a407a06-929a-49ce-8bae-4df35b5f8b40 |
tb3-bxb-vnfm1-em_tb3-bx_0_92c5224b-1f1f-4f3f-8ac8-137be69ce473 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.5;
tb3-bxb-autovnf1-uas-management=172.17.181.10

|
| e4528022-6e7b-43f9-94f6-a6ab6289478d |
tb3-bxb-vnfm1-em_tb3-bx_0_d9f7ecb2-a7dc-439b-b492-5ce0402264ea | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.2;
tb3-bxb-autovnf1-uas-management=172.17.181.7

|
| 2ca11e5b-8eec-456d-9001-1f2600605ad4 |
vnfd1-deployment_c1_0_5b287829-6a9d-4c0a-97d0-a5e0f645b767 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.16;
tb3-bxb-vnfm1-di-internal1=192.168.1.4; tb3-bxb-autovnf1-uas-management=172.17.181.15;
tb3-bxb-vnfm1-di-internal2=192.168.2.5

|
| 0bdbd9e3-926a-4abe-81b3-95dc42ea0676 |
vnfd1-deployment_c2_0_7074a450-5268-4c94-965b-8fb809410d14 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.15;
tb3-bxb-vnfm1-di-internal1=192.168.1.2; tb3-bxb-autovnf1-uas-management=172.17.181.18;
tb3-bxb-vnfm1-di-internal2=192.168.2.6

|
| 8b07a9b1-139f-4a12-b16e-d35cb17f6668 |
vnfd1-deployment_s10_0_f6d110f9-9e49-43fe-be14-4ab87ca3334c | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.7;
tb3-bxb-vnfm1-di-internal1=192.168.1.8; tb3-bxb-vnfm1-service-network1=10.10.10.3,
10.10.10.10; tb3-bxb-vnfm1-service-network2=20.20.20.5, 20.20.20.4;
tb3-bxb-vnfm1-di-internal2=192.168.2.12 | |
| 4ff0ce2e-1d97-4056-a7aa-018412c0385d |
vnfd1-deployment_s3_0_5380ef6c-6fe3-4e92-aa44-d94ef6e94235 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.19;
tb3-bxb-vnfm1-di-internal1=192.168.1.5; tb3-bxb-vnfm1-service-network1=10.10.10.7, 10.10.10.2;
tb3-bxb-vnfm1-service-network2=20.20.20.9, 20.20.20.6; tb3-bxb-vnfm1-di-internal2=192.168.2.8

|
| 3954cd6e-0f12-4d4b-8558-2e035c126d9a |
vnfd1-deployment_s4_0_e5ae4aa9-a90e-4bfe-aaff-82ffd8f7fe34 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.8;
tb3-bxb-vnfm1-di-internal1=192.168.1.9; tb3-bxb-vnfm1-service-network1=10.10.10.13,
10.10.10.8; tb3-bxb-vnfm1-service-network2=20.20.20.12, 20.20.20.10;
tb3-bxb-vnfm1-di-internal2=192.168.2.3 | |
| 2cc6728c-2982-42bf-bb8b-198a14fdcb31 |
vnfd1-deployment_s5_0_1d57c15d-alde-40d4-aac2-1715f01ac50a | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.17;
tb3-bxb-vnfm1-di-internal1=192.168.1.7; tb3-bxb-vnfm1-service-network1=10.10.10.5,
10.10.10.18; tb3-bxb-vnfm1-service-network2=20.20.20.11, 20.20.20.2;
tb3-bxb-vnfm1-di-internal2=192.168.2.4 | |
| 876cc650-ae8b-497b-805a-24a305be6c13 |
vnfd1-deployment_s6_0_05e13a62-623c-4749-ae2a-15c70dd12e16 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.11;
tb3-bxb-vnfm1-di-internal1=192.168.1.6; tb3-bxb-vnfm1-service-network1=10.10.10.12,
10.10.10.9; tb3-bxb-vnfm1-service-network2=20.20.20.13, 20.20.20.18;
tb3-bxb-vnfm1-di-internal2=192.168.2.16 | |
| 89f7245e-c2f7-4041-b5e6-1eee48641cfcd |
vnfd1-deployment_s7_0_3a4d7273-e808-4b5f-8877-7aa182483d93 | ACTIVE | -
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.24;

```

Checking Cinder Type

```
tb3-bxb-vnfm1-di-internal1=192.168.1.12; tb3-bxb-vnfm1-service-network1=10.10.10.14,
10.10.10.6; tb3-bxb-vnfm1-service-network2=20.20.20.20, 20.20.20.8;
tb3-bxb-vnfm1-di-internal2=192.168.2.7 | |
| 535b0bca-d3c5-4d99-ba41-9953da6339f4 |
vnfd1-deployment_s8_0_1e0f3ebf-b6e0-4bfe-9b1c-985dc32e1519 | ACTIVE | - |
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.18;
tb3-bxb-vnfm1-di-internal1=192.168.1.14; tb3-bxb-vnfm1-service-network1=10.10.10.17,
10.10.10.11; tb3-bxb-vnfm1-service-network2=20.20.20.17, 20.20.20.15;
tb3-bxb-vnfm1-di-internal2=192.168.2.9 | |
| dfdffafab-a624-4063-bae6-63c4a757473f |
vnfd1-deployment_s9_0_26db8332-8dac-43fc-84c5-71a8b975fd17 | ACTIVE | - |
Running | tb3-bxb-autovnf1-uas-orchestration=172.17.180.22;
tb3-bxb-vnfm1-di-internal1=192.168.1.10; tb3-bxb-vnfm1-service-network1=10.10.10.21,
10.10.10.24; tb3-bxb-vnfm1-service-network2=20.20.20.23, 20.20.20.22;
tb3-bxb-vnfm1-di-internal2=192.168.2.19 |
+-----+-----+-----+-----+
```

Checking Cinder Type

Log on to the server on which OSP-D is running to check the Cinder volume type by executing the following commands:

```
cd /home/stack
source ~/<stack_name>rc-core
cinder type-list
```

Example command output:

| ID | Name | Description | Is_Public |
|--------------------------------------|------|-------------|-----------|
| 208ef179-dfe4-4735-8a96-e7beee472944 | LUKS | - | True |

```
cinder type-show LUKS
```

Example command output:

| Property | Value |
|---------------------------------|--------------------------------------|
| description | None |
| extra_specs | {} |
| id | bf855b0f-8b3f-42bf-9497-05013b4ddad9 |
| is_public | True |
| name | LUKS |
| os-volume-type-access:is_public | True |
| qos_specs_id | None |

Checking Core Project (Tenant) and User Core

Log on to the server on which OSP-D is running to check the core projects and users by executing the following commands:

```
cd /home/stack
source ~/<stack_name> rc-core
openstack project list
```

Example command output:

```
+-----+-----+
| ID | Name |
+-----+-----+
| 271ab207a197465f9d166c2dc7304b18 | core |
| 52547e0fc994cd682aa733b941d0f68 | service |
| 9543ad9db4dd422ea5aef04756d3682 | admin |
+-----+-----+
```

openstack project show core

Example command output:

```
+-----+-----+
| Field | Value |
+-----+-----+
| description | core tenant |
| enabled | True |
| id | 271ab207a197465f9d166c2dc7304b18 |
| name | core |
| properties | |
+-----+-----+
```

openstack project show service

Example command output:

```
+-----+-----+
| Field | Value |
+-----+-----+
| description | Tenant for the openstack services |
| enabled | True |
| id | 52547e0fc994cd682aa733b941d0f68 |
| name | service |
| properties | |
+-----+-----+
```

openstack project show admin

Example command output:

```
+-----+-----+
| Field | Value |
+-----+-----+
| description | admin tenant |
| enabled | True |
| id | 9543ad9db4dd422ea5aef04756d3682 |
| name | admin |
| properties | |
+-----+-----+
```

openstack user list

Example command output:

```
+-----+-----+
| ID | Name |
+-----+-----+
| 1ac7208b033a41ccba805d86bf60dbb7 | admin |
| a6adac4ee79c4206a29de5165d7c7a6a | neutron |
| 79da40fe88c64de7a93bc691a42926ea | heat |
| 525048a99816474d91d692d9516e951c | nova |
| 8d6688db8d19411080eeb4c84c1d586b | glance |
| 9aadd12171474d1e8bcbacf890e070ab | cinder |
| d2ee641a72c4493995de70a1a9671f2b | heat-cfn |
| 7fb088c15e1428ab6ce677aad5415f4 | swift |
| 828cbf69cf564747a81bb313208a1c21 | core |
+-----+-----+
```

Checking Nova/Neutron Security Groups

```
| 40563efc469d4c1295de0d6d4cf545c2 | tom          |
+-----+-----+
```

openstack user show core

Example command output:

| Field | Value |
|------------|----------------------------------|
| email | None |
| enabled | True |
| id | 828cbf69cf564747a81bb313208a1c21 |
| name | core |
| project_id | 271ab207a197465f9d166c2dc7304b18 |
| username | core |

openstack role list

Example command output:

| ID | Name |
|----------------------------------|-----------------|
| 315d3058519a4b1a9385e11aa5ffe25b | admin |
| 585de968688e4257bc76f6dec13752cb | ResellerAdmin |
| 9717fe8079ba49e9ba9eadd5a37689e7 | swiftoperator |
| 9fe2ff9ee4384b1894a90878d3e92bab | _member_ |
| d75dcf507bfa4a6abee3bb0323c6 | heat_stack_user |

openstack role show admin

Example command output:

| Field | Value |
|-----------|----------------------------------|
| domain_id | None |
| id | 315d3058519a4b1a9385e11aa5ffe25b |
| name | admin |

Checking Nova/Neutron Security Groups

Log on to the server on which OSP-D is running to check Nova and Neutron security groups by executing the following commands:

nova secgroup-list

Example command output:

WARNING: Command secgroup-list is deprecated and will be removed after Nova 15.0.0 is released. Use python-neutronclient or python-openstackclient instead.

| Id | Name | Description |
|--------------------------------------|---------|------------------------|
| ce308d67-7645-43c1-a83e-89d3871141a2 | default | Default security group |

neutron security-group-list

Example command output:

| id | name | security_group_rules |
|--------------------------------------|---------|--|
| 4007a7a4-e7fa-4ad6-bc74-fc0b20f0b60c | default | egress, IPv4 egress, IPv6 ingress, IPv4, remote_group_id: 4007a7a4-e7fa-4ad6-bc74-fc0b20f0b60c ingress, IPv6, remote_group_id: 4007a7a4-e7fa-4ad6-bc74-fc0b20f0b60c 8bee29ae-88c0-4d5d-b27a-a123f20b6858 |
| 8bee29ae-88c0-4d5d-b27a-a123f20b6858 | default | egress, IPv4 egress, IPv6 ingress, IPv4, 1-65535/tcp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, 1-65535/udp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, icmp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, remote_group_id: 8bee29ae-88c0-4d5d-b27a-a123f20b6858 ingress, IPv6, remote_group_id: 8bee29ae-88c0-4d5d-b27a-a123f20b6858 b6b27428-35a3-4be4-af9b-38559132d28e |
| b6b27428-35a3-4be4-af9b-38559132d28e | default | egress, IPv4 egress, IPv6 ingress, IPv4, remote_group_id: b6b27428-35a3-4be4-af9b-38559132d28e ingress, IPv6, remote_group_id: b6b27428-35a3-4be4-af9b-38559132d28e ce308d67-7645-43c1-a83e-89d3871141a2 |
| ce308d67-7645-43c1-a83e-89d3871141a2 | default | egress, IPv4 egress, IPv6 ingress, IPv4, 1-65535/tcp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, 1-65535/udp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, icmp, remote_ip_prefix: 0.0.0.0/0 ingress, IPv4, remote_group_id: ce308d67-7645-43c1-a83e-89d3871141a2 ingress, IPv6, remote_group_id: ce308d67-7645-43c1-a83e-89d3871141a2 |

neutron security-group-show ce308d67-7645-43c1-a83e-89d3871141a2

Example command output:

| Field | Value |
|-------------|--------------------------------------|
| created_at | 2017-06-03T04:57:01Z |
| description | Default security group |
| id | ce308d67-7645-43c1-a83e-89d3871141a2 |

Checking Nova/Neutron Security Groups

```

| name           | default
|
| project_id    | 271ab207a197465f9d166c2dc7304b18
|
| revision_number | 4
|
| security_group_rules | {
|
|               |   "remote_group_id": null,
|
|               |   "direction": "egress",
|
|               |   "protocol": null,
|
|               |   "description": null,
|
|               |   "ethertype": "IPv4",
|
|               |   "remote_ip_prefix": null,
|
|               |   "port_range_max": null,
|
|               |   "updated_at": "2017-06-03T04:57:01Z",
|
|               |   "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|
|               |   "port_range_min": null,
|
|               |   "revision_number": 1,
|
|               |   "tenant_id": "271ab207a197465f9d166c2dc7304b18",
|
|               |   "created_at": "2017-06-03T04:57:01Z",
|
|               |   "project_id": "271ab207a197465f9d166c2dc7304b18",
|
|               |   "id": "337838dd-0612-47f8-99e8-7d4f58dc09d6"
|
|             }
|
|             {
|
|               |   "remote_group_id": null,
|
|               |   "direction": "ingress",
|
|               |   "protocol": "udp",
|
|               |   "description": "",
|
|               |   "ethertype": "IPv4",
|
|               |   "remote_ip_prefix": "0.0.0.0/0",
|
|               |   "port_range_max": 65535,
|
|               |   "updated_at": "2017-06-03T04:57:20Z",
|
|               |   "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|
|               |   "port_range_min": 1,
|
|               |   "revision_number": 1,
|
|             }

```

```
|     |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
|     |     "created_at": "2017-06-03T04:57:20Z",
|     |
|     |     "project_id": "271ab207a197465f9d166c2dc7304b18",
|     |
|     |     "id": "48b04902-d617-4e25-ad0d-4d087128f3b9"
|     |
|     |   }
|     |
|     |   {
|     |
|     |     "remote_group_id": null,
|     |
|     |     "direction": "ingress",
|     |
|     |     "protocol": "icmp",
|     |
|     |     "description": "",
|     |
|     |     "ethertype": "IPv4",
|     |
|     |     "remote_ip_prefix": "0.0.0.0/0",
|     |
|     |     "port_range_max": null,
|     |
|     |     "updated_at": "2017-06-03T04:57:33Z",
|     |
|     |     "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|     |
|     |     "port_range_min": null,
|     |
|     |     "revision_number": 1,
|     |
|     |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
|     |
|     |     "created_at": "2017-06-03T04:57:33Z",
|     |
|     |     "project_id": "271ab207a197465f9d166c2dc7304b18",
|     |
|     |     "id": "68913f31-6788-4473-8b3b-90a264e9ef62"
|     |
|     |   }
|     |
|     |   {
|     |
|     |     "remote_group_id": null,
|     |
|     |     "direction": "ingress",
|     |
|     |     "protocol": "tcp",
|     |
|     |     "description": "",
|     |
|     |     "ethertype": "IPv4",
|     |
|     |     "remote_ip_prefix": "0.0.0.0/0",
|     |
|     |     "port_range_max": 65535,
|     |
|     |     "updated_at": "2017-06-03T04:57:02Z",
|     |
|     |     "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|     |
```

Checking Nova/Neutron Security Groups

```

    |     "port_range_min": 1,
    |
    |     "revision_number": 1,
    |
    |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
    |
    |     "created_at": "2017-06-03T04:57:02Z",
    |
    |     "project_id": "271ab207a197465f9d166c2dc7304b18",
    |
    |     "id": "85ece95b-d361-4986-8db0-78d1a404dd3c"
    |
    |   }
    |
    | {
    |
    |     "remote_group_id": null,
    |
    |     "direction": "egress",
    |
    |     "protocol": null,
    |
    |     "description": null,
    |
    |     "ethertype": "IPv6",
    |
    |     "remote_ip_prefix": null,
    |
    |     "port_range_max": null,
    |
    |     "updated_at": "2017-06-03T04:57:01Z",
    |
    |     "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
    |
    |     "port_range_min": null,
    |
    |     "revision_number": 1,
    |
    |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
    |
    |     "created_at": "2017-06-03T04:57:01Z",
    |
    |     "project_id": "271ab207a197465f9d166c2dc7304b18",
    |
    |     "id": "88320991-5232-44f6-b74b-8cf934165d0"
    |
    |   }
    |
    | {
    |
    |     "remote_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
    |
    |     "direction": "ingress",
    |
    |     "protocol": null,
    |
    |     "description": null,
    |
    |     "ethertype": "IPv4",
    |
    |     "remote_ip_prefix": null,
    |
    |     "port_range_max": null,
    |
    |

```

```

|           |     "updated_at": "2017-06-03T04:57:01Z",
|           |
|           |     "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|
|           |     "port_range_min": null,
|
|           |     "revision_number": 1,
|
|           |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
|
|           |     "created_at": "2017-06-03T04:57:01Z",
|
|           |     "project_id": "271ab207a197465f9d166c2dc7304b18",
|
|           |     "id": "ba306ee2-d21f-48be-9de2-7f04bea5e43a"
|
|           |   }
|
|           |   {
|
|           |     "remote_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|
|           |     "direction": "ingress",
|
|           |     "protocol": null,
|
|           |     "description": null,
|
|           |     "ethertype": "IPv6",
|
|           |     "remote_ip_prefix": null,
|
|           |     "port_range_max": null,
|
|           |     "updated_at": "2017-06-03T04:57:01Z",
|
|           |     "security_group_id": "ce308d67-7645-43c1-a83e-89d3871141a2",
|
|           |     "port_range_min": null,
|
|           |     "revision_number": 1,
|
|           |     "tenant_id": "271ab207a197465f9d166c2dc7304b18",
|
|           |     "created_at": "2017-06-03T04:57:01Z",
|
|           |     "project_id": "271ab207a197465f9d166c2dc7304b18",
|
|           |     "id": "deb7752c-e642-462e-92f0-5dff983f0739"
|
|           |   }
|
| tenant_id | 271ab207a197465f9d166c2dc7304b18
|
| updated_at | 2017-06-03T04:57:33Z
+-----+

```

Checking Tenant Project Default Quotas

Log on to the server on which OSP-D is running to check default project quotas by executing the following commands:

Checking Tenant Project Default Quotas**nova quota-show****Example command output:**

| Quota | Limit |
|-----------------------------|----------|
| instances | 1000 |
| cores | 1000 |
| ram | 51200000 |
| metadata_items | 128 |
| injected_files | 100 |
| injected_file_content_bytes | 1024000 |
| injected_file_path_bytes | 255 |
| key_pairs | 100 |
| server_groups | 10 |
| server_group_members | 10 |

openstack project list | grep core**Example command output:**

| 271ab207a197465f9d166c2dc7304b18 | core |

nova quota-class-show 271ab207a197465f9d166c2dc7304b18**Example command output:**

| Quota | Limit |
|-----------------------------|-------|
| instances | 10 |
| cores | 20 |
| ram | 51200 |
| floating_ips | 10 |
| fixed_ips | -1 |
| metadata_items | 128 |
| injected_files | 5 |
| injected_file_content_bytes | 10240 |
| injected_file_path_bytes | 255 |
| key_pairs | 100 |
| security_groups | 10 |
| security_group_rules | 20 |

neutron quota-show**Example command output:**

| Field | Value |
|---------------------|-------|
| floatingip | 100 |
| network | 1000 |
| port | 4092 |
| rbac_policy | 10 |
| router | 100 |
| security_group | 100 |
| security_group_rule | 300 |
| subnet | 1000 |
| subnetpool | -1 |
| trunk | -1 |

openstack project list | grep core

Example command output:

```
| 271ab207a197465f9d166c2dc7304b18 | core |
cinder quota-show 271ab207a197465f9d166c2dc7304b18
```

Example command output:

| Property | Value |
|----------------------|-------|
| backup_gigabytes | 1000 |
| backups | 10 |
| gigabytes | 8092 |
| gigabytes_LUKS | -1 |
| per_volume_gigabytes | -1 |
| snapshots | 300 |
| snapshots_LUKS | -1 |
| volumes | 500 |
| volumes_LUKS | -1 |

Checking the Nova Hypervisor List

Log on to the server on which OSP-D is running to check the status of nova api on all compute nodes by executing the following command:

```
nova hypervisor-list
```

Example command output:

| ID | Hypervisor hostname | State | Status |
|----|--------------------------------------|-------|---------|
| 3 | tb3-ultram-compute-7.localdomain | up | enabled |
| 6 | tb3-ultram-compute-6.localdomain | up | enabled |
| 9 | tb3-ultram-osd-compute-0.localdomain | up | enabled |
| 12 | tb3-ultram-compute-9.localdomain | up | enabled |
| 15 | tb3-ultram-compute-0.localdomain | up | enabled |
| 18 | tb3-ultram-compute-14.localdomain | up | enabled |
| 21 | tb3-ultram-compute-2.localdomain | up | enabled |
| 24 | tb3-ultram-compute-8.localdomain | up | enabled |
| 27 | tb3-ultram-compute-13.localdomain | up | enabled |
| 30 | tb3-ultram-compute-15.localdomain | up | enabled |
| 33 | tb3-ultram-compute-12.localdomain | up | enabled |
| 36 | tb3-ultram-compute-5.localdomain | up | enabled |
| 39 | tb3-ultram-osd-compute-1.localdomain | up | enabled |
| 42 | tb3-ultram-compute-10.localdomain | up | enabled |
| 45 | tb3-ultram-compute-11.localdomain | up | enabled |
| 48 | tb3-ultram-compute-3.localdomain | up | enabled |
| 51 | tb3-ultram-osd-compute-2.localdomain | up | enabled |
| 54 | tb3-ultram-compute-4.localdomain | up | enabled |
| 57 | tb3-ultram-compute-1.localdomain | up | enabled |

Checking the Router Main Configuration

Log on to the server on which OSP-D is running to check the Neutron router by entering the following commands:

```
neutron router-list
```

Example command output:

Checking the Router Main Configuration

| id | distributed | ha | name | external_gateway_info |
|--------------------------------------|-------------|----|------|--|
| 2d0cdee4-bb5e-415b-921c-97caf0aa0cd1 | | | main | {"network_id": "1c46790f-cab5-4b1d-afc7-a637fe2dbe08", "enable_snat": true, "external_fixed_ips": [{"subnet_id": "a23a740e-3ad0-4fb1-8526-3353dfd0010f", "ip_address": "10.169.127.176"}]} |

```
[stack@lbucs001-ospd ~]$ neutron router-show
2d0cdee4-bb5e-415b-921c-97caf0aa0cd1
```

Example command output:

| Field | Value |
|-------------------------|--|
| admin_state_up | True |
| availability_zone_hints | |
| availability_zones | nova |
| created_at | 2017-06-03T05:05:08Z |
| description | |
| distributed | False |
| external_gateway_info | {"network_id": "1c46790f-cab5-4b1d-afc7-a637fe2dbe08", "enable_snat": true, "external_fixed_ips": [{"subnet_id": "a23a740e-3ad0-4fb1-8526-3353dfd0010f", "ip_address": "10.169.127.176"}]} |
| flavor_id | |
| ha | True |
| id | 2d0cdee4-bb5e-415b-921c-97caf0aa0cd1 |
| name | main |
| project_id | 271ab207a197465f9d166c2dc7304b18 |
| revision_number | 94 |
| routes | |
| status | ACTIVE |
| tenant_id | 271ab207a197465f9d166c2dc7304b18 |
| updated_at | 2017-07-28T00:44:27Z |

Checking the External Network Using the core-project-id

Log on to the server on which OSP-D is running to check the external network configuration by entering the following commands:

neutron net-list

Example command output:

| id | name |
|--------------------------------------|--|
| subnets | |
| 1236bd98-5389-42f9-bac8-433997525549 | LBUCS001-AUTOIT-MGMT |
| c63451f2-7e44-432e-94fc-167f6a31e4aa | 172.16.182.0/24 |
| 1c46790f-cab5-4b1d-afc7-a637fe2dbe08 | LBUCS001-EXTERNAL-MGMT |
| a23a740e-3ad0-4fb1-8526-3353dfd0010f | 10.169.127.160/27 |
| 1c70a9ab-212e-4884-b7d5-4749c44a87b6 | LBPGW101-DI-INTERNAL1 |
| e619b02e-84e0-48d9-9096-f16adc84f1cc | HA network tenant 271ab207a197465f9d166c2dc7304b18 |
| cefd5f5f-0c97-4027-b385-ca1a57f2cfac | 169.254.192.0/18 |

neutron net-show 1c46790f-cab5-4b1d-afc7-a637fe2dbe08

Example command output:

| Field | Value |
|---------------------------|--------------------------------------|
| admin_state_up | True |
| availability_zone_hints | |
| availability_zones | |
| created_at | 2017-06-05T07:18:59Z |
| description | |
| id | 1c46790f-cab5-4b1d-afc7-a637fe2dbe08 |
| ipv4_address_scope | |
| ipv6_address_scope | |
| is_default | False |
| mtu | 1500 |
| name | LBUCS001-EXTERNAL-MGMT |
| port_security_enabled | True |
| project_id | 271ab207a197465f9d166c2dc7304b18 |
| provider:network_type | vlan |
| provider:physical_network | datacentre |
| provider:segmentation_id | 101 |
| qos_policy_id | |
| revision_number | 6 |
| router:external | True |
| shared | False |
| status | ACTIVE |
| subnets | a23a740e-3ad0-4fb1-8526-3353dfd0010f |
| tags | |
| tenant_id | 271ab207a197465f9d166c2dc7304b18 |
| updated_at | 2017-06-05T07:22:51Z |

Note down the **provider:segmentation_id**. In this example, 101 is the vlan for the external interface.

neutron subnet-list

Example command output:

Checking the Staging Network Configuration

| id | allocation_pools | name | cidr |
|--------------------------------------|--|------------------------|----------------------------------|
| a23a740e-3ad0-4fb1-8526-3353dfd0010f | {"start": "10.169.127.168", "end": "10.169.127.190"} | LBUCS001-EXTERNAL-MGMT | 10.169.127.160/27 |
| c63451f2-7e44-432e-94fc-167f6a31e4aa | {"start": "172.16.182.2", "end": "172.16.182.254"} | LBUCS001-AUTOIT-MGMT | 172.16.182.0/24 |
| cefd5f5f-0c97-4027-b385-ca1a57f2cfac | | HA subnet tenant | 169.254.192.0/18 |
| | | | 271ab207a197465f9d166c2dc7304b18 |
| | | | "169.254.255.254" |

neutron subnet-show a23a740e-3ad0-4fb1-8526-3353dfd0010f

Example command output:

| Field | Value |
|-------------------|--|
| allocation_pools | {"start": "10.169.127.168", "end": "10.169.127.190"} |
| cidr | 10.169.127.160/27 |
| created_at | 2017-06-05T07:22:51Z |
| description | |
| dns_nameservers | |
| enable_dhcp | False |
| gateway_ip | 10.169.127.163 |
| host_routes | |
| id | a23a740e-3ad0-4fb1-8526-3353dfd0010f |
| ip_version | 4 |
| ipv6_address_mode | |
| ipv6_ra_mode | |
| name | LBUCS001-EXTERNAL-MGMT |
| network_id | 1c46790f-cab5-4b1d-afc7-a637fe2dbe08 |
| project_id | 271ab207a197465f9d166c2dc7304b18 |
| revision_number | 2 |
| service_types | |
| subnetpool_id | |
| tenant_id | 271ab207a197465f9d166c2dc7304b18 |
| updated_at | 2017-06-05T07:22:51Z |

Checking the Staging Network Configuration

Log on to the server on which OSP-D is running to check the staging network configuration by entering the following commands:

neutron subnet-show <ext-mgmt-id>

<ext-mgmt-id> is the ID for the external management interface as obtained through the **neutron subnet-list** command output.

Example output:

| Field | Value |
|------------------|--|
| allocation_pools | {"start": "10.169.127.168", "end": "10.169.127.190"} |

```

| cidr          | 10.169.127.160/27
| created_at    | 2017-06-05T07:22:51Z
| description   |
| dns_nameservers |
| enable_dhcp   | False
| gateway_ip    | 10.169.127.163
| host_routes   |
| id            | a23a740e-3ad0-4fb1-8526-3353dfd0010f
| ip_version    | 4
| ipv6_address_mode |
| ipv6_ra_mode   |
| name           | LBUCS001-EXTERNAL-MGMT
| network_id     | 1c46790f-cab5-4b1d-afc7-a637fe2dbe08
| project_id     | 271ab207a197465f9d166c2dc7304b18
| revision_number | 2
| service_types  |
| subnetpool_id  |
| tenant_id      | 271ab207a197465f9d166c2dc7304b18
| updated_at     | 2017-06-05T07:22:51Z
+-----+

```

neutron subnet-show <autoit-mgmt-id>

<autoit-mgmt-id> is the ID for the AutoIT management interface as obtained through the **neutron subnet-list** command output.

Example output:

```

+-----+-----+
| Field      | Value
+-----+-----+
| allocation_pools | {"start": "172.16.182.2", "end": "172.16.182.254"} |
| cidr        | 172.16.182.0/24
| created_at   | 2017-06-05T07:41:45Z
| description   |
| dns_nameservers |
| enable_dhcp   | True
| gateway_ip    | 172.16.182.1
| host_routes   |
| id            | c63451f2-7e44-432e-94fc-167f6a31e4aa
| ip_version    | 4
| ipv6_address_mode |
| ipv6_ra_mode   |
| name           | LBUCS001-AUTOIT-MGMT
| network_id     | 1236bd98-5389-42f9-bac8-433997525549
| project_id     | 271ab207a197465f9d166c2dc7304b18
| revision_number | 2
| service_types  |
| subnetpool_id  |
| tenant_id      | 271ab207a197465f9d166c2dc7304b18
| updated_at     | 2017-06-05T07:41:45Z
+-----+

```

Checking the DI-Internal and Service Network Configurations

Log on to the server on which OSP-D is running to check the DI-internal and service network configuration by entering the following commands:

neutron net-list

Example command output:

```

+-----+-----+
| id      | name
+-----+

```

Checking the DI-Internal and Service Network Configurations

| subnets | |
|--------------------------------------|--|
| 1236bd98-5389-42f9-bac8-433997525549 | LBUCS001-AUTOIT-MGMT |
| c63451f2-7e44-432e-94fc-167f6a31e4aa | 172.16.182.0/24 |
| 1c46790f-cab5-4b1d-afc7-a637fe2dbe08 | LBUCS001-EXTERNAL-MGMT |
| a23a740e-3ad0-4fb1-8526-3353dfd0010f | 10.169.127.160/27 |
| 1c70a9ab-212e-4884-b7d5-4749c44a87b6 | LBPGW101-DI-INTERNAL1 |
| e619b02e-84e0-48d9-9096-f16adc84f1cc | HA network tenant 271ab207a197465f9d166c2dc7304b18 |
| cefd5f5f-0c97-4027-b385-ca1a57f2cfac | 169.254.192.0/18 |

neutron net-show LBPGW101-DI-INTERNAL1

Example command output:

| Field | Value |
|---------------------------|--------------------------------------|
| admin_state_up | True |
| availability_zone_hints | |
| availability_zones | |
| created_at | 2017-07-28T22:25:53Z |
| description | |
| id | 1c70a9ab-212e-4884-b7d5-4749c44a87b6 |
| ipv4_address_scope | |
| ipv6_address_scope | |
| mtu | 1500 |
| name | LBPGW101-DI-INTERNAL1 |
| port_security_enabled | True |
| project_id | 271ab207a197465f9d166c2dc7304b18 |
| provider:network_type | flat |
| provider:physical_network | phys_pcie1_0 |
| provider:segmentation_id | |
| qos_policy_id | |
| revision_number | 3 |
| router:external | False |
| shared | True |
| status | ACTIVE |
| subnets | |
| tags | |
| tenant_id | 271ab207a197465f9d166c2dc7304b18 |
| updated_at | 2017-07-28T22:25:53Z |

neutron subnet-list

Example command output:

| id | allocation_pools | name | cidr |
|--------------------------------------|--|------------------------------|-------------------|
| 96ae7e6e-f2e9-4fa5-a816-769c5a79f8f4 | {"start": "192.168.1.2", "end": "192.168.1.254"} | LBPGW101-DI-INTERNAL1-SUBNET | 192.168.1.0/24 |
| a23a740e-3ad0-4fb1-8526-3353dfd0010f | {"start": "10.169.127.168", "end": "10.169.127.190"} | LBUCS001-EXTERNAL-MGMT | 10.169.127.160/27 |
| c63451f2-7e44-432e-94fc-167f6a31e4aa | {"start": "172.16.182.2", "end": "172.16.182.254"} | LBUCS001-AUTOIT-MGMT | 172.16.182.0/24 |

```
| cefdf5f-0c97-4027-b385-cala57f2cfac | HA subnet tenant
169.254.192.0/18 | {"start": "169.254.192.1", "end": "271ab207a197465f9d166c2dc7304b18"
| "169.254.255.254"} |
```

Checking the Flavor List

Log on to the server on which OSP-D is running to check the flavor list and to do so by entering the following command:

nova flavor-list

Example command output:

| ID | Name | Memory_MB | Disk | Ephemeral |
|--------------------------------------|------------------------|-------------|-----------|-----------|
| Swap | VCPUs | RXTX_Factor | Is_Public | |
| eff0335b-3374-46c3-a3de-9f4b1ccaae04 | DNUCS002-AUTOIT-FLAVOR | 8192 | 80 | 0 |
| | 2 | 1.0 | True | |

Checking Host Aggregate and Availability Zone Configuration

Log on to the server on which OSP-D is running to check the host aggregate and availability zone configurations for the OSD Compute and for the AutoDeploy and AutoIT VMs.



Note

It is assumed that the AutoDeploy and AutoIT VMs reside on the same OSD Compute node.

This is done by executing the following commands:

```
cd /home/stack
source ~/<stack_name>rc-core
nova aggregate-list
```

Example command output:

| Id | Name | Availability Zone |
|-----|-------------------|-------------------|
| 108 | LBUCS001-AUTOIT | mgmt |
| 147 | LBPGW101-EM-MGMT1 | - |
| 150 | LBPGW101-SERVICE1 | - |
| 153 | LBPGW101-CF-MGMT1 | - |

nova aggregate-show LBUCS001-AUTOIT

| Id | Name | Availability Zone | Hosts | Metadata |
|-----|-----------------|-------------------|--------------------------------------|---------------------------------------|
| 108 | LBUCS001-AUTOIT | mgmt | 'newtonoc-osd-compute-0.localdomain' | 'availability_zone=mgmt', 'mgmt=true' |

Checking Controller Server Health



Note This information can also be verified through the Horizon GUI. Login to Horizon as the user core and navigate to **Project > Compute > Instances**. Check each instance to verify that the status is Active and the power state is Running.

Correct any instance that does not meet these criteria before continuing.

Checking Controller Server Health



Note The commands in this section should be executed on any one of the Controller nodes and do not need to be repeated on the other Controller nodes unless an issue is observed.

Checking the Pacemaker Cluster Stack (PCS) Status

Log on to one of the Controller nodes and verify that the group of resources in the PCS cluster are active and in the expected state by executing the following command:

sudo pcs status

Example command output:

```
Cluster name: tripleo_cluster
Stack: corosync
Current DC: tb3-ultram-controller-0 (version 1.1.15-11.el7_3.4-e174ec8) - partition with
quorum
Last updated: Wed Jul 12 13:28:56 2017           Last change: Tue Jul 11 21:45:09 2017 by
root via crm_attribute on tb3-ultram-controller-0

3 nodes and 22 resources configured

Online: [ tb3-ultram-controller-0 tb3-ultram-controller-1 tb3-ultram-controller-2 ]

Full list of resources:

ip-192.200.0.104   (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-1
ip-10.84.123.6    (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-0
ip-11.119.0.42    (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-0
Clone Set: haproxy-clone [haproxy]
    Started: [ tb3-ultram-controller-0 tb3-ultram-controller-1 tb3-ultram-controller-2 ]
Master/Slave Set: galera-master [galera]
    Masters: [ tb3-ultram-controller-0 tb3-ultram-controller-1 tb3-ultram-controller-2 ]
ip-11.120.0.47    (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-1
ip-11.118.0.49    (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-0
Clone Set: rabbitmq-clone [rabbitmq]
    Started: [ tb3-ultram-controller-0 tb3-ultram-controller-1 tb3-ultram-controller-2 ]
ip-11.120.0.48    (ocf::heartbeat:IPaddr2):          Started tb3-ultram-controller-1
Master/Slave Set: redis-master [redis]
    Masters: [ tb3-ultram-controller-0 ]
        Slaves: [ tb3-ultram-controller-1 tb3-ultram-controller-2 ]
openstack-cinder-volume   (systemd:openstack-cinder-volume):      Started
tb3-ultram-controller-0
my-ipmilan-for-controller-0   (stonith:fence_ipmilan):       Started
tb3-ultram-controller-0
my-ipmilan-for-controller-1   (stonith:fence_ipmilan):       Started
tb3-ultram-controller-1
```

```
my-ipmilan-for-controller-2      (stonith:fence_ipmilan):      Started
tb3-ultram-controller-0
```

```
Daemon Status:
  corosync: active/enabled
  pacemaker: active/enabled
  pcsd: active/enabled
```

From the output of this command, ensure that:

- All 3 controllers are listed as Online
- haproxy-clone is started on all 3 controllers
- galera-master lists all 3 controllers as Masters
- rabbitmq-clone is started on all 3 controllers
- redis-master lists one controller as master and the other 2 controllers as slaves
- openstack-cinder-volume is started on one node
- my-ipmilan/stonith is started on all 3 controllers
- Daemons corosync, pacemaker and pcsd are active and enabled



Note

If the output displays any “Failed Actions”, execute the **sudo pcs resource cleanup** command and then re-execute the **sudo pcs status** command.

Checking Ceph Storage Status

Log on to the Controller node and verify the health of the Ceph storage from the Controller node by executing the following command:

sudo ceph status

Example command output:

```
cluster eb2bb192-b1c9-11e6-9205-525400330666
  health HEALTH_OK
  monmap e1: 3 mons at
{tb3-ultram-controller-0=11.118.0.10:6789/0,tb3-ultram-controller-1=11.118.0.11:6789/0,
tb3-ultram-controller-2=11.118.0.12:6789/0}
  election epoch 152, quorum 0,1,2
tb3-ultram-controller-0,tb3-ultram-controller-1,tb3-ultram-controller-2
  osdmap e158: 12 osds: 12 up, 12 in
    flags sortbitwise,require_jewel_osds
  pgmap v1417251: 704 pgs, 6 pools, 321 GB data, 110 kobjects
    961 GB used, 12431 GB / 13393 GB avail
    704 active+clean
  client io 53755 B/s wr, 0 op/s rd, 7 op/s wr
```

From the output of this command, ensure that:

- health is listed as HEALTH_OK
- The correct number of monitors are listed in the monmap
- The correct number of OSDs are listed in the osdmap

Checking Controller Node Services

Log on to the Controller node and check the status of all services by executing the following command:

```
sudo systemctl list-units "openstack*" "neutron*" "openvswitch*"
```

Example command output:

| UNIT | LOAD | ACTIVE | SUB | DESCRIPTION |
|--|--------|--------|---------|---|
| neutron-dhcp-agent.service | loaded | active | running | OpenStack Neutron DHCP Agent |
| neutron-l3-agent.service | loaded | active | running | OpenStack Neutron Layer 3 Agent |
| neutron-metadata-agent.service | loaded | active | running | OpenStack Neutron Metadata Agent |
| neutron-openvswitch-agent.service | loaded | active | running | OpenStack Neutron Open vSwitch Agent |
| neutron-ovs-cleanup.service | loaded | active | exited | OpenStack Neutron Open vSwitch Cleanup Utility |
| neutron-server.service | loaded | active | running | OpenStack Neutron Server |
| openstack-cinder-api.service | loaded | active | running | OpenStack Cinder API Server |
| openstack-cinder-scheduler.service | loaded | active | running | OpenStack Cinder Scheduler Server |
| openstack-cinder-volume.service | loaded | active | running | Cluster Controlled |
| openstack-glance-api.service | loaded | active | running | OpenStack Image Service (code-named Glance) API server |
| openstack-glance-registry.service | loaded | active | running | OpenStack Image Service (code-named Glance) Registry server |
| openstack-heat-api-cfn.service | loaded | active | running | Openstack Heat CFN-compatible API Service |
| openstack-heat-api-cloudwatch.service | loaded | active | running | OpenStack Heat CloudWatch API Service |
| openstack-heat-api.service | loaded | active | running | OpenStack Heat API Service |
| openstack-heat-engine.service | loaded | active | running | Openstack Heat Engine Service |
| openstack-nova-api.service | loaded | active | running | OpenStack Nova API Server |
| openstack-nova-conductor.service | loaded | active | running | OpenStack Nova Conductor Server |
| openstack-nova-consoleauth.service | loaded | active | running | OpenStack Nova VNC console auth Server |
| openstack-nova-novncproxy.service | loaded | active | running | OpenStack Nova NoVNC Proxy Server |
| openstack-nova-scheduler.service | loaded | active | running | OpenStack Nova Scheduler Server |
| openstack-swift-account-auditor.service | loaded | active | running | OpenStack Object Storage (swift) - Account Auditor |
| openstack-swift-account-reaper.service | loaded | active | running | OpenStack Object Storage (swift) - Account Reaper |
| openstack-swift-account-replicator.service | loaded | active | running | OpenStack Object Storage (swift) - Account Replicator |
| openstack-swift-account.service | loaded | active | running | OpenStack Object Storage (swift) - Account Server |
| openstack-swift-container-auditor.service | loaded | active | running | OpenStack Object Storage (swift) - Container Auditor |
| openstack-swift-container-replicator.service | loaded | active | running | OpenStack Object Storage (swift) - Container Replicator |
| openstack-swift-container-updater.service | loaded | active | running | OpenStack Object Storage (swift) - Container Updater |
| openstack-swift-container.service | loaded | active | running | OpenStack Object Storage (swift) - Container Server |
| openstack-swift-object-auditor.service | loaded | active | running | OpenStack Object Storage (swift) - Object Auditor |

```

openstack-swift-object-expirer.service           loaded active running OpenStack Object Storage
  (swift) - Object Expirer
openstack-swift-object-replicator.service        loaded active running OpenStack Object Storage
  (swift) - Object Replicator
openstack-swift-object-updater.service          loaded active running OpenStack Object Storage
  (swift) - Object Updater
openstack-swift-object.service                 loaded active running OpenStack Object Storage
  (swift) - Object Server
openstack-swift-proxy.service                  loaded active running OpenStack Object Storage
  (swift) - Proxy Server
openvswitch.service                           loaded active exited  Open vSwitch

LOAD   = Reflects whether the unit definition was properly loaded.
ACTIVE = The high-level unit activation state, i.e. generalization of SUB.
SUB    = The low-level unit activation state, values depend on unit type.

43 loaded units listed. Pass --all to see loaded but inactive units, too.
To show all installed unit files use 'systemctl list-unit-files'.

```

Check the RabbitMQ Database Status

From each of the controller nodes, determine if the rabbitmq database is in a good state by executing the following command:

```
sudo rabbitmqctl eval 'rabbit_diagnostics:maybe_stuck() .'
```

Example command output:

```

2017-07-20 01:58:02 There are 11020 processes.
2017-07-20 01:58:02 Investigated 0 processes this round, 5000ms to go.
2017-07-20 01:58:03 Investigated 0 processes this round, 4500ms to go.
2017-07-20 01:58:03 Investigated 0 processes this round, 4000ms to go.
2017-07-20 01:58:04 Investigated 0 processes this round, 3500ms to go.
2017-07-20 01:58:04 Investigated 0 processes this round, 3000ms to go.
2017-07-20 01:58:05 Investigated 0 processes this round, 2500ms to go.
2017-07-20 01:58:05 Investigated 0 processes this round, 2000ms to go.
2017-07-20 01:58:06 Investigated 0 processes this round, 1500ms to go.
2017-07-20 01:58:06 Investigated 0 processes this round, 1000ms to go.
2017-07-20 01:58:07 Investigated 0 processes this round, 500ms to go.
2017-07-20 01:58:07 Found 0 suspicious processes.
ok

```

If the database is healthy, the command returns “Found 0 suspicious processes.” If the database is not healthy, the command returns 1 or more suspicious processes. Contact your local support representative if suspicious processes are found.

Checking OSD Compute Server Health

Checking Ceph Status

Log on to the OSD Compute and check the Ceph storage status by executing the following command:

```
sudo ceph status
```

Example command output:

```

sudo ceph status
cluster eb2bb192-b1c9-11e6-9205-525400330666
  health HEALTH_OK
  monmap e1: 3 mons at
{tb3-ultram-controller-0=11.118.0.10:6789/0,tb3-ultram-controller-1=11.118.0.11:6789/0,

```

Checking OSD Compute Node Services

```

tb3-ultram-controller-2=11.118.0.12:6789/0}
    election epoch 152, quorum 0,1,2
tb3-ultram-controller-0,tb3-ultram-controller-1,tb3-ultram-controller-2
    osdmap e158: 12 osds: 12 up, 12 in
        flags sortbitwise,require_jewel_osds
    pgmap v1417867: 704 pgs, 6 pools, 321 GB data, 110 kobjects
        961 GB used, 12431 GB / 13393 GB avail
        704 active+clean
client io 170 kB/s wr, 0 op/s rd, 24 op/s wr

```

Checking OSD Compute Node Services

Log on to each OSD Compute node and check the status of all services by executing the following command:

```
sudo systemctl list-units "openstack*" "neutron*" "openvswitch*"
```

Example command output:

| UNIT | LOAD | ACTIVE | SUB | DESCRIPTION |
|-----------------------------------|--------|--------|---------|--|
| neutron-openvswitch-agent.service | loaded | active | running | OpenStack Neutron Open vSwitch Agent |
| neutron-ovs-cleanup.service | loaded | active | exited | OpenStack Neutron Open vSwitch Cleanup Utility |
| neutron-sriov-nic-agent.service | loaded | active | running | OpenStack Neutron SR-IOV NIC Agent |
| openstack-nova-compute.service | loaded | active | running | OpenStack Nova Compute Server |
| openvswitch.service | loaded | active | exited | Open vSwitch |

LOAD = Reflects whether the unit definition was properly loaded.
 ACTIVE = The high-level unit activation state, i.e. generalization of SUB.
 SUB = The low-level unit activation state, values depend on unit type.

6 loaded units listed. Pass --all to see loaded but inactive units, too.
 To show all installed unit files use 'systemctl list-unit-files'.

Monitoring AutoDeploy Operations

This section identifies various commands that can be used to determine the status and health of AutoDeploy.

To use them, you must:

1. Log on to the AutoDeploy VM as *ubuntu*. Use the password that was created earlier for this user.
2. Become the root user.

```
sudo -i
```

Viewing AutoDeploy Logs

AutoDeploy logs are available on the AutoDeploy VM in the following directory:

```
/var/log/upstart/autodeploy.log
```



Important To access the command used to view logs, you must be logged in to the Confd CLI as the *admin* user on the AutoDeploy VM:

```
confd_cli -u admin -C
```

AutoDeploy Transaction Logs

Execute the following command to display AutoDeploy transaction logs:

```
show log $TX-ID | display xml
```

Example VIM-ORCH and VIM Activation Log:

```
2018-01-23 22:01:56,266 - Send Deployment notification for: autoit-instance
2018-01-23 22:08:36,876 - Deployment activate-ns-deployment: autoit initiated
2018-01-23 22:08:36,919 - Send Deployment notification for: autoit-instance
2018-01-23 22:08:36,951 - Deployment activate-ns-deployment: autoit initiated
2018-01-23 22:08:37,004 - Send Deployment notification for: autoit-deploy
2018-01-23 22:08:37,029 - Image '/var/cisco/isos/rhel-server-7.3-x86_64-dvd.iso' exists
2018-01-23 22:08:37,134 - Send Deployment notification for: autoit-instance
2018-01-23 22:08:37,165 - Deployment activate-ns-deployment: autoit started
2018-01-23 22:08:37,181 - Adding NSR: autoit-instance
2018-01-23 22:08:37,215 - Start pipeline of 1 tasks
2018-01-23 22:08:37,257 - Scheduling Task: autoit
2018-01-23 22:08:37,269 - Waiting for all workers to finish the transactions
2018-01-23 22:08:37,364 - Send Deployment notification for: autoit-deploy
2018-01-23 22:08:37,387 - Deployment activate-ns-deployment: autoit started
2018-01-23 22:08:37,395 - Skipping VNF pre-deployment , since VNFD is not defined
2018-01-23 22:08:37,424 - Skipping VNF-Package pre-deployment, since is not defined
2018-01-23 22:08:37,440 - Skipping VIM-Artifact pre-deployment, since VIM-Artifact is not defined
2018-01-23 22:08:37,463 - VIM-Orchestrator deployment pre-check success, entry already exists. Continuing...
2018-01-23 22:08:37,470 - VIM deployment pre-check success, entry already exists.
Continuing...
2018-01-23 22:08:37,501 - NS pre-check success
2018-01-23 22:08:37,513 - Copying '/var/cisco/isos/rhel-server-7.3-x86_64-dvd.iso' to '/var/cisco/isos/underc_rhel-server-7.3-x86_64-dvd.iso'
/tmp/_MEIulQrBS/Crypto/Cipher/blockalgo.py:141: FutureWarning: CTR mode needs counter parameter, not IV
2018-01-23 22:09:00,685 - Connected to AutoIT[172.21.203.121]
2018-01-23 22:09:02,281 - Skipping VNFDs
2018-01-23 22:09:02,298 - Skipping VNF-PACKAGE
2018-01-23 22:09:02,314 - Skipping VIM-Artifact
2018-01-23 22:09:02,332 - XML:[<config>
  <nsd xmlns="http://www.cisco.com/usp/nfv/usp-nsds">
    <nsd-id>autoit</nsd-id>
    <vim-orch>underc</vim-orch>
    <vim>overc</vim>
  </nsd>
  <vim-orchd xmlns="http://www.cisco.com/usp/nfv/usp-vim-orch">
    <vim-orch-id>underc</vim-orch-id>
    <hostname>tb3-undercloud</hostname>
    <domain-name>cisco.com</domain-name>
  .
  .
  .
  2018-01-23 22:38:53,531 - VIM-ORCH: in-progress:84/84
  2018-01-23 22:38:53,781 - Received vim-orchestrator-deployment-event for underc:1516745343-313472/1516745343-460684 with status:success
  2018-01-23 22:38:53,811 - VIM-ORCH: success:None/None
  2018-01-23 22:38:53,983 - Received vim-deployment-event for overc:1516745343-313472/1516745343-581981 with status:in-progress
  2018-01-23 22:38:54,426 - Received vim-deployment-event for overc:1516745343-313472/1516745343-581981 with status:in-progress
  2018-01-23 23:39:15,038 - Received vim-deployment-event for overc:1516745343-313472/1516745343-581981 with status:success
  2018-01-23 23:39:15,113 - Received ns-deployment-event for autoit:1516745343-313472 with status:success
```

AutoDeploy Transaction Logs

```

2018-01-23 23:39:15,167 - RPC NS[autoit:autoit-instance] success
2018-01-23 23:39:15,271 - Deployment activate-ns-deployment: autoit succeeded
2018-01-23 23:39:15,344 - Send Deployment notification for: autoit-deploy
No handlers could be found for logger "AutoVNF-Traces"
2018-01-23 23:39:15,518 - All workers finished the job
2018-01-23 23:39:15,532 - Deployment activate-ns-deployment: autoit succeeded
2018-01-23 23:39:15,571 - Send Deployment notification for: autoit-instance

```

Example Tenant Creation Log:

```

2018-01-23 23:48:54,420 - Deployment activate-ns-deployment: autoit initiated
2018-01-23 23:48:54,449 - Send Deployment notification for: autoit-instance
2018-01-23 23:48:54,465 - Parsing role for tenant 'sjccore'
2018-01-23 23:48:54,473 - Parsing credentials for tenant 'sjccore'
2018-01-23 23:48:54,484 - Parsing attributes for tenant 'sjccore'
2018-01-23 23:48:54,540 - Deployment activate-ns-deployment: autoit initiated
2018-01-23 23:48:54,574 - Send Deployment notification for: autoit-deploy
2018-01-23 23:48:54,599 - Image '/var/cisco/isos/rhel-server-7.3-x86_64-dvd.iso' exists
2018-01-23 23:48:54,666 - Send Deployment notification for: autoit-instance
2018-01-23 23:48:54,689 - Deployment activate-ns-deployment: autoit started
2018-01-23 23:48:54,691 - Adding NSR: autoit-instance
2018-01-23 23:48:54,712 - Start pipeline of 1 tasks
2018-01-23 23:48:54,723 - Scheduling Task: autoit
2018-01-23 23:48:54,749 - Waiting for all workers to finish the transactions
2018-01-23 23:48:54,804 - Send Deployment notification for: autoit-deploy
2018-01-23 23:48:54,806 - Deployment activate-ns-deployment: autoit started
2018-01-23 23:48:54,822 - Skipping VNF pre-deployment , since VNFD is not defined
2018-01-23 23:48:54,829 - Skipping VNF-Package pre-deployment, since is not defined
2018-01-23 23:48:54,862 - VIM-Artifact deployment pre-check success
2018-01-23 23:48:54,866 - VIM-Orchestrator deployment pre-check success, entry already exists. Continuing...
2018-01-23 23:48:54,879 - VIM deployment pre-check success, entry already exists.
Continuing...
2018-01-23 23:48:54,885 - NS pre-check success
2018-01-23 23:48:54,895 - Skipping copy, file
'/var/cisco/isos/underc_rhel-server-7.3-x86_64-dvd.iso' already exists
/tmp/_MEIulQrBS/Crypto/Cipher/blockalgo.py:141: FutureWarning: CTR mode needs counter parameter, not IV
2018-01-23 23:48:55,244 - Connected to AutoIT[172.21.203.121]
2018-01-23 23:48:55,259 - Skipping VNFDs
2018-01-23 23:48:55,274 - Skipping VNF-PACKAGE
2018-01-23 23:48:55,279 - XML:[<config>
<nsd xmlns="http://www.cisco.com/usp/nfv/nsd">
<nsd-id>autoit</nsd-id>
<vim-identity>vim1</vim-identity>

.
.
.

2018-01-23 23:48:56,419 - Received vim-orchestrator-deployment-event for
underc:1516751336-209342/1516751336-428695 with status:success
2018-01-23 23:48:56,441 - VIM-ORCH: success:None/None
2018-01-23 23:48:56,540 - Received vim-deployment-event for
overc:1516751336-209342/1516751336-532373 with status:in-progress
2018-01-23 23:48:56,671 - Received vim-deployment-event for
overc:1516751336-209342/1516751336-532373 with status:success
2018-01-23 23:48:56,802 - Received vim-deployment-event for
sjccore:1516751336-209342/1516751336-654858 with status:in-progress
2018-01-23 23:49:13,305 - Received vim-deployment-event for
sjccore:1516751336-209342/1516751336-654858 with status:success
2018-01-23 23:49:13,387 - Received ns-deployment-event for autoit:1516751336-209342 with
status:success
2018-01-23 23:49:13,414 - RPC NS[autoit:autoit-instance] success
2018-01-23 23:49:13,496 - Deployment activate-ns-deployment: autoit succeeded
2018-01-23 23:49:13,540 - Send Deployment notification for: autoit-deploy

```

```
No handlers could be found for logger "AutoVNF-Traces"
2018-01-23 23:49:13,670 - All workers finished the job
2018-01-23 23:49:13,689 - Deployment activate-ns-deployment: autoit succeeded
2018-01-23 23:49:13,723 - Send Deployment notification for: autoit-instance
```

Example AutoVNF Creation Log:

```
<config xmlns="http://tail-f.com/ns/config/1.0">
  <log xmlns="http://www.cisco.com/usp/nfv/usp-transaction">
    <tx-id>1516900912-955117</tx-id>
    <log>
      2018-01-25 17:21:54,162 - Send Deployment notification for: autoit-instance
      2018-01-25 17:21:54,195 - Deployment activate-ns-deployment: autoit started
      2018-01-25 17:21:54,225 - Adding NSR: autoit-instance
      2018-01-25 17:21:54,288 - Start pipeline of 1 tasks
      2018-01-25 17:21:54,312 - Scheduling Task: autoit
      2018-01-25 17:21:54,342 - Waiting for all workers to finish the transactions
      2018-01-25 17:23:19,325 - All workers finished the job
      2018-01-25 17:23:19,365 - Deployment activate-ns-deployment: autoit succeeded
      2018-01-25 17:23:19,517 - Send Deployment notification for: autoit-instance
      2018-01-25 17:24:28,117 - Deployment activate-ns-deployment: tb3-autovnf_vpc initiated
      2018-01-25 17:24:28,209 - Send Deployment notification for: tb3-autovnf_vpc-instance
      2018-01-25 17:21:54,505 - Send Deployment notification for: autoit-deploy
      2018-01-25 17:21:54,550 - Deployment activate-vnf-deployment: autoit started
      2018-01-25 17:21:54,588 - Adding NSR: autoit-instance, VNFR: autoit-tb3-autovnf1, vlrs: None
      2018-01-25 17:21:54,661 - VNF deployment pre-check success(all-not-present)
      2018-01-25 17:21:55,001 - Connected to AutoIT[10.84.123.51]
      2018-01-25 17:21:55,039 - XML:[&lt;config>
        &lt;nsd xmlns="http://www.cisco.com/usp/nfv/usp-nsds">
          &lt;nsd-id>autoit&lt;/nsd-id>
          &lt;vim-identity>vim2&lt;/vim-identity>
        .
        .
        .
        2018-01-25 17:25:04,646 - &lt;?xml version="1.0" encoding="UTF-8"?>
        &lt;rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
          message-id="urn:uuid:1d0dd00b-a3a9-4e10-9a71-376680d05dca"
          xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0">&lt;transaction-id
          xmlns='http://www.cisco.com/usp/nfv/usp-nsds'>1516901142-922838&lt;/transaction-id>
        &lt;/rpc-reply>
        2018-01-25 17:25:04,736 - Waiting for deployment notifications for tx-id '1516901142-922838'
        2018-01-25 17:25:04,816 - Received ns-deployment-event for tb3-autovnf_vpc:1516901142-922838
          with status:requested
        2018-01-25 17:25:04,851 - Received vim-deployment-event for
          tb3-vnf1-rack:1516901142-922838/1516901143-301032 with status:requested
        2018-01-25 17:25:04,908 - VIM: requested:None/None
        2018-01-25 17:25:04,977 - Received vnf-package-deployment-event for
          usp_6_0:1516901142-922838/1516901143-337769 with status:requested
        2018-01-25 17:25:05,034 - VNF-PKG[usp_6_0]: requested, activate-vnf-package
        2018-01-25 17:25:05,118 - Received vnf-deployment-event for
          esc:1516901142-922838/1516901143-372586 with status:requested
        2018-01-25 17:25:05,166 - Received vnf-deployment-event for
          vpc:1516901142-922838/1516901143-418832 with status:requested
        2018-01-25 17:25:05,201 - Received ns-deployment-event for tb3-autovnf_vpc:1516901142-922838
          with status:in-progress
        2018-01-25 17:25:05,235 - Received vim-deployment-event for
          tb3-vnf1-rack:1516901142-922838/1516901143-301032 with status:in-progress
        2018-01-25 17:25:05,269 - VIM: in-progress:None/None
        2018-01-25 17:25:15,753 - Received vim-deployment-event for
          tb3-vnf1-rack:1516901142-922838/1516901143-301032 with status:success
        2018-01-25 17:25:15,786 - VIM: success:None/None
        2018-01-25 17:25:15,889 - Received vnf-package-deployment-event for
          usp_6_0:1516901142-922838/1516901143-337769 with status:in-progress
```

Checking AutoDeploy Processes

```

2018-01-25 17:25:15,927 - VNF-PKG[usp_6_0]: in-progress, activate-vnf-package
2018-01-25 17:27:44,479 - Received vnf-package-deployment-event for
  usp_6_0:1516901142-922838/1516901143-337769 with status:success
2018-01-25 17:27:44,566 - VNF-PKG[usp_6_0]: success, activate-vnf-package
2018-01-25 17:27:44,624 - Received vnf-deployment-event for
  esc:1516901142-922838/1516901143-372586 with status:in-progress
2018-01-25 17:31:13,916 - Received vnf-deployment-event for
  esc:1516901142-922838/1516901143-372586 with status:success
2018-01-25 17:31:13,972 - Received vnf-deployment-event for
  vpc:1516901142-922838/1516901143-418832 with status:in-progress
2018-01-25 17:45:29,291 - Received vnf-deployment-event for
  vpc:1516901142-922838/1516901143-418832 with status:success
2018-01-25 17:45:29,318 - Received ns-deployment-event for tb3-autovnf_vpc:1516901142-922838
  with status:success
2018-01-25 17:45:29,382 - RPC NS[tb3-autovnf_vpc:tb3-autovnf_vpc-instance] success
2018-01-25 17:45:30,000 - Deployment activate-ns-deployment: tb3-autovnf_vpc succeeded
2018-01-25 17:45:30,141 - Send Deployment notification for: tb3-autovnf_vpc-deploy</log>
</log>
</config>
```

Checking AutoDeploy Processes

Check the status of AutoDeploy VM by entering the following commands:

```
service autodeploy status
service uas-confd status
```

Determining the Running AutoDeploy Version

To display the version of the AutoDeploy software role that is currently operational:

```
show uas
```

Example output:

```

uas version          6.0.0
uas state           active
uas external-connection-point 172.28.185.132
INSTANCE IP      STATE   ROLE
-----
172.28.185.133  alive   CONFD-MASTER
172.28.185.134  alive   CONFD-SLAVE

NAME            LAST HEARTBEAT
-----
AutoDeploy-MASTER 2018-01-24 21:29:54
USPCFMWorker    2018-01-24 21:29:45
USPCHBWorker    2018-01-24 21:29:45
USPCWorker       2018-01-24 21:29:45
```

Monitoring AutoIT Operations

This section identifies various commands that can be used to determine the status and health of AutoIT.

To use them, you must:

1. Log on to the AutoIT VM as *ubuntu*. Use the password that was created earlier for this user.

2. Become the *root* user.

```
sudo -i
```

Viewing AutoIT Logs

AutoIT maintains logs containing information pertaining to UAS deployment and termination transactions. The *autoit.log* file is located in the following directory on the Ultra M Manager Node:

```
/var/log/cisco/usp/auto-it/autoit.log
```

Example Deployment Log:

```
tail -100f /var/log/cisco/usp/auto-it/autoit.log &^C

2017-05-25 22:04:57,527 - INFO: Received a request to list config folder names.
2017-05-25 22:04:57,527 - INFO: config contents are:
2017-05-25 22:04:57,536 - INFO: Received a request to list config folder names.
2017-05-25 22:04:57,536 - INFO: config contents are:
2017-05-25 22:04:57,545 - INFO: Received a request to create a configuration folder.
2017-05-25 22:04:57,551 - INFO: Received a request to create a configuration folder.
2017-05-25 22:04:57,553 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:04:57,563 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:04:57,565 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:04:57,566 - INFO: Received request to upload config file system.cfg to config
named vnf-pkg1
2017-05-25 22:04:57,567 - INFO: Uploaded file system.cfg to config named vnf-pkg1

2017-05-25 22:05:54,268 - INFO: Received request to upload ISO usp-5_1_0.iso
2017-05-25 22:05:54,268 - INFO: Saving ISO to /tmp/tmpxu7Mu0/usp-5_1_0.iso
2017-05-25 22:06:30,678 - INFO: Mounting ISO to /tmp/tmpxu7Mu0/iso_mount
2017-05-25 22:06:30,736 - INFO: ISO version already installed, (5.1.0-662)
2017-05-25 22:06:31,355 - INFO: Received a request to list file names in config named
vnf-pkg1.
2017-05-25 22:06:31,355 - INFO: config contents are: system.cfg
2017-05-25 22:06:31,362 - INFO: Received a request to list file names in config named
vnf-pkg1-images.
2017-05-25 22:06:31,362 - INFO: config contents are:
2017-05-25 22:06:31,370 - INFO: Received request to get ISO details 5.1.0-662
2017-05-25 22:06:31,391 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:06:31,857 - INFO: Getting Host Aggregate failed: Aggregate
'auto-test-sjc-service1' not found on OpenStack setup
2017-05-25 22:06:31,872 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:06:32,415 - INFO: Deploying Host Aggregate 'auto-test-sjc-service1' completed
2017-05-25 22:06:32,427 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:06:32,975 - INFO: Getting Host Aggregate failed: Aggregate
'auto-test-sjc-cf-esc-mgmt1' not found on OpenStack setup
2017-05-25 22:06:32,986 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:06:33,513 - INFO: Deploying Host Aggregate 'auto-test-sjc-cf-esc-mgmt1'
completed
2017-05-25 22:06:33,524 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:06:33,881 - INFO: Getting Host Aggregate failed: Aggregate
'auto-test-sjc-em-autovnf-mgmt1' not found on OpenStack setup
2017-05-25 22:06:33,891 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:06:34,535 - INFO: Deploying Host Aggregate 'auto-test-sjc-em-autovnf-mgmt1'
completed
2017-05-25 22:06:34,580 - INFO: Received a request to deploy AutoVnf
2017-05-25 22:06:40,340 - INFO: Creating AutoVnf deployment (3 instance(s)) on
'http://172.21.201.217:5000/v2.0' tenant 'core' user 'core', ISO '5.1.0-662'
2017-05-25 22:06:40,340 - INFO: Creating network 'auto-testautovnfl-uas-management'
2017-05-25 22:06:42,241 - INFO: Created network 'auto-testautovnfl-uas-management'
2017-05-25 22:06:42,241 - INFO: Creating network 'auto-testautovnfl-uas-orchestration'
```

Viewing AutoIT Logs

```

2017-05-25 22:06:42,821 - INFO: Created network 'auto-testautovnf1-uas-orchestration'
2017-05-25 22:06:42,888 - INFO: Created flavor 'auto-testautovnf1-uas'
2017-05-25 22:06:42,888 - INFO: Loading image 'auto-testautovnf1-usp-uas-1.0.0-601.qcow2'
from '/opt/cisco/usp/bundles/5.1.0-662/uas-bundle/usp-uas-1.0.0-601.qcow2'
2017-05-25 22:06:53,927 - INFO: Loaded image 'auto-testautovnf1-usp-uas-1.0.0-601.qcow2'
2017-05-25 22:06:53,928 - INFO: Creating volume 'auto-testautovnf1-uas-vol-0' with command

[ /opt/cisco/usp/apps/auto-it/vnf/.../common/autoit/.../autoit_os_utils/scripts/autoit_volume_staging.sh
OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
auto-testautovnf1-uas-vol-0 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpphsTAj6/encrypted.cfg]
2017-05-25 22:07:06,104 - INFO: Created volume 'auto-testautovnf1-uas-vol-0'
2017-05-25 22:07:06,104 - INFO: Creating volume 'auto-testautovnf1-uas-vol-1' with command

[ /opt/cisco/usp/apps/auto-it/vnf/.../common/autoit/.../autoit_os_utils/scripts/autoit_volume_staging.sh
OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
auto-testautovnf1-uas-vol-1 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpphsTAj6/encrypted.cfg]
2017-05-25 22:07:17,598 - INFO: Created volume 'auto-testautovnf1-uas-vol-1'
2017-05-25 22:07:17,598 - INFO: Creating volume 'auto-testautovnf1-uas-vol-2' with command

[ /opt/cisco/usp/apps/auto-it/vnf/.../common/autoit/.../autoit_os_utils/scripts/autoit_volume_staging.sh
OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
auto-testautovnf1-uas-vol-2 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpphsTAj6/encrypted.cfg]
2017-05-25 22:07:29,242 - INFO: Created volume 'auto-testautovnf1-uas-vol-2'
2017-05-25 22:07:30,477 - INFO: Assigned floating IP '172.21.201.59' to IP '172.57.11.101'
2017-05-25 22:07:33,843 - INFO: Creating instance 'auto-testautovnf1-uas-0' and attaching
volume 'auto-testautovnf1-uas-vol-0'
2017-05-25 22:08:00,717 - INFO: Created instance 'auto-testautovnf1-uas-0'
2017-05-25 22:08:00,717 - INFO: Creating instance 'auto-testautovnf1-uas-1' and attaching
volume 'auto-testautovnf1-uas-vol-1'
2017-05-25 22:08:27,577 - INFO: Created instance 'auto-testautovnf1-uas-1'
2017-05-25 22:08:27,578 - INFO: Creating instance 'auto-testautovnf1-uas-2' and attaching
volume 'auto-testautovnf1-uas-vol-2'
2017-05-25 22:08:58,345 - INFO: Created instance 'auto-testautovnf1-uas-2'
2017-05-25 22:08:58,345 - INFO: Deploy request completed
2017-05-25 22:14:07,201 - INFO: Received request to download file system.cfg from config
named vnf-pkg1
2017-05-25 22:19:05,050 - INFO: Received a request to list config folder names.
2017-05-25 22:19:05,051 - INFO: config contents are: vnf-pkg1-images,vnf-pkg1
2017-05-25 22:19:05,059 - INFO: Received a request to list config folder names.
2017-05-25 22:19:05,059 - INFO: config contents are: vnf-pkg1-images,vnf-pkg1
2017-05-25 22:19:05,066 - INFO: Received a request to create a configuration folder.
2017-05-25 22:19:05,073 - INFO: Received a request to create a configuration folder.
2017-05-25 22:19:05,076 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:19:05,083 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:19:05,085 - INFO: Received request to download package: system.cfg from ISO
2017-05-25 22:19:05,086 - INFO: Received request to upload config file system.cfg to config
named vnf-pkg2
2017-05-25 22:19:05,087 - INFO: Uploaded file system.cfg to config named vnf-pkg2
2017-05-25 22:19:59,895 - INFO: Received request to upload ISO usp-5_1_0.iso
2017-05-25 22:19:59,895 - INFO: Saving ISO to /tmp/tmpWbdnxm/usp-5_1_.iso
2017-05-25 22:20:21,395 - INFO: Mounting ISO to /tmp/tmpWbdnxm/iso_mount
2017-05-25 22:20:22,288 - INFO: ISO version already installed, (5.1.0-662)
2017-05-25 22:20:23,203 - INFO: Received a request to list file names in config named
vnf-pkg2.
2017-05-25 22:20:23,203 - INFO: config contents are: system.cfg
2017-05-25 22:20:23,211 - INFO: Received a request to list file names in config named
vnf-pkg2-images.
2017-05-25 22:20:23,211 - INFO: config contents are:
2017-05-25 22:20:23,220 - INFO: Received request to get ISO details 5.1.0-662
2017-05-25 22:20:23,251 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:20:23,621 - INFO: Getting Host Aggregate failed: Aggregate

```

```
'auto-test-sjc-em-autovnf-mgmt2' not found on OpenStack setup
2017-05-25 22:20:23,633 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:20:24,301 - INFO: Deploying Host Aggregate 'auto-test-sjc-em-autovnf-mgmt2' completed
2017-05-25 22:20:24,313 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:20:24,843 - INFO: Getting Host Aggregate failed: Aggregate 'auto-test-sjc-service2' not found on OpenStack setup
2017-05-25 22:20:24,853 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:20:25,524 - INFO: Deploying Host Aggregate 'auto-test-sjc-service2' completed
2017-05-25 22:20:25,537 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:20:25,898 - INFO: Getting Host Aggregate failed: Aggregate 'auto-test-sjc-cf-esc-mgmt2' not found on OpenStack setup
2017-05-25 22:20:25,909 - INFO: Received a request to deploy an Host Aggregate
2017-05-25 22:20:26,540 - INFO: Deploying Host Aggregate 'auto-test-sjc-cf-esc-mgmt2' completed
2017-05-25 22:20:26,584 - INFO: Received a request to deploy AutoVnf
2017-05-25 22:20:31,604 - INFO: Creating AutoVnf deployment (3 instance(s)) on 'http://172.21.201.217:5000/v2.0' tenant 'core' user 'core', ISO '5.1.0-662'
2017-05-25 22:20:31,605 - INFO: Creating network 'auto-testautovnf2-uas-management'
2017-05-25 22:20:33,720 - INFO: Created network 'auto-testautovnf2-uas-management'
2017-05-25 22:20:33,720 - INFO: Creating network 'auto-testautovnf2-uas-orchestration'
2017-05-25 22:20:34,324 - INFO: Created network 'auto-testautovnf2-uas-orchestration'
2017-05-25 22:20:34,402 - INFO: Created flavor 'auto-testautovnf2-uas'
2017-05-25 22:20:34,402 - INFO: Loading image 'auto-testautovnf2-usp-uas-1.0.0-601.qcow2' from '/opt/cisco/usp/bundles/5.1.0-662/uas-bundle/usp-uas-1.0.0-601.qcow2'
2017-05-25 22:20:43,169 - INFO: Loaded image 'auto-testautovnf2-usp-uas-1.0.0-601.qcow2'
2017-05-25 22:20:43,169 - INFO: Creating volume 'auto-testautovnf2-uas-vol-0' with command

[ /opt/cisco/usp/apps/auto-it/vnf/../common/autoit/..../autoit_os_utils/scripts/autoit_volume_staging.sh
  OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
  http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
  auto-testautovnf2-uas-vol-0 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpelMIL/encrypted.cfg]
2017-05-25 22:20:54,713 - INFO: Created volume 'auto-testautovnf2-uas-vol-0'
2017-05-25 22:20:54,714 - INFO: Creating volume 'auto-testautovnf2-uas-vol-1' with command

[ /opt/cisco/usp/apps/auto-it/vnf/../common/autoit/..../autoit_os_utils/scripts/autoit_volume_staging.sh
  OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
  http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
  auto-testautovnf2-uas-vol-1 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpelMIL/encrypted.cfg]
2017-05-25 22:21:06,203 - INFO: Created volume 'auto-testautovnf2-uas-vol-1'
2017-05-25 22:21:06,204 - INFO: Creating volume 'auto-testautovnf2-uas-vol-2' with command

[ /opt/cisco/usp/apps/auto-it/vnf/../common/autoit/..../autoit_os_utils/scripts/autoit_volume_staging.sh
  OS_USERNAME core OS_TENANT_NAME core OS_PASSWORD **** OS_AUTH_URL
  http://172.21.201.217:5000/v2.0 ARG_TENANT core ARG_DEPLOYMENT test-uas ARG_VM_NAME
  auto-testautovnf2-uas-vol-2 ARG_VOLUME_TYPE LUKS FILE_1 /tmp/tmpelMIL/encrypted.cfg]
2017-05-25 22:21:18,184 - INFO: Created volume 'auto-testautovnf2-uas-vol-2'
2017-05-25 22:21:19,626 - INFO: Assigned floating IP '172.21.201.64' to IP '172.67.11.101'
2017-05-25 22:21:22,762 - INFO: Creating instance 'auto-testautovnf2-uas-0' and attaching volume 'auto-testautovnf2-uas-vol-0'
2017-05-25 22:21:49,741 - INFO: Created instance 'auto-testautovnf2-uas-0'
2017-05-25 22:21:49,742 - INFO: Creating instance 'auto-testautovnf2-uas-1' and attaching volume 'auto-testautovnf2-uas-vol-1'
2017-05-25 22:22:16,881 - INFO: Created instance 'auto-testautovnf2-uas-1'
2017-05-25 22:22:16,881 - INFO: Creating instance 'auto-testautovnf2-uas-2' and attaching volume 'auto-testautovnf2-uas-vol-2'
2017-05-25 22:22:43,304 - INFO: Created instance 'auto-testautovnf2-uas-2'
2017-05-25 22:22:43,304 - INFO: Deploy request completed
2017-05-25 22:28:08,865 - INFO: Received request to download file system.cfg from config named vnf-pkg2
2017-05-25 22:40:03,550 - INFO: Received request to download file system.cfg from config named vnf-pkg1
```

Example Termination Log:

Viewing AutoIT Logs

```

2017-05-25 22:53:30,970 - INFO: Received a request to destroy AutoVnf
2017-05-25 22:53:31,310 - INFO: Destroying AutoVnf deployment on
'http://172.21.201.217:5000/v2.0' tenant 'core' user 'core', ISO '5.1.0-662'
2017-05-25 22:53:32,698 - INFO: Removed floating IP '172.21.201.64'
2017-05-25 22:53:34,114 - INFO: 3 instance(s) found with name matching 'auto-testautovnf2'
2017-05-25 22:53:34,448 - INFO: Removing volume 'auto-testautovnf2-uas-vol-2'
2017-05-25 22:53:43,481 - INFO: Removed volume 'auto-testautovnf2-uas-vol-2'
2017-05-25 22:53:43,481 - INFO: Removing instance 'auto-testautovnf2-uas-2'
2017-05-25 22:53:47,080 - INFO: Removed instance 'auto-testautovnf2-uas-2'
2017-05-25 22:53:47,283 - INFO: Removing volume 'auto-testautovnf2-uas-vol-1'
2017-05-25 22:53:56,508 - INFO: Removed volume 'auto-testautovnf2-uas-vol-1'
2017-05-25 22:53:56,508 - INFO: Removing instance 'auto-testautovnf2-uas-1'
2017-05-25 22:54:00,290 - INFO: Removed instance 'auto-testautovnf2-uas-1'
2017-05-25 22:54:00,494 - INFO: Removing volume 'auto-testautovnf2-uas-vol-0'
2017-05-25 22:54:04,714 - INFO: Removed volume 'auto-testautovnf2-uas-vol-0'
2017-05-25 22:54:04,714 - INFO: Removing instance 'auto-testautovnf2-uas-0'
2017-05-25 22:54:11,647 - INFO: Removed instance 'auto-testautovnf2-uas-0'
2017-05-25 22:54:15,107 - INFO: 1 image(s) 'auto-testautovnf2-usp-uas-1.0.0-601.qcow2'
found, removing
2017-05-25 22:54:19,289 - INFO: Removed network 'auto-testautovnf2-uas-management'
2017-05-25 22:54:20,463 - INFO: Removed network 'auto-testautovnf2-uas-orchestration'
2017-05-25 22:54:20,541 - INFO: Removed flavor 'auto-testautovnf2-uas'
2017-05-25 22:54:20,541 - INFO: Destroy request completed
2017-05-25 22:54:20,562 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:54:20,925 - INFO: Getting Host Aggregate 'auto-test-sjc-em-autovnf-mgmt2'
completed
2017-05-25 22:54:20,940 - INFO: Received a request to destroy an Host Aggregate
2017-05-25 22:54:21,564 - INFO: Destroying Host Aggregate 'auto-test-sjc-em-autovnf-mgmt2'
completed
2017-05-25 22:54:21,575 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:54:21,930 - INFO: Getting Host Aggregate 'auto-test-sjc-service2' completed
2017-05-25 22:54:21,947 - INFO: Received a request to destroy an Host Aggregate
2017-05-25 22:54:22,456 - INFO: Destroying Host Aggregate 'auto-test-sjc-service2' completed
2017-05-25 22:54:22,468 - INFO: Received a request to get an Host Aggregate details
2017-05-25 22:54:22,826 - INFO: Getting Host Aggregate 'auto-test-sjc-cf-esc-mgmt2' completed
2017-05-25 22:54:22,840 - INFO: Received a request to destroy an Host Aggregate
2017-05-25 22:54:23,394 - INFO: Destroying Host Aggregate 'auto-test-sjc-cf-esc-mgmt2'
completed
2017-05-25 22:56:55,925 - INFO: Received a request to destroy AutoVnf
2017-05-25 22:56:56,391 - INFO: Destroying AutoVnf deployment on
'http://172.21.201.217:5000/v2.0' tenant 'core' user 'core', ISO '5.1.0-662'
2017-05-25 22:56:57,507 - INFO: Removed floating IP '172.21.201.59'
2017-05-25 22:56:58,614 - INFO: 3 instance(s) found with name matching 'auto-testautovnf1'
2017-05-25 22:56:58,949 - INFO: Removing volume 'auto-testautovnf1-uas-vol-2'
2017-05-25 22:57:08,166 - INFO: Removed volume 'auto-testautovnf1-uas-vol-2'
2017-05-25 22:57:08,166 - INFO: Removing instance 'auto-testautovnf1-uas-2'
2017-05-25 22:57:15,117 - INFO: Removed instance 'auto-testautovnf1-uas-2'
2017-05-25 22:57:15,323 - INFO: Removing volume 'auto-testautovnf1-uas-vol-1'
2017-05-25 22:57:24,501 - INFO: Removed volume 'auto-testautovnf1-uas-vol-1'
2017-05-25 22:57:24,502 - INFO: Removing instance 'auto-testautovnf1-uas-1'
2017-05-25 22:57:28,275 - INFO: Removed instance 'auto-testautovnf1-uas-1'
2017-05-25 22:57:28,722 - INFO: Removing volume 'auto-testautovnf1-uas-vol-0'
2017-05-25 22:57:37,702 - INFO: Removed volume 'auto-testautovnf1-uas-vol-0'
2017-05-25 22:57:37,703 - INFO: Removing instance 'auto-testautovnf1-uas-0'
2017-05-25 22:57:44,622 - INFO: Removed instance 'auto-testautovnf1-uas-0'
2017-05-25 22:57:47,921 - INFO: 1 image(s) 'auto-testautovnf1-usp-uas-1.0.0-601.qcow2'
found, removing
2017-05-25 22:57:52,453 - INFO: Removed network 'auto-testautovnf1-uas-management'
2017-05-25 22:57:53,677 - INFO: Removed network 'auto-testautovnf1-uas-orchestration'
2017-05-25 22:57:53,760 - INFO: Removed flavor 'auto-testautovnf1-uas'
2017-05-25 22:57:53,760 - INFO: Destroy request completed

```

Viewing AutoIT Operational Data

View the AutoIT operational data by executing the following command:

```
show uas
```

Example show uas Command Output

```
uas version          6.0.0
uas state           active
uas external-connection-point 172.28.185.132
INSTANCE IP      STATE   ROLE
-----
172.28.185.133  alive    CONFD-MASTER
172.28.185.134  alive    CONFD-SLAVE

NAME            LAST HEARTBEAT
-----
AutoIT-MASTER   2018-01-24 21:24:30
USPCFMWorker   2018-01-24 21:24:30
USPCHBWorker   2018-01-24 21:24:30
USPCWorker     2018-01-24 21:24:30
```



Important In case of standalone mode (non-HA) deployments, the *uas external-connection-point* information and *Instance IP* table are not applicable and are not displayed.

Checking AutoIT Processes

Verify that key processes are running on the AutoIT VM:

With Ubuntu 14.04:

```
service autoit status
```

Example output:

```
AutoIT is running.
```

Check ConfD.

```
service uas-confd status
```

Monitoring AutoVNF Operations

This section identifies various commands that can be used to determine the status and health of AutoVNF.

To use them, you must:

1. Log on to the AutoVNF VM as *ubuntu*. Use the password that was created earlier for this user.
2. Become the root user.

```
sudo -i
```

Viewing AutoVNF Logs

General AutoVNF Logs

AutoVNF logs are available on the AutoVNF VM in the following file:

```
/var/log/upstart/autovnf.log
```

To collect AutoVNF logs:

1. Navigate to the *scripts* directory.

```
cd /opt/cisco/usp/uas/scripts
```

2. Launch the *collect-uas-logs.sh* script to collect the logs.

```
sudo ./collect-uas-logs.sh
```

Example log output:

```
Creating log tarball uas-logs-2017-05-26_00.24.55_UTC.tar.bz2 ...
uas-logs/
uas-logs/autovnf/
uas-logs/autovnf/autovnf_server.log
uas-logs/autovnf/a15bf26c-41a1-11e7-b3ab-fa163eccafffc/
uas-logs/autovnf/a15bf26c-41a1-11e7-b3ab-fa163eccafffc/netconf_traces
uas-logs/autovnf/a15bf26c-41a1-11e7-b3ab-fa163eccafffc/vnfd
uas-logs/autovnf/audit.log
uas-logs/autovnf/579b4546-41a2-11e7-b3ab-fa163eccafffc/
uas-logs/autovnf/579b4546-41a2-11e7-b3ab-fa163eccafffc/netconf_traces
uas-logs/autovnf/579b4546-41a2-11e7-b3ab-fa163eccafffc/vnfd
uas-logs/ha/
uas-logs/ha/info.log
uas-logs/uas_manager/
uas-logs/uas_manager/info.log
uas-logs/zk/
uas-logs/zk/zookeeper.out
uas-logs/zk/zookeeper.log
uas-logs/upstart/
uas-logs/upstart/uas-confd.log
uas-logs/upstart/zk.log
uas-logs/upstart/autovnf.log
uas-logs/upstart/uws-ae.log
uas-logs/upstart/ensemble.log

=====
 Tarball available at: /tmp/uas-logs-2017-05-26_00.24.55_UTC.tar.bz2
=====

To extract the tarball, run: "tar jxf /tmp/uas-logs-2017-05-26_00.24.55_UTC.tar.bz2"
```

AutoVNF Transaction Logs

AutoVNF server and transaction logs are available on the Ultra M Manager Node in the following directory on the UAS VM:

```
/var/log/cisco-uas/autovnf
```

Inside this directory are transaction sub-directories, VNFD information and NETCONF traces are provided for the given transaction.

Example:

```

total 3568
drwxr-xr-x 4 root root    4096 May 25 23:31 .
drwxr-xr-x 7 root root    4096 May 25 19:39 ../
drwxr-xr-x 2 root root    4096 May 25 23:31 579b4546-41a2-11e7-b3ab-fa163eccaffc/
drwxr-xr-x 2 root root    4096 May 25 23:29 a15bf26c-41a1-11e7-b3ab-fa163eccaffc/
-rw-r--r-- 1 root root 3632813 May 26 18:33 audit.log
-rw-r--r-- 1 root root      0 May 25 23:26 autovnf_server.log

cd a15bf26c-41a1-11e7-b3ab-fa163eccaffc
total 2568
drwxr-xr-x 2 root root    4096 May 25 23:29 .
drwxr-xr-x 4 root root    4096 May 25 23:31 ../
-rw-r--r-- 1 root root 2614547 May 25 23:37 netconf_traces
-rw-r--r-- 1 root root      0 May 25 23:29 vnfd

```

AutoVNF Event Logs

Event logs provide useful information on UAS task progress. These logs are located in the *autovnf.log* file within the following directory on the UAS VM:

/var/log/upstart

Event logs are filed by transaction ID. To view transaction IDs:

1. Login to the ConfD CLI as the *admin* user.

confd_cli -u admin -C

2. List the transactions.

show transactions

Example output:

| TX ID | TX TYPE | DEPLOYMENT ID | TIMESTAMP |
|--------------------------------------|--------------------|--------------------|-----------|
| STATUS | | | |
| 562c18b0-4199-11e7-ad05-fa163ec6a7e4 | vnf-deployment | vnfd2-deployment | |
| 2017-05-25T22:27:28.962293-00:00 | deployment-success | | |
| abf51428-4198-11e7-ad05-fa163ec6a7e4 | vnmf-deployment | ab-auto-test-vnfm2 | |
| 2017-05-25T22:22:43.389059-00:00 | deployment-success | | |

To view the logs associated with a specific transaction:

show log <transaction_id> | display xml

Example log pertaining to VNFM deployment:

```

<config xmlns="http://tail-f.com/ns/config/1.0">
  <logs xmlns="http://www.cisco.com/usp/nfv/usp-autovnf-oper">
    <tx-id>abf51428-4198-11e7-ad05-fa163ec6a7e4</tx-id>
    <log>2017-05-25 22:22:43,402 - VNFM Deployment RPC triggered for deployment:
ab-auto-test-vnfm2, deactivate: 0
2017-05-25 22:22:43,446 - Notify deployment
2017-05-25 22:22:43,472 - VNFM Transaction: abf51428-4198-11e7-ad05-fa163ec6a7e4 for
deployment: ab-auto-test-vnfm2 started
2017-05-25 22:22:43,497 - Downloading Image:
http://172.21.201.63:80/bundles/5.1.0-662/vnfm-bundle/ESC-2_3_2_143.qcow2
2017-05-25 22:22:49,146 - Image: //opt/cisco/vnf-staging/vnfm_image downloaded
successfully
2017-05-25 22:22:49,714 - Checking network 'public' existence
2017-05-25 22:22:49,879 - Checking flavor 'ab-auto-test-vnfm2-ESC-flavor' non existence
2017-05-25 22:22:50,124 - Checking image 'ab-auto-test-vnfm2-ESC-image' non existence
2017-05-25 22:22:50,598 - Checking network 'auto-testautovnf2-uas-management' existence
2017-05-25 22:22:50,752 - Checking network 'auto-testautovnf2-uas-orchestration' existence

```

AutoVNF Event Logs

```

2017-05-25 22:22:50,916 - Checking instance 'ab-auto-test-vnfm2-ESC-0' non existence
2017-05-25 22:22:51,357 - Checking instance 'ab-auto-test-vnfm2-ESC-1' non existence
2017-05-25 22:22:52,084 - Creating flavor 'ab-auto-test-vnfm2-ESC-flavor'
2017-05-25 22:22:52,184 - Loading image 'ab-auto-test-vnfm2-ESC-image' from
'//opt/cisco/vnf-staging/vnfm_image'...
2017-05-25 22:23:06,444 - ESC HA mode is ON
2017-05-25 22:23:07,118 - Allocated these IPs for ESC HA: ['172.67.11.3', '172.67.11.4',
'172.67.11.5']
2017-05-25 22:23:08,228 - Creating VNFM 'ab-auto-test-vnfm2-ESC-0' with [python
//opt/cisco/vnf-staging/bootvm.py ab-auto-test-vnfm2-ESC-0 --flavor
ab-auto-test-vnfm2-ESC-flavor --image b29e7a72-9ad0-4178-aa35-35df0a2b23b7 --net
auto-testautovnf2-uas-management --gateway_ip 172.67.11.1 --net
auto-testautovnf2-uas-orchestration
--os_auth_url http://172.21.201.217:5000/v2.0 --os_tenant_name core --os_username *****
--os_password ***** --bs_os_auth_url http://172.21.201.217:5000/v2.0 --bs_os_tenant_name
core --bs_os_username ***** --bs_os_password ***** --esc_ui_startup false
--esc_params_file /tmp/esc_params.cfg --encrypt_key ***** --user_pass *****
--user_confd_pass ***** --kad_vif eth0 --kad_vip 172.67.11.5 --ipaddr 172.67.11.3 dhcp
--ha_node_list 172.67.11.3 172.67.11.4 --file
root:0755:/opt/cisco/esc/esc-scripts/esc_volume_em_staging.sh:
/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_volume_em_staging.sh
--file
root:0755:/opt/cisco/esc/esc-scripts/esc_vpc_chassis_id.py:/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_vpc_chassis_id.py
--file
root:0755:/opt/cisco/esc/esc-scripts/esc_vpc_di_internal_keys.sh:/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_vpc_di_internal_keys.sh]...
2017-05-25 22:24:13,329 - ESC started!
2017-05-25 22:24:13,803 - Creating VNFM 'ab-auto-test-vnfm2-ESC-1' with [python
//opt/cisco/vnf-staging/bootvm.py ab-auto-test-vnfm2-ESC-1 --flavor
ab-auto-test-vnfm2-ESC-flavor --image b29e7a72-9ad0-4178-aa35-35df0a2b23b7 --net
auto-testautovnf2-uas-management --gateway_ip 172.67.11.1 --net
auto-testautovnf2-uas-orchestration
--os_auth_url http://172.21.201.217:5000/v2.0 --os_tenant_name core --os_username *****
--os_password ***** --bs_os_auth_url http://172.21.201.217:5000/v2.0 --bs_os_tenant_name
core --bs_os_username ***** --bs_os_password ***** --esc_ui_startup false
--esc_params_file /tmp/esc_params.cfg --encrypt_key ***** --user_pass *****
--user_confd_pass ***** --kad_vif eth0 --kad_vip 172.67.11.5 --ipaddr 172.67.11.4 dhcp
--ha_node_list 172.67.11.3 172.67.11.4
--file
root:0755:/opt/cisco/esc/esc-scripts/esc_volume_em_staging.sh:
/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_volume_em_staging.sh --file
root:0755:/opt/cisco/esc/esc-scripts/esc_vpc_chassis_id.py:/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_vpc_chassis_id.py
--file
root:0755:/opt/cisco/esc/esc-scripts/esc_vpc_di_internal_keys.sh:/opt/cisco/usp/uas/autovnf/vnfms/esc-scripts/esc_vpc_di_internal_keys.sh]...
2017-05-25 22:25:12,660 - ESC started!
2017-05-25 22:25:12,677 - Waiting for VIM to declare 2 instance(s) active
2017-05-25 22:25:18,254 - Instance(s) are active
2017-05-25 22:25:18,271 - Waiting for VNFM to be ready...
2017-05-25 22:25:18,292 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:25:21,313 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:25:31,341 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:25:31,362 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:25:41,379 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:25:41,397 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:25:51,424 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:25:51,495 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:26:01,521 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:01,539 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:26:11,563 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:11,591 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:26:21,617 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:21,635 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:26:31,662 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:31,680 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:26:41,706 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:41,726 - Could not establish NETCONF session to 172.67.11.5

```

```

2017-05-25 22:26:51,748 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:26:51,765 - Could not establish NETCONF session to 172.67.11.5
2017-05-25 22:27:01,791 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:27:02,204 - NETConf Sessions (Transaction/Notifications) established
2017-05-25 22:27:02,507 - Notify VNFM Up
2017-05-25 22:27:02,525 - VNFM Transaction: abf51428-4198-11e7-ad05-fa163ec6a7e4 for
deployment: ab-auto-test-vnfm2 completed successfully.
2017-05-25 22:27:02,545 - Notify deployment</log>
    </logs>
</config>

```

Example log pertaining to VNF deployment:

```

<config xmlns="http://tail-f.com/ns/config/1.0">
    <logs xmlns="http://www.cisco.com/usp/nfv/usp-autovnf-oper">
        <tx-id>562c18b0-4199-11e7-ad05-fa163ec6a7e4</tx-id>
        <log>2017-05-25 22:27:29,039 - Notify deployment
2017-05-25 22:27:29,062 - Connection to VNFM (esc) at 172.67.11.5
2017-05-25 22:27:29,404 - NETConf Sessions (Transaction/Notifications) established
2017-05-25 22:27:29,420 - Get Images
2017-05-25 22:27:29,435 - NETCONF get-config Request sent, waiting for reply
2017-05-25 22:27:29,560 - NETCONF Transaction success!
2017-05-25 22:27:29,570 - Get Flavors List
2017-05-25 22:27:29,582 - Adding images ...
2017-05-25 22:27:29,592 - Creating Images
2017-05-25 22:27:29,603 -     image: ab-auto-test-vnfm2-element-manager
2017-05-25 22:27:29,620 -         src:
http://172.21.201.63:80/bundles/5.1.0-662/em-bundle/em-1_0_0_532.qcow2
2017-05-25 22:27:29,630 -         disk_format: qcow2
2017-05-25 22:27:29,641 -         container_format: bare
2017-05-25 22:27:29,655 -         serial_console: True
2017-05-25 22:27:29,665 -         disk_bus: virtio
2017-05-25 22:27:29,674 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:27:29,901 - NETCONF Transaction success!
2017-05-25 22:27:29,911 - Waiting for VNFM to process CREATE_IMAGE transaction
2017-05-25 22:27:46,987 - | CREATE_IMAGE | ab-auto-test-vnfm2-element-manager | SUCCESS
| (1/1)
2017-05-25 22:27:47,004 - NETCONF transaction completed successfully!
2017-05-25 22:27:47,749 - Creating Images
2017-05-25 22:27:47,764 -     image: ab-auto-test-vnfm2-control-function
2017-05-25 22:27:47,776 -         src:
http://172.21.201.63:80/bundles/5.1.0-662/ugp-bundle/qvpc-di-cf.qcow2
2017-05-25 22:27:47,793 -         disk_format: qcow2
2017-05-25 22:27:47,805 -         container_format: bare
2017-05-25 22:27:47,819 -         serial_console: True
2017-05-25 22:27:47,831 -         disk_bus: virtio
2017-05-25 22:27:47,841 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:27:48,317 - NETCONF Transaction success!
2017-05-25 22:27:48,331 - Waiting for VNFM to process CREATE_IMAGE transaction
2017-05-25 22:27:56,403 - | CREATE_IMAGE | ab-auto-test-vnfm2-control-function | SUCCESS
| (1/1)
2017-05-25 22:27:56,434 - NETCONF transaction completed successfully!
2017-05-25 22:27:56,822 - Creating Images
2017-05-25 22:27:56,838 -     image: ab-auto-test-vnfm2-session-function
2017-05-25 22:27:57,267 -         src:
http://172.21.201.63:80/bundles/5.1.0-662/ugp-bundle/qvpc-di-sf.qcow2
2017-05-25 22:27:57,412 -         disk_format: qcow2
2017-05-25 22:27:57,423 -         container_format: bare
2017-05-25 22:27:57,523 -         serial_console: True
2017-05-25 22:27:57,535 -         disk_bus: virtio
2017-05-25 22:27:57,550 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:27:58,378 - NETCONF Transaction success!
2017-05-25 22:27:58,391 - Waiting for VNFM to process CREATE_IMAGE transaction
2017-05-25 22:28:06,339 - | CREATE_IMAGE | ab-auto-test-vnfm2-session-function | SUCCESS
| (1/1)

```

AutoVNF Event Logs

```

2017-05-25 22:28:06,355 - NETCONF transaction completed successfully!
2017-05-25 22:28:06,367 - Images added successfully
2017-05-25 22:28:06,378 - Creating flavors ...
2017-05-25 22:28:06,388 - Creating flavors
2017-05-25 22:28:06,432 - flavor: ab-auto-test-vnfm2-element-manager
2017-05-25 22:28:06,444 - vcpus: 2
2017-05-25 22:28:06,457 - memory_mb: 4096
2017-05-25 22:28:06,469 - root_disk_mb: 40960
2017-05-25 22:28:06,481 - ephemeral_disk_mb: 0
2017-05-25 22:28:06,491 - swap_disk_mb: 0
2017-05-25 22:28:06,505 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:28:06,781 - NETCONF Transaction success!
2017-05-25 22:28:06,793 - Waiting for VNFM to process CREATE_FLAVOR transaction
2017-05-25 22:28:07,286 - | CREATE_FLAVOR | ab-auto-test-vnfm2-element-manager | SUCCESS
| (1/1)
2017-05-25 22:28:07,298 - NETCONF transaction completed successfully!
2017-05-25 22:28:07,310 - Creating flavors
2017-05-25 22:28:07,328 - flavor: ab-auto-test-vnfm2-control-function
2017-05-25 22:28:07,341 - vcpus: 8
2017-05-25 22:28:07,358 - memory_mb: 16384
2017-05-25 22:28:07,374 - root_disk_mb: 6144
2017-05-25 22:28:07,386 - ephemeral_disk_mb: 0
2017-05-25 22:28:07,398 - swap_disk_mb: 0
2017-05-25 22:28:07,410 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:28:07,586 - NETCONF Transaction success!
2017-05-25 22:28:07,603 - Waiting for VNFM to process CREATE_FLAVOR transaction
2017-05-25 22:28:07,818 - | CREATE_FLAVOR | ab-auto-test-vnfm2-control-function | SUCCESS
| (1/1)
2017-05-25 22:28:07,830 - NETCONF transaction completed successfully!
2017-05-25 22:28:07,842 - Creating flavors
2017-05-25 22:28:07,853 - flavor: ab-auto-test-vnfm2-session-function
2017-05-25 22:28:07,865 - vcpus: 8
2017-05-25 22:28:07,877 - memory_mb: 16384
2017-05-25 22:28:07,889 - root_disk_mb: 6144
2017-05-25 22:28:07,901 - ephemeral_disk_mb: 0
2017-05-25 22:28:07,917 - swap_disk_mb: 0
2017-05-25 22:28:07,928 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:28:08,204 - NETCONF Transaction success!
2017-05-25 22:28:08,216 - Waiting for VNFM to process CREATE_FLAVOR transaction
2017-05-25 22:28:08,455 - | CREATE_FLAVOR | ab-auto-test-vnfm2-session-function | SUCCESS
| (1/1)
2017-05-25 22:28:08,473 - NETCONF transaction completed successfully!
2017-05-25 22:28:08,489 - Flavors created successfully
2017-05-25 22:28:08,501 - Onboarding configuration file: ('control-function',
'staros_config.txt', 'http://172.21.201.63:5001/configs/vnf-pkg2/files/system.cfg')
2017-05-25 22:28:08,547 - NETCONF get-operational Request sent, waiting for reply
2017-05-25 22:28:08,724 - NETCONF Transaction success!
2017-05-25 22:28:08,855 - Notify VDU Create Catalog for : element-manager, status:
SUCCESS, txid: 562c18b0-4199-11e7-ad05-fa163ec6a7e4
2017-05-25 22:28:08,892 - Notify VDU Create Catalog for : control-function, status:
SUCCESS, txid: 562c18b0-4199-11e7-ad05-fa163ec6a7e4
2017-05-25 22:28:09,008 - Notify VDU Create Catalog for : session-function, status:
SUCCESS, txid: 562c18b0-4199-11e7-ad05-fa163ec6a7e4
2017-05-25 22:28:09,024 - NETCONF get-config Request sent, waiting for reply
2017-05-25 22:28:09,151 - NETCONF Transaction success!
2017-05-25 22:28:14,837 - Deployment: vnfd2-deployment started ...
2017-05-25 22:28:14,858 - Generating VNFD
2017-05-25 22:28:14,930 - VNFD generated successfully.
2017-05-25 22:28:14,966 - Generating configuration files for EM
2017-05-25 22:28:14,979 - Creating VIP Ports
2017-05-25 22:28:16,970 - VIP ports created successfully
2017-05-25 22:28:16,987 - Deploying EM
2017-05-25 22:28:17,000 - Added anti-affinity placement policy for ab-auto-test-vnfm2-em-1
2017-05-25 22:28:17,012 - Added anti-affinity placement policy for ab-auto-test-vnfm2-em-2

```

```

2017-05-25 22:28:17,025 - Added anti-affinity placement policy for ab-auto-test-vnfm2-em-3
2017-05-25 22:28:17,041 - Starting Service Deployment: ab-auto-test-vnfm2-em
2017-05-25 22:28:17,054 - Start VM: ab-auto-test-vnfm2-em-1
2017-05-25 22:28:17,066 - Start VM: ab-auto-test-vnfm2-em-2
2017-05-25 22:28:17,077 - Start VM: ab-auto-test-vnfm2-em-3
2017-05-25 22:28:17,089 - NETCONF edit-config Request sent, waiting for reply
2017-05-25 22:28:17,721 - NETCONF Transaction success!
2017-05-25 22:28:17,733 - Waiting for VNFM to process SERVICE_ALIVE transaction
2017-05-25 22:29:37,185 - | VM_DEPLOYED | ab-auto-test-vnfm2-em-1 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:29:59,679 - | VM_ALIVE | ab-auto-test-vnfm2-em-1 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:30:42,170 - | VM_DEPLOYED | ab-auto-test-vnfm2-em-2 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:30:59,620 - | VM_ALIVE | ab-auto-test-vnfm2-em-2 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:31:51,510 - | VM_DEPLOYED | ab-auto-test-vnfm2-em-3 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:32:13,584 - | VM_DEPLOYED | c2 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:32:29,639 - | VM_ALIVE | ab-auto-test-vnfm2-em-3 | SUCCESS | Waiting for: SERVICE_ALIVE|
2017-05-25 22:32:29,661 - | SERVICE_ALIVE | ab-auto-test-vnfm2-em | SUCCESS | (1/1)
2017-05-25 22:32:29,674 - NETCONF transaction completed successfully!
2017-05-25 22:32:29,687 - EM Online !
2017-05-25 22:32:29,699 - HA-VIP[element-manager] : 172.67.11.12
2017-05-25 22:32:29,716 - HA-VIP[control-function] : 172.67.11.13
2017-05-25 22:32:29,729 - Deployment: vnfd2-deployment completed successfully.
2017-05-25 22:32:29,742 - NETCONF get-operational Request sent, waiting for reply
2017-05-25 22:32:30,221 - NETCONF Transaction success!
2017-05-25 22:32:30,261 - Notify EM Up
2017-05-25 22:32:30,274 - VNF Transaction completed successfully!
2017-05-25 22:32:30,292 - Notify deployment</log>
</logs>
</config>

```

Viewing AutoVNF Operational Data

AutoVNF maintains history information for all transactions, associated events, and related error/information logs in persistent storage. These logs are useful for monitoring deployment progress and for troubleshooting issues.

These logs can be retrieved at time using the “task-id” returned as well as by running Confd “show” commands.

To access these commands, you must be logged in to the Confd CLI as the *admin* user on the AutoVNF VM:

confd_cli -u admin -c

Table 2: Confd Log Descriptions, on page 47 provides a list of the available commands and describes the information in the output.

Table 2: Confd Log Descriptions

| Confd Command | Purpose |
|---|--|
| In releases prior to 6.0: show autovnf-oper:errors In 6.0 and later releases: show uas | Displays a list of any deployment errors that may have occurred. |

Viewing AutoVNF Operational Data

| ConfD Command | Purpose |
|---|---|
| In releases prior to 6.0: show autovnf-oper:logs display xml In 6.0 and later releases: show log display xml | Displays log messages for AutoVNF transactions. |
| In releases prior to 6.0: show autovnf-oper:network-catalog In 6.0 and later releases: show vnf-packager | Displays information for the networks deployed with USP. |
| In releases prior to 6.0: show autovnf-oper:transactions In 6.0 and later releases: show transaction | Displays a list of transaction IDs that correspond to the USP deployment along with their execution date, time, and status. |
| In releases prior to 6.0: show autovnf-oper:vdu-catalog In 6.0 and later releases: show vnfr | Displays information pertaining to the virtual descriptor units (VDUs) used to deploy USP. |
| In releases prior to 6.0: show autovnf-oper:vip-port In 6.0 and later releases: show vnfr | Displays information port, network, and virtual IP addresses information. |
| In releases prior to 6.0: show autovnf-oper:vnfm In 6.0 and later releases: show vnfr | Displays information pertaining to the VNFM deployment and UEM VM deployment. |
| show confd-state | Displays information pertaining to confd-state on AutoVNF. |
| show confd-state ha | Displays information pertaining to HA specific confd-state on AutoVNF. |
| show log <transaction_id> | Displays detailed log information for a specific transaction ID. |
| show running-config | Displays the configuration running on the AutoVNF. |
| show uas | Displays information pertaining to the AutoVNF VM deployment. |

| ConfD Command | Purpose |
|--|---|
| In releases prior to 6.0: show usp In 6.0 and later releases: show vnfr | Displays information pertaining to the overall USP VM deployment. |

NOTES:

- Log information can be saved out of ConfD to a file for later retrieval using one of the following commands:

```
show log transaction_id | save url
```

OR

```
show autovnf-oper: command | save url
```

Where *transaction_id* is a specific ID, *url* is a valid directory path, and *command* is one of the command operators identified in [Table 2: ConfD Log Descriptions, on page 47](#).

Example show confd-state Command Output

```
show confd-state

confd-state version 6.3.1
confd-state epoll false
confd-state daemon-status started
confd-state ha mode master
confd-state ha node-id confd-master
confd-state ha connected-slave [ a2dd5178-afae-4b3a-8b2b-910216583501 ]

          EXPORTED
NAME           REVISION      NAMESPACE
PREFIX         TO ALL      EXPORTED TO
_____
iana-crypt-hash      2014-08-06 urn:ietf:params:xml:ns:yang:iana-crypt-hash
    ianach        X      -
ietf-inet-types      2013-07-15 urn:ietf:params:xml:ns:yang:ietf-inet-types
    inet          X      -
ietf-netconf-acm      2012-02-22 urn:ietf:params:xml:ns:yang:ietf-netconf-acm
    nacm          X      -
ietf-netconf-monitoring 2010-10-04 urn:ietf:params:xml:ns:yang:ietf-netconf-monitoring
    ncm            X      -
<-- SNIP -->
```

Example show confd-state ha Command Output

```
show confd-state ha

confd-state ha mode master
confd-state ha node-id confd-master
confd-state ha connected-slave [ a2dd5178-afae-4b3a-8b2b-910216583501 ]
```

Example show log Command Output

```
show log <transaction_id> | display xml
```

Example show running-config Command Output**Example show running-config Command Output**

```

show running-config

<-- SNIP -->
autovnf:secure-token autovnf-admin
  user      $8$YQiswhu0QLpA4N2kBo7t5eZN2uUW0L19m8WaaBzkVoc=
  password $8$mSaszfxjZ8My8Y/FqLL3Sasn1b/DmRh3pdblatq49cM=
!
autovnf:secure-token autovnf-oper
  user      $8$kTEQZ4YNdV6BcnH3ggRHJPmhk6lsh5KQFqhsQnh/KV8=
  password $8$KdTBD7ZeYuHrpdkLk5m888ckE3ZGIM7RbEMJwMwCjfo=
!
autovnf:secure-token em-login
  user      $8$jVDkSMi/WlXzkZj/qx07kEfHB9PlpPlnzCKUSjWiPXA=
  password $8$52ELrKMlGT/nad5WcPgUh7cijHiizAt8A8Tly79Q/I=
!
autovnf:secure-token confd-auth
  user      $8$bHYvP179/h1GWO8qoTnJFmm8A1Hqq1REsasX+GlSAPw=
  password $8$S52APq1vb9WhLjbSPNSWiBmAmaG1tzTTmSkktKs8reo=
!
volume-catalog em-volume
  volume type LUKS
  volume size 1024
  volume bus ide
  volume bootable false
!
volume-catalog cf-boot
  volume type LUKS
  volume size 16
  volume bus ide
  volume bootable true
!
volume-catalog cf-cdr
  volume type LUKS
  volume size 200
  volume bus ide
  volume bootable false
!
autovnf:network-catalog di-internal1
  pre-created di-internal1
  type      sriov-flat
  physnet   phys_pciei_0
  ip-prefix 192.168.1.0/24
  dhcp      true
  vlan-tag  true
  vlan      2110
<-- SNIP -->

<-- SNIP -->
autovnf:vdu-catalog control-function
  ha-type          one-to-one
  health-check-frequency 10
  health-probe-max-miss 6
  recovery-type    recovery-restart
  image location http://172.21.201.63:80/bundles/5.1.0-662/ugp-bundle/qvpc-di-cf.qcow2
  neds netconf
    ned-id        cisco-staros-nc
    port-number   830
    authentication confd-auth
!
  volumes cf-cdr
!
  volumes cf-boot

```

```
!
flavor host-aggregate    auto-test-sjc-cf-esc-mgmt1
flavor vcpus              8
flavor ram                16384
flavor root-disk          6
flavor ephemeral-disk    0
flavor swap-disk          0
flavor anti-affinity-placement true
configuration staros_config.txt
apply-at      day-zero
source-url http://172.21.201.63:5001/configs/vnf-pkg1/files/system.cfg
<-- SNIP -->
```

Example show uas Command Output

```
show uas
uas version          6.0.0
uas state            active
uas external-connection-point 50.50.50.67 INSTANCE
IP      STATE   ROLE
-----
10.2.3.6  alive   CONFD-MASTER
10.2.3.11 alive   CONFD-SLAVE

NAME                  LAST HEARTBEAT
-----
AutoVNF-MASTER        2018-01-20 02:35:03
ESCHearBeatMonitor-fremont-autovnf-vpc 2018-01-20 02:35:00
USPCFMWorker          2018-01-20 02:34:51
USPCHBWorker          2018-01-20 02:35:00
USPCWorker            2018-01-20 02:35:00
```



Important In this example, 10.2.3.6 is the confd-master and the active UAS VM.



Important In case of standalone mode (non-HA) deployments, the *uas external-connection-point* information and *Instance IP* table are not applicable and are not displayed.

Example output that shows the floating IP for AutoVNF:

```
-SNIP-
nsd autoit
vim-identity vim1
vim-artifact vim_artifact_one
vnfd-package [ usp_5_7 ]
vld mgmt
  vl-type      management
  network-instance bmarconi-management
!
vld orch
  vl-type orchestration
  network sjc-orch
!
vnfd f-autovnf
  vnfd-type      usp-uas
  version        6.0
  high-availability true
  nsd           fremont-autovnf
```

Example show vnfr Command Output

```

configuration boot-time 1800
configuration set-vim-instance-name true
external-connection-point avf
  connection-point eth0
    floating-ip enabled
    floating-ip external-network public
!
vnfc avf
  health-check disabled
  health-check boot-time 300
vdu vdu-id autovnf
  connection-point eth0
    virtual-link service-vl mgmt
  !
  connection-point eth1
    virtual-link service-vl orch
  !
!
!
!
-SNIP-

```

The current version of AutoVNF software can also be seen through the USP UWS – AutoVNF User Interface under –

- the Site Overview screen (Service Deployment > Site) only if the AutoVNF configuration type is a record.
- the Auto-Vnf Configuration Overview screen only if the AutoVNF configuration type is a record.
- the UWS – AutoVNF dashboard.

Example show vnfr Command Output

```

show vnfr

vnfr sj-autovnf-esc
  vnfd      esc
  vnf-type esc
  state     deployed
  external-connection-point esc
    connection-point-instance-id sj-autovnf-esc-ha-vip
    virtual-link-ref          uas-management
    ip-address                12.12.12.40
    mac-address               fa:16:3e:6a:db:9b
    connection-point-type     virtual-port
    port-id                  37a14e07-52f7-48c0-9dbb-471146a709a5
  vdu esc
    vnfc-instance sj-autovnf-esc-esc-1
      state     deployed
      vnfc      esc
      flavor-key sj-autovnf-esc
      uuid      83f44e0f-380e-4320-a35a-34de82cf84dd
      image name /vnfm-bundle/ESC-4_2_0_74.qcow2
      image version "Version: 4.2.0.74, SHA1: de45b53, Date: Sat Sep 01 08:51:12 EDT 2018"
      image package usp_6_0
      image uuid c35c2a86-6d60-4259-85cc-d023803c7245
      host       tb2-compute-15.localdomain
      vdu-type   cisco-esc
      connection-point-instance eth0
        virtual-link-ref      uas-management
        ip-address            12.12.12.22
        mac-address           fa:16:3e:e8:d6:b1
        connection-point-type virtual-port

```

```

port-id          f0f6b82f-336f-4f9f-aae5-d581be8cfa63
connection-point-instance eth1
virtual-link-ref uas-orchestration
ip-address      22.22.22.27
mac-address     fa:16:3e:16:32:4c
connection-point-type virtual-port
port-id          f2b7aaee-83f1-4f83-b45e-f92b3a1f6600
vnfc-instance sj-autovnf-esc-esc-2
state           deployed
vnfc            esc
flavor-key     sj-autovnf-esc-esc
uuid            087a5b48-db45-4002-a157-51fa37236545
image name     /vnfm-bundle/ESC-4_2_0_74.qcow2
image version "Version: 4.2.0.74, SHA1: de45b53, Date: Sat Sep 01 08:51:12 EDT 2018"
image package usp_6_0
image uuid    c35c2a86-6d60-4259-85cc-d023803c7245
host            tb2-compute-12.localdomain
vdu-type       cisco-esc
connection-point-instance eth0
virtual-link-ref uas-management
ip-address      12.12.12.37
mac-address     fa:16:3e:48:c4:6c
connection-point-type virtual-port
port-id          8cb138ab-c575-4eb2-a622-d2648042f48f
connection-point-instance eth1
virtual-link-ref uas-orchestration
ip-address      22.22.22.28
mac-address     fa:16:3e:98:78:07
connection-point-type virtual-port
port-id          7d73aaee-81e1-410b-ac3a-e34c1bd23c16
vnfr sj-autovnf-vpc
vnfd            vpc
vnf-type        upg
state           ha-error
external-connection-point cf
connection-point-instance-id CF-sj-autovnf-vpc-vip
virtual-link-ref uas-management
ip-address      12.12.12.43
mac-address     fa:16:3e:04:80:b7
connection-point-type virtual-port
port-id          984a6e8b-107a-48f7-b0b4-398a308aff9a
external-connection-point em
connection-point-instance-id em-sj-autovnf-vpc-vip
virtual-link-ref uas-management
ip-address      12.12.12.35
mac-address     fa:16:3e:b4:7e:b8
connection-point-type virtual-port
port-id          f47c2150-932c-455f-99c1-7b77fe47a9d7
vdu cf
vnfc-instance sj-autovnf-vpc-cf-0
state           alive
vnfc            cf
flavor-key     sj-autovnf-vpc-cf
uuid            a46de643-b76d-4307-91e8-996b79da4c1e
image name     /ugp-bundle/qvpc-di-cf.qcow2
image version "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
image package usp_6_0
image uuid    6d63f613-9b46-4bd9-853d-024dcf27f1a7
host            tb2-compute-9.localdomain
vdu-type       control-function
connection-point-instance eth0
virtual-link-ref di-internal1
ip-address      192.168.10.105
mac-address     fa:16:3e:46:f8:79

```

Example show vnfr Command Output

```

connection-point-type pnic-sriov
port-id b408eedd-8650-44e2-930c-95ee2c9ae380
connection-point-instance eth1
virtual-link-ref uas-management
ip-address 12.12.12.44
mac-address fa:16:3e:5e:e0:bc
connection-point-type virtual-port
port-id 3e94bcd8-0e58-44e1-99a5-366f7453df02
connection-point-instance eth2
virtual-link-ref uas-orchestration
ip-address 22.22.22.33
mac-address fa:16:3e:c5:58:c6
connection-point-type virtual-port
port-id e0a51253-5740-4e34-b4a2-ba6cdcaa504cf
vnfc-instance sj-autovnf-vpc-cf-1
state alive
vnfc cf
flavor-key sj-autovnf-vpc-cf
uuid 10b1e4c2-d3e5-494c-bec9-26bd38e4c705
image name /upg-bundle/qvpc-di-cf.qcow2
image version "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
image package usp_6_0
image uuid 6d63f613-9b46-4bd9-853d-024dcf27f1a7
host tb2-compute-12.localdomain
vdu-type control-function
connection-point-instance eth0
virtual-link-ref di-internal1
ip-address 192.168.10.99
mac-address fa:16:3e:94:3d:38
connection-point-type pnic-sriov
port-id c1df9769-fcdc-4cb1-b7ea-f791ef80ff65
connection-point-instance eth1
virtual-link-ref uas-management
ip-address 12.12.12.47
mac-address fa:16:3e:66:27:71
connection-point-type virtual-port
port-id 7d77aac2-6409-499a-a4b0-afc4c70e6904
connection-point-instance eth2
virtual-link-ref uas-orchestration
ip-address 22.22.22.45
mac-address fa:16:3e:c3:c1:a4
connection-point-type virtual-port
port-id 75d7b8c7-1801-4cce-b665-64a060414abd
vdu em
vnfc-instance sj-autovnf-vpc-em-1
state ha-error
vnfc em
flavor-key sj-autovnf-vpc-em
uuid 119edc4c-9ba0-48f8-a928-63e0c3c88f22
image name /em-bundle/em-6_3_0_4148.qcow2
image version "Version: 6.3.0, SHA1: 40d8f29, Date: Thu Aug 30 22:15:22 EDT 2018"
image package usp_6_0
image uuid d21b6d92-9964-4db8-8376-4a645fecfbf2
host tb2-compute-14.localdomain
vdu-type element-manager
connection-point-instance eth0
virtual-link-ref uas-orchestration
ip-address 22.22.22.40
mac-address fa:16:3e:33:57:a6
connection-point-type virtual-port
port-id 050d8843-f309-45b3-889a-a1516a338c9f
connection-point-instance eth1
virtual-link-ref uas-management
ip-address 12.12.12.26

```

```

mac-address          fa:16:3e:02:b8:4a
connection-point-type virtual-port
port-id              ae8036c5-1a91-488d-98f2-65a8fe57a033
vnfc-instance sj-autovnf-vpc-em-2
state      ha-error
vnfc       em
flavor-key sj-autovnf-vpc-em
uuid       dd2c9327-c954-49bf-803c-ca38d718da2c
image name /em-bundle/em-6_3_0_4148.qcow2
image version "Version: 6.3.0, SHA1: 40d8f29, Date: Thu Aug 30 22:15:22 EDT 2018"
image package usp_6_0
image uuid d21b6d92-9964-4db8-8376-4a645fecfbf2
host       tb2-compute-15.localdomain
vdu-type   element-manager
connection-point-instance eth0
virtual-link-ref    uas-orchestration
ip-address         22.22.22.46
mac-address        fa:16:3e:e5:f7:18
connection-point-type virtual-port
port-id             30816589-9a12-4c1d-840c-c84100f714f4
connection-point-instance eth1
virtual-link-ref    uas-management
ip-address         12.12.12.45
mac-address        fa:16:3e:f3:ff:4e
connection-point-type virtual-port
port-id             cf9d991f-e45b-41ed-9ac1-7e6f0bee620b
vdu sf
vnfc-instance sj-autovnf-vpc-sf-0
state      alive
vnfc       sf
flavor-key sj-autovnf-vpc-sf
uuid       d9b13253-a67e-4078-a75c-04d834577cc2
image name /ugp-bundle/qvpc-di-xf.qcow2
image version "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
image package usp_6_0
image uuid c65df544-0230-4e86-88bf-4aa93e0e268d
host       tb2-compute-14.localdomain
vdu-type   session-function
connection-point-instance eth0
virtual-link-ref    di-internal1
ip-address         192.168.10.95
mac-address        fa:16:3e:87:49:22
connection-point-type pnic-sriov
port-id             5d9a9a89-5857-48cb-8081-7273c4b9354c
connection-point-instance eth1
virtual-link-ref    uas-orchestration
ip-address         22.22.22.18
mac-address        fa:16:3e:8f:47:ce
connection-point-type virtual-port
port-id             d7dd7006-0134-4767-af02-1922d351d1d5
connection-point-instance eth2
virtual-link-ref    vpc-svc
ip-address         22.11.11.8
mac-address        fa:16:3e:a6:fa:9e
connection-point-type virtual-port
port-id             1c5ddaa23-65f0-4541-ace5-0d6e5e1564ea
vnfc-instance sj-autovnf-vpc-sf-1
state      alive
vnfc       sf
flavor-key sj-autovnf-vpc-sf
uuid       868158de-e202-4af4-9f3e-c5c7722c5a7f
image name /ugp-bundle/qvpc-di-xf.qcow2
image version "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
image package usp_6_0

```

Example show vnf-packager Command Output

```

image uuid c65df544-0230-4e86-88bf-4aa93e0e268d
host tb2-compute-15.localdomain
vdu-type session-function
connection-point-instance eth0
  virtual-link-ref di-internal1
  ip-address 192.168.10.97
  mac-address fa:16:3e:bb:ee:38
  connection-point-type pnic-sriov
  port-id c166c76d-3ef9-4f52-a243-25b49ae0886f
connection-point-instance eth1
  virtual-link-ref uas-orchestration
  ip-address 22.22.22.47
  mac-address fa:16:3e:b0:8e:75
  connection-point-type virtual-port
  port-id 9dd61ba8-9455-4f0a-a6ce-13ef28ce6c39
connection-point-instance eth2
  virtual-link-ref vpc-svc
  ip-address 22.11.11.13
  mac-address fa:16:3e:25:5a:56
  connection-point-type virtual-port
  port-id 3f8b60aa-4155-4192-b537-afb812d784da

```

Example show vnf-packager Command Output

show vnf-packager

```

version      "Version: 6.4.M0, SHA1: cdd46bcm, Build-Number: 0"
image application-function
  image-uri   /ugp-bundle/qvpc-di-xf.qcow2
  vim-id      c65df544-0230-4e86-88bf-4aa93e0e268d
  version     "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
  disk-format qcow2
image automation-service
  image-uri   /uas-bundle/usp-uas-6.3.0-0.qcow2
  vim-id      b32d2aeb-9dbe-42f0-99bf-982db8ae7ae8
  version     "Version: 6.3.0, SHA1: 175ea8em, Date: Thu Sep 06 16:17:26 PDT 2018"
  disk-format qcow2
image cisco-esc
  image-uri   /vnfm-bundle/ESC-4_2_0_74.qcow2
  vim-id      c35c2a86-6d60-4259-85cc-d023803c7245
  version     "Version: 4.2.0.74, SHA1: de45b53, Date: Sat Sep 01 08:51:12 EDT 2018"
  disk-format qcow2
image control-function
  image-uri   /ugp-bundle/qvpc-di-cf.qcow2
  vim-id      6d63f613-9b46-4bd9-853d-024dcf27f1a7
  version     "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
  disk-format qcow2
image element-manager
  image-uri   /em-bundle/em-6_3_0_4148.qcow2
  vim-id      d21b6d92-9964-4db8-8376-4a645fecfbf2
  version     "Version: 6.3.0, SHA1: 40d8f29, Date: Thu Aug 30 22:15:22 EDT 2018"
  disk-format qcow2
image network-function
  image-uri   /ugp-bundle/qvpc-di-xf.qcow2
  vim-id      c65df544-0230-4e86-88bf-4aa93e0e268d
  version     "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
  disk-format qcow2
image session-function
  image-uri   /ugp-bundle/qvpc-di-xf.qcow2
  vim-id      c65df544-0230-4e86-88bf-4aa93e0e268d
  version     "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
  disk-format qcow2
image user-plane-function

```

```
image-uri    /ugp-bundle/qvpc-si-21.10.M0.70226.qcow2
vim-id       078bc882-d29c-4974-a21d-dbf2bc59149b
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
configuration bootvm
data-id      1538437650-071830
configuration staros
data-id      1538437650-060109
vnf-packager 6.4.M0-6133
vnf-package usp_6_t
version      "Version: 6.4.M0, SHA1: cdd46bcm, Build-Number: 6133"
image application-function
image-uri    /ugp-bundle/qvpc-di-xf.qcow2
vim-id       d3b3dd85-464d-4b49-90f1-5dc59c9a111b
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
image automation-service
image-uri    /uas-bundle/usp-uas-6.3.0-4206.qcow2
vim-id       294e5f52-453a-4bd8-8192-b8144607759f
version      "Version: 6.3.0, SHA1: 175ea8e, Date: Wed Sep 05 06:15:40 EDT 2018"
disk-format  qcow2
image cisco-esc
image-uri    /vnfm-bundle/ESC-4_2_0_74.qcow2
vim-id       87a322cc-3736-407d-855f-f2a566fadd22
version      "Version: 4.2.0.74, SHA1: de45b53, Date: Sat Sep 01 08:51:12 EDT 2018"
disk-format  qcow2
image control-function
image-uri    /ugp-bundle/qvpc-di-cf.qcow2
vim-id       22b34ebf-060c-4e99-8083-e702cef96aca
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
image element-manager
image-uri    /em-bundle/em-6_3_0_4148.qcow2
vim-id       c4424476-a9b6-4308-98b3-4aa0f441d5c1
version      "Version: 6.3.0, SHA1: 40d8f29, Date: Thu Aug 30 22:15:22 EDT 2018"
disk-format  qcow2
image network-function
image-uri    /ugp-bundle/qvpc-di-xf.qcow2
vim-id       d3b3dd85-464d-4b49-90f1-5dc59c9a111b
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
image session-function
image-uri    /ugp-bundle/qvpc-di-xf.qcow2
vim-id       d3b3dd85-464d-4b49-90f1-5dc59c9a111b
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
image user-plane-function
image-uri    /ugp-bundle/qvpc-si-21.10.M0.70226.qcow2
vim-id       8c78ef58-4556-4e8c-bef6-8f98a33bf6c1
version      "Version: 21.10.M0.70226, SHA1: NA, Date: Thu Sep 06 10:07:27 EDT 2018"
disk-format  qcow2
configuration bootvm
data-id      1538437651-235460
configuration staros
data-id      1538437651-221341
```

Monitoring VNF Operations

**Note**

The Cisco Elastic Services Controller (ESC) is the only VNF supported in this release.

Viewing ESC Status

ESC status can be viewed from the ESC command line or by executing a REST API from AutoVNF.

Monitoring Status Through the ESC Command Line

Log on to the primary ESC VM and execute the following command from the command line:

escadm status

Example command output:

```
0 ESC status=0 ESC Master Healthy
```

Monitoring Status Through an AutoVNF API

Log on to the master AutoVNF VM and execute the following command:

```
curl -u admin:<password> -k https://<master_vnfm_address>:60000/esc/health
```

Example command output:

```
{"message": "ESC services are running.", "status_code": "2000"}
```

Status code and message display information about ESC health conditions as identified in [Table 3: ESC Status Code Messages, on page 58](#). Status codes in the 2000s imply ESC is operational, 5000 status codes imply at least one of the ESC components is not in service.

Table 3: ESC Status Code Messages

| Code | Message |
|------|---|
| 2000 | ESC services are running |
| 2010 | ESC services are running. ESC High-Availability node not reachable. |
| 2020 | ESC services are running. One or more VIM services (keystone, nova) not reachable.* |
| 2030 | ESC services are running. VIM credentials not provided. |
| 2040 | ESC services running. VIM is configured, ESC initializing connection to VIM. |
| 2100 | ESC services are running. ESC High-Availability node not reachable. One or more VIM services (nova) not reachable |
| 5010 | ESC service ESC_MANAGER not running. |

| Code | Message |
|------|--|
| 5020 | ESC service CONFD not running. |
| 5030 | ESC service MONA not running. |
| 5040 | ESC service VIM_MANAGER not running. |
| 5090 | More than one ESC service (confd, mona) not running.** |

Viewing ESC Health

ESC health can be viewed by logging on to the primary ESC VM and executing the following command from the command line:

health.sh

Example command output:

```
esc ui is disabled -- skipping status check
esc_monitor start/running, process 840
esc_mona is up and running ...
vimmanager start/running, process 2807

vimmanager start/running, process 2807
esc_confd is started
tomcat6 (pid 2973) is running...
postgresql-9.4 (pid 2726) is running...
[ OK ]
ESC service is running...
Active VIM = OPENSTACK
ESC Operation Mode=OPERATION

/opt/cisco/esc/esc_database is a mountpoint
===== ESC HA (MASTER) with DRBD =====
DRBD_ROLE_CHECK=0
MNT_ESC_DATABASE_CHECK=0
VIMMANAGER_RET=0
ESC_CHECK=0
STORAGE_CHECK=0
ESC_SERVICE_RET=0
MONA_RET=0
ESC_MONITOR_RET=0
=====
ESC HEALTH PASSED
```

Viewing ESC Logs

ESC logs are available on the VNFM VM in the following directory:

/var/log/esc/

Two levels of logs are available for ESC:

- [ESC Logs, on page 60](#)
- [ESC YANG Logs, on page 61](#)

Refer also to the ESC user documentation for additional information on monitoring and maintaining the software.

ESC Logs

To collect ESC logs:

1. Log on to the primary VNFM VM.
2. Navigate to the scripts directory.

```
cd /opt/cisco/esc/esc-scripts
```

3. Launch the *collect-esc-logs.sh* script to collect the logs.

```
sudo ./collect-esc-logs.sh
```

Example log output:

We trust you have received the usual lecture from the local System Administrator. It usually boils down to these three things:

```
#1) Respect the privacy of others.  
#2) Think before you type.  
#3) With great power comes great responsibility.  
  
[sudo] password for admin: Creating log tarball:  
/var/tmp/esc_log-2017-05-25_18.09.31_UTC.tar.bz2  
Creating temporary working directory: /var/tmp/esc_log-2017-05-25_18.09.31_UTC  
  
Dumping thread status of ESCManager from tomcat pid 2973 to catalina.out  
escadm-output.txt  
vm_info.txt  
esc_version.txt  
esc/  
esc/vimmanager/  
esc/vimmanager/operations_vimmanager.log  
esc/vimmanager/vimmanager.log  
esc/esc_gc.log.2.current  
esc/esc_gc.log.0  
esc/escmanager.log  
esc/event_escmanager.log  
esc/escmanager_tagged.log  
esc/esc_gc.log.1  
esc/custom_script/  
esc/pgstartup.log  
esc/mona/  
esc/mona/actions_mona.log  
esc/mona/mona_gc.log.0.current  
esc/mona/rules_mona.log  
esc/mona/mona.log  
tar: esc/mona/mona.log: file changed as we read it  
esc/confd/  
esc/confd/global.data  
esc/confd-devel.log  
esc/confd-confd.log  
esc/confd-browser.log  
esc/confd-audit.log  
esc/confd-netconf.trace  
esc/confd-netconf.log  
esc/spy.log  
esc/error_escmanager.log  
esc/esc_monitor.log
```

```

esc/esc_haagent.log
esc/yangesc.log
esc/debug_yangesc.log
esc/esc_confd.log
boot.log
secure
messages
dmesg
tomcat6/
tomcat6/localhost.2017-05-24.log
tomcat6/host-manager.2017-05-24.log
tomcat6/manager.2017-05-24.log
tomcat6/catalina.out
tomcat6/catalina.2017-05-24.log
audit/
audit/audit.log
postgresql/data/pg_log/
postgresql/data/pg_log/postgresql-Thu.log
postgresql/data/pg_log/postgresql-Wed.log
esc-config/esc-config.xml
Warning: tar completed with status: 1

Tarball file: /var/tmp/esc_log-2017-05-25_18.09.31_UTC.tar.bz2
Symbolic link: /tmp/esc_log-2017-05-25_18.09.31_UTC.tar.bz2

Suggestions:
1. Transfer the tarball file from the esc vm
2. Remove the tarball and symbolic link (to save ESC disk space):
   sudo rm /var/tmp/esc_log-2017-05-25_18.09.31_UTC.tar.bz2
   sudo rm /tmp/esc_log-2017-05-25_18.09.31_UTC.tar.bz2
3. Command to list contents of tarball:
   tar jtvf esc_log-2017-05-25_18.09.31_UTC.tar.bz2
4. Command to extract from the tarball:
   tar jxf esc_log-2017-05-25_18.09.31_UTC.tar.bz2

```

ESC YANG Logs

ESC YANG logs are stored in the following file:

`/var/log/esc/yangesc.log`

Monitoring VNF Operations

Viewing UEM Service Status

1. Log on to the master UEM VM as the user *ubuntu*.
2. Access the NCS CLI.

`/opt/cisco/usp/packages/nso/ncs-4.1.1/bin/ncs_cli -C -u admin`

3. Check the NCS state.

`show ncs-state ha`

Example command output:

```

ncs-state ha mode master
ncs-state ha node-id 3-1501714180
ncs-state ha connected-slave [ 4-1501714262 ]

```

Viewing UEM Logs

4. Display the health of cluster.

```
show ems
```

Example command output:

| EM | VNFM | | | |
|----|------|-----|-------|---------|
| ID | SLA | SCM | PROXY | VERSION |
| 3 | UP | UP | UP | 5.7.0 |
| 6 | UP | UP | UP | 5.7.0 |

Viewing UEM Logs

To collect UEM logs:

1. Navigate to the *scripts* directory.

```
cd /opt/cisco/em-scripts
```

2. Launch the *collect-em-logs.sh* script to collect the logs.

```
sudo ./collect-em-logs.sh
```

Example log output:

```
Collecting Zookeeper nodes...
Traceback (most recent call last):
  File "/opt/cisco/em-scripts/zk_dump.py", line 2, in <module>
    from kazoo.client import KazooClient
ImportError: No module named kazoo.client

Creating log tarball em-logs-2017-05-26_00.37.28_UTC.tar.bz2 ...
em-logs/
em-logs/upstart/
em-logs/upstart/proxy.log
em-logs/upstart/zk.log
em-logs/upstart/ncs.log
em-logs/scm/
em-logs/scm/audit.log.1.gz
em-logs/scm/ncserr.log.1
em-logs/scm/ncs-java-vm.log.2.gz
em-logs/scm>xpath.trace.1.gz
em-logs/scm/ncs-java-vm.log.1.gz
em-logs/scm>xpath.trace.2.gz
em-logs/scm/ncs-java-vm.log
em-logs/scm/ncserr.log.siz
em-logs/scm>xpath.trace
em-logs/scm/audit.log
em-logs/scm/audit.log.2.gz
em-logs/scm/ncserr.log.idx
em-logs/sla/
em-logs/sla/sla-mgr.log
em-logs/sla/sla-system.log
em-logs/zookeeper/
em-logs/zookeeper/zookeeper.out
em-logs/zookeeper/zookeeper.log
em-logs/vnfm-proxy/
em-logs/vnfm-proxy/vnfm-proxy.log

=====
 Tarball available at: /tmp/em-logs-2017-05-26_00.37.28_UTC.tar.bz2
=====
```

To extract the tarball, run: "tar jxf /tmp/em-logs-2017-05-26_00.37.28_UTC.tar.bz2"

Viewing UEM Zookeeper Logs

The UEM maintains logs on the Zookeeper process. The logs are located in the following directories:

/var/log/em/zookeeper/zookeeper.log
 /var/log/em/zookeeper/zookeeper.out

Viewing VNF Information through the Control Function

Information on the VNF deployment can be obtained by executing commands on the Control Function (CF) VNFC. To access the CF CLI:

1. Open an SSH connection to the IP address of the management interface associated with CF1.
2. Press **Enter** to bring up the log in prompt.
3. Enter the username and password.
4. At the Exec mode prompt, enter each of the following commands and observe the results to ensure that the VNF components have been properly deployed according to the desired configuration:

| Command | Purpose |
|------------------------------|---|
| show card table | Displays all VM types (e.g. CF, SF, NF, and AF) that have been deployed. |
| show crash list | Displays software crash events records and associated dump files (minicore, NPU or kernel) for all crashes or a specified crash event. Verify that there are no new or unexpected crashes listed. |
| show emctrl vdu list | Displays card to VM mappings for the VNF. Each card should have a valid universally unique identifier (UUID). |
| show rct stats | Displays statistics associated with Recovery Control Task (RCT) events, including migrations, switchovers and shutdowns. RCT statistics are associated with card-to-card session recovery activities. |
| show session progress | Displays session progress information for the current context filtered by the options specified. Check for any active or new calls before proceeding with a deactivation. |
| show version verbose | Displays the software version that has been deployed. |
| show vdu summary | Displays general information pertaining to the virtual descriptor units (VDUs) that have been deployed. |

| Command | Purpose |
|--|---|
| In releases prior to 6.0: show usf vdu all In 6.0 and later releases: show vnfr vdu all | Displays detailed information for the VDUs that have been deployed for the USF VDU. |
| In releases prior to 6.0: show usf vdu-group all In 6.0 and later releases: show vnfr vdu-group all | Displays information for VDU groups pertaining to the USF VNF use case (if deployed). |
| In releases prior to 6.0: show usf network-path all In 6.0 and later releases: show vnfr network-path all | Displays network path information for USF VNF components (if deployed). |
| In releases prior to 6.0: show usf service-function-chain all In 6.0 and later releases: show vnfr service-function-chain all | Displays SFC information for the USF VNF (if deployed). |

Monitoring and Recovering AutoVNF Through AutoIT

AutoIT provides the ability to monitor and auto-recover AutoVNF instances.

This functionality is enabled through configuration of the AutoVNF VNFC(s) at the time of deployment. Once enabled, AutoIT automatically monitors for faults/failures of the AutoVNF VNFC(s) for which the functionality is enabled. If a fault/failure is detected, AutoIT automatically attempts to auto-heal/recover (redeploy) the VNFC(s).



Important The Provisioning Network (floating) IP address is required to leverage the health monitoring functionality.

The following parameters must be configured at the VNFC-level:

Table 4: Health Check Descriptor Parameters

| Parameter | Required | Type | Description |
|-----------|----------|------|-----------------------------------|
| enabled | O | bool | Enable/Disable health monitoring. |

| Parameter | Required | Type | Description |
|-----------------|----------|---------------|---|
| probe-frequency | O | uint16 | Health Check Frequency in seconds. UAS uses this as health probe time, meaning every polling interval UAS will invoke health check. Default value is 10 seconds. |
| probe-max-miss | O | uint16 | Maximum number of health probe misses before VNFC instance is declared dead. Default value is 6. |
| recovery-type | O | choice string | Recovery type. It can be one of the following: <ul style="list-style-type: none">• restart: Recovery only by restarting, move the VNFC instance to error after max retries• external: Recovery performed by external entity. No auto-recovery• restart-then-redeploy: Restart the VM on failure. After maximum retries, redeploy the failed VNFC instances. Default value is restart-then-redeploy. |
| retry-count | O | uint16 | Number of retries to recover the VNFC Instance. Default value is set to restart-then-redeploy. |
| boot-time | O | uint16 | Initial Bootup time for the VNFC. Default value is 300 seconds. |
| script | O | string | Script to check VNFC health, by default UAS ICMP script will be used. |

The above parameters are configured at the VNFC-level within the VNF descriptor information that is part of the deployment network service descriptor (NSD) as shown in the following example configuration:

```
nsd <nsd_name>
...
vnfd <autovnf_vnfd_name>
...
vnfc <autovnf_vnfc_name>
  health-check enabled
  health-check probe-frequency 10
  health-check probe-max-miss 6
  health-check retry-count 6
  health-check recovery-type restart-then-redeploy
  health-check boot-time 300
...

```

Refer to the *Cisco Ultra Services Platform NETCONF API Guide* for more information on the use of these and other parameters related to VNF configuration and deployment.

In the event that automatic recovery is not possible, an API is available to manually recover the VNFC(s).

VNFC status can be viewed by executing the **show vnfr** command from AutoIT. Additional details can be found in the transaction logs for the deployment.

To manually recover a failed AutoVNF VNFC, execute the following command:

```
recover nsd-id <nsd_name> vnfid <vnfd_name>
```

Monitoring and Recovering VNFC Through AutoVNF

The UEM, CF, and SF VNFCs were autorecovered through the VNFM (ESC). In these situations, AutoVNF was not informed of these events. With this release, the AutoVNF monitors these VNFC VMs and can auto-recover them if required. Additionally, the AutoVNF can also monitor the VNFM (ESC) VMs and provide auto-recovery as needed.

This functionality is enabled through configuration of the VNFC(s) at the time of deployment. Once enabled, AutoVNF automatically monitors for faults/failures of the VNFCs for which the functionality is enabled. If a fault/failure is detected, AutoVNF automatically attempts to auto-heal/recover (redeploy) the VNFC(s).



Important The Provisioning Network (floating) IP address is required to leverage the health monitoring functionality.

This functionality is currently only supported for the following VNFCs:

- VNFM (ESC)
- UEM
- CF
- SF



Important Ultra M Manager sends fault notification when VMs are down and/or recovered.

The following parameters must be configured at the VNFC-level:

Table 5: Health Check Descriptor Parameters

| Parameter | Required | Type | Description |
|-----------------|----------|--------|--|
| enabled | O | bool | Enable/disable health monitoring. |
| probe-frequency | O | uint16 | Health Check Frequency in seconds. UAS uses this as health probe time, meaning every polling interval UAS will invoke health check. Default value is 10 seconds. |
| probe-max-miss | O | uint16 | Maximum number of health probe misses before VNFC instance is declared dead. Default value is 6. |

| Parameter | Required | Type | Description |
|---------------|----------|---------------|---|
| recovery-type | O | choice string | <p>Recovery type. It can be one of the following:</p> <ul style="list-style-type: none"> • restart: Recovery only by restarting, move the VNFC instance to error after max retries • external: Recovery performed by external entity. No auto-recovery • restart-then-redeploy: Restart the VM on failure. After maximum retries, redeploy the failed VNFC instances. <p>Default value is restart-then-redeploy.</p> |
| retry-count | O | uint16 | Number of retries to recover the VNFC Instance. Default value is set to restart-then-redeploy. |
| boot-time | O | uint16 | Initial bootup time for the VNFC. Default value is 300 seconds. |
| script | O | string | Script to check VNFC health, by default UAS ICMP script will be used. |

The above parameters are configured at the VNFC-level within the VNF descriptor information that is part of the deployment network service descriptor (NSD) as shown in the following example configuration:

```

nsd <nsd_name>
...
vnfd <autovnf_vnfd_name>
...
vnfc <vnfm_vnfc_name>
  health-check enabled
  health-check probe-frequency 10
  health-check probe-max-miss 6
  health-check retry-count 6
  health-check recovery-type restart-then-redeploy
  health-check boot-time 300
...
vnfc <uem_vnfc_name>
  health-check enabled
  health-check probe-frequency 10
  health-check probe-max-miss 6
  health-check retry-count 6
  health-check recovery-type restart-then-redeploy
  health-check boot-time 300
...
vnfc <cf_vnfc_name>
  health-check enabled
  health-check probe-frequency 10
  health-check probe-max-miss 6
  health-check retry-count 6
  health-check recovery-type restart-then-redeploy
  health-check boot-time 300
...
vnfc <sf_vnfc_name>
  health-check enabled
  health-check probe-frequency 10
  health-check probe-max-miss 6

```

Troubleshooting Deactivation Process and Issues

```

health-check retry-count 6
health-check recovery-type restart-then-redeploy
health-check boot-time 300
...

```

Refer to the *Cisco Ultra Services Platform NETCONF API Guide* for more information on the use of these and other parameters related to VNF configuration and deployment.

In the event that automatic recovery is not possible, an API is available to manually recover the VNFC(s).

VNFC status can be viewed by executing the **show vnfr** command from AutoIT. Additional details can be found in the transaction logs for the deployment.

To manually recover a failed VNFC, execute the following command:

```
recover nsd-id <nsd_name> vnfd <vnfd_name>
```

Troubleshooting Deactivation Process and Issues

NOTES:

- The deactivate process is idempotent and can be multiple times and without error. The system will retry to remove any resources that remain.
- If a deactivation fails (a transaction failure occurs), look at the logs on various UAS software components (AutoDeploy, AutoIT, and AutoVNF), VNFM (ESC), and UEM.
- If deactivation has failed, you must ensure that a clean up is performed either using automation tools or manually if necessary.
- Activation must not be reattempted until all of the previous artifacts have been removed.

Deactivation Fails Due to Communication Errors with AutoVNF

Problem Description

During the AutoVNF deactivation process, AutoDeploy indicates that it is unable to deactivate the AutoVNF. This is observed through:

- AutoDeploy transaction log
- AutoDeploy upstart log

Possible Cause(s)

- AutoDeploy is not able to communicate with AutoVNF.

Action(s) to Take

- Check network connectivity between the AutoDeploy VM and the AutoVNF VIP.
- Check the management and orchestration network.
- Address any connectivity issues.

Next Steps

- Once connectivity issues are addressed, perform the deactivate procedure again.

Deactivation Fails Because AutoDeploy Generates an Exception

Problem Description

AutoDeploy generates an exception error during the deactivation process.

Possible Cause(s)

- Connectivity issues
- Configuration issues
- OpenStack/VIM specific issues
- Hardware issues

Action(s) to Take

- Capture logs from `/var/log/upstart/autodeploy.log` along with exception error message.
- Log on to AutoIT and collect the logs from `/var/log/upstart/autoit.log` along with the exception message, if any.
- Log on to VIP of the active (master) AutoVNF VM and perform a cleanup by running the **deactivate** command from there.
 - Log on to the AutoVNF VM as the default user, *ubuntu*.
 - Switch to the root user.
`sudo su`
 - Enter the ConfD CLI.
`confd_cli -C -u admin`
 - Deactivate the deployment.
`deactivate nsd-id <nsd_name>`
- Check the last transaction log to verify that the deactivation was successful. (Transactions are auto-sorted by timestamp, so it should be the last one in the list.)

Example commands and outputs:

`show transactions`

| TX ID | TX TYPE | ID | TIMESTAMP | STATUS |
|--------|---------|----|-----------|--------|
| DETAIL | | | | |

```

1500605583-055162 vnf-deployment dep-5-5 2017-07-21T02:53:03.055205-00:00
deployment-failed -
1500606090-581863 vnf-deployment dep-5-5 2017-07-21T03:01:30.581892-00:00
deployment-success -
1500606127-221084 vnf-deployment dep-5-5 2017-07-21T03:02:07.221114-00:00
deployment-success -

```

```

show log 1500606127-221084 | display xml
<config xmlns="http://tail-f.com/ns/config/1.0">

```

Deactivation Fails Because of AutoVNF-VNFM Communication Issues

```

<log xmlns="http://www.cisco.com/usp/nfv/usp-autovnf-oper">
<tx-id>1500606127-221084</tx-id>
<log>2017-07-21 03:02:07,276 - Notify deployment
2017-07-21 03:02:07,297 - Connection to VNFM (esc) at 172.16.181.107
2017-07-21 03:02:07,418 - NETConf Sessions (Transaction/Notifications) established
...

```

5. Manually delete the AutoDeploy VM using the information in [Terminating the AutoDeploy VM, on page 2](#).

Next Steps

- Open a support case providing all of the log information that was collected.

Deactivation Fails Because of AutoVNF-VNFM Communication Issues

Problem Description

During the AutoVNF deactivation process, AutoVNF indicates that it is unable to deactivate the VNFM. This is observed through:

- AutoVNF transaction log
- AutoVNF upstart log

Possible Cause(s)

- AutoVNF is not able to communicate with the VNFM.

Action(s) to Take

- Check network connectivity between the master AutoVNF VM and the VNFM VIP.
- Check the management and orchestration network.
- Address any connectivity issues.

Next Steps

- Once connectivity issues are addressed, perform the deactivate procedure again.

Deactivation Fails Because of Issue at VNFM

Problem Description

During the AutoVNF deactivation process, the VNFM returns an error. This is observed through:

- AutoVNF transaction log
- AutoVNF upstart log
- ESC logs

Possible Cause(s)

- ESC health is not good due to an issue or network connectivity.

- ESC is not able to communicate with the VIM.
- ESC has an internal error.
- AutoVNF is unable to create/delete OpenStack artifacts.

Action(s) to Take

1. Check `/var/log/esc/yangesc.log` for any issues or error messages.
2. Run **health.sh** to determine the health of ESC.
3. Check network connectivity and address any issues. Retry the deactivation.
4. Check network connectivity with the VIM and address any issues. Retry the deactivation.
5. Determine if ESC has a deployment configuration. From the active ESC VM:

```
/opt/cisco/esc/confd/bin/confd_cli -C  
show running-config
```

If a configuration is present, most likely ESC is still retrying the deactivation, allow more time for the process to continue.

If no configuration exists, check if there are deployment artifacts still on the VIM. Retry the deactivation.

6. Collect logs by running `collect_esc_log.sh` from both the active and standby ESC VMs.
7. Perform a manual cleanup.



Note

Only artifacts which UAS created need to be removed. Any pre-created artifacts must remain in place.

- a. Login on to the VIM as tenant.
- b. Remove all VMs.
- c. Remove all VIP Ports.
- d. Remove all networks.
- e. Remove all flavors.
- f. Remove all volumes.
- g. Remove all images.
- h. Remove host-aggregate created as part of automation.

Next Steps

- Open a support case providing all of the log information that was collected.

Deactivation Fails Because AutoVNF Generates an Exception

Problem Description

AutoVNF generates an exception error during the deactivation process.

Possible Cause(s)

- Connectivity issues
- Configuration issues
- OpenStack/VIM specific issues
- Hardware issues

Action(s) to Take

1. Collect all logs from `/var/log/cisco-uas`.
2. Perform a manual cleanup.



Note Only artifacts which UAS created need to be removed. Any pre-created artifacts can remain in place.

- a. Login on to the VIM as tenant.
- b. Remove all VMs.
- c. Remove all VIP Ports.
- d. Remove all networks.
- e. Remove all flavors.
- f. Remove all volumes.
- g. Remove all images.
- h. Remove host-aggregate created as part of automation.

Next Steps

- Open a support case providing all of the log information that was collected.

Troubleshooting UEM Issues

This section contains information on troubleshooting UEM issues.

UEM VM Stuck in a Boot Loop

Problem Description

Processes that normally run on the UEM VM are unable to start and the VM is stuck in a boot-loop.

Possible Cause(s)

There is an error with the Zookeeper database keeping the Zookeeper process and other UEM processes from starting. (No other UEM process can be started unless the Zookeeper process has started.)

Action(s) to Take

1. Check the UEM Zookeeper logs. Refer to [Viewing UEM Zookeeper Logs, on page 63](#).
2. Look for error messages similar to the following:

```
[myid:4] - INFO  [main:FileSnap@83] - Reading snapshot
/var/lib/zookeeper/data/version-2/snapshot.5000004ba
[myid:4] - ERROR [main:QuorumPeer@557] - Unable to load database on disk
java.io.EOFException
```

If the above errors exist, proceed to the next step. If not, further debugging is required. Please contact your local support representative.

3. Rebuild the Zookeeper database.

- a. Check the health of Master and Slave EM instances. Execute the following commands on each instance.

Master UEM VM:

```
sudo -i
ncs_cli -u admin -C
admin connected from 127.0.0.1 using console on deploymentem-1

show ems
EM          VNFM
ID   SLA   SCM   PROXY   VERSION
-----
3    UP     UP     UP      5.7.0
6    UP     UP     UP      5.7.0

exit
```



Important Only the master UEM status may be displayed in the above command because the slave UEM is in the boot loop.

```
show ncs-state ha
ncs-state ha mode master
ncs-state ha node-id 6-1506059686
ncs-state ha connected-slave [ 3-1506059622 ]
```

Slave UEM VM:

Important The slave UEM may not be accessible if it is experiencing the boot loop issue.

```
sudo -i
ncs_cli -u admin -C
admin connected from 127.0.0.1 using console on deploymentem-1

show ems
EM          VNFM
ID   SLA   SCM   PROXY   VERSION
-----
3    UP     UP     UP      5.7.0
6    UP     UP     UP      5.7.0

exit
```

```
show ncs-state ha
ncs-state ha mode slave
ncs-state ha node-id 3-1506059622
ncs-state ha master-node-id 6-1506059686
```

- b. Log on to the node on which Zookeeper data is corrupted.

- c. Enable the debug mode.

```
/opt/cisco/em-scripts/enable_debug_mode.sh
Disable EM reboot. Enable debug mode
```

- d. Reboot the VM in order to enter the debug mode.

- e. Remove the corrupted data.

```
cd /var/lib/zookeeper/data/
ls
myid version-2 zookeeper_server.pid

mv version-2 version-2_old
```



Important

This process removes the Zookeeper database by renaming it for additional debugging/recovery.

- f. Reboot the node instance for it to reconcile and rebuild the Zookeeper database from a healthy UEM instance.

reboot

- g. Log on to the UEM VM upon reboot.

- h. Validate that the database has been successfully rebuilt on the previously failing UEM node.

```
sudo -i
ncs_cli -u admin -C
admin connected from 127.0.0.1 using console on vnfdeploymentem-0
```

```
show ems
EM          VNFM
ID   SLA   SCM   PROXY   VERSION
-----
3    UP     UP     UP      5.7.0
6    UP     UP     UP      5.7.0
```

```
show ncs-state ha
ncs-state ha mode slave
ncs-state ha node-id 3-1506093933
ncs-state ha master-node-id 6-1506093930
```

exit

```
cd /var/lib/zookeeper/data/
ls
myid version-2 version-2_old zookeeper_server.pid
```

```
cat /var/log/em/zookeeper/zookeeper.log
<--SNIP-->
2017-09-22 15:25:35,192 [myid:3] - INFO
[QuorumPeer[myid=3]/0:0:0:0:0:0:2181:Follower@61] - FOLLOWING - LEADER ELECTION
```

```
TOOK - 236
2017-09-22 15:25:35,194 [myid:3] - INFO
[QuorumPeer[myid=3]/0:0:0:0:0:0:0:2181:QuorumPeer$QuorumServer@149] - Resolved
hostname: 30.30.62.6 to address: /30.30.62.6
2017-09-22 15:25:35,211 [myid:3] - INFO
[QuorumPeer[myid=3]/0:0:0:0:0:0:0:2181:Learner@329] - Getting a snapshot from leader
2017-09-22 15:25:35,224 [myid:3] - INFO
[QuorumPeer[myid=3]/0:0:0:0:0:0:0:2181:FileTxnSnapLog@240] - Snapshotting:
0x200000050 to /var/lib/zookeeper/data/version-2/snapshot.200000050
2017-09-22 15:25:37,561 [myid:3] - INFO
[NIOServerCxn.Factory:0.0.0.0/0.0.0.0:2181:NIOServerCnxnFactory@192] - Accepted socket
connection from /30.30.62.15:58011
2017-09-22 15:25:37,650 [myid:3] - WARN
[NIOServerCxn.Factory:0.0.0.0/0.0.0.0:2181:ZooKeeperServer@882] - Connection request
from old client /30.30.62.15:58011; will be dropped if server is in r-o mode
2017-09-22 15:25:37,652 [myid:3] - INFO
[NIOServerCxn.Factory:0.0.0.0/0.0.0.0:2181:ZooKeeperServer@928] - Client attempting
to establish new session at /30.30.62.15:58011
<---SNIP--->
```

- i. Disable the UEM debug mode on the VM on which the Zookeeper database was rebuilt.

```
/opt/cisco/em-scripts/disable_debug_mode.sh
Disable debug mode
```

Next Steps

Open a support case providing all the log information that was collected.

