

# **Session Recovery**

- Feature Summary and Revision History, on page 1
- Feature Description, on page 1
- How it Works, on page 2
- Configuring the System to Support Session Recovery, on page 2

# **Feature Summary and Revision History**

### **Summary Data**

Applicable Product(s) or Functional Area	5G-UPF
Applicable Platform(s)	VPC-SI
	SMI
Feature Default Setting	Disabled – License Required
Related Changes in this Release	Not Applicable
Related Documentation	Not Applicable

## **Revision History**

Revision Details	Release
First introduced.	2020.02.0

## **Feature Description**

With robust hardware failover and redundancy protection, any hardware or software failures on the system can quickly be corrected. However, software failures can occur for numerous reasons, often without prior indication.

This chapter describes the Session Recovery feature that provides seamless failover and reconstruction of subscriber session information in the event of a hardware or software fault.



Important

Session Recovery is a licensed Cisco feature. A separate feature license may be required. Contact your Cisco Account representative for detailed information on specific licensing requirements.

## **How it Works**

This section provides an overview of how this feature is implemented and the recovery process.

The Session Recovery feature provides seamless failover and reconstruction of subscriber session information in the event of a hardware or software fault within the system preventing a fully connected user session from being disconnected.

Session recovery is performed by mirroring key software processes (for example, session manager and AAA manager) within the system. These mirrored processes remain in an idle state (standby-mode) wherein they perform no processing, until they may be needed in the event of a software failure (for example, a session manager task aborts).

There are some situations wherein session recovery may not operate properly. More software or hardware failures occur during the session recovery operation. For example, an AAA manager fails while the state information it contained was being used to populate the newly activated session manager task.

Important

After a session recovery operation, some statistics, such as those collected and maintained on a per manager basis (AAA Manager, Session Manager, and so on) are in general not recovered, only accounting and billing related information is checkpointed and recovered.

## **Configuring the System to Support Session Recovery**

The following procedures allow you to configure the session recovery feature for either an operational system that is currently in-service (able to accept incoming calls) or a system that is out-of-service (not part of your production network and, therefore, not processing any live subscriber/customer data).



**Important** The session recovery feature, even when the feature use key is present, is disabled by default on the system.

## **Enabling Session Recovery**

As noted earlier, session recovery can be enabled on a system that is out-of-service (OOS) and does not yet have any contexts configured, or on an in-service system that is currently capable of processing calls. However, if the system is in-service, it must be restarted before the session recovery feature takes effect.

#### Enabling Session Recovery on an Out-of-Service System

The following procedure is for a system that does not have any contexts configured.

To enable the session recovery feature on an Out-of-Service system, perform the following procedure. This procedure assumes that you begin at the EXEC mode prompt.

#### Procedure

**Step 1** At the EXEC mode prompt, verify that the session recovery feature is enabled through the session and feature use licenses on the system by running the **show license info** command.

If the current status of the Session Recovery feature is Disabled, you cannot enable this feature until a license key is installed in the system.

**Step 2** Use the following configuration example to enable session recovery.

#### configure require session recovery end

- **Note** After you configure this command, you must save the configuration and then reload the chassis for the command to take effect. For information on saving the configuration file and reloading the chassis, refer to the System Administration Guide for your deployment.
- **Step 3** Save your configuration as described in *Verifying and Saving Your Configuration*.

The system, when started, enables session recovery, creates all mirrored "standby-mode" tasks, and performs packet processing card reservations and other operations automatically.

**Step 4** After the system has been configured and placed in-service, you must verify the preparedness of the system to support this feature as described in *Viewing Session Recovery Status* section.

#### Enabling Session Recovery on an In-Service System

When enabling session recovery on a system that already has a saved configuration, the session recovery commands are automatically placed before any service configuration commands in the configuration file.

To enable the session recovery feature on an in-service system, perform the following procedure. This procedure assumes that you begin at the EXEC mode prompt.

#### Procedure

**Step 1** At the EXEC mode prompt, verify that the session recovery feature is enabled through the session and feature use licenses on the system by running the **show license info** command:

If the current status of the Session Recovery feature is Disabled, You cannot enable this feature until a license key is installed in the system.

**Step 2** Use the following configuration example to enable session recovery.

configure require session recovery end This feature does not take effect until after the system has been restarted.

- **Step 3** Save your configuration as described in *Verifying and Saving Your Configuration*.
- **Step 4** Perform a system restart by entering the **reload** command:

The following prompt appears:

Are you sure? [Yes|No]:

Confirm your desire to perform a system restart by entering yes.

The system, when restarted, enables session recovery and creates all mirrored "standby-mode" tasks, performs packet processing card reservations, and other operations automatically.

**Step 5** After the system has been restarted, you must verify the preparedness of the system to support this feature as described in *Viewing Session Recovery Status* section.

More advanced users may opt to simply insert the **require session recovery** command syntax into an existing configuration file using a text editor or other means, and then applying the configuration file manually. Exercise caution when doing this to ensure that this command is placed among the first few lines of any existing configuration file; it must appear before the creation of any nonlocal context.

### **Disabling the Session Recovery Feature**

To disable the session recovery feature on a system, enter the **no require session recovery** command from the Global Configuration mode prompt.

```
6
```

Important

ant If this command is issued on an in-service system, then the system must be restarted by issuing the **reload** command.

### Viewing Session Recovery Status

To determine if the system is capable of performing session recovery, when enabled, enter the **show session** recovery status verbose command from the Exec mode prompt.

The output of this command should be similar to the examples shown below.

[local]host_name# <b>show s</b>	session	recovery status
Session Recovery Status:		
Overall Status	:	SESSMGR Not Ready For Recovery
Last Status Update	:	1 second ago
[local] <i>host_name</i> # <b>show</b> s	session	recovery status
Session Recovery Status:		
Overall Status	:	Ready For Recovery
Last Status Update	:	8 seconds ago
[local]host_name# <b>show s</b>	session	recovery status verbose
Session Recovery Status:		
Overall Status	:	Ready For Recovery
Last Status Update	:	2 seconds ago

	sessi	graaamgr		gr	demux		
cpu state	active	standby	active	standby	active	status	
1/0 Active	7	1	7	1	7	Good	
[local]host_na	ame#						

## **Viewing Recreated Session Information**

To view session state information and any session recreation status, enter the following command:

```
show subscriber debug-info callid id
```

The following example shows the output of this command both before and after a session recovery operation has been performed. The "Redundancy Status" fields in this example have been bold-faced for clarity.

1	2		1		2		
username: user1	callid:	callid: 01callb1			msid: 0000100003		
Card/Cpu: 4/2	- 7						
Sessmgr Instanc							
Primary calllin							
Redundancy S	tatus: Original	Session					
Checkpoints	Attempts	Success	s Las	st-Attempt	Last-Success		
Full:	69	68	3	29800ms	29800ms		
Micro:	206	206	5	20100ms	20100ms		
Current state	: SMGR_STATE_CONNEC	CTED					
FSM Event tra	ce:						
State		E	lvent				
SMGR_ST	ATE_OPEN	S	MGR_EVT_NEW	VCALL			
SMGR_ST	ATE_NEWCALL_ARRIVE	D S	MGR_EVT_ANS	SWER_CALL			
SMGR ST	ATE NEWCALL ANSWER	ED S	SMGR EVT LIN	NE CONNECTED			
SMGR ST	ATE LINE CONNECTED	S	SMGR EVT LIN	NK CONTROL UE	2		
SMGR_ST	ATE_LINE_CONNECTED	S	MGR_EVT_AU1	"H_REQ			
SMGR ST	ATE LINE CONNECTED	S	SMGR EVT IPA	ADDR ALLOC SU	JCCESS		
SMGR_ST				TH_SUCCESS			
SMGR_ST				DATE_SESS_CON	IFIG		
SMGR ST	ATE LINE CONNECTED	S	SMGR EVT LOW	WER LAYER UP			
Data Reorder st	atistics						
Total timer exp	iry:	0	Total flush	n (tmr expiry	7): 0		
Total n	o buffers:	0	Total flush	n (no buffers	s): 0		
Total f	lush (queue full):	0	Total flush	n (out of rar	nge): 0		
Total f	lush (svc change):	0	Total out-o	of-seq pkt dr	cop: 0		
Total o	ut-of-seq arrived:	0					
IPv4 Reassembly	Statistics:						
Succe	ss:	0	In Progress	s: 0			
Failu	re (timeout):	0	Failure (no	buffers): (	)		
Failu	re (other reasons)	: 0					
Redirected Sess	ion Entries:	All	owed:				
2000 Cur	rent:			0			
Add	ed:			0	Deleted:		
	0						
Rev	oked for use by di:	fferent sub	oscriber: 0				
Peer callline:							
Redundancy	Status: Recreat	ed Sessi	on				
Checkpoints -	Attempts	Success		-Attempt	Last-Success		
Full:	0	0		Oms	Oms		
Micro:	0	0		Oms	Oms		
	: SMGR STATE CONNEG	CTED					
FSM Event tra							
State					Event		
	ATE_LINE_CONNECTED		SMGR EVT I	LOWER_LAYER_U			
	ATE CONNECTED		SMGR EVT A				
_	ATE CONNECTED			AUTH SUCCESS			
—	ATE CONNECTED			REQ SUB SESSI	ON		
51101(_01				~_~~_~	-		

I

SMGR STATE CONNECTED		SMGR EVT RSP SUB SESSION	
SMGR STATE CONNECTED		SMGR EVT ADD SUB SESSION	
SMGR STATE CONNECTED		SMGR EVT AUTH REQ	
SMGR STATE CONNECTED		SMGR EVT AUTH SUCCESS	
SMGR STATE CONNECTED		SMGR EVT AUTH REQ	
SMGR STATE CONNECTED		SMGR EVT AUTH SUCCESS	
SMGR STATE CONNECTED		SMGR EVT AUTH REQ	
SMGR STATE CONNECTED		SMGR EVT AUTH SUCCESS	
SMGR STATE CONNECTED		SMGR EVT AUTH REQ	
SMGR STATE CONNECTED		SMGR EVT AUTH SUCCESS	
SMGR STATE CONNECTED		SMGR EVT AUTH REQ	
SMGR STATE CONNECTED		SMGR EVT AUTH SUCCESS	
Data Reorder statistics			
Total timer expiry:	0	Total flush (tmr expiry):	0
Total no buffers:	0	Total flush (no buffers):	0
Total flush (queue full):	0	Total flush (out of range):	0
Total flush (svc change):	0	Total out-of-seq pkt drop:	0
Total out-of-seq arrived:	0		
IPv4 Reassembly Statistics:			
Success:	0	In Progress:	0
Failure (timeout):	0	Failure (no buffers):	0
Failure (other reasons):	. 0		
Redirected Session Entries:			
Allowed:	2000	Current: 0	
Added:		Deleted: 0	
Revoked for use by diffe	erent	subscriber: 0	