



# Cisco Remote PHY Controller Profile and RPD Configuration

---

The Remote PHY (R-PHY) Controller Profile includes upstream controller-profile and downstream controller-profile. Upstream controller-profile is used to specify the upstream (US) channels and related parameters, which are part of a specific profile, similar to the following:

- Channel width
- DOCSIS mode
- Frequency
- Minislot size
- Modulation-profile

The downstream controller-profile is used to specify the RF channels and their RF parameters that belong to a specific profile, including the following details:

- Channel type (DOCSIS, Video Sync, Video Async)
- Frequency
- RF output
- QAM-profile (annex, modulation, inter-leaver, symbol rate, and so on)

Your software release may not support all the features that are documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. The Feature Information Table at the end of this document provides information about the documented features and lists the releases in which each feature is supported.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://tools.cisco.com/ITDIT/CFN/>. An account on <http://www.cisco.com/> is not required.

- [Hardware Compatibility Matrix for Cisco Remote PHY Device, on page 2](#)
- [Controller Profile and RPD, on page 2](#)
- [Configure Controller Profile and RPD, on page 5](#)
- [Troubleshooting Tips, on page 14](#)
- [Configuration Examples, on page 14](#)

- [Feature Information for Remote PHY Controller Profile and RPD Configuration, on page 15](#)

## Hardware Compatibility Matrix for Cisco Remote PHY Device



**Note** Unless otherwise specified, the hardware components introduced in a given Cisco Remote PHY Device Software Release are supported in all subsequent releases.

**Table 1: Hardware Compatibility Matrix for the Cisco Remote PHY Device**

| Cisco HFC Platform                                      | Remote PHY Device  |
|---|--|
| Cisco GS7000 Super High Output Node                     | Cisco 1x2 / Compact Shelf RPD Software 2.1 and Later Releases  |
| Cisco GS7000 Super High Output Intelligent Node (iNode) | Cisco 1x2 / Compact Shelf RPD Software 4.1 and Later Releases<br><br>Cisco Intelligent Remote PHY Device 1x2 <ul style="list-style-type: none"> <li>• PID—iRPD-1X2=</li> <li>• PID—iRPD-1X2-PKEY=</li> </ul> |



**Note** The -PKEY suffix in the PID indicates units that enable the SCTE-55-2 Out-of-Band protocol support.

## Controller Profile and RPD

The Controller Profile functions in a similar way to the controller integrated-cable Slot/Bay/Port (for downstream controller) or upstream-cable Slot/Bay/Port (for upstream controller) in I-CMTS. However if a Controller Profile is not associated to an RPD, physical resources cannot be allocated.

You can create a controller profile that supports either unicast or multicast traffic. Multicast profile is used for downstream sharing. You can multicast the same traffic to all RPDs in the multicast group, or to applications such as switched digital video (SDV) or broadcast video.

An R-PHY configuration consists of one principal core interface and one auxiliary core interface. The principal core specifies the DPIC interface to which the RPD connects. Auxiliary core interfaces specify the external DPIC interfaces that can be used for downstream sharing. Auxiliary core is used in this release only for video multicast and video OOB.

Configuring Controller Profile and cable RPD are the prerequisites for configuring R-PHY video.

### RPD CIN QoS Marking Values

The following table lists the default DSCP values for different kinds of upstream packets.

| Packet Type                     | Per-Hop-Behavior (PHB) | DSCP Value |
|---------------------------------|------------------------|------------|
| BWR                             | EF                     | 46         |
| PTP                             | EF                     | 46         |
| RNG-REQ                         | EF                     | 46         |
| GCP                             | CS2                    | 16         |
| DLM (L2TP)                      | Best Effort / CS0      | 0          |
| DOCSIS data (L2TP)              | Best Effort / CS0      | 0          |
| L2TPv3 Control / L2TP Keepalive | Best Effort / CS0      | 0          |
| NDR                             | Best Effort / CS0      | 0          |
| OOB 55-1                        | Best Effort / CS0      | 0          |

**Note**

- In Cisco 1x2 / Compact Shelf RPD Software 9.3 and earlier releases, Per-Hop-Behavior for upstream GCP is Best Effort.
- For NDR, Per-Hop-Behavior and DSCP values in the table are the default values. You can configure alternate values while configuring static-pseudowires for NDR.
- For PTP, you can change the DSCP value by following the configuration method in [Cisco Remote PHY Device Software Configuration Guide for Cisco 1x2](#). For more information on PTP network principles, see [PTP Design Recommendations For R-PHY Networks](#).

The following table lists the default DSCP values for different kinds of downstream packets.

| Packet Type                    | Per-Hop-Behavior (PHB) | DSCP Value |
|--------------------------------|------------------------|------------|
| L2TP Control / L2TP Keepalive  | CS6                    | 48         |
| MAP/UCD (L2TP, DOCSIS control) | EF                     | 46         |
| OFDM PLC                       | EF                     | 46         |
| PTP                            | EF                     | 46         |
| MDD (L2TP, DOCSIS control)     | CS5                    | 40         |
| Voice                          | CS5                    | 40         |
| Broadcast Video                | CS4                    | 32         |
| Narrowcast Video               | CS4                    | 32         |
| OOB 55-1                       | CS2                    | 16         |

| Packet Type        | Per-Hop-Behavior (PHB)       | DSCP Value |
|--------------------|------------------------------|------------|
| DOCSIS data (L2TP) | Best Effort / CS0            | 0          |
| DLM (L2TP)         | Best Effort / CS0            | 0          |
| GCP                | Best Effort / CS0            | 0          |
| NDF                | Determined by traffic source |            |

## RPD Configurations

Compared to the iCMTS configuration, R-PHY configuration supports the following features:

- Up to 512 RPDs per cBR-8 chassis and 64 RPDs per CBR-CCAP-LC-G2-R line card
- 128 separate service groups per cBR-8 chassis
- 32 downstream-video controllers per CBR-CCAP-LC-G2-R line card
- 32 downstream-cable controllers per CBR-CCAP-LC-G2-R line card
- 80 downstream OFDM channels and up to 1536 downstream SC-QAM channels per CBR-CCAP-LC-G2-R line card
- Up to 158 downstream SC-QAM channels (0-157) per downstream controller
- 64 upstream controllers and 128 upstream channels per CBR-CCAP-LC-G2-R line card



### Note

- Cisco IOS XE Fuji 16.9.1 and later releases support 10 Gbps of upstream throughput on the CBR-CCAP-LC-G2-R line cards.
- In Cisco IOS XE Amsterdam 17.3.1 and earlier releases, each CBR-CCAP-LC-G2-R line card supports 32 downstream OFDM channels and up to 1024 downstream SC-QAM channels.

In the R-PHY configuration, the following mapping relationships are supported between the controller and the port on RPD:

- Downstream 1:N ( $N \geq 2$ ) mapping: one downstream controller is shared by several RPDs and one downstream controller is mapped to one downstream port of all these RPDs, that is “downstream virtual split”, all these downstream ports share the same signals from the same downstream controller.
- Downstream N:1 mapping: several downstream controllers are mapped into the same downstream port of one RPD. Notice: the downstream channels in these downstream controllers should use different rf-channel numbers.
- Downstream N:N mapping: mixed 1:N and N:1 mapping. For example: several downstream controllers are mapped into one downstream port of one RPD. But at the same time they are “virtual split” downstream controllers and are shared by several RPDs.
- Upstream 1:N ( $N \leq 8$ ) mapping: one upstream controller can be shared by N ( $N \leq 8$ ) upstream ports of multiple RPDs. Currently max two upstream ports are supported on one RPD, and for each upstream port, one upstream controller can be configured.

For the two upstream ports of one RPD, the same upstream controller number can be configured.



**Note** Downstream 1:1 mapping is not supported under 512 RPD configuration, but still supported under smaller scale configuration.

## Prerequisites for Configuring Controller Profile and RPD

The following restrictions are applicable to configuring controller profiles:

- All channels within the profiles of an RPD must be unique. Frequencies must not overlap each other.
- The principal core must contain at least one DOCSIS downstream profile
- Auxiliary core should contain only video and out-of-band profiles
- A DS controller can be associated to only one profile

## Restrictions for Configuring Controller Profile and RPD

The following restrictions are applicable to configuring upstream controller profiles:

- Legacy controller configuration commands are not supported
- Legacy controller configuration cannot be shown in running-configuration

# Configure Controller Profile and RPD

## Configure Upstream Controller Profile

To configure the upstream controller-profile, use the cable upstream controller-profile command, as given in the following example:

```
Router#cable upstream controller-profile 4
  cable def-phy-burst 0
  us-channel 0 chan-class-id 0
  us-channel 0 channel-width 1600000 1600000
  us-channel 0 docsis-mode atdma
  us-channel 0 equalization-coefficient
  us-channel 0 frequency 50000000
  us-channel 0 hop-priority frequency modulation channel-width
  us-channel 0 ingress-noise-cancellation 100
  us-channel 0 maintain-psd
  us-channel 0 max-logical-chans 1
  us-channel 0 minislots-size 4
  us-channel 0 modulation-profile 221
  us-channel 0 power-level 0
  us-channel 0 rng-holdoff 0
  us-channel 0 shutdown
  us-channel 0 specsvl error-adaptive-profile 1
  us-channel 0 threshold cnr-profiles 25 13
```

```

us-channel 0 threshold corr-fec 3
us-channel 0 threshold hysteresis 3
us-channel 0 threshold snr-profiles 25 13
us-channel 0 threshold uncorr-fec 1
...
end

```

## Verify Upstream Controller Profile Configuration

To verify the Upstream controller profile configuration, use the **show cable downstream controller-profile** command or **show running-config | section upstream controller-profile <ID>** command, as shown in the following example:

```

Router#show cable upstream controller-profile 0
Load for five secs: 2%/0%; one minute: 3%; five minutes: 3%
Time source is NTP, 15:14:27.916 CST Fri Feb 24 2017

Upstream controller-profile 0
Description:
Upstream controller-profile 0 is being used by controller Upstream-Cable:
8/0/1, 8/0/0
  Controller Upstream-Cable
  ...
  Upstream-channel 0
    chan-class-id           : 0x0
    channel-width           : 1600000 1600000
    docsis-mode              : atdma
    ...

```

Example for the **show running-config | section upstream controller-profile <ID>** command

```

Router#show running-config | s cable upstream controller-profile 0
cable upstream controller-profile 0
us-channel 0 channel-width 1600000 1600000
us-channel 0 docsis-mode atdma
us-channel 0 equalization-coefficient
us-channel 0 frequency 6000000
us-channel 0 minislots-size 4
us-channel 0 modulation-profile 221
no us-channel 0 shutdown
us-channel 1 channel-width 1600000 1600000
us-channel 1 docsis-mode atdma
us-channel 1 equalization-coefficient
us-channel 1 frequency 7600000
us-channel 1 minislots-size 4
us-channel 1 modulation-profile 221
no us-channel 1 shutdown
us-channel 2 channel-width 1600000 1600000
us-channel 2 docsis-mode atdma
us-channel 2 equalization-coefficient
us-channel 2 frequency 9200000
us-channel 2 minislots-size 4
us-channel 2 modulation-profile 221
no us-channel 2 shutdown
us-channel 3 channel-width 1600000 1600000
us-channel 3 docsis-mode atdma
us-channel 3 equalization-coefficient
us-channel 3 frequency 10800000
us-channel 3 minislots-size 4
us-channel 3 modulation-profile 221
no us-channel 3 shutdown
us-channel 4 channel-width 1600000 1600000
us-channel 4 docsis-mode atdma

```

```

us-channel 4 frequency 12400000
us-channel 4 minislots-size 4
us-channel 4 modulation-profile 221
no us-channel 4 shutdown
us-channel 5 channel-width 1600000 1600000
us-channel 5 docsis-mode atdma
us-channel 5 frequency 14000000
us-channel 5 minislots-size 4
us-channel 5 modulation-profile 221

```

## Configure RPD for US Controller Profile

To configure RPD for associating an upstream controller-profile, using the **rpds <port-id> Upstream-Cable <slot/sub-slot/controller> [profile <id>]** command, as given in the following example:

```

Router#cable rpd 1
  identifier 0004.9f00.0743
  core-interface Te8/1/0
  principal
    rpd-us 0 upstream-cable 8/0/0 profile 0
    rpd-us 1 upstream-cable 8/0/1 profile 4
  r-dti 11
  rpd-event profile 0
  rpd-55d1-us-event profile 0
---
end

```

The Remote PHY (R-PHY) Controller Profile now provides a new summary that displays the Per RPD us port description. The summary helps distinguish between the different controllers that share the same description of us-channels.

For example, the **show cable modem rpd all summary** command displays the following information:

```
Router#show cable modem rpd all summary
```

```

Load for five secs: 5%/0%; one minute: 5%; five minutes: 5%
No time source, *15:36:49.777 UTC Thu Mar 8 2018

```

```
RPD ID: badb.ad13.417c
```

| Interface | Cable Modem |     |      |       |         |          |        | Description |        |       |                     |
|-----------|-------------|-----|------|-------|---------|----------|--------|-------------|--------|-------|---------------------|
|           | Total       | Reg | Oper | Unreg | Offline | Wideband | initRC | initD       | initIO | initO |                     |
| C9/0/4/U0 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.417c us 0 |
| C9/0/4/U1 | 2           | 0   | 0    | 2     | 0       | 0        | 2      | 0           | 0      | 0     | badb.ad13.417c us 0 |
| C9/0/4/U3 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.417c us 0 |
| C9/0/5/U0 | 2           | 0   | 0    | 2     | 0       | 0        | 2      | 0           | 0      | 0     | badb.ad13.417c us 1 |
| C9/0/5/U1 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.417c us 1 |

```
RPD ID: badb.ad13.41fa
```

| Interface | Cable Modem |     |      |       |         |          |        | Description |        |       |                     |
|-----------|-------------|-----|------|-------|---------|----------|--------|-------------|--------|-------|---------------------|
|           | Total       | Reg | Oper | Unreg | Offline | Wideband | initRC | initD       | initIO | initO |                     |
| C9/0/2/U0 | 2           | 0   | 0    | 2     | 0       | 1        | 1      | 0           | 0      | 1     | badb.ad13.41fa us 0 |
| C9/0/2/U1 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.41fa us 0 |
| C9/0/2/U3 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.41fa us 0 |
| C9/0/3/U1 | 1           | 0   | 0    | 1     | 0       | 0        | 1      | 0           | 0      | 0     | badb.ad13.41fa us 1 |

```

C9/0/3/U2 2 0 0 2 0 0 2 0 0 0 badb.ad13.41fa
us 1
C9/0/3/U3 1 0 0 1 0 0 1 0 0 0 badb.ad13.41fa
us 1

```




---

**Note** The length of configurable limitation is 20 characters while there are 80 characters reserved.

---

## Configure Downstream Controller Profile

To configure downstream controller profile, use the following commands:

```

configure terminal
cable downstream controller-profile <profile ID>
multicast-pool <id>
rf-chan 20 47
type video <SYNC | ASYNC>
frequency 231000000
rf-output NORMAL
qam-profile <profile ID>

```

The *multicast-pool <id>* defines the DEPI multicast group. The type video *<SYNC / ASYNC>* defines synchronous or asynchronous mode.

## Verify Downstream Controller Profile Configuration

To verify the Downstream controller profile configuration, use the show cable downstream controller-profile command as shown in the following example:

```

Router#show running-config | section downstream controller-profile
cable downstream controller-profile 0
rf-chan 0 3
type DOCSIS
frequency 111000000
rf-output NORMAL
qam-profile 1
docsis-channel-id 1

```

## Configure RPD for DS Controller Profile

To configure RPD for associating a downstream controller-profile, use the following commands:

```

configure terminal
cable rpd RPD01
identifier 0004.9f31.0435
core-interface Te3/1/0
principal
rpd-ds 0 downstream-cable 3/0/0 profile 1
rpd-ds 0 downstream-cable 3/0/1 profile 2
rpd-us 0 upstream-cable 3/0/0 profile 1
core-interface te6/1/0
rpd-ds 0 downstream-cable 6/0/0 profile 2
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0

```



The **rpds 0 downstream-cable 3/0/0 profile 1** associates *controller 3/0/0* with *profile 1*, which is a DOCSIS profile.

The **rpds 0 downstream-cable 3/0/1 profile 2** associates *controller 3/0/1* with *profile 3*, which is a video profile.

The **core-interface te6/1/0** defines an auxiliary interface for this RPD. This auxiliary interface is used to configure downstream sharing across line cards.

## Verify RPD Association with Controller Profile

To verify the downstream controller profile association with RPD, use the **show running-config | section cable rpd <ID>** command as shown in the following example:

```
Router#show running-config | section cable rpd RPD01
cable rpd toi-test1
  identifier 0000.1cbf.0000
  core-interface Te2/1/0
  principal
    rpd-ds 0 downstream-cable 2/0/9 profile 0
  rpd-event profile 0
  rpd-55d1-us-event profile 0
```

## Configure Downstream Video Controller Profile

To configure a downstream video controller profile, use the following commands:

```
cable downstream controller-profile <profile ID> Video
max-carrier <RF Port Max Carrier Value>
rf-chan <Starting QAM ID> <Ending QAM ID>
  type VIDEO <SYNC | ASYNC>
  qam-profile <profile id>
  frequency 453000000
  rf-output NORMAL
```

### Configure RPD for Downstream Video Controller Profile

To configure RPD for associating a downstream video controller-profile, use the following commands:

```
cable rpd RPD01
identifier 0053.ad17.5c80
core-interface Tel1/1/0
  principal
    rpd-ds 0 downstream-cable 1/0/0 profile 7
    rpd-ds 0 downstream-video 1/0/0 profile 100
    rpd-us 0 upstream-cable 1/0/1 profile 3
  r-dti 7
  rpd-event profile 0
  rpd-55d1-us-event profile 0
```

The **rpds 0 downstream-cable 1/0/0 profile 7** associates *controller 1/0/0* with *profile 7*, which is a DOCSIS profile.

The **rpds 0 downstream-video 1/0/0 profile 100** associates *controller 1/0/0* with *profile 100*, which is a video profile.

**Note**

- The **rpds downstream-video** command is available from Cisco IOS XE Gibraltar 16.12.1 release and Cisco IOS XE Amsterdam 17.3.1x release. Using this command, you can create up to 32 separate video service groups on the Kobl-R line card.
- We recommend using **rpds downstream-video** command for video channels and **rpds downstream-cable** command for DOCSIS channels.
- We do not recommend using **downstream-cable** controllers for video and DOCSIS channels simultaneously. Use **downstream-video** controllers for video channels.

## Configure Analog Tx/Rx Modules Alarm Threshold

To adjust the alarm threshold of the analog Tx/Rx module in RPD node, use **analog** commands as shown in the following example:

```
configure terminal
cable rpd RPD01
identifier 0004.9f31.0435
core-interface Te3/1/0
principal
rpds 0 downstream-cable 3/0/0 profile 1
rpds 0 downstream-cable 3/0/1 profile 2
rpds 0 upstream-cable 3/0/0 profile 1
r-dti 1
rpd-event profile 0
rpd-55d1-us-event profile 0
analog rx-power major-lo-th 0 minor-lo-th 50 normal-th 150 minor-hi-th 200
analog tx-power major-lo-th 0 minor-lo-th 50 normal-th 100 minor-hi-th 150
```

## Verify Analog Tx/Rx Modules Alarm Threshold Configuration

To verify the analog Tx/Rx module alarm threshold configuration, use **show environment** commands in RPD as shown in the following example:

```
R-PHY#show environment table 49
sensor_id: 49
name: TX1_OPT_PWR_MON
.....
Configuration Values:
```

| state      | low  | high |
|------------|------|------|
| MAJOR-LOW  | N/A  | 0.00 |
| MINOR-LOW  | 0.00 | 0.59 |
| NORMAL     | 0.60 | 1.09 |
| MINOR-HIGH | 1.10 | 1.59 |
| MAJOR-HIGH | 1.60 | N/A  |

## Configure Downstream Sharing

This configuration is optional. DS sharing is used for multicast (MC) traffic. To configure downstream sharing, use the following commands:

```

configure terminal
cable rpd RPD01
core-interface Te3/1/0
principal
rpd-ds 0 downstream-cable 3/0/1 profile 2
cable rpd RPD02
core-interface te3/1/0
principal
rpd-ds 0 downstream-cable 3/0/1 profile 2

```



**Note** All RDPs in the same multicast group should have the same controller and profile association.

## Configure Controller in Fiber Node

To configure the controllers in fiber-node, use the **cable fiber-node** command, as given in the following example:

```

cable fiber-node 113
downstream Downstream-Cable 8/0/0
upstream Upstream-Cable 8/0/1

```

## Verify CM RPD Association

To verify the RPD associated with the cable modem, use the **show cable modem rpd** command as shown in the following example:

```

Router# show cable modem rpd 0004.9f03.0249
Load for five secs: 4%/2%; one minute: 3%; five minutes: 4%
Time source is NTP, 10:48:11.763 CST Tue Feb 28 2017

```

| MAC Address    | IP Address  | I/F       | MAC State | Prim Sid | RxPwr (dBmv) | Timing Offset | Num CPE | I P |
|----------------|-------------|-----------|-----------|----------|--------------|---------------|---------|-----|
| 0023.be5a.bb6c | 10.10.10.12 | C6/0/0/UB | w-online  | 5        | 0.00         | 862           | 0       | N   |
| 1859.3356.8876 | 10.10.10.13 | C6/0/0/UB | w-online  | 6        | 0.50         | 907           | 0       | N   |

## Display GCP Related Information

To display Generic Control Plane (GCP) related information of the RPD, use the command as shown in the following example:

```

Router#show cable rpd 0004.9f03.0280 Te3/1/0 gcp-state

```

| MAC Address    | IP Address  | I/F     | State | Role | HA  | Name |
|----------------|-------------|---------|-------|------|-----|------|
| 0004.9f03.0280 | 10.10.10.11 | Te3/1/0 | ready | Pri  | Act | 2    |

```

A06#show cable rpd 0004.9f03.0280 Te3/1/0 gcp-state
MAC Address      IP Address      I/F      State      Role HA Name
0004.9f03.0280  10.10.10.11    Te3/1/0  ready      Pri Act 2

Router#show cable rpd name node te1/1/0 gcp-session

GCP Session ID : 10
Core Address    : 10.100.10.11:8190
RPD Address     : 10.10.10.11:60656
Next Hop MAC    : 0004.9F00.0901

```

## Display DEPI Related Information

```
Session State : Active
```

```
Packet Statistics:
```

```
=====
Rx          : 5038
Tx          : 5034
Rx Dropped : 0
Tx Dropped : 0
```

```
Message Statistics:
```

```
=====
Rx          : 5948
Tx          : 5954
Rx Dropped : 7
Tx Dropped : 0
Rx Illegal : 0
Tx Illegal : 0
```

```
Router#show cable rpd 120.102.6.7 te9/1/1 gcp-transaction
```

```
Load for five secs: 3%/1%; one minute: 4%; five minutes: 4%
No time source, *10:22:57.158 CST Thu Mar 16 2017
```

| RPD ID                         | I/F     | TRANS ID | GCP MSG TYPE       | RCP MSG TYPE | TIMESTAMP  |
|--------------------------------|---------|----------|--------------------|--------------|------------|
| 0004.9f31.1007<br>10:22:54.440 | Te9/1/1 | 7452     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:54.415 | Te9/1/1 | 7452     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:54.240 | Te9/1/1 | 7451     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:54.215 | Te9/1/1 | 7451     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:54.040 | Te9/1/1 | 7450     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:54.015 | Te9/1/1 | 7450     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:53.836 | Te9/1/1 | 7449     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:53.815 | Te9/1/1 | 7449     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:50.236 | Te9/1/1 | 7448     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:50.215 | Te9/1/1 | 7448     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:50.038 | Te9/1/1 | 7447     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:50.015 | Te9/1/1 | 7447     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:49.839 | Te9/1/1 | 7446     | GCP_MSG_ID_EDS_RSP | TYPE_REX     | 2017-03-16 |
| 0004.9f31.1007<br>10:22:49.815 | Te9/1/1 | 7446     | GCP_MSG_ID_EDS     | TYPE_REX     | 2017-03-16 |

## Display DEPI Related Information

To display the Downstream External PHY Interface (DEPI) related information, use the command as shown in the following example:

```
Router#show cable rpd depi
```

```
DEPI Tunnel and Session Information Total tunnels 1 sessions 26
```

```

LocTunID  RemTunID  Remote Device  State  Remote Address  Sessn L2TP Class
Count
338514820  671581873  0004.9f00.0901  est    10.10.10.11    26    rphy-l2tp-gl...

```

```

LocID      RemID      Pseudowire      State  Last Chg Uniq ID  Type Mode RemSt
0x41040008 0x00000B02 US1/0/0:2(R)    est    00:34:57 21    P    PSP  UP
0x41010000 0x00000600 US1/0/0:0(D)    est    00:34:57 11    P    PSP  UP
0x00002006 0x00000405 DS1/0/0:5       est    00:34:57 6     P    PSP  UP
0x00002004 0x00000403 DS1/0/0:3       est    00:34:57 4     P    PSP  UP
0x4100000C 0x00000D03 US1/0/0:3(M)    est    00:34:57 23    P    PSP  UP
0x00002002 0x00000401 DS1/0/0:1       est    00:34:57 2     P    PSP  UP
0x00002007 0x00000406 DS1/0/0:6       est    00:34:57 7     P    PSP  UP
0x00002008 0x00000407 DS1/0/0:7       est    00:34:57 8     P    PSP  UP
0x4101000C 0x00000603 US1/0/0:3(D)    est    00:34:57 24    P    PSP  UP
0x41000004 0x00000D01 US1/0/0:1(M)    est    00:34:57 15    P    PSP  UP
0x00002001 0x00000400 DS1/0/0:0       est    00:34:57 1     P    PSP  UP
0x41080008 0x00000F02 US1/0/0:2(S)    est    00:34:57 22    P    PSP  UP
0x41010004 0x00000601 US1/0/0:1(D)    est    00:34:57 16    P    PSP  UP
0x41020000 0x00000800 US1/0/0:0(B)    est    00:34:57 12    P    PSP  UP
0x00002009 0x00000408 DS1/0/0:8       est    00:34:57 9     P    PSP  UP
0x41010008 0x00000602 US1/0/0:2(D)    est    00:34:57 20    P    PSP  UP
0x41000008 0x00000D02 US1/0/0:2(M)    est    00:34:57 19    P    PSP  UP
0x4108000C 0x00000F03 US1/0/0:3(S)    est    00:34:57 26    P    PSP  UP
0x00002003 0x00000402 DS1/0/0:2       est    00:34:57 3     P    PSP  UP
0x41080000 0x00000F00 US1/0/0:0(S)    est    00:34:57 14    P    PSP  UP
0x41040004 0x00000B01 US1/0/0:1(R)    est    00:34:57 17    P    PSP  UP
0x41080004 0x00000F01 US1/0/0:1(S)    est    00:34:57 18    P    PSP  UP
0x41000000 0x00000D00 US1/0/0:0(M)    est    00:34:56 10    P    PSP  UP
0x00002005 0x00000404 DS1/0/0:4       est    00:34:56 5     P    PSP  UP
0x4104000C 0x00000B03 US1/0/0:3(R)    est    00:34:56 25    P    PSP  UP
0x41040000 0x00000B00 US1/0/0:0(R)    est    00:34:56 13    P    PSP  UP

```

```
outer#show cable rpd 0004.9f03.0214 te7/1/0 depi tunnel
```

```

Load for five secs: 7%/2%; one minute: 6%; five minutes: 6%
No time source, *12:41:44.228 CST Mon Mar 20 2017

```

```

LocTunID  RemTunID  Remote Device  State  Remote Address  Sessn L2TP Class
Count
3388764998 1054297851 0004.9f03.0214  est    10.10.10.11    29    rphy-l2tp-gl...

```

**Table 2: show cable rpd depi Field Descriptions**

| Field        | Description   |
|--------------|---|
| LocID        | Local session ID.   |
| RemID        | Remote session ID.  |
| US1/0/0:2(R) | US means UEPI session, DS means DEPI session. This string means UEPI session on line card slot 1, controller 0, rf-channel 2. |
| est in State | Established state.  |
| P in Type    | On primary line card.   |

## Troubleshooting Tips

Refer to the following troubleshooting tips if configuration errors occur.

If you configure DS controller profile and cable RPD, you can check the controller status, regardless of the status of the RPD. If the channel's state is DOWN, use verbose option to view the reason.

```
Router#show controllers downstream-Cable 6/0/1 rf-channel 20 <verbose>
Chan State Admin Frequency Type Annex Mod srates Interleaver dcid output
20 UP UP 231000000 VIDEO-SYNC B 256 5361 I128-J1 - NORMAL
```

## Configuration Examples

This section provides example configurations for the R-PHY Controller Profile.

### Example: Controller Profile Configuration

#### Upstream Controller Profile Configuration

```
configure terminal
cable upstream controller-profile 2
  cable def-phy-burst 0
  us-channel 0 chan-class-id 0
  us-channel 0 channel-width 1600000 1600000
  us-channel 0 docsis-mode atdma
  us-channel 0 equalization-coefficient
  us-channel 0 frequency 50000000
  us-channel 0 hop-priority frequency modulation channel-width
  us-channel 0 ingress-noise-cancellation 100
  us-channel 0 maintain-psd
  us-channel 0 max-logical-chans 1
  us-channel 0 minislots-size 4
  us-channel 0 modulation-profile 221
  us-channel 0 power-level 0
  us-channel 0 rng-holdoff 0
  us-channel 0 shutdown
  us-channel 0 specsvl error-adaptive-profile 1
  us-channel 0 threshold cnr-profiles 25 13
  us-channel 0 threshold corr-fec 3
  us-channel 0 threshold hysteresis 3
  us-channel 0 threshold snr-profiles 25 13
  us-channel 0 threshold uncorr-fec 1
  ...
end
```

#### Downstream Controller Profile Configuration

```
configure terminal
cable downstream controller-profile 1
multicast-pool 20
Rf-channel 0 15
Type docsis
Frequency 111000000
Rf-output NORMAL
Qam-profile 1
Docsis-channel-id 1
```

```

cable downstream controller-profile 2
multicast-pool 20
Rf-channel 20 47
Type video sync
Frequency 231000000
Rf-output NORMAL
Qam-profile 14

```

## Example: Downstream Sharing Configuration

```

cable rpd RPD01
identifier 0004.9f31.0979
core-interface te6/1/0
principal
rpd-ds 0 downstream-cable 6/0/0 profile 1
rpd-ds 0 downstream-cable 6/0/1 profile 2
rpd-us 0 upstream-cable 6/0/0 profile 1
r-dti 6
rpd-event profile 0
rpd-55dl-us-event profile 0
cable rpd RPD2
identifier 0004.9f31.1437
core-interface Te3/1/0
principal
rpd-ds 0 downstream-cable 3/0/0 profile 1
rpd-us 0 upstream-cable 3/0/0 profile 1
core-interface Te6/1/0
rpd-ds 0 downstream-cable 6/0/1 profile 2
r-dti 3
rpd-event profile 0
rpd-55dl-us-event profile 0

```

## Feature Information for Remote PHY Controller Profile and RPD Configuration

Use Cisco Feature Navigator to find information about the platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to the <https://cfng.cisco.com/> link. An account on the Cisco.com page is not required.



**Note** The following table lists the software release in which a given feature is introduced. Unless noted otherwise, subsequent releases of that software release train also support that feature.

**Table 3: Feature Information for Remote PHY Controller Profile and RPD Configuration**

| Feature Name   | Releases                                   | Feature Information   |
|--|--|---|
| Large Scale Controller Support (32DS/64US) with node | Cisco 1x2 / Compact Shelf RPD Software 3.1 | This feature was integrated into the Cisco Remote PHY Device. |
| 256 RPD Support per Chassis                          | Cisco 1x2 / Compact Shelf RPD Software 3.1 | This feature was integrated into the Cisco Remote PHY Device. |

| Feature Name                     | Releases                                   | Feature Information   |
|----------------------------------|--|---|
| Controller profile configuration | Cisco 1x2 / Compact Shelf RPD Software 3.1 | This feature was integrated into the Cisco Remote PHY Device. |
| US 128 channels                  | Cisco 1x2 / Compact Shelf RPD Software 3.1 | This feature was integrated into the Cisco Remote PHY Device. |