



IP Multicast Dynamic NAT

Last Updated: November 29, 2012

The IP Multicast Dynamic Network Address Translation (NAT) feature supports the source address translation of multicast packets. You can use source address translation when you want to connect to the Internet, but not all your hosts have globally unique IP addresses. NAT translates the internal local addresses to globally unique IP addresses before sending packets to the outside network. The IP multicast dynamic translation establishes a one-to-one mapping between an inside local address and one of the addresses from the pool of outside global addresses.

- [Finding Feature Information, page 1](#)
- [Restrictions for IP Multicast Dynamic NAT, page 1](#)
- [Information About IP Multicast Dynamic NAT, page 2](#)
- [How to Configure IP Multicast Dynamic NAT, page 3](#)
- [Configuration Examples for IP Multicast Dynamic NAT, page 6](#)
- [Additional References, page 7](#)
- [Feature Information for IP Multicast Dynamic NAT, page 7](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Restrictions for IP Multicast Dynamic NAT

The IP Multicast Dynamic NAT feature does not support:

- IPv4-to-IPv6 address translation.
- Multicast destination address translation.
- Port Address Translation (PAT) overloading for multicast.
- Source and destination address translation.



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- Unicast-to-multicast address translation.

Information About IP Multicast Dynamic NAT

- [How NAT Works, page 2](#)
- [Uses of NAT, page 2](#)
- [NAT Inside and Outside Addresses, page 2](#)
- [Dynamic Translation of Addresses, page 3](#)

How NAT Works

A router configured with NAT will have at least one interface to the inside network and one to the outside network. In a typical environment, NAT is configured at the exit router between a stub domain and a backbone. When a packet leaves the domain, NAT translates the locally significant source address into a globally unique address. When a packet enters the domain, NAT translates the globally unique destination address into a local address. If more than one exit point exists, each NAT must have the same translation table. If NAT cannot allocate an address because it has run out of addresses, it drops the packet and sends an Internet Control Message Protocol (ICMP) host unreachable packet.

Uses of NAT

NAT can be used for the following applications:

- When you want to connect to the Internet, but not all of your hosts have globally unique IP addresses. NAT enables private IP internetworks that use nonregistered IP addresses to connect to the Internet. NAT is configured on the router at the border of a stub domain (referred to as the *inside network*) and a public network such as the Internet (referred to as the *outside network*). NAT translates internal local addresses to globally unique IP addresses before sending packets to the outside network. As a solution to the connectivity problem, NAT is practical only when relatively few hosts in a stub domain communicate outside of the domain at the same time. When this is the case, only a small subset of the IP addresses in the domain must be translated into globally unique IP addresses when outside communication is necessary, and these addresses can be reused when they are no longer in use.
- When you must change your internal addresses. Instead of changing the internal addresses, which can be a considerable amount of work, you can translate them by using NAT.
- When you want to do basic load sharing of TCP traffic. You can map a single global IP address to many local IP addresses by using the TCP load distribution feature.

NAT Inside and Outside Addresses

The term *inside* in a NAT context refers to networks owned by an organization that must be translated. When NAT is configured, hosts within this network will have addresses in one space (known as the *local* address space) that will appear to those outside the network as being in another space (known as the *global* address space).

Similarly, *outside* refers to those networks to which the stub network connects, and which are generally not under the control of the organization. Hosts in outside networks can be subject to translation, and can thus have local and global addresses.

NAT uses the following definitions:

- Inside local address--The IP address that is assigned to a host on the inside network. The address is probably not a legitimate IP address assigned by the NIC or service provider.
- Inside global address--A legitimate IP address (assigned by the NIC or service provider) that represents one or more inside local IP addresses to the outside world.
- Outside local address--The IP address of an outside host as it appears to the inside network. The address is not necessarily legitimate; it was allocated from the address space routable on the inside.
- Outside global address--The IP address that is assigned to a host on the outside network by the owner of the host. The address was allocated from a globally routable address or network space.

Dynamic Translation of Addresses

Dynamic translation establishes a mapping between an inside local address and a pool of global addresses. Dynamic translation is useful when multiple users on a private network need to access the Internet. The dynamically configured pool IP address may be used as needed and is released for use by other users when access to the Internet is no longer required.



Note

When inside global or outside local addresses belong to a directly connected subnet on a NAT router, the router will add IP aliases for them so that it can answer Address Resolution Protocol (ARP) requests. However, a situation can arise where the router itself answers packets that are not destined for it, possibly causing a security issue. This can happen when an incoming Internet Control Message Protocol (ICMP) or UDP packet that is destined for one of the aliased addresses does not have a corresponding NAT translation in the NAT table, and the router itself runs a corresponding service, for example, the Network Time Protocol (NTP). Such a situation might cause minor security risks.

How to Configure IP Multicast Dynamic NAT

- [Configuring IP Multicast Dynamic NAT, page 3](#)

Configuring IP Multicast Dynamic NAT



Note

IP multicast dynamic translation establishes a one-to-one mapping between an inside local address and one of the addresses from the pool of outside global addresses

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip nat pool** *name start-ip end-ip* { **netmask** *netmask* | **prefix-length** *prefix-length* } [**type** { **match-host** | **rotary** }]
4. **access-list** *access-list-number* **permit** *source-address wildcard-bits* [**any**]
5. **ip nat inside source list** *access-list-number* **pool** *name*
6. **ip multicast-routing distributed**
7. **interface** *type number*
8. **ip address** *ip-address mask*
9. **ip pim sparse-mode**
10. **ip nat inside**
11. **exit**
12. **interface** *type number*
13. **ip address** *ip-address mask*
14. **ip pim sparse-mode**
15. **ip nat outside**
16. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3	ip nat pool <i>name start-ip end-ip</i> { netmask <i>netmask</i> prefix-length <i>prefix-length</i> } [type { match-host rotary }] Example: <pre>Router(config)# ip nat pool mypool 10.41.10.1 10.41.10.23 netmask 255.255.255.0</pre>	Defines a pool of global addresses to be allocated as needed.

	Command or Action	Purpose
Step 4	<p>access-list <i>access-list-number</i> permit <i>source-address wildcard-bits</i> [any]</p> <p>Example: Router(config)# access-list 100 permit 10.3.2.0 0.0.0.255 any</p>	Defines a standard access list for the inside addresses that are to be translated.
Step 5	<p>ip nat inside source list <i>access-list-number</i> pool <i>name</i></p> <p>Example: Router(config)# ip nat inside source list 100 pool mypool</p>	Establishes dynamic source translation, specifying the access list defined in the prior step.
Step 6	<p>ip multicast-routing distributed</p> <p>Example: Router(config)# ip multicast-routing distributed</p>	Enables Multicast Distributed Switching (MDS).
Step 7	<p>interface <i>type number</i></p> <p>Example: Router(config)# interface gigabitethernet 0/0/0</p>	Configures an interface and enters interface configuration mode.
Step 8	<p>ip address <i>ip-address mask</i></p> <p>Example: Router(config-if)# ip address 10.1.1.1 255.255.255.0</p>	Sets a primary or secondary IP address for an interface.
Step 9	<p>ip pim sparse-mode</p> <p>Example: Router(config-if)# ip pim sparse-mode</p>	Enables sparse mode operation of Protocol Independent Multicast (PIM) on an interface.
Step 10	<p>ip nat inside</p> <p>Example: Router(config-if)# ip nat inside</p>	Indicates that the interface is connected to the inside network (the network that is subject to NAT translation).
Step 11	<p>exit</p> <p>Example: Router(config-if)# exit</p>	Exits interface configuration mode and enters global configuration mode.

Command or Action	Purpose
Step 12 <code>interface type number</code> Example: Router(config)# interface gigabitethernet 0/0/1	Configures an interface and enters interface configuration mode.
Step 13 <code>ip address ip-address mask</code> Example: Router(config-if)# ip address 10.2.2.1 255.255.255.0	Sets a primary or secondary IP address for an interface.
Step 14 <code>ip pim sparse-mode</code> Example: Router(config-if)# ip pim sparse-mode	Enables sparse mode operation of PIM on an interface.
Step 15 <code>ip nat outside</code> Example: Router(config-if)# ip nat outside	Indicates that the interface is connected to the outside network.
Step 16 <code>end</code> Example: Router(config-if)# end	Exits interface configuration mode and enters privileged EXEC mode.

Configuration Examples for IP Multicast Dynamic NAT

- [Example: Configuring IP Multicast Dynamic NAT, page 6](#)

Example: Configuring IP Multicast Dynamic NAT

```

Router# configure terminal
Router(config)# ip nat pool mypool 10.41.10.1 10.41.10.23 netmask 255.255.255.0
Router(config)# access-list 100 permit 10.3.2.0 0.0.0.255 any
Router(config)# ip nat inside source list 100 pool mypool
Router(config)# ip multicast-routing distributed
Router(config)# interface gigabitethernet 0/0/0
Router(config-if)# ip address 10.0.0.1 255.255.255.0
Router(config-if)# ip pim sparse-mode
Router(config-if)# ip nat inside
Router(config-if)# exit
Router(config)# interface gigabitethernet 0/0/1
Router(config-if)# ip address 10.2.2.1 255.255.255.0
Router(config-if)# ip pim sparse-mode
Router(config-if)# ip nat outside
Router(config-if)# end

```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	<i>Cisco IOS Master Commands List, All Releases</i>
NAT commands	<i>Cisco IOS IP Addressing Services Command Reference</i>
Configuring NAT for IP address conservation	<i>Configuring NAT for IP Address Conservation module</i>

Standards and RFCs

Standard/RFC	Title
None	—

MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for IP Multicast Dynamic NAT

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software

release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1 **Feature Information for IP Multicast Dynamic NAT**

Feature Name	Releases	Feature Information
IP Multicast Dynamic NAT	Cisco IOS XE Release 3.4S	The IP Multicast Dynamic Network Address Translation feature supports the source address translation of multicast packets. You can use source address translation when you want to connect to the Internet, but not all your hosts have globally unique IP addresses. NAT translates the internal local addresses to globally unique IP addresses before sending packets to the outside network. The IP multicast dynamic translation establishes a one-to-one mapping between an inside local address and one of the addresses from the pool of outside global addresses.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2012 Cisco Systems, Inc. All rights reserved.