

# IS-IS Support for an IS-IS Instance per VRF for IP

This feature provides multiple VRF-aware IS-IS instances. The VRF functionality allows Internet service providers (ISPs) to separate routing protocol information and propagate it to the appropriate routing table and network neighbors. Using one router with VRF functionality is more cost-effective than using separate routers to separate and forward the routing information.

- Finding Feature Information, page 1
- Prerequisites for IS-IS Support for an IS-IS Instance per VRF for IP, page 2
- Restrictions for IS-IS Support for an IS-IS Instance per VRF for IP, page 2
- Information About IS-IS Support for an IS-IS Instance per VRF for IP, page 3
- How to Configure IS-IS Support for an IS-IS Instance per VRF for IP, page 3
- Configuration Examples for IS-IS Support for an IS-IS Instance per VRF for IP, page 8
- Additional References, page 12
- Feature Information for IS-IS Support for an IS-IS Instance per VRF for IP, page 13

# **Finding Feature Information**

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see **Bug Search** Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

# Prerequisites for IS-IS Support for an IS-IS Instance per VRF for IP

- It is presumed that you are running IS-IS on your network.
- The VRF configuration is a prerequisite to associating an IS-IS instance with that specific VRF. However, the VRF configuration is independent of associating it with IS-IS or any other routing protocol. An IS-IS instance cannot be referred to as being VRF-aware until it has been associated with a particular VRF.

# **Restrictions for IS-IS Support for an IS-IS Instance per VRF for IP**

Support for IS-IS VRF is provided only for IPv4.

When you configure the IS-IS Support for an IS-IS Instance per VRF for IP feature, you must comply with the following nine best-practice guidelines:

- IS-IS instances running Connectionless Network Services (CLNS) must have the same system ID.
- An IS-IS instance that is running CLNS or IPv6 cannot be associated with a VRF.
- You can configure only one IS-IS instance to run both CLNS and IP.
- IS-IS instances within the same VRF must have unique system IDs, although IS-IS instances located in separate VRFs can have the same system ID.
- You can associate an IS-IS instance with only one VRF.
- You can configure the passive-interface default command only on one IS-IS instance per VRF.
- · Redistribution is allowed only within the same VRF.
- · You can enable only one IS-IS instance per interface.
- An interface can belong to an IS-IS instance only if it is associated with the same VRF.



If you are using LDP, you cannot use the **route-target** command when configuring a VRF. The router will use BGP for Multiprotocol Label Switching (MPLS) labels.

# Information About IS-IS Support for an IS-IS Instance per VRF for IP

## **VRF-Aware IS-IS**

You can configure IS-IS to be VPN routing and forwarding (VRF)-aware. A VRF consists of an IP routing table, a derived Cisco Express Forwarding (CEF) table, a set of interfaces that use the forwarding table, and a set of rules and routing protocol parameters that control the information that is included in the routing table.

## **IS-IS Support for an IS-IS Instance per VRF for IP Feature Operation**

ISPs have the capability to create multiple VRF-aware IS-IS instances that run on one router, rather than requiring duplicate hardware. IS-IS can be enabled to be VRF-aware, and ISPs can use multiple VRF-aware IS-IS instances to separate customer data while propagating the information to appropriate service providers.

For example, an ISP can create three VRFs--VRF First, VRF Second, and VRF Third--to represent three separate customers. A VRF-aware IS-IS instance is created and associated with each VRF: tagFIRST, tagSECOND, and tagTHIRD. Each instance will have its own routing process, IS-IS database, and routing table, and will calculate its own shortest path first (SPF) tree.

# How to Configure IS-IS Support for an IS-IS Instance per VRF for IP

## **Creating a VRF**

#### **Before You Begin**

- It is presumed that you have IS-IS running on your network.
- If CEF is not enabled by default on your platform, you will need to enable CEF in order to associate interfaces with VRF-aware IS-IS instances.

#### SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3.** ip cef [distributed]
- 4. ip vrf vrf-name
- 5. rd route-distinguisher

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	ip cef [distributed]	Enables CEF on the Route Processor card.
	Example:	• If CEF is not enabled by default on your particular platform, you must configure it with the <b>ip cef</b> command.
	<pre>Device(config)# ip cef distributed</pre>	
Step 4	ip vrf vrf-name	Configures a VRF routing table, and enters VRF configuration mode.
	Example:	
	Device(config)# ip vrf first	
Step 5	rd route-distinguisher	Creates routing and forwarding tables for a VRF.
	Example:	
	Device(config-vrf)# rd 1:1	

# Attaching an Interface to the VRF

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- **3.** interface type number
- 4. ip vrf forwarding vrf-name
- 5. end

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	interface type number	Configures an interface type and enters interface configuration mode.
	Example:	
	Device(config)# interface GigabitEthernet 0/0	
Step 4	ip vrf forwarding vrf-name	Associates a VPN routing and forwarding instance (VRF) with an interface or subinterface.
	Example:	
	<pre>Device(config-if)# ip vrf forwarding vrffirst</pre>	
Step 5	end	Exits interface configuration mode and returns to privileged EXEC mode.
	Example:	
	Device(config-if)# end	

# **Creating VRF-Aware IS-IS Instances**

### Prerequisites

Before you create VRF-aware IS-IS instances, you need to enable IP routing on the router.



I

Only one instance within the VRF can be configured as the passive interface default.

### **Creating a VRF-Aware IS-IS Instance in Interface Configuration Mode**

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- **3.** interface type number
- 4. ip address ip-address mask [secondary]
- 5. ip router isis process-tag
- 6. no shutdown
- 7. end

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	interface type number	Configures an interface type and enters interface configuration mode.
	Example:	
	<pre>Device(config)# interface GigabitEthernet     0/2/0</pre>	
Step 4	<b>ip address</b> <i>ip-address</i> mask [secondary]	Sets a primary or secondary IP address for an interface.
	Example:	
	Device(config-if)# ip address 172.16.11.1 255.255.255.255	
Step 5	ip router isis process-tag	Configures an IS-IS routing process for IP on an interface and attaches a tag to the routing process.
	Example:	
	<pre>Device(config-if)# ip router isis tagfirst</pre>	

	Command or Action	Purpose	
		<b>Note</b> The configuration of the interface-mode <b>ip router isis</b> command will overwrite the prior configuration on that interface, but only if the new configuration is attempting to change the interface ownership to a different instance that is in the same VRF as the currently configured owner instance. The configuration will be rejected if the attempted change is between two instances that are associated with different VRFs.	
Step 6	no shutdown	Restarts a disabled interface.	
	Example:		
	Device(config-if)# no shutdown		
Step 7	end	Exits interface configuration mode.	
	Example:		
	Device(config-if)# end		

### **Creating a VRF-Aware IS-IS Instance in Router Configuration Mode**

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- 3. router isis process-tag
- 4. vrf vrf-name
- **5. net** *network-entity-title*
- 6. end

#### **DETAILED STEPS**

I

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	

	Command or Action	Purpose
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	router isis process-tag	Enables the IS-IS routing protocol, specifies an IS-IS process, and enters router configuration mode.
	Example:	• It is presumed that the VRF named First was
	<pre>Device(config-if)# router isis tagFirst</pre>	previously created.
Step 4	vrf vrf-name	Associates an IS-IS instance with a VRF.
	Example:	
	Device(config-router)# vrf first	
Step 5	net network-entity-title	Configures an IS-IS NET for a CLNS routing process.
	Example:	
	Device(config-router)# net 49.000b.0000.0001.0002.00	
Step 6	end	Exits router configuration mode.
	Example:	
	Device(config-router)# end	

# Configuration Examples for IS-IS Support for an IS-IS Instance per VRF for IP

## **Example Configuring Multiple VRF-Aware IS-IS Instances**

In the following example, the VRF Second is created and an IS-IS instance is created explicitly by entering the **router isis** command on the router:

```
Device(config)# ip cef distributed
Device(config)# ip routing
Device(config)# ip vrf Second
Device(config-vrf)# rd 1:1
Device(config-if)# router isis tagSecond
Device(config-router)# vrf Second
Device(config-router)# net 49.000b.0000.0001.0002.00
```

The VRF Third is created and a VRF-aware IS-IS instance is automatically created when the **ip router isis** command is entered:

Device(config)# ip vrf Third Device(config-vrf)# rd 1:1 Device(config-if)# interface GigabitEthernet0/2/0 Device(config-if)# ip vrf forwarding Third Device(config-if)# ip address 172.16.10.1 255.255.255.0 Device(config-if)# ip router isis tagThird Device(config-if)# no shutdown

A new IS-IS instance with the process tag tagThird will automatically be created and associated with the VRF Third. When the **show running-config** command is entered, the following information for the new IS-IS instance will be displayed:

The following sample output verifies information for the VRF-aware IS-IS instances that were created in the previous examples:

Device# show isis tagThird topology Tag tagThird: IS-IS paths to level-2 routers System Id Metric Next-Hop Interface SNPA router-02 10 router-02 GE4/3/00010.0ddc.e00b router-03 10 router-03 GE0/2/00006.0e03.0c45 router-04 10 router-04 GE4/0/0 000a.f3c3.1c70 router-04 GE4/1/0 000a.f3c3.1c71 Device# show clns tagSecond neighbors Tag tagSecond: System Id Interface SNPA State Holdtime Type Protocol 00d0.2b7f.9502 router-03 GE0/2/0 Up g L2 IS-IS 27 router-03 PO2/2/0 DLCI 211 L2 IS-IS Up PO2/0/0 Up router-02 DLCI 131 29 L2 IS-IS GE0/4/0 7 router-11 000e.d79d.7920 L2 Up IS-IS GE0/5/0 000e.d79d.7921 8 T.2 router-11 Up TS-TS router-11 PO3/2/0 DLCI 451 Up 24 L2 IS-IS Device# show isis tagThird database level-2 Tag tagThird: IS-IS Level-2 Link State Database: LSP Seq Num LSP Checksum LSP Holdtime ATT/P/OL LSPID router-01.00-00 0x000000A 0x5E73 914 0/0/0 0x0000001 router-01.03-00 0x8E41 894 0/0/0 router-01.04-00 0x0000001 0x8747 894 0/0/0 router-03.00-00 0x00000005 0x55AD 727 0/0/0 router-03.02-00 \* 0x0000001 0x3B97 727 0/0/0 router-02.00-00 0x00000004 0xC1FB 993 0/0/0 router-02.01-00 0x0000001 0x448D 814 0/0/0 router-04.00-00 0x0000004 0x76D0 892 0/0/0 Device# show isis tagThird database level-1 Tag tagThird: IS-IS Level-1 Link State Database: LSP Seq Num LSP Checksum LSP Holdtime ATT/P/OL LSPID router-03.00-00 \* 0x000000B 0xBDF6 1005 1/0/0 \* 0x0000001 router-03.02-00 0xC473 940 0/0/0 router-07.00-00 0x0000006 0x403A 940 0/0/0

```
Device# show clns tagSecond protocol
IS-IS Router: tagSecond
  System Id: 0000.0001.0002.00 IS-Type: level-2-only
  Manual area address(es):
        49.000b
  Routing for area address(es):
        49.000b
  Interfaces supported by IS-IS:
        GigabitEthernet4/1/0 - IP
        GigabitEthernet4/0/0 - IP
        GigabitEthernet4/3/0 - IP
  Redistributing:
    static
  Distance: 110
  RRR level: none
  Generate narrow metrics: level-1-2
  Accept narrow metrics:
                          level-1-2
  Generate wide metrics:
                           none
  Accept wide metrics:
                           none
Device# show clns tagThird protocol
IS-IS Router: tagThird
  System Id: 0000.0001.0001.00 IS-Type: level-1-2
  Manual area address(es):
        49.000b
  Routing for area address(es):
        49.000b
  Interfaces supported by IS-IS:
        POS2/2/0 - IP
        GigabitEthernet0/2/0 - IP
        GigabitEthernet0/4/0 - IP
        POS2/0/0 - IP
        GigabitEthernet0/5/0 - IP
        POS3/2/0 - IP
  Redistributing:
   static
  Distance: 110
  RRR level: none
  Generate narrow metrics: none
  Accept narrow metrics:
                           none
  Generate wide metrics:
                           level-1-2
                           level-1-2
  Accept wide metrics:
```

### Example Creating an IS-IS Instance Without a Process Tag

In the following example, an IS-IS instance was created without the optional process tag. When an IS-IS instance is created without the optional process tag, you can display its information by entering the commands such as **show clns protocol** with "null" specified for the *process-tag* argument.

```
Device (config) # router isis
Device (config-router) # vrf first
Device (config-router) # net 49.000b.0000.0001.ffff.00
Device (config-router) # is-type level-1
Device (config) # interface POS 6/1/0
Device (config-if) # ip vrf forwarding first
Device (config-if) # ip address 172.16.2.1 255.255.255.0
Device (config-if) # ip router isis
Device (config-if) # ip router isis
Device (config-if) # no shutdown
```

Because the IS-IS instance is created without the optional process tag, its information is displayed when the **show clns protocol** command is entered with "**null**" **specified for the** *process-tag* **argument**:

```
49.000b

Interfaces supported by IS-IS:

POS6/1/0 - IP

Redistributing:

static

Distance: 110

RRR level: none

Generate narrow metrics: level-1-2

Accept narrow metrics: level-1-2

Generate wide metrics: none

Accept wide metrics: none
```

### Example Redistributing Routes from an IS-IS Instance

In the following sample configuration, routes have been redistributed from the IS-IS instance "null" into the IS-IS instance named tagBLUE. Routes from an OSPF process in VRF Blue have been redistributed into the IS-IS instance named tagBLUE.

```
Device(config) # router isis tagBLUE
Device(config-router) # redistribute isis null ip metric 10 route-map isisMAP1
Device(config-router) # redistribute ospf 1 vrf BLUE metric 1 metric-type external
level-1-2
.
.
.
Device(config) # route-map isisMAP1 permit 10
Device(config-route-map) # match route-type level-2 level-1
Device(config-route-map) # set level level-2
```

### Example Changing the Interface Ownership

In the following sample configuration, POS interface 6/1/0 was originally enabled for IS-IS IP routing for a "null" instance that does not have a process tag, which is in vrfSecond. The new configuration changes the ownership of POS interface 6/1/0 to another instance tagSecond, which is also in vrfSecond.



Note that use of the **ip router isis**command in interface configuration mode will overwrite the prior configuration on that interface, but only if the new configuration is attempting to change the interface ownership to a different instance that is in the same VRF as the currently configured owner instance. The configuration will be rejected if the attempted change is between two instances that are associated with different VRFs.

```
Device(config)# interface POS 6/1/0
Device(config-if)# ip router isis tagSecond
%ISIS: Interface detached from null and to be attached to instance tagBLUE.
```

1

# **Additional References**

#### **Related Documents**

Related Topic	Document Title
IS-IS commands: complete command syntax, command mode, defaults, command history, usage guidelines, and examples	Cisco IOS IP Routing: ISIS Command Reference
Overview of Cisco IS-IS conceptual information with links to all the individual IS-IS modules	"Integrated IS-IS Routing Protocol Overview" module
ISO CLNS commands	Cisco IOS ISO CLNS Command Reference
Cisco IOS master command list, all releases	Cisco IOS Master Command List, All Releases

#### Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	

#### MIBs

MIBs	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

#### RFCs

RFCs	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	

#### **Technical Assistance**

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

# Feature Information for IS-IS Support for an IS-IS Instance per VRF for IP

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature Name	Releases	Feature Information
IS-IS Support for an IS-IS Instance per VRF for IP		This feature provides multiple VRF-aware IS-IS instances. The VRF functionality allows ISPs to separate routing protocol information and propagate it to the appropriate routing table and network neighbors. Using one router with VRF functionality is more cost-effective than using separate routers to separate and forward the routing information.
		This feature was introduced on the Cisco ASR 1000 Series Aggregation Services Routers.
		The following commands were modified by this release: <b>show clns</b> <b>neighbors</b> , <b>show clns protocol</b> , <b>show isis database</b> , <b>show isis</b> <b>topology</b> , <b>vrf (router</b> <b>configuration)</b>

Table 1: Feature Information for IS-IS Support for an IS-IS Instance per VRF for IP

I

٦