



show ip traffic-engineering routes through show mpls memory

- [show ip traffic-engineering routes](#), on page 3
- [show ip vrf](#), on page 5
- [show ipv6 cef vrf](#), on page 9
- [show ipv6 route vrf](#), on page 11
- [show isis database verbose](#), on page 14
- [show isis mpls ldp](#), on page 17
- [show isis mpls traffic-eng adjacency-log](#), on page 19
- [show isis mpls traffic-eng advertisements](#), on page 21
- [show isis mpls traffic-eng downstream-tree](#), on page 23
- [show isis mpls traffic-eng tunnel](#), on page 25
- [show issu clients](#), on page 27
- [show issu entities](#), on page 30
- [show issu message types](#), on page 32
- [show issu negotiated](#), on page 34
- [show issu sessions](#), on page 36
- [show l2vpn atom binding](#) , on page 38
- [show l2vpn atom checkpoint](#), on page 42
- [show l2vpn atom hw-capability](#), on page 43
- [show l2vpn atom memory](#), on page 45
- [show l2vpn atom pwid](#), on page 46
- [show l2vpn atom static-oam](#), on page 47
- [show l2vpn atom summary](#), on page 49
- [show l2vpn atom vc](#), on page 51
- [show l2vpn pwmib](#), on page 66
- [show l2vpn rib](#), on page 67
- [show l2vpn service](#), on page 70
- [show l2vpn signaling rib](#), on page 72
- [show l2vpn vfi](#) , on page 74
- [show mpls atm-ldp bindings](#), on page 76
- [show mpls atm-ldp bindwait](#), on page 79
- [show mpls atm-ldp capability](#), on page 81

- [show mpls atm-ldp summary](#), on page 84
- [show mpls cef mpls exact-route](#), on page 86
- [show mpls cos-map](#), on page 88
- [show mpls flow mappings](#), on page 90
- [show mpls forwarding vrf](#), on page 92
- [show mpls forwarding-table](#), on page 94
- [show mpls forwarding-table exact-route](#), on page 103
- [show mpls infra lfd block-database](#), on page 105
- [show mpls interfaces](#), on page 107
- [show mpls ip binding](#), on page 112
- [show mpls ip iprm counters](#), on page 123
- [show mpls ip iprm ldm](#), on page 126
- [show mpls ip iprm statistics](#), on page 129
- [show mpls l2 vc detail](#), on page 130
- [show mpls l2transport binding](#), on page 132
- [show mpls l2transport checkpoint](#), on page 139
- [show mpls l2transport hw-capability](#), on page 140
- [show mpls l2transport static-oam](#), on page 144
- [show mpls l2transport summary](#), on page 145
- [show mpls l2transport vc](#), on page 147
- [show mpls label range](#), on page 164
- [show mpls ldp backoff](#), on page 165
- [show mpls ldp bindings](#), on page 168
- [show mpls ldp capabilities](#), on page 174
- [show mpls ldp checkpoint](#), on page 176
- [show mpls ldp discovery](#), on page 178
- [show mpls ldp graceful-restart](#), on page 185
- [show mpls ldp igp sync](#), on page 187
- [show mpls ldp neighbor](#), on page 190
- [show mpls ldp neighbor password](#), on page 198
- [show mpls ldp parameters](#), on page 201
- [show mpls memory](#), on page 203

show ip traffic-engineering routes

To display information about the requested filters configured for traffic engineering, use the **show ip traffic-engineering routes** command in privileged EXEC mode.

show ip traffic-engineering routes [*filter-number*] [**detail**]

Syntax Description	
<i>filter-number</i>	(Optional) A decimal value representing the number of the filter to display.
detail	(Optional) Display of command output in long form.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.1CT	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Requests can be limited to a specific filter.

Examples

The following is sample output from the **show ip traffic-engineering routes** command:

```
Router# show ip traffic-engineering routes
Installed traffic engineering routes:
Codes: T - traffic engineered route
T    43.0.0.1/32 (not override of routing table entry)
      is directly connected, 00:06:35, Tunnel7
T    44.0.0.0/8 (override of routing table entry)
      is directly connected, 01:12:39, Tunnel5
```

The table below describes the significant fields shown in the display.

Table 1: show ip traffic-engineering routes Field Descriptions

Field	Description
T	Traffic engineering route.
43.0.0.1/32 (not override of routing table entry) is directly connected	Prefix/mask being routed. The routing table does not contain an entry for this prefix/mask.
00:06:35	The time since the route was installed (hours:minutes:seconds).
Tunnel7	The LSP tunnel for the route.

Related Commands

Command	Description
show ip traffic-engineering configuration	Displays information about configured traffic engineering filters and routes.

show ip vrf

To display the set of defined Virtual Private Network (VPN) routing and forwarding (VRF) instances and associated interfaces, use the **show ip vrf** command in user EXEC or privileged EXEC mode.

```
show ip vrf [{brief | detail | interfaces | id}] [vrf-name]
```

Syntax Description	Keyword	Description
	brief	(Optional) Displays concise information on the VRFs and associated interfaces.
	detail	(Optional) Displays detailed information on the VRFs and associated interfaces.
	interfaces	(Optional) Displays detailed information about all interfaces bound to a particular VRF or any VRF.
	id	(Optional) Displays the VPN IDs that are configured in a PE router for different VPNs.
	<i>vrf-name</i>	(Optional) Name assigned to a VRF.

Command Default When you do not specify keywords or arguments, the command shows concise information about all configured VRFs.

Command Modes
 User EXEC (>)
 Privileged EXEC (#)

Command History	Release	Modification
	12.0(5)T	This command was introduced.
	12.0(17)ST	This command was modified. The id keyword was added. The VPN ID information was added to the output of the show ip vrf detail command.
	12.2(4)B	This command was integrated into Cisco IOS Release 12.2(4)B.
	12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
	12.3(6)	This command was integrated into Cisco IOS Release 12.3(6). The command shows the downstream VRF for each associated Virtual access interface (VAI).
	12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines Use this command to display information about VRFs. Two levels of detail are available:

- The **brief** keyword (or no keyword) displays concise information.
- The **detail** keyword displays all information.

To display information about all interfaces bound to a particular VRF, or to any VRF, use the `interfaces` keyword. To display information about VPN IDs assigned to a PE router, use the `id` keyword.

When you use the `show ip vrf` command, interface and subinterface names are truncated in the output. For example, `GigabitEthernet3/1/0.100` is displayed as `Gi3/1/0.100`.

Examples

Cisco IOS T Train, Cisco IOS SB Train, Cisco IOS B Train, and Cisco IOS SX Train

The following example displays information about all the VRFs configured on the router, including the downstream VRF for each associated VAI. The lines that are highlighted (for documentation purposes only) indicate the downstream VRF.

```
Router# show ip vrf
Name                               Default RD      Interfaces
v1                                  20:20          Gi0/2.4294967291
                                                     Gi0/2.4294967293
                                                     Gi0/2.4294967294
                                                     Gi0/2.4294967295
vpn152-1                             152:1          Lol
```

The table below describes the significant fields shown in the display.

Table 2: show ip vrf Field Descriptions

Field	Description
Name	Specifies the VRF name.
Default RD	Specifies the default route distinguisher.
Interfaces	Specifies the network interface.

The following example displays detailed information about all of the VRFs configured on the router, including all of the VAIs associated with each VRF:

```
Router# show ip vrf detail vpn152-1
VRF vpn152-1; default RD 152:1; default VPNID <not set>
VRF Table ID = 2
  Interfaces:
    Lol
  Connected addresses are not in global routing table
  Export VPN route-target communities
    RT:152:1
  Import VPN route-target communities
    RT:152:1
  No import route-map
  No export route-map
  VRF label distribution protocol: not configured
```

The table below describes the significant fields shown in the display.

Table 3: show ip vrf detail Field Descriptions

Field	Description
default VPNID	Specifies the VPN ID that uniquely identifies every VPN in the network.

Field	Description
VRF Table ID	Uniquely identifies the VRF routing table.
Interfaces	Specifies the network interfaces.
Export VPN route-target communities	Specifies VPN route-target export communities.
Import VPN route-target communities	Specifies VPN route-target import communities.
VRF label distribution protocol	MPLS label distribution protocol in the VRF context. This is required when VRF is configured for Carrier Supporting Carrier (CSC). This could be LDP (enabled via the mpls ip command on the VRF interface) or BGP (enabled via the send-label command in the router bgp VRF address-family configuration mode).

The following example shows the interfaces bound to a particular VRF:

```
Router# show ip vrf interfaces
Interface          IP-Address      VRF          Protocol
Gi0/2.4294967291  unassigned      v1           down
Gi0/2.4294967293  unassigned      v1           down
Gi0/2.4294967294  unassigned      v1           down
Gi0/2.4294967295  unassigned      v1           down
Lo1                10.1.1.1        vpn152-1     up
```

The table below describes the significant fields shown in the display.

Table 4: show ip vrf interfaces Field Descriptions

Field	Description
Interface	Specifies the network interfaces for a VRF.
IP-Address	Specifies the IP address of a VRF interface.
VRF	Specifies the VRF name.
Protocol	Displays the state of the protocol (up or down) for each VRF interface.

Cisco IOS SR Train

The following example displays output from the **show ip vrf detail** command. The information shown is for a VRF named vpn1.

```
Router# show ip vrf detail vpn1
VRF vpn1 (VRF Id = 1); default RD 1:1; default VPNID <not set>
  Interfaces:
    Lo1                Lo99                Et0/0
VRF Table ID = 1
  Export VPN route-target communities
    RT:1:1
  Import VPN route-target communities
    RT:1:1            RT:2:1
No import route-map
```

```
No export route-map
VRF label distribution protocol: not configured
VRF label allocation mode: per-prefix
```

The table above and the table below describe the significant fields shown in the display.

Table 5: show ip vrf detail Field Descriptions

Field	Description
VRF ID	Uniquely identifies the VRF within the router.
VRF label allocation mode	Indicates the type of label mode used based on the route types.

Related Commands

Command	Description
import map	Configures an import route map for a VRF.
ip vrf	Configures a VRF routing table.
ip vrf forwarding (interface)	Associates a VRF with an interface or subinterface.
rd	Creates routing and forwarding tables for a VRF.
route-target	Creates a route-target extended community for a VRF.
vpn id	Assigns a VPN ID to a VRF.

show ipv6 cef vrf

To display the Cisco Express Forwarding Forwarding Information Base (FIB) associated with an IPv6 Virtual Private Network (VPN) routing and forwarding (VRF) instance, use the **show ipv6 cef vrf** command in user EXEC or privileged EXEC mode.

```
show ipv6 cef vrf [{vrf-name | * | internal}]
```

Syntax Description

<i>vrf-name</i>	(Optional) Name assigned to the VRF.
*	(Optional) All VRFs are displayed.
internal	(Optional) Only internal data is displayed.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.2(33)SRB	This command was introduced.
12.2(33)SRB1	This command was integrated into Cisco IOS Release 12.2(33)SRB1.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
15.2(2)SNI	This command was implemented on the Cisco ASR 901 Series Aggregation Services Routers.

Usage Guidelines

Use the **show ipv6 cef vrf** command to display content of the IPv6 FIB for the specified VRF.

Examples

The following is sample output from a Cisco Express Forwarding FIB associated with a VRF named cisco1:

```
Router# show ipv6 cef vrf cisco1
 2001:8::/64
   attached to FastEthernet0/0
 2001:8::3/128
   receive
 2002:8::/64
   nexthop 10.1.1.2 POS4/0 label 22 19
 2010::/64
   nexthop 2001:8::1 FastEthernet0/0
 2012::/64
   attached to Loopback1
 2012::1/128
   receive
```

The table below describes the significant fields shown in the display.

Table 6: show ipv6 cef vrf Field Descriptions

Field	Description
2001:8::/64	Specifies the network prefix.
attached to FastEthernet0/0	Specifies the VRF interface.
nexthop 10.1.1.2 POS4/0 label 22 19	Specifies the BGP next hop address.

show ipv6 route vrf

To display IPv6 routing table information associated with a VPN routing and forwarding (VRF) instance, use the **show ipv6 route vrf** command in user EXEC or privileged EXEC mode.

```
show ipv6 route vrf {vrf-name|vrf-number}[tag {tag-value | tag-value-dotted-decimal [{mask}]]]
```

Syntax Description		
<i>vrf-name</i>		Name assigned to the VRF.
<i>vrf-number</i>		Hexadecimal number assigned to the VRF.
tag		(Optional) Displays information about route tags in the VRF table.
<i>tag-value</i>		(Optional) Displays route tag value in plain decimals.
<i>tag-value-dotted-decimal</i>		(Optional) Displays route tag values in dotted decimals.
<i>mask</i>		(Optional) Route tag wildcard mask.

Command Modes	
	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	12.2(33)SRB	This command was introduced.
	12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
	12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
	15.2(2)S	This command was integrated into Cisco IOS Release 15.2(2)S. The tag keyword and the <i>tag-value</i> , <i>tag-value-dotted-decimal</i> , and <i>mask</i> arguments were added to enable the display of route tags as plain decimals or dotted decimals in the command output.
	Cisco IOS XE Release 3.6S	This command was integrated into Cisco IOS XE Release 3.6S. The tag keyword and the <i>tag-value</i> , <i>tag-value-dotted-decimal</i> , and <i>mask</i> arguments were added to enable the display of route tags as plain decimals or dotted decimals in the command output.
	15.2(4)M	This command was integrated into Cisco IOS Release 15.2(4)M.
	15.2(2)SNI	This command was implemented on the Cisco ASR 901 Series Aggregation Services Routers.

Examples

The following sample output from the **show ipv6 route vrf** command displays information about the IPv6 routing table associated with VRF1:

```
Device# show ipv6 route vrf VRF1
```

```

IPv6 Routing Table VRF1 - 6 entries
Codes: C - Connected, L - Local, S - Static, R - RIP, B - BGP
       U - Per-user Static route
       I1 - ISIS L1, I2 - ISIS L2, IA - ISIS interarea
       O - OSPF intra, OI - OSPF inter, OE1 - OSPF ext 1, OE2 - OSPF ext 2
C    2001:DB8:4::2/48 [0/0]
    via ::, FastEthernet0/0
L    2001:DB8:4::3/48 [0/0]
    via ::, FastEthernet0/0
B    2001:DB8:4::4/48 [200/0]
    via ::FFFF:192.168.1.4,
B    2001:DB8:4::5/48 [20/1]
    via 2001:8::1,
C    2001:DB8:4::6/48 [0/0]
    via ::, Loopback1
L    2001:DB8:4::7/48 [0/0]
    via ::, Loopback1

```

The following sample output from the **show ip route vrf vrf-name tag** command displays information about tagged IPv6 routes in vrf1:

```

Device# show ipv6 route vrf vrf1 tag 0.0.0.6

IPv6 Routing Table - vrf1 - 2 entries
Codes: C - Connected, L - Local, S - Static, U - Per-user Static route
       B - BGP, R - RIP, H - NHRP, I1 - ISIS L1
       I2 - ISIS L2, IA - ISIS interarea, IS - ISIS summary, D - EIGRP
       EX - EIGRP external, ND - ND Default, NDp - ND Prefix, DCE - Destination
       NDr - Redirect, l - LISP
       O - OSPF Intra, OI - OSPF Inter, OE1 - OSPF ext 1, OE2 - OSPF ext 2
       ON1 - OSPF NSSA ext 1, ON2 - OSPF NSSA ext 2
Routing entry for 2001::/32
  Known via "static", distance 1, metric 0
  Tag 0.0.0.6
  Route count is 1/1, share count 0
  Routing paths:
    directly connected via Null0
    Last updated 00:00:23 ago

```

The table below describes the significant fields shown in the displays.

Table 7: show ipv6 route vrf Field Descriptions

Field	Description
Codes	<p>Indicates the protocol that derived the route. It can be one of the following values:</p> <ul style="list-style-type: none"> • B—BGP derived • C—Connected • D—Enhanced Interior Gateway Routing Protocol (EIGRP) • EX—EIGRP external • H—NHRP • I—IS-IS derived • L—Local • O—Open Shortest Path First (OSPF) derived • P—Periodic downloaded static route • R—Routing Information Protocol (RIP) derived • S—Static • U—Per-user static route
via ::, FastEthernet0/0	Indicates how the route was derived.
Tag	Identifies the tag associated with the remote network.

show isis database verbose

To display details about the Intermediate System-to-Intermediate System (IS-IS) link-state database, use the **show isis database verbose** command in user EXEC or privileged EXEC mode.

show isis database verbose

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(3)T	This command was integrated into Cisco IOS Release 12.1(3)T.
12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST.
12.2(27)SBC	This command was integrated into Cisco IOS Release 12.2(27)SBC.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 2.1	This command was implemented on Cisco ASR 1000 Series Aggregation Services Routers.
Cisco IOS XE Release 3.6S	This command was modified. Support was added for administrative tags in IPv6 prefixes.

Examples

The following is sample output from the **show isis database verbose** command:

```
Device# show isis database verbose

IS-IS Level-1 Link State Database
LSPID          LSP Seq Num  LSP Checksum  LSP Holdtime  ATT/P/OL
dtp-5.00-00    * 0x000000E6  0xC9BB        1042           0/0/0
  Area Address:49.0001
  NLPID:        0xCC
  Hostname:dtp-5
  Router ID:    10.5.5.5
  IP Address:   172.16.39.5
  Metric:10    IP 172.16.39.0/24
dtp-5.00-01    * 0x000000E7  0xAB36        1065           0/0/0
  Metric:10    IS-Extended dtp-5.01
  Affinity:0x00000000
```

```

Interface IP Address:172.21.39.5
Physical BW:10000000 bits/sec
Reservable BW:1166000 bits/sec
BW Unreserved[0]: 1166000 bits/sec, BW Unreserved[1]: 1166000 bits/sec
BW Unreserved[2]: 1166000 bits/sec, BW Unreserved[3]: 1166000 bits/sec
BW Unreserved[4]: 1166000 bits/sec, BW Unreserved[5]: 1166000 bits/sec
BW Unreserved[6]: 1166000 bits/sec, BW Unreserved[7]: 1153000 bits/sec
Metric:0          ES dtp-5

```

The table below describes the significant fields shown in the display.

Table 8: show isis database verbose Field Descriptions

Field	Description
LSPID	<p>Link-state packet (LSP) identifier. The first six octets form the System ID of the router that originated the LSP.</p> <p>The next octet is the pseudonode ID. When this byte is zero, the LSP describes links from the system. When it is nonzero, the LSP is a pseudonode LSP. This is similar to a router LSA in Open Shortest Path First (OSPF); the LSP describes the state of the originating router. For each LAN, the designated router for that LAN creates and floods a pseudonode LSP that describes all systems attached to that LAN.</p> <p>The last octet is the LSP number. If all the data cannot fit into a single LSP, the LSP is divided into multiple LSP fragments. Each fragment has a different LSP number. An asterisk (*) indicates that the system issuing this command originated the LSP.</p>
LSP Seq Num	LSP sequence number that allows other systems to determine if they received the latest information from the source.
LSP Checksum	Checksum of the entire LSP packet.
LSP Holdtime	Amount of time that the LSP remains valid (in seconds). An LSP hold time of zero indicates that this LSP was purged and is being removed from all routers' link-state databases (LSDBs). The value indicates how long the purged LSP will stay in the LSDB before it is completely removed.
ATT	Attach bit. This bit indicates that the router is also a Level 2 router, and it can reach other areas. Level 1 routers use the Attach bit to find the closest Level 2 router. They install a default route to the closest Level 2 router.
P	P bit. This bit detects if the IS can repair area partitions. Cisco and other vendors do not support area partition repair.
OL	Overload bit. This bit determines if the IS is congested. If the overload bit is set, other routers do not use this system as a transit router when they calculate routes. Only packets for destinations directly connected to the overloaded router are sent to this router.
Area Address	Reachable area addresses from the router. For Level 1 LSPs, these are the area addresses configured manually on the originating router. For Level 2 LSPs, these are all the area addresses for the area to which this router belongs.
NLPID	Network Layer Protocol identifier.
Hostname	Hostname of the node.

Field	Description
Router ID	Traffic engineering router identifier for the node.
IP Address	IPv4 address for the interface.
Metric	IS-IS metric for the cost of the adjacency between the originating router and the advertised neighbor, or the metric of the cost to get from the advertising router to the advertised destination (which can be an IP address, an end system (ES), or a Connectionless Network Service [CLNS] prefix).
Affinity	Link attribute flags that are being flooded.
Physical BW	Link bandwidth capacity (in bits per second, or b/s).
Reservable BW	Amount of reservable bandwidth on this link, in b/s.
BW Unreserved	Amount of bandwidth that is available for reservation, in b/s.

The following example includes a route tag:

```
Device# show isis database verbose
```

```
IS-IS Level-1 Link State Database:
```

```
LSPID          LSP Seq Num    LSP Checksum   LSP Holdtime   ATT/P/OL
dasher.00-00   0x000000F8     0xE57B         518             1/0/0
  Area Address: 49.0002
  NSPID:        0xCC
  Hostname:     dasher
  IP Address:   10.3.0.1
  Metric: 10    IP 172.16.170.0/24
  Metric: 10    IP 10.0.3.0/24
  Metric: 10    IP 10.0.3.3/30
  Metric: 10    IS-Extended dasher.02172.19.170.0/24
  Metric: 20    IP-Interarea 10.1.1.1/32
    Route Admin Tag: 60
  Metric: 20    IP-Interarea 192.168.0.6/32
    Route Admin Tag: 50
```

Related Commands

Command	Description
show isis mpls traffic-eng adjacency-log	Displays a log of 20 entries of MPLS traffic engineering IS-IS adjacency changes.
show isis mpls traffic-eng advertisements	Displays the last flooded record from MPLS traffic engineering.
show isis mpls traffic-eng tunnel	Displays information about tunnels considered in the IS-IS next hop calculation.

show isis mpls ldp

To display synchronization and autoconfiguration information about interfaces belonging to Intermediate System-to-Intermediate System (IS-IS) processes, use the **show isis mpls ldp** command in privileged EXEC mode.

```
show isis [process-tag] mpls ldp [interface interface]
```

Syntax Description

<i>process-tag</i>	(Optional) Process ID. Displays information only for the specified routing process.
interface <i>interface</i>	(Optional) Defines the interface for which Label Distribution Protocol (LDP)-Interior Gateway Protocol (IGP) synchronization and LDP autoconfiguration information will be displayed.

Command Modes

Privileged EXEC

Command History

Release	Modifications
12.0(32)SY	This command was introduced.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
Cisco IOS XE Release 3.6S	This command was implemented on the Cisco ASR 903 series routers.

Usage Guidelines

This command shows Multiprotocol Label Switching (MPLS) LDP synchronization and autoconfiguration information for interfaces that are running IS-IS processes. If you do not specify a keyword or argument, information appears for each interface that is configured for MPLS LDP synchronization and autoconfiguration. MPLS LDP synchronization and autoconfiguration for IS-IS is supported only in Cisco IOS Release 12.0(32)SY.

Examples

In the following example, interface POS0/2 is running IS-IS. Autoconfiguration is enabled. Synchronization is configured.

```
Router# show isis mpls ldp

Interface: POS0/2; ISIS tag null enabled
ISIS is UP on interface
AUTOCONFIG Information :
  LDP enabled: YES
SYNC Information :
  Required: YES
  Achieved: YES
  IGP Delay: NO
  Holddown time: Infinite
  State: SYNC achieved
```

This command returns information for interfaces that are configured for IS-IS, which are indicated by the message “ISIS is UP” on the interface.

The table below describes the significant fields shown in the display.

Table 9: show isis mpls ldp Field Descriptions

Field	Description
AUTOCONFIG Information	LDP enabled--Indicates whether LDP autoconfiguration is enabled on this interface. Value is YES or NO.
SYNC Information	<p>Provides synchronization information.</p> <ul style="list-style-type: none"> • Required--Indicates whether synchronization is required on the interface. • Achieved--Indicates whether synchronization was achieved with LDP. If IS-IS was configured on an interface but synchronization is not achieved, the Achieved field indicates NO. The Required field still indicates YES. • IGP Delay--Indicates whether the IS-IS process must wait for synchronization with LDP before bringing up the interface adjacency. • Holddown time--Valid values are Finite or Infinite. The finite value is equal to the hold-down delay that you configured using the mpls ldp igp sync holddown command. If this field indicates Infinite, hold-down time was not configured. Therefore, IS-IS waits until synchronization is achieved before bringing adjacency UP. <p>The Holddown time field is significant only if the IGP Delay field indicates YES.</p> <ul style="list-style-type: none"> • State--Indicates information about the state of synchronization on the interface. If synchronization is achieved, the output shows the following: <ul style="list-style-type: none"> • SYNC achieved--Synchronization was required and has been achieved. <p>If synchronization is not achieved, the output shows one of the following:</p> <ul style="list-style-type: none"> • Holding down until SYNC--No hold-down timer was configured, so IS-IS continues to hold down adjacency until synchronization is achieved. • Holding down with timer--A hold-down timer was configured and IS-IS is holding down adjacency until the timer, indicated in the IGP Delay field, expires. • Maximum metric in effect--Although synchronization was not achieved, the IGP brought up adjacency with the maximum metric.

Related Commands

Command	Description
mpls ldp autoconfig	Globally enables LDP autoconfiguration on all interfaces that belong to an OSPF or IS-IS process.
mpls ldp sync	Enables MPLS LDP-IGP synchronization on interfaces for an OSPF process or an IS-IS process.

show isis mpls traffic-eng adjacency-log

To display a log of 20 entries of Multiprotocol Label Switching (MPLS) traffic engineering Intermediate System-to-Intermediate System (IS-IS) adjacency changes, use the **show isis mpls traffic-eng adjacency-log** command in user EXEC or privileged EXEC mode.

show isis mpls traffic-eng adjacency-log

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(3)T	This command was integrated into Cisco IOS Release 12.1(3)T.
12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show isis mpls traffic-eng adjacency-log** command:

```
Router# show isis mpls traffic-eng adjacency-log
IS-IS RRR log
When      Neighbor ID      IP Address      Interface  Status  Level
04:52:52  0000.0024.0004.02  0.0.0.0        Et0/2     Up      level-1
04:52:50  0000.0026.0001.00  172.16.1.2     PO1/0/0   Up      level-1
04:52:37  0000.0024.0004.02  10.0.0.0       Et0/2     Up      level-1
```

The table below describes the significant fields shown in the display.

Table 10: show isis mpls traffic-eng adjacency-log Field Descriptions

Field	Description
When	Amount of time since the entry was recorded in the log.
Neighbor ID	Identification value of the neighbor.
IP Address	Neighbor IPv4 address.
Interface	Interface from which a neighbor is learned.

Field	Description
Status	Up (active) or Down (disconnected).
Level	Routing level.

Related Commands

Command	Description
show isis mpls traffic-eng advertisements	Displays the last flooded record from MPLS traffic engineering.

show isis mpls traffic-eng advertisements

To display the last flooded record from Multiprotocol Label Switching (MPLS) traffic engineering, use the **show isis mpls traffic-eng advertisements** command in user EXEC or privileged EXEC mode.

show isis mpls traffic-eng advertisements

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(3)T	This command was integrated into Cisco IOS Release 12.1(3)T.
12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show isis mpls traffic-eng advertisements** command:

```
Router# show isis mpls traffic-eng advertisements
System ID:dtp-5.00
  Router ID:10.5.5.5
  Link Count:1
  Link[1]
    Neighbor System ID:dtp-5.01 (broadcast link)
    Interface IP address:172.21.39.5
    Neighbor IP Address:0.0.0.0
    Admin. Weight:10
    Physical BW:10000000 bits/sec
    Reservable BW:1166000 bits/sec
    BW unreserved[0]:1166000 bits/sec, BW unreserved[1]:1166000 bits/sec
    BW unreserved[2]:1166000 bits/sec, BW unreserved[3]:1166000 bits/sec
    BW unreserved[
4]:1166000 bits/sec, BW unreserved[5]:1166000 bits/sec
    BW unreserved[6]:1166000 bits/sec, BW unreserved[7]:1153000 bits/sec
    Affinity Bits:0x00000000
```

The table below describes the significant fields shown in the display.

Table 11: show isis mpls traffic-eng advertisements Field Descriptions

Field	Description
System ID	Identification value for the local system in the area.
Router ID	MPLS traffic engineering router ID.
Link Count	Number of links that MPLS traffic engineering advertised.
Neighbor System ID	Identification value for the remote system in an area.
Interface IP address	IPv4 address of the interface.
Neighbor IP Address	IPv4 address of the neighbor.
Admin. Weight	Administrative weight associated with this link.
Physical BW	Link bandwidth capacity (in bits per second).
Reservable BW	Amount of reservable bandwidth on this link.
BW unreserved	Amount of bandwidth that is available for reservation.
Affinity Bits	Link attribute flags being flooded.

Related Commands

Command	Description
show isis mpls traffic-eng adjacency-log	Displays a log of 20 entries of MPLS traffic engineering IS-IS adjacency changes.

show isis mpls traffic-eng downstream-tree

To display the Multiprotocol Label Switching (MPLS) traffic engineering Intermediate System-to-Intermediate System (IS-IS) children list for a specific node, use the **show isis mpls traffic-eng downstream-tree** command in privileged EXEC mode.

```
show isis mpls traffic-eng downstream-tree system-id [{level-1 | level-2}]
```

Syntax Description	
<i>system-id</i>	Displays the traffic engineering downstream tree information for the specified system ID as either a hostname or in the MAC address format.
level-1	(Optional) Displays the traffic engineering downstream tree information for the Level 1 database.
level-2	(Optional) Displays the traffic engineering downstream tree information for the Level 2 database.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(24)S	This command was introduced in a release earlier than Cisco IOS Release 12.0(24)S.
12.3(7)T	This command was integrated into Cisco IOS Release 12.3(7)T.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXI	This command was integrated into Cisco IOS Release 12.2(33)SXI.
Cisco IOS 2.1 XE	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following is sample output from the **show isis mpls traffic-eng downstream-tree** command. The fields are self-explanatory.

```
Router# show isis mpls traffic-eng downstream-tree
cr2.amsterdam1
System cr2.amsterdam1.00 with metric 5
  MPLS TE-tunnel Children List
    15 ar5.hilversum1.00
    15 ar5.zwolle1.00
    15 ar5.tilburg1.00
    15 ar5.wageningen.00
    15 ar5.groningen1.00
    15 ar5.enschede1.00
    15 ar5.nijmegen1.00
    15 cr1.amsterdam1.00
    1 cr1.amsterdam1.00
    25 ar5.den Haag1.00
    25 ar5.delft1.00
    25 ar5.leiden1.00
    25 ar5.rotterdam1.00
```

show isis mpls traffic-eng downstream-tree

```

25   ar5.amsterdam1.00
25   ar5.eindhoven1.00
25   ar5.maastricht.00

```

Related Commands

Command	Description
show isis mpls traffic-eng adjacency-log	Displays a log of 20 entries of MPLS traffic engineering IS-IS adjacency changes.
show isis mpls traffic-eng advertisements	Displays the last flooded record from MPLS traffic engineering.
show isis mpls traffic-eng tunnel	Displays information about tunnels considered in the IS-IS next hop calculation.

show isis mpls traffic-eng tunnel

To display information about tunnels considered in the Intermediate System-to-Intermediate System (IS-IS) next hop calculation, use the **show isis mpls traffic-eng tunnel** command in privileged EXEC mode.

show isis mpls traffic-eng tunnel

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0(5)S	This command was introduced.
12.1(3)T	This command was integrated into Cisco IOS Release 12.1(3)T.
12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show isis mpls traffic-eng tunnel** command:

```
Router# show isis mpls traffic-eng tunnel
Station Id      Tunnel Name    Bandwidth    Nexthop      Metric    Mode
kangpa-router1.00  Tunnel1022    3333        10.2.2.2     -3        Relative
                  Tunnel1021    10000       10.2.2.2     11        Absolute
tomklong-route.00  Tunnel1031    10000       172.17.3.3   -1        Relative
                  Tunnel1032    10000       172.17.3.3
```

The table below describes the significant fields shown in the display.

Table 12: show isis mpls traffic-eng tunnel Field Descriptions

Field	Description
Station Id	Name or system ID of the MPLS traffic engineering tailend router.
Tunnel Name	Name of the MPLS traffic engineering tunnel interface.
Bandwidth	MPLS traffic engineering specified bandwidth of the tunnel.
Nexthop	MPLS traffic engineering destination IP address of the tunnel.
Metric	MPLS traffic engineering metric of the tunnel.

Field	Description
Mode	MPLS traffic engineering metric mode of the tunnel. It can be relative or absolute.

Related Commands

Command	Description
show mpls traffic-eng autoroute	Displays tunnels that are announced to IGP, including interface, destination, and bandwidth.

show issu clients

To display a list of the current In Service Software Upgrade (ISSU) clients--that is, the network applications and protocols supported by ISSU--use the **show issu clients** command in user EXEC or privileged EXEC mode.

show issu clients

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC (>) Privileged EXEC (#)

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRB1	ISSU is supported on the Cisco 7600 series routers in Cisco IOS Release 12.2(33)SRB1.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

This command lists all ISSU clients currently operating in the network, along with their Client ID numbers and the number of entities each client contains.

You should enter this command before you enter the **issu runversion** command, because if a client (application or protocol) that needs to continue operating in the network does not appear in the displayed list, you will know not to continue the software upgrade (because proceeding further with ISSU would then halt the operation of that application or protocol).

Examples

The following example shows a client list displayed by entering this command:

```
Router# show issu clients
Client_ID = 2, Client_Name = ISSU Proto client, Entity_Count = 1
Client_ID = 3, Client_Name = ISSU RF, Entity_Count = 1
Client_ID = 4, Client_Name = ISSU CF client, Entity_Count = 1
Client_ID = 5, Client_Name = ISSU Network RF client, Entity_Count = 1
Client_ID = 7, Client_Name = ISSU CONFIG SYNC, Entity_Count = 1
Client_ID = 8, Client_Name = ISSU ifIndex sync, Entity_Count = 1
Client_ID = 9, Client_Name = ISSU IPC client, Entity_Count = 1
Client_ID = 10, Client_Name = ISSU IPC Server client, Entity_Count = 1
Client_ID = 11, Client_Name = ISSU Red Mode Client, Entity_Count = 1
Client_ID = 12, Client_Name = ISSU EHSA services client, Entity_Count = 1
Client_ID = 100, Client_Name = ISSU rfs client, Entity_Count = 1
Client_ID = 110, Client_Name = ISSU ifs client, Entity_Count = 1
Client_ID = 1001, Client_Name = OC3POS-6, Entity_Count = 4
Client_ID = 1002, Client_Name = C10K ATM, Entity_Count = 1
Client_ID = 1003, Client_Name = C10K CHSTM1, Entity_Count = 1
Client_ID = 1004, Client_Name = C10K CT3, Entity_Count = 1
Client_ID = 1005, Client_Name = C10K GE, Entity_Count = 1
Client_ID = 1006, Client_Name = C10K ET, Entity_Count = 1
Client_ID = 1007, Client_Name = C10K CHE1T1, Entity_Count = 1
Client_ID = 1009, Client_Name = C10K MFE, Entity_Count = 1
Client_ID = 1010, Client_Name = C10K APS, Entity_Count = 1
Client_ID = 1013, Client_Name = C10K CARD OIR, Entity_Count = 1
Client_ID = 2002, Client_Name = CEF Push ISSU client, Entity_Count = 1
```

```

Client_ID = 2003, Client_Name = ISSU XDR client, Entity_Count = 1
Client_ID = 2004, Client_Name = ISSU SNMP client, Entity_Count = 1
Client_ID = 2005, Client_Name = ISSU HDLC Client, Entity_Count = 1
Client_ID = 2006, Client_Name = ISSU QoS client, Entity_Count = 1
Client_ID = 2007, Client_Name = ISSU LSD Label Mgr HA Client, Entity_Count = 1
Client_ID = 2008, Client_Name = ISSU Tableid Client, Entity_Count = 1
Client_ID = 2009, Client_Name = ISSU MPLS VPN Client, Entity_Count = 1
Client_ID = 2010, Client_Name = ARP HA, Entity_Count = 1
Client_ID = 2011, Client_Name = ISSU LDP Client, Entity_Count = 1
Client_ID = 2012, Client_Name = ISSU HSRP Client, Entity_Count = 1
Client_ID = 2013, Client_Name = ISSU ATM Client, Entity_Count = 1
Client_ID = 2014, Client_Name = ISSU FR Client, Entity_Count = 1
Client_ID = 2015, Client_Name = ISSU REDSSOC client, Entity_Count = 1
Client_ID = 2019, Client_Name = ISSU TCP client, Entity_Count = 1
Client_ID = 2020, Client_Name = ISSU BGP client, Entity_Count = 1
Client_ID = 2021, Client_Name = XDR Int Priority ISSU client, Entity_Count = 1
Client_ID = 2022, Client_Name = XDR Proc Priority ISSU client, Entity_Count = 1
Client_ID = 2023, Client_Name = FIB HWIDB ISSU client, Entity_Count = 1
Client_ID = 2024, Client_Name = FIB IDB ISSU client, Entity_Count = 1
Client_ID = 2025, Client_Name = FIB HW subblock ISSU client, Entity_Count = 1
Client_ID = 2026, Client_Name = FIB SW subblock ISSU client, Entity_Count = 1
Client_ID = 2027, Client_Name = Adjacency ISSU client, Entity_Count = 1
Client_ID = 2028, Client_Name = FIB IPV4 ISSU client, Entity_Count = 1
Client_ID = 2030, Client_Name = MFI Pull ISSU client, Entity_Count = 1
Client_ID = 2031, Client_Name = MFI Push ISSU client, Entity_Count = 1
Client_ID = 2051, Client_Name = ISSU CCM Client, Entity_Count = 1
Client_ID = 2052, Client_Name = ISSU PPP SIP CCM Client, Entity_Count = 1
Client_ID = 2054, Client_Name = ISSU process client, Entity_Count = 1

```

Base Clients:

```

Client_Name = ISSU Proto client
Client_Name = ISSU RF
Client_Name = ISSU CF client
Client_Name = ISSU Network RF client
Client_Name = ISSU CONFIG SYNC
Client_Name = ISSU ifIndex sync
Client_Name = ISSU IPC client
Client_Name = ISSU IPC Server client
Client_Name = ISSU Red Mode Client
Client_Name = ISSU EHSA services client

```

The table below describes the significant fields shown in the display.

Table 13: show issu clients Field Descriptions

Field	Description
Client_ID	The identification number used by ISSU for that client.

Field	Description
Client_Name	<p>A character string describing the client.</p> <p>“Base Clients” are a subset, which includes:</p> <ul style="list-style-type: none"> • Inter-Process Communications (IPC) • Redundancy Framework (RF) • Checkpoint Facility (CF) • Cisco Express Forwarding • Network RF (for IDB stateful switchover) • EHSA Services (including ifIndex) • Configuration Synchronization.
Entity_Count	The number of entities within this client. An entity is a logical group of sessions with some common attributes.

Related Commands

Command	Description
show issu message types	Displays the formats, versions, and size of ISSU messages supported by a particular client.
show issu negotiated	Displays results of a negotiation that occurred concerning message versions or client capabilities.
show issu sessions	Displays detailed information about a particular ISSU client, including whether the client status is compatible for the impending software upgrade.

show issu entities

To display information about entities within one or more In Service Software Upgrade (ISSU) clients, use the **show issu entities** command in user EXEC or privileged EXEC mode.

show issu entities [*client-id*]

Syntax Description

<i>client-id</i>	(Optional) The identification number of a single ISSU client.
------------------	---

Command Modes

User EXEC Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRB1	ISSU is supported on the Cisco 7600 series routers in Cisco IOS Release 12.2(33)SRB1.

Usage Guidelines

An entity is a logical group of sessions that possess some common attributes. Enter a Client_ID if you are interested in seeing information only about one client's entities. If a Client_ID is not specified, the command will display all ISSU clients' entities known to the device.

If you are not sure of the precise Client_ID number to enter for the client you are interested in, use the **show issu clients** command to display the current list of clients with their names and ID numbers.

Examples

The following example shows detailed information about the entities within the virtual routing and forwarding (VRF) ("Table ID") client:

```
Router# show issu entities 2008
Client_ID = 2008 :
  Entity_ID = 1, Entity_Name = Tableid Entity :
    MsgType MsgGroup CapType CapEntry CapGroup
      Count Count Count count Count
  2 2 1 2 2
```

The tabl below describes the significant field shown in the display.

Table 14: show issu entities Field Descriptions

Field	Description
Client_ID	The identification number used by ISSU for the specified client.
Entity_ID	The identification number used by ISSU for each entity within this client.
Entity_Name	A character string describing the entity.
MsgType Count	The number of message types within the identified entity.
MsgGroup Count	The number of message groups within the identified entity. A message group is a list of message types.

Field	Description
CapType Count	The number of capability types within the identified entity.
CapEntry Count	The number of capability entries within the identified entity. A capability entry is a list of all mutually dependent capability types within a particular client session and, optionally, other capability types belonging to that client session.
CapGroup Count	The number of capability groups within the identified entity. A capability group is a list of capability entries given in priority sequence.

Related Commands

Command	Description
show issu clients	Lists the current ISSU clients--that is, the applications and protocols on this network supported by ISSU.
show issu sessions	Displays detailed information about a particular ISSU client--including whether the client status for the impending software upgrade is COMPATIBLE.

show issu message types

To display formats (“types”), versions, and maximum packet size of the In Service Software Upgrade (ISSU) messages supported by a particular client, use the **show issu message types** command in user EXEC or privileged EXEC mode.

show issu message types *client-id*

Syntax Description

<i>client-id</i>	The identification number used by ISSU for a client application.
------------------	--

Command Modes

User EXEC Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRB1	ISSU is supported on the Cisco 7600 series routers in Cisco IOS Release 12.2(33)SRB1.

Usage Guidelines

If you are not sure of the Client_ID number to enter into this command, use the **show issu clients** command. It displays the current list of clients, along with their names and ID numbers.

Examples

The following example displays the message type, version, and maximum message size supported by the Multiprotocol Label Switching (MPLS) Virtual Private Network (VPN) client:

```
Router# show issu message types 2009
Client_ID = 2009, Entity_ID = 1 :
  Message_Type = 1, Version_Range = 1 ~ 1
    Message_Ver = 1, Message_Mtu = 32
```

The table below describes the significant fields shown in the display.

Table 15: show issu message types Field Descriptions

Field	Description
Client_ID	The identification number used by ISSU for this client.
Entity_ID	The identification number used by ISSU for this entity.
Message_Type	An identification number that uniquely identifies the format used in the ISSU messages conveyed between the two endpoints.
Version_Range	The lowest and highest message-version numbers contained in the client application.
Message_Ver	Message version. Because each client application contains one or more versions of its messages, ISSU needs to discover these versions and negotiate between the new and old system software which version to use in its preparatory communications.

Field	Description
Message_Mtu	Maximum size (in bytes) of the transmitted message. A value of 0 means there is no restriction on size; fragmentation and reassembly are therefore being handled in a manner transparent to the ISSU infrastructure.

Related Commands

Command	Description
show issu clients	Lists the current ISSU clients--that is, the applications on this network supported by ISSU.
show issu negotiated	Displays results of a negotiation that occurred concerning message versions or client capabilities.
show issu sessions	Displays detailed information about a particular ISSU client, including whether the client status is compatible for the impending software upgrade.

show issu negotiated

To display details of the session's negotiation about message version or client capabilities, use the **show issu negotiated** command in user EXEC or privileged EXEC mode.

show issu negotiated {**version** | **capability**} *session-id*

Syntax Description

version	Displays results of a negotiation about versions of the messages exchanged during the specified session, between the active and standby endpoints.
capability	Displays results of a negotiation about the client application's capabilities for the specified session.
<i>session-id</i>	The number used by In Service Software Upgrade (ISSU) to identify a particular communication session between the active and the standby devices.

Command Modes

User EXEC Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRB1	ISSU is supported on the Cisco 7600 series routers in Cisco IOS Release 12.2(33)SRB1.

Usage Guidelines

If you are not sure of the *session_ID* number to enter into this command, enter the **show issu sessions** command. It will display the *session_ID*.

Examples

The following example displays the results of a negotiation about message versions:

```
router# show issu negotiated version 39
Session_ID = 39 :
  Message_Type = 1,  Negotiated_Version = 1,  Message_MTU = 32
```

The table below describes the significant fields shown in the display.

Table 16: show issu negotiated version Field Descriptions

Field	Description
Session_ID	The identification number of the session being reported on.
Message_Type	An identification number that uniquely identifies the format that was used by the ISSU messages conveyed between the two endpoints.
Negotiated_Version	The message version that was decided upon, for use during the software upgrade process.
Message_Mtu	Maximum size (in bytes) of the transmitted message. A value of 0 means there is no restriction on size. In that case, fragmentation and reassembly are handled in a manner transparent to the ISSU infrastructure.

The following example displays the results of a negotiation about the client application's capabilities:

```
router# show issu negotiated capability 39
Session_ID = 39 :
    Negotiated_Cap_Entry = 1
```

The table below describes the significant fields shown in the display.

Table 17: show issu negotiated capability Field Descriptions

Field	Description
Session_ID	The identification number of the session being reported on.
Negotiated_Cap_Entry	A numeral that stands for a list of the negotiated capabilities in the specified client session.

Related Commands

Command	Description
show issu clients	Lists the current ISSU clients--that is, the applications on this network supported by ISSU.
show issu message types	Displays the formats, versions, and maximum packet size of ISSU messages supported by a particular client.
show issu sessions	Displays detailed information about a particular ISSU client, including whether the client status is compatible for the impending software upgrade.

show issu sessions

To display detailed information about a particular In Service Software Upgrade (ISSU) client--including whether the client status for the impending software upgrade is compatible--use the **show issu sessions** command in user EXEC or privileged EXEC mode.

show issu sessions *client-id*

Syntax Description

<i>client-id</i>	The identification number used by ISSU for the client.
------------------	--

Command Modes

User EXEC (>) Privileged EXEC (#)

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRB1	ISSU is supported on the Cisco 7600 series routers in Cisco IOS Release 12.2(33)SRB1.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.

Usage Guidelines

If you are not sure of the Client_ID number to enter into this command, use the **show issu clients** command to display the current list of clients with their names and ID numbers.

Examples

The following example shows detailed information about the LDP Client:

```
Router# show issu sessions 2011
Client_ID = 2011, Entity_ID = 1 :
*** Session_ID = 46, Session_Name = LDP Session :
  Peer  Peer  Negotiate  Negotiated  Cap    Msg    Session
  UniqueID Sid   Role       Result      GroupID GroupID Signature
   4      34   PRIMARY   COMPATIBLE  1      1      0
                        (no policy)
  Negotiation Session Info for This Message Session:
    Nego_Session_ID = 46
    Nego_Session_Name = LDP Session
    Transport_Mtu = 3948
```

The table below describes the significant fields shown in the display.

Table 18: show issu sessions Field Descriptions

Field	Description
Client_ID	The identification number used by ISSU for that client.
Entity_ID	The identification number used by ISSU for each entity within this client.
Session_ID	The identification number used by ISSU for this session.
Session_Name	A character string describing the session.

Field	Description
Peer UniqueID	An identification number used by ISSU for a particular endpoint, such as a Route Processor or line card (could be a value based on slot number, for example). The peer that has the smaller unique_ID becomes the Primary (initiating) side in the capability and message version negotiations.
Peer Sid	Peer session ID.
Negotiate Role	Negotiation role of the endpoint: either PRIMARY (in which case the device initiates the negotiation) or PASSIVE (in which case the device responds to a negotiation initiated by the other device).
Negotiated Result	The features (“capabilities”) of this client’s new software were found to be either COMPATIBLE or INCOMPATIBLE with the intended upgrade process. (“Policy” means that an override of the negotiation result has been allowed by the software. Likewise, “no policy” means that no such override is present to be invoked).
Cap GroupID	Capability group ID: the identification number used for a list of distinct functionalities that the client application contains.
Msg GroupID	Message group ID: the identification number used for a list of formats employed when conveying information between the active device and the standby device.
Session Signature	Session signature: a unique ID to identify a current session in a shared negotiation scenario.
Nego_Session_ID	Negotiation session ID: the identification number used by ISSU for this negotiation session.
Nego_Session_Name	Negotiation session name: a character string describing this negotiation session.
Transport_Mtu	Maximum packet size (in bytes) of the ISSU messages conveyed between the two endpoints. A value of 0 means there is no restriction on size; in this case, fragmentation and reassembly then are handled in a manner transparent to the ISSU infrastructure.

Related Commands

Command	Description
show issu clients	Lists the current ISSU clients--that is, the applications on this network supported by ISSU.
show issu message types	Displays the formats, versions, and maximum packet size of ISSU messages supported by a particular client.
show issu negotiated	Displays results of a negotiation that occurred concerning message versions or client capabilities.

show l2vpn atom binding

To display Layer 2 VPN (L2VPN) Any Transport over MPLS (AToM) label binding information, use the **show l2vpn atom binding** command in privileged EXEC mode.

show l2vpn atom binding [{*vc-idip-address* | **local-label** *number* | **pseudowire** *int-number* | **remote-label** *number*}]

Syntax Description

<i>vc-id</i>	(Optional) Displays L2VPN AToM label binding information for the specified virtual circuit (VC).
<i>ip-address</i>	(Optional) Displays L2VPN AToM label binding information for the specified VC destination.
local-label <i>number</i>	(Optional) Displays L2VPN AToM label binding information for the specified local assigned label.
pseudowire <i>int-number</i>	(Optional) Displays pseudowire interface number.
remote-label <i>number</i>	(Optional) Displays L2VPN AToM label binding information for the specified remote assigned label.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based Layer 2 VPN (L2VPN) command modifications for cross-OS support. This command will replace the show mpls l2transport binding command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following example shows the L2VPN AToM label binding information:

```
Device# show l2vpn atom binding
Destination Address: 10.5.5.51, VC ID: 108
  Local Label: 1001
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV: CC Type: CW [1]
          CV Type: None
  Remote Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: "This is Left PE"
    VCCV: CC Type: CW [1], RA [2], TTL [3]
          CV Type: LSPV [2], BFD [3]
```

The table below describes the significant fields shown in the display.

Table 19: show l2vpn atom binding Field Descriptions

Field	Description
Destination Address	IP address of the interface on the remote device to which the VC has been established.
VC ID	The VC identifier assigned to one of the interfaces on the device.
Local Label	The VC label that a device signals to its peer device, which is used by the peer device during imposition.
Remote Label	The disposition VC label of the remote peer device.
Cbit	The control word bit. If it is set, the value is 1.
VC Type	The type of VC, such as ATM, Ethernet, and Frame Relay.
GroupID	The group ID assigned to the local or remote VCs.
MTU	The maximum transmission unit assigned.
Interface Desc	Interface parameters, if applicable.
VCCV Capabilities	<p>Any Transport over Multi Protocol Label Switching (AToM) Virtual Circuit Connectivity Verification (VCCV) information. This field displays how an AToM VCCV packet is identified.</p> <ul style="list-style-type: none"> • Type 1—The Protocol ID field of the AToM Control Word (CW) is identified in the AToM VCCV packet. • Type 2—An MPLS Router Alert (RA) Level above the VC label identified in the AToM VCCV packet. Type 2 is used for VC types that do not support or do not interpret the AToM Control Word.
VCCV: CC Type	<p>Type of Control Channel (CC) processing that are supported. The number indicates the position of the bit that was set in the received octet. The following values can be displayed:</p> <ul style="list-style-type: none"> • CW [1]—Control Word • RA [2]—Router Alert • TTL [3]—Time to Live • Unkn [x]—Unknown

Field	Description
CV Type	<p>Type of Connectivity Verification (CV) packets that can be processed in the control channel of the MPLS pseudowire. The following are the CV packets that can be processed. The number following the CV type indicates the position of the bit that was set in the received octet.</p> <ul style="list-style-type: none"> • ICMP [1]—Internet Control Management Protocol (ICMP) is used to verify connectivity. • LSPV [2]—Link-state packet (LSP) ping is used to verify connectivity. • BFD [3]—Bidirectional Forwarding Detection (BFD) is used to verify connectivity for more than one pseudowire. • Unkn [x]—A CV type was received that could not be interpreted.

The following sample output shows information about L2VPN multisegment pseudowires:

```

Device# show l2vpn atom binding

Destination Address: 10.1.1.1, VC ID: 102
  Local Label: 17
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV: CC Type: CW [1], RA [2], TTL [3]
    CV Type: LSPV [2]
  Remote Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV: CC Type: CW [1], RA [2], TTL [3]
    CV Type: LSPV [2]
  PW Switching Point:
Vcid  local IP addr  remote IP addr  Description
101   10.11.11.11     10.20.20.20    PW Switching Point PE3
100   10.20.20.20     10.11.11.11    PW Switching Point PE2

```

The table below describes the significant fields shown in the display.

Table 20: show l2vpn atom binding Field Descriptions for Multisegment Pseudowires

Field	Description
TTL	Time to live (TTL) setting of the label.
Vcid	VC identifier.
local IP addr	Local IP address assigned to the switching point.
remote IP addr	Remote IP address assigned to the switching point.
Description	Description assigned to the switching point.

Related Commands

Command	Description
cell-packing	Enables ATM over MPLS or L2TPv3 to pack multiple ATM cells into each MPLS or L2TPv3 packet.
show l2vpn atom hw-capability	Displays the transport types and their supported capabilities.
show l2vpn atom vc	Displays information about AToM VCs and static pseudowires that have been enabled to route Layer 2 packets on a device.
show mpls l2transport binding	Displays VC label binding information.

show l2vpn atom checkpoint

To display checkpointing information about Layer 2 VPN (L2VPN) Any Transport over Multiprotocol Label Switching (AToM) virtual circuits (VCs), use the **show l2vpn atom checkpoint** command in privileged EXEC mode.

show l2vpn atom checkpoint

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based Layer 2 VPN (L2VPN) command modifications for cross-OS support. This command will replace the show mpls l2transport checkpoint command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Usage Guidelines

The output of the commands varies, depending on whether the output reflects the active or standby Route Processor (RP). In general, the output on the active RP shows that checkpointing information is sent to the backup RP. The output on the backup RP shows that checkpointing information is received from the active RP.

Examples

On the active RP, the command displays the following output:

```
Device# show l2vpn atom checkpoint

AToM Checkpoint info for active RP
Checkpointing is allowed
Bulk-sync checkpointed state for 1 VC
```

On the standby RP, the command displays the following output:

```
Device# show l2vpn atom checkpoint

AToM HA Checkpoint info for standby RP
1 checkpoint information block in use
```

The output fields are self-explanatory.

Related Commands

Command	Description
show l2vpn atom vc	Displays information about the checkpointed data when checkpointing is enabled.
show mpls l2transport checkpoint	Displays information of MPLS Layer 2 transport checkpointed data when checkpointing is enabled.

show l2vpn atom hw-capability

To display the transport types supported on an interface, use the **show l2vpn atom hw-capability** command in privileged EXEC mode.

show l2vpn atom hw-capability interface *type number*

Syntax Description	interface	Displays information for the specified interface.
	<i>type number</i>	Type and number of the interface.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based Layer 2 VPN (L2VPN) command modifications for cross-OS support. This command will replace the show mpls l2transport hw-capability command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Usage Guidelines

Use the **show l2vpn atom hw-capability** command to determine the interface to use for the various transport types. Use this command to check if core-facing and edge-facing interfaces can accommodate different transport types.

Examples

The following is sample output from the **show l2vpn atom hw-capability** command:

```
Device# show l2vpn atom hw-capability interface serial5/1

Interface Serial5/1
Transport type FR DLCI
  Core functionality:
    MPLS label disposition supported
    Control word processing supported
    Sequence number processing not supported
  Edge functionality:
    MPLS label imposition supported
    Control word processing supported
    Sequence number processing not supported
  !
  !
  !
```



Note These examples show only a portion of the output. The command displays the capabilities of every transport type.

The table below describes the fields shown in the command display.

Table 21: show l2vpn atom hw-capability Field Descriptions

Field	Description
Transport type	Indicates the transport type.
Core functionality	Displays the functionalities that the core-facing interfaces support, such as label disposition, control word, and sequence number processing.
Edge functionality	Displays the functionalities that the edge-facing interfaces support, such as label disposition, control word, and sequence number processing.

Related Commands

Command	Description
show l2vpn atom binding	Displays VC label binding information.
show l2vpn atom checkpoint	Displays the checkpoint information about AToM VCs.
show l2vpn atom summary	Displays summary information about VCs.
show l2vpn atom vc	Displays information about AToM VCs and static pseudowires that have been enabled to route Layer 2 packets on a device.
show mpls l2transport hw-capability	Displays the transport types supported on an interface.

show l2vpn atom memory

To display the Layer 2 VPN (L2VPN) Any Transport over MPLS (AToM) memory usage information, use the **show l2vpn atom memory** command in privileged EXEC mode.

show l2vpn atom memory [{detail}]

Syntax Description	detail	(Optional) Displays detailed information for L2VPN AToM memory usage.
--------------------	--------	---

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the show mpls l2transport memory command in future releases.

Examples

The following is sample output from the **show l2vpn atom memory detail** command:

```
Device# show l2vpn atom memory detail
```

```
AToM memory
-----
AToM LDP Adj Chunk      :      --      320/592      --      32      10/10
AToM LDP Chunk          :      --      400/664      --      40      10/10
AToM LDP DB             :      --      32760/36272   --      40      512/819
AToM LDP pw tlv chunk   :      --      2816/3272     --      256     10/11
AToM LDP sw point subtl :      --      1456/1776    --      104     10/14
AToM Mgr VC Table       :      --      32760/36272   --      40      512/819
AToM Seg Context        :      76        76/128        1        76     --/--
AToM Test LDP           :      --      32760/36272   --      40      512/819
Total                   :      76      103348/115248  1        --     --/--

AToM structs
-----
atom_mgr_vc_t           :      --      --/--         --      584     --/--
atom_mgr_sig_t          :      --      --/--         --      44      --/--
atom_vc_msg_t           :      --      --/--         --      392     --/--
```

Related Commands	Command	Description
	show l2vpn atom summary	Displays summary information about VCs that have been enabled to route AToM Layer 2 packets on a device.
	show mpls l2transport memory	Displays the L2VPN AToM memory usage information.

show l2vpn atom pwid

To display Layer 2 VPN (L2VPN) Any Transport over MPLS (AToM) dataplane pseudowire identifier usage information, use the **show l2vpn atom pwid** command in privileged EXEC mode.

show l2vpn atom pwid

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command wasS introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support.. This command will replace the show mpls l2transport pwid command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following is sample output from the **show l2vpn atom pwid** command. The output fields are self-explanatory.

```
Device# show l2vpn atom pwid
```

```
AToM Pseudowire IDs: In use: 1, In holddown: 0
```

Label	Peer-Address	VCID	PWID	In-Use	FirstUse	ResuedAt	FreedAt
0	10.1.1.1	4500	1	Yes	00:22:44	Never	Never

Related Commands

Command	Description
show l2vpn atom binding	Displays VC label binding information.
show l2vpn atom checkpoint	Displays the checkpoint information about AToM VCs.
show l2vpn atom summary	Displays summary information about VCs.
show l2vpn atom vc	Displays information about AToM VCs and static pseudowires that have been enabled to route Layer 2 packets on a device.
show mpls l2transport pwid	Displays Layer 2 transport dataplane pseudowire identifier usage information.

show l2vpn atom static-oam

To display the status of Layer 2 VPN (L2VPN) Any Transport over MPLS (AToM) static pseudowires, use the **show l2vpn atom static-oam** command in privileged EXEC mode.

```
show l2vpn atom static-oam [fault [{inbound | outbound}]] [event-trace] [ip-address vc-id]
```

Syntax Description	Parameter	Description
	fault	(Optional) Displays faults related to static pseudowires.
	inbound	(Optional) Displays faults related to inbound static pseudowires.
	outbound	(Optional) Displays faults related to outbound static pseudowires.
	event-trace	(Optional) Displays event trace information related to static pseudowires.
	<i>ip-address</i>	(Optional) Displays information related to the static pseudowire with the specified peer IP address.
	<i>vc-id</i>	(Optional) Displays information related to the static pseudowire with the specified virtual circuit (VC) ID.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the show mpls l2transport static-oam command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following example shows how to enable the display of status messages for the static pseudowire with peer IP address of 10.10.10.10 and VC ID of 4:

```
Device# show l2vpn atom static-oam 10.10.10.10 4

Peer IP address: 10.10.10.10, VC ID: 4, Protocol: MPLS, PW ID: 1
Configured Parameters:
  Refresh send rate: 30 sec
  Refresh rcv rate: 600 sec
  Ack disabled
Negotiated Parameters:
  Peer refresh rate: 0 sec
  Requested refresh rate: 0 sec
Remote Fault:
  FSM state: No Remote Fault, status code: fwding
Local Fault:
  FSM state: No Local Fault, status code: fwding
```

Related Commands

Command	Description
debug l2vpn atom static-oam	Enables the display of messages related to static pseudowire OAM.
show mpls l2transport static-oam	Displays the status of MPLS TP static pseudowires.

show l2vpn atom summary

To display summary information about virtual circuits (VCs) that have been enabled to route Any Transport over MPLS (AToM) Layer 2 packets on a device, use the **show l2vpn atom summary** command in privileged EXEC mode.

show l2vpn atom summary

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based Layer 2 VPN (L2VPN) command modifications for cross-OS support. This command will replace the show mpls l2transport summary command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Usage Guidelines

This command will replace the **show mpls l2transport summary** command in future releases.

Examples

The following is sample output from the command that shows summary information about the VCs that have been enabled to transport Layer 2 packets:

```
Device# show l2vpn atom summary

Destination address: 10.16.24.12 Total number of VCs: 60
0 unknown, 58 up, 0 down, 2 admin down
5 active vc on MPLS interface PO4/0
```

The table below describes the fields shown in the command display.

Table 22: show l2vpn atom summary Field Descriptions

Field	Description
Destination address	IP address of the remote device to which the VC has been established.
Total number of VCs	Number of VCs that are established.
unknown	Number of VCs that are in an unknown state.
up	Number of VCs that are operational.
down	Number of VCs that are not operational.
admin down	Number of VCs that have been disabled.

Related Commands

Command	Description
show l2vpn atom binding	Displays VC label binding information.
show l2vpn atom checkpoint	Displays the checkpoint information about AToM VCs.
show l2vpn atom hw-capability	Displays the transport types and their supported capabilities.
show l2vpn atom vc	Displays information about AToM VCs that have been enabled to route Layer 2 packets on a device.
show mpls l2transport summary	Displays summary information about VCs that have been enabled to route AToM Layer 2 packets on a device.

show l2vpn atom vc

To display information about Any Transport over MPLS (AToM) virtual circuits (VCs) and static pseudowires that have been enabled to route Layer 2 packets on a device, use the **show l2vpn atom vc** command in user EXEC or privileged EXEC mode.

```
show l2vpn atom vc [[vcid] vc-id-min] [vc-id-max] [interface type number [local-circuit-id]]
[destination {ip-addresshostname}] [detail] [pwid pw-identifier] [vpls-id vpls-identifier] [stitch
endpoint endpoint]
```

Syntax	Description
vcid	(Optional) Displays the VC ID.
<i>vc-id-min</i>	(Optional) Minimum VC ID value. The range is from 1 to 4294967295.
<i>vc-id-max</i>	(Optional) Maximum VC ID value. The range is from 1 to 4294967295.
interface	(Optional) Displays the interface or subinterface of the device that has been enabled to transport Layer 2 packets. Use this keyword to display information about the VCs that have been assigned VC IDs on that interface or subinterface.
<i>type</i>	(Optional) Interface type. For more information about the interface type, use the question mark (?) online help function.
<i>number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
<i>local-circuit-id</i>	(Optional) The number assigned to the local circuit. This argument value is supported only with the following transport types: <ul style="list-style-type: none"> • For Frame Relay, enter the data-link connection identifier (DLCI) of the permanent virtual circuit (PVC). • For ATM adaptation layer 5 (AAL5) and cell relay, enter the virtual path identifier (VPI) or virtual channel identifier (VCI) of the PVC. • For Ethernet VLANs, enter the VLAN number.
destination	(Optional) Displays the remote device.
<i>ip-address</i>	(Optional) IP address of the remote device.
<i>hostname</i>	(Optional) The name assigned to the remote device.
detail	(Optional) Displays detailed information about VCs.

pwid <i>pw-identifier</i>	(Optional) Displays the number of a pseudowire for a single VC. The range is from 1 to 4294967295.
vpls-id <i>vpls-identifier</i>	(Optional) Virtual Private LAN Switching (VPLS) ID extended community value.
stitch <i>endpoint endpoint</i>	(Optional) Displays information about dynamically stitched pseudowires between specified endpoints. The endpoints are the Source Attachment Individual Identifier (SAII) and the Target Attachment Individual Identifier (TAII). When the stitch keyword is used with the vpls-id keyword, a single pair of stitched VCs is displayed.

Command Default The command displays a summary of all the VCs.

Command Modes User EXEC (>)
Privileged EXEC (#)

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the show mpls l2transport vc command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Usage Guidelines The output of the commands varies based on the type of Layer 2 packets being transported over AToM VCs.

Examples The following is sample output from the **show l2vpn atom vc** command, which displays information about interfaces and VCs that are configured to transport various Layer 2 packets on the device:

```
Device# show l2vpn atom vc

Local intf      Local circuit    Dest address     VC ID           Status
-----
Se5/0           FR DLCI 55       10.0.0.1         55              UP
AT4/0           ATM AAL5 0/100   10.0.0.1         100             UP
AT4/0           ATM AAL5 0/200   10.0.0.1         200             UP
AT4/0.300       ATM AAL5 0/300   10.0.0.1         300             UP
```

The table below describes the fields shown in the display.

Table 23: show l2vpn atom vc Field Descriptions

Field	Description
Local intf	Interface on the local device that is enabled to transport Layer 2 packets.

Field	Description
Local circuit	Type and number (if applicable) of the local circuit. The output shown in this column varies, depending on the transport type: <ul style="list-style-type: none"> • For Frame Relay, the output shows the DLCI of the PVC. • For ATM cell relay and AAL5, the output shows the VPI or VCI of the PVC. • For Ethernet VLANs, the output shows the VLAN number. • For PPP and High-Level Data Link Control (HDLC), the output shows the interface number.
Dest address	IP address of the remote device's interface that is the other end of the VC.
VC ID	VC identifier assigned to one of the interfaces on the device.
Status	Status of the VC, which can be one of the following: <ul style="list-style-type: none"> • Admin down—The VC is disabled by a user. • Down—The VC is not ready to carry traffic between the two VC endpoints. Use the detail keyword to determine the reason that the VC is down. • Hotstandby—The active pseudowire on a standby Route Processor (RP). • Recovering—The VC is recovering from a stateful switchover. • Standby—The VC is designated as the backup circuit in a stateful switchover configuration. • Up—The VC can carry traffic between the two VC endpoints. A VC is up when both imposition and disposition interfaces are programmed. <ul style="list-style-type: none"> • The disposition interface is programmed if the VC is configured and the client interface is up. • The imposition interface is programmed if the disposition interface is also programmed, and a remote VC label and an Interior Gateway Protocol (IGP) label are configured. The IGP label can be implicit null in a back-to-back configuration. The IGP label implies that there is a label switched path (LSP) to the peer.

The following is sample output from the **show l2vpn atom vc detail** command and shows information about the nonstop forwarding (NSF), stateful switchover (SSO), and graceful restart capabilities on the AToM VC. The SSO portion indicates whether checkpoint data is sent (on active) or received (on standby). When SSO data is successfully sent or is released, the SSO information is not displayed.

```
Device# show l2vpn atom vc detail

Local interface: Fa5/1/1.2 down, line protocol down, Eth VLAN 2 up
  Destination address: 10.55.55.2, VC ID: 1002, VC status: down
  Output interface: Se4/0/3, imposed label stack {16}
  Preferred path: not configured
Default path: active
  Tunnel label: imp-null, next hop point2point
  Create time: 02:03:29, last status change time: 02:03:26
  Signaling protocol: LDP, peer 10.55.55.2:0 down
```

```

MPLS VC labels: local 16, remote unassigned
Group ID: local 0, remote unknown
MTU: local 1500, remote unknown
Remote interface description:
Sequencing: receive disabled, send disabled
SSO Descriptor: 10.55.55.2/1002, local label: 16
SSM segment/switch IDs: 12290/8193, PWID: 8193
VC statistics:
packet totals: receive 0, send 0
byte totals:   receive 0, send 0
packet drops:  receive 0, send 0

```

The following is sample output from the **show l2vpn atom vc detail** command and shows the information that is displayed when an AToM static pseudowire is provisioned and the command is used to check the configuration. The Signaling protocol field specifies “Manual” because a directed control protocol such as Label Distribution Protocol (LDP) cannot be used to exchange parameters on static pseudowires. The remote interface description field seen for nonstatic pseudowire configurations is not displayed because remote information is exchanged using signaling between the provider edge (PE) devices and not on static pseudowires.

```

Device# show l2vpn atom vc detail

Local interface: Et1/0 up, line protocol up, Ethernet up
  Destination address: 10.1.1.2, VC ID: 100, VC status: up
  Output interface: Et2/0, imposed label stack {10003 150}
  Preferred path: not configured
  Default path: active
  Next hop: 10.0.0.2
  Create time: 00:18:57, last status change time: 00:16:10
  Signaling protocol: Manual
  MPLS VC labels: local 100, remote 150
  Group ID: local 0, remote 0
  MTU: local 1500, remote 1500
  Remote interface description:
  Sequencing: receive disabled, send disabled
  VC statistics:
  packet totals: receive 219, send 220
  byte totals:   receive 20896, send 26694
  packet drops:  receive 0, send 0

```

The following is sample output from the **show l2vpn atom vc detail** command and shows VC statistics, including the number of packets and bytes being sent from the device. The VC statistics fields include the word “transit” to indicate that the packet totals no longer include packets being sent to the device.

```

Device# show l2vpn atom vc detail

Local interface: Et1/0 up, line protocol up, Ethernet up
.
.
.
VC statistics:
  transit packet totals: receive 219, send 220
  transit byte totals:   receive 20896, send 26694
  transit packet drops:  receive 0, send 0

```

The table below describes the significant fields shown in the display.

Table 24: show l2vpn atom vc detail Field Descriptions

Field	Description
Local interface	Interface on the local device that has been enabled to send and receive Layer 2 packets. The interface varies, depending on the transport type. The output also shows the status of the interface.
line protocol	Status of the line protocol on the edge-facing interface.
Destination address	IP address of the remote device specified for the VC. Specify the destination IP address as part of the mpls l2transport route command.
VC ID	VC identifier assigned to the interface on the device.
VC status	Status of the VC, which can be one of the following: <ul style="list-style-type: none"> • Admin down—The VC was disabled by a user. • Down—The VC is not ready to carry traffic between the two VC endpoints. • up—The VC is in a state where it can carry traffic between the two VC endpoints. A VC is up when both imposition and disposition interfaces are enabled. <ul style="list-style-type: none"> • The disposition interface is enabled if the VC is configured and the client interface is up. • The imposition interface is enabled if the disposition interface is enabled and a remote VC label and an IGP label exist. The IGP label can be an implicit null in a back-to-back configuration. (An IGP label implies that there is an LSP to the peer.)
Output interface	Interface on the remote device that has been enabled to transmit and receive Layer 2 packets.
imposed label stack	Summary of the Multiprotocol Label Switching (MPLS) label stack used to direct the VC to the PE device.
Preferred path	Path that was assigned to the VC and the status of that path. The path can be an MPLS traffic engineering tunnel or an IP address or hostname of a peer PE device.
Default path	Status of the default path, which can be disabled or active. By default, if the preferred path fails, the device uses the default path. However, you can disable the device from using the default path when the preferred path fails by specifying the disable-fallback keyword with the preferred-path command.

Field	Description
Tunnel label	<p>IGP label used to route the packet over the MPLS backbone to the destination device. The first part of the output displays the type of label. The second part of the output displays the route information.</p> <p>The tunnel label information can display any of the following states:</p> <ul style="list-style-type: none"> • imp-null—Implicit null means that the provider device is absent and the tunnel label will not be used. Alternatively, imp-null can signify traffic engineering tunnels between the PE devices. • no adjacency—The adjacency for the next hop is missing. • no route—The label is not in the routing table. • not ready, Cisco Express Forwarding disabled—Cisco Express Forwarding is disabled. • not ready, LFIB disabled—The MPLS switching subsystem is disabled. • not ready, LFIB entry present—The tunnel label exists in the Label Forwarding Information Base (LFIB), but the VC is down. • not ready, no route—An IP route for the peer does not exist in the routing table. • not ready, not a host table—The route in the routing table for the remote peer device is not a host route. • unassigned—The label has not been assigned.
Create time	Time (in hours, minutes, and seconds) when the VC is provisioned.
last status change time	Last time (in hours, minutes, and seconds) when the VC state change occurred.
Signaling protocol	Type of protocol used to send the MPLS labels on dynamically configured connections. The output also shows the status of the peer device. For AToM statically configured pseudowires, the field indicates Manual because there is no exchange of labels using a directed control protocol, such as LDP.
MPLS VC labels	Local VC label is a disposition label, which identifies the egress interface of an arriving packet from the MPLS backbone. The remote VC label is a disposition VC label of the remote peer device.
Group ID	Local group ID used to group VCs locally. The remote group ID is used by the peer to group several VCs.
MTU	Maximum transmission unit (MTU) specified for local and remote interfaces.
Remote interface description	Interface on the remote device that is enabled to transmit and receive Layer 2 packets.
Sequencing	Indicates whether sequencing of out-of-order packets is enabled or disabled.
SSO Descriptor	Identifies the VC for which the information is checkpointed.

Field	Description
local label	Value of the local label that is checkpointed (that is, sent on the active RP and received on the standby RP).
SSM segment/switch IDs	IDs used for the control plane and data plane for this VC. This data is not for customer use but for Cisco personnel for troubleshooting purposes. When the Source Specific Multicast (SSM) IDs are followed by the word “used,” the checkpointed data has been successfully sent.
PWID	Pseudowire ID used in the data plane to correlate the switching context for the segment associated with the MPLS switching context. This data is not for customer use but for Cisco personnel for troubleshooting purposes.
packet totals	Number of packets sent and received. Received packets are those AToM packets received from the MPLS core. Sent packets are those AToM packets sent to the MPLS core. This number excludes dropped packets. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the device.
byte totals	Number of bytes sent and received from the core-facing interface, including the payload, control word if present, and AToM VC label. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the device.
packet drops	Number of dropped packets. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the device.

The following is sample output from the **show l2vpn atom vc detail** command when the VPLS Autodiscovery feature has been configured on VPLS pseudowires.

```
Device# show l2vpn atom vc detail

Local interface: VFI my_test VFI up
MPLS VC type is VFI, interworking type is Ethernet
Destination address: 10.3.3.1, VC ID: 123456, VC status: up
Next hop PE address: 10.55.55.2
Output interface: Et3/0, imposed label stack {17 19}
Preferred path: not configured
Default path:
Next hop: 10.1.0.2
Create time: 2d05h, last status change time: 2d05h
Signaling protocol: LDP, peer 10.55.55.2:0 up
MPLS VC labels: local 21, remote 19
AGI: type 1, len 8, 0000 3333 4F4E 44C4
Local AII: type 1, len 4, 0909 0909 (10.9.9.9)
Remote AII: type 1, len 4, 0303 0301 (10.3.3.3)
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
VC statistics:
```

```

packet totals: receive 22611, send 22611
byte totals:   receive 2346570, send 2853581
packet drops:  receive 0, send 0

```

The table below describes the fields shown in the display.

Table 25: show l2vpn atom vc detail Field Descriptions

Field	Description
Next hop PE address	IP address of the next hop device.
AGI	Attachment group identifier (AGI).
Local AII	Attachment individual identifier (AII)—the local IP address used for signaling.
Remote AII	Remote IP address used for signaling. This address is the provisioned IP address, which might be different from the LDP peer IP address.

The following is sample output from the **show l2vpn atom vc** command when the circuit emulation (CEM) interface is specified:

```

Device# show l2vpn atom vc interface CEM 3/1/1

Local intf  Local circuit  Dest address  VC ID  Status
-----
CE3/1/1    CESOPSN Basic  10.30.30.3   300    DOWN

```

The following sample output displays the number of MAC address withdrawal messages sent and received as part of the H-VPLS N-PE Redundancy for queue-in-queue (QinQ) and MPLS Access feature:

```

Device# show l2vpn atom vc detail

Local interface: VFI TEST VFI up
MPLS VC type is VFI, interworking type is Ethernet
Destination address: 10.1.1.1, VC ID: 1000, VC status: up
  Output interface: Se2/0, imposed label stack {17}
  Preferred path: not configured
  Default path: active
  Next hop: point2point
Create time: 00:04:34, last status change time: 00:04:15
Signaling protocol: LDP, peer 10.1.1.1:0 up
  Targeted Hello: 10.1.1.1(LDP Id) -> 10.1.1.1
  MPLS VC labels: local 16, remote 17
  Group ID: local 0, remote 0
  MTU: local 1500, remote 1500
  Remote interface description:
  MAC Withdraw: sent 5, received 3
Sequencing: receive disabled, send disabled
VC statistics:
  packet totals: receive 0, send 0
  byte totals:   receive 0, send 0
  packet drops:  receive 0, send 0

```

The following sample output displays the status messages for the MPLS Pseudowire Status Signaling feature when it is enabled on both PE devices:

```

Device# show l2vpn atom vc detail

```

```

Local interface: Et1/0 up, line protocol up, Ethernet up
  Destination address: 10.1.1.1, VC ID: 456, VC status: up
  Output interface: Et2/0, imposed label stack {10005 10240}
  Preferred path: not configured
  Default path: active
  Next hop: 10.0.0.1
Create time: 00:39:30, last status change time: 00:26:48
Signaling protocol: LDP, peer 10.1.1.1:0 up
  Targeted Hello: 10.1.1.2(LDP Id) -> 10.1.1.1
Status TLV support (local/remote)   : enabled/supported
Label/status state machine          : established, LruRru
Last local dataplane status rcvd: no fault
Last local SSS circuit status rcvd: no fault
Last local SSS circuit status sent: no fault
Last local LDP TLV status sent: no fault
Last remote LDP TLV status rcvd: PW DOWN(rx,tx faults)
MPLS VC labels: local 2000, remote 10240
Group ID: local 6, remote 0
MTU: local 1500, remote 1500
Remote interface description:
  Sequencing: receive disabled, send disabled
VC statistics:
  packet totals: receive 243651, send 243705
  byte totals:   receive 27768366, send 34109320
  packet drops:  receive 0, send 0

```

The table below describes the fields shown in the display.

Table 26: show l2vpn atom vc detail Field Descriptions

Field	Description
Status TLV support (local/remote)	For the local device, the output indicates whether the MPLS Pseudowire Signaling Status feature is enabled or disabled. For the remote device, the output indicates whether the MPLS Pseudowire Signaling Status feature is supported.
Label/status state machine	The first value in the output indicates whether label advertisement has been established or not. The second value (LruRru) indicates the status of the local and remote devices. The following list translates the status codes: <ul style="list-style-type: none"> • D—Dataplane • L—local device • r or n—ready (r) or not ready (n) • R—remote device • S—Local shutdown • u or d—up (u) or down (d) status
Last local dataplane status rcvd	Last status message received about the dataplane on the local device.
Last local SSS circuit status rcvd	Last status message received about the subscriber service switch (SSS) on the local device.

Field	Description
Last local SSS circuit status sent	Last status message sent about the subscriber service switch on the local device.
Last local LDP TLV status sent	Last status message sent about the type, length, values (TLV) on the local device.
Last remote LDP TLV status rcvd	Last status message received about the TLV on the local device.

The following sample output from the **show l2vpn atom vc detail** command displays the status of multisegment pseudowires:

```
Device# show l2vpn atom vc detail

Local interface: Se3/0 up, line protocol up, HDLC up
  Destination address: 10.12.1.1, VC ID: 100, VC status: down
  Output interface: Se2/0, imposed label stack {23}
  Preferred path: not configured
  Default path: active
  Next hop: point2point
  Create time: 00:03:02, last status change time: 00:01:41
  Signaling protocol: LDP, peer 10.12.1.1:0 up
  Targeted Hello: 10.11.1.1(LDP Id) -> 10.12.1.1, LDP is UP
  Status TLV support (local/remote)   : enabled/supported
  LDP route watch                      : enabled
  Label/status state machine           : established, LruRrd
  Last local dataplane status rcvd: No fault
  Last local SSS circuit status rcvd: No fault
  Last local SSS circuit status sent: DOWN(PW-tx-fault)
  Last local LDP TLV status sent: No fault
  Last remote LDP TLV status rcvd: DOWN(PW-tx-fault)
  PW Switching Point:
  Fault type Vcid local IP addr remote IP addr Description
  PW-tx-fault 101 10.13.1.1 10.12.1.1 S-PE2
  Last remote LDP ADJ status rcvd: No fault
  MPLS VC labels: local 19, remote 23
  Group ID: local 0, remote 0
  MTU: local 1500, remote 1500
  Remote interface description:
  Sequencing: receive disabled, send disabled
  VC statistics:
  packet totals: receive 16, send 27
  byte totals: receive 2506, send 3098
  packet drops: receive 0, seq error 0, send 0
```

The table below describes the significant fields shown in the display.

Table 27: show l2vpn atom vc detail Field Descriptions

Field	Description
Fault type	Type of fault encountered on the switching point.
Vcid	ID of the VC on which the fault occurred.
local IP addr	Local IP address of the pseudowire.
remote IP addr	Remote IP address of the pseudowire.

Field	Description
Description	Descriptions assigned to the segment of the pseudowire.

The following sample output from the **show l2vpn atom vc detail** command displays the status of the control word when it is not configured (that is, it defaults to autosense):

```
Device# show l2vpn atom vc 123400 detail

Local interface: Et0/0 up, line protocol up, Ethernet up
  Destination address: 10.1.1.2, VC ID: 123400, VC status: down
  Output interface: if-?(0), imposed label stack {}
  Preferred path: not configured
  Default path: no route
  No adjacency
Create time: 01:03:48, last status change time: 01:03:48
Signaling protocol: LDP, peer 10.1.1.3:0 up
Targeted Hello: 10.1.1.1(LDP Id) -> 10.1.1.2
Status TLV support (local/remote)   : enabled/unknown (no remote binding)
  Label/status state machine         : local ready, LruRnd
  Last local dataplane status rcvd: no fault
  Last local SSS circuit status rcvd: no fault
  Last local SSS circuit status sent: not sent
  Last local LDP TLV status sent: no fault
  Last remote LDP TLV status rcvd: unknown (no remote binding)
MPLS VC labels: local 1002, remote unassigned
Group ID: local 0, remote unknown
MTU: local 1500, remote unknown
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: on (configured: autosense)
```

If the control word is negotiated by the peer and is different from the configured value, the configured value is shown in parentheses.

- If the control word is configured to be disabled, the displayed value is as follows:

```
Control Word: off (configured: disabled)
```

- If the control word is configured to be enabled but negotiated by the peer to be off, the displayed value is as follows:

```
Control Word: off (configured: enabled)
```

- If the control word is not configured, the displayed value is as follows:

```
Control Word: on (configured: autosense)
```

The following sample output from the **show l2vpn atom vc detail** command displays load balancing information and shows whether flow labels are added to the MPLS label as part of the L2VPN Advanced VPLS feature:

```
Device# show l2vpn atom vc detail

Local interface: VFI dci_vlan_100 VFI up
  MPLS VC type is VFI, interworking type is Ethernet
```

```

Destination address: 10.2.2.2, VC ID: 100, VC status: up
Output interface: Tu0, imposed label stack {16}
Preferred path: not configured
Default path: active
Next hop: point2point
Load Balance: Flow
Flow Label: enabled

```

The table below describes the significant fields shown in the display.

Table 28: show l2vpn atom vc detail Field Descriptions

Field	Description
Load Balance	Displays the type of load-balancing configured. The load-balancing configuration can be either flow-based or port channel-based.
Flow Label	Indicates whether the imposition and disposition of flow labels for the pseudowire is enabled.

The following sample output from the **show l2vpn atom vc detail** command displays Bidirectional Forwarding Detection (BFD) information:

```

Device# show l2vpn atom vc detail

Local interface: AT1/1/0 up, line protocol up, ATM AAL5 10/101 up
Destination address: 10.1.1.151, VC ID: 1234001, VC status: up
Output interface: Gi1/0/0, imposed label stack {2000}
Preferred path: not configured
Default path: active
Next hop: 10.151.152.1
Create time: 6d03h, last status change time: 6d03h
Signaling protocol: LDP, peer 10.1.1.151:0 up
Targeted Hello: 10.1.1.152(LDP Id) -> 10.1.1.151, LDP is UP
Status TLV support (local/remote) : enabled/supported
LDP route watch : enabled
Label/status state machine : established, LruRru
Last local dataplane status rcvd: No fault
Last local SSS circuit status rcvd: No fault
Last local SSS circuit status sent: No fault
Last local LDP TLV status sent: No fault
Last remote LDP TLV status rcvd: No fault
Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 2000, remote 2000
PWID: 20490
Group ID: local 0, remote 0
MTU: local 4470, remote 4470
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
VCCV BFD protection active
BFD Template - sampleBFDTemplate
CC Type - 1
CV Type - fault detection only with IP/UDP headers
VC statistics:
transit packet totals: receive 0, send 0
transit byte totals: receive 0, send 0
transit packet drops: receive 0, seq error 0, send 0

```

The table below describes the significant fields shown in the display.

Table 29: show l2vpn atom vc detail Field Descriptions for the BFD CC over VCCV—Support for ATM Pseudowire Feature

Field	Description
VCCV BFD protection active	Displays the virtual circuit connectivity verification (VCCV) BFD protection status.
BFD Template	Displays the BFD template name.
CC Type	Displays the continuity check (CC) type. <ul style="list-style-type: none"> • Type 1: control word. • Type 2: MPLS device alert label. • Type 3: MPLS pseudowire label with time to live (TTL).
CV Type	Displays the Control Verification type.

The following is sample output from the **show l2vpn atom vc** command when the L2VPN VPLS Inter-AS Option B feature has been configured. The fields in the display are self-explanatory or described in other tables in this document:

```
Device# show l2vpn atom vc

Load for five secs: 4%/1%; one minute: 4%; five minutes: 2%
Time source is hardware calendar, *17:26:56.066 GMT Mon Oct 18 2010
Local intf      Local circuit      Dest address      VC ID      Status
-----
VFI auto       VFI                 10.1.1.1         100        UP
```

The following is sample output from the **show l2vpn atom vc detail** command when the L2VPN VPLS Inter-AS Option B feature has been configured:

```
Device# show l2vpn atom vc detail

Load for five secs: 4%/1%; one minute: 4%; five minutes: 2%
Time source is hardware calendar, *17:27:28.076 GMT Mon Oct 18 2010
Local interface: VFI auto VFI up
  Interworking type is Ethernet
  Destination address: 192.0.2.1, VC ID: 100, VC status: up
  Next hop PE address: 198.51.100.1
  Output interface: Et1/0, imposed label stack {2012}
  Preferred path: not configured
  Default path: active
  Next hop: 10.0.0.3
Create time: 00:00:48, last status change time: 00:00:48
Signaling protocol: LDP, peer 192.0.2.3:0 up
  Targeted Hello: 192.0.2.6(from BGP) -> 192.0.2.8, LDP is UP
  Status TLV support (local/remote) : enabled/supported
  LDP route watch : enabled
  Label/status state machine : established, LruRru
  Last local dataplane status rcvd: No fault
  Last local SSS circuit status rcvd: No fault
  Last local SSS circuit status sent: No fault
  Last local LDP TLV status sent: No fault
  Last remote LDP TLV status rcvd: No fault
  Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 1011, remote 2012
```

```

PWID: 4096
AGI: type 1, len 8, 000A 0001 0000 0001
Local AII: type 1, len 4, 0101 0001 (203.0.113.1)
Remote AII: type 1, len 4, 0201 0101 (203.0.113.5)
VPLS-ID: 1:1
Group ID: local n/a, remote n/a
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
SSO Descriptor: 203.0.113.5/100, local label: 1011
SSM segment/switch IDs: 16387/8193 (used), PWID: 4096
VC statistics:
transit packet totals: receive 0, send 0
transit byte totals: receive 0, send 0
transit packet drops: receive 0, seq error 0, send 0

```

The table below describes the significant fields shown in the display.

Table 30: show l2vpn atom vc detail Field Descriptions for the L2VPN VPLS Inter-AS Option B

Field	Description
PWID	Pseudowire identifier.
VPLS-ID	The VPLS identifier associated with the pseudowire.

The following is sample output from the **show l2vpn atom vc detail** command when there is a remote AC failure and when VCCV BFD status signaling is enabled, that is, **vccv bfd status signaling** is configured:

```

Device# show l2vpn atom vc detail

Load for five secs: 0%/0%; one minute: 0%; five minutes: 0%
Time source is hardware calendar, *03:31:33.136 PST Thu Mar 24 2011
Local interface: Et1/0.1 up, line protocol up, Eth VLAN 1001 up
Destination address: 192.0.2.1, VC ID: 1234000, VC status: down
  Output interface: Et0/0, imposed label stack {150}
  Preferred path: not configured
  Default path: active
  Next hop: 198.58.100.2
Create time: 00:03:45, last status change time: 00:00:02
Signaling protocol: Manual
  Status TLV support (local/remote) : enabled/N/A
  LDP route watch : enabled
  Label/status state machine : established, LruRrd
  Last local dataplane status rcvd: No fault
  Last BFD dataplane status rcvd: No fault
  Last local SSS circuit status rcvd: No fault
  Last local SSS circuit status sent: DOWN AC(rx/tx faults)
  Last local LDP TLV status sent: None
  Last remote LDP TLV status rcvd: DOWN AC(rx/tx faults), (UP)
  Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 100, remote 150
PWID: 4096
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
VCCV BFD protection active
  BFD Template - t1

```



```

CC Type - 1
CV Type - fault detection and status signaling without IP/UDP headers
VC statistics:
transit packet totals: receive 0, send 5
transit byte totals:   receive 0, send 580
transit packet drops: receive 0, seq error 0, send 0

```

The table below describes the significant fields shown in the display.

Table 31: show l2vpn atom detail Field Descriptions for Remote AC Failure

Field	Description
Last BFD dataplane status rcvd	Last status message received about the BFD dataplane on the local device.
Last local dataplane status rcvd	Last status message received about the dataplane on the local device.
Last local SSS circuit status rcvd	Last status message received about the subscriber service switch (SSS) on the local device.
Last local SSS circuit status sent	Last status message sent about the subscriber service switch on the local device.
Last remote LDP ADJ	Last status message received about the ADJ on the local device.
VCCV BFD protection active	Displays the VCCV BFD protection status.
BFD Template	Displays the BFD template name.
CC Type	Displays the CC type. <ul style="list-style-type: none"> • Type 1: control word. • Type 2: MPLS device alert label. • Type 3: MPLS pseudowire label with TTL.
CV Type	Displays the Control Verification (CV) type.

Related Commands

Command	Description
show l2vpn atom summary	Displays summary information about VCs that have been enabled to route AToM Layer 2 packets on a device.
show l2vpn atom vc	Displays information about AToM VCs and static pseudowires.
show xconnect	Displays information about xconnect attachment circuits and pseudowires.
show mpls forwarding-table	Displays the contents of the MPLS LFIB.

show l2vpn pwmib

To display information about the Layer 2 VPN (L2VPN) pseudowire MIB, use the **show l2vpn pwmib** command in privileged EXEC mode.

show l2vpn pwmib [{peer ip-address vcid-value}]

Syntax Description

peer	(Optional) Displays information about L2VPN cross connect attachment circuits and pseudowires associated with the specified peer.
<i>ip-address</i>	(Optional) IP address of the peer.
<i>vcid-value</i>	(Optional) Virtual circuit (VC) ID value.

Command Default

Information about the L2VPN pseudowire MIB for all peers is displayed.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the pwmib keyword in the show xconnect command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Usage Guidelines

Use the **show l2vpn pwmib** command to display information about the L2VPN pseudowire MIB. You can specify the peer IP address and the virtual circuit (VC) ID value to display information associated with the specified peer IP address and the specified VC ID.

Examples

The following is sample output from the **show l2vpn pwmib** command for a peer with IP address is 10.3.2.1 and a VC ID value of 4000:

```
Device# show l2vpn pwmib peer 10.3.2.1 4000
VCINDEX  VC ID  Peer Address  Encap  Status  Interface
1         4      10.10.10.10  MPLS   up      Et1/0
2         5      11.11.11.11  MPLS   down   Et1/0
```

Related Commands

Command	Description
show l2vpn rib	Displays information about the L2VPN cross connect RIB.
show l2vpn vfi	Displays L2VPN VFI information.
show l2vpn service	Displays L2VPN service information.
show xconnect	Displays information about xconnect attachment circuits and pseudowires.

show l2vpn rib

To display information about the Layer 2 VPN (L2VPN) pseudowire Routing Information Base (RIB), use the **show l2vpn rib** command in privileged EXEC mode.

```
show l2vpn rib [{{{next-hop | target-id} ip-address} [{detail}]] | vpls-id {asn:nn | ip-address:nn}}
```

Syntax Description	Parameter	Description
	next-hop	(Optional) Displays the L2VPN RIB information for the specified next hop.
	target-id	(Optional) Displays the L2VPN RIB information for the specified target.
	<i>ip-address</i>	IP address of the next-hop or target address.
	detail	(Optional) Displays detailed information about the L2VPN RIB.
	vpls-id	(Optional) Displays the L2VPN RIB information about the specified Virtual Private LAN Service (VPLS) extended community.
	<i>asn:nn ip-address:nn</i>	(Optional) IP address and network number or autonomous system number (ASN) and network number of the VPLS.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the rib keyword in the show xconnect command in future releases.
	15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following is sample output from the **show l2vpn rib** command:

```
Device# show l2vpn rib

Local Router ID: 10.0.0.0
+- Origin of entry (I=iBGP/e=eBGP)
| +- Imported without a matching route target (Yes/No)?
| | +- Provisioned (Yes/No)?
| | | +- Stale entry (Yes/No)?
| | | |
| | | |
v v v v
O I P S          VPLS-ID          Target ID          Next-Hop          Route-Target
+---+---+-----+-----+-----+-----+-----+
I Y N N          66:66            10.0.0.1          10.1.1.2          66:66
I Y N N          66:66            10.1.1.2          10.1.1.3          66:66
I N Y N          1:1              10.1.1.1          10.1.1.1          2:2
I N Y N          1:1              10.1.1.1          10.1.1.3          2:2
I N Y N
```

The table below describes the fields shown in the command display.

Table 32: show l2vpn rib Field Descriptions

Field	Description
Local Router ID	A unique router identifier. Virtual Private LAN Service (VPLS) autodiscovery automatically generates a router ID using the MPLS global router ID.
Origin of entry	Origin of the entry. The origin can be "I" for internal Border Gateway Protocol (BGP) or "e" for external BGP.
Imported without a matching route target	Specifies whether the route was imported prior to configuring a route target.
Provisioned	Specifies whether the pseudowire has been provisioned using a learned route.
VPLS/WPWS-ID	VPLS domain. VPLS Autodiscovery automatically generates a VPLS ID using the BGP autonomous system number and the configured VFI VPN ID.
Target ID	Target ID. The IP address of the destination device.
next-hop	IP address of the next-hop device.
Route-Target	Route target (RT). VPLS autodiscovery generates a route target using the lower 6 bytes of the route distinguisher (RD) and VPN ID.

The following is sample output for the **show l2vpn rib detail** command.

```
Device# show l2vpn rib detail

Local Router ID: 10.9.9.9
VPLS-ID 10:123, TID 10.7.7.7
  Next-Hop: 10.7.7.7
  Hello-Source: 10.9.9.9
  Route-Target: 10:123
  Incoming RD: 10:10
  Forwarder: vfi VPLS1
  Origin: BGP
  Provisioned: Yes
VPLS-ID 10:123, TID 10.7.7.8
  Next-Hop: 10.7.7.8
  Hello-Source: 10.9.9.9
  Route-Target: 10:123
  Incoming RD: 10:11
  Forwarder: vfi VPLS1
  Origin: BGP
  Provisioned: No
VPLS-ID 10.100.100.100:1234, TID 0.0.0.2
  Next-Hop: 10.2.2.2, 10.3.3.3, 10.4.4.4
  Hello-Source: 10.9.9.9
  Route-Target: 10.111.111.111:12345, 10.8.8.8:345
  Incoming RD: 10:12
  Forwarder: vfi VPLS2
  Origin: BGP
  Provisioned: Yes
VPLS-ID 10.100.100.100:1234, TID 10.13.1.1
  Next-Hop: 10.1.1.1
```

```

Hello-Source: 10.9.9.9
Route-Target: 10.111.111.111:12345
Incoming RD: 10:13
Forwarder: vfi VPLS2
Origin: BGP
Provisioned: Yes

```

The table below describes the fields shown in the command display.

Table 33: show l2vpn rib Field Descriptions

Field	Description
Hello-Source	Source IP address used when Label Distribution Protocol (LDP) hello messages are sent to the LDP peer for the autodiscovered pseudowire.
Incoming RD	Route distinguisher for the autodiscovered pseudowire.
Forwarder	VFI to which the autodiscovered pseudowire is attached.

The following is sample output from the **show l2vpn rib** command when used in a L2VPN VPLS Inter-AS Option B configuration:

```

Device# show l2vpn rib

Local Router ID: 10.9.9.9
+- Origin of entry (I=iBGP/e=eBGP)
| +- Provisioned (Yes/No)?
| | +- Stale entry (Yes/No)?
| | |
v v v
O P S      VPLS-ID      Target ID      Next-Hop      Route-Target
-+-+-----+-----+-----+-----+-----
I Y N      1:1          10.11.11.11   10.11.11.11   1:1
I Y N      1:1          10.12.12.12   10.12.12.12   1:1

```

Related Commands

Command	Description
show l2vpn vfi	Displays L2VPN VFI information.
show l2vpn service	Displays L2VPN service information.
show xconnect	Displays information about xconnect attachment circuits and pseudowires.

show l2vpn service

To display Layer 2 VPN (L2VPN) service information, use the **show l2vpn service** command in privileged EXEC mode.

```
show l2vpn service[{vfi | xconnect}] {all [{detail}] | interface int-type number | name service-name | peer peer-address {all | vcid vcid-value [{detail}]}}
```

Syntax Description

vfi	(Optional) Displays all Virtual Private LAN Services (VPLS).
xconnect	(Optional) Displays all Virtual Private Wire Services (VPWS).
all	Displays all service entries.
detail	(Optional) Displays detailed service information.
interface <i>int-type number</i>	Displays information about all services by the specified interface type and number.
name <i>service-name</i>	Displays information for the specified service.
peer <i>peer-address</i>	Displays all services by the IP address of the remote peer.
vcid <i>vcid-value</i>	Displays all services by the virtual circuit (VC) ID.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support.
15.3(1)S	This command was integrated as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following is sample output from **show l2vpn service all** command when Label Distribution Protocol (LDP) signaling is used:

```
Device# show l2vpn service all
```

```
Legend: St=State      Prio=Priority
         UP=Up         DN=Down         AD=Admin Down   IA=Inactive
         SB=Standby   HS=Hot Standby RV=Recovering  NH=No Hardware
```

```
Interface          Group          Encapsulation          Prio  St  XC St
-----          -
XC name: serviceWire1, State: UP
```

```

Eth1/1:10      access      EVC 45          0      UP  UP
Pw1            core        MPLS 5.5.5.5:100 0      UP  UP

Pw2            core        MPLS 6.6.6.6:200 1      SB  IA
XC name: serviceConn2, State:UP
Eth2/1:20      access_conn EVC 55          0      UP  UP
Eth3/1:20      core_conn   EVC 55          0      DN  IA

Eth4/1:20      core_conn   EVC 55          1      UP  UP

XC name: serviceStit3, State: UP
Pw3            left        MPLS 7.7.7.7:300 0      UP  UP

Pw4            right       MPLS 8.8.8.8:300 0      UP  UP

```

The following is sample output from **show l2vpn service all detail** command when LDP signaling is used:

Device# **show l2vpn service all detail**

```

Legend: St=State      Prio=Priority
        UP=Up          DN=Down          AD=Admin Down    IA=Inactive
        SB=Standby    HS=Hot Standby  RV=Recovering    NH=No Hardware

```

XC name: serviceWire1, State: UP, Signaling Protocol: LDP

Group: access

```

Interface      Encapsulation      Prio  St  XC  St
-----
Ethernet1/1    EVC 45, dot1q 10   0     UP  UP

```

Group: core

```

Interface      Encapsulation      Prio  St  XC  St
-----
Pseudowire1    MPLS 5.5.5.5:100   0     UP  UP
Local VC label 2004
Remote VC label 3004

```

```

Interworking: none, VC type: 4
template: mpls_1
Pseudowire2    MPLS 6.6.6.6:200   1     SB  IA
Local VC label 2008
Remote VC label 4008

```

```

Interworking: none, VC type: 4
template: mpls_1

```



```

i Y N 1:1 11 10 10 2002 1.1.1.2
i Y N 1:1 12 10 10 2002 1.1.1.3
i Y N 1:2 21 12 12 2012 1.1.1.2
i Y N 1:2 22 12 12 2012 1.1.1.3

```

Table 34: show l2vpn signaling rib Field Descriptions

Field	Description
Origin of entry	Origin of the entry. The origin can be “i” for internal Border Gateway Protocol (BGP) or “e” for external BGP.
Provisioned	Specifies whether the pseudowire has been provisioned using a learned route.
Next-Hop	IP address of the next-hop device.

The following is sample output from the **show l2vpn signaling rib detail** command:

```

Device# show l2vpn signaling rib rd 1:1 detail
Load for five secs: 0%/0%; one minute: 0%; five minutes: 0%
Time source is hardware calendar, *20:57:12.265 GMT Wed Aug 29 2012
Route 1:1:11 (epoch:1) from iBGP peer 1.1.1.2
Provisioned (Y) Stale (N)
Route-Target: 1:1
NLRI [6E000001]
VE-ID:11 VBO:10 VBS:10 LB:2002
MTU: 1500 Control Word: off
RIB Filter [44000001]
RD: 1:1
VE-ID: 10, VBO: 10, VBS: 10 LB: 1002
Forwarder [F0000001] VFI VFI1
Route 1:1:12 (epoch:1) from iBGP peer 1.1.1.3
Provisioned (Y) Stale (N)
Route-Target: 1:1
NLRI [35000003]
VE-ID:12 VBO:10 VBS:10 LB:2002
MTU: 1500 Control Word: off
RIB Filter [44000001]
RD: 1:1
VE-ID: 10, VBO: 10, VBS: 10 LB: 1002
Forwarder [F0000001] VFI VFI1

```

Related Commands

Command	Description
show l2vpn rib	Displays information about the L2VPN cross-connect RIB.
show l2vpn rib vfi	Displays L2VPN VFI information.
show l2vpn service	Displays L2VPN service information.
show xconnect	Displays information about xconnect attachment circuits and pseudowires.

show l2vpn vfi

To display Layer 2 VPN (L2VPN) virtual forwarding instance (VFI) information use the **show l2vpn vfi** command in privileged EXEC mode.

show l2vpn vfi [{**name** *vfi-name* | **neighbor** *peer-address* **vcid** *vcid-value*}] [{**mac static address**}]

Syntax Description

name <i>vfi-name</i>	(Optional) Displays L2VPN VFI information for a specific VFI.
neighbor	(Optional) Displays VFI per neighbor information.
<i>peer-address</i>	(Optional) IP address of the remote peer.
mac static address	(Optional) Displays static MAC information.
vcid <i>vcid-value</i>	(Optional) Displays VFI information for the specific virtual circuit (VC) ID value of a remote peer.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 3.7S	This command was introduced as part of the Multiprotocol Label Switching (MPLS)-based L2VPN command modifications for cross-OS support. This command will replace the show vfi command in future releases.
15.3(1)S	This command was integrated in Cisco IOS Release 15.3(1)S.

Examples

The following is sample output from the **show l2vpn vfi** command when Label Distribution Protocol (LDP) signaling is used. The output fields are self-explanatory.

```
Device# show l2vpn vfi
```

```
Legend: RT= Route-target
```

```
VFI name: serviceCore1, State: UP, Signaling Protocol: LDP
VPN ID: 100, VPLS-ID: 9:10, Bridge-domain vlan: 100
RD: 9:10, RT: 10.10.10.10:150
Pseudo-port Interface: Virtual-Ethernet1000
```

```
Neighbors connected via pseudowires:
```

Interface	Peer Address	VC ID	Discovered Router ID	Next Hop
Pw2000	10.0.0.1	10	10.0.0.1	10.0.0.1
Pw2001	10.0.0.2	10	10.1.1.2	10.0.0.2
Pw2002	10.0.0.3	10	10.1.1.3	10.0.0.3
Pw5	10.0.0.4	10	-	10.0.0.4

The following is sample output from the **show l2vpn vfi** command when Border Gateway Protocol (BGP) signaling is used. The output fields are self-explanatory.

```
Device# show l2vpn vfi
```

```

VFI name: serviceCore1, State: UP, Signaling Protocol: BGP
  Bridge Domain: <bd>
  VPN ID: <vpn>
  RD: <rd>, RT: <rt>
  Pseudo-port Interface: Virtual-Ethernet1000

Local Edge ID: <ve_id>, Label Blocks (<num> Blocks)
Label Base Offset      Size      Timestamp  St
-----
5000      1          100      <time>    UP

List of discovered peers (<num>):
Remote Edge Device 1:
Remote Edge ID: <remote_ve_id>, NLRIs (<num> NLRIs)
Interface Label Base Offset      Size      Peer ID      Timestamp  St
-----
Pw1      6000      1          10      10.1.1.1    <time>    UP

Remote Edge Device 2:
Remote Edge ID: <remote_ve_id>, NLRIs (<num> NLRIs)
Interface Label Base Offset      Size      Peer ID      Timestamp  St
-----
Pw2      7000      100      10      20.1.1.1    <time>    UP

```

Related Commands	Command	Description
	show l2vpn atom binding	Displays VC label binding information.
	show l2vpn atom checkpoint	Displays the checkpoint information about AToM VCs.
	show l2vpn atom hw-capability	Displays the transport types and their supported capabilities.
	show l2vpn atom vc	Displays information about AToM VCs that have been enabled to route Layer 2 packets on a device.
	show l2vpn rib	Displays information about the L2VPN crossconnect RIB.
	show l2vpn service	Displays L2VPN service information.
	show xconnect vfi	Displays xconnect VFI information.

show mpls atm-ldp bindings



Note Effective with Cisco IOS Release 12.4(20)T, the **show mpls atm-ldp bindings** command is not available in Cisco IOS software.

To display specified entries from the ATM label binding database, use the **show mpls atm-ldp bindings** command in privileged EXEC mode.

show mpls atm-ldp bindings [*network* {*masklength*}] [**local-label** *vpi vci*] [**remote-label** *vpi vci*] [**neighbor** *interface*]

Syntax Description

<i>network</i>	(Optional) Defines the destination network number.
<i>mask</i>	(Optional) Defines the network mask in the form A.B.C.D (destination prefix).
<i>length</i>	(Optional) Defines the mask length (1 to 32).
local-label <i>vpi vci</i>	(Optional) Selects the label values assigned by this router. The virtual path identifier (VPI) range is 0 to 4095. The virtual channel identifier (VCI) range is 0 to 65535.
remote-label <i>vpi vci</i>	(Optional) Selects the label values assigned by the other router. VPI range is 0 to 4095. VCI range is 0 to 65535.
neighbor <i>interface</i>	(Optional) Selects the label values assigned by the neighbor on a specified interface.

Command Default

The entire ATM label binding database is displayed if no optional arguments or keywords are specified.



Note To display information about entries in the label binding database for interfaces other than ATM interfaces, use the **show mpls ip binding** command.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	This command was modified to use Multiprotocol Label Switching (MPLS) Internet Engineering Task Force (IETF) command syntax and terminology.
12.0(14)ST	This command was integrated into Cisco IOS Release 12.0(14)ST.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.

Release	Modification
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	The VPI range of values for this command was extended to 4095.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000-PRE2 router.
12.4(20)T	This command was removed.

Usage Guidelines

The ATM label binding database contains entries for label virtual circuits (VCs) on label-controlled (LC)-ATM interfaces. Command output can show a summary of entries from the entire database, or the output can be limited to a subset of entries based on the following:

- Specific prefix
- Specific VC label value
- Specific assigning interface



Note This command displays ATM label bindings learned by the Label Distribution Protocol (LDP) or Tag Distribution Protocol (TDP). TDP is not supported for LDP features in Cisco IOS 12.0(30)S and later releases, 12.2(27)SBC and later 12.2S releases, and 12.3(14)T and later releases.



Note The show mpls ip binding command includes the output generated by the show mpls atm-ldp bindings command and information about label bindings for packet interfaces.

Examples

The following is sample output from the **show mpls atm-ldp bindings** command:

```
Router# show mpls atm-ldp bindings
Destination: 10.24.0.0/24
  Tailend Router ATM1/0.1 1/39 Active, VCD=3
Destination: 10.15.0.15/32
  Tailend Router ATM1/0.1 1/33 Active, VCD=4
Destination: 10.0.7.7/32
  Headend Router ATM1/0.1 (2 hops) 1/34 Active, VCD=810
```

The following is sample output from the **show mpls atm-ldp bindings** command on an ATM switch:

```
Router# show mpls atm-ldp bindings
Destination: 172.16.0.0/16
    Tailend Switch ATM0/0/3 1/35 Active -> Terminating Active
Destination: 10.4.4.4/32
    Transit ATM0/0/3 1/33 Active -> ATM0/1/1 1/33 Active
```

The table below describes the significant fields shown in the displays.

Table 35: show mpls atm-ldp bindings Field Descriptions

Field	Description
Destination	Destination (network/mask).
Headend Router	Indicates types of VCs. Options are the following: <ul style="list-style-type: none"> • Tailend--VC that terminates at this platform • Headend--VC that originates at this router • Transit--VC that passes through a switch
Tailend Router	
Tailend Switch	
Transit	
ATM1/0.1	ATM interface.
1/35	VPI/VCI.
Active	Indicates VC state. Options include the following: <ul style="list-style-type: none"> • Active--Set up and working • Bindwait--Waiting for a response • Remote Resource Wait--Waiting for resources (VPI/VCI space) to be available on the downstream device • Parent Wait--Transit VC input side waiting for output side to become active
VCD=3	Virtual circuit descriptor number.

Related Commands

Command	Description
show mpls ip binding	Displays specified information about label bindings learned by the MPLS LDP.

show mpls atm-ldp bindwait



Note Effective with Cisco IOS Release 12.4(20)T, the **show mpls atm-ldp bindwait** command is not available in Cisco IOS software.

To display the number of bindings waiting for label assignments from a remote Multiprotocol Label Switching (MPLS) ATM switch, use the **show mpls atm-ldp bindwait** command in privileged EXEC mode.

show mpls atm-ldp bindwait

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(5)T	This command was introduced.
12.2(4)T	This command was modified to use MPLS Internet Engineering Task Force (IETF) command syntax and terminology.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.4(20)T	This command was removed.

Usage Guidelines

Use this command to display information about virtual circuits (VCs) in the bindwait state.

Examples

The following is sample output from the **show mpls atm-ldp bindwait** command:

```
Router# show mpls atm-ldp bindwait
Waiting for bind on ATM1/0.2
 10.3.3.1/32      10.3.3.1/32      10.3.3.2/32
 10.3.3.2/32      10.3.3.3/32      10.3.3.3/32
 10.3.3.4/32      10.3.3.4/32      10.3.3.5/32
 10.3.3.5/32      10.3.3.6/32      10.3.3.6/32
 10.3.3.7/32      10.3.3.7/32      10.3.3.8/32
 10.3.3.8/32      10.3.3.9/32      10.3.3.9/32
```

```
.  
.end
```

If there are no bindings waiting for label assignments from the remote MPLS ATM switch, this command does not display any output.

Related Commands

Command	Description
show mpls atm-ldp bindings	Displays specified entries from the ATM label binding database.

show mpls atm-ldp capability



Note Effective with Cisco IOS Release 12.4(20)T, the **show mpls atm-ldp capability** command is not available in Cisco IOS software.

To display the Multiprotocol Label Switching (MPLS) ATM capabilities negotiated with Label Distribution Protocol (LDP) neighbors for label-controlled (LC)-ATM interfaces, use the **show mpls atm-ldp capability** command in privileged EXEC mode.

show mpls atm-ldp capability

Syntax Description

This command has no arguments or keywords.

Command Default

This command always displays all the MPLS ATM capabilities negotiated with all the LDP neighbors.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	This command was modified to use MPLS Internet Engineering Task Force (IETF) command syntax and terminology.
12.0(14)ST	This command was integrated into Cisco IOS Release 12.0(14)ST.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000-PRE2 router.

Release	Modification
12.4(20)T	This command was removed.

Usage Guidelines

When two label switch routers (LSRs) establish an LDP session, they negotiate parameters for the session, such as the range of virtual path identifiers (VPIs) and virtual channel identifiers (VCIs) that will be used as labels.

This command displays the MPLS ATM capabilities negotiated by LDP or the Tag Distribution Protocol (TDP).

**Note**

TDP is not supported for LDP features in Cisco IOS 12.0(30)S and later releases, 12.2(27)SBC and later 12.2S releases, and 12.3(14)T and later releases.

Examples

The following is sample output from the **show mpls atm-ldp capability** command:

```
Router# show mpls atm-ldp capability
          VPI          VCI          Alloc  Odd/Even  VC Merge
ATM0/1/0  Range          Range          Scheme Scheme    IN   OUT
  Negotiated [100 - 101]   [33 - 1023]   UNIDIR          -   -
  Local      [100 - 101]   [33 - 16383] UNIDIR          EN  EN
  Peer       [100 - 101]   [33 - 1023]   UNIDIR          -   -

          VPI          VCI          Alloc  Odd/Even  VC Merge
ATM0/1/1  Range          Range          Scheme Scheme    IN   OUT
  Negotiated [201 - 202]   [33 - 1023]   BIDIR          -   -
  Local      [201 - 202]   [33 - 16383] UNIDIR  ODD      NO  NO
  Peer       [201 - 202]   [33 - 1023]   BIDIR  EVEN     -   -
```

The table below describes the significant fields shown in the display.

Table 36: show mpls atm-ldp capability Field Descriptions

Field	Description
VPI Range	Minimum and maximum numbers of VPIs supported on this interface.
VCI Range	Minimum and maximum numbers of VCIs supported on this interface.

Field	Description
Alloc Scheme	<p>Indicates the applicable allocation scheme, as follows:</p> <ul style="list-style-type: none"> • UNIDIR--Unidirectional capability indicates that the peer can, within a single VPI, support binding of the same VCI to different prefixes on different directions of the link. • BIDIR--Bidirectional capability indicates that within a single VPI, a single VCI can appear in one binding only. In this case, one peer allocates bindings in the even VCI space, and the other in the odd VCI space. The system with the lower LDP identifier assigns even-numbered VCIs. <p>The negotiated allocation scheme is UNIDIR, only if both peers have UNIDIR capability. Otherwise, the allocation scheme is BIDIR.</p> <p>Note These definitions for unidirectional and bidirectional are consistent with normal ATM usage of the terms; however, they are exactly opposite from the definitions for them in the IETF LDP specification.</p>
Odd/Even Scheme	Indicates whether the local device or the peer is assigning an odd- or even-numbered VCI when the negotiated scheme is BIDIR. It does not display any information when the negotiated scheme is UNIDIR.
VC Merge	<p>Indicates the type of virtual circuit (VC) merge support available on this interface. There are two possibilities, as follows:</p> <ul style="list-style-type: none"> • IN--Indicates the input interface merge capability. IN accepts the following values: <ul style="list-style-type: none"> • EN--The hardware interface supports VC merge, and VC merge is enabled on the device. • DIS--The hardware interface supports VC merge and VC merge is disabled on the device. • NO--The hardware interface does not support VC merge. • OUT--Indicates the output interface merge capability. OUT accepts the same values as the input merge side. <p>The VC merge capability is meaningful only on ATM switches. This capability is not negotiated.</p>
Negotiated	Indicates the set of options that both LDP peers have agreed to share on this interface. For example, the VPI or VCI allocation on either peer remains within the negotiated range.
Local	Indicates the options supported locally on this interface.
Peer	Indicates the options supported by the remote LDP peer on this interface.

Related Commands

Command	Description
mpls ldp atm vc-merge	Controls whether the vc-merge (multipoint-to-point) is supported for unicast label VCs.

show mpls atm-ldp summary



Note Effective with Cisco IOS Release 12.4(20)T, the **show mpls atm-ldp summary** command is not available in Cisco IOS software.

To display summary information about all the entries in the ATM label binding database, use the **show mpls atm-ldp summary** command in privileged EXEC mode.

show mpls atm-ldp summary

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	This command was modified to use Multiprotocol Label Switching (MPLS) Internet Engineering Task Force (IETF) command syntax and terminology.
12.0(14)ST	This command was integrated into Cisco IOS Release 12.0(14)ST.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.4(20)T	This command was removed.

Usage Guidelines Use this command to display dynamic ATM accounting information.

Examples The following is sample output from the **show mpls atm-ldp summary** command:

```

Router# show mpls atm-ldp summary
Total number of destinations: 406

ATM label bindings summary
interface      total   active  local   remote  Bwait   Rwait   IFwait
ATM0/0/0       406    406     404     2        0        0        0
ATM0/0/1       406    406     3        403     0        0        0

```

The table below describes the significant fields shown in the display.

Table 37: show mpls atm-ldp summary Field Descriptions

Field	Description
Total number of destinations:	Number of known destination address prefixes.
interface	Name of an interface with associated ATM label bindings.
total	Total number of ATM labels on this interface.
active	Number of ATM labels in an “active” state that are ready to use for data transfer.
local	Number of ATM labels assigned by this label switch router (LSR) on this interface.
remote	Number of ATM labels assigned by the neighbor LSR on this interface.
Bwait	Number of bindings that are waiting for a label assignment from the neighbor LSR.
Rwait	Number of bindings that are waiting for resources (virtual path identifier [VPI] /virtual channel identifier [VCI] space) to be available on the downstream device.
IFwait	Number of bindings that are waiting for learned labels to be installed for switching use.

Related Commands

Command	Description
show isis database verbose	Displays the requested entries from the ATM LDP label binding database.

show mls cef mpls exact-route

To display the Multiprotocol Label Switching (MPLS) hardware load-sharing results from the Multilayer Switching (MLS) hardware Layer 3 switching table, use the **show mls cef mpls exact-route** command in user EXEC or privileged EXEC mode.

show mls cef mpls exact-route {*dst-address src-address label-stack-depth value label outer-most-value* | **label** *outer-most-value*} [**label** *inner-most-value*]

Syntax Description

<i>dst-address</i>	Destination IP address.
<i>src-address</i>	Source IP address.
label-stack-depth <i>value</i>	Specifies the depth of the label stack. The range is from 1 to 1048575. The default value is zero.
label <i>outer-most-value</i>	Specifies the top-most label in the incoming packet. The range is from 16 to 1048575. The default value is zero.
label <i>inner-most-value</i>	(Optional) Specifies the bottom-most label in the incoming packet. The range is from 16 to 1048575. The default value is zero.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
15.1(2)S	This command was introduced on Cisco 7600 series routers.

Usage Guidelines

You can use the **show mls cef mpls exact-route** command to find the actual path used by the label traffic in an Equal Cost Multipath (ECMP). This command helps in debugging Layer 2 VPN (L2VPN)) and Layer 3 VPN (L3VPN) load balancing.



Note The **show mls cef mpls exact-route** command is supported only for L2VPN and L3VPN.

You must configure the appropriate parameters based on the control word in the incoming packets as follows:

- If the incoming packet contains the control word, you need not provide the source and destination address along with the label stack depth value.



Note You must configure the inner label value if you do not specify the source and destination IP address.

- If the incoming packet does not have the control word, you must provide all the attributes applicable for the packet; that is, source address, destination address, and label stack depth value.



Note The **show mls cef mpls exact-route** command may not display valid results when you use the command on provider edge (PE) routers for L2 and L3 VPNs. Hence, Cisco does not recommend using the command on PE routers for L2 and L3 VPNs.

Examples

The following is sample output from the **show mls cef mpls exact-route** command. Fields in the display are self-explanatory.

```
Router# show mls cef mpls exact-route 192.0.2.1 192.0.2.2 label-stack-depth 2 label 19
For EOS [0] choice Adjacency details are:
    Interface: Gi3/3/0, Next Hop: 192.168.3.1, Vlan: 1019, DestinationMac: 0006.5248.a400

For EOS [1] choice Adjacency details are:
    Interface: Gi3/3/0, Next Hop: 192.168.3.1, Vlan: 1019, DestinationMac: 0006.5248.a400
```

The following is sample output from the **show mls cef mpls exact-route** command when the source and destination IP address are not specified. Fields in the display are self-explanatory.

```
Router# show mls cef mpls exact-route label 18 label 20
For EOS [0] choice Adjacency details are:
    Interface: Tel/0/0, Next Hop: 10.0.0.1, Vlan: 1023, DestinationMac: 000b.fc1c.ee40
For EOS [1] choice Adjacency details are:
    Interface: Tel/0/0, Next Hop: 10.0.0.1, Vlan: 1023, DestinationMac: 000b.fc1c.ee40
```

Related Commands

Command	Description
show mpls forwarding-table	Displays the contents of the MPLS LIB.

show mpls cos-map



Note Effective with Cisco IOS Release 12.4(20)T, the **show mpls cos-map** command is not available in Cisco IOS software.

To display the quality of service (QoS) map used to assign a quantity of label virtual circuits and the associated class of service (CoS) for those virtual circuits, use the **show mpls cos-map** in privileged EXEC mode.

show mpls cos-map [*cos-map*]

Syntax Description

<i>cos-map</i>	(Optional) Number specifying the QoS map to be displayed.
----------------	---

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(5)T	This command was introduced.
12.0(10)ST	This command was modified to match Multiprotocol Label Switching (MPLS) syntax and terminology.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(25)S	The heading in the output was changed from tag-vc to label-vc.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.4(20)T	This command was removed.

Usage Guidelines

Not entering a specific QoS number causes all QoS maps to be displayed.



Note Cisco 10000 series routers do not use the **show mpls cos-map** command.

Examples

The following is sample output from the **show mpls cos-map** command:

```
Router# show mpls cos-map 2
cos-map 2    class Label-VC
             3    control
             2    control
             1    available
             0    available
```

The table below describes the significant fields shown in the display.

Table 38: show mpls cos-map Field Descriptions

Field	Description
cos-map	Configures a class map, which specifies how classes map to MPLS virtual circuits when they are combined with a prefix map.
class	The IP precedence.
Label-VC	An ATM virtual circuit that is set up through ATM label switch router (LSR) label distribution procedures.

Related Commands

Command	Description
mpls cos-map	Creates a class map specifying how classes map to label virtual circuits when they are combined with a prefix map.

show mpls flow mappings

To display all entries in the Multiprotocol Label Switching (MPLS) Prefix/Application/Label (PAL) table, use the **show mpls flow mappings** command in user EXEC mode or privileged EXEC mode.

show mpls flow mappings

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Usage Guidelines

If you are interested in only a certain type of MPLS label and do not want to display the entire MPLS PAL table, you can use the **show mpls flow mappings | include label-type** command.

Examples

The following sample output from the **show mpls flow mappings** command displays all entries in the MPLS PAL table:

```
Router# show mpls flow mappings
Label   Owner   Route-Distinguisher Prefix           Allocated
18      LDP     10.0.0.5          10.0.0.5        00:52:10
21      BGP     0.0.0.0           0.0.0.0         00:52:18
22      BGP     0.0.0.0           0.0.0.0         00:52:18
25      BGP     0.0.0.0           0.0.0.0         00:51:44
26      LDP     10.32.0.0         10.32.0.0       00:52:10
27      TE-MIDPT 10.30.0.2         10.30.0.2       00:52:06
28      LDP     10.33.0.0         10.33.0.0       00:52:10
29      LDP     10.0.0.1          10.0.0.1        00:52:10
30      LDP     10.0.0.3          10.0.0.3        00:52:10
```

In this example, the **mpls export vpnv4 prefixes** command was not configured. Therefore, the MPLS PAL table did not export a route distinguisher for the Border Gateway Protocol (BGP) application, and the associated prefix is exported as 0.0.0.0.

The table below describes the significant fields shown in the display.

Table 39: show mpls flow mappings Field Descriptions

Field	Description
Label	Value given to the MPLS label by the router.

Field	Description
Owner	MPLS application that allocated the label. <ul style="list-style-type: none"> • LDP = Label Distribution Protocol • BGP = Border Gateway Protocol • TE-MIDT = Traffic engineering tunnel midpoint
Route-Distinguisher	Value (8-byte) that is concatenated with an IPv4 prefix to create a unique VPN IPv4 prefix.
Prefix	Prefix used by the router to route data to the destination address.
Allocated	System uptime at which the MPLS PAL mapping record was created.

The following is sample output from the **show mpls flow mappings** command if you previously entered the **mpls export vpnv4 prefixes** command:

```
Router# show mpls flow mappings
Label  Owner      Route-Distinguisher Prefix      Allocated
16     LDP        10.0.0.3          10.0.0.3   00:58:03
17     LDP        10.33.0.0         10.33.0.0  00:58:03
19     TE-MIDPT   10.30.0.2         10.30.0.2  00:58:06
20     LDP        10.0.0.5          10.0.0.5   00:58:03
23     LDP        10.0.0.1          10.0.0.1   00:58:03
24     LDP        10.32.0.0         10.32.0.0  00:58:03
27     BGP        100:1             10.34.0.0  00:57:48
31     BGP        100:1             10.0.0.9   00:58:21
32     BGP        100:1             10.3.3.0   00:58:21
```

The following sample output from the **show mpls flow mappings | include LDP** command displays only MPLS PAL entries that were allocated by LDP:

```
Router# show mpls flow mappings | include LDP
Label  Owner      Route-Distinguisher Prefix      Allocated
16     LDP        10.0.0.3          10.0.0.3   00:58:03
17     LDP        10.33.0.0         10.33.0.0  00:58:03
20     LDP        10.0.0.5          10.0.0.5   00:58:03
23     LDP        10.0.0.1          10.0.0.1   00:58:03
24     LDP        10.32.0.0         10.32.0.0  00:58:03
```

Related Commands

Command	Description
show ip cache verbose flow	Displays a detailed summary of NetFlow statistics.
show ip flow export	Displays the status and the statistics for NetFlow accounting data export.

show mpls forwarding vrf

To display label forwarding information for advertised Virtual Private Network (VPN) routing and forwarding (VRF) instance routes, use the **show mpls forwarding vrf** command in privileged EXEC mode. To disable the display of label forwarding information, use the **no** form of this command.

show mpls forwarding vrf *vrf-name*[*{ip-prefix/length*[*{mask}*]]][**detail**][*{output-modifiers}*]

no show mpls forwarding vrf *vrf-name*[*{ip-prefix/length*[*{mask}*]]][**detail**][*{output-modifiers}*]

Syntax Description

<i>vrf-name</i>	Displays network layer reachability information (NLRI) associated with the named VRF.
<i>ip-prefix/length</i>	(Optional) IP prefix address (in dotted decimal format) and length of mask (0 to 32).
<i>mask</i>	(Optional) Destination network mask, in dotted decimal format.
detail	(Optional) Displays detailed information on the VRF routes.
<i>output-modifiers</i>	(Optional) For a list of associated keywords and arguments, use context-sensitive help.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0(5)T	This command was introduced.
12.0(21)ST	This command was modified to reflect new Multiprotocol Label Switching (MPLS) Internet Engineering Taskforce (IETF) terminology and CLI command syntax and was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(22)S	The command output was modified so that directly connected VRF networks no longer display as aggregate; no label appears instead.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

Use this command to display label forwarding entries associated with a particular VRF or IP prefix.

Examples

The following example shows label forwarding entries that correspond to the VRF called vpn1:

```

Router# show mpls forwarding vrf vpn1 detail
Local  Outgoing  Prefix          Bytes tag  Outgoing  Next Hop
tag    tag or VC   or Tunnel Id    switched   interface
35     24 10.0.0.0/8[V]  0            Et0/0/4  10.0.0.1
      MAC/Encaps=14/22, MRU=1496, Tag Stack{24 19}
      00D006FEDBE100D0974988048847 0001800000013000
      VPN route: vpn1
      No output feature configured
      Per-packet load-sharing

```

Related Commands

Command	Description
show ip cef vrf	Displays VRFs and associated interfaces.
show mpls forwarding-table	Displays the contents of the LFIB.

show mpls forwarding-table

To display the contents of the Multiprotocol Label Switching (MPLS) Label Forwarding Information Base (LFIB), use the **show mpls forwarding-table** command in user EXEC or privileged EXEC mode.



Note When a local label is present, the forwarding entry for IP imposition will not be showed; if you want to see the IP imposition information, use **show ip cef**.

show mpls forwarding-table [{*network* {*masklength*} | **interface** *interface* | **labels** *label* [**dash** *label*] | **lcatm atm** *atm-interface-number* | **next-hop** *address* | **lsp-tunnel** [*tunnel-id*]}] [**vrf** *vrf-name*] [**detail** *slot* *slot-number*]

Syntax Description

<i>network</i>	(Optional) Destination network number.
<i>mask</i>	IP address of the destination mask whose entry is to be shown.
<i>length</i>	Number of bits in the mask of the destination.
interface <i>interface</i>	(Optional) Displays entries with the outgoing interface specified.
labels <i>label-label</i>	(Optional) Displays entries with the local labels specified.
lcatm atm <i>atm-interface-number</i>	Displays ATM entries with the specified Label Controlled Asynchronous Transfer Mode (LCATM).
next-hop <i>address</i>	(Optional) Displays only entries with the specified neighbor as the next hop.
lsp-tunnel	(Optional) Displays only entries with the specified label switched path (LSP) tunnel, or with all LSP tunnel entries.
<i>tunnel-id</i>	(Optional) Specifies the LSP tunnel for which to display entries.
vrf <i>vrf-name</i>	(Optional) Displays entries with the specified VPN routing and forwarding (VRF) instance.
detail	(Optional) Displays information in long form (includes length of encapsulation, length of MAC string, maximum transmission unit [MTU], and all labels).
slot <i>slot-number</i>	(Optional) Specifies the slot number, which is always 0.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
11.1CT	This command was introduced.

Release	Modification
12.1(3)T	This command was integrated into Cisco IOS Release 12.1(3)T. The command was updated with MPLS terminology and command syntax.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T. The command was modified to accommodate use of the MPLS experimental (EXP) level as a selection criterion for packet forwarding. The output display was modified to include a bundle adjacency field and exp (vcd) values when the optional detail keyword is specified.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S. The IPv6 MPLS aggregate label and prefix information was added to the display.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.0(27)S	This command was integrated into Cisco IOS Release 12.0(27)S. The command output was modified to include explicit-null label information.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S. The output was changed in the following ways: <ul style="list-style-type: none"> • The term “tag” was replaced with the term “label.” • The term “untagged” was replaced with the term “no label.”
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA. This command was modified to remove the lsp-tunnel keyword.
12.2(33)SXH	This command was modified. The command output shows the status of local labels in holddown for the Cisco IOS Software Modularity: MPLS Layer 3 VPNs feature. The status indicator showing that traffic is forwarded through an LSP tunnel is moved to the local label and the lsp-tunnel keyword was removed.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.
15.1(1)S	This command was integrated into Cisco IOS Release 15.1(1)S. The output was modified to display the pseudowire identifier when the interface keyword is used.
15.1(2)SNG	This command was integrated into Cisco ASR 901 Series Aggregation Services Routers.
Cisco IOS XE Release 3.12S	The output was modified to display the configured label blocks.

Examples

The following is sample output from the **show mpls forwarding-table** command:

```
Device# show mpls forwarding-table
Local Outgoing      Prefix          Bytes label  Outgoing     Next Hop
-----
```

show mpls forwarding-table

```

Label Label or VC      or Tunnel Id      switched interface
26    No Label        10.253.0.0/16     0      Et4/0/0      10.27.32.4
28    1/33            10.15.0.0/16     0      AT0/0.1      point2point
29    Pop Label      10.91.0.0/16     0      Hs5/0        point2point
      1/36            10.91.0.0/16     0      AT0/0.1      point2point
30    32              10.250.0.97/32   0      Et4/0/2      10.92.0.7
      32              10.250.0.97/32   0      Hs5/0        point2point
34    26              10.77.0.0/24     0      Et4/0/2      10.92.0.7
      26              10.77.0.0/24     0      Hs5/0        point2point
35    No Label[T]     10.100.100.101/32 0      Tu301        point2point
36    Pop Label      10.1.0.0/16      0      Hs5/0        point2point
      1/37            10.1.0.0/16      0      AT0/0.1      point2point

[T] Forwarding through a TSP tunnel.
     View additional labeling info with the 'detail' option

```

The following is sample output from the **show mpls forwarding-table** command when the IPv6 Provider Edge Router over MPLS feature is configured to allow IPv6 traffic to be transported across an IPv4 MPLS backbone. The labels are aggregated because there are several prefixes for one local label, and the prefix column contains “IPv6” instead of a target prefix.

```

Device# show mpls forwarding-table
Local Outgoing Prefix Bytes label Outgoing Next Hop
Label Label or VC or Tunnel Id switched interface
16    Aggregate IPv6 0
17    Aggregate IPv6 0
18    Aggregate IPv6 0
19    Pop Label 192.168.99.64/30 0 Se0/0 point2point
20    Pop Label 192.168.99.70/32 0 Se0/0 point2point
21    Pop Label 192.168.99.200/32 0 Se0/0 point2point
22    Aggregate IPv6 5424
23    Aggregate IPv6 3576
24    Aggregate IPv6 2600

```

The following is sample output from the **show mpls forwarding-table detail** command. If the MPLS EXP level is used as a selection criterion for packet forwarding, a bundle adjacency exp (vcd) field is included in the display. This field includes the EXP value and the corresponding virtual circuit descriptor (VCD) in parentheses. The line in the output that reads “No output feature configured” indicates that the MPLS egress NetFlow accounting feature is not enabled on the outgoing interface for this prefix.

```

Device# show mpls forwarding-table detail
Local Outgoing Prefix Bytes label Outgoing Next Hop
label label or VC or Tunnel Id switched interface
16    Pop label 10.0.0.6/32 0 AT1/0.1 point2point
     Bundle adjacency exp(vcd)
     0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
     MAC/Encaps=12/12, MTU=4474, label Stack{}
     00010000AAAA030000008847
     No output feature configured
17    18 10.0.0.9/32 0 AT1/0.1 point2point
     Bundle adjacency exp(vcd)
     0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
     MAC/Encaps=12/16, MTU=4470, label Stack{18}
     00010000AAAA030000008847 00012000
     No output feature configured
18    19 10.0.0.10/32 0 AT1/0.1 point2point
     Bundle adjacency exp(vcd)
     0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
     MAC/Encaps=12/16, MTU=4470, label Stack{19}
     00010000AAAA030000008847 00013000
     No output feature configured

```



```

19  17          10.0.0.0/8      0      AT1/0.1      point2point
    Bundle adjacency exp(vcd)
    0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
    MAC/Encaps=12/16, MTU=4470, label Stack{17}
    00010000AAAA030000008847 00011000
    No output feature configured
20  20          10.0.0.0/8      0      AT1/0.1      point2point
    Bundle adjacency exp(vcd)
    0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
    MAC/Encaps=12/16, MTU=4470, label Stack{20}
    00010000AAAA030000008847 00014000
    No output feature configured
21  Pop label    10.0.0.0/24      0      AT1/0.1      point2point
    Bundle adjacency exp(vcd)
    0(1) 1(1) 2(1) 3(1) 4(1) 5(1) 6(1) 7(1)
    MAC/Encaps=12/12, MTU=4474, label Stack{}
    00010000AAAA030000008847
    No output feature configured
22  Pop label    10.0.0.4/32      0      Et2/3        10.0.0.4
    MAC/Encaps=14/14, MTU=1504, label Stack{}
    000427AD10430005DDFE043B8847
    No output feature configured

```

The following is sample output from the **show mpls forwarding-table detail** command. In this example, the MPLS egress NetFlow accounting feature is enabled on the first three prefixes, as indicated by the line in the output that reads “Feature Quick flag set.”

```

Device# show mpls forwarding-table detail
Local  Outgoing  Prefix          Bytes label  Outgoing  Next Hop
label  label or VC or Tunnel Id  switched  interface
16     Aggregate 10.0.0.0/8[V]  0           Et0/0/2    10.0.0.1
      MAC/Encaps=0/0, MTU=0, label Stack{}
      VPN route: vpn1
      Feature Quick flag set
Per-packet load-sharing, slots: 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
17     No label  10.0.0.0/8[V]  0           Et0/0/2    10.0.0.1
      MAC/Encaps=0/0, MTU=1500, label Stack{}
      VPN route: vpn1
      Feature Quick flag set
Per-packet load-sharing, slots: 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
18     No label  10.42.42.42/32[V] 4185      Et0/0/2    10.0.0.1
      MAC/Encaps=0/0, MTU=1500, label Stack{}
      VPN route: vpn1
      Feature Quick flag set
Per-packet load-sharing, slots: 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
19     2/33     10.41.41.41/32  0           AT1/0/0.1  point2point
      MAC/Encaps=4/8, MTU=4470, label Stack{2/33(vcd=2)}
      00028847 00002000
      No output feature configured

```

Cisco 10000 Series Examples

The following is sample output from the **show mpls forwarding-table** command for Cisco 10000 series routers:

```

Device# show mpls forwarding-table

Local  Outgoing  Prefix          Bytes Label  Outgoing  Next Hop
Label  Label or VC or Tunnel Id  Switched  interface
16     Pop Label  10.0.0.0/8      0           Fa1/0/0    10.0.0.2

```

show mpls forwarding-table

```

      Pop Label      10.0.0.0/8      0      Fa1/1/0      10.0.0.2
17    Aggregate     10.0.0.0/8[V]    570     vpn2
21    Pop Label     10.11.11.11/32   0      Fa1/0/0      10.0.0.2
22    Pop Label     10.12.12.12/32   0      Fa1/1/0      10.0.0.2
23    No Label      10.3.0.0/16[V]   0      Fa4/1/0      10.0.0.2

```

The following is sample output from the **show mpls forwarding-table detail** command for Cisco 10000 series routers:

```
Device# show mpls forwarding-table detail
```

```

Local   Outgoing   Prefix           Bytes Label   Outgoing   Next Hop
Label   Label or VC or Tunnel Id   Switched     interface
16      Pop Label   10.0.0.0/8      0             Fa1/0/0     10.0.0.2
      MAC/Encaps=14/14, MRU=1500, Label Stack{
      000B45C93889000B45C930218847
      No output feature configured
      Pop Label   10.0.0.0/8      0             Fa1/1/0     10.0.0.2
      MAC/Encaps=14/14, MRU=1500, Label Stack{
      000B45C92881000B45C930288847
      No output feature configured
17      Aggregate  10.0.0.0/8[V]   570          vpn2
      MAC/Encaps=0/0, MRU=0, Label Stack{
      VPN route: vpn2
      No output feature configured
21      Pop Label   10.11.11.11/32  0            Fa1/0/0     10.0.0.2
      MAC/Encaps=14/14, MRU=1500, Label Stack{
      000B45C93889000B45C930218847
      No output feature configured

```

The table below describes the significant fields shown in the displays.

Table 40: show mpls forwarding-table Field Descriptions

Field	Description
Local label	Label assigned by this device.
Outgoing Label or VC Note This field is not supported on the Cisco 10000 series routers.	Label assigned by the next hop or the virtual path identifier (VPI)/virtual channel identifier (VCI) used to get to next hop. The entries in this column are the following: <ul style="list-style-type: none"> • [T]--Forwarding is through an LSP tunnel. • No Label--There is no label for the destination from the next hop or label switching is not enabled on the outgoing interface. • Pop Label--The next hop advertised an implicit NULL label for the destination and the device removed the top label. • Aggregate--There are several prefixes for one local label. This entry is used when IPv6 is configured on edge devices to transport IPv6 traffic over an IPv4 MPLS network.

Field	Description
Prefix or Tunnel Id	Address or tunnel to which packets with this label are sent. Note If IPv6 is configured on edge devices to transport IPv6 traffic over an IPv4 MPLS network, "IPv6" is displayed here. • [V]--The corresponding prefix is in a VRF.
Bytes label switched	Number of bytes switched with this incoming label. This includes the outgoing label and Layer 2 header.
Outgoing interface	Interface through which packets with this label are sent.
Next Hop	IP address of the neighbor that assigned the outgoing label.
Bundle adjacency exp(vcd)	Bundle adjacency information. Includes the MPLS EXP value and the corresponding VCD.
MAC/Encaps	Length in bytes of the Layer 2 header and length in bytes of the packet encapsulation, including the Layer 2 header and label header.
MTU	MTU of the labeled packet.
label Stack	All the outgoing labels. If the outgoing interface is transmission convergence (TC)-ATM, the VCD is also shown. Note TC-ATM is not supported on Cisco 10000 series routers.
00010000AAAA030000008847 00013000	The actual encapsulation in hexadecimal form. A space is shown between Layer 2 and the label header.

Explicit-Null Label Example

The following is sample output, including the explicit-null label = 0 (commented in bold), for the **show mpls forwarding-table** command on a CSC-PE device:

```
Device# show mpls forwarding-table
Local  Outgoing  Prefix          Bytes label  Outgoing  Next Hop
label  label or VC or Tunnel Id    switched    interface
17     Pop label  10.10.0.0/32    0            Et2/0     10.10.0.1
18     Pop label  10.10.10.0/24  0            Et2/0     10.10.0.1
19     Aggregate  10.10.20.0/24[V] 0
20     Pop label  10.10.200.1/32[V] 0            Et2/1     10.10.10.1
21     Aggregate  10.10.1.1/32[V] 0
22     0          192.168.101.101/32[V] \
                                0
                                Et2/1     192.168.101.101
23     0          192.168.101.100/32[V] \
                                0
                                Et2/1     192.168.101.100
25     0          192.168.102.125/32[V] 0            Et2/1     192.168.102.125 !outlabel
value 0
```

The table below describes the significant fields shown in the display.

Table 41: show mpls forwarding-table Field Descriptions

Field	Description
Local label	Label assigned by this device.
Outgoing label or VC	Label assigned by the next hop or VPI/VCI used to get to the next hop. The entries in this column are the following: <ul style="list-style-type: none"> • [T]--Forwarding is through an LSP tunnel. • No label--There is no label for the destination from the next hop or that label switching is not enabled on the outgoing interface. • Pop label--The next hop advertised an implicit NULL label for the destination and that this device popped the top label. • Aggregate--There are several prefixes for one local label. This entry is used when IPv6 is configured on edge devices to transport IPv6 traffic over an IPv4 MPLS network. • 0--The explicit null label value = 0.
Prefix or Tunnel Id	Address or tunnel to which packets with this label are sent. <p>Note If IPv6 is configured on edge devices to transport IPv6 traffic over an IPv4 MPLS network, IPv6 is displayed here.</p> <ul style="list-style-type: none"> • [V]--Means that the corresponding prefix is in a VRF.
Bytes label switched	Number of bytes switched with this incoming label. This includes the outgoing label and Layer 2 header.
Outgoing interface	Interface through which packets with this label are sent.
Next Hop	IP address of the neighbor that assigned the outgoing label.

Cisco IOS Software Modularity: MPLS Layer 3 VPNs Example

The following is sample output from the **show mpls forwarding-table** command:

```
Device# show mpls forwarding-table
Local      Outgoing  Prefix      Bytes Label  Outgoing  Next Hop
Label      Label     or Tunnel Id  Switched     interface
16         Pop Label IPv4 VRF[V]  62951000    aggregate/v1
17         [H] No Label  10.1.1.0/24  0           AT1/0/0.1 point2point
           No Label  10.1.1.0/24  0           PO3/1/0 point2point
           [T] No Label  10.1.1.0/24  0           Tu1 point2point
18         [HT] Pop Label 10.0.0.3/32  0           Tu1 point2point
19         [H] No Label  10.0.0.0/8   0           AT1/0/0.1 point2point
           No Label  10.0.0.0/8   0           PO3/1/0 point2point
20         [H] No Label  10.0.0.0/8   0           AT1/0/0.1 point2point
           No Label  10.0.0.0/8   0           PO3/1/0 point2point
21         [H] No Label  10.0.0.1/32  812        AT1/0/0.1 point2point
           No Label  10.0.0.1/32  0           PO3/1/0 point2point
```

```

22      [H] No Label 10.1.14.0/24 0 AT1/0/0.1 point2point
        No Label 10.1.14.0/24 0 PO3/1/0 point2point
23      [HT] 16 172.1.1.0/24[V] 0 Tu1 point2point
24      [HT] 24 10.0.0.1/32[V] 0 Tu1 point2point
25      [H] No Label 10.0.0.0/8[V] 0 AT1/1/0.1 point2point
26      [HT] 16 10.0.0.3/32[V] 0 Tu1 point2point
27      No Label 10.0.0.1/32[V] 0 AT1/1/0.1 point2point
[T] Forwarding through a TSP tunnel.
View additional labelling info with the 'detail' option
[H] Local label is being held down temporarily.

```

The table below describes the Local Label fields relating to the Cisco IOS Software Modularity: MPLS Layer 3 VPNs feature.

Table 42: show mpls forwarding-table Field Descriptions

Field	Description
Local Label	<p>Label assigned by this device.</p> <ul style="list-style-type: none"> [H]--Local labels are in holddown, which means that the application that requested the labels no longer needs them and stops advertising them to its labeling peers. <p>The label's forwarding-table entry is deleted after a short, application-specific time.</p> <p>If any application starts advertising a held-down label to its labeling peers, the label could come out of holddown.</p> <p>Note [H] is not shown if labels are held down globally.</p> <p>A label enters global holddown after a stateful switchover or a restart of certain processes in a Cisco IOS modularity environment.</p> <ul style="list-style-type: none"> [T]--The label is forwarded through an LSP tunnel. <p>Note Although [T] is still a property of the outgoing interface, it is shown in the Local Label column.</p> <ul style="list-style-type: none"> [HT]--Both conditions apply.

L2VPN Inter-AS Option B: Example

The following is sample output from the **show mpls forwarding-table interface** command. In this example, the pseudowire identifier (that is, 4096) is displayed in the Prefix or Tunnel Id column. The **show mpls l2transport vc detail** command can be used to obtain more information about the specific pseudowire displayed.

```

Device# show mpls forwarding-table
Local      Outgoing  Prefix          Bytes Label  Outgoing  Next Hop
Label      Label     or Tunnel Id   Switched     interface
1011      No Label  12ckt(4096)    0            none      point2point

```

The table below describes the fields shown in the display.

Table 43: show mpls forwarding-table interface Field Descriptions

Field	Description
Local Label	Label assigned by this device.
Outgoing Label	Label assigned by the next hop or virtual path identifier (VPI)/virtual channel identifier (VCI) used to get to the next hop.
Prefix or Tunnel Id	Address or tunnel to which packets with this label are going.
Bytes Label Switched	Number of bytes switched with this incoming label. This includes the outgoing label and Layer 2 header.
Outgoing interface	Interface through which packets with this label are sent.
Next Hop	IP address of the neighbor that assigned the outgoing label.

Related Commands

Command	Description
neighbor send-label	Enables a BGP device to send MPLS labels with BGP routes to a neighboring BGP device.
neighbor send-label explicit-null	Enables a BGP device to send MPLS labels with explicit-null information for a CSC-CE device and BGP routes to a neighboring CSC-PE device.
show mpls l2transport vc detail	Displays information about AToM VCs and static pseudowires that have been enabled to route Layer 2 packets on a device.

show mpls forwarding-table exact-route

To display the exact path for the source and destination address pair, use the **show mpls forwarding-table exact-route** command in user EXEC or privileged EXEC mode.

show mpls forwarding-table exact-route label *label-number* {**bottom-label** *value* | **ipv4** *source destination* | **ipv6** *source destination* | **ethernet** *source destination*} [**detail**]

Syntax Description	label <i>label-number</i>	Displays the exact path for a source and destination address pair.
	bottom-label <i>value</i>	Bottom label value. Range is from 0 to 1048575.
	ipv4 <i>source destination</i>	Exact path for IPv4 traffic. The IPv4 source and destination addresses are in x.x.x.x format.
	ipv6 <i>source destination</i>	Exact path for IPv6 traffic. The IPv6 source and destination addresses are in x::x format.
	ethernet <i>source destination</i>	(Optional) Exact path for Ethernet traffic. The Ethernet source and destination addresses are in aaaa.bbbb.cccc format.
	[detail]	(Optional) Displays detailed information about the exact path for the source and destination address pair.

Command Modes User EXEC (>)

Privileged EXEC (#)

Command History	Release	Modification
	15.4(1)T	This command was introduced.
	15.4(1)S	This command was integrated into Cisco IOS Release 15.4(1)S.

Usage Guidelines The **ethernet** option is available only when the *label-number* specified in the **label** option is an L2VPN flow aware local label.

Examples The following is detailed sample output from the **show mpls forwarding-table exact-route detail** command:

```
Device# show mpls forwarding-table exact-route label 16 ethernet source aaaa.aaaa.aaaa
destination bbbb.bbbb.bbbb detail
```

```
Local      Outgoing  Prefix          Bytes Label  Outgoing  Next Hop
Label     Label    or Tunnel Id   Switched     interface
16        No Label  l2ckt(1)       0            Fa0/0/2   point2point
          MAC/Encaps=0/0, MRU=0, Label Stack{}
          No output feature configured
          Flow label: 4112
```

The following is sample output from the **show mpls forwarding-table exact-route** command:

show mpls forwarding-table exact-route

```
Device# show mpls forwarding-table exact-route label 19 bottom-label 4112
```

Local Label	Outgoing Label	Prefix or Tunnel Id	Bytes Switched	Label	Outgoing interface	Next Hop
19	20	4.4.4.4/32	687		Fa0/0/0	10.10.10.2

The following is sample output from the **show mpls forwarding-table exact-route** command, showing the exact path for IPv4 traffic:

```
Device# show mpls forwarding-table exact-route label 19 ipv4 source 1.1.1.1 destination 3.3.3.3
```

Local Label	Outgoing Label	Prefix or Tunnel Id	Bytes Switched	Label	Outgoing interface	Next Hop
19	17	3.3.3.3/32	0		Fa1/1	12.12.12.2

Related Commands

Command	Description
show mpls forwarding-table	Displays the contents of the MPLS LFIB.

show mpls infra lfd block-database

To display Multiprotocol Label Switching (MPLS) block application key databases, use the **show mpls infra lfd block-database** command in privileged EXEC mode.

```
show mpls infra lfd block-database [{detail | internal | slot number}] [{label number | id id-value}
[detail | internal | slot number}}]
```

Syntax Description	detail	(Optional) Displays detailed information.
	internal	(Optional) Displays the internal event counter.
	slot number	(Optional) Specifies slot and the slot number (0 to 15) of the Label Forwarding Database (LFD).
	label number	(Optional) Displays the MPLS label block and the label number (16 to 1048575).
	id id-value	(Optional) Displays the block ID (1 to 4294967295).
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Release 3.8S	This command was introduced.
Usage Guidelines	To enable the show mpls infra lfd block-database key command, the user must firstly enter global configuration mode, and then enter the service internal command, followed by the end command.	

Example

The following shows how to enable the **show mpls infra lfd block-database** command:

```
Device> enable
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# service internal
Device(config)# end
01:23:40: %SYS-5-CONFIG_I: Configured from console by console
Device# show mpls infra lfd block-database
```

Example

The following is sample output from the **show mpls infra lfd block-database id 3** command. In this example, the pseudowire identifier (that is, l2ckt[46]) corresponding to a label block is displayed.

```
Device#show mpls infra lfd block-database id 3
Block-DB entry for block-id : 0x3
Block-size : 10, App-Key type : ATOM PWID
App-Key entries:
l2ckt(46) 16
l2ckt(47) 17
l2ckt(48) 18
```

```

12ckt (49) 19
12ckt (50) 20
12ckt (51) 21
12ckt (52) 22
12ckt (53) 23
12ckt (54) 24
12ckt (55) 25

```

Related Commands

Command	Description
service internal	Enables infra commands to be configured.
show mpls forwarding-table	Displays the contents of the MPLS LFIB.
show mpls l2vc detail	Displays detailed information related to the VC.

show mpls interfaces

To display information about one or more or all interfaces that are configured for label switching, use the **show mpls interfaces** command in user EXEC or privileged EXEC mode.

show mpls interfaces [{*interface* | **vrf** *vpn-name*}] [**all**] [**detail**] [**internal**]

Syntax Description		
	<i>interface</i>	(Optional) Defines the interface about which to display label switching information.
	vrf <i>vpn-name</i>	(Optional) Displays information about the interfaces that have been configured for label switching for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance (<i>vpn-name</i>).
	all	(Optional) When the all keyword is specified alone in this command, information about the interfaces configured for label switching is displayed for all VPNs, including the VPNs in the default routing domain.
	detail	(Optional) Displays detailed label switching information.
	internal	(Optional) Indicates whether Multiprotocol Label Switching (MPLS) egress NetFlow accounting is enabled.

Command Default If no optional keyword or argument is specified in this command, summary information is displayed for each interface that has been configured for label switching in the default routing domain.

Command Modes
 User EXEC (>)
 Privileged EXEC (#)

Command History	Release	Modification
	11.1CT	This command was introduced.
	12.1(3)T	This command was updated with MPLS command syntax and terminology.
	12.0(10)ST	The internal keyword was added.
	12.0(14)ST	This command was modified to reflect MPLS VPN support for LDP.
	12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
	12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
	12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
	12.2(25)S	This command was modified to show Border Gateway Protocol (BGP) and static routing information.
	12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Usage Guidelines

This command shows MPLS information about the specified interface, or about all the interfaces for which MPLS has been configured.

If no optional keyword or argument is specified in this command, summary information is displayed for each interface configured for label switching.

Examples

The following is sample output from the **show mpls interfaces** command:

```
Router# show mpls interfaces
Interface          IP          Tunnel  Operational
Ethernet1/1/1     Yes (tdp)  No      No
Ethernet1/1/2     Yes (tdp)  Yes     No
Ethernet1/1/3     Yes (tdp)  Yes     Yes
POS2/0/0          Yes (tdp)  No      No
ATM0/0.1          Yes (tdp)  No      No          (ATM labels)
ATM3/0.1          Yes (ldp)  No      Yes          (ATM labels)
ATM0/0.2          Yes (tdp)  No      Yes
```

Cisco 10000 Series Example

The following is sample output from the **show mpls interfaces** command:

```
Router# show mpls interfaces
Interface          IP          Tunnel  BGP Static Operational
GigabitEthernet1/0/0  Yes       No      No  No  No
GigabitEthernet2/0/0  No        No      No  Yes No
GigabitEthernet3/0/0  No        Yes     No  No  No
```



Note

If an interface uses LC-ATM procedures, the associated line in the display is flagged with the notation (ATM labels).

The table below describes the significant fields shown in the display.

Table 44: show mpls interfaces Field Descriptions

Field	Description
Interface	Interface name.
IP	If IP label switching (sometimes called hop-by-hop label switching) is enabled on this interface, the column entry is “Yes.” Otherwise, the entry is “No.”

Field	Description
Tunnel	If label switched path (LSP) tunnel labeling is on this interface, the column entry is “Yes.” Otherwise, the entry is “No.”
BGP	If BGP has been enabled, the column entry is “Yes.” Otherwise, the entry is “No.”
Static	If static routes have been enabled, the column entry is “Yes.” Otherwise, the entry is “No.”
Operational	If packets are being labeled, the column entry is “Yes.” Otherwise, the entry is “No.”

The following is sample output from the **show mpls interfaces detail** command:

```
Router# show mpls interfaces detail
Interface Ethernet1/1/1:
  IP labeling enabled (tdp)
  LSP Tunnel labeling not enabled
  MPLS operational
  MPLS turbo vector
  MTU = 1500
Interface POS2/0/0:
  IP labeling enabled (ldp)
  LSP Tunnel labeling not enabled
  MPLS not operational
  MPLS turbo vector
  MTU = 4470
Interface ATM3/0.1:
  IP labeling enabled (ldp)
  LSP Tunnel labeling not enabled
  MPLS operational
  MPLS turbo vector
  MTU = 4470
  ATM labels: Label VPI = 1
               Label VCI range = 33 - 65535
               Control VC = 0/32
```

Cisco 10000 Series Example

The following example is sample output of the **show mpls interfaces detail** command:

```
Router# show mpls interfaces detail
Interface GigabitEthernet1/0/0:
  IP labeling enabled (ldp)
  LSP Tunnel labeling not enabled
  MPLS operational
  MTU = 1500
Interface POS2/0/0:
  IP labeling enabled (ldp)
  LSP Tunnel labeling not enabled
  MPLS not operational
  MTU = 4470
```

The table below describes the significant fields shown in the display.

Table 45: show mpls interfaces detail Field Descriptions

Field	Description
Interface	Interface name.
IP labeling	If IP label switching is enabled on this interface, the entry is “enabled.” Otherwise, the entry is “not enabled.” The output also shows whether LDP or TDP is being used.
LSP Tunnel labeling	If the LSP tunnel labeling is enabled on this interface, the entry is “enabled.” Otherwise, the entry is “not enabled.”
MPLS	If packets are labeled, the entry is “operational.” Otherwise, the entry is “not operational.”
BGP	If BGP has been enabled, the entry is “enabled.” Otherwise, the entry is “not enabled.”
MTU	The setting of the maximum transmission unit, in bytes.
ATM labels: Label VPI	The virtual path identifier (VPI). Note This field does not apply to the Cisco 10000 series routers.
Label VCI range	The range of values used in the VPI field for label VCs. Note This field does not apply to the Cisco 10000 series routers.
Control VC	The values assigned to the control VC. Note This field does not apply to the 10000 series routers.

The following is sample output from the **show mpls interfaces all** command:

```
Router# show mpls interfaces all
Interface          IP          Tunnel  Operational
ATM1/1/0.1        Yes (tdp)  No      Yes
VRF vpn1:
ATM3/0/0.1        Yes (ldp)  No      Yes
VRF vpn2:
ATM3/0/0.2        Yes (ldp)  No      Yes
VRF vpn3:
ATM3/0/0.3        Yes (ldp)  No      Yes
VRF vpn4:
ATM3/0/0.4        Yes (ldp)  No      Yes
VRF vpn5:
ATM3/0/0.5        Yes (ldp)  No      Yes
VRF vpn6:
Interface          IP          Tunnel  Operational
ATM3/0/0.6        Yes (ldp)  No      Yes
VRF vpn7:
ATM3/0/0.7        Yes (ldp)  No      Yes
VRF vpn8:
ATM3/0/0.8        Yes (ldp)  No      Yes
VRF vpn9:
ATM3/0/0.9        Yes (ldp)  No      Yes
```

```

VRF vpn10:
ATM3/0/0.10          Yes (ldp)    No          Yes
VRF vpn11:
ATM3/0/0.11          Yes (ldp)    No          Yes
VRF vpn12:
ATM3/0/0.12          Yes (ldp)    No          Yes
.
.
.

```

The following is sample output from the **show mpls interfaces internal** command. The output shows whether MPLS egress NetFlow accounting is enabled on the interface. If MPLS egress NetFlow accounting is disabled, the `Output_feature_state` field displays 0x0. If MPLS egress Netflow accounting is enabled, the `Output_feature_state` field is any number, except 0x0.

```

Router# show mpls interfaces internal
Interface Ethernet0/0/1:
  IP labeling enabled (tdp)
  LSP Tunnel labeling not enabled
  MPLS operational
  IP to Tag Fast Feature Switching Vector
  MPLS turbo vector
  MTU = 1500, status=0x100043, appcount=1
  Output_feature_state=0x0
Interface Ethernet0/0/2:
  IP labeling enabled (tdp)
  LSP Tunnel labeling not enabled
  MPLS operational
  IP to Tag Fast Feature Switching Vector
  MPLS turbo vector
  MTU = 1500, status=0x100043, appcount=1
  Output_feature_state=0x1

```

Related Commands

Command	Description
mpls ip (global configuration)	Enables MPLS forwarding of IPv4 packets along normally routed paths for the platform.
mpls ip (interface configuration)	Enables MPLS forwarding of IPv4 packets along normally routed paths for a particular interface.
mpls label protocol (global configuration)	Specifies the default label distribution protocol for a platform.
mpls label protocol (interface configuration)	Specifies the label distribution protocol to be used on a given interface.
mpls traffic-eng tunnels (global configuration)	Enables MPLS traffic engineering tunnel signaling on a device.
mpls traffic-eng tunnels (interface configuration)	Enables MPLS traffic engineering tunnel signaling on an interface.

show mpls ip binding

To display specified information about label bindings learned by the Multiprotocol Label Switching (MPLS) Label Distribution Protocol (LDP), use the show **show mpls ip binding** command in user EXEC or privileged EXEC mode.

```
show mpls ip binding [{vrf vrf-name | all}] [network {masklength} [longer-prefixes]] [{neighbor
address | local}] [local-label {atm vpi vci | label [- label]}] [remote-label {atm vpi vc I | label [-
label]}] [interface interface] [{generic | atm}]
show mpls ip binding [{vrf vrf-name | all}] [{detail | summary}]
```

Cisco 10000 Series Routers

```
show mpls ip binding [network {masklength} [longer-prefixes]] [{neighbor address | local}]
[local-label label [- label]] [remote-label label [- label]] [generic]
show mpls ip binding [{detail | summary}]
```

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the LDP neighbors for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance (<i>vrf-name</i>). Note This keyword and argument pair does not apply to the Cisco 10000 series routers.
all	(Optional) Displays binding information for all VRFs. Note This keyword does not apply to the Cisco 10000 series routers.
<i>network</i>	(Optional) Defines the destination network number.
<i>mask</i>	Defines the network mask, written as A.B.C.D.
<i>length</i>	Defines the mask length (1 to 32 characters).
longer-prefixes	(Optional) Selects any prefix that matches the <i>mask</i> with a <i>length</i> from 1 to 32 characters.
neighbor <i>address</i>	(Optional) Displays label bindings assigned by the selected neighbor.
local	(Optional) Displays the local label bindings.
local-label atm <i>vpi vci</i>	(Optional) Displays the entry with the locally assigned ATM label that matches the specified ATM label value. The virtual path identifier (VPI) range is 0 to 4095. The virtual channel identifier (VCI) range is 0 to 65535. Note These keywords and arguments do not apply to the Cisco 10000 series routers.
local-label <i>label-label</i>	(Optional) Displays entries with locally assigned labels that match the specified label values. Use the arguments and keyword to indicate the label range. The hyphen (-) keyword is required for a label range.

remote-label atm atm vpi vci	(Optional) Displays entries with remotely assigned ATM label values learned from neighbor routers that match the specified ATM label value. The VPI range is 0 to 4095. The VCI range is 0 to 65535. Note These keywords and arguments do not apply to the Cisco 10000 series routers.
remote-label label-label	(Optional) Displays entries with remotely assigned labels learned from neighbor routers that match the specified label values. Use the arguments to indicate the label range. The hyphen (-) keyword is required for a label range.
interface interface	(Optional) Displays label bindings associated with the specified interface (for label-controlled (LC)-ATM only). Note This keyword and argument pair does not apply to the Cisco 10000 series routers.
generic	(Optional) Displays only generic (non-LC-ATM) label bindings.
atm	(Optional) Displays only LC-ATM label bindings. Note This keyword does not apply to the Cisco 10000 series routers.
detail	(Optional) Displays detailed information about label bindings learned by LDP.
summary	(Optional) Displays summary information about label bindings learned by LDP.

Command Default

All label bindings are displayed when no optional arguments or keywords are specified.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0(10)ST	This command was introduced.
12.0(14)ST	This command was modified to reflect MPLS VPN support for LDP.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	The VPI range of values was extended to 4095.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.

Release	Modification
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(25)S	The detail keyword was added to display checkpoint status for local label bindings.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines

The **show mpls ip binding** command displays label bindings learned by LDP or the Tag Distribution Protocol (TDP).

**Note**

TDP is not supported for LDP features in Cisco IOS 12.0(30)S and later releases, 12.2(27)SBC and later 12.2S releases, and 12.3(14)T and later releases.

To summarize information about label bindings learned by LDP, use the **show mpls ip binding summary** command in user EXEC or privileged EXEC mode.

A request can specify that the entire database be displayed, that a summary of entries from the database be displayed, or that the display be limited to a subset of entries. The subset can be limited according to any of the following:

- Prefix
- Input or output label values or ranges
- Neighbor advertising the label
- Interface for label bindings of interest (LC-ATM only)

**Note**

LC-ATM label binding interface does not apply to the Cisco 10000 series routers.

- Generic (non-LC-ATM) label bindings
- LC-ATM label bindings

**Note**

LC-ATM label binding interface does not apply to the Cisco 10000 series routers.

Examples

The following is sample output from the **show mpls ip binding** command. The output shows all the label bindings in the database.

```
Router# show mpls ip binding

10.0.0.0/8
  in label:      20
  out label:     26      lsr: 10.0.0.55:0
  out vc label: 1/80      lsr: 10.0.7.7:2      ATM1/0.8
                    Active ingress 3 hops (vcd 49)

172.16.0.0/8
  in label:      25
  in vc label:   1/36      lsr: 10.0.7.7:2      ATM1/0.8
                    Active egress (vcd 55)
  out label:     imp-null lsr: 10.0.0.55:0      inuse

192.168.0.66/32
  in label:      26
  in vc label:   1/39      lsr: 10.0.7.7:2      ATM1/0.8
                    Active egress (vcd 58)
  out label:     16      lsr: 10.0.0.55:0      inuse

.
.
.
```

In the following example, a request is made for the display of the label binding information for prefix 192.168.44.0/24:

```
Router# show mpls ip binding 192.168.44.0 24
192.168.44.0/24
  in label:      24
  in vc label:   1/37      lsr: 10.0.7.7:2      ATM1/0.8
                    Active egress (vcd 56)
  out label:     imp-null lsr: 10.0.0.55:0      inuse
```

In the following example, the local-label keyword is used to request that label binding information be displayed for the prefix with local label 58:

```
Router# show mpls ip binding local-label 58
192.168.0.0/16
  in label:      58
  out label:     imp-null lsr: 10.0.0.55:0      inuse
```

The following sample output shows the label bindings for the VPN routing and forwarding instance named vpn1:

```
Router# show mpls ip binding vrf vpn1
10.3.0.0/16
  in label:      117
  out label:     imp-null lsr:10.14.14.14:0

10.13.13.13/32
  in label:      1372
  out label:     268      lsr:10.14.14.14:0

10.14.14.14/32
  in label:      118
  out label:     imp-null lsr:10.14.14.14:0

10.15.15.15/32
  in label:      1370
  out label:     266      lsr:10.14.14.14:0

10.16.16.16/32
  in label:      8370
```

show mpls ip binding

```

    out label: 319      lsr:10.14.14.14:0
10.18.18.18/32
    in label: 21817
    out label: 571      lsr:10.14.14.14:0
30.2.0.0/16
    in label: 6943
    out label: 267      lsr:10.14.14.14:0
10.30.3.0/16
    in label: 2383
    out label: imp-null lsr:10.14.14.14:0
10.30.4.0/16
    in label: 77
    out label: imp-null lsr:10.14.14.14:0
10.30.5.0/16
    in label: 20715
    out label: 504      lsr:10.14.14.14:0
10.30.7.0/16
    in label: 17
    out label: imp-null lsr:10.14.14.14:0
10.30.10.0/16
    in label: 5016
    out label: 269      lsr:10.14.14.14:0
10.30.13.0/16
    in label: 76
    out label: imp-null lsr:10.14.14.14:0

```

The following sample output shows label binding information for all VRFs:

```

Router# show mpls ip binding all

10.0.0.0/24
    in label:  imp-null
    out label: imp-null lsr: 10.131.0.1:0
10.11.0.0/24
    in label:  imp-null
    out label: imp-null lsr: 10.131.0.1:0
10.101.0.1/32
    out label: imp-null lsr: 10.131.0.1:0
10.131.0.1/32
    in label:  20
    out label: imp-null lsr: 10.131.0.1:0      inuse
10.134.0.1/32
    in label:  imp-null
    out label: 16      lsr: 10.131.0.1:0
VRF vrf1:
10.0.0.0/24
    out label: imp-null lsr: 10.132.0.1:0
10.11.0.0/24
    out label: imp-null lsr: 10.132.0.1:0
10.12.0.0/24
    in label:  17
    out label: imp-null lsr: 10.132.0.1:0
10.132.0.1/32
    out label: imp-null lsr: 10.132.0.1:0
10.134.0.2/32
    in label:  18
    out label: 16      lsr: 10.132.0.1:0
10.134.0.4/32
    in label:  19
    out label: 17      lsr: 10.132.0.1:0
10.138.0.1/32
    out label: imp-null lsr: 10.132.0.1:0

```

Cisco 10000 Series Examples

The following sample shows binding information for a Cisco 10000 series router:

```
Router# show mpls ip binding

0.0.0.0/0
  in label:    imp-null
10.29.0.0/16
  in label:    imp-null
  out label:   imp-null lsr: 10.66.66.66:0
  out label:   imp-null lsr: 10.44.44.44:0
10.20.0.0/24
  in label:    imp-null
  out label:   26      lsr: 10.66.66.66:0
  out label:   imp-null lsr: 10.44.44.44:0
10.30.0.0/24
  in label:    imp-null
  out label:   imp-null lsr: 10.66.66.66:0
  out label:   18      lsr: 10.44.44.44:0
10.44.44.44/32
  in label:    21
  out label:   19      lsr: 10.66.66.66:0
  in label:    imp-null
  out label:   26      lsr: 10.66.66.66:0
  out label:   imp-null lsr: 10.44.44.44:0
10.30.0.0/24
  in label:    imp-null
  out label:   imp-null lsr: 10.66.66.66:0
  out label:   18      lsr: 10.44.44.44:0
10.44.44.44/32
  in label:    21
  out label:   19      lsr: 10.66.66.66:0
  out label:   imp-null lsr: 10.44.44.44:0   inuse
10.55.55.55/32
  in label:    imp-null
  out label:   25      lsr: 10.66.66.66:0
  out label:   55      lsr: 10.44.44.44:0
10.66.66.66/32
  in label:    18
  out label:   imp-null lsr: 10.66.66.66:0   inuse
  out label:   16      lsr: 10.44.44.44:0
10.255.254.244/32
  in label:    24
  out label:   16      lsr: 10.66.66.66:0
  out label:   59      lsr: 10.44.44.44:0
```

In the following example on a Cisco 10000 series router, a request is made for the display of the label binding information for prefix 172.16.44.44/32:

```
Router# show mpls ip binding 172.16.44.44 32
172.16.44.44/32
  in label:    21
  out label:   19      lsr: 10.66.66.66:0
  out label:   imp-null lsr: 10.44.44.44:0   inuse
```

In the following example on a Cisco 10000 series router, the local-label keyword is used to request that label binding information be displayed for the prefix with local label 21:

```
Router# show mpls ip binding local-label 21
```

```

10.44.44.44/32
  in label:      21

```

The table below describes the significant fields shown in the displays.

Table 46: show mpls ip binding Field Descriptions

Field	Description
172.16.44.44/32	Destination prefix. Indicates that the following lines are for a particular destination (network/mask).
in label	Incoming label. This is the local label assigned by the label switch router (LSR) and advertised to other LSRs. The label value imp-null indicates the well-known Implicit NULL label.
out label	Outgoing label. This is a remote label learned from an LDP neighbor. The neighbor is identified by its LDP ID in the lsr field.
inuse	Indicates that the outgoing label is in use for Multiprotocol Label Switching (MPLS) forwarding, that is, it is installed in the MPLS forwarding table (the Label Forwarding Information Base [LFIB]).
in vc label	Incoming MPLS ATM label. This is the local VPI/VCI assigned by the LSR as the incoming label for the destination and advertised to the upstream LSRs. Note This field applies to the Cisco 7500 series routers only.
out vc label	Outgoing MPLS ATM label. This is the VPI/VCI learned from the destination next hop as its label for the destination and advertised to this LSR. Note This field applies to the Cisco 7500 series routers only.
ATM1/0.8	The ATM interface with which the MPLS ATM label is associated. Note This field applies to the Cisco 7500 series routers only.

Field	Description
Active	<p>State of the label VC (LVC) associated with the destination prefix.</p> <p>Note This field applies to the Cisco 7500 series routers only.</p> <p>States are the following:</p> <ul style="list-style-type: none"> • Active. Established and operational. • Bindwait. Waiting for a response from the destination next hop. • Remote Resource Wait. Waiting for resources (VPI/VCI) to become available on the destination next hop. • Parent Wait. Transit LVC upstream side waiting for downstream side to become active. • AbortAckWait. Waiting for response to a Label Abort message sent to the destination next hop. • ReleaseWait. Waiting for response to a Label Withdraw message sent to an upstream neighbor.
vcd 49	<p>Virtual circuit descriptor number for the LVC.</p> <p>Note This field applies to the Cisco 7500 series routers only.</p>
ingress 3 hops	<p>Indicates whether the LSR is an ingress, transit, or egress node for the destination.</p> <p>Note This field applies to the Cisco 7500 series routers only.</p> <p>Options include the following:</p> <ul style="list-style-type: none"> • Ingress 3 hops. The LSR is an ingress edge router for the MPLS ATM cloud for the destination. • Egress. The LSR is an egress edge router for the MPLS ATM cloud for the destination. • Transit. The LSR is a transit LSR within the MPLS ATM cloud for the destination.

The following sample output displays detailed information about the label bindings:

```
Router# show mpls ip binding detail
 10.0.0.0/8, rev 2, chkpt: add-skipped
   in label:   imp-null   (owner LDP)
   Advertised to:
     10.60.60.60:0      10.30.30.30:0
   out label:   imp-null   lsr: 10.60.60.60:0
   out label:   imp-null   lsr: 10.30.30.30:0
 10.10.10.10/32, rev 18, chkpt: added
   in label:    17        (owner LDP)
   Advertised to:
     10.60.60.60:0      10.30.30.30:0
   out label:   142       lsr: 10.60.60.60:0
   out label:   19        lsr: 10.30.30.30:0   inuse
 10.0.0.1/32, rev 10, chkpt: add-skipped
   in label:   imp-null   (owner LDP)
```

```

    Advertised to:
    10.60.60.60:0          10.30.30.30:0
    out label:   21          lsr: 10.60.60.60:0
    out label:   17          lsr: 10.30.30.30:0
10.30.30.30/32, rev 20, chkpt: added
    in label:    18          (owner LDP)
    Advertised to:
    10.60.60.60:0          10.30.30.30:0
    out label:   22          lsr: 10.60.60.60:0

```

The table below describes the significant fields shown in the display.

Table 47: show mpls ip binding detail Field Descriptions

Field	Description
chkpt	<p>The status of the checkpointed entry.</p> <ul style="list-style-type: none"> • add-skipped--Means that the local label is a null label and does not need to be checkpointed. • added-- Means that the checkpoints entry was copied to the backup Route Processor (RP)
owner	<p>The application that created the binding.</p> <ul style="list-style-type: none"> • owner LDP--Means that LDP created the binding. • owner other--Means that another application created the binding, possibly Border Gateway protocol (BGP).
Advertised to	The LSRs that received the local label binding.
inuse or stale	<p>The status of the label.</p> <ul style="list-style-type: none"> • inuse--Indicates that the outgoing label is in use for MPLS forwarding, that is, it is installed in the MPLS forwarding table (LFIB). • stale--Indicates a label that is no longer in use. This happens when an LDP session is lost and the routers begin a graceful restart. Then the remote label bindings are marked stale.

Cisco 7500 Series Example

The following sample output shows summary information about the label bindings learned by LDP:

```

Router# show mpls ip binding summary

Total number of prefixes: 53

Generic label bindings
      assigned      learned
prefixes  in labels  out labels
      53           53           51

ATM label bindings summary
interface  total  active  local  remote  Bwait  Rwait  IFwait

```



```

          ATM1/0.8      47      47      40      7      0      0      0
Router#

```

The table below describes the significant fields shown in the display.

Table 48: show mpls ip binding summary Field Descriptions (Cisco 7500 Series Example)

Field	Description
Total number of prefixes	Number of destinations for which the LSR has label bindings.
Generic label bindings	Indicates the start of summary information for “generic” label bindings. Generic labels are used for MPLS forwarding on all interface types except MPLS ATM interfaces.
prefixes	Number of destinations for which the LSR has a generic label binding.
assigned in labels	Number of prefixes for which the LSR has assigned an incoming (local) label.
learned out labels	Number of prefixes for which the LSR has learned an outgoing (remote) label from an LDP neighbor.
ATM label bindings summary	Indicates the start of summary information for MPLS ATM label bindings. An ATM label is a VPI/VCI.
interface	Indicates a row in the ATM label bindings summary table. The summary information in the row is for ATM labels associated with this interface.
total	Total number of ATM labels associated with the interface.
active	Number of ATM labels (LVCs) in the active (operational) state.
local	Number of ATM labels assigned by this LSR for the interfaces. These are incoming labels.
remote	Number of ATM labels learned from the neighbor LSR for this interface. These are outgoing labels.
Bwait	Number of bindings (LVCs) waiting for a label assignment from the neighbor LSR for the interface.
Rwait	Number of bindings (LVCs) waiting for resources (VPI/VCI) to become available on the neighbor LSR for the interface.
IFwait	Number of bindings (LVCs) waiting for labels to be installed for switching use.

Cisco 10000 Series Example

The following sample output displays summary information about the label bindings learned by LDP:

```
Router# show mpls ip binding summary
```

Total number of prefixes: 53

```
Generic label bindings
      prefixes      assigned      learned
                  in labels    out labels
                53          53          51
```

The table below describes the significant fields shown in the display.

Table 49: show mpls ip binding summary Field Descriptions (Cisco 10000 Series Example)

Field	Description
Total number of prefixes	Number of destinations for which the LSR has label bindings.
Generic label bindings	Indicates the start of summary information for “generic” label bindings. Generic labels are used for MPLS forwarding on all interface types except MPLS ATM interfaces.
prefixes	Number of destinations for which the LSR has a generic label binding.
assigned in labels	Number of prefixes for which the LSR has assigned an incoming (local) label.
learned out labels	Number of prefixes for which the LSR has learned an outgoing (remote) label from an LDP neighbor.

Related Commands

Command	Description
show mpls atm-ldp bindings	Displays specified entries from the ATM label binding database.
show mpls ldp bindings	Displays the contents of the LIB.

show mpls ip iprm counters

To display the number of occurrences of various Multiprotocol Label Switching (MPLS) IP Rewrite Manager (IPRM) events, use the `show mpls ip iprm counters` command in privileged EXEC mode.

show mpls ip iprm counters

Syntax Description This command has no arguments or keywords.

Command Default No default behaviors or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(25)S	This command was introduced.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
	12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.

Usage Guidelines This command reports the occurrences of IPRM events.

Examples The command in the following example displays the events that the IPRM logs:

```
Router# show mpls ip iprm counters
  CEF Tree Changes Processed/Ignored:      91/12
  CEF Deletes Processed/Ignored:           12/2
  Label Discoveries:                         74
  Rewrite Create Successes/Failures:        60/0
  Rewrite Gets/Deletes:                     82/0
  Label Announcements: Info/Local/Path:     6/119/80
  Walks: Recursion Tree/CEF Full/CEF interface: 78/2/0
```

The table below describes the significant fields shown in the display.

Table 50: show mpls ip iprm counters Command Field Descriptions

Field	Description
CEF Tree Changes Processed/Ignored	<p>Processed--The number of Cisco Express Forwarding tree change announcements that IPRM processed.</p> <p>Ignored--The number of Cisco Express Forwarding tree change announcements that IPRM ignored.</p> <p>Typically, IPRM processes tree change announcements only for prefixes in a routing table.</p>
CEF Deletes Processed/Ignored	<p>Processed--The number of Cisco Express Forwarding delete entry announcements that IPRM processed.</p> <p>Ignored--The number of Cisco Express Forwarding delete entry announcements that IPRM ignored.</p> <p>Typically, IPRM processes delete entry announcements only for prefixes in a routing table.</p>
Label Discoveries	The number of label discoveries performed by IPRM. Label discovery is the process by which IPRM obtains prefix labels from the IP Label Distribution Modules (LDMs).
Rewrite Create Successes/Failures	<p>Successes--The number of times IPRM successfully updated the MPLS forwarding information.</p> <p>Failures--The number of times IPRM attempted to update the MPLS forwarding information and failed.</p>
Rewrite Gets/Deletes	<p>Gets--The number of times IPRM retrieved forwarding information from the MPLS forwarding infrastructure.</p> <p>Deletes--The number of times IPRM removed prefix forwarding information from the MPLS forwarding infrastructure.</p>
Label Announcements: Info/Local/Path	<p>Info--The number of times an IP label distribution module informed IPRM that label information for a prefix changed.</p> <p>Local--The number of times an IP label distribution module specified local labels for a prefix.</p> <p>Path--The number of times an IP LDM specified outgoing labels for a prefix route.</p>
Walks: Recursion Tree/CEF Full/CEF interface	<p>Recursion Tree--The number of times IPRM requested Cisco Express Forwarding to walk the recursion (path) tree for a prefix.</p> <p>CEF Full--The number of times IPRM requested Cisco Express Forwarding to walk a Cisco Express Forwarding table and notify IPRM about each prefix.</p> <p>CEF interface--The number of times IPRM requested Cisco Express Forwarding to walk a Cisco Express Forwarding table and notify IPRM about each prefix with a path that uses a specific interface.</p>

Related Commands

Command	Description
clear mpls ip iprm counters	Clears the IPRM counters.
show mpls ip iprm ldm	Displays information about the IP LDMs that have registered with the IPRM.

show mpls ip iprm ldm

To display information about the IP Label Distribution Modules (LDMs) that have registered with the IP Rewrite Manager (IPRM), use the `show mpls ip iprm ldm` command in privileged EXEC mode.

```
show mpls ip iprm ldm [{table {all | table-id} | vrf vrf-name}] [{ipv4 | ipv6}]
```

Cisco 10000 Series Routers

```
show mpls ip iprm ldm [{table {all | table-id} | vrf vrf-name}] [ipv4]
```

Syntax Description

table	(Optional) Displays the LDMs for one or more routing tables.
all	Displays the LDMs for all routing tables.
<i>table-id</i>	Displays the LDMs for the routing table you specify. Table 0 is the default or global routing table.
vrf	(Optional) Displays the LDMs for the VPN routing and forwarding (VRF) instance you specify.
<i>vrf-name</i>	(Optional) The name of the VRF instance. You can find VRF names with the <code>show ip vrf</code> command.
ipv4	(Optional) Displays IPv4 LDMs.
ipv6	(Optional) Displays IPv6 LDMs. Note Applies to Cisco 7500 series routers only.

Command Default

If you do not specify any keywords or parameters, the command displays the LDMs for the global routing table (the default).

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)S	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SSH.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.

Usage Guidelines

This command displays the IP LDMs registered with IPRM.

Examples

The command in the following example displays the LDMs for the global routing tables. It shows that two LDMs (lcatm and ldp) are registered for the ipv4 global routing table, and that one LDM (bgp ipv6) is registered for the ipv6 global routing table.

```
Router# show mpls ip iprm ldm
  table (global;ipv4); ldms: 2
    lcatm, ldp
  table (global;ipv6); ldms: 1
    bgp ipv6
```

The command in the following example displays all of the LDMs registered with IPRM. The output shows the following:

- The LDMs called lcatm and ldp have registered with IPRM for the ipv4 global table.
- The LDM called bgp ipv6 is registered for the IPv6 global table.
- The LDM called bgp vpnv4 is registered for all IPv4 vrf routing tables.

```
Router# show mpls ip iprm ldm table all
  table (global;ipv4); ldms: 2
    lcatm, ldp
  table (global;ipv6); ldms: 1
    bgp ipv6
  table (all-tbls;ipv4); ldms: 1
    bgp vpnv4
```

The command in the following example displays the LDMs registered for the IPv6 routing tables.

```
Router# show mpls ip iprm ldm ipv6
  table (global;ipv6); ldms: 1
    bgp ipv6
```

Cisco 10000 Series Examples Only

The command in the following example displays the LDMs for the global routing tables. It shows that one LDM (ldp) is registered for the ipv4 global routing table.

```
Router# show mpls ip iprm ldm
  table (global;ipv4); ldms: 1
    ldp
```

The command in the following example displays all of the LDMs registered with IPRM. The output shows the following:

- The LDM called ldp has registered with IPRM for the ipv4 global table.
- The LDM called bgp vpnv4 is registered for all IPv4 vrf routing tables.

```
Router# show mpls ip iprm ldm table all
  table (global;ipv4); ldms: 1
    ldp
  table (all-tbls;ipv4); ldms: 1
    bgp vpnv4
```

Related Commands

Command	Description
show mpls ip iprm counters	Displays the number of occurrences of various IPRM events.

show mpls ip iprm statistics

To display information about the IP Rewrite Manager (IPRM) statistics, use the **show mpls ip iprm statistics** command in privileged EXEC mode.

show mpls ip iprm statistics

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(20)T	This command was introduced in a release earlier than Cisco IOS Release 12.4(20)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following is sample output from the **show mpls ip iprm statistics** command:

```
Router# show mpls ip iprm statistics
Chunk cache size: IPv4 pfx/path:      1/2
Chunk cache size: outinfo:           2
```

The table below describes the significant fields shown in the display.

Table 51: show mpls ip iprm statistics Field Descriptions

Field	Description
Chunk cache size	Displays the size of the cache.

Related Commands

Command	Description
show mpls ip iprm counters	Displays the number of occurrences of various MPLS IPRM events.

show mpls l2 vc detail

To display detailed information related to a virtual circuit (VC), use the **show mpls l2 vc detail** command in user EXEC or privileged EXEC mode.

show mpls l2 vc *vc-id* detail

Syntax Description

<i>vc-id</i>	Name of the VC.
--------------	-----------------

Command Default

This command displays detailed information related to a VC.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
12.2(33)SRA	This command was introduced.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRE	This command was modified. STANDBY and HOTSTANDBY were added as options for the Status column in output displays.
15.0(1)S	This command was integrated into Cisco IOS Release 15.(0)1S.
Cisco IOS XE Release 3.1S	This command was integrated into Cisco IOS XE Release 3.1S.

Examples

The following is sample output from the **show mpls l2 vc 1100 detail** command:

```
Device# show mpls l2 vc 1100 detail

Local interface: VFI VPLS-1100 up
MPLS VC type is VFI, internetworking type is Ethernet
Destination address: 1.1.1.1,VC ID:1100, VC status: up
Output interface: Tu0,imposed label stack {27 17}
Preferred path: not configured
Default path: active
Next hop:point2point
Create time:2d23h, last status change time: 2d23h
Signaling protocol: LDP, peer 1.1.1.1:0 up
MPLS VC labels: local 17, remote 17
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: on (configured: autosense)
VC statistics
packet totals: receive 1146978, send 3856011
byte totals: receive 86579172, send 316899920
packet drops: receive 0, send 0
```

The following examples show the status of the active and backup pseudowires before, during, and after a switchover.

The **show mpls l2 vc detail** command on the active PE device displays the status of the pseudowires.

```
Device# show mpls l2 vc detail
```

```
Local intf      Local circuit          Dest address      VC ID      Status
-----
AT0/2/0.1      ATM VPC CELL 50       10.1.1.2         100        UP
AT0/2/0.1      ATM VPC CELL 50       10.1.1.3         100        STANDBY
```

The **show mpls l2 vc detail** command on the backup PE device displays the status of the pseudowires. The active pseudowire on the backup PE device has the HOTSTANDBY status.

```
Device-standby# show mpls l2 vc detail
```

```
Local intf      Local circuit          Dest address      VC ID      Status
-----
AT0/2/0.1      ATM VPC CELL 50       10.1.1.2         100        HOTSTANDBY
AT0/2/0.1      ATM VPC CELL 50       10.1.1.3         100        DOWN
```

During a switchover, the status of the active and backup pseudowires changes:

```
Device# show mpls l2 vc detail
```

```
Local intf      Local circuit          Dest address      VC ID      Status
-----
AT0/2/0.1      ATM VPC CELL 50       10.1.1.2         100        RECOVERING
AT0/2/0.1      ATM VPC CELL 50       10.1.1.3         100        DOWN
```

After the switchover is complete, the recovering pseudowire shows a status of UP:

```
Device# show mpls l2 vc detail
```

```
Local intf      Local circuit          Dest address      VC ID      Status
-----
AT0/2/0.1      ATM VPC CELL 50       10.1.1.2         100        UP
AT0/2/0.1      ATM VPC CELL 50       10.1.1.3         100        STANDBY
```

Related Commands

Command	Description
show xconnect	Displays information about xconnect attachment circuits and pseudowires.

show mpls l2transport binding

To display virtual circuit (VC) label binding information, use the **show mpls l2transport binding** command in privileged EXEC mode.

show mpls l2transport binding [*vc-idip-address* | **local-label** *number* | **remote-label** *number*]

Syntax Description

<i>vc-id</i>	(Optional) Displays VC label binding information for the specified VC.
<i>ip-address</i>	(Optional) Displays VC label binding information for the specified VC destination.
local-label <i>number</i>	(Optional) Displays VC label binding information for the specified local assigned label.
remote-label <i>number</i>	(Optional) Displays VC label binding information for the specified remote assigned label.

Command Modes

EXEC and Privileged EXEC (#)

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.0(27)S	This command was updated to display AToM Virtual Circuit Connection Verification (VCCV) information.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.2(30)S	This command was updated to display Connectivity Verification (CV) type capabilities.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was updated to display Circuit Emulation (CEM) information for the Cisco 7600 series router.
Cisco IOS XE Release 2.3	The command was updated to display information about multisegment pseudowires.
12.2(1)SRE	This command was modified to display VC label binding information for the control word.
12.2(33)SCC	This command was integrated into Cisco IOS Release 12.2(33)SCC.
15.0(1)S	This command was integrated into Cisco IOS Release 15.0(1)S. The display was updated to show VC label binding information for the control word.

Release	Modification
Cisco IOS XE Release 3.1S	This command was modified. The display was updated to show VC label binding information for the control word.
15.1(2)SNG	This command was integrated into Cisco ASR 901 Series Aggregation Services Routers.

Examples

The following example shows the VC label binding information for Cisco IOS Releases 12.0(27)S and 12.2(18)SXE and later releases:

```
Router# show mpls l2transport binding
Destination Address: 10.0.0.203, VC ID: 1
  Local Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV Capabilities: Type 1, Type 2
  Remote Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV Capabilities: Type 1, Type 2
```

The following example shows the VC label binding information for Cisco IOS Release 12.2(30)S and later releases:

```
Router# show mpls l2transport binding
Destination Address: 10.5.5.51, VC ID: 108
  Local Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV: CC Type: CW [1], RA [2]
           CV Type: LSPV [2]
  Remote Label: 16
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
    VCCV: CC Type: RA [2]
           CV Type: LSPV [2]
```

The output of the command changed between Cisco IOS releases. The following table maps the older output to the new output:

Output in Cisco IOS Releases 12.0(27)S and 12.2(18)SXE	Output In Cisco IOS Release 12.2(30)S
VCCV Capabilities	VCCV: CC Type
Type 1	CW [1]
Type 2	RA [2]

The following sample output from the **show mpls l2transport binding** command shows the VC label binding information on a Cisco uBR10012 router:

```
Router# show mpls l2transport binding
Destination Address: 10.76.1.1, VC ID: 2002
  Local Label: 42
    Cbit: 1, VC Type: Ethernet, GroupID: 0
    MTU: 1500, Interface Desc: n/a
```

```

      VCCV: CC Type: CW [1], RA [2]
          CV Type: LSPV [2]
Remote Label: 60
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]
Destination Address: 10.76.1.1, VC ID: 2003
Local Label: 46
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: CW [1], RA [2]
          CV Type: LSPV [2]
Remote Label: 27
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]
Destination Address: 10.76.1.1, VC ID: 2004
Local Label: unassigned.
Remote Label: 111
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]
Destination Address: 10.76.1.1, VC ID: 2017
Local Label: 43
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: CW [1], RA [2]
          CV Type: LSPV [2]
Remote Label: 110
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]
Destination Address: 10.76.1.1, VC ID: 2018
Local Label: 45
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: CW [1], RA [2]
          CV Type: LSPV [2]
Remote Label: 88
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]
Destination Address: 10.76.1.1, VC ID: 2019
Local Label: 44
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: CW [1], RA [2]
          CV Type: LSPV [2]
Remote Label: 16
      Cbit: 1,      VC Type: Ethernet,      GroupID: 0
      MTU: 1500,   Interface Desc: n/a
      VCCV: CC Type: RA [2]
          CV Type: LSPV [2]

```

The table below describes the significant fields shown in the display.

Table 52: show mpls l2transport binding Field Descriptions

Field	Description
Destination Address	The IP address of the remote router's interface that is at the other end of the VC.
VC ID	The virtual circuit identifier assigned to one of the interfaces on the router.
Local Label	The VC label that a router signals to its peer router, which is used by the peer router during imposition.
Remote Label	The disposition VC label of the remote peer router.
Cbit	The control word bit. If it is set, the value is 1.
VC Type	The type of VC, such as Frame Relay, Ethernet, and ATM.
GroupID	The group ID assigned to the local or remote VCs.
MTU	The maximum transmission unit assigned.
Interface Desc	Interface parameters, if applicable.
VCCV Capabilities	(Cisco IOS Releases 12.0(27)S and 12.2(18)SXE and later releases) AToM VCCV information. This field displays how an AToM VCCV packet is identified. <ul style="list-style-type: none"> • Type 1--The Protocol ID field of the AToM Control Word (CW) is identified in the AToM VCCV packet. • Type 2--An MPLS Router Alert (RA) Level above the VC label in identified in the AToM VCCV packet. Type 2 is used for VC types that do not support or do not interpret the AToM Control Word.
VCCV: CC Type	(Cisco IOS Releases 12.2(30)S and later releases) The types of Control Channel (CC) processing that are supported. The number indicates the position of the bit that was set in the received octet. The following values can be displayed: <ul style="list-style-type: none"> • CW [1]--Control Word • RA [2]--Router Alert • TTL [3]--Time to Live • Unkn [x]--Unknown

Field	Description
CV Type	<p>(Cisco IOS Releases 12.2(30)S and later releases) The type of Connectivity Verification (CV) packets that can be processed in the control channel of the MPLS pseudowire. The number indicates the position of the bit that was set in the received octet.</p> <ul style="list-style-type: none"> • ICMP [1]--Internet Control Management Protocol (ICMP) is used to verify connectivity. • LSPV [2]--LSP Ping is used to verify connectivity. • BFD [3]--Bidirectional Forwarding Detection is used to verify connectivity for more than one pseudowire. • Unkn [x]--A CV type was received that could not be interpreted.

The following sample output shows information about L2VPN multisegment pseudowires (in bold):

```
Router# show mpls l2transport binding
Destination Address: 10.1.1.1, VC ID: 102
Local Label: 17
  Cbit: 1, VC Type: Ethernet, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: CW [1], RA [2], TTL [3]
  CV Type: LSPV [2]
Remote Label: 16
  Cbit: 1, VC Type: Ethernet, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: CW [1], RA [2], TTL [3]
  CV Type: LSPV [2]
PW Switching Point:
  Vcid  local IP addr  remote IP addr  Description
101    10.11.11.11      10.20.20.20    PW Switching Point PE3
      100             10.20.20.20    10.11.11.11    PW Switching Point PE2
```

The table below describes the significant fields shown in the display.

Table 53: show mpls l2transport binding Field Descriptions for Multisegment Pseudowires

Field	Description
TTL	The Time to Live (TTL) setting of the label.
Vcid	The virtual circuit identifier.
local IP addr	The local IP address assigned to the switching point.
remote IP addr	The remote IP address assigned to the switching point.
Description	The description assigned to the switching point.

CEM circuits are supported on the Cisco 7600 series router transport time-division multiplexing (TDM) traffic. The following sample output displays AToM VCs and the applicable local and remote CEM settings as exchanged over LDP label mapping messages.

Router# show mpls l2transport binding


```

Destination Address: 10.7.1.1, VC ID: 100
Local Label: 18
  Cbit: 1, VC Type: CESoPSN BRI, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: RA [2]
        CV Type: LSPV [2]
CEM/TDM Options
  Payload Bytes: 80, Payload Type: 0
  SP bits: 11 - Data/Signaling, CAS Type: CAS T1 SF
  RTP header in use: Yes, Bitrate (Kbit/s): 64
  Differential Timestamp Mode: disabled
  Clock Frequency (kHz): 64
  Synchronization Source id: 0
Remote Label: 19
  Cbit: 1, VC Type: CESoPSN BRI, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: RA [2]
        CV Type: LSPV [2]
CEM/TDM Options
  Payload Bytes: 80, Payload Type: 0
  SP bits: 11 - Data/Signaling, CAS Type: CAS T1 SF
  RTP header in use: Yes, Bitrate (Kbit/s): 64
  Differential Timestamp Mode: disabled
  Clock Frequency (kHz): 64
  Synchronization Source id: 0

```

The following sample output shows the VC label binding information for the control word, which in this case is set to 0, meaning that it is disabled:

```

Router# show mpls l2transport binding 102
Destination Address: 10.1.1.3, VC ID: 102
Local Label: 1004
  Cbit: 0, VC Type: Ethernet, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: CW [1], RA [2]
        CV Type: LSPV [2]
Remote Label: 1005
  Cbit: 0, VC Type: Ethernet, GroupID: 0
  MTU: 1500, Interface Desc: n/a
  VCCV: CC Type: RA [2]
        CV Type: LSPV [2]

```

The following sample output shows the maximum number of cells that can be packed (in bold) for both provider edge routers, as specified by the **cell-packing** command:

```

Router# show mpls l2transport binding 1010
Destination Address: 10.6.1.2, VC ID: 1010
Local Label: 20008
  Cbit: 1, VC Type: ATM VCC CELL, GroupID: 0
  MTU: n/a, Interface Desc: n/a
  Max Concatenated ATM Cells: 10
  VCCV: CC Type: CW [1], RA [2]
        CV Type: LSPV [2], BFD [3]
Remote Label: 47
  Cbit: 1, VC Type: ATM VCC CELL, GroupID: 0
  MTU: n/a, Interface Desc: n/a
  Max Concatenated ATM Cells: 10
  VCCV: CC Type: CW [1], RA [2]
        CV Type: LSPV [2]

```

Related Commands

Command	Description
cell-packing	Enables ATM over MPLS or L2TPv3 to pack multiple ATM cells into each MPLS or L2TPv3 packet.
show mpls l2transport hw-capability	Displays the transport types and their supported capabilities.
show mpls l2transport vc	Displays information about AToM VCs and static pseudowires that have been enabled to route Layer 2 packets on a router.

show mpls l2transport checkpoint

To display checkpointing information about Any Transport over MPLS (AToM) virtual circuits (VCs), use the **show mpls l2transport checkpoint** command in privileged EXEC mode.

show mpls l2transport checkpoint

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(25)S	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SRC	This command was integrated into Cisco IOS Release 12.2(33)SRC.
12.2(33)SCC	This command was integrated into Cisco IOS Release 12.2(33)SCC.

Examples

The output of the commands varies, depending on whether the output reflects the active or standby Route Processor (RP).

On the active RP, the command displays the following output:

```
Router# show mpls l2transport checkpoint
AToM Checkpoint info for active RP
Checkpointing is allowed
Bulk-sync checkpointed state for 1 VC
```

On the standby RP, the command displays the following output:

```
Router# show mpls l2transport checkpoint
AToM HA Checkpoint info for standby RP
1 checkpoint information block in use
```

In general, the output on the active RP shows that checkpointing information was sent to the backup RP. The output on the backup RP shows that checkpointing information was received from the active RP.

Related Commands

Command	Description
show mpls l2transport vc	Displays information about the checkpointed data when checkpointing is enabled.

show mpls l2transport hw-capability

To display the transport types supported on an interface, use the **show mpls l2transport hw-capability** command in privileged EXEC mode.

show mpls l2transport hw-capability interface *type number*

Syntax Description

interface	Displays information for the specified interface.
<i>type number</i>	Type and number of the interface. For example, serial6/0.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.0(27)S	This command was updated to display AToM Virtual Circuit Connection Verification (VCCV) information.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.2(30)S	This command was updated to display VCCV type capabilities.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SCC	This command was integrated into Cisco IOS Release 12.2(33)SCC.

Usage Guidelines

This command can help you determine the interface to use for the various transport types. Use this command to check if core-facing and edge-facing interfaces can accommodate different transport types.

Examples

The following is partial sample output of the **show mpls l2transport hw-capability** command for Cisco IOS Releases 12.0(23)S, 12.2(14)S, and 12.2(15)T and later. For more information on the fields, see the table below.

```
Router# show mpls l2transport hw-capability interface serial5/1

Interface Serial5/1
Transport type FR DLCI
Core functionality:
  MPLS label disposition supported
  Control word processing supported
  Sequence number processing not supported
Edge functionality:
  MPLS label imposition supported
  Control word processing supported
```

```
Sequence number processing not supported
```

```
.  
.  
.
```



Note These examples show only a portion of the output. The command displays the capabilities of every transport type.

The following is partial sample output of the **show mpls l2transport hw-capability** command for Cisco IOS Releases 12.0(27)S and 12.2(18)SXE and later releases. This output shows VCCV data under the Core Functionality section. Type 1 means that the AToM Control Word identified the AToM VCCV packet. For more information on the fields, see the table below.

```
Transport type FR DLCI
Core functionality:
  MPLS label disposition supported
  Control word processing supported
  Sequence number processing not supported
  VCCV CC Type 1 processing supported
Edge functionality:
  MPLS label imposition supported
  Control word processing supported
  Sequence number processing not supported
```

The following is partial sample output of the **show mpls l2transport hw-capability** command for Cisco IOS Releases 12.2(30)S and later releases. The VCCV output shows that AToM Control Word (CW) identified the AToM VCCV packet. For more information on the fields, see the table below.

```
Transport type FR DLCI
Core functionality:
  MPLS label disposition supported
  Control word processing supported
  Sequence number processing not supported
  VCCV CC Type CW [1] processing supported
Edge functionality:
  MPLS label imposition supported
  Control word processing supported
  Sequence number processing not supported
```

The following is a sample output of the **show mpls l2transport hw-capability** command that displays the transport types supported on the Gigabit Ethernet interface 3/0/0 on a Cisco uBR10012 router:

```
Router# show mpls l2transport hw-capability interface gigabitethernet 3/0/0
Interface GigabitEthernet3/0/0
Transport type DOCSIS
Core functionality:
  MPLS label disposition supported
  Control word processing supported
  Sequence number processing not supported
  VCCV CC Type CW [1] processing not supported
Edge functionality:
  Not supported
Transport type DOCSIS VLAN
Core functionality:
```

```

MPLS label disposition supported
Control word processing supported
Sequence number processing not supported
VCCV CC Type CW [1] processing not supported
Edge functionality:
Not supported

```

The output of the command changed between Cisco IOS releases. The following table maps the older output to the newer output:

Output in Cisco IOS Releases 12.0(27)S and 12.2(18)SXE and later	Output In Cisco IOS Release 12.2(30)S
VCCV CC processing supported	VCCV CC processing supported
Type 1	Type CW [1]

The table below describes the fields shown in the **show mpls l2transport hw-capability** command display.

Table 54: show mpls l2transport hw-capability Field Descriptions

Field	Description
Transport type	Indicates the transport type.
Core functionality	Displays the functionalities that the core-facing interfaces support, such as label disposition, and control word and sequence number processing.
VCCV CC Type processing supported	Displays whether the core-facing interfaces support Control Word processing, or Router Alert Processing. (Cisco IOS Releases 12.0(27)S and 12.2(18)SXE and later) <ul style="list-style-type: none"> • Type 1--The Protocol ID field of in the AToM Control Word (CW) identified the AToM VCCV packet. (Cisco IOS Releases 12.2(30)S and later) <ul style="list-style-type: none"> • CW [1]--Control Word • Unkn [x]--Unknown. The number indicates the position of the bit that was set in the received octet.
Edge functionality	Displays the functionalities that the edge-facing interfaces support, such as label disposition, and control word and sequence number processing.

Related Commands

Command	Description
show mpls l2transport binding	Displays virtual circuit (VC) label binding information.
show mpls l2transport checkpoint	Displays the checkpoint information about Any Transport over MPLS (AToM) virtual circuits.
show mpls l2transport summary	Displays summary information about virtual circuits.

Command	Description
show mpls l2transport vc	Displays information about AToM virtual circuits and static pseudowires that have been enabled to route Layer 2 packets on a router.

show mpls l2transport static-oam

To display the status of Multiprotocol Label Switching (MPLS) Transport Profile (TP) static pseudowires, use the **show mpls l2transport static-oam** command in privileged EXEC mode.

show mpls l2transport static-oam [**fault** [{**inbound** | **outbound**}]] [*ip-address* *vc-id*]

Syntax Description

fault	Displays faults related to static pseudowires.
inbound	Displays faults related to inbound static pseudowires.
outbound	Displays faults related to outbound static pseudowires.
<i>ip-address</i>	Displays information related to the static pseudowire with the specified peer IP address.
<i>vc-id</i>	Displays information related to the static pseudowire with the specified virtual circuit (VC) ID.

Command Default

Status messages are not displayed.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.1(1)SA	This command was introduced.
15.1(3)S	This command was integrated.

Usage Guidelines

This command is for MPLS-TP static pseudowires.

Examples

The following example enables the display of status messages for the static pseudowire with the peer IP address of 10.10.10.10 and the VC ID of 4:

```
Router# show mpls l2transport static-oam 10.10.10.10 4
```

Related Commands

Command	Description
debug mpls l2transport static-oam	Enables the display of messages related to static pseudowire operations administrative and management (OAM).

show mpls l2transport summary

To display summary information about virtual circuits (VCs) that have been enabled to route Any Transport over MPLS (AToM) Layer 2 packets on a router, use the **show mpls l2transport summary** command in privileged EXEC mode.

show mpls l2transport summary

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(23)S	This command was introduced.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SCC	This command was integrated into Cisco IOS Release 12.2(33)SCC.

Examples

The following is a sample output of the **show mpls l2transport summary** command that shows summary information about the VCs that have been enabled to transport Layer 2 packets:

```
Router# show mpls l2transport summary
Destination address: 10.16.24.12 Total number of VCs: 60
0 unknown, 58 up, 0 down, 2 admin down
5 active vc on MPLS interface PO4/0
```

The following is a sample output of the **show mpls l2transport summary** command that shows summary information about the VCs that have been enabled to transport Layer 2 packets on a Cisco uBR10012 router:

```
Router# show mpls l2transport summary
Destination address: 10.76.1.1, total number of vc: 6
 0 unknown, 5 up, 1 down, 0 admin down, 0 recovering, 0 standby
 5 active vc on MPLS interface Gi3/0/0
```

The table below describes the fields shown in the **show mpls l2transport summary** command display.

Table 55: show mpls l2transport summary Field Descriptions

Field	Description
Destination address	IP address of the remote router to which the VC has been established.
Total number of VCs	Number of VCs that have been established.
unknown	Number of VCs that are in an unknown state.
up	Number of VCs that are operational.
down	Number of VCs that are not operational.
admin down	Number of VCs that have been disabled.

Related Commands

Command	Description
show mpls l2transport binding	Displays virtual circuit (VC) label binding information.
show mpls l2transport checkpoint	Displays the checkpoint information about Any Transport over MPLS (AToM) virtual circuits.
show mpls l2transport hw-capability	Displays the transport types and their supported capabilities.
show mpls l2transport vc	Displays information about AToM VCs that have been enabled to route Layer 2 packets on a router.

show mpls l2transport vc

To display information about Any Transport over MPLS (AToM) virtual circuits (VCs) and static pseudowires that have been enabled to route Layer 2 packets on a router, use the **show mpls l2transport vc** command in user EXEC or privileged EXEC mode.

```
show mpls l2transport vc [[vcid] vc-id-min] [vc-id-max] [interface type number [local-circuit-id]]
[destination {ip-addresshostname}] [detail] [pwid pw-identifier] [vpls-id vpls-identifier] [stitch
endpoint endpoint]
```

Syntax Description

vcid	(Optional) Specifies the VC ID.
<i>vc-id-min</i>	(Optional) Minimum VC ID value. The range is 1 to 4294967295.
<i>vc-id-max</i>	(Optional) Maximum VC ID value. The range is 1 to 4294967295.
interface	(Optional) Specifies the interface or subinterface of the router that has been enabled to transport Layer 2 packets. Use this keyword to display information about the VCs that have been assigned VC IDs on that interface or subinterface.
<i>type</i>	(Optional) Interface type. For more information about the interface type, use the question mark (?) online help function.
<i>number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
<i>local-circuit-id</i>	(Optional) The number assigned to the local circuit. This argument value is supported only with the following transport types: <ul style="list-style-type: none"> • For Frame Relay, enter the data-link connection identifier (DLCI) of the permanent virtual circuit (PVC). • For ATM adaptation layer 5 (AAL5) and cell relay, enter the virtual path identifier (VPI) or virtual channel identifier (VCI) of the PVC. • For Ethernet VLANs, enter the VLAN number.
destination	(Optional) Specifies the remote router.
<i>ip-address</i>	(Optional) The IP address of the remote router.
<i>hostname</i>	(Optional) The name assigned to the remote router.
detail	(Optional) Specifies detailed information about VCs.
pwid <i>pw-identifier</i>	(Optional) Specifies the number of a pseudowire for a single VC. Valid entries are from 1 to 4294967295.
vpls-id <i>vpls-identifier</i>	(Optional) Virtual Private LAN Switching (VPLS) ID extended community value.

stitch <i>endpoint endpoint</i>	(Optional) Specifies dynamically stitched pseudowires between specified endpoints. The endpoints are the Source Attachment Individual Identifier (SAII) and the Target Attachment Individual Identifier (TAII). When the stitch keyword is used with the vpls-id keyword, a single pair of stitched VCs is displayed.
--	---

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.1(8a)E	This command was introduced.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S and implemented on the Cisco 10720 router.
12.0(23)S	This command was modified. The interface and destination keywords were added.
12.2(14)SX	This command was integrated into Cisco IOS Release 12.2(14)SX and was implemented on the Supervisor Engine 720.
12.2(14)SZ	This command was integrated into Cisco IOS Release 12.2(14)SZ.
12.2(15)T	This command was integrated into Cisco IOS Release 12.2(15)T.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and was implemented on the Cisco 10000 series routers. The example output was changed for the Cisco 10000 series router, and two fields (SSO Descriptor and SSM segment/switch IDs) were removed from the output.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was modified. This command was updated to include forwarding equivalence class (FEC) 129 signaling information for pseudowires configured through VPLS Autodiscovery, and to support provisioning Any Transport over MPLS (AToM) static pseudowires.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SRC	This command was modified. This command was updated to display the number of MAC address withdrawal messages sent and received as part of the H-VPLS N-PE Redundancy for QinQ and MPLS Access feature. This command was updated to display pseudowire status between peer routers that have been configured for the MPLS Pseudowire Status Signaling feature.
Cisco IOS XE Release 2.1	This command was implemented on the Cisco ASR 1000 Series Aggregation Services Routers.

Release	Modification
Cisco IOS XE Release 2.3	This command was modified. This command output was updated to display the following information: <ul style="list-style-type: none"> • The status of pseudowires before, during, and after a switchover. • The status of a pseudowire switching point for multisegment pseudowires. • The number of packets and bytes being sent from the router. The VC statistics fields include the word “transit” to show that the packet totals no longer include packets being sent to the router.
12.2(33)SCC	This command was integrated into Cisco IOS Release 12.2(33)SCC.
12.2(33)SXI4	This command was modified. The command output was updated to display information about load balancing and the imposition and disposition of flow labels for the L2VPN Advanced VPLS feature.
15.0(1)S	This command was modified. The command output was updated to display information about Bidirectional Forwarding Detection (BFD).
15.1(1)S	<ul style="list-style-type: none"> • This command was modified. Support for the L2VPN VPLS Inter-AS Option B feature was provided, and the pwid, stitch, and vpls-id keywords were added. • The command output was updated to display information about remote AC failures and when Virtual Circuit Connectivity Verification (VCCV) BFD status signaling is enabled.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
15.1(1)SY	This command was integrated into Cisco IOS Release 15.1(1)SY.
15.1(2)SNG	This command was integrated into Cisco ASR 901 Series Aggregation Services Routers.

Usage Guidelines

If you do not specify any keywords or arguments, the command displays a summary of all the VCs.

Examples

The output of the commands varies, depending on the type of Layer 2 packets being transported over ATM VCs.

The following sample output shows information about interfaces and VCs that have been configured to transport various Layer 2 packets on the router:

```
Router# show mpls l2transport vc
```

```

Local intf      Local circuit    Dest address     VC ID           Status
-----
Se5/0          FR DLCI 55      10.0.0.1        55              UP
AT4/0          ATM AAL5 0/100  10.0.0.1        100             UP
AT4/0          ATM AAL5 0/200  10.0.0.1        200             UP
AT4/0.300      ATM AAL5 0/300  10.0.0.1        300             UP

```

The table below describes the fields shown in the display.

Table 56: show mpls l2transport vc Field Descriptions

Field	Description
Local intf	Interface on the local router that has been enabled to transport Layer 2 packets.
Local circuit	Type and number (if applicable) of the local circuit. The output shown in this column varies, depending on the transport type: <ul style="list-style-type: none"> • For Frame Relay, the output shows the DLCI of the PVC. • For ATM cell relay and AAL5, the output shows the VPI or VCI of the PVC. • For Ethernet VLANs, the output shows the VLAN number. • For PPP and High-Level Data Link Control (HDLC), the output shows the interface number.
Dest address	IP address of the remote router's interface that is the other end of the VC.
VC ID	Virtual circuit identifier assigned to one of the interfaces on the router.
Status	Status of the VC, which can be one of the following: <ul style="list-style-type: none"> • Admin down—The VC was disabled by a user. • Down--The VC is not ready to carry traffic between the two VC endpoints. Use the detail keyword to determine the reason that the VC is down. • Hotstandby—The active pseudowire on a standby Route Processor (RP). • Recovering—The VC is recovering from a stateful switchover. • Standby—The VC is designated as the backup circuit in a stateful switchover configuration. • Up—The VC can carry traffic between the two VC endpoints. A VC is up when both imposition and disposition interfaces are programmed. <ul style="list-style-type: none"> • The disposition interface is programmed if the VC has been configured and the client interface is up. • The imposition interface is programmed if the disposition interface is programmed and you have a remote VC label and an Interior Gateway Protocol (IGP) label. The IGP label can be implicit null in a back-to-back configuration. An IGP label means there is a label switched path (LSP) to the peer.

The following sample output shows information about the nonstop forwarding (NSF), stateful switchover (SSO), and graceful restart capabilities on the AToM VC. The SSO portion indicates whether checkpoint data has been sent (on active) or received (on standby). When SSO data has not been successfully sent or has been released, the SSO information is not displayed.

```
Router# show mpls l2transport vc detail
Local interface: Fa5/1/1.2 down, line protocol down, Eth VLAN 2 up
Destination address: 10.55.55.2, VC ID: 1002, VC status: down
```

```

Output interface: Se4/0/3, imposed label stack {16}
Preferred path: not configured
Default path: active
Tunnel label: imp-null, next hop point2point
Create time: 02:03:29, last status change time: 02:03:26
Signaling protocol: LDP, peer 10.55.55.2:0 down
MPLS VC labels: local 16, remote unassigned
Group ID: local 0, remote unknown
MTU: local 1500, remote unknown
Remote interface description:
Sequencing: receive disabled, send disabled
SSO Descriptor: 10.55.55.2/1002, local label: 16
SSM segment/switch IDs: 12290/8193, PWID: 8193
VC statistics:
packet totals: receive 0, send 0
byte totals:   receive 0, send 0
packet drops:  receive 0, send 0

```

The table above and the tables below describe the fields shown in the display.

The following sample output shows the information that is displayed when an AToM static pseudowire has been provisioned and the **show mpls l2transport vc detail** command is used to check the configuration. The Signaling protocol field specifies Manual because a directed control protocol such as Label Distribution Protocol (LDP) cannot be used to exchange parameters on static pseudowires. The remote interface description field seen for nonstatic pseudowire configurations is not displayed because remote information is exchanged using signaling between the Provider Edge (PE) routers and this is not done on static pseudowires.

```

Router# show mpls l2transport vc detail
Local interface: Et1/0 up, line protocol up, Ethernet up
Destination address: 10.1.1.2, VC ID: 100, VC status: up
Output interface: Et2/0, imposed label stack {10003 150}
Preferred path: not configured
Default path: active
Next hop: 10.0.0.2
Create time: 00:18:57, last status change time: 00:16:10
Signaling protocol: Manual
MPLS VC labels: local 100, remote 150
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
VC statistics:
packet totals: receive 219, send 220
byte totals:   receive 20896, send 26694
packet drops:  receive 0, send 0

```

The table above and the tables below describe the fields shown in the display.

The following sample output shows VC statistics, including the number of packets and bytes being sent from the router. The VC statistics fields include the word “transit” to indicate that the packet totals no longer include packets being sent to the router.

```

Router# show mpls l2transport vc detail
Local interface: Et1/0 up, line protocol up, Ethernet up
.
.
.
VC statistics:
transit packet totals: receive 219, send 220

```

```
transit byte totals:  receive 20896, send 26694
transit packet drops: receive 0, send 0
```

The table below describes the significant fields shown in the display.

Table 57: show mpls l2transport vc detail Field Descriptions

Field	Description
Local interface	Interface on the local router that has been enabled to send and receive Layer 2 packets. The interface varies, depending on the transport type. The output also shows the status of the interface.
line protocol	Status of the line protocol on the edge-facing interface.
Destination address	IP address of the remote router specified for this VC. Specify the destination IP address as part of the mpls l2transport route command.
VC ID	Virtual circuit identifier assigned to the interface on the router.
VC status	Status of the VC, which can be one of the following: <ul style="list-style-type: none"> • Admin down—The VC was disabled by a user. • Down—The VC is not ready to carry traffic between the two VC endpoints. • up—The VC is in a state where it can carry traffic between the two VC endpoints. A VC is up when both imposition and disposition interfaces are enabled. <ul style="list-style-type: none"> • The disposition interface is enabled if the VC has been configured and the client interface is up. • The imposition interface is enabled if the disposition interface is enabled and a remote VC label and an IGP label exist. The IGP label can be an implicit null in a back-to-back configuration. (An IGP label means there is an LSP to the peer.)
Output interface	Interface on the remote router that has been enabled to transmit and receive Layer 2 packets.
imposed label stack	Summary of the Multiprotocol Label Switching (MPLS) label stack used to direct the VC to the PE router.
Preferred path	Path that was assigned to the VC and the status of that path. The path can be an MPLS traffic engineering tunnel or an IP address or hostname of a peer PE router.
Default path	Status of the default path, which can be disabled or active. By default, if the preferred path fails, the router uses the default path. However, you can disable the router from using the default path when the preferred path fails by specifying the disable-fallback keyword with the preferred-path command.

Field	Description
Tunnel label	<p>IGP label used to route the packet over the MPLS backbone to the destination router. The first part of the output displays the type of label. The second part of the output displays the route information.</p> <p>The tunnel label information can display any of the following states:</p> <ul style="list-style-type: none"> • imp-null: Implicit null means that the provider (P) router is absent and the tunnel label will not be used. Alternatively, imp-null can signify traffic engineering tunnels between the PE routers. • no adjacency: The adjacency for the next hop is missing. • no route: The label is not in the routing table. • not ready, Cisco Express Forwarding disabled: Cisco Express Forwarding is disabled. • not ready, LFIB disabled: The MPLS switching subsystem is disabled. • not ready, LFIB entry present: The tunnel label exists in the Label Forwarding Information Base (LFIB), but the VC is down. • not ready, no route: An IP route for the peer does not exist in the routing table. • not ready, not a host table: The route in the routing table for the remote peer router is not a host route. • unassigned: The label has not been assigned.
Create time	Time (in hours, minutes, and seconds) when the VC was provisioned.
last status change time	Last time (in hours, minutes, and seconds) the VC state changed.
Signaling protocol	Type of protocol used to send the MPLS labels on dynamically configured connections. The output also shows the status of the peer router. For AToM statically configured pseudowires, the field indicates Manual because there is no exchange of labels using a directed control protocol, such as LDP.
MPLS VC labels	Local VC label is a disposition label, which determines the egress interface of an arriving packet from the MPLS backbone. The remote VC label is a disposition VC label of the remote peer router.
Group ID	Local group ID used to group VCs locally. The remote group ID is used by the peer to group several VCs.
MTU	Maximum transmission unit specified for local and remote interfaces.
Remote interface description	Interface on the remote router that has been enabled to transmit and receive Layer 2 packets.
Sequencing	Indicates whether sequencing of out-of-order packets is enabled or disabled.
SSO Descriptor	Identifies the VC for which the information was checkpointed.

Field	Description
local label	Value of the local label that was checkpointed (that is, sent on the active RP and received on the standby RP).
SSM segment/switch IDs	IDs used for the control plane and data plane for this VC. This data is not for customer use but for Cisco personnel for troubleshooting purposes. When the Source Specific Multicast (SSM) IDs are followed by the word “used,” the checkpointed data has been successfully sent.
PWID	Pseudowire ID used in the data plane to correlate the switching context for the segment associated with the MPLS switching context. This data is not for customer use but for Cisco personnel for troubleshooting purposes.
packet totals	Number of packets sent and received. Received packets are those AToM packets received from the MPLS core. Sent packets are those AToM packets sent to the MPLS core. This number excludes dropped packets. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the router.
byte totals	Number of bytes sent and received from the core-facing interface, including the payload, control word if present, and AToM VC label. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the router.
packet drops	Number of dropped packets. Note If the VC statistics fields include the word “transit,” the output shows the number of packets and bytes being sent from the router.

The following is sample output from the **show mpls l2transport vc detail** command when the VPLS Autodiscovery feature has been configured on VPLS pseudowires. The output that is specific to VPLS Autodiscovery is shown in bold.

```
Router# show mpls l2transport vc detail
Local interface: VFI my_test VFI up
MPLS VC type is VFI, interworking type is Ethernet
Destination address: 10.3.3.1, VC ID: 123456, VC status: up
Next hop PE address: 10.55.55.2
Output interface: Et3/0, imposed label stack {17 19}
Preferred path: not configured
Default path:
Next hop: 10.1.0.2
Create time: 2d05h, last status change time: 2d05h
Signaling protocol: LDP, peer 10.55.55.2:0 up
MPLS VC labels: local 21, remote 19
AGI: type 1, len 8, 0000 3333 4F4E 44C4
Local AII: type 1, len 4, 0909 0909 (10.9.9.9)
Remote AII: type 1, len 4, 0303 0301 (10.3.3.3)
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
VC statistics:
```

```

packet totals: receive 22611, send 22611
byte totals:   receive 2346570, send 2853581
packet drops:  receive 0, send 0

```

The table below describes the fields shown in the display.

Table 58: show mpls l2transport vc detail Field Descriptions for VPLS Autodiscovery

Field	Description
Next hop PE address	IP address of the next hop router.
AGI	Attachment group identifier (AGI).
Local AII	Attachment individual identifier (AII)—the local IP address used for signaling.
Remote AII	Remote IP address used for signaling. This address is the provisioned IP address, which might be different from the LDP peer IP address.

The following is sample output from the **show mpls l2transport vc** command when the circuit emulation (CEM) interface is specified:

```
Router# show mpls l2transport vc interface CEM 3/1/1
```

```

Local intf  Local circuit  Dest address  VC ID  Status
-----
CE3/1/1    CESOPSN Basic 10.30.30.3   300    DOWN

```

The tables above and the tables below describes the fields shown in the display.

The following sample output displays (in bold) the number of MAC address withdrawal messages sent and received as part of the H-VPLS N-PE Redundancy for QinQ and MPLS Access feature:

```
Router# show mpls l2transport vc detail
```

```

Local interface: VFI TEST VFI up
MPLS VC type is VFI, interworking type is Ethernet
Destination address: 10.1.1.1, VC ID: 1000, VC status: up
Output interface: Se2/0, imposed label stack {17}
Preferred path: not configured
Default path: active
Next hop: point2point
Create time: 00:04:34, last status change time: 00:04:15
Signaling protocol: LDP, peer 10.1.1.1:0 up
Targeted Hello: 10.1.1.1(LDP Id) -> 10.1.1.1
MPLS VC labels: local 16, remote 17
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
MAC Withdraw: sent 5, received 3
Sequencing: receive disabled, send disabled
VC statistics:
packet totals: receive 0, send 0
byte totals:   receive 0, send 0
packet drops:  receive 0, send 0

```

The tables above and the tables below describe the fields shown in the display.

The following sample output displays (in bold) the status messages for the MPLS Pseudowire Status Signaling feature when it is enabled on both PE routers:

```
Router# show mpls l2transport vc detail

Local interface: Et1/0 up, line protocol up, Ethernet up
Destination address: 10.1.1.1, VC ID: 456, VC status: up
Output interface: Et2/0, imposed label stack {10005 10240}
Preferred path: not configured
Default path: active
Next hop: 10.0.0.1
Create time: 00:39:30, last status change time: 00:26:48
Signaling protocol: LDP, peer 10.1.1.1:0 up
Targeted Hello: 10.1.1.2(LDP Id) -> 10.1.1.1
Status TLV support (local/remote) : enabled/supported
Label/status state machine : established, LruRru
Last local dataplane status rcvd: no fault
Last local SSS circuit status rcvd: no fault
Last local SSS circuit status sent: no fault
Last local LDP TLV status sent: no fault
Last remote LDP TLV status rcvd: PW DOWN(rx,tx faults)
MPLS VC labels: local 2000, remote 10240
Group ID: local 6, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
VC statistics:
packet totals: receive 243651, send 243705
byte totals: receive 27768366, send 34109320
packet drops: receive 0, send 0
```

The table below describes the fields shown in the display.

Table 59: show mpls l2transport vc detail Field Descriptions for the MPLS Pseudowire Signaling Status Feature

Field	Description
Status TLV support (local/remote)	For the local router, the output indicates whether the MPLS Pseudowire Signaling Status feature is enabled or disabled. For the remote router, the output indicates whether the MPLS Pseudowire Signaling Status feature is supported.
Label/status state machine	The first value in the output indicates whether label advertisement has been established or not. The second value (LruRru) indicates the status of the local and remote routers. The following list translates the status codes: <ul style="list-style-type: none"> • D—Dataplane • L—local router • r or n—ready (r) or not ready (n) • R—remote router • S—Local shutdown • u or d—up (u) or down (d) status

Field	Description
Last local dataplane status rcvd	Last status message received about the dataplane on the local router.
Last local SSS circuit status rcvd	Last status message received about the subscriber service switch (SSS) on the local router.
Last local SSS circuit status sent	Last status message sent about the subscriber service switch on the local router.
Last local LDP TLV status sent	Last status message sent about the type, length, values (TLV) on the local router.
Last remote LDP TLV status rcvd	Last status message received about the TLV on the local router.

The following sample output from the **show mpls l2transport vc detail** command displays the status of multisegment pseudowires:

```
Router# show mpls l2transport vc detail
Local interface: Se3/0 up, line protocol up, HDLC up
  Destination address: 10.12.1.1, VC ID: 100, VC status: down
  Output interface: Se2/0, imposed label stack {23}
  Preferred path: not configured
  Default path: active
  Next hop: point2point
Create time: 00:03:02, last status change time: 00:01:41
Signaling protocol: LDP, peer 10.12.1.1:0 up
  Targeted Hello: 10.11.1.1(LDP Id) -> 10.12.1.1, LDP is UP
  Status TLV support (local/remote)   : enabled/supported
  LDP route watch                      : enabled
  Label/status state machine           : established, LruRrd
  Last local dataplane status rcvd: No fault
  Last local SSS circuit status rcvd: No fault
  Last local SSS circuit status sent: DOWN(PW-tx-fault)
  Last local LDP TLV status sent: No fault
  Last remote LDP TLV status rcvd: DOWN(PW-tx-fault)
  PW Switching Point:
  Fault type Vcid local IP addr remote IP addr Description
  PW-tx-fault 101 10.13.1.1 10.12.1.1 S-PE2
  Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 19, remote 23
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
VC statistics:
  packet totals: receive 16, send 27
  byte totals: receive 2506, send 3098
  packet drops: receive 0, seq error 0, send 0
```

The table below describes the significant fields shown in the display.

Table 60: show mpls l2transport vc detail Field Descriptions for the MPLS Multisegment Pseudowire Feature

Field	Description
Fault type	Type of fault encountered on the switching point.
Vcid	ID of the VC on which the fault occurred.

Field	Description
local IP addr	Local IP address of the pseudowire.
remote IP addr	Remote IP address of the pseudowire.
Description	Descriptions assigned to the segment of the pseudowire.

The following sample output from the **show mpls l2transport vc detail** command displays the status of the control word when it is not configured (that is, it defaults to autosense):

```
Router# show mpls l2transport vc 123400 detail
Local interface: Et0/0 up, line protocol up, Ethernet up
  Destination address: 10.1.1.2, VC ID: 123400, VC status: down
  Output interface: if-(0), imposed label stack {}
  Preferred path: not configured
  Default path: no route
  No adjacency
Create time: 01:03:48, last status change time: 01:03:48
Signaling protocol: LDP, peer 10.1.1.3:0 up
  Targeted Hello: 10.1.1.1(LDP Id) -> 10.1.1.2
  Status TLV support (local/remote)   : enabled/unknown (no remote binding)
  Label/status state machine          : local ready, LruRnd
  Last local dataplane status rcvd: no fault
  Last local SSS circuit status rcvd: no fault
  Last local SSS circuit status sent: not sent
  Last local LDP TLV status sent: no fault
  Last remote LDP TLV status rcvd: unknown (no remote binding)
MPLS VC labels: local 1002, remote unassigned
Group ID: local 0, remote unknown
MTU: local 1500, remote unknown
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: on (configured: autosense)
```

If the control word is negotiated by the peer and is different from the configured value, the configured value is shown in parentheses.

- If the control word is configured to be disabled, the displayed value is as follows:

```
Control Word: off (configured: disabled)
```

- If the control word is configured to be enabled but negotiated by the peer to be off, the displayed value is as follows:

```
Control Word: off (configured: enabled)
```

- If the control word is not configured, the displayed value is as follows:

```
Control Word: on (configured: autosense)
```

The following sample output from the **show mpls l2transport vc detail** command displays load balancing information and shows whether flow labels are added to the MPLS label as part of the L2VPN Advanced VPLS feature:

```
Router# show mpls l2transport vc detail
```

```

Local interface: VFI dci_vlan_100 VFI up
MPLS VC type is VFI, interworking type is Ethernet
Destination address: 10.2.2.2, VC ID: 100, VC status: up
Output interface: Tu0, imposed label stack {16}
Preferred path: not configured
Default path: active
Next hop: point2point
Load Balance: Flow
Flow Label: enabled

```

The table below describes the significant fields shown in the display.

Table 61: show mpls l2transport vc detail Field Descriptions for the L2VPN Advanced VPLS Feature

Field	Description
Load Balance	Displays the type of load-balancing configured. The load-balancing configuration can be either flow-based or port channel-based.
Flow Label	Indicates whether the imposition and disposition of flow labels for the pseudowire is enabled.

The following sample output from the **show mpls l2transport vc detail** command displays BFD information:

```

Router# show mpls l2transport vc detail
Local interface: AT1/1/0 up, line protocol up, ATM AAL5 10/101 up
Destination address: 10.1.1.151, VC ID: 1234001, VC status: up
Output interface: Gi1/0/0, imposed label stack {2000}
Preferred path: not configured
Default path: active
Next hop: 10.151.152.1
Create time: 6d03h, last status change time: 6d03h
Signaling protocol: LDP, peer 10.1.1.151:0 up
Targeted Hello: 10.1.1.152(LDP Id) -> 10.1.1.151, LDP is UP
Status TLV support (local/remote) : enabled/supported
LDP route watch : enabled
Label/status state machine : established, LruRru
Last local dataplane status rcvd: No fault
Last local SSS circuit status rcvd: No fault
Last local SSS circuit status sent: No fault
Last local LDP TLV status sent: No fault
Last remote LDP TLV status rcvd: No fault
Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 2000, remote 2000
PWID: 20490
Group ID: local 0, remote 0
MTU: local 4470, remote 4470
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
VCCV BFD protection active
BFD Template - sampleBFDTemplate
CC Type - 1
CV Type - fault detection only with IP/UDP headers
VC statistics:
transit packet totals: receive 0, send 0
transit byte totals: receive 0, send 0
transit packet drops: receive 0, seq error 0, send 0

```

The table below describes the significant fields shown in the display.

Table 62: show mpls l2transport vc detail Field Descriptions for the BFD CC over VCCV - Support for ATM Pseudowire Feature

Field	Description
VCCV BFD protection active	Displays the VCCV BFD protection status.
BFD Template	Displays the BFD template name.
CC Type	Displays the CC type. <ul style="list-style-type: none"> • Type 1: control word. • Type 2: MPLS router alert label. • Type 3: MPLS pseudowire label with TTL.
CV Type	Displays the Control Verification type.

The following is sample output from the **show mpls l2transport vc** command when the L2VPN VPLS Inter-AS Option B feature has been configured. The fields in the display are self-explanatory or described in other tables in this document.

```
Router# show mpls l2transport vc
Load for five secs: 4%/1%; one minute: 4%; five minutes: 2%
Time source is hardware calendar, *17:26:56.066 GMT Mon Oct 18 2010
Local intf      Local circuit      Dest address      VC ID      Status
-----
VFI auto        VFI                 10.1.1.1         100        UP
```

The following is sample output from the **show mpls l2transport vc detail** command when the L2VPN VPLS Inter-AS Option B feature has been configured. The output that is specific to the L2VPN VPLS Inter-AS Option B feature is shown in bold.

```
Router# show mpls l2transport vc detail
Load for five secs: 4%/1%; one minute: 4%; five minutes: 2%
Time source is hardware calendar, *17:27:28.076 GMT Mon Oct 18 2010
Local interface: VFI auto VFI up
  Interworking type is Ethernet
  Destination address: 192.0.2.1, VC ID: 100, VC status: up
  Next hop PE address: 198.51.100.1
  Output interface: Et1/0, imposed label stack {2012}
  Preferred path: not configured
  Default path: active
  Next hop: 10.0.0.3
  Create time: 00:00:48, last status change time: 00:00:48
  Signaling protocol: LDP, peer 192.0.2.3:0 up
  Targeted Hello: 192.0.2.6(from BGP) -> 192.0.2.8, LDP is UP
  Status TLV support (local/remote) : enabled/supported
    LDP route watch                   : enabled
    Label/status state machine        : established, LruRru
    Last local dataplane status rcvd: No fault
    Last local SSS circuit status rcvd: No fault
    Last local SSS circuit status sent: No fault
    Last local LDP TLV status sent: No fault
    Last remote LDP TLV status rcvd: No fault
    Last remote LDP ADJ status rcvd: No fault
  MPLS VC labels: local 1011, remote 2012
PWID: 4096
```



```

AGI: type 1, len 8, 000A 0001 0000 0001
Local AII: type 1, len 4, 0101 0001 (203.0.113.1)
Remote AII: type 1, len 4, 0201 0101 (203.0.113.5)
VPLS-ID: 1:1
Group ID: local n/a, remote n/a
MTU: local 1500, remote 1500
Remote interface description:
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
SSO Descriptor: 203.0.113.5/100, local label: 1011
SSM segment/switch IDs: 16387/8193 (used), PWID: 4096
VC statistics:
transit packet totals: receive 0, send 0
transit byte totals: receive 0, send 0
transit packet drops: receive 0, seq error 0, send 0

```

The table below describes the feature-specific significant fields shown in the display.

Table 63: show mpls l2transport vc detail Field Descriptions for the L2VPN VPLS Inter-AS Option B

Field	Description
PWID	Pseudowire identifier.
VPLS-ID	The VPLS identifier associated with the pseudowire.

The following is sample output from the **show mpls l2transport vc detail** command when there is a remote AC failure and when VCCV BFD status signaling is enabled, that is, **vccv bfd status signaling** is configured.

```

Router# show mpls l2transport vc detail
Load for five secs: 0%/0%; one minute: 0%; five minutes: 0%
Time source is hardware calendar, *03:31:33.136 PST Thu Mar 24 2011
Local interface: Et1/0.1 up, line protocol up, Eth VLAN 1001 up
Destination address: 192.0.2.1, VC ID: 1234000, VC status: down
  Output interface: Et0/0, imposed label stack {150}
  Preferred path: not configured
  Default path: active
  Next hop: 198.58.100.2
Create time: 00:03:45, last status change time: 00:00:02
Signaling protocol: Manual
  Status TLV support (local/remote)   : enabled/N/A
  LDP route watch                      : enabled
  Label/status state machine          : established, LruRrd
  Last local dataplane status rcvd: No fault
  Last BFD dataplane status rcvd: No fault
  Last local SSS circuit status rcvd: No fault
  Last local SSS circuit status sent: DOWN AC(rx/tx faults)
  Last local LDP TLV status sent: None
  Last remote LDP TLV status rcvd: DOWN AC(rx/tx faults), (UP)
  Last remote LDP ADJ status rcvd: No fault
MPLS VC labels: local 100, remote 150
PWID: 4096
Group ID: local 0, remote 0
MTU: local 1500, remote 1500
Sequencing: receive disabled, send disabled
Control Word: On (configured: autosense)
VCCV BFD protection active
  BFD Template - t1
  CC Type - 1
  CV Type - fault detection and status signaling without IP/UDP headers

```

```

VC statistics:
  transit packet totals: receive 0, send 5
  transit byte totals:   receive 0, send 580
  transit packet drops:  receive 0, seq error 0, send 0

```

The table below describes the significant fields shown in the display.

Table 64: show mpls l2transport vc detail Field Descriptions for Remote AC Failure

Field	Description
Last BFD dataplane status rcvd	Last status message received about the BFD dataplane on the local router.
Last local dataplane status rcvd	Last status message received about the dataplane on the local router.
Last local SSS circuit status rcvd	Last status message received about the subscriber service switch (SSS) on the local router.
Last local SSS circuit status sent	Last status message sent about the subscriber service switch on the local router.
Last remote LDP ADJ	Last status message received about the ADJ on the local router.
VCCV BFD protection active	Displays the VCCV BFD protection status.
BFD Template	Displays the BFD template name.
CC Type	Displays the CC type. <ul style="list-style-type: none"> • Type 1: control word. • Type 2: MPLS router alert label. • Type 3: MPLS pseudowire label with TTL.
CV Type	Displays the Control Verification type.

Sample Output for show mpls l2transport vc Command on a Cisco uBR10012 Router in the Brief Display Format in Cisco IOS Release 12.2(33)SCF

The following is sample output from the **show mpls l2transport vc** command when the L2VPN Pseudowire Redundancy feature has been configured. The fields in the display are self-explanatory or described in other tables in this document:

```

Router# show mpls l2transport vc
Local intf      Local circuit    Dest address     VC ID           Status
-----
Bu254          DOCSIS 55       10.2.3.4        55             DOWN
Bu254          DOCSIS 1000     10.2.3.4        1000           UP
Bu254          DOCSIS 400      10.76.2.1       400            UP
Bu254          DOCSIS 600      10.76.2.1       600            DOWN
Bu254          DOCSIS 1800     10.76.2.1       1800           UP
Bu254          DOCSIS 45454    10.76.2.1       45454          DOWN

```

Related Commands

Command	Description
show mpls forwarding-table	Displays the contents of the MPLS LFIB.
show mpls l2transport summary	Displays summary information about VCs that have been enabled to route AToM Layer 2 packets on a router.
show xconnect	Displays information about xconnect attachment circuits and pseudowires.

show mpls label range

To display the range of local labels available for use on packet interfaces, use the show **show mpls label range** command in privileged EXEC mode.

show mpls label range

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Release	Modification
12.0(9)ST	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
XE Release 2.2	This command was integrated into Cisco IOS XE Release 2.2. The “Usage Guidelines” and the sample command output changed.

Usage Guidelines You can use the **mpls label range** command to configure a range for local labels that is different from the default range. The **show mpls label range** command displays both the label range currently in use and the label range that will be in use following the next router reload.

Examples In the following example, the use of the **show mpls label range** command is shown before and after the **mpls label range** command is used to configure a label range that does not overlap the starting label range:

```
Router# show mpls label range
Downstream label pool: Min/Max label: 16/100000
Router# configure terminal
Router(config)# mpls label range 200 120000
Router(config)# exit
Router# show mpls label range
Downstream label pool: Min/Max label: 200/120000
```

Command	Description
mpls label range	Configures a range of values for use as local labels.

show mpls ldp backoff

To display information about the configured session setup backoff parameters and any potential Label Distribution Protocol (LDP) peers with which session setup attempts are being throttled, use the **show mpls ldp backoff** command in user EXEC or privileged EXEC mode.

```
show mpls ldp backoff [{vrf vrf-name | all}]
```

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays backoff information for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance (<i>vrf-name</i>).
all	(Optional) Displays LDP discovery information for all VPNs.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0(10)ST	This command was introduced.
12.0(14)ST	This command was integrated into Cisco IOS Release 12.0(14)ST.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(30)S	The vrf <i>vrf-name</i> keyword and argument pair and the all keyword were added.
12.4(3)	The vrf <i>vrf-name</i> keyword and argument pair and the all keyword were added.
12.4(4)T	The vrf <i>vrf-name</i> keyword and argument pair and the all keyword were added.
12.0(32)S	The vrf <i>vrf-name</i> keyword and argument pair and the all keyword were added.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show mpls ldp backoff** command:

```
Router# show mpls ldp backoff

LDP initial/maximum backoff: 30/240 sec
Backoff table: 2 entries
LDP Id           Backoff(sec)    Waiting(sec)
10.144.0.44:0    60              30
10.155.0.55:0    120             90
```

The table below describes the significant fields shown in the display.

Table 65: show mpls ldp backoff Field Descriptions

Field	Description
LDP initial/maximum backoff	Indicates the configured backoff parameters (initial and maximum) in seconds.
Backoff table	Contains a list of discovered LDP neighbors for which session setup is being delayed because of previous failures to establish a session due to incompatible configuration. The backoff table incorporates the following information: <ul style="list-style-type: none"> • LDP Id--Identifies the LDP neighbors. • Backoff(sec)--Shows the amount of time that session setup is being delayed. • Waiting(sec)--Shows the approximate amount of time that session setup has been delayed.

The following is sample output from the **show mpls ldp backoff vrf vrf-name** command that shows one entry in the Backoff table for VRF vrf1:

```
Router# show mpls ldp backoff vrf vrf1

LDP initial/maximum backoff: 15/120 sec
VRF vrf1 Backoff table: 1 entries
LDP Id           Backoff(sec)    Waiting(sec)
10.12.0.2:0      120             30
```

The following is sample output from a form of the **show mpls ldp backoff all** command:

```
Router# show mpls ldp backoff all

LDP initial/maximum backoff: 15/120 sec
Backoff table: 2 entries
LDP Id           Backoff(sec)    Waiting(sec)
10.155.0.55:0    120             30
10.144.0.44:0    60              60
```

```
VRF vrf1 Backoff table: 1 entries
LDP Id           Backoff(sec)  Waiting(sec)
10.12.0.2:0      120           45
VRF vrf2 Backoff table: 1 entries
LDP Id           Backoff(sec)  Waiting(sec)
10.13.0.1:0      120           30
```

See the table below for a description of the significant fields shown in the displays.

Related Commands

Command	Description
mpls ldp backoff	Configures session setup delay parameters for the LDP backoff mechanism.

show mpls ldp bindings

To display the contents of the Label Information Base (LIB), use the **show mpls ldp bindings** command in user EXEC or privileged EXEC mode.

show mpls ldp bindings [{**vrf** *vrf-name* | **all**}] [**network** {*masklength*} [**longer-prefixes**]] [**local-label** *label* [- *label*]] [**remote-label** *label* [- *label*]] [{**neighbor** *address* | **local**}] [**detail**]

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the label bindings for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance (<i>vrf-name</i>).
all	(Optional) Displays LIB information for all VPNs.
<i>network</i>	(Optional) Destination network number.
<i>mask</i>	Network mask, written as A.B.C.D.
<i>length</i>	Mask length (1 to 32 characters).
longer-prefixes	(Optional) Selects any prefix that matches the value in the <i>mask</i> argument with a <i>length</i> from 1 to 32 characters.
local-label <i>label-label</i>	(Optional) Display entries matching local label values. Use the <i>label-label</i> arguments and keyword to indicate the label range. The hyphen (-) keyword is required for a label range.
remote-label <i>label-label</i>	(Optional) Displays entries matching the label values assigned by a neighbor router. Use the <i>label-label</i> arguments and keyword to indicate the label range. The hyphen (-) keyword is required for a label range.
neighbor <i>address</i>	(Optional) Displays the label bindings assigned by the selected neighbor.
local	(Optional) Displays the local label bindings.
detail	(Optional) Displays the checkpoint status of the local label bindings.

Command Default

If no optional keywords or arguments are entered, the command displays the LIB for the default routing domain only.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	This command was modified to support Multiprotocol Label Switching (MPLS) Internet Engineering Task Force (IETF) command syntax and terminology.

Release	Modification
12.0(14)ST	This command was modified to include MPLS Virtual Private Network (VPN) support for Label Distribution Protocol (LDP).
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.0(21)ST	This command was integrated into Cisco IOS Release 12.0(21)ST.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.0(23)S	This command was integrated into Cisco IOS Release 12.0(23)S.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.2(25)S	The detail keyword was added.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SRC	The output of the command was updated to display information about LDP local label allocation filtering.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.

Usage Guidelines

The **show mpls ldp bindings** command displays label bindings learned by the LDP or Tag Distribution Protocol (TDP).



Note TDP is not supported for LDP features in Cisco IOS 12.0(30)S and later releases, 12.2(28)SB and later 12.2S releases, and 12.3(14)T and later releases.

A request can specify that the entire database be displayed, or that the display be limited to a subset of entries according to the following:

- Prefix
- Input or output label values or ranges
- Neighbor advertising the label



Note The **show mpls ip bindings** command includes the output generated by the **show mpls ldp bindings** command. On the Cisco 7000 series router, this command displays information about label bindings for LC-ATM interfaces.

Examples

The following is sample output from the **show mpls ldp bindings** command. This form of the command displays the contents of the LIB for the default routing domain.

```
Router# show mpls ldp bindings
 10.0.0.0/8, rev 9
   local binding: label: imp-null
   remote binding: lsr: 10.10.0.55:0, label: 17
   remote binding: lsr: 10.66.0.66:0, label: 18
   remote binding: lsr: 10.0.0.44:0, label: imp-null
 172.16.0.0/8, rev 17
   local binding: label: 19
   remote binding: lsr: 10.0.0.55:0, label: imp-null
   remote binding: lsr: 10.66.0.66:0, label: 16
   remote binding: lsr: 10.0.0.44:0, label: imp-null
 192.168.0.66/32, rev 19
   local binding: label: 20
   remote binding: lsr: 10.0.0.55:0, label: 19
   remote binding: lsr: 10.66.0.66:0, label: imp-null
   remote binding: lsr: 10.0.0.44:0, label: 18
.
.
.
```

The following is sample output from the **show mpls ldp bindings network length longer-prefixes neighbor address** variant of the command; it displays labels learned from label switch router (LSR) 10.144.0.44 for network 10.166.0.0 and any of its subnets. The use of the **neighbor** keyword suppresses the output of local labels and labels learned from other neighbors.

```
Router# show mpls ldp bindings 10.166.0.0 8 longer-prefixes neighbor 10.144.0.44
 10.166.44.0/16, rev 31
   remote binding: lsr: 10.144.0.44:0, label: 25
 10.166.45.0/16, rev 33
   remote binding: lsr: 10.144.0.44:0, label: 26
 10.166.245.0/16, rev 71
   remote binding: lsr: 10.144.0.44:0, label: 45
 10.166.246.0/16, rev 73
   remote binding: lsr: 10.144.0.44:0, label: 46
.
.
.
```

The following is sample output from the **show mpls ldp bindings vrf vpn1** command, which displays the label bindings for the specified VPN routing and forwarding instance named vpn1:

```
Router# show mpls ldp bindings vrf vpn1
 10.3.3.0/16, rev 164
   local binding: label:117
   remote binding:lsr:10.14.14.14:0, label:imp-null
 10.13.13.13/32, rev 1650
   local binding: label:1372
   remote binding:lsr:10.14.14.14:0, label:268
 10.14.14.14/32, rev 165
```

```

        local binding: label:118
        remote binding:lsr:10.14.14.14:0, label:imp-null
10.15.15.15/32, rev 1683
        local binding: label:1370
        remote binding:lsr:10.14.14.14:0, label:266
10.16.16.16/32, rev 775
        local binding: label:8370
        remote binding:lsr:10.14.14.14:0, label:319
10.18.18.18/32, rev 1655
        local binding: label:21817
        remote binding:lsr:10.14.14.14:0, label:571
10.30.2.0/16, rev 1653
        local binding: label:6943
        remote binding:lsr:10.14.14.14:0, label:267
10.30.3.0/16, rev 413
        local binding: label:2383
        remote binding:lsr:10.14.14.14:0, label:imp-null
10.30.4.0/16, rev 166
        local binding: label:77
        remote binding:lsr:10.14.14.14:0, label:imp-null
10.30.5.0/16, rev 1429
        local binding: label:20715
        remote binding:lsr:10.14.14.14:0, label:504
10.30.7.0/16, rev 4
        local binding: label:17
        remote binding:lsr:10.14.14.14:0, label:imp-null
10.30.10.0/16, rev 422
        local binding: label:5016
        remote binding:lsr:10.14.14.14:0, label:269
.
.
.

```

The following is sample output from the **show mpls ldp bindings all** command, which displays the label bindings for all VRFs:

```

Router# show mpls ldp bindings all

lib entry: 10.0.0.0/24, rev 4
        local binding: label: imp-null
        remote binding: lsr: 10.131.0.1:0, label: imp-null
lib entry: 10.11.0.0/24, rev 15
        local binding: label: imp-null
        remote binding: lsr: 10.131.0.1:0, label: imp-null
lib entry: 10.101.0.1/32, rev 18
        remote binding: lsr: 10.131.0.1:0, label: imp-null
lib entry: 10.131.0.1/32, rev 17
        local binding: label: 20
        remote binding: lsr: 10.131.0.1:0, label: imp-null
lib entry: 10.134.0.1/32, rev 6
        local binding: label: imp-null
        remote binding: lsr: 10.131.0.1:0, label: 16
VRF vrf1:
lib entry: 10.0.0.0/24, rev 6
        remote binding: lsr: 10.132.0.1:0, label: imp-null
lib entry: 10.11.0.0/24, rev 7
        remote binding: lsr: 10.132.0.1:0, label: imp-null
lib entry: 10.12.0.0/24, rev 8
        local binding: label: 17
        remote binding: lsr: 10.132.0.1:0, label: imp-null
lib entry: 10.132.0.1/32, rev 4
        remote binding: lsr: 10.132.0.1:0, label: imp-null
lib entry: 10.134.0.2/32, rev 9

```

```

    local binding: label: 18
    remote binding: lsr: 10.132.0.1:0, label: 16
lib entry: 10.134.0.4/32, rev 10
    local binding: label: 19
    remote binding: lsr: 10.132.0.1:0, label: 17
lib entry: 10.138.0.1/32, rev 5
    remote binding: lsr: 10.132.0.1:0, label: imp-null

```

The following is sample output from the **show mpls ldp bindings detail** command:

```

Router# show mpls ldp bindings detail
lib entry: 10.3.3.0/16, rev 2,
    local binding: label: imp-null
    Advertised to:
        10.20.20.20:0          10.25.25.25:0
    remote binding: lsr: 10.20.20.20:0, label: imp-null stale
    remote binding: lsr: 10.25.25.25:0, label: imp-null stale
lib entry: 10.13.1.0/24, rev 4,
    local binding: label: imp-null
    Advertised to:
        10.20.20.20:0          10.25.25.25:0
    remote binding: lsr: 10.20.20.20:0, label: imp-null stale
    remote binding: lsr: 10.25.25.25:0, label: 16 stale
lib entry: 10.13.2.0/24, rev 6,
    local binding: label: imp-null
    Advertised to:
        10.20.20.20:0          10.25.25.25:0
    remote binding: lsr: 10.20.20.20:0, label: 16 stale
    remote binding: lsr: 10.25.25.25:0, label: imp-null stale
lib entry: 10.6.1.0/24, rev 22,
    local binding: label: 21
    Advertised to:
        10.20.20.20:0          10.25.25.25:0
    remote binding: lsr: 10.20.20.20:0, label: 19 stale
    remote binding: lsr: 10.25.25.25:0, label: imp-null stale

```

The following is sample output from the **show mpls ldp bindings detail** command when LDP local label allocation filtering is configured:

```

Router# show mpls ldp bindings detail
Advertisement spec:
    Prefix acl = bar
Local label filtering spec: host routes.
lib entry: 10.1.1.1/32, rev 9
lib entry: 10.10.7.0/24, rev 10
lib entry: 10.10.8.0/24, rev 11
lib entry: 10.10.9.0/24, rev 12
lib entry: 10.41.41.41/32, rev 17
lib entry: 10.50.50.50/32, rev 15
lib entry: 10.60.60.60/32, rev 18
lib entry: 10.70.70.70/32, rev 16
lib entry: 10.80.80.80/32, rev 14

```

The table below describes the significant fields shown in the displays.

Table 66: show mpls ldp bindings Field Descriptions

Field	Description
10.3.3.0/16 10.1.1.1/32	IP prefix and mask for a particular destination (network/mask).

Field	Description
rev 9	Revision number that is used internally to manage label distribution for this destination.
Advertised to	The LSRs that received the label binding.
local binding	Labels assigned by the local LSR.
remote binding	List of outgoing labels for this destination learned from other LSRs. Each item in this list identifies the LSR from which the outgoing label was learned and the label itself. The LSR is identified by its LDP identifier.
stale	After an LDP session is lost and the routers begin a graceful restart, the remote label bindings are marked stale.
Local label filtering spec: host routes.	LDP allocates local labels for host routes.

Related Commands

Command	Description
show mpls ip binding	Displays specified information about label bindings learned by the MPLS LDP.
show mpls ldp neighbor	Displays the status of LDP sessions.

show mpls ldp capabilities

To display the Label Distribution Protocol (LDP) capability information, use the **show mpls ldp capabilities** command in user EXEC or privileged EXEC mode.

show mpls ldp capabilities [{vrf *vrf-name* | all}]

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the LDP capability information for the specified VPN routing and forwarding (VRF) instance.
all	(Optional) Displays LDP capability information for all VPNs, including those in the default routing domain.

Command Default

Displays information about LDP capability for the default routing domain if you do not specify the optional **vrf** or **all** keyword.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.2(33)SRE4	This command was introduced.

Usage Guidelines

The **show mpls ldp capabilities** command can provide information about the capabilities that will be advertised through LDP sessions associated to a particular routing domain.

Examples

The following is sample output from the **show mpls ldp capabilities** command, which shows the router's capabilities associated with the default routing domain.

```
Router# show mpls ldp capabilities
LDP Capabilities - [<description> (<type>)]
-----
    [Dynamic Announcement (0x0506)]
    [Typed Wildcard (0x050B)]
```

The following is sample output from the **show mpls ldp capabilities all** command, which shows the router's capabilities associated with all VRF routing domains including the default routing domain.

```
Router# show mpls ldp
capabilities all

LDP Capabilities - [<description> (<type>)]
-----
    [Dynamic Announcement (0x0506)]
    [Typed Wildcard (0x050B)]
VRF vpn1:
    [Dynamic Announcement (0x0506)]
    [Typed Wildcard (0x050B)]
VRF vpn2:
```

```
[Dynamic Announcement (0x0506)]
[Typed Wildcard (0x050B)]
```

The following is sample output from the **show mpls ldp capabilities vrf** command, which shows the router's capabilities associated with the VRF routing domain named `vpn1`:

```
Router# show mpls ldp
capabilities vrf vpn1
LDP Capabilities - [<description> (<type>)]
-----
[Dynamic Announcement (0x0506)]
[Typed Wildcard (0x050B)]
```

Table 67: show mpls ldp neighbor Field Descriptions

Field	Description
LDP Capabilities	LDP capability information.
VRF	LDP capability information for the specified VRF.

Related Commands

Command	Description
show mpls ldp neighbor capabilities	Displays LDP announce and receive information for an LDP neighbor.
show mpls ldp neighbor details	Displays information in long form, including password information for a neighbor.

show mpls ldp checkpoint

To display information about the Label Distribution Protocol (LDP) checkpoint system on the active route processor, use the **show mpls ldp checkpoint** command in user EXEC or privileged EXEC mode.

show mpls ldp checkpoint

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.2(25)S	This command was introduced.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines

This command shows the following LDP checkpointing information:

- The status of the checkpointing system
- The status of the resend timer
- The number of Label Information Base (LIB) entries in a checkpointed state

This command displays checkpoint status information only for the active route processor.

Examples

The following example shows the LDP checkpoint settings and configuration:

```
Router# show mpls ldp checkpoint
Checkpoint status: dynamic-sync
Checkpoint resend timer: not running
5 local bindings in add-skipped
9 local bindings in added
1 of 15+ local bindings in none
```

The table below describes the significant fields shown in the display.

Table 68: show mpls ldp checkpoint Field Descriptions

Field	Description
Checkpoint status	The status of the checkpointing system. If the status shows dynamic-sync or another enabled state, then the checkpointing system is enabled. If the status shows disabled, then the checkpointing system is disabled.

Field	Description
Checkpoint resend timer	The status of the resend timer.
local bindings in add-skipped	The number of local bindings that were not checkpointed, because they do not need to be checkpointed. For example, local label bindings using null labels are not checkpointed.
local bindings in added	The number of local bindings that were copied to the standby route processor.
local bindings in none	The number of local bindings that reside on the active route processor and need to be copied to the backup route processor.

Related Commands

Command	Description
show mpls ldp graceful-restart	Displays a summary of the LDP Graceful Restart status.

show mpls ldp discovery

To display the status of the Label Distribution Protocol (LDP) discovery process, use the **show mpls ldp discovery** command in user EXEC or privileged EXEC mode.

show mpls ldp discovery [{*vrf vrf-name* | **all**}] [**detail**]

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the neighbor discovery information for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance.
all	(Optional) Displays LDP discovery information for all VPNs, including those in the default routing domain.
detail	(Optional) Displays detailed information about all LDP discovery sources on a label switch router (LSR).

Command Default

This command displays neighbor discovery information for the default routing domain if an optional **vrf** keyword is not specified.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST. The command was modified to comply with Multiprotocol Label Switching (MPLS) Internet Engineering Task Force (IETF) command syntax and terminology.
12.0(14)ST	This command was modified for MPLS VPN support for LDP. The vrf and all keywords were added.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.2(8)T	This command was modified for MPLS VPN support for LDP. The vrf and all keywords were added.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.3(14)T	The detail keyword was added to the command to display information related to the LDP Autoconfiguration feature.
12.2(28)SB	The detail keyword was updated to display information related to LDP Message Digest 5 (MD5) password configuration.

Release	Modification
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.0(33)S	This command was integrated into Cisco IOS Release 12.0(33)S and LDP MD5 password rollover information displays in the command output when the detail keyword is used with the show mpls ldp discovery command.
Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
Cisco IOS XE Release 3.6S	This command was implemented on the Cisco ASR 903 series routers.

Usage Guidelines

This command displays neighbor discovery information for LDP or Tag Distribution Protocol (TDP). It generates a list of interfaces over which the LDP discovery process is running.

Examples

The following is sample output from the **show mpls ldp discovery** command:

```
Router# show mpls ldp discovery
Local LDP Identifier:
 10.1.1.1:0
Discovery Sources:
  Interfaces:
    Ethernet1/1/3 (ldp): xmit/recv
      LDP Id: 172.23.0.77:0
      LDP Id: 10.144.0.44:0
      LDP Id: 10.155.0.55:0
    ATM3/0.1 (ldp): xmit/recv
      LDP Id: 10.203.0.7:2
    ATM0/0.2 (tdp): xmit/recv
      TDP Id: 10.119.0.1:1
Targeted Hellos:
 10.8.1.1 -> 10.133.0.33 (ldp): active, xmit/recv
      LDP Id: 10.133.0.33:0
 10.8.1.1 -> 192.168.7.16 (tdp): passive, xmit/recv
      TDP Id: 10.133.0.33:0
Router#
```

The following is sample output from the **show mpls ldp discovery all** command, which shows the interfaces engaged in LDP discovery activity for all the VPN routing and forwarding instances, including those in the default routing domain. In this example, note that the same neighbor LDP ID (10.14.14.14) appears in all the listed VRF interfaces, highlighting the fact that the same IP address can coexist in different VPN routing and forwarding instances.

```
Router# show mpls ldp discovery all
Local LDP Identifier:
 10.12.12.12:0
Discovery Sources:
  Interfaces:
    ATM1/1/0.1 (tdp):xmit/recv
      TDP Id:10.11.11.11:0
VRF vpn1:Local LDP Identifier:
 172.30.7.2:0
```

show mpls ldp discovery

```

Discovery Sources:
Interfaces:
    ATM3/0/0.1 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn2:Local LDP Identifier:
172.30.13.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.2 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn3:Local LDP Identifier:
172.30.15.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.3 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn4:Local LDP Identifier:
172.30.17.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.4 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn5:Local LDP Identifier:
172.30.19.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.5 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn6:Local LDP Identifier:
172.30.21.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.6 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn7:Local LDP Identifier:
172.23.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.7 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn8:Local LDP Identifier:
172.30.25.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.8 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn9:Local LDP Identifier:
172.30.27.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.9 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn10:Local LDP Identifier:
172.30.29.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.10 (ldp):xmit/recv
        LDP Id:10.14.14.14:0
VRF vpn11:Local LDP Identifier:
172.30.31.2:0
Discovery Sources:
Interfaces:
    ATM3/0/0.11 (ldp):xmit/recv
        LDP Id:10.14.14.14:0

```

```

VRF vpn12:Local LDP Identifier:
  172.30.33.2:0
  Discovery Sources:
  Interfaces:
    ATM3/0/0.12 (ldp):xmit/recv
      LDP Id:10.14.14.14:0
VRF vpn13:Local LDP Identifier:

```

Router#

The table below describes the significant fields shown in the display.

Table 69: show mpls ldp discovery Field Descriptions

Field	Description
Local LDP Identifier	<p>The LDP identifier for the local router. An LDP identifier is 6-bytes displayed in the form “IP address:number.”</p> <p>By convention, the first four bytes of the LDP identifier constitute the router ID; integers, starting with 0, constitute the final two bytes of the IP address:number construct.</p>
Interfaces	<p>Lists the interfaces that are engaging in LDP discovery activity:</p> <ul style="list-style-type: none"> • The xmit field--Indicates that the interface is sending LDP discovery hello packets. • The recv field--Indicates that the interface is receiving LDP discovery hello packets. • The (LDP) or (TDP) field--Indicates the Label Distribution Protocol or Tag Distribution Protocol configured for the interface. <p>The LDP (or TDP) identifiers indicate the LDP (or TDP) neighbors discovered on the interface.</p>
Targeted Hellos	<p>Lists the platforms to which targeted hello messages are being sent:</p> <ul style="list-style-type: none"> • The xmit, recv, (ldp), and (tdp) fields are as described for the Interfaces field. • The active field indicates that this LSR has initiated targeted hello messages. • The passive field indicates that the neighbor LSR has initiated targeted hello messages and that this LSR is configured to respond to the targeted hello messages from the neighbor. <p>Note The entry for a given target platform may indicate both active and passive.</p>

The following is sample output from the **show mpls ldp discovery detail** command showing that LDP was enabled by the **mpls ip** command and the **mpls ldp autoconfig** command:

```

Router# show mpls ldp discovery detail
Local LDP Identifier:
  10.11.11.11:0
  Discovery Sources:
  Interfaces:
    Serial2/0 (ldp): xmit/recv
      Enabled: Interface config, IGP config;
      Hello interval: 5000 ms; Transport IP addr: 10.11.11.11
      LDP Id: 10.10.10.10:0

```

```
Src IP addr: 172.140.0.1; Transport IP addr: 10.10.10.10
Hold time: 15 sec; Proposed local/peer: 15/15 sec
```

The table below describes the significant fields shown in the display.

Table 70: show mpls ldp discovery detail Field Descriptions

Field	Description
Local LDP Identifier	The LDP identifier for the local router. An LDP identifier is a 6-byte construct displayed in the form "IP address:number." By convention, the first four bytes of the LDP identifier constitute the router ID; integers, starting with 0, constitute the final two bytes of the IP address:number construct.
Interfaces	Lists the interfaces that are engaging in LDP discovery activity: <ul style="list-style-type: none"> • The xmit field--Indicates that the interface is sending LDP discovery hello packets. • The rcv field--Indicates that the interface is receiving LDP discovery hello packets. • The (LDP) or (TDP) field--Indicates the Label Distribution Protocol or Tag Distribution Protocol configured for the interface. The LDP (or TDP) identifiers indicate the LDP (or TDP) neighbors discovered on the interface.
Interface config, IGP config;	Describes how LDP is enabled: <ul style="list-style-type: none"> • Interface config--Enabled by the mpls ip command. • IGP config--Enabled by the mpls ldp autoconfig command. • Interface config, IGP config;--Enabled by the mpls ip command and the mpls ldp autoconfig command.
Hello interval	Period of time (in milliseconds) between the sending of consecutive hello messages.
Transport IP addr	Specifies that the interface address should be advertised as the transport address in the LDP discovery hello messages.
LDP Id	LDP ID of the peer router.
Src IP addr	Source IP address of the local router.
Transport IP addr	Specifies that the named IP address should be advertised as the transport address in the LDP discovery hello messages sent on an interface.
Hold time	Period of time (in seconds) a discovered LDP neighbor is remembered without receipt of an LDP hello message from the neighbor.
Proposed local/peer	Hold times (in seconds) proposed for LDP hello timer by the local router and the peer router. LDP uses the lower of these two values as the hold time.

The following is sample output from the **show mpls ldp discovery detail** command, which displays information related to LDP MD5 passwords. Information related to MD5 passwords is pointed out in bold text in the output.

```
Router# show mpls ldp discovery detail
Local LDP Identifier:
 10.10.10.10:0
Discovery Sources:
Interfaces:
  Ethernet1/0 (ldp): xmit/recv
    Hello interval: 5000 ms; Transport IP addr: 10.10.10.10
    LDP Id: 10.4.4.4:0
    Src IP addr: 10.0.20.4; Transport IP addr: 10.4.4.4
    Hold time: 15 sec; Proposed local/peer: 15/15 sec

Password: not required, none, stale      <-- LDP MD5 password information
Targeted Hellos:
 10.10.10.10 -> 10.3.3.3 (ldp): passive, xmit/recv
    Hello interval: 10000 ms; Transport IP addr: 10.10.10.10
    LDP Id: 10.3.3.3:0
    Src IP addr: 10.3.3.3; Transport IP addr: 10.3.3.3
    Hold time: 90 sec; Proposed local/peer: 90/90 sec

Password: required, neighbor, in use     <-- LDP MD5 password information
```

Password information displayed by this command includes:

- Password requirement for the neighbor (required or not required).
- Password source in the current configuration. The source is described by one of the following:
 - neighbor--The password for the neighbor is retrieved from the **mpls ldp neighbor [vrf vrf-name] ip-address password [0 | 7] password** command. The *ip-address* argument is the router ID of the neighbor.
 - num--The password for the neighbor is retrieved from **mpls ldp [vrf vrf-name] password option number for acl [0 | 7] password** command. The *number* argument is a number from 1 to 32767. The *acl* argument is the name or number of an IP standard access list that permits the neighbor router ID.
 - fallback--The password for the neighbor is retrieved from **mpls ldp [vrf vrf-name] password fallback password** command.
 - none--No password is configured for this neighbor.
- Password used by LDP sessions established with the neighbor is from current or previous configuration (in use or stale).

Related Commands

Command	Description
mpls label protocol (global configuration)	Specifies the LDP or TDP to be used on a platform.
mpls label protocol (interface configuration)	Specifies the LDP or TDP to be used on a given interface.
mpls ldp neighbor password	Configures a password key for computing MD5 checksums for the session TCP connection with the specified neighbor.
mpls ldp neighbor password fallback	Configures an MD5 password for LDP sessions with peers.

Command	Description
mpls ldp neighbor password option	Configures an MD5 password for LDP sessions with neighbors whose LDP router IDs are permitted by a specified access list.
mpls ldp neighbor password required	Specifies that LDP must use a password when establishing a session between LDP peers.
mpls ldp neighbor password rollover duration	Configures the duration before the new password takes effect on an MPLS label switch router (LSR).
show mpls interfaces	Displays information about one or more interfaces that have been configured for label switching.
show mpls ldp neighbor	Displays the status of LDP sessions.
show mpls ldp neighbor password	Displays password information used in established LDP sessions.

show mpls ldp graceful-restart

To display a summary of the Label Distribution Protocol (LDP) Graceful Restart status, use the **show mpls ldp graceful-restart** command in user EXEC or privileged EXEC mode.

show mpls ldp graceful-restart

Syntax Description

This command has no arguments or keywords.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.0(29)S	This command was introduced.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.3(14)T	This command was integrated into Cisco IOS Release 12.3(14)T.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Usage Guidelines

This command shows the following information about LDP sessions:

- Configured parameters.
- The state of the LDP sessions (for which Graceful Restart was negotiated during initialization).
- The list of LDP sessions for which graceful recovery is pending. However, the router has retained the state information from those neighbors.

Examples

The following example shows a summary of the LDP Graceful Restart settings and configuration:

```
Router# show mpls ldp graceful-restart
LDP Graceful Restart is enabled
Neighbor Liveness Timer: 5 seconds
Max Recovery Time: 200 seconds
Down Neighbor Database (0 records):
Graceful Restart-enabled Sessions:
VRF default:
  Peer LDP Ident: 10.18.18.18:0, State: estab
  Peer LDP Ident: 10.17.17.17:0, State: estab
```

The table below describes the significant fields shown in the display.

Table 71: show mpls ldp graceful-restart Field Descriptions

Field	Description
Neighbor Liveness Timer	The number of seconds the neighbor liveness timer is set for.
Max Recovery Time	The number of seconds the maximum recovery timer is set for.
Down Neighbor Database	Information about the down (failed or restarting) LDP neighbor.
Graceful Restart-enabled Sessions	Information about the LDP sessions that are enabled for Graceful Restart.
Peer LDP Ident	The LDP ID of the provider edge (PE) neighbor.
State	The state of the session with the neighbor.

Related Commands

Command	Description
show mpls ldp neighbor	Displays the status of LDP sessions.

show mpls ldp igp sync

To display the status of the Multiprotocol Label Switching (MPLS) Label Distribution Protocol (LDP)-Interior Gateway Protocol (IGP) synchronization process, use the **show mpls ldp igp sync** command in user EXEC or privileged EXEC mode.

```
show mpls ldp igp sync [{all | interface type-number | vrf vrf-name}]
```

Syntax Description	all	(Optional) Displays all the MPLS LDP-IGP synchronization information available.
	interface <i>type-number</i>	(Optional) Displays the MPLS LDP-IGP synchronization information for the specified interface.
	vrf <i>vrf-name</i>	(Optional) Displays the MPLS LDP-IGP synchronization information for the specified Virtual Private Network (VPN) routing and forwarding instance (<i>vpn-name</i>).

Command Default If an optional argument is not specified, this command displays LDP synchronization for all interfaces enabled for MPLS LDP-IGP synchronization.

Command Modes

User EXEC(>)
Privileged EXEC(#)

Command History	Release	Modification
	12.0(30)S	This command was introduced.
	12.3(14)T	This command was integrated into Cisco IOS Release 12.3(14)T.
	12.0(32)S	This command was integrated into Cisco IOS Release 12.0(32)S. The output of this command was changed to display the configured delay time and the time remaining on the delay timer.
	12.4(12)	This command was integrated into Cisco IOS Release 12.4(12).
	12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
	12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
	Cisco IOS XE Release 3.6S	This command was implemented on the Cisco ASR 903 series routers.

Examples

The following is sample output from the **show mpls ldp igp sync** command when LDP-IGP synchronization is not enabled on an interface:

```
Router# show mpls ldp igp sync
Ethernet0/0:
  LDP configured; SYNC enabled.
```

```

SYNC status: sync achieved; peer reachable.
IGP holddown time: infinite.
Peer LDP Ident: 10.130.0.1:0
IGP enabled: OSPF 1

```

The table below describes the significant fields shown in the display.

Table 72: show mpls ldp igp sync Field Descriptions

Field	Description
Ethernet0/0	Interface name and type.
LDP configured	Label Distribution Protocol is configured.
SYNC enabled	Synchronization is active.
SYNC status	Synchronization is successful. Note Peer reachable is an LDP internal state used only for MPLS LDP synchronization. Do not use it to verify that LDP can reach the peer or to troubleshoot LDP functionality.
IGP holddown time	Interior Gateway Protocol hold-down time. • Infinite--No specific time is set.
Peer LDP Ident	IP address of the peer.
IGP enabled	Interior Gateway Protocol is enabled for the specified Open Shortest Path First (OSPF) protocol.

If LDP-IGP synchronization is not enabled on an interface, the output looks like the following:

```

Router# show mpls ldp igp sync
Ethernet5/1:
  LDP configured; LDP-IGP Synchronization not enabled.

```

The following is sample output from the **show mpls ldp igp sync** command when you configured a time delay for MPLS LDP-IGP synchronization:

```

Router# show mpls ldp igp sync
Ethernet0/0:
  LDP configured; LDP-IGP Synchronization enabled.
  Sync status: sync achieved; peer reachable.
  Sync delay time: 20 seconds (10 seconds left)
  IGP holddown time: infinite.
  IGP enabled: OSPF 1

```

Related Commands

Command	Description
debug mpls ldp igp sync	Displays events related to MPLS LDP -IGP synchronization.
mpls ldp igp sync	Enables MPLS LDP-IGP synchronization on an interface that belongs to an OSPF process.

Command	Description
mpls ldp igp sync holddown	Specifies how long an IGP should wait for LDP synchronization to be achieved.
mpls ldp sync	Enables MPLS LDP-IGP synchronization on interfaces for an OSPF process or an IS-IS process.

show mpls ldp neighbor

To display the status of Label Distribution Protocol (LDP) sessions, use the **show mpls ldp neighbor** command in user EXEC or privileged EXEC mode.

```
show mpls ldp neighbor [{vrf vrf-name | all}] [{addressinterface}] [detail] [graceful-restart]
[capabilities]
```

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the LDP neighbors for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance.
all	(Optional) Displays LDP neighbor information for all VPNs, including those in the default routing domain.
<i>address</i>	(Optional) IP address of this neighbor.
<i>interface</i>	(Optional) Interface over which the LDP neighbors are accessible.
detail	(Optional) Displays information in long form, including password information for this neighbor.
graceful-restart	(Optional) Displays per-neighbor graceful restart information.
capabilities	(Optional) Displays LDP announce and receive information for an LDP neighbor.

Command Default

This command displays information about LDP neighbors for the default routing domain if you do not specify the optional **vrf** keyword.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
11.1CT	This command was introduced.
12.0(10)ST	The command was modified to reflect Multiprotocol Label Switching (MPLS) IETF command syntax and terminology.
12.0(14)ST	This command was modified to reflect MPLS VPN support for LDP and the vrf and all keywords were added.
12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
12.0(26)S	This command was modified. The detail keyword was updated to display information about inbound filtering.

Release	Modification
12.2(25)S	This command was modified. The graceful-restart keyword was added.
12.3(14)T	This command was modified. The command output was updated so that the detail keyword displays information about MPLS LDP Session Protection.
12.2(18)SXE	This command was integrated into Cisco IOS Release 12.2(18)SXE.
12.2(28)SB	This command was modified. The detail keyword was updated to include Message Digest 5 (MD5) password information and the command was implemented on the Cisco 10000 series routers.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.0(33)S	This command was integrated into Cisco IOS Release 12.0(33)S.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.
12.2(33)SRE4	The command was modified. The detail keyword displays LDP capabilities announce and receive information. The capabilities keyword was added.

Usage Guidelines

The **show mpls ldp neighbor** command can provide information about all LDP neighbors, or the information can be limited to the following:

- Neighbor with specific IP address
- LDP neighbors known to be accessible over a specific interface



Note This command displays information about LDP and Tag Distribution Protocol (TDP) neighbor sessions.

Examples

The following is sample output from the **show mpls ldp neighbor** command:

```
Device# show mpls ldp neighbor

Peer LDP Ident: 10.0.7.7:2; Local LDP Ident 10.1.1.1:1
TCP connection: 10.0.7.7.11032 - 10.1.1.1.646
State: Oper; Msgs sent/rcvd: 5855/6371; Downstream on demand
Up time: 13:15:09
LDP discovery sources:
  ATM3/0.1
Peer LDP Ident: 10.1.1.1:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.1.1.1.646 - 10.1.1.1.11006
State: Oper; Msgs sent/rcvd: 4/411; Downstream
Up time: 00:00:52
LDP discovery sources:
  Ethernet1/0/0
Addresses bound to peer LDP Ident:
  10.0.0.29      10.1.1.1      10.0.0.199     10.10.1.1
  10.205.0.9
```

The following is sample output from the **show mpls ldp neighbor** command, in which duplicate addresses are detected. They indicate an error because a given address should be bound to only one peer.

```
Device# show mpls ldp neighbor

Peer LDP Ident: 10.0.7.7:2; Local LDP Ident 10.1.1.1:1
  TCP connection: 10.0.7.7.11032 - 10.1.1.1.646
  State: Oper; Msgs sent/rcvd: 5855/6371; Downstream on demand
  Up time: 13:15:09
  LDP discovery sources:
    ATM3/0.1
Peer LDP Ident: 10.1.1.1:0; Local LDP Ident 10.1.1.1:0
  TCP connection: 10.1.1.1.646 - 10.1.1.1.11006
  State: Oper; Msgs sent/rcvd: 4/411; Downstream
  Up time: 00:00:52
  LDP discovery sources:
    Ethernet1/0/0
  Addresses bound to peer LDP Ident:
    10.0.0.29 10.1.1.1 10.0.0.199 10.10.1.1
    10.205.0.9
  Duplicate Addresses advertised by peer:
    10.10.8.111
```

The following is sample output from the **show mpls ldp neighbor vrf vpn10** command, which displays the LDP neighbor information for the specified VPN routing and forwarding instance named vpn10:

```
Device# show mpls ldp neighbor vrf vpn10

Peer LDP Ident:10.14.14.14:0; Local LDP Ident 10.29.0.2:0
  TCP connection:10.14.14.14.646 - 10.29.0.2.11384
  State:Oper; Msgs sent/rcvd:1423/800; Downstream
  Up time:02:38:11
  LDP discovery sources:
    ATM3/0/0.10
  Addresses bound to peer LDP Ident:
    10.3.36.9      10.7.0.1      10.14.14.14    10.13.0.1
    10.15.0.1      10.17.0.1      10.19.0.1      10.21.0.1
    10.23.0.1      10.25.0.1      10.27.0.1      10.29.0.1
    10.31.0.1      10.33.0.1      10.35.0.1      10.37.0.1
    10.39.0.1      10.41.0.1      10.43.0.1      10.45.0.1
    10.47.0.1      10.49.0.1      10.51.0.1      10.53.0.1
    10.55.0.1      10.57.0.1      10.59.0.1      10.61.0.1
    10.63.0.1      10.65.0.1      10.67.0.1      10.69.0.1
    10.71.0.1      10.73.0.1      10.75.0.1      10.77.0.1
    10.79.0.1      10.81.0.1      10.83.0.1      10.85.0.1
    10.87.0.1      10.89.0.1      10.91.0.1      10.93.0.1
    10.95.0.1      10.97.0.1      10.99.0.1      10.101.0.1
    10.103.0.1     10.105.0.1     10.107.0.1     10.109.0.1
    10.4.0.2       10.3.0.2
```

The following is sample output from the **show mpls ldp neighbor vrf vpn1 detail** command, which displays information about inbound filtering:

```
Device# show mpls ldp neighbor vrf vpn1 detail

Peer LDP Ident: 10.13.13.13:0; Local LDP Ident 10.33.0.2:0
  TCP connection: 10.13.13.13.646 - 10.33.0.2.31581
  State: Oper; Msgs sent/rcvd: 11/10; Downstream; Last TIB rev sent 13
  Up time: 00:02:25; UID: 26; Peer Id 0;
```



```

LDP discovery sources:
  Ethernet1/0/2; Src IP addr: 10.33.0.1
    holdtime: 15000 ms, hello interval: 5000 ms
Addresses bound to peer LDP Ident:
  10.3.105.1      10.13.13.13      10.33.0..1
Peer holdtime: 180000 ms; KA interval: 60000 ms; Peer state: estab
LDP inbound filtering accept acl:1
Peer LDP Ident: 10.14.14.14:0; Local LDP Ident 10.33.0.2:0
TCP connection: 10.14.14.14.646 - 10.33.0.2.31601
State: Oper; Msgs sent/rcvd: 10/9; Downstream; Last TIB rev sent 13
Up time: 00:01:17; UID: 29; Peer Id 3;
LDP discovery sources:
  Ethernet1/0/3; Src IP addr: 10.33.0.1
    holdtime: 15000 ms, hello interval: 5000 ms
Addresses bound to peer LDP Ident:
  10.3.104.1      10.14.14.14      10.32.0.1
Peer holdtime: 180000 ms; KA interval: 60000 ms; Peer state: estab
NSR: Not Ready
Capabilities Sent:
  [ICCP (type 0x0405) MajVer 1 MinVer 0]
  [Dynamic Announcement (0x0506)]
  [mLDP Point-to-Multipoint (0x0508)]
  [mLDP Multipoint-to-Multipoint (0x0509)]
  [Typed Wildcard (0x050B)]
Capabilities Received:
  [ICCP (type 0x0405) MajVer 1 MinVer 0]
  [Dynamic Announcement (0x0506)]
  [mLDP Point-to-Multipoint (0x0508)]
  [mLDP Multipoint-to-Multipoint (0x0509)]
  [Typed Wildcard (0x050B)]
LDP inbound filtering accept acl:1

```

The following is sample output from the **show mpls ldp neighbor all** command, which displays the LDP neighbor information for all VPN routing and forwarding instances, including those in the default routing domain. In this example, note that the same neighbor LDP ID (10.14.14.14) appears in all the listed VRF interfaces, highlighting the fact that the same IP address can coexist in different VPN routing and forwarding instances.

```

Device# show mpls ldp neighbor all

Peer TDP Ident:10.11.11.11:0; Local TDP Ident 10.12.12.12:0
  TCP connection:10.11.11.11.711 - 10.12.12.12.11003
  State:Oper; PIEs sent/rcvd:185/187; Downstream
  Up time:02:40:02
  TDP discovery sources:
    ATM1/1/0.1
  Addresses bound to peer TDP Ident:
    10.3.38.3      10.1.0.2      10.11.11.11
VRF vpn1:
  Peer LDP Ident:10.14.14.14:0; Local LDP Ident 10.7.0.2:0
  TCP connection:10.14.14.14.646 - 10.7.0.2.11359
  State:Oper; Msgs sent/rcvd:952/801; Downstream
  Up time:02:38:49
  LDP discovery sources:
    ATM3/0/0.1
  Addresses bound to peer LDP Ident:
    10.3.36.9      10.7.0.1      10.14.14.14      10.13.0.1
    10.15.0.1      10.17.0.1      10.19.0.1      10.21.0.1
    10.23.0.1      10.25.0.1      10.27.0.1      10.29.0.1
    10.31.0.1      10.33.0.1      10.35.0.1      10.37.0.1
    10.39.0.1      10.41.0.1      10.43.0.1      10.45.0.1
    10.47.0.1      10.49.0.1      10.51.0.1      10.53.0.1
    10.55.0.1      10.57.0.1      10.59.0.1      10.61.0.1

```

show mpls ldp neighbor

```

10.63.0.1      10.65.0.1      10.67.0.1      10.69.0.1
10.71.0.1      10.73.0.1      10.75.0.1      10.77.0.1
10.79.0.1      10.81.0.1      10.83.0.1      10.85.0.1
10.87.0.1      10.89.0.1      10.91.0.1      10.93.0.1
10.95.0.1      10.97.0.1      10.99.0.1      10.101.0.1
10.103.0.1     10.105.0.1     10.107.0.1     10.109.0.1
10.4.0.2       10.3.0.2

VRF vpn2:
Peer LDP Ident:10.14.14.14:0; Local LDP Ident 10.13.0.2:0
TCP connection:10.14.14.14.646 - 10.13.0.2.11361
State:Oper; Msgs sent/rcvd:964/803; Downstream
Up time:02:38:50
LDP discovery sources:
  ATM3/0/0.2
Addresses bound to peer LDP Ident:
10.3.36.9      10.7.0.1      10.14.14.14    10.13.0.1
10.15.0.1      10.17.0.1     10.19.0.1      10.21.0.1
10.23.0.1      10.25.0.1     10.27.0.1      10.29.0.1
10.31.0.1      10.33.0.1     10.35.0.1      10.37.0.1
10.39.0.1      10.41.0.1     10.43.0.1      10.45.0.1
10.47.0.1      10.49.0.1     10.51.0.1      10.53.0.1
10.55.0.1      10.57.0.1     10.59.0.1      10.61.0.1
10.63.0.1      10.65.0.1     10.67.0.1      10.69.0.1
10.71.0.1      10.73.0.1     10.75.0.1      10.77.0.1
10.79.0.1      10.81.0.1     10.83.0.1      10.85.0.1
10.87.0.1      10.89.0.1     10.91.0.1      10.93.0.1
10.95.0.1      10.97.0.1     10.99.0.1      10.101.0.1
10.103.0.1     10.105.0.1    10.107.0.1     10.109.0.1
10.4.0.2       10.3.0.2

VRF vpn3:
Peer LDP Ident:10.14.14.14:0; Local LDP Ident 10.15.0.2:0
TCP connection:10.14.14.14.646 - 10.15.0.2.11364
State:Oper; Msgs sent/rcvd:1069/800; Downstream
Up time:02:38:52
LDP discovery sources:
  ATM3/0/0.3
Addresses bound to peer LDP Ident:
10.3.36.9      10.17.0.1     10.14.14.14    10.13.0.1
10.15.0.1      10.17.0.1     10.19.0.1      10.21.0.1
10.23.0.1      10.25.0.1     10.27.0.1      10.29.0.1
10.31.0.1      10.33.0.1     10.35.0.1      10.37.0.1
10.39.0.1      10.41.0.1     10.43.0.1      10.45.0.1
10.47.0.1      10.49.0.1     10.51.0.1      10.53.0.1
10.55.0.1      10.57.0.1     10.59.0.1      10.61.0.1
10.63.0.1      10.65.0.1     10.67.0.1      10.69.0.1
10.71.0.1      10.73.0.1     10.75.0.1      10.77.0.1
10.79.0.1      10.81.0.1     10.83.0.1      10.85.0.1
10.87.0.1      10.89.0.1     10.91.0.1      10.93.0.1
10.95.0.1      10.97.0.1     10.99.0.1      10.101.0.1
10.103.0.1     10.105.0.1    10.107.0.1     10.109.0.1
10.4.0.2       10.3.0.2

VRF vpn4:
Peer LDP Ident:10.14.14.14:0; Local LDP Ident 10.17.0.2:0
TCP connection:10.14.14.14.646 - 10.17.0.2.11366
State:Oper; Msgs sent/rcvd:1199/802; Downstream

```

The following is sample output from the **show mpls ldp neighbor graceful-restart** command, which shows the Graceful Restart status of the LDP neighbors:

```

Device# show mpls ldp neighbor graceful-restart

Peer LDP Ident: 10.20.20.20:0; Local LDP Ident 10.17.17.17:0
TCP connection: 10.20.20.20.16510 - 10.17.17.17.646

```

```

State: Oper; Msgs sent/rcvd: 8/18; Downstream
Up time: 00:04:39
Graceful Restart enabled; Peer reconnect time (msecs): 120000
Peer LDP Ident: 10.19.19.19:0; Local LDP Ident 10.17.17.17:0
TCP connection: 10.19.19.19.11007 - 10.17.17.17.646
State: Oper; Msgs sent/rcvd: 8/38; Downstream
Up time: 00:04:30
Graceful Restart enabled; Peer reconnect time (msecs): 120000
    
```

The following sample output from the **show mpls ldp neighbor detail** command, which displays information about the MD5 password configuration:

```

Device# show mpls ldp neighbor detail

Peer LDP Ident: 10.3.3.0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.3.3.3.11018 - 10.1.1.1.646
Password: required, neighbor, in use
State: Oper; Msgs sent/rcvd: 167/167; Downstream; Last TIB rev sent 9
Up time: 02:24:02; UID: 5; Peer Id 3;
LDP discovery sources:
  Targeted Hello 10.1.1.1 -> 10.3.3.3, passive;
    holdtime: 90000 ms, hello interval: 10000 ms
Addresses bound to peer LDP Ident:
  10.3.3.3      10.0.30.3
Peer holdtime: 180000 ms; KA interval: 60000 ms; Peer state: estab
Peer LDP Ident: 10.4.4.4:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.4.4.4.11017 - 10.1.1.1.646
Password: not required, none, stale
State: Oper; Msgs sent/rcvd: 9/9; Downstream; Last TIB rev sent 9
Up time: 00:05:35; UID: 6; Peer Id 1;
LDP discovery sources:
  Ethernet1/0; Src IP addr: 10.0.20.4
    holdtime: 15000 ms, hello interval: 5000 ms
Addresses bound to peer LDP Ident:
  10.0.40.4      10.4.4.4      10.0.20.4
Peer holdtime: 180000 ms; KA interval: 60000 ms; Peer state: estab
    
```

The table below describes the significant fields shown in the displays.

Table 73: show mpls ldp neighbor Field Descriptions

Field	Description
Peer LDP Ident	LDP (or TDP) identifier of the neighbor (peer) for this session.
Local LDP Ident	LDP (or TDP) identifier for the local label switch router (LSR) for this session.
TCP connection	TCP connection used to support the LDP session, shown in the following format: <ul style="list-style-type: none"> • peer IP address.peer port • local IP address.local port

Field	Description
Password	Indicates if password protection is being used. Password status is as follows: <ul style="list-style-type: none"> • Required or not required—Indicates whether password configuration is required. • Neighbor, none, option #, or fallback—Indicates the password source when the password was configured. • In use (current) or stale (previous)—Indicates the current LDP session password usage status.
State	State of the LDP session. Generally, this is Oper (operational), but transient is another possible state.
Msgs sent/rcvd	Number of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintenance of the LDP session.
Downstream on demand	Indicates that the Downstream on Demand method of label distribution is being used for this LDP session. When the Downstream on Demand method is used, an LSR advertises its locally assigned (incoming) labels to its LDP peer only when the peer requests them.
Downstream	Indicates that the downstream method of label distribution is being used for this LDP session. When the downstream method is used, an LSR advertises all of its locally assigned (incoming) labels to its LDP peer (subject to any configured access list restrictions).
Up time	Length of time (in hours, minutes, seconds) the LDP session has existed.
Graceful Restart enabled	Indicates whether the LDP session has Graceful Restart enabled.
Peer reconnect time	The length of time, in milliseconds (ms), the peer device waits for a device to reconnect.
LDP discovery sources	Sources of LDP discovery activity that led to the establishment of this LDP session.
Targeted Hello	Lists the platforms to which targeted hello messages are being sent: <ul style="list-style-type: none"> • The active field indicates that this LSR has initiated targeted hello messages. • The passive field indicates that the neighbor LSR has initiated targeted hello messages and that this LSR is configured to respond to the targeted hello messages from the neighbor.
holdtime	Period of time, in milliseconds (ms), a discovered LDP neighbor is remembered without receipt of an LDP hello message from the neighbor.
hello interval	Period of time, in milliseconds (ms), between the sending of consecutive hello messages.

Field	Description
Addresses bound to peer LDP Ident	Known interface addresses of the LDP session peer. These are addresses that might appear as “next hop” addresses in the local routing table. They are used to maintain the Label Forwarding Information Base (LFIB).
Duplicate Addresses advertised by peer	IP addresses that are bound to another peer. They indicate an error because a given address should be bound to only one peer.
Peer holdtime	The time, in milliseconds (ms), that the neighbor session is retained without the receipt of an LDP message from the neighbor.
KA Interval	Keepalive interval. The amount of time, in milliseconds (ms), that a device lets pass without sending an LDP message to its neighbor. If this time elapses and the device has nothing to send, it sends a keepalive message.
Peer state	State of the peer; estab means established.
LDP inbound filtering accept acl: 1	Access list that is permitted for inbound label-binding filtering.

Related Commands

Command	Description
mpls ldp neighbor password	Configures a password key for computing MD5 checksums for the session TCP connection with the specified neighbor.
mpls ldp neighbor password fallback	Configures an MD5 password for LDP sessions with peers.
mpls ldp neighbor password option	Configures an MD5 password for LDP sessions with neighbors whose LDP device IDs are permitted by a specified access list.
mpls ldp neighbor password required	Specifies that LDP must use a password when establishing a session between LDP peers.
mpls ldp neighbor password rollover duration	Configures the duration before the new password takes effect on an MPLS LSR.
show mpls interfaces	Displays information about one or more interfaces that have been configured for label switching.
show mpls ldp discovery	Displays the status of the LDP discovery process.
show mpls ldp neighbor password	Displays password information used in established LDP sessions.

show mpls ldp neighbor password

To display password information used in established Label Distribution Protocol (LDP) sessions, use the **show mpls ldp neighbor password** command in user EXEC mode or privileged EXEC mode.

```
show mpls ldp neighbor [vrf vrf-name] [{ip-addressinterface}] password [{pending | current}]
[all]
```

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays the LDP neighbors for the specified Virtual Private Network (VPN) routing and forwarding (VRF) instance.
<i>ip-address</i>	(Optional) Identifies the neighbor that has this IP address.
<i>interface</i>	(Optional) Identifies the LDP neighbors accessible over this interface.
pending	(Optional) Displays LDP sessions whose password is different from that in the current configuration.
current	(Optional) Displays LDP sessions whose password is the same as that in the current configuration.
all	(Optional) When the all keyword is specified alone in this command, the command displays LDP password information for all neighbors in all VPNs, including those in the global routing table.

Command Default

If you do not specify an optional keyword for this command, password information for all established LDP sessions is displayed.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
12.2(28)SB	This command was introduced.
12.0(32)SY	This command was integrated into Cisco IOS Release 12.0(32)SY.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.0(33)S	This command was integrated into Cisco IOS Release 12.0(33)S.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.

Usage Guidelines

Use this command to display password information for established LDP sessions. If you do not specify an option, password information for all established LDP sessions is displayed. To display LDP sessions whose password is the same as that in the current configuration, use the **current** keyword with the command. To display LDP sessions whose password is different from that in the current configuration, use the **pending** keyword with the command.

Examples

The following is sample output from the **show mpls ldp neighbor password** command, which displays information for all established LDP sessions:

```
Router# show mpls ldp neighbor password
Peer LDP Ident: 10.4.4.4:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.4.4.4.11017 - 10.10.01.10.646
Password: not required, none, stale
State: Oper; Msgs sent/rcvd: 57/57
Peer LDP Ident: 10.3.3.3:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.3.3.3.11018 - 10.1.1.1.646
Password: required, neighbor, in use
State: Oper; Msgs sent/rcvd: 216/215
```

The following is sample output from the **show mpls ldp neighbor password pending** command, which displays information for LDP sessions whose passwords are different from those in the current configuration:

```
Router# show mpls ldp neighbor password pending
Peer LDP Ident: 10.4.4.4:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.4.4.4.11017 - 10.1.1.1.646
Password: not required, none, stale
State: Oper; Msgs sent/rcvd: 57/57
```

The following is sample output from the **show mpls ldp neighbor password current** command, which displays information for LDP sessions whose passwords are the same as those in the current configuration:

```
Router# show mpls ldp neighbor password current
Peer LDP Ident: 10.3.3.3:0; Local LDP Ident 10.1.1.1:0
TCP connection: 10.3.3.3.11018 - 10.1.1.1.646
Password: required, neighbor, in use
State: Oper; Msgs sent/rcvd: 216/215
```

The table below describes the significant fields shown in the displays.

Table 74: show mpls ldp neighbor password Field Descriptions

Field	Description
Peer LDP Ident	LDP identifier of the neighbor (peer) for this session.
Local LDP Ident	LDP identifier for the local label switch router (LSR) for this session.
TCP connection	TCP connection used to support the LDP session, shown in the following format: <ul style="list-style-type: none"> peer IP address.peer port local IP address.local port
Password	Indicates the password source and status. <ul style="list-style-type: none"> Required or not required indicates whether password configuration is required or not. Neighbor, none, option #, or fallback indicates the password source when the password was configured. None indicates that no password was configured. In use (current) or stale (previous) is the usage status of the current LDP session password.

Field	Description
State	State of the LDP session. Generally this is Oper (operational), but transient is another possible state.
Msgs sent/rcvd	Numbers of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintaining the LDP session.

Related Commands

Command	Description
mpls ldp neighbor password	Configures a password key for computing MD5 checksums for the session TCP connection with the specified neighbor.
mpls ldp password fallback	Configures an MD5 password for LDP sessions with peers.
mpls ldp password option	Configures an MD5 password for LDP sessions with neighbors whose LDP router IDs are permitted by a specified access list.
mpls ldp password required	Specifies that LDP must use a password when establishing a session between LDP peers.
mpls ldp password rollover duration	Configures the duration before the new password takes effect on an MPLS LSR.
show mpls interfaces	Displays information about one or more interfaces that have been configured for label switching.
show mpls ldp discovery	Displays the status of the LDP discovery process.
show mpls ldp neighbor	Displays the status of LDP sessions.
show mpls ldp neighbor password	Displays password information used in established LDP sessions.

show mpls ldp parameters

To display current Label Distribution Protocol (LDP) parameters, use the **show mpls ldp parameters** command in user EXEC or privileged EXEC mode.

show mpls ldp parameters

Syntax Description This command has no arguments or keywords.

Command Default This command displays LDP parameters.

Command Modes User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	11.1CT	This command was introduced.
	12.0(10)ST	This command was integrated into Cisco IOS Release 12.0(10)ST. The command was modified to reflect Multiprotocol Label Switching (MPLS) IETF command syntax and terminology.
	12.1(8a)E	This command was integrated into Cisco IOS Release 12.1(8a)E.
	12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T.
	12.0(22)S	This command was integrated into Cisco IOS Release 12.0(22)S.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB and implemented on the Cisco 10000-PRE2 router.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Examples

The following is sample output from the **show mpls ldp parameters** command:

```
Device# show mpls ldp parameters

Protocol version: 1
Downstream label pool: min label 16; max label 100000
Session hold time: 180 sec; keep alive interval: 60 sec
Discovery hello: holdtime: 15 sec; interval: 5 sec
Discovery targeted hello: holdtime: 180 sec; interval: 5 sec
LDP for targeted sessions; peer acl: 1
LDP initial/maximum backoff: 30/240 sec
Device#
```

The table below describes the significant fields shown in the display.

Table 75: show mpls ldp parameters Field Descriptions

Field	Description
Protocol version	Indicates LDP version running on the platform.
Downstream label pool	Describes the range of labels available to the platform to assign for label-switching purposes. The available labels range from the smallest label value (min label) to the largest label value (max label), with a modest number of labels at the low end of the range (reserved labels) reserved for diagnostic purposes.
Session hold time	Indicates the time (in seconds) to maintain an LDP session with an LDP peer without receiving LDP traffic or an LDP keepalive message from the peer.
keep alive interval	Indicates time (in seconds) between consecutive transmission of LDP keepalive messages to an LDP peer.
Discovery hello	Indicates time (in seconds) that a neighbor platform continues an LDP session without receiving an LDP hello message from the neighbor (hold time), and the seconds between the transmission of consecutive LDP hello messages to neighbors (interval).
Discovery targeted hello	Indicates the time a neighbor platform continues an LDP session when: <ol style="list-style-type: none"> 1. The neighbor platform is not directly connected to the device. 2. The neighbor platform has not sent an LDP hello message. This intervening interval is known as hold time. <p>This field also indicates the time interval between the transmission of consecutive hello messages to a neighbor not directly connected to the device.</p>
LDP for targeted sessions	Reports the parameters that have been set by the show mpls atm-ldp bindings command.
LDP initial/maximum backoff	Reports the parameters that have been set by the mpls ldp backoff command.

Related Commands

Command	Description
mpls ldp holdtime	Changes the time that an LDP session is maintained in the absence of LDP messages from the session peer.

show mpls memory

To display information about the Multiprotocol Label Switching (MPLS) Label Distribution Protocol memory usage, use the **show mpls memory** command in user EXEC or privileged EXEC mode.

show mpls memory [**all**] [{**component** *string* | **detailed**}]

Syntax Description	all	(Optional) Specifies all the related memory of other modules.
	component <i>string</i>	(Optional) Specifies the sorted output based on component names.
	detailed	(Optional) Specifies the details about the memory usage.

Command Modes

User EXEC(>)
Privileged EXEC(#)

Command History

Release	Modification
12.4(22)T	This command was introduced in a release earlier than Cisco IOS Release 12.4(22)T.
12.2(33)SRC	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SRC.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following is sample output from the **show mpls memory** command:

```
Router: show mpls memory
Allocator-Name                               In-use/Allocated          Count
-----
LFD: AToM pwid                               :          0/67232        ( 0%) [ 0] Chunk
LFD: FPI LBL                                 :         144/22424        ( 0%) [ 4] Chunk
LFD: LTE                                     :         192/35704        ( 0%) [ 4] Chunk
LFD: MOI DEAG                                :          96/22704        ( 0%) [ 3] Chunk
LFD: MOI DROP                                :          20/24208        ( 0%) [ 1] Chunk
LFD: RW NONE                                 :         160/36248        ( 0%) [ 4] Chunk
LSD: FPI FRR                                 :        22312/22424        ( 99%) [ 2]
LSD: FPI LBL                                 :        22312/22424        ( 99%) [ 2]
LSD: MOI DEAG                                :        23424/23536        ( 99%) [ 2]
LSD: MOI DROP                                :        13424/13536        ( 99%) [ 2]
LSD: RW NONE                                 :        36136/36248        ( 99%) [ 2]
LSD: intf                                    :        33512/33624        ( 99%) [ 2]
LSD: label tbl                               :        22704/35952        ( 63%) [ 516] Chunk
LSD: label tbl                               :          64/1800          ( 3%) [ 1] Chunk
MFI: Clnt CMsg                               :          0/65592        ( 0%) [ 0] Chunk
MFI: Clnt SMsg                               :        71200/131184        ( 54%) [ 4] Chunk
MFI: InfoReq                                 :          0/808           ( 0%) [ 0] Chunk
MFI: InfoRply                                :          0/65592        ( 0%) [ 0] Chunk
Total allocated: 0.629 Mb, 645 Kb, 661240 bytes
```

The table below describes the significant fields shown in the display.

Table 76: show mpls memory Field Descriptions

Field	Description
Allocator-Name	The specific name of the allocator.
In-use/Allocated	The details of usage of the allocators.
Count	The number of allocators used.

Related Commands

Command	Description
debug mpls ldp igp sync	Displays events related to MPLS LDP-IGP synchronization.
mpls ldp igp sync	Enables MPLS LDP-IGP synchronization on an interface that belongs to an OSPF process.
mpls ldp igp sync holddown	Specifies how long an IGP should wait for LDP synchronization to be achieved.
mpls ldp sync	Enables MPLS LDP-IGP synchronization on interfaces for an OSPF process or an IS-IS process.