



CHAPTER 3

TL1 Command Descriptions

This chapter provides specific information on TL1 commands and autonomous messages for the Cisco ONS 15454 and Cisco ONS 15327, Release 4.6, including:

- TL1 commands by category
- TL1 commands by card
- TL1 commands

For information on command components, such as parameters, see [Chapter 4, “TL1 Command Components.”](#)



Note

The terms "Unidirectional Path Switched Ring" and "UPSR" may appear in Cisco literature. These terms do not refer to using Cisco ONS 15xxx products in a unidirectional path switched ring configuration. Rather, these terms, as well as "Path Protected Mesh Network" and "PPMN," refer generally to Cisco's path protection feature, which may be used in any topological network configuration. Cisco does not recommend using its path protection feature in any particular topological network configuration.

3.1 TL1 Commands by Category

Table 3-1 *TL1 Commands by Category*

| Category | Command or Autonomous Message | |
|-------------------|---|--|
| BLSR | DLT-<MOD_RING> ED-<MOD_RING> ENT-<MOD_RING> | EX-SW-<OCN_BLSR> RTRV-<MOD_RING> RTRV-TRC-<OCN_BLSR> |
| Cross Connections | DLT-CRS-<PATH> ED-CRS-<PATH> ENT-CRS-<PATH> | RTRV-CRS RTRV-CRS-<PATH> |

Table 3-1 TL1 Commands by Category (continued)

| Category | Command or Autonomous Message | |
|---------------------------------|---|--|
| DWDM (Cisco ONS 15454 only) | DLT-FFP-CLNT DLT-LNK-<MOD2O> DLT-OSC DLT-WLEN ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OSC ED-OTS ED-TRC-CLNT ED-TRC-OCH ED-WDMANS ED-WLEN ENT-FFP-CLNT ENT-LNK-<MOD2O> ENT-OSC ENT-WLEN OPR-LASER-OTS OPR-LNK OPR-PROTN SW-CLNT | OPR-PROTN SW-OCH OPR-WDMANS RLS-LASER-OTS RLS-PROTN SW-CLNT RLS-PROTN SW-OCH RTRV-ALMTH-<MOD2> RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK RTRV-NE-WDMANS RTRV-OCH RTRV-OMS RTRV-OSC RTRV-OTS RTRV-PROTN SW-CLNT RTRV-PROTN SW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH RTRV-WDMANS RTRV-WLEN SET-ALMTH-<MOD2> |
| Environment | RTRV-ATTR-CONT RTRV-ATTR-ENV | SET-ATTR-CONT SET-ATTR-ENV |
| Environment Alarms and Controls | OPR-ACO-ALL OPR-EXT-CONT REPT ALM ENV REPT EVT ENV | RLS-EXT-CONT RTRV-ALM-ENV RTRV-COND-ENV RTRV-EXT-CONT |
| Equipment | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT REPT ALM EQPT | REPT EVT EQPT RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Fault | REPT ALM <MOD2ALM> REPT ALM COM REPT EVT <MOD2ALM> REPT EVT COM | RTRV-ALM-ALL RTRV-COND-<MOD2ALM> RTRV-COND-ALL |
| File Transfer | APPLY COPY-RFILE REPT EVT FXFR | |

Table 3-1 *TL1 Commands by Category (continued)*

| Category | Command or Autonomous Message | |
|-----------------------|--|---|
| IOS | COPY-IOSCFG REPT EVT IOSCFG | |
| Log | ALW-MSG-DBCHG INH-MSG-DBCHG | REPT DBCHG RTRV-LOG |
| Network | RTRV-MAP-NETWORK RTRV-NE-IPMAP | |
| Paths | ED-<MOD_PATH> RTRV-<PATH> | RTRV-STS |
| Performance | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-TH-<MOD2> |
| Ports | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<OCN_TYPE> | RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |
| Security | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU | INH-MSG-SECU INH-USER-SECU REPT ALM SECU REPT EVT SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-SECUDFLT |
| SONET Line Protection | DLT-FFP-<OCN_TYPE> ED-FFP-<OCN_TYPE> ENT-FFP-<OCN_TYPE> OPR-PROTNSTW-<OCN_TYPE> | RLS-PROTNSTW-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-PROTNSTW-<OCN_TYPE> |
| Switch | RTRV-PROTNSTW-<PATH> | |

Table 3-1 TL1 Commands by Category (continued)

| Category | Command or Autonomous Message | |
|---------------------------|------------------------------------|------------------|
| Synchronization | ED-BITS | RLS-SYNCNSW |
| | ED-NE-SYNCCN | RTRV-ALM-BITS |
| | ED-SYNCCN | RTRV-ALM-SYNCCN |
| | OPR-SYNCNSW | RTRV-BITS |
| | REPT ALM BITS | RTRV-COND-BITS |
| | REPT ALM SYNCN | RTRV-COND-SYNCCN |
| | REPT EVT BITS | RTRV-NE-SYNCCN |
| | REPT EVT SYNCN | RTRV-SYNCCN |
| System | ALW-MSG-ALL | RTRV-HDR |
| | ED-DAT | RTRV-INV |
| | ED-NE-GEN | RTRV-NE-GEN |
| | ED-NE-PATH | RTRV-NE-PATH |
| | INH-MSG-ALL | RTRV-TOD |
| | INIT-SYS | SET-TOD |
| Test Access | CHG-ACCMD-<MOD_TACC> | DISC-TACC |
| | CONN-TACC-<MOD_TACC> | RTRV-TACC |
| Testing | OPR-LPBK-<MOD2> RLS-LPBK-<MOD2> | |
| Trace | RTRV-PTHTRC-<STS_PATH> | |
| UCP | DLT-UCP-CC | ENT-UCP-NBR |
| | DLT-UCP-IF | REPT ALM UCP |
| | DLT-UCP-NBR | REPT EVT UCP |
| | ED-UCP-CC | RTRV-ALM-UCP |
| | ED-UCP-IF | RTRV-COND-UCP |
| | ED-UCP-NBR | RTRV-UCP-CC |
| | ED-UCP-NODE | RTRV-UCP-IF |
| | ENT-UCP-CC | RTRV-UCP-NBR |
| | ENT-UCP-IF | RTRV-UCP-NODE |
| Path Protection Switching | REPT SW | |
| VCAT | DLT-VCG | RTRV-VCG |
| | ENT-VCG | |

3.2 TL1 Commands by Card (Cisco ONS 15454)

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454)*

| Card | Applicable Commands |
|--|---|
| AD-1B, AD-4B, AD-1C, AD-2C, AD-4C, MD-4, MUX-32, DMUX-32 | DLT-EQPT DLT-LNK-<MOD20> DLT-WLEN ED-EQPT ED-OCH (not for AD-1B, AD-4B) ED-LNK-<MOD20> ED-OMS (AD-1B, AD-4B, MD-4) ED-OTS (not for MD-4) ED-WDMANS ED-WLEN ENT-EQPT ENT-LNK-<MOD20> ENT-WLEN INIT-REG-<MOD2> OPR-LNK OPR-WDMANS REPT ALM WLEN REPT ALM <MOD2ALM> REPT EVT WLEN REPT EVT <MOD2ALM> REPT PM <MOD2> RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL RTRV-ALM-EQPT |
| AIC, AIC-I | DLT-EQPT ENT-EQPT INIT-SYS OPR-ACO-ALL OPR-EXT-CONT REPT ALM ENV REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT ENV REPT EVT EQPT REPT EVT <MOD2ALM> RLS-EXT-CONT RTRV-ALM-ALL |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|-----------------------------------|---|
| DS1, DS1N, DS3, DS3N, DS3E, DS3NE | ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-EQPT ED-NE-PATH ED-T1 (DS1) ED-T3 (DS1N, DS3, DS3N, DS3E, DS3NE) ED-VT1 (DS1) ENT-CRS-<PATH> ENT-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LPBK-<MOD2_IO> RMV-<MOD2_IO> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|---------------|---|
| DS3XM | ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-DS1 ED-EQPT ED-NE-PATH ED-T1 ED-T3 ED-VT1 ENT-CRS-<PATH> ENT-EQPT ENT-CRS-VT1 INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LPBK-<MOD2_IO> RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-CRS RTRV-CRS-<PATH> RTRV-DS1 RTRV-EQPT RTRV-INV RTRV-NE-PATH RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> RTRV-PMSCHED-<MOD2> RTRV-PTHTRC-<STS_PATH> RTRV-TACC RTRV-T1 RTRV-T3 RTRV-TH-<MOD2> RTRV-TH-ALL RTRV-VT RTRV-<PATH> SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| E100T, E1000T | DLT-EQPT ENT-EQPT INIT-SYS REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-EQPT RTRV-INV |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|-------------|--|
| EC1 | ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-EC1 ED-EQPT ED-NE-PATH ED-VT1 ENT-CRS-<PATH> ENT-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LPBK-<MOD2_IO> RMV-<MOD2_IO> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands | |
|-------------|---|---|
| FC-MR-4 | DLT-CRS-<PATH> DLT-EQPT DLT-VCG ED-<MOD_PATH> ED-CRS-<PATH> ED-FC ED-NE-PATH ENT-CRS-<PATH> ENT-EQPT ENT-VCG INIT-REG-FC INIT-SYS REPT ALM <MOD2ALM> REPT ALM EQPT REPT DBCHG REPT EVT <MOD2ALM> REPT EVT EQPT RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<PATH> RTRV-ALM-<MOD2ALM> | RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-FC RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-FC RTRV-CRS RTRV-CRS-<PATH> RTRV-EQPT RTRV-FC RTRV-INV RTRV-NE-PATH RTRV-POS RTRV-PROTNSTW-<PATH> RTRV-PTHTRC-<STS_PATH> RTRV-STS RTRV-TH-ALL RTRV-VCG SET-TH-<MOD2> |
| G1000-4 | DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-G1000 ED-NE-PATH ENT-CRS-<PATH> ENT-EQPT INIT-REG-G1000 INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> RLS-LPBK-<MOD2_IO> RLS-PROTNSTW-<PATH> RMV-<MOD2_IO> | RST-<MOD2_IO> RTRV-<PATH> RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-CRS RTRV-CRS-<PATH> RTRV-EQPT RTRV-G1000 RTRV-INV RTRV-NE-PATH RTRV-PROTNSTW-<PATH> RTRV-PTHTRC-<STS_PATH> RTRV-STS RTRV-TH-ALL |

Table 3-2 TL1 Commands by Card (Cisco ONS 15454) (continued)

| Card | Applicable Commands | |
|-----------------------------|--|---|
| ML1000-2, ML100T-12 | COPY-IOSCFG DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-NE-PATH ENT-CRS-<PATH> ENT-EQPT INIT-SYS REPT ALM EQPT REPT ALM <MOD2ALM> REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT IOSCFG REPT EVT <MOD2ALM> RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<PATH> | RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-CRS RTRV-CRS-<PATH> RTRV-EQPT RTRV-FSTE RTRV-GIGE RTRV-INV RTRV-NE-PATH RTRV-POS RTRV-PROTNSTW-<PATH> RTRV-PTHTRC-<STS_PATH> RTRV-STS RTRV-TH-ALL |
| MXP_2.5G_10G, TXP_MR_10G | DLT-EQPT DLT-FFP-CLNT ED-CLNT ED-DWDM ED-FFP-CLNT ED-OCH ED-SYNCN (MXP) ED-TRC-CLNT ENT-EQPT ENT-FFP-CLNT INIT-REG-CLNT INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNSTW-CLNT REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-PROTNSTW-CLNT RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL, | RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-ALMTH-<MOD2ALM> RTRV-CLNT RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-DWDM RTRV-EQPT RTRV-FFP-CLNT RTRV-INV RTRV-OCH RTRV-PM-<MOD2> RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-PROTNSTW-CLNT RTRV-SYNCN (MXP) RTRV-TH-<MOD2> RTRV-TRC-CLNT RTRV-TRC-OCH SCHED-PMREPT-<MOD2> SET-ALMTH-<MOD2> SET-ALMTH-EQPT SET-TH-<MOD2> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|-----------------------------------|---|
| OC12, OC12-4, OC48, OC48AS, OC192 | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-<MOD_RING> DLT-CRS-<PATH> DLT-EQPT DLT-FFP-<OCN_TYPE> DLT-UCP-CC DLT-UCP-IF ED-<MOD_PATH> ED-<MOD_RING> ED-CRS-<PATH> ED-FFP-<OCN_TYPE> ED-NE-PATH ED-UCP-CC ED-UCP-IF ED-VT1 ED-<OCN_TYPE> ENT-CRS-VT1 ENT-CRS-<PATH> ENT-EQPT ENT-FFP-<OCN_TYPE> ENT-UCP-CC ENT-UCP-IF EX-SW-<OCN_BLSR> INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNST-VT1 OPR-PROTNST-<OCN_TYPE> OPR-PROTNST-<PATH> OPR-SYNCNSW REPT ALM EQPT REPT ALM RING REPT ALM SYNCN REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT RING REPT EVT SYNCN REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LPBK-<MOD2_IO> RLS-PROTNST-<OCN_TYPE> RLS-PROTNST-<PATH> RLS-SYNCNSW RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-RING RTRV-ALM-SYNCS RTRV-ALM-<MOD2ALM> RTRV-<MOD_RING> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-COND-RING RTRV-CRS RTRV-CRS-<PATH> RTRV-EQPT RTRV-FFP-<OCN_TYPE> RTRV-INV RTRV-NE-IPMAP RTRV-NE-PATH RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> RTRV-PMSCHED-<MOD2> RTRV-PROTNST-<OCN_TYPE> RTRV-PROTNST-<PATH> RTRV-PROTNST-VT1 RTRV-PTHTRC-<STS_PATH> (OC48 AS, OC192) RTRV-TACC RTRV-TH-<MOD2> RTRV-TH-ALL RTRV-VT1 (OC48, OC48AS, OC192) RTRV-<OCN_TYPE> RTRV-<PATH> RTRV-TRC-<OCN_BLSR> RTRV-UCP-CC RTRV-UCP-IF SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|-------------|---|
| OC3, OC3-8 | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-VT1 DLT-CRS-<PATH> DLT-EQPT DLT-FFP-<OCN_TYPE> DLT-UCP-CC DLT-UCP-IF ED-<MOD_PATH> ED-<MOD_RING> ED-<OCN_TYPE> ED-CRS-<PATH> ED-FFP-<OCN_TYPE> ED-NE-PATH ED-UCP-CC ED-UCP-IF ENT-CRS-<PATH> ENT-EQPT ENT-FFP-<OCN_TYPE> ENT-UCP-CC ENT-UCP-IF EX-SW-<OCN_BLSR> (OC3-8) INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNST-<OCN_TYPE> OPR-PROTNST-<PATH> OPR-SYNCNSW REPT ALM EQPT REPT ALM SYNCN REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT SYNCN REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LPBK-<MOD2_IO> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|------------------|--|
| OPT-BST, OPT-PRE | DLT-EQPT DLT-LNK-<MOD20> DLT-OSC (OPT-BST) DLT-WLEN ED-EQPT ED-LNK-<MOD20> ED-OSC (OPT-BST) ED-OTS ED-WDMANS ED-WLEN ENT-EQPT ENT-LNK-<MOD20> ENT-WLEN INIT-REG-<MOD2> OPR-LASER-OTS OPR-LNK OPR-WDMANS REPT ALM RING (OPT-PRE) REPT ALM WLEN REPT ALM <MOD2ALM> REPT EVT OSC (OPT-PRE) REPT EVT WLEN REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-LASER-OTS RMV-<MOD2_IO> RST-<MOD2_IO> |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands | |
|-------------|--|---|
| OSCM, OSCMS | DLT-EQPT DLT-LNK-<MOD20> DLT-OSC DLT-WLEN ED-EQPT ED-LNK-<MOD20> ED-OSC ED-OTS ED-SYNCN ED-WDMANS ED-WLEN ED-<OCN_TYPE> ENT-EQPT ENT-LNK-<MOD20> ENT-WLEN INIT-REG-<MOD2> OPR-LNK OPR-WDMANS REPT ALM RING REPT ALM WLEN REPT ALM <MOD2ALM> REPT EVT OSC REPT EVT WLEN REPT EVT <MOD2ALM> REPT PM <MOD2> RMV-<MOD2_IO> RST-<MOD2_IO> | RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-OSC RTRV-ALM-WLEN RTRV-ALMTH-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-OSC RTRV-COND-WLEN RTRV-EQPT RTRV-INV RTRV-LNK-<MOD20> RTRV-OSC RTRV-OTS RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-SYNCN RTRV-TH-<MOD2> RTRV-<OCN_TYPE> RTRV-WDMANS RTRV-WLEN SCHED-PMREPT-<MOD2> SET-ALMTH-<MOD2> SET-ALMTH-EQPT SET-TH-<MOD2> |
| TCC2 | APPLY COPY-RFILE | REPT DBCHG REPT EVT FXFR |

Table 3-2 *TL1 Commands by Card (Cisco ONS 15454) (continued)*

| Card | Applicable Commands |
|------------------------------|--|
| TXP_MR_2.5G, TXPP_MR_2.5G | DLT-EQPT DLT-FFP-CLNT (TXP) ED-CLNT ED-DWDM ED-FFP-CLNT (TXP) ED-FFP-OCH (TXP-P) ED-OCH ED-TRC-OCH ENT-EQPT ENT-FFP-CLNT (TXP) INIT-REG-CLNT INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNST-CLNT (TXP) OPR-PROTNST-OCH (TXP-P) REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-PROTNST-CLNT (TXP) RLS-PROTNST-OCH (TXP-P) RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL |
| XC, XCVT, XC192 | ALW-Swdx-EQPT DLT-EQPT ENT-EQPT INH-Swdx-EQPT INIT-SYS REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> |
| XCVXL | REPT DBCHG |

3.3 TL1 Commands by Card (ONS 15327)

Table 3-3 *TL1 Commands by Card (Cisco ONS 15327)*

| Card | Applicable Commands |
|---------|---|
| XTC/DS1 | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-<PATH> ED-<MOD_PATH> ED-CRS-<PATH> ED-EQPT ED-T1 ENT-CRS-<PATH> ENT-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM RLS-LPBK-<MOD2_IO> RMV-<MOD2_IO> RST-<MOD2_IO> |

Table 3-3 *TL1 Commands by Card (Cisco ONS 15327) (continued)*

| Card | Applicable Commands |
|-------------|--|
| XTC/DS3 | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-CRS-<PATH> ED-<MOD_PATH> ED-CRS-<PATH> ED-EQPT ED-T3 ENT-CRS-<PATH> ENT-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM RLS-LPBK-<MOD2_IO> RMV-<MOD2_IO> |

Table 3-3 *TL1 Commands by Card (Cisco ONS 15327) (continued)*

| Card | Applicable Commands |
|-----------------|---|
| OC3, OC12, OC48 | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC DLT-<MOD_RING> (OC12, OC48) DLT-CRS-<PATH> DLT-EQPT DLT-FFP-<OCN_TYPE> ED-<MOD_PATH> ED-<MOD_RING> (OC12, OC48) ED-<OCN_TYPE> ED-CRS-<PATH> ED-FFP-<OCN_TYPE> ENT-<MOD_RING> (OC12, OC48) ENT-CRS-<PATH> ENT-EQPT ENT-FFP-<OCN_TYPE> EX-SW-<OCN_BLSR> (OC12, OC48) INIT-REG-<MOD2> INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNST-<OCN_TYPE> OPR-PROTNST-<PATH> OPR-SYNCNSW REPT ALM EQPT REPT ALM RING (OC12, OC48) REPT ALM SYNCN REPT ALM <MOD2ALM> REPT EVT EQPT REPT EVT RING (OC12, OC48) REPT EVT SYNCN REPT EVT <MOD2ALM> REPT PM RLS-LPBK-<MOD2_IO> RLS-PROTNST-<OCN_TYPE> |
| E100T, E1000T | DLT-EQPT ENT-EQPT INIT-SYS REPT ALM EQPT REPT ALM <MOD2ALM> REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM (E100T) |

Table 3-3 TL1 Commands by Card (Cisco ONS 15327) (continued)

| Card | Applicable Commands | |
|----------|---|--|
| XTC | APPLY COPY-RFILE DLT-EQPT ED-BITS ED-NE-GEN ED-NE-SYNCN ED-SYNCN ENT-EQPT INIT-SYS OPR-ACO-ALL OPR-SYNCNSW REPT ALM BITS REPT ALM EQPT REPT ALM SYNCN REPT ALM <MOD2ALM> REPT EVT BITS REPT EVT EQPT REPT EVT FXFR REPT EVT SYNCN | REPT EVT <MOD2ALM> RLS-SYNCNSW RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-<MOD2ALM> RTRV-BITS RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-<MOD2ALM> RTRV-EQPT RTRV-INV RTRV-NE-GEN RTRV-NE-SYNCN RTRV-SYNCN |
| G1000-2 | DLT-CRS-<PATH> DLT-EQPT ED-<MOD_PATH> ED-CRS-<PATH> ED-G1000 ENT-CRS-<PATH> ENT-EQPT INIT-REG-G1000 INIT-SYS OPR-LPBK-<MOD2_IO> REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> RLS-LPBK-<MOD2_IO> | RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<PATH> RTRV-ALM-ALL RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-CRS RTRV-CRS-<PATH> RTRV-EQPT RTRV-G1000 RTRV-INV RTRV-PTHTRC-<STS_PATH> |
| XTC/XCVT | ENT-EQPT INH-Swdx-EQPT INIT-SYS REPT ALM EQPT REPT ALM <MOD2ALM> REPT EVT EQPT REPT EVT <MOD2ALM> REPT SW RTRV-ALM-ALL | RTRV-ALM-EQPT RTRV-ALM-<MOD2ALM> RTRV-COND-ALL RTRV-COND-EQPT RTRV-COND-<MOD2ALM> RTRV-EQPT RTRV-INV SW-DX-EQPT |

Table 3-3 *TL1 Commands by Card (Cisco ONS 15327) (continued)*

| Card | Applicable Commands |
|-----------------------------|--|
| XTC/AIC | ENT-EQPT INIT-SYS OPR-EXT-CONT REPT ALM ENV REPT ALM EQPT REPT ALM <MOD2ALM> REPT EVT ENV REPT EVT EQPT REPT EVT <MOD2ALM> RLS-EXT-CONT RTRV-ALM-ALL RTRV-ALM-ENV RTRV-ALM-EQPT |
| MXP_2.5G_10G, TXP_MR_10G | DLT-EQPT DLT-FFP-CLNT ED-CLNT ED-DWDM ED-FFP-CLNT ED-OCH ED-SYNCN (MXP) ED-TRC-CLNT ENT-EQPT ENT-FFP-CLNT INIT-REG-CLNT INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNSW-CLNT REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-PROTNSW-CLNT RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL, |

Table 3-3 TL1 Commands by Card (Cisco ONS 15327) (continued)

| Card | Applicable Commands |
|------------------------------|--|
| TXP_MR_2.5G, TXPP_MR_2.5G | DLT-EQPT DLT-FFP-CLNT (TXP) ED-CLNT ED-DWDM ED-FFP-CLNT (TXP) ED-FFP-OCH (TXP-P) ED-OCH ED-TRC-OCH ENT-EQPT ENT-FFP-CLNT (TXP) INIT-REG-CLNT INIT-SYS OPR-LPBK-<MOD2_IO> OPR-PROTNST-CLNT (TXP) OPR-PROTNST-OCH (TXP-P) REPT ALM EQPT REPT ALM <MOD2ALM> REPT DBCHG REPT EVT EQPT REPT EVT <MOD2ALM> REPT PM <MOD2> RLS-PROTNST-CLNT (TXP) RLS-PROTNST-OCH (TXP-P) RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-ALM-ALL |

3.4 TL1 Commands

The commands and autonomous messages used for ONS 15454 and ONS 15327 are described in detail in this section and are listed alphabetically according to the first alpha character of the command string.

Each TL1 command must be less than or equal to 255 characters. Any command larger than 255 characters must be split into multiple commands. For example, if you use the ED-<MOD_PATH> command to edit the J1 EXPTRC/TRC message, path protection attributes, and TACC attributes and the command exceeds 255 characters the command will not be processed. You must use multiple ED-<MOD_PATH> commands instead.



Note The CTAG of any TL1 line mode command is a mandatory field in this TL1 release.



Note The AID definitions provided are supersets of the actual AID definitions.



Note TL1 commands that are entered incorrectly are not completed.

**Note**

In release 3.3 and later, the ACT-USER command will return a DENY without any error message. Any other command will return DENY with the PLNA (Login Not Active) error message.

3.4.1 ACT-USER: Activate User

This command set-ups a session with the Network Element (NE).

Notes:

1. Passwords are masked for the following security commands: ACT-USER, COPY-RFILE, COPY-IOSCFG, ED-PID, ENT-USER-SECU and ED-USER-SECU. Access to a TL1 session via any means will have the password masked. The CTC Request History and Message Log will also show the masked commands. When a password-masked command is re-issued by double-clicking the command from CTC Request History, the password will still be masked in the CTC Request History and Message Log. The actual password that was previously issued will be sent to the NE. To use a former command as a template only, single-click the command in CTC Request History. The command will be placed in the Command Request text box, where you can edit the appropriate fields prior to re-issuing it.
2. This command is backwards compatible with userids and passwords from ONS 15454 2.X software versions according to the following rules:

ACT-USER:[TID]:[STRING]:CTAG::[STRING]

- a. The syntax of the userid (first [STRING]) and the password (second [STRING]) are not checked.
- b. Invalid syntax for both the userid and password is permitted, but the user can only log in if the userid/password match what is in the database.
- c. The userid and password cannot exceed 10 characters.
3. For the ACT-USER command, it is required that no error code be transmitted except to convey that the login is granted or denied. Per TR-835, Appendix A, Section A.2:
“... the error codes corresponding to ACT ... do not apply to the ACT-USER command because this command requires that no error code be provided to the session request except to indicate that it has been denied. Before a session is established, a specific error code may reveal clues to an intruder attempting unauthorized entry.”

**Note**

Starting with this release (R4.6) the following feature can be turned on or off and the default is off: A new user must change his or her password after establishing a session for the first time before continuing. All TL1 commands except for ED-PID and CANC-USER will be denied until the password is changed. Once the password has been changed, a user can execute any command that his security level allows. If the user logs out without changing his password each following session will DENY all commands, except ED-PID and CANC-USER, until the password is changed.

| Section | ACT-USER Description |
|----------|----------------------|
| Category | System |
| Security | N/A |

| Section | ACT-USER Description |
|------------------|---|
| Related Messages | ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU |
| Input Format | ACT-USER:[<TID>]:<UID>:<CTAG>::<PID>; where: <ul style="list-style-type: none">• <UID> is the user identifier; <UID> is any combination of up to 10 alphanumeric characters. <UID> is a string and must not be null• <PID> is the user password; <PID> is any combination of up to 10 alphanumeric characters. <PID> is a string and must not be null Note CTC allows <UID> and <PID> of up to 20 characters. The 20 character CTC-entered <UID> and <PID> are not valid TL1 <UID> and <PID> |
| Input Example | ACT-USER:PETALUMA:TERRI:100::MYPASSWD; |
| Output Format | SID DATE TIME A CTAG COMPLD “<UID>:<LASTLOGINTIME>,<UNSUCCESSFULLOGINS>” ; where: <ul style="list-style-type: none">• <UID> userid of the person logging in; <UID> is a string• <LASTLOGINTIME> date and time of the last successful connection to the NE (not including current login); <LASTLOGINTIME> is a string• <UNSUCCESSFULLOGINS> number of unsuccessful login attempts since the last successful login; <UNSUCCESSFULLOGINS> is an integer |
| Output Example | TID-000 1998-06-20 14:30:00 A 001 COMPLD “TERRI:2003-01-02 14-04-49,0” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.2 ALW-MSG-ALL: Allow Message All

This command instructs the NE to enter a mode in which all the REPT ALM and REPT EVT autonomous messages are transmitted. See the INH-MSG-ALL command to inhibit these autonomous messages. When a TL1 session starts, the REPT ALM and REPT EVT messages are allowed by default.



If this command is issued twice in the same session, the SAAL (Status, Already Allowed) error message will be returned. The optional fields in the e block are not supported.

| Section | ALW-MSG-ALL Description |
|------------------|--|
| Category | System |
| Security | Retrieve |
| Related Messages | INH-MSG-ALL |
| Input Format | ALW-MSG-ALL:[<TID>]::<CTAG>[::,,]; |
| Input Example | ALW-MSG-ALL:PETALUMA::549; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.3 ALW-MSG-DBCHG: Allow Database Change Message

This command enables REPT DBCHG. When a TL1 session starts, the REPT DBCHG messages are not allowed by default.


Note

This command is not defined in the GR.

| Section | ALW-MSG-DBCHG Description |
|------------------|--|
| Category | Log |
| Security | Retrieve |
| Related Messages | INH-MSG-DBCHG REPT DBCHG |
| Input Format | ALW-MSG-DBCHG:[<TID>]::<CTAG>[::,,]; |
| Input Example | ALW-MSG-DBCHG:CISCO::123; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.4 ALW-MSG-SECU: Allow Message Security

This command enables REPT EVT SECU and REPT ALM SECU

| Section | ALW-MSG-SECU Description |
|----------|--------------------------|
| Category | Security |
| Security | Superuser |

| Section | ALW-MSG-SECU Description | |
|------------------|---|---|
| Related Messages | ACT-USER ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU | INH-MSG-SECU INH-USER-SECU REPT ALM SECU REPT EVT SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-SECUDFLT |
| Input Format | ALW-MSG-SECU:[<TID>]::<CTAG>; | |
| Input Example | ALW-MSG-SECU:PETALUMA::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.5 ALW-PMREPT-ALL: Allow Performance Report All

This command resumes processing all the PM reports that are inhibited. The allowance of the PM reporting is session-based, which means the command is only effective to the TL1 session that issues this command. REPT PM messages are inhibited by default for a session.

| Section | ALW-PMREPT-ALL Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> RTRV-PMSCHED-<MOD2> | RTRV-PMSCHED-ALL RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | ALW-PMREPT-ALL:[<TID>]::<CTAG>; | |
| Input Example | ALW-PMREPT-ALL:CISCONODE::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.6 ALW-Swdx-EQPT: Allow Switch Duplex Equipment

(Cisco ONS 15454 only)

This command allows automatic or manual switching on a duplex system containing duplexed or redundant equipment. To inhibit an NE switching to duplex, use the INH-Swdx-EQPT command.

ALW-Swdx-EQPT is not used for SONET line or electrical card protection switching. For SONET line or path protection switching commands, see OPR-PROTNSW and RLS-PROTNSW commands. For the electrical card protection switching, see the SW-TOWKG-EQPT and SW-TOPROTN-EQPT commands.



Note This command applies to the XC, XCVT, or XC10G equipment units only in this release.

| Section | ALW-Swdx-EQPT Description | |
|------------------|---|--|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT REPT ALM EQPT REPT EVT EQPT | REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | ALW-Swdx-EQPT:[<TID>]:<AID>:<CTAG>[::]; where: <ul style="list-style-type: none">• <AID> is the XC/XCVT/XC10G equipment AID from the “EQPT” section on page 4-27 | |
| Input Example | ALW-Swdx-EQPT:CISCO:SLOT-8:1234; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.7 ALW-SWTOPROTN-EQPT: Allow Switch to Protection Equipment

(Cisco ONS 15454 only)

This command allows automatic or manual switching of an equipment unit back to a protection status. Use the INH-SWTOPROTN-EQPT command to inhibit an NE from switching to protection.

ALW-SWTOPROTN-EQPT is used for non-SONET line cards (e.g. DS1, DS3, DS3XM, and EC1). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection. When this command is given to a working unit, the working unit will be allowed to switch to the protection unit. When this command is given to a protection unit, any working unit in the protection group is allowed to switch to the protection unit.

The standing condition of INHSWPR on the unit specified by the AID will be cleared.

Notes:

1. This command only supports one value of the <DIRN> parameter - BTH. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message should be responded.
2. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will receive an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-Swdx-EQPT commands.

3. This command is not used for SONET (OCN) cards. A command on a SONET card will receive an IIAC (Input, Invalid Access identifier) error message. To use a SONET card switching command, use OPR-PROTNSW and RLS-PROTNSW commands.
4. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message should be responded.
5. If this command is used on a card that is not in the inhibit state, the SAAL (Status, Already Allowed) error message should be responded.
6. The following situation(s) are allowed and will not generate any error response: Sending this command to missing cards so long as none of the previous error conditions apply.

| Section | ALW-SWTOPROTN-EQPT Description | |
|------------------|---|---|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-Swtoprottn-EQPT INH-Swtowkg-EQPT REPT ALM EQPT | REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | ALW-SWTOPROTN-EQPT:[<TID>]:<AID>:<CTAG>[::<DIRN>]; where: <ul style="list-style-type: none">• <AID> This parameter can either be the protection unit for which carrying traffic is to be allowed (release of lockout) or the working unit for which switching to protect is to be allowed (release of lock on); <AID> is from the “EQPT” section on page 4-27• <DIRN> is the direction of the switching. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56 | |
| Input Example | ALW-SWTOPROTN-EQPT:CISCO:SLOT-2:123::BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.8 ALW-SWTOWKG-EQPT: Allow Switch to Working Equipment

(Cisco ONS 15454 only)

This command allows automatic or manual switching of an equipment unit back to a working status. Use the INH-SWTOWKG-EQPT command to inhibit an NE from switching to working.

ALW-SWTOWKG-EQPT is used for non-SONET line cards (e.g. DS1, DS3, DS3XM, and EC1). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection.

When this command is given to a working unit, the working unit will be allowed to carry traffic. In the case of revertive protection, the traffic will switch immediately from the protection unit to the working unit regardless of the reversion time setting.

When this command is given to a protection unit, the protection unit will be allowed to switch back to the working unit currently protected as long as the working unit has not raised INHSWWKG. In the case of revertive protection, the traffic will switch immediately from the protection unit to the working unit regardless of the reversion time setting. In the case of non-revertive protection, the protection unit will continue to carry the traffic.

The standing condition of INHSWWKG on the unit specified by the AID will be cleared.

Notes:

1. This command only supports one value of the <DIRN> parameter - BTH. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message should be responded.
2. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will receive an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-SWDX-EQPT commands.
3. This command is not used for SONET (OCN) cards. A command on a SONET card will receive an IIAC (Input, Invalid Access Identifier) error message. To use a SONET card switching command, use the OPR-PROTNSW and RLS-PROTNSW commands.
4. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message should be responded.
5. If this command is used on a card that is not in the inhibit state, the SAAL (Status, Already Allowed) error message should be responded.
6. The following situation(s) are allowed and will not generate any error response: sending this command to missing cards as long as none of the previous error conditions apply.

| Section | ALW-SWTOWKG-EQPT Description | |
|------------------|--|---|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-SWDX-EQPT ALW-SWTOPROTN-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-SWDX-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT REPT ALM EQPT | REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |

| Section | ALW-SWTOWKG-EQPT Description |
|---------------|--|
| Input Format | ALW-SWTOWKG-EQPT:[<TID>]:<AID>:<CTAG>[::<DIRN>]; where: <ul style="list-style-type: none">• <AID> This parameter can either be the protection unit for which switching back to working is to be allowed (release of lock on) or the working unit for which carrying traffic is to be allowed (release of lockout); <AID> is from the “EQPT” section on page 4-27• <DIRN> is the direction of the switching. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56 |
| Input Example | ALW-SWTOWKG-EQPT:CISCO:SLOT-2:123::BTH; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.9 ALW-USER-SECU: Allow User Security

This command enables a userid that has been disabled (e.g., via the INH-USER-SECU command) so the user can establish a session with the NE.

| Section | ALW-USER-SECU Description | |
|------------------|---|---|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER ALW-MSG-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU | INH-MSG-SECU INH-USER-SECU REPT ALM SECU REPT EVT SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-SECUDFLT |
| Input Format | ALW-USER-SECU:[<TID>]:<CTAG>::<UID>; where: <ul style="list-style-type: none">• <UID> is the userid to enable. The userid can be a list of userids separated by ‘&’. The keyword ALL cannot be used to specify all users on an NE. <UID> is a string | |
| Input Example | ALW-USER-SECU:PETALUMA::123::UID; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.10 APPLY: Apply

This command activates or reverts a software load during a software upgrade or downgrade process.

**Note**

An error will be generated if you attempt to activate an older software load or attempt to revert to a newer software load.

| Section | APPLY Description |
|------------------|--|
| Category | File Transfer |
| Security | Superuser |
| Related Messages | COPY-RFILE REPT EVT FXFR |
| Input Format | APPLY:[<TID>]::<CTAG>[::<MEM_SW_TYPE>]; where: <ul style="list-style-type: none">• <MEM_SW_TYPE> indicates memory switch action during the software upgrade; valid values are shown in the “DL_TYPE” section on page 4-57 |
| Input Example | APPLY:CISCO::123::ACT; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.11 CANC: Cancel

Reports the occurrence of a session timeout event.

CANC is an autonomous message transmitted by the NE to a user when a session established by that user is terminated because no messages were exchanged for a long period of time, a timeout. There is a default timeout period based on the user's privilege/security level, and starting with Release 4.0 timeouts can be provisioned. The default timeouts based on privilege/security level are: superuser [SUPER] has the timeout period of 15 minutes., the Provision user [PROV] has the timeout period of 30 minutes, the Maintenance [MAINT] user has the timeout period of 60 minutes, the Retrieve user [RTRV] has no timeout.

When a timeout occurs, the corresponding port drops and the next session initiation at that port requires the regular login procedure.

The CANC message is only used to indicate that a session has been terminated because of a timeout. If a session is terminated for a different reason (e.g., forced logout, loss of communication), the REPT EVT SESSION message is used.

| Section | CANC Description |
|----------|------------------|
| Category | Security |
| Security | Retrieve |

| Section | CANC Description |
|------------------|---|
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU |
| Output Format | SID DATE TIME A ATAG CANC “<UID>” ; where: • <UID> refers to the user’s identification whose session is terminated due to timeout; <UID> is a string |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 CANC “CISCO15” ; |

3.4.12 CANC-USER: Cancel User

This command logs a user out of an active session with the NE.



Note

The USERID field of this command is a mandatory field.

For the CANC-USER command: CANC-USER:[TID]:[STRING]:CTAG

the syntax of the userid (first [STRING]) is not checked. Invalid syntax for the userid is permitted and the userid must not exceed 10 characters.

| Section | CANC-USER Description |
|----------|-----------------------|
| Category | Security |
| Security | Retrieve |

| Section | CANC-USER Description |
|------------------|--|
| Related Messages | ACT-USER INH-MSG-SECU ALW-MSG-SECU INH-USER-SECU ALW-USER-SECU REPT ALM SECU CANC REPT EVT SECU CANC-USER-SECU REPT EVT SESSION DLT-USER-SECU RTRV-CMD-SECU ED-CMD-SECU RTRV-DFLT-SECU ED-PID RTRV-USER-SECU ED-USER-SECU SET-ATTR-SECUDFLT ENT-USER-SECU |
| Input Format | CANC-USER:[<TID>]:<USERID>:<CTAG>; where: <ul style="list-style-type: none">• <USERID> identifies the user to the system; <USERID> is any combination of up to 10 alphanumeric characters. <USERID> is a string Note CTC allows <UID> and <PID> of up to 20 characters. The 20 character CTC-entered <UID> and <PID> are not valid TL1 <UID> and <PID> |
| Input Example | CANC-USER:PETALUMA:TERRI:101; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.13 CANC-USER-SECU: Cancel User Security

This command forces a user off of the NE.

The UID specified can be a single userid or a list of userids separated by '&'. The keyword ALL is not permitted. The UID specified cannot be the userid of the administrator issuing the command.



Note This command will log out ALL sessions on the NE (TL1 and CTC) of a user whose userid matches the UID specified in the command.

| Section | CANC-USER-SECU Description |
|------------------|---|
| Category | Security |
| Security | Superuser |
| Related Messages | ACT-USER INH-MSG-SECU ALW-MSG-SECU INH-USER-SECU ALW-USER-SECU REPT ALM SECU CANC REPT EVT SECU CANC-USER REPT EVT SESSION DLT-USER-SECU RTRV-CMD-SECU ED-CMD-SECU RTRV-DFLT-SECU ED-PID RTRV-USER-SECU ED-USER-SECU SET-ATTR-SECUDFLT ENT-USER-SECU |

| Section | CANC-USER-SECU Description |
|---------------|--|
| Input Format | CANC-USER-SECU:[<TID>]:<UID>:<CTAG>; where: <ul style="list-style-type: none">• <UID> is a user identifier, or list of UIDs separated by ‘&’. The keyword ALL is not permitted. <UID> is a string |
| Input Example | CANC-USER-SECU:PETALUMA:CISCO10:100; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.14 CHG-ACCMD-<MOD_TACC>: Change Test Access Mode (DS1, DS3I, E1, E3, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command changes the test access (TACC) mode for the circuit being tested. For more information on TACC, refer to the “[Test Access](#)” section on page 1-21.

This may be a change from monitoring the data to inserting data into the STS. This command can only be applied to an existing TAP connection.

For this command to be applicable, you must first create the TAP using the ED-<MOD_PATH> command. Intrusive test access modes are traffic-affecting. If a facility/path is connected to a TAP in an intrusive test access mode, it is forced to go into the OOS-MT state. The forced transition could be traffic-affecting. The present state of the facility/path is stored by the NE and is restored when the TAP connection is brought down. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

Notes:

1. If there is no TAP connection, a DENY error message is returned.
2. If a requested condition already exists, a SRCN error message is returned.
3. If a requested access configuration is invalid, a SRAC error message is returned
4. If a requested TAP does not exist, a RTEEN error message is returned.

| Section | CHG-ACCMD-<MOD_TACC> Description |
|------------------|--|
| Category | Test Access |
| Security | Maintenance |
| Related Messages | CONN-TACC-<MOD_TACC> DISC-TACC RTRV-TACC |

| Section | CHG-ACCMD-<MOD_TACC> Description |
|---------------|---|
| Input Format | <p>CHG-ACCMD-<MOD_TACC>:[<TID>]:<TAP>:<CTAG>::<MD>;</p> <p>where:</p> <ul style="list-style-type: none"> • <TAP> indicates the test access path number selected by the NE. The <TAP> is used to identify all messages between the TSC and NE until the access point is released. The <TAP> number must be an integer with a range of 1 to 999. <TAP> is a string <p>Note This command only changes a single TAP at a time.</p> <ul style="list-style-type: none"> • <MD> indicates the test access mode (SPLTE, SPLTF, LOOPE, AND LOOPF require an external QRS input signal); valid values for <MD> are shown in the “TACC_MODE” section on page 4-91 |
| Input Example | CHG-ACCMD-STS1:CISCO:8:123::MONE; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.15 CONN-TACC-<MOD_TACC>: Connect Test Access (DS1, DS3I, E1, E3, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command connects the STS or VT defined by AID to the STS specified by the TAP number. For more information on TACC, refer to the “[Test Access](#)” section on page 1-21.

For this command to be applicable, you must first create the TAP using the ED-<MOD_PATH> command. Intrusive test access modes are traffic-affecting. If a facility/path is connected to a TAP in an intrusive test access mode, it is forced to go into the OOS-MT state. The forced transition could be traffic-affecting. The present state of the facility/path is stored by the NE and is restored when the TAP connection is brought down. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

Notes:

1. If all TAPs are busy, a RABY error message is returned.
2. If a requested TAP is busy, a RTBY error message is returned.
3. If a requested TAP does not exist, a RTEN error message is returned.
4. If a circuit is already connected to another TAP, a SCAT error message is returned.
5. If a requested condition already exists, a SRCN error message is returned.
6. If the AID is invalid, an IIAC (Input, Invalid Access Identifier) error message is returned.
7. If an access is not supported, an EANS error message is returned.
8. If a requested access configuration is invalid, a SRAC error message is returned.
9. A connection can be made to a cross-connection in which case all modes of access are supported. A connection to an Unmapped AID (AID without a cross-connect on it) will allow only MONE, SPLTE, and LOOPE modes.
10. A connection to the protect path of a 1+1, 1:1, or 1:N is not allowed; however, connecting to the PCA path of a two-fiber or four-fiber is supported. This will be preempted when a BLSR switch occurs.

| Section | CONN-TACC-<MOD_TACC> Description |
|------------------|---|
| Category | Test Access |
| Security | Provisioning |
| Related Messages | CHG-ACCMD-<MOD_TACC> DISC-TACC RTRV-TACC |
| Input Format | CONN-TACC-<MOD_TACC>:[<TID>]:<SRC>:<CTAG>:<TAP>:MD=<MD>; where: <ul style="list-style-type: none">• <SRC> is the AID from the “ALL” section on page 4-9 and must not be null• <TAP> indicates the test access path number selected by the NE. The <TAP> is used to identify all messages between the TSC and the NE until the access point is released. The <TAP> number must be an integer with a range of 1 to 999. A null <TAP> defaults to an appropriate <TAP> number selected by the NE. <TAP> is an integer and a null value is equivalent to ALL• <MD> indicates the test access mode (SPLTE, SPLTF, LOOPE and LOOPF require an external QRS input signal); valid values for <MD> are shown in the “TACC_MODE” section on page 4-91. <MD> must not be null |
| Input Example | CONN-TACC-STS1:CISCO:STS-2-1-4:123::8:MD=MONE; |
| Output Format | SID DATE TIME M CTAG COMPLD “<TAP>” ; where: <ul style="list-style-type: none">• <TAP> indicates the test access path number selected by the NE. The <TAP> is used to identify all messages between the TSC and NE until the access point is released. The <TAP> number must be an integer with a range of 1 - 999. A null <TAP> defaults to an appropriate <TAP> number selected by the NE. <TAP> is an integer |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “8” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.16 COPY-IOSCFG: Copy IOS Config File

(Cisco ONS 15454 only)

This command supports the following types of operations on the IOS configuration file of ML-series Ethernet cards:

1. Uploading of startup IOS configuration file from the network to the node.

FTP is the only protocol allowed for uploading. When doing this operation, the SRC field must be a FTP URL string specifying the user name and password for FTP authentication, and specifying the host and the directory to locate the startup config file from the network. The DEST field must be a string of “STARTUP”.

2. Downloading of startup IOS configuration file from the node to the network.

FTP is the only protocol allowed for downloading. When doing this operation, the SRC field must be a string of “STARTUP”. The DEST field must be a FTP URL string specifying the user name and password for FTP authentication, and specifying the host and the directory to store the startup config file.

Notes:

1. The IOS configuration file is unique for each ML-series card, and is specified by the SLOT number in the AID field of the command.
2. In the GNE/ENE environment, if the GNE firewall exists, the download (backup) of IOS configuration file via TL1 is not allowed. Any such attempt will receive a “Data Connection Error” from the GNE. For the upload of IOS configuration file via TL1, GNE will allow it to go through the firewall only if the file contains the header “! Cisco IOS config <text>”. If the configuration file does not contain this header, GNE will block the uploading with “Data Connection Error”.
3. The format of the FTP URL string used in the SRC or DEST field of the command is as follows:

In a non-firewall environment, the format of the URL should be “FTP://[FTPUSER[:FTPPASSWORD]]@FTPHOST/PACKAGE_PATH” where:
 <FTPUSER> is the userid to connect to the computer with the package file
 <FTPPASSWORD> is the password used to connect to the computer with the package file
 <FTPHOST> is the IP address of the computer with the package file, DNS lookup of hostnames is not supported
 <PACKAGE_PATH> is the long path name to the package file



Note Note that USERID and PASSWORD are optional if the user does not need to log into the host computer. Also note that the password may be optional if the user does not need to log in. All the other portions of the URL are required, including the initial “FTP:\\" string.

In a firewall environment, the hostname should be replaced with a list of IP addresses each separated by a @ character. The first IP address should be for the machine where the package file is stored. Subsequent IP addresses should then be for firewall machines moving outwards towards the edge of the network, until the final IP address listed was the machine that outside users first access the network.

For example: if your topology is “FTPHOST <-> GNE3 <-> GNE2 <-> GNE1 <-> ENE”, your FTP URL will be:

FTP://FTPUSER:FTPPASSWORD@FTPHOST@GNE3@GNE2@GNE1/PACKAGE_PATH

| Section | COPY-IOSCFG Description |
|------------------|-------------------------|
| Category | IOS |
| Security | Provisioning |
| Related Messages | REPT EVT IOSCFG |

| Section | COPY-IOSCFG Description |
|---------------|--|
| Input Format | COPY-IOSCFG:[<TID>]:<AID>:<CTAG>::SRC=<SRC>,DEST=<DEST>; where: <ul style="list-style-type: none">• <AID> specifies the slot number of the card where the IOS configuration file belongs and is from the AID “EQPT” section on page 4-27• <SRC> specifies where the IOS config file is copied from and is a string• <DEST> specifies where the IOS config file is copied to and is a string |
| Input Example | COPY-IOSCFG::SLOT-1:CTAG::SRC=“LONG_FTP_PATH”,DEST=“STARTUP”; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.17 COPY-RFILE: Copy RFILE

This command downloads a new software package from the location specified by the FTP URL. It is also used to backup and restore the system database.

In order to upload package files or restore databases from a host, the host must be running an FTP server application. If the host is not running an FTP server application, the command fails indicating that the NE was unable to connect to the remote IP address (host). A host can either be a PC or a workstation running an FTP Server Application.

- Userid is the userid to connect to the computer with the package file or system database.
- Password is the password used to connect to the computer with the package file or system database.



Note Both the userid and password are optional if the user does not need to log into the host computer. The password may be optional if the user does not need to log in.

- Hostname is the hostname or IP address of the computer with the package file or system database.
- Package_path is the long path name to the package file or system database.

All the other portions of the URL are required, including the initial “FTP://” string.

Example:

```
COPY-RFILE:TID:RFILE-PKG:703::TYPE=SWDL,SRC=“FTP://USERID:  
PASSWORD@HOSTIP:21/DIR1/DIR2/DIR3/PACKAGE.PKG”;
```

Notes:

1. The SWDL type is used for software package uploads. The RFBU type is used for system database backups, and the RFR type is used for system database restores. The SRC input is required when the type is SWDL or RFR. The DEST input is needed when the type is RFBU. The SRC and DEST inputs cannot both be used in the same command.
2. FTP is the only allowed file transfer method.
3. The extended FTP URL syntax is required by the COPY-RFILE syntax.
4. Port number (21) is optional. 21 is the only supported Port Number. Leaving this field blank defaults to 21.

| Section | COPY-RFILE Description |
|--------------------------|--|
| Category | File Transfer |
| Security | Superuser |
| Related Messages | APPLY REPT EVT FXFR |
| Input Format | <p>COPY-RFILE:[<TID>]:[<SRC>]:<CTAG>::TYPE=<XFERTYPE>, [SRC=<SRC1>],[DEST=<DEST>],[OVWRT=<OVWRT>],[FTTD=<FTTD>]; where:</p> <ul style="list-style-type: none"> • <SRC> is the type of file being transferred; <SRC> is the AID from the “RFILE” section on page 4-31 • <XFERTYPE> is the file transfer protocol; valid values for <XFERTYPE> are shown in the “TX_TYPE” section on page 4-95 • <SRC1> specifies the source of the file to be transferred. Only the FTP URL is supported. In a non-firewall environment the format of the URL should be: “FTP://FTP_USER[:FTP_PASSWORD]@FTP_HOST_IP[:21]/PACKAGE_PATH[;TYPE=I]” where: <ul style="list-style-type: none"> – <FTP_USER> is the userid to connect to the computer with the package file – <FTP_PASSWORD> is the password used to connect to the computer with the package file – <FTP_HOST_IP> is the IP address of the computer with the package file, DNS lookup of hostnames is not supported – <PACKAGE_PATH> is the long path name to the package file <p>Note Userid and password are optional if the user does not need to log into the host computer. The password may be optional if the user does not need to log in. All the other portions of the URL are required, including the initial “FTP://” string.</p> <p>In a firewall environment, the hostname should be replaced with a list of IP addresses each separated by a @ character. The first IP address should be for the machine where the package file is stored. Subsequent IP addresses should then be for firewall machines moving outwards towards the edge of the network, until the final IP address listed is the machine that outside users first access the network.</p> |
| Input Format (continued) | <p>For example, if the topology is “FTP_HOST_IP <-> GNE3 <-> GNE2 <-> GNE1 <-> ENE”, the FTP URL is:</p> <p>FTP://FTP_USER:FTP_PASSWORD@FTP_HOST_IP@GNE3@GNE2@GNE1/PACKAGE_PATH</p> <p><SRC1> is a string.</p> <ul style="list-style-type: none"> • <DEST> specifies the destinations of the file to be transferred. Same values as <SRC1> above. • <FTTD> the node does not support FTTD. If <FTTD> is used, the COPY-RFILE command will fail with and “FTTD Unsupported” error. <FTTD> is a string |

| Section | COPY-RFILE Description |
|---------------|---|
| Input Example | COPY-RFILE:HERNDON:RFILE-PKG:703::TYPE=SWDL, SRC="LONG_FTP_PATH",DEST="LONG_FTP_PATH",OVWRT=YES, FTTD="UNUSED"; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.18 DISC-TACC: Disconnect Test Access

This command disconnects the TAP and puts the connection back to its original state (no splits). For more information on TACC, refer to the “[Test Access](#)” section on page 1-21.

For this command to be applicable, you must first create the TAP using the ED-<MOD_PATH> command.

Notes:

1. If you send this command to an already disconnected connection, a SADC error message is returned.
2. If the system cannot release TAP, an SRTN error message is returned.

| Section | DISC-TACC Description |
|------------------|--|
| Category | Test Access |
| Security | Provisioning |
| Related Messages | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> RTRV-TACC |
| Input Format | DISC-TACC:[<TID>]:<TAP>:<CTAG>; where: <ul style="list-style-type: none">• <TAP> indicates the test access path number; <TAP> must be an integer with a range of 1- 999. <TAP> is a string <p>Note This command only supports disconnecting one <TAP> at a time.</p> |
| Input Example | DISC-TACC:CISCO:8:123; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.19 DLT-<MOD_RING>: Delete (BLSR)

This command deletes the BLSR of the NE.



Note ONS 15327 does not support four-fiber BLSR.

Error conditions:

1. If the system fails on getting IOR, a SROG (Status, Get IOR Failed) error message is returned.
2. If the AID is invalid, an IIAC (Invalid AID) error message is returned.
3. If the BLSR does not exist, a SRQN (BLSR Does Not Exist) error message is returned.
4. The ALL AID is invalid for this command.

5. The list AID format is supported in this release (R4.6).
6. The SROF (Facility Not Provisioned) or (Cannot Access BLSR) error message will be returned for the invalid query.
7. If the BLSR is in use, a SROF (BLSR In Use) error message is returned.
8. The SRQN (BLSR Deletion Failed) error message is returned for the invalid deletion query.

| Section | DLT-<MOD_RING> Description | |
|------------------|---|-----------------|
| Category | BLSR | |
| Security | Provisioning | |
| Related Messages | ED-<MOD_RING> | RTRV-<MOD_RING> |
| Input Format | DLT-<MOD_RING>:[<TID>]:<AID>:<CTAG>[::]; where: <ul style="list-style-type: none"> • <AID> identifies the BLSR of the NE. “ALL” or “BLSR-ALL” AID is not allowed for editing BLSR. <AID> is the AID from the “AidUnionId” section on page 4-15 | |
| Input Example | DLT-BLSR:PETALUMA:BLSR-2:123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.20 DLT-CRS-<PATH>: Delete Cross Connection (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command deletes a cross-connection between STS and VT paths. STS paths are specified using their STS AID.

Notes:

1. The fields after CTAG (trailing colons) are optional.
2. For the 1-way cross-connections the AIDs must be in the same order as originally entered; for the 2-way cross-connections, either order will work.
3. This command does not support deleting multiple STS cross-connections.
4. Using “&” in the AID field of this command can delete an path protection STS cross-connection.
 - a. The following command is used to delete a 1-way selector or 2-way selector and bridge with:
from points: F1, F2
to points: T1
DLT-CRS-{STS_PATH}:[<TID>]:F1&F2,T1:<CTAG>;
 - b. The following command is used to delete a 1-way bridge or 2-way selector and bridge with:
from point: F1
to points: T1, T2
DLT-CRS-{STS_PATH}:[<TID>]:F1,T1&T2:<CTAG>;

- c. The following command is used to delete a 1-way or 2-way subtending path protection connection with:

from point: F1, F2
to points: T1, T2

`DLT-CRS-{STS_PATH}:[<TID>]:F1&F2,T1&T2:<CTAG>;`
 - d. The AID format in the deletion command is the same as the AID format in the retrieved response message. For example, if the output of any retrieved AID is “F1&F2,T1:CCT,STS3C”, the deletion command with the AID format (F1&F2,T1) is required to delete this cross-connection.
 - e. The following command is used to create a path protection IDRI Cross-Connection:

`ENT-CRS-{STS_PATH}:[<TID>]:A&B,C&D:<CTAG>::2WAYDC;`

A–Path on ring X to which traffic from ring Y is bridged
B–Path on ring X to which traffic from the same ring is bridged
C–Path on ring Y to which traffic from ring X is bridged
D–Path on ring Y to which traffic from the same ring is bridged

A, B, C, and D have a positional meaning. Connection type 2WAYDC is used for path protection IDRI cross-connections.
 - f. The following command is used to create a path protection DRI Cross-Connection:

`ENT-CRS-{STS_PATH}:[<TID>]:A&B,C:<CTAG>::2WAYDC;`

A–Path on ring X to which traffic from ring Y is bridged
B–Path on ring X to which traffic from the same ring is bridged
C–Traffic to and from ring Y

A, B, C, and D have a positional meaning. Connection type 2WAYDC is used for path protection DRI cross-connections.
5. All A&B AIDs in the TL1 cross-connection command are in the format of WorkingAID&ProtectAID.
 6. You can experience some implementation behavior problems if additional drops have been added to the connection object.
 7. The facility AID is only valid for slots holding the G1000-4 card.
 8. The virtual facility AID (VFAC) is only valid on slots holding an ML-series card.
 9. A TL1 cross-connect that has been upgraded to a CTC circuit can no longer be managed by TL1. For example, if you issue a `DLT-CRS-<PATH>` command to delete a circuit, you will see that the circuit still appears in CTC as “incomplete”. The reason for this is because in addition to creating cross-connects (as TL1 does), CTC creates another object on the source node that stores network-level circuit attributes. CTC will continue to see that object after the cross-connect is deleted which is why it shows an incomplete circuit.

| Section | DLT-CRS-<PATH> Description | |
|------------------|---|------------------------------------|
| Category | Cross Connections | |
| Security | Provisioning | |
| Related Messages | <code>ED-CRS-<PATH></code> | <code>RTRV-CRS</code> |
| | <code>ENT-CRS-<PATH></code> | <code>RTRV-CRS-<PATH></code> |

| Section | DLT-CRS-<PATH> Description |
|---------------|--|
| Input Format | DLT-CRS-<PATH>:[<TID>]:<SRC>,<DST>:<CTAG>[::]; where: <ul style="list-style-type: none">• <SRC> is the AID from the “CrossConnectId1” section on page 4-23• <DST> is the AID from the “CrossConnectId1” section on page 4-23 |
| Input Example | DLT-CRS-STS12C:VINBURG:STS-1-1-1,STS-12-1-1:102; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.21 DLT-EQPT: Delete Equipment

This command deletes a card from the NE.

This command removes the card type and attributes that were entered for a particular slot. If any facilities are assigned, they are deleted too. The command will be denied if the card is part of a protection group or has a cross-connect end-point.

To delete a card that is part of a protection group, it has to be removed from the protection group first using the ED-EQPT command.

Error conditions for deleting equipment may be:

1. If a card in a protection group that has a cross-connection, DCC or is a synchronization source, the SPLD (Equipment in use) error message will be returned.
2. If a card is not provisioned, an error message will be returned.

| Section | DLT-EQPT Description | |
|------------------|---|-----------------|
| Category | Equipment | |
| Security | Provisioning | |
| Related Messages | ALW-Swdx-EQPT | REPT EVT EQPT |
| | ALW-Swtoprotn-EQPT | RTRV-ALM-EQPT |
| | ALW-Swtowkg-EQPT | RTRV-ALMTH-EQPT |
| | ED-EQPT | RTRV-COND-EQPT |
| | ENT-EQPT | RTRV-EQPT |
| | INH-Swdx-EQPT | SET-ALMTH-EQPT |
| | INH-Swtoprotn-EQPT | SW-DX-EQPT |
| | INH-Swtowkg-EQPT | SW-Toprotn-EQPT |
| | REPT ALM EQPT | SW-Towkg-EQPT |
| Input Format | DLT-EQPT:[<TID>]:<AID>:<CTAG>[::]; where: <ul style="list-style-type: none">• <AID> is the equipment unit (slot) to act on and is the AID from the “EQPT” section on page 4-27 | |
| Input Example | DLT-EQPT:SONOMA:SLOT-1:104; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.22 DLT-FFP-<OCN_TYPE>: Delete Facility Protection Group (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command deletes an OCN facility protection group in a 1+1 architecture.


Note

If the protection group does not exist, an error message will be returned.

| Section | DLT-FFP-<OCN_TYPE> Description | |
|------------------|--|---|
| Category | Facility Protection | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT | OPR-PROTNSW-<OCN_TYPE> RLS-PROTNSW-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-PROTNSW-<OCN_TYPE> |
| Input Format | DLT-FFP-<OCN_TYPE>:[<TID>]:<WORK>,<PROTECT>:<CTAG>[::]; where: <ul style="list-style-type: none">• <WORK> identifies the working facility and is the AID from the “FACILITY section on page 4-28• <PROTECT> identifies the protect facility and is the AID “FACILITY” section on page 4-28 | |
| Input Example | DLT-FFP-OC3:PETALUMA:FAC-2-1,FAC-1-1:1; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.23 DLT-FFP-CLNT: Delete Facility Protection Group Client

(Cisco ONS 15454 only)

This command deletes Y cable protection on client facilities.

| Section | DLT-FFP-CLNT Description |
|----------|--------------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | DLT-FFP-CLNT Description | |
|------------------|--|--|
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNST-<OCN_TYPE> OPR-PROTNST-CLNT | OPR-PROTNST-OCH RLS-LASER-OTS RLS-PROTNST-<OCN_TYPE> RLS-PROTNST-CLNT RLS-PROTNST-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNST-<OCN_TYPE> RTRV-PROTNST-CLNT RTRV-PROTNST-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | DLT-FFP-CLNT:[<TID>]:<WORKAID>,<PROTAID>:<CTAG>[::]; where: <ul style="list-style-type: none">• <WORKAID> identifies the working facility and is the AID from the “FACILITY” section on page 4-28• <PROTECTAID> identifies the protect facility and is the AID “FACILITY” section on page 4-28 | |
| Input Example | DLT-FFP-CLNT:CISCO:FAC-1-1,FAC-2-1:100; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.24 DLT-LNK-<MOD2O>: Delete Optical Link (OCH, OMS, OTS)

(Cisco ONS 15454 only)

This command deletes an optical link between two optical connection points. Optical link is specified by using the AID of the involved Optical Connection points.

| Section | DLT-LNK-<MOD2O> Description |
|----------|-----------------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | DLT-LNK-<MOD2O> Description | |
|------------------|--|---|
| Related Messages | DLT-FFP-CLNT ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT OPR-PROTNSW-OCH | RLS-LASER-OTS RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | DLT-LNK-<MOD2O>:[<TID>]:<FROM>,<TO>:<CTAG>; where: <ul style="list-style-type: none">• <FROM> indicates an identifier at one end of the optical link and is the AID from the “BAND” section on page 4-18• <TO> indicates an identifier at the other end of the optical link and is the AID from the “BAND” section on page 4-18. | |
| Input Example | DLT-LNK-OMS:PENNGROVE:BAND-6-1-TX,BAND-13-1-RX:114; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.25 DLT-OSC: Delete OSC

(Cisco ONS 15454 only)

This command deletes the OSC group of the NE.

| Section | DLT-OSC Description |
|------------------|--|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | ENT-OSC ED-OSC RTRV-OSC |
| Input Format | DLT-OSC:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> identifies the OSC group of the NE and is the AID “OSC” section on page 4-30 |
| Input Example | DLT-OSC:PENNGROVE:OSC-1:114; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.26 DLT-UCP-CC: Delete Unified Control Plane Control Channel

(Cisco ONS 15454 only)

This command deletes a UCP IP control channel.

1. If you send this command to a control channel that is in use, a SRQN (Status, Invalid Request) error message is returned.
2. If sending this command to delete an SDCC IPCC with a complete result, the SDCC of the specified SONET line is deleted (or disabled) automatically with a DB change reporting (if the DB change report is enabled).
3. If sending this command to delete an IPCC which is in use by a UCP Interface, an SROF (Delete UCP IPCC Failed - Object Is In Use) error message is returned.

| Section | DLT-UCP-CC Description | |
|------------------|---|--|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR REPT ALM UCP | REPT EVT UCP RTRV-ALM-UCP RTRV-CKT-ORIG RTRV-CKT-TERM RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |
| Input Format | DLT-UCP-CC:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <AID> indicates an individual IPCC ID; <AID> is the AID from the “IPCC” section on page 4-29 | |
| Input Example | DLT-UCP-CC:CISCO:CC-9:CTAG; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.27 DLT-UCP-IF: Delete Unified Control Plane Interface

This command deletes a UCP interface.



Note If the UCP interface is not found or in use, a SRQN (Status, Invalid Request) error message is returned.

| Section | DLT-UCP-IF Description | |
|----------|------------------------|--|
| Category | UCP | |
| Security | Provisioning | |

| Section | DLT-UCP-IF Description | |
|------------------|---|--|
| Related Messages | DLT-UCP-CC DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR | REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |
| Input Format | DLT-UCP-IF:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <AID> indicates the interface port index of the data link; <AID> is the AID from the “FACILITY” section on page 4-28 | |
| Input Example | DLT-UCP-IF:CISCO:FAC-2-1:CTAG; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.28 DLT-UCP-NBR: Delete Unified Control Plane Neighbor

This command deletes a UCP neighbor.

Notes:

1. If the neighbor is in use, an SRQN (Status, Invalid Request) error message is returned.
2. If sending this command to delete a neighbor which is in use by IPCC, an SROF (Delete UCP neighbor Failed - Object Is In Use) error message is returned.

| Section | DLT-UCP-NBR Description | |
|------------------|---|--|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC DLT-UCP-IF ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR | REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |
| Input Format | DLT-UCP-NBR:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <AID> indicates an individual neighbor AID of the UCP; <AID> is the AID from the “NBR” section on page 4-30 | |
| Input Example | DLT-UCP-NBR:CISCO:NBR-8:CTAG; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.29 DLT-USER-SECU: Delete User Security

This command deletes a user and can only be performed by a Superuser. Privilege levels are described in the ENT-USER-SECU command.

This command cannot be used to delete a user that is currently logged on.

For the DLT-USER-SECU command:

DLT-USER-SECU:[TID]:<UID>:[CTAG];

the syntax of <UID> is not checked. The user is deleted if the <UID> exists in the database.

| Section | DLT-USER-SECU Description | |
|------------------|--|-------------------|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER | INH-MSG-SECU |
| | ALW-MSG-SECU | INH-USER-SECU |
| | ALW-USER-SECU | REPT ALM SECU |
| | CANC-USER | REPT EVT SECU |
| | CANC-USER-SECU | REPT EVT SESSION |
| | ED-CMD-SECU | RTRV-CMD-SECU |
| | ED-PID | RTRV-DFLT-SECU |
| | ED-USER-SECU | RTRV-USER-SECU |
| | ENT-USER-SECU | SET-ATTR-SECUDFLT |
| Input Format | DLT-USER-SECU:[<TID>]:<UID>:<CTAG>; | |
| | where: | |
| | <ul style="list-style-type: none"> • <UID> is the user identifier and is a string; <UID> is any combination of up to 10 alphanumeric characters <p>Note CTC allows <UID> and <PID> of up to 20 characters. The 20 character CTC-entered <UID> and <PID> are not valid TL1 <UID> and <PID>.</p> | |
| Input Example | DLT-USER-SECU:PETALUMA:CISCO15:123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.30 DLT-VCG: Delete Virtual Concatenated Group

(Cisco ONS 15454 only)

This command deletes a VCG object.

| Section | DLT-VCG Description |
|------------------|---------------------|
| Category | VCAT |
| Security | Provisioning |
| Related Messages | ENT-VCG |
| | RTRV-VCG |

| Section | DLT-VCG Description |
|---------------|--|
| Input Format | DLT-VCG:[<TID>]:<SRC>:<CTAG>:::[CMDMDE=<CMDMDE>][:]; where: <ul style="list-style-type: none">• <SRC> AID to address the VCG from the “FACILITY” section on page 4-28• <CMDMDE> command mode. FRCD deletes all the VCG members and member cross-connects of a VCG; valid values are shown in the “CMD_MODE” section on page 4-54 |
| Input Example | DLT-VCG:NODE1:FAC-1-1:1234:::CMDMDE=FRCD; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.31 DLT-WLEN: Delete Wavelength

(Cisco ONS 15454 only)

This command deletes the provisioned wavelength (WLEN).

Note:

1. The fields after CTAG (trailing colons) are the optional.
2. This command does not support multiple deleting WLEN provisioning.

| Section | DLT-WLEN Description |
|------------------|---|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | ENT-WLEN ED-WLEN RTRV-WLEN |
| Input Format | DLT-WLEN:[<TID>]:<AID>:<CTAG>[:::CMDMDE=<CMDMDE>]; where: <ul style="list-style-type: none">• <AID> is the wavelength AID per ring direction from the “WLEN” section on page 4-37• <CMDMDE> indicates the command execution mode. There are two options: NORM for normal (default), and FRCD for forced. Forced will override any safeguards that normally reject a request to delete an In Service resource. Valid values are shown in the “CMD_MODE” section on page 4-54 |
| Input Example | DLT-WLEN: PENNGROVE:WLEN-W_E-1530.33:114:::CMDMDE=NORM; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.32 ED-<MOD_PATH>: Edit (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

This command edits the attributes associated with STS and VT paths.

The SFBER, SDBER, RVRTV, and RVTM parameters only apply to path protection.

The path trace message is a 64 character string including the terminating CR (carriage return) and LF (line feed) that is transported in the J1 byte of the SONET STS Path overhead. Both the EXPTRC and TRC string can be provisioned by user with up to 62 character string.

The EXPTRC indicates the contents of the expected incoming path trace are provisioned by the user. The TRC indicates the contents of the outgoing path trace message. The INCTRC indicates the contents of the incoming path trace message.

The path trace mode has three modes: OFF, MANUAL, and AUTO. The path trace mode defaults to OFF. The MANUAL mode performs the comparison of the received string with the user-entered expected string. The AUTO mode performs the comparison of the present received string with an expected string set to a previously received string. If there is a mismatch, TIM-P alarm is raised. When the path trace mode is in OFF mode, there is no path trace processing, and all the alarm and state conditions are reset.

The TACC parameter edits an existing single STS or VT and changes it to a test access point. When an editing command on TACC is executed, it assigns the STS for the first 2-way connection and STS=1 as the second 2-way connection. For STS3C and STS12C, the next available STS of the same width is chosen. For more information on TACC, refer to the “[Test Access](#)” section on page 1-21.

J1 is implemented on the DS1/DS1N, DS3E/DS3NE, DS3XM, EC1, OC3, OC12, OC48AS and OC192 cards.

DS3/DS3N, OC48, E100, and E1000 cards do not support path trace.

DS1/DS1N, DS3E/DS3NE, and DS3XM support both TRC and EXPTRC in the ED-STS-PATH command.

EC1, OC3, OC48AS, and OC192 only support EXPTRC in the ED-STS-PATH command.



Note

Each TL1 command must be less than or equal to 255 characters. Any command larger than 255 characters must be split into multiple commands. For example, if you use the ED-<MOD_PATH> command to edit the J1 EXPTRC/TRC message, path protection attributes, and TACC attributes and the command exceeds 255 characters the command will not be processed. You must use multiple ED-<MOD_PATH> commands instead.

Error conditions:

1. If sending this command to edit SFBER or SDBER or RVRTV or RVTM for the non-path protection STS path, an error message will be returned.
2. If sending this command to edit the EXPTRC string with the AUTO path trace mode (TRCMODE=AUTO), an error message will be returned.
3. If sending this command to edit TRC on any card other than DS3(N)E, DS1(N), and DS3XM cards, an error message (TRC-not allowed for monitor paths. Incorrect card type.) will be returned.
4. This command is allowed to edit EXPTRC on DS1(N), DS3(N)E, DS3XM, EC1, OC3, OC48AS, and OC192 cards.
5. If sending this command to edit both TACC and any other attribute(s), the (Parameters Not compatible) error message will be returned.
6. If sending this command to edit TACC on an AID with cross-connections, an error message (STS in Use) will be returned.
7. TACC creation will also be denied on the protect ports/cards for 1:1, 1:N, and 1+1.
8. The VFAC AID is only valid on slots containing an ML1000-2 or ML100T-12 card. TACC is not supported for the ML1000-2 or ML100T-12 cards.

9. After the BLSR switching, provisioning of the J1 trace string or trace mode is not allowed on the protection path.
10. TACC creation is allowed on PCA for two-fiber and four-fiber BLSR.
11. TACC is not supported on G1000, MXP_2.5_10G/TXP_MR-10G, ML1000-2 and ML100T-12 cards.
12. HOLDOFFTIMER is not specific to a path. It is applicable to the path protection selector. If HOLDOFFTIMER is changed on one path associated with the selector, the HOLDOFFTIMER of the other path associated with the same selector is also changed.

| Section | ED-<MOD_PATH> Description |
|------------------|---------------------------|
| Category | Paths |
| Security | Provisioning |
| Related Messages | — |

| Section | ED-<MOD_PATH> Description |
|--------------|---|
| Input Format | <p>ED-<MOD_PATH>:[<TID>]:<AID>:<CTAG>:::[SFBER=<SFBER>,<SDBER=<SDBER>,<RVRTV=<RVRTV>,<RVTM=<RVTM>,<SWPDIP=<SWPDIP>,<HOLDOFFTIMER=<HOLDOFFTIMER>,<EXPTRC=<EXPTRC>,<TRC=<TRC>,<TRCMODE=<TRCMODE>,<TACC=<TACC>,<TAPTYPE=<TAPTYPE>:<PST>,<SST>>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “CrossConnectId1” section on page 4-23 • <SFBER> identifies an STS path SFBER which only applies to path protection; valid values for <SFBER> are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies an STS path SDBER which only applies to path protection; valid values for <SDBER> are shown in the “SD_BER” section on page 4-85 • <RVRTV> identifies a revertive mode which only applies to path protection; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies a revertive time which only applies to path protection; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84. <RVTM> is not allowed to be set while <RVRTV> is N. • <SWPDIP> On-Off switch for path protection Payload Defect Level switching. Valid values for <SWPDIP> are shown in the “ON_OFF” section on page 4-76 • <HOLDOFFTIMER> Hold-off timer for path protection DRI. Values must be within 0 and 10000 milliseconds (0 to 10 seconds) with increments of 100 milliseconds; <HOLDOFFTIMER> is an integer • <EXPTRC> indicates the expected path trace message (J1) contents. The EXPTRC is any 64 character string, including the terminating CR (carriage return) and LF (line feed); <EXPTRC> is a string • <TRC> identifies the path trace message to be transmitted. The TRC is any combination of 64 characters, including the terminating CR and LF. The trace byte (J1) continuously transmits a 64 byte string, one byte at a time. A null value defaults to the NE transmitting null characters (Hex 00); <TRC> is a string • <TRCMODE> indicates the path trace mode, and defaults to the OFF mode; valid values for <TRCMODE> are shown in the “TRCMODE” section on page 4-94 • <TACC> is the TAP number in a range of 0 to 999. When TACC is 0 (zero), the TAP is deleted. • <TAPTYPE> is the TAP type and valid values are shown in the “TAPTYPE” section on page 4-92; <TAPTYPE> defaults to Dual • <PST> is the primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> is the secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |

| Section | ED-<MOD_PATH> Description |
|---------------|--|
| Input Example | ED-STS3C:FERNDALE:STS-2-1-4:115::SFBER=1E-3,SDBER=1E-5, RVRTV=Y,RVTM=1.0,SWPDIP=Y,HOLDOFFTIMER=2000, EXPTRC="EXPTRCSTRING",TRC="TRCSTRING", TRCMODE=OFF,TACC=8,TAPTYPE=SINGLE:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.33 ED-<MOD_RING>: Edit Bidirectional Line Switched Ring

This command edits the BLSR attributes.

Notes:

1. ONS 15327 does not support four-fiber BLSR.
2. Only the RVRTV, RVTM, SRVRTV, SRVTM attributes can be edited for the 4-Fiber BLSR.
3. Only the RVRTV and RVTM attributes can be edited for the 2-Fiber BLSR.

Error conditions:

1. If the system fails on getting IOR, a SDBE (Status, Internal Data Base Error) error message will be returned.
2. If the AID is invalid, an IIAC (Invalid AID) error message is returned.
3. If the BLSR does not exist, a SRQN (BLSR Does Not Exist) error message is returned.
4. The ALL AID is invalid for this command.
5. The list AID format is supported in this release (R4.6).
6. The SROF (Facility Not Provisioned) or Cannot Access BLSR) error message will be returned for the invalid query.
7. The SRQN (BLSR Edition Failed) error message is returned for the invalid edition query.
8. If sending this command to modify SRVRTV or SRVTM on a two-fiber BLSR, an IDNV (Invalid Data For 2F-BLSR) error message will be returned.
9. If sending this command to modify the nodeid with invalid data, an IIAC (Invalid NodeId) error message is returned.
10. If sending this command to change the ringid into invalid data, an IIAC (Invalid RingId) error message is returned.
11. If changing the BLSR nodeid with a duplicated ID, a SROF (Cannot Set NodeId) error message is returned.
12. If changing the BLSR ringid with a duplicated ID, a SROF (Cannot Set RingId) error message is returned.

| Section | ED-<MOD_RING> Description | |
|------------------|----------------------------------|-----------------|
| Category | BLSR | |
| Security | Provisioning | |
| Related Messages | DLT-<MOD_RING> ENT-<MOD_RING> | RTRV-<MOD_RING> |

| Section | ED-<MOD_RING> Description |
|---------------|---|
| Input Format | <p>ED-<MOD_RING>:[<TID>]:<AID>:<CTAG>:::[RINGID=<RINGID>,<NODEID=<NODEID>,<RVRTV=<RVRTV>,<RVTM=<RVTM>,<SRVRTV=<SRVRTV>,<SRVTM=<SRVTM>>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the BLSR of the NE and is from the “AidUnionId” section on page 4-15 (the AID “ALL” or “BLSR ALL” is not allowed for editing BLSR). • <RINGID> identifies the BLSR ring ID of the NE. <RINGID> is a string of up to six characters; valid characters are [A-Z, 0-9] • <NODEID> identifies the BLSR node ID of the NE. It ranges from 0-31. <NODEID> is an integer • <RVRTV> identifies the revertive mode and valid values are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies the revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 • <SRVRTV> identifies the span revertive mode for 4F BLSR only and valid values are shown in the “ON_OFF” section on page 4-76 • <SRVTM> identifies the span revertive time for 4F BLSR only; valid values for <SRVTM> are shown in the “REVERTIVE_TIME” section on page 4-84. <SRVTM> is not allowed to be set while <SRVRTV> is N |
| Input Example | ED-BLSR:PETALUMA:BLSR-43:123:::RINGID=43,NODEID=3,RVRTV=Y,RVTM=2.0,SRVRTV=Y,SRVTM=5.0; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.34 ED-<OCN_TYPE>: Edit (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command edits the attributes (i.e., service parameters) and state of an OC-N facility. Allowable states for a facility are Out Of Service (OOS), Out Of Service with Automatic In Service transitioning (OOS-AINS), Out Of Service for Maintenance (OOS-MT), and In Service (IS).

The DCC transmit is bridged to both working and protect in a 1+1 configuration. On the receive side, the active one is selected for DCC. The DCC is provisioned on the working port only in a 1+1 configuration.

All lines in a 1+1 BLSR must have the same mode. If you change the mode of a line that is in a 1+1 BLSR, an error message will be returned.

UNI-C DCC provisioning notes:

1. The attributes DCC(Y/N) and mode (SONET/SDH) remain the same in the ED/RTRV-OCN commands when the DCC is used for UNI-C, in which case the port attribute UNIC is enabled (UNIC=Y).
2. UNI-C DCC termination cannot be deleted by the regular DCC de-provisioning command.
3. If the DCC is created under regular SONET provisioning, and this port is used by UNI-C, the port is converted as a UNI-C DCC automatically.
4. De-provisioning UNI-C IF/IB IPCC will free up DCC termination automatically.

5. The parameters ALSMODE, ALSCRINT and ALSRCPW are valid only for OC3-8, OC-192, and OC48ELR cards.

| Section | ED-<OCN_TYPE> Description |
|---------------------|---------------------------|
| Category | Ports |
| Security | Provisioning |
| Related Messages | ED-DS1 RTRV-DS1 |
| | ED-EC1 RTRV-EC1 |
| | ED-FAC RTRV-FAC |
| | ED-FC RTRV-FC |
| | ED-G1000 RTRV-FSTE |
| | ED-T1 RTRV-G1000 |
| | ED-T3 RTRV-GIGE |
| | RMV-<MOD2_IO> RTRV-POS |
| | RST-<MOD2_IO> RTRV-T1 |
| | RTRV-<OCN_TYPE> RTRV-T3 |

| Section | ED-<OCN_TYPE> Description |
|--------------|---|
| Input Format | <p>ED-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>:::[DCC=<DCC>,<AREA=<AREA>,<SYNCMSG=<SYNCMSG>,<SENDDUS=<SENDDUS>,<PJMON=<PJMON>,<SFBER=<SFBER>,<SDBER=<SDBER>,<MODE=<MODE>,<MUX=<MUX>,<SOAK=<SOAK>,<OSPF=<OSPF>,<LDCC=<LDCC>,<ALSMODE=<ALSMODE>,<ALSRCINT=<ALSRCINT>,<ALSRCPW=<ALSRCPW>,<RLASER=<RLASER>>:[<PST>],[<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 • <DCC> identifies the section DCC connection of the port; valid values are shown in the “ON_OFF” section on page 4-76 • <AREA> is area ID and shows up only if the DCC is enabled; <AREA> is a string • <SYNCMSG> indicates if sync status messaging is enabled or disabled on the facility; valid values for <SYNCMSG> are shown in the “ON_OFF” section on page 4-76 • <SENDDUS> indicates that the facility will send out the DUS (do not use for synchronization) value as the sync status message for that facility; valid values are shown in the “ON_OFF” section on page 4-76 • <PJMON> identifies an OC-N port PJMON with a value range of [0, highest STS number for the SONET card]; <PJMON> is an integer • <SFBER> identifies an OC-N port SFBER; valid values for <SFBER> are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies an OC-N port SDBER; valid values for <SDBER> are shown in the “SD_BER” section on page 4-85 • <MODE> indicates the OCN port mode; valid values for are shown in the “OPTICAL_MODE” section on page 4-77 • <MUX> BLSR Extension Byte (supported only on OC48AS cards); valid values for <MUX> are shown in the “MUX_TYPE” section on page 4-75 • <SOAK> OOS-AINS to IS transition soak time as measured in 15 minute intervals, so a value of 4 translates to a soak time of 1 hour. The allowable range is 0–192 intervals (maximum of 48 hours). <SOAK> is an integer. • <OSPF> indicates the OSPF discovery; valid values are shown in the “ON_OFF” section on page 4-76 • <LDCC> indicates the Line DCC connection on the port; valid values are shown in the “EXT_RING” section on page 4-65 • <ALSMODE> valid only for OC3-8, OC192 and OC48ELR cards. Indicates the ALS recovery interval. The range is 100–300 seconds; <ALSMODE> is an integer • <ALSRCINT> valid only for OC3-8, OC192 and OC48ELR cards. Indicates the ALS recovery interval. The range is 100–300 seconds; <ALSRCINT> is an integer |

| Section | ED-<OCN_TYPE> Description |
|-----------------------------|---|
| Input Format (continued) | <ul style="list-style-type: none"> <ALSRCPW> valid only for OC3-8, OC192 and OC48ELR cards. Indicates the ALS recovery pulse width. The range is 20–100 seconds; <ALSRCPW> is a float <RLASER> indicates if the laser should be restarted. Applicable only if the ALSMODE is not Automatic; valid values are shown in the “ON_OFF” section on page 4-76 <PST> is the primary state; valid values for <PST> are shown in the “PST” section on page 4-83 <SST> is the secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |
| Input Example | ED-OC48: PENNGROVE:FAC-6-1:114:::DCC=Y, AREA=10.92.63.1, SYNCMSG=Y, SENDDUS=N, PJMON=48, SFBER=1E-4, SDBER=1E-6, MODE=SONET, MUX=E2, SOAK=10, OSPF=Y, LDCC=N, ALSMODE=MAN, ALSRCINT=101, ALSRCPW=35.1, RLASER=Y:OOS, AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.35 ED-BITS: Edit Building Integrated Timing Supply

This command edits the BITS reference attributes.



Note

SYNC-BITS1 and SYNC-BITS2 AIDs can be used for setting the port state of BITS-OUT ports.

| Section | ED-BITS Description | |
|------------------|---------------------|-----------------|
| Category | Synchronization | |
| Security | Provisioning | |
| Related Messages | ED-NE-SYNCN | RTRV-ALM-BITS |
| | ED-SYNCN | RTRV-ALM-SYNCN |
| | OPR-SYNCNSW | RTRV-BITS |
| | REPT ALM BITS | RTRV-COND-BITS |
| | REPT ALM SYNCN | RTRV-COND-SYNCN |
| | REPT EVT BITS | RTRV-NE-SYNCN |
| | REPT EVT SYNCN | RTRV-SYNCN |
| | RLS-SYNCNSW | |

| Section | ED-BITS Description |
|---------------|---|
| Input Format | <p>ED-BITS:[<TID>]:<AID>:<CTAG>:::[LINECDE=<LINECDE>],[FMT=<FMT>],[LBO=<LBO>],[SYNCMSG=<SYNCMSG>],[AISTHRSHLD=<AISTHRSHLD>],[SABIT=<SABIT>],[IMPEDANCE=<IMPEDANCE>][:<PST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “BITS” section on page 4-19 • <LINECDE> is a line code; valid values for <LINECDE> are shown in the “LINE_CODE” section on page 4-68 • <FMT> is the frame format; valid values for <FMT> are shown in the “FRAME_FORMAT” section on page 4-65 • <LBO> indicates BITS line build out. The default value is 0–133. Valid values for <LBO> are shown in the “BITS_LineBuildOut” section on page 4-50 • <SYNCMSG> indicates if this BITS facility supports synchronization status message; <SYNCMSG> defaults to (Y) and valid values are shown in the “ON_OFF” section on page 4-76 • <AISTHRSHLD> is the AIS Threshold. Valid values for <AISTHRSHLD> shown in the “SYNC_CLOCK_REF_QUALITY_LEVEL” section on page 4-89 • <SABIT> when the frame format selection is E1, <SABIT> indicates the BIT used to receive and transmit the SSM; valid values are shown in the “SABITS” section on page 4-84 • <IMPEDANCE> when the frame format selection is one of the E1 values <IMPEDANCE> indicates the terminal impedance of BITS-IN port. Valid values are shown in the “IMPEDANCE” section on page 4-66 • <PST> is a state; valid values for <PST> are shown in the “PST” section on page 4-83 |
| Input Example | ED-BITS:SONOMA:BITS-2:779:::LINECDE=AMI,FMT=ESF,LBO=0-133,SYNCMSG=Y,AISTHRSHLD=PRS:IS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.36 ED-CLNT: Edit Client

(Cisco ONS 15454 only)

This command edits client facility attributes.



Note Primary=OOS and secondary=AINS states do not apply to Ethernet mode.

| Section | ED-CLNT Description |
|----------|---------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | ED-CLNT Description | |
|------------------|---|---|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNST-CLNT OPR-PROTNST-OCH | RLS-LASER-OTS RLS-PROTNST-CLNT RLS-PROTNST-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNST-CLNT RTRV-PROTNST-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |

| Section | ED-CLNT Description |
|--------------|---|
| Input Format | <p>ED-CLNT:[<TID>]:<AID>:<CTAG>:::[NAME=<PORTNAME>,<SFBER=<SFBER>,<SDBER=<SDBER>,<ALSMODE=<ALSMODE>,<ALSRCINT=<ALSRCINT>,<ALSRCPW=<ALSRCPW>,<COMM=<COMM>,<MACADDR=<MACADDR>,<SYNCMSG=<SYNCMSG>,<SEDDUS=<SEDDUS>,<RLASER=<RLASER>,<SOAK=<SOAK>,<OSPF=<OSPF>>]:<PST>],[<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is from the “FACILITY” section on page 4-28 • <PORTNAME> indicates the port name and is a string • <SFBER> identifies the SFBER for the SONET payload; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies the SDBER for the SONET payload; valid values are shown in the “SD_BER” section on page 4-85 • <ALSMODE> indicates if the Automatic Laser Shutdown is enabled or disabled; valid values are shown in the “ALS_MODE” section on page 4-49 • <ALSRCINT> indicates the ALS recovery interval. Range is 100–300 seconds; <ALSRCINT> is an integer • <ALSRCPW> indicates the ALS recovery pulse width. The range is 2–100 seconds, in increments of 100ms, e.g. 30.1; <ALSRCPW> is a float • <COMM> indicates if the GCC or DCC is enabled or disabled. The GCC can be enabled only if the digital wrapper has been enabled for the card. The default is NONE. Valid values are shown in the “COMM_TYPE” section on page 4-54. Rules for an MXP_2.5G_10G/TXP_MR_10G client port are; only the DCC can be provisioned, if the termination mode is not transparent and the payload is SONET. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the DCC can be enabled only if the G.709 is not enabled and if the payload is SONET and the termination mode is not transparent. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the GCC can be enabled if there is no DCC and the G.709 flag is enabled. • <MACADDR> identifies the MAC address for the 10GEthernet payload; <MACADDR> is a string • <SYNCMSG> indicates that the facility be enabled to provide the synchronization clock. This does not apply to a TXP_MR_10G card. This applies to an MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT - All Client ports are available for all timing selections. All Trunk ports are not available. Valid values are shown in the “ON_OFF” section on page 4-76 <p>LINE - All ports are available for all-timing selections.</p> |

| Section | ED-CLNT Description |
|-----------------------------|--|
| Input Format (continued) | <ul style="list-style-type: none"> <SENDDUS> indicates that the facility send out a Do not Use for Sync message. This does not apply to a TXP_MR_10G card. This applies to an MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT - All Client ports are available for all timing selections. All Trunk ports are not available. LINE - All ports are available for all-timing selections. Valid values are shown in the “ON_OFF” section on page 4-76 <RLASER> indicates if the laser should be restarted. This is applicable only if the ALSMODE is not automatic; valid values are shown in the “ON_OFF” section on page 4-76 <SOAK> OOS-AINS to IS transition soak time as measured in 15-minute intervals. A value of 4 translates to a soak time of one hour. The allowable range is 0–192 intervals (maximum of 48–hours). <SOAK> is an integer <OSPF> indicates the OSPF discovery. <OSPF> can be edited only if the DCC is enabled; valid values are shown in the “ON_OFF” section on page 4-76 <PST> primary state; valid values are shown in the “PST” section on page 4-83 <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ED-CLNT:CISCO:FAC-1-1:100:::NAME=“NY PORT”,SFBER=1E-4,SDBER=1E-5,ALSMODE=Y,ALSRCINT=30, ALSRCPW=35.1,COMM=DCC,MACADDR=00-0E-AA-BB-CC-FF, SYNCMSG=Y,SENDDUS=Y,RLASER=Y,SOAK=10,OSPF=Y:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.37 ED-CMD-SECU: Edit Command Security

This command edits the command security level of a particular command.

| Section | ED-CMD-SECU Description | | | | | | | | | | | | | | | | | | | | |
|---------------------|--|----------|--------------|--------------|---------------|---------------|---------------|------|---------------|-----------|------------------|----------------|---------------|---------------|----------------|--------|----------------|--------------|-------------------|---------------|--|
| Category | Security | | | | | | | | | | | | | | | | | | | | |
| Security | Administrator | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tbody> <tr> <td>ACT-USER</td> <td>INH-MSG-SECU</td> </tr> <tr> <td>ALW-MSG-SECU</td> <td>INH-USER-SECU</td> </tr> <tr> <td>ALW-USER-SECU</td> <td>REPT ALM SECU</td> </tr> <tr> <td>CANC</td> <td>REPT EVT SECU</td> </tr> <tr> <td>CANC-USER</td> <td>REPT EVT SESSION</td> </tr> <tr> <td>CANC-USER-SECU</td> <td>RTRV-CMD-SECU</td> </tr> <tr> <td>DLT-USER-SECU</td> <td>RTRV-DFLT-SECU</td> </tr> <tr> <td>ED-PID</td> <td>RTRV-USER-SECU</td> </tr> <tr> <td>ED-USER-SECU</td> <td>SET-ATTR-SECUDFLT</td> </tr> <tr> <td>ENT-USER-SECU</td> <td></td> </tr> </tbody> </table> | ACT-USER | INH-MSG-SECU | ALW-MSG-SECU | INH-USER-SECU | ALW-USER-SECU | REPT ALM SECU | CANC | REPT EVT SECU | CANC-USER | REPT EVT SESSION | CANC-USER-SECU | RTRV-CMD-SECU | DLT-USER-SECU | RTRV-DFLT-SECU | ED-PID | RTRV-USER-SECU | ED-USER-SECU | SET-ATTR-SECUDFLT | ENT-USER-SECU | |
| ACT-USER | INH-MSG-SECU | | | | | | | | | | | | | | | | | | | | |
| ALW-MSG-SECU | INH-USER-SECU | | | | | | | | | | | | | | | | | | | | |
| ALW-USER-SECU | REPT ALM SECU | | | | | | | | | | | | | | | | | | | | |
| CANC | REPT EVT SECU | | | | | | | | | | | | | | | | | | | | |
| CANC-USER | REPT EVT SESSION | | | | | | | | | | | | | | | | | | | | |
| CANC-USER-SECU | RTRV-CMD-SECU | | | | | | | | | | | | | | | | | | | | |
| DLT-USER-SECU | RTRV-DFLT-SECU | | | | | | | | | | | | | | | | | | | | |
| ED-PID | RTRV-USER-SECU | | | | | | | | | | | | | | | | | | | | |
| ED-USER-SECU | SET-ATTR-SECUDFLT | | | | | | | | | | | | | | | | | | | | |
| ENT-USER-SECU | | | | | | | | | | | | | | | | | | | | | |

| Section | ED-CMD-SECU Description |
|---------------|--|
| Input Format | ED-CMD-SECU:[<TID>]:<AID>:<CTAG>::<CAP>; where: <ul style="list-style-type: none">• <AID> is the access identifier string. It is the command verb along with the verb modifier(s) as it currently exists. It may be a single command or a block of commands where the block may include all commands. Only INIT-REG is supported in this release (R4.6). <AID> is a string and must not be null• <CAP> is the command access privilege; valid values are shown in the “PRIVILEGE” section on page 4-82. <CAP> must not be null |
| Input Example | ED-CMD-SECU::INIT-REG:1::SU; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.38 ED-CRS-<PATH>:ED Cross Connect (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS 48C, STS192C, VT1, VT2)

This command edits the state of an STS or VT cross-connection.

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

| Section | ED-CRS-<PATH> Description |
|------------------|--|
| Category | Cross Connections |
| Security | Provisioning |
| Related Messages | DLT-CRS-<PATH> RTRV-CRS ENT-CRS-<PATH> RTRV-CRS-<PATH> |
| Input Format | ED-CRS-<PATH>:[<TID>]:<SRC>,<DST>:<CTAG>:::[ADD=<ADD>],[REMOVE=<REMOVE>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none">• <SRC> is the AID from the “CrossConnectId1” section on page 4-23• <DST> is the AID from the “CrossConnectId1” section on page 4-23• <ADD> is the AID from the “CrossConnectId1” section on page 4-23• <REMOVE> is the AID from the “CrossConnectId1” section on page 4-23• <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83• <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |
| Input Example | ED-CRS-STS3C::STS-1-1-1,STS-2-1-1:1::ADD=STS-13-1-1, REMOVE=STS-2-1-1:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.39 ED-DAT: Edit Date and Time

This command edits the date and the time

| Section | ED-DAT Description | |
|------------------|--|--|
| Category | System | |
| Security | Provisioning | |
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG INIT-SYS RTRV-HDR | RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |
| Input Format | ED-DAT:[<TID>]::<CTAG>::[<DATE>],[<TIME>]; where: <ul style="list-style-type: none"> • <DATE> identifies the date and is a string • <TIME> identifies the time and is a string | |
| Input Example | ED-DAT:CISCO::1234::99-12-21,14-35-15; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.40 ED-DS1: Edit DS1

(Cisco ONS 15454 only)

This command edits the test access attribute for DS1 access on a DS3XM card.



Note This command is not allowed if the card is a protecting card.

| Section | ED-DS1 Description | |
|------------------|---|---|
| Category | Ports | |
| Security | Provisioning | |
| Related Messages | ED-<OCN_TYPE> ED-EC1 ED-FAC ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<OCN_TYPE> | RTRV-DS1 RTRV-EC1 RTRV-FAC RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |

| Section | ED-DS1 Description |
|---------------|--|
| Input Format | <p>ED-DS1:[<TID>]:<AID>:<CTAG>:::[TACC=<TACC>,<TAPTYPE=<TAPTYPE>>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the DS1 AID from the “DS1” section on page 4-26 • <TACC> is the TAP number. The TAP number ranges from 0–999. When <TACC> is 0, the TAP is deleted. <TACC> is an integer • <TAPTYPE> is the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92. The default value is DUAL |
| Input Example | ED-DS1:PETALUMA:DS1-2-1-6-12:123:::TACC=8,TAPTYPE=DUAL; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.41 ED-DWDM: Edit Dense Wavelength Division Multiplexing

(Cisco ONS 15454 only)

The command edits an already pre-provisioned/provisioned MXP_2.5G_10G/TXP_MR_10G card. It changes the operating parameters for the card.

The rules for provisioning a regeneration group are: a regeneration group can be created only between a pair of TXP cards. The peer slot should contain a card of the same type, and should not have an existing regeneration group for the same slot. The termination mode should be identical for the cards. All the client port level settings should be identical for the cards. Setting the PEERID=NULL will remove an existing regeneration group. The two TXP cards should be set to transparent termination mode to successfully create a regeneration group.

The rules for provisioning the payload field are as follows: For a TXP_MR_10G card, the SONET/10GE (Ethernet) applies. For a TXP_MR_2.5G card or TXPP_MR_2.5G card, the options of SONET/10GE are not applicable. Instead, the actual protocol; for example, OC3/OC12/OC48/STM1 should be used. The port has to be in OOS state for a payload change to be successful. There should be no Trace enabled for the port. To set the Payload to 10GE, the termination mode should already be in Transparent mode.

The MXP_2.5_10G card does not support 10GE payload. To change the payload type for the MXP_2.5_10G card, all the ports should be in OOS state.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | ED-DWDM Description |
|----------|---------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | ED-DWDM Description |
|------------------|--|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT OPR-PROTNSW-OCH |
| Input Format | ED-DWDM:[<TID>]:<AID>:<CTAG>:::[PEERID=<PEERID>,<NAME=<NAME>>][TERMMODE=<TERMMODE>,<PAYLOAD=<PAYLOAD>>][PWL=<PWL>]; where: <ul style="list-style-type: none"> • <AID> is from the “EQPT” section on page 4-27 • <PEERID> peer regeneration group card slot AID from the “EQPT” section on page 4-27 • <NAME> name for the regeneration group; <NAME> is a string • <TERMMODE> termination mode of the card; valid values are shown in the “TERM_MODE” section on page 4-92 • <PAYLOAD> type of payload supported by the card; valid values are shown in the “EQPT_TYPE” section on page 4-59 • <PWL> provisioned wavelength; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 |
| Input Example | ED-DWDM:VA454-22:SLOT-1:100:::PEERID=SLOT-2, NAME=“NY GROUP”,TERMMODE=TRANS,PAYLOAD=OC48,PWL=1546.52; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.42 ED-EC1: Edit Electrical Carrier

(Cisco ONS 15454 only)

This command edits the attributes of an EC1.



This command is not allowed if the card is a protecting card.

| Section | ED-EC1 Description | |
|------------------|--|------------|
| Category | Ports | |
| Security | Provisioning | |
| Related Messages | ED-<OCN_TYPE> | RTRV-DS1 |
| | ED-DS1 | RTRV-EC1 |
| | ED-G1000 | RTRV-FSTE |
| | ED-T1 | RTRV-G1000 |
| | ED-T3 | RTRV-GIGE |
| | INIT-REG-G1000 | RTRV-POS |
| | RMV-<MOD2_IO> | RTRV-T1 |
| | RST-<MOD2_IO> | RTRV-T3 |
| | RTRV-<OCN_TYPE> | |
| Input Format | ED-EC1:[<TID>]:<AID>:<CTAG>:::[PJMON=<PJMON>],[LBO=<LBO>],[SOAK=<SOAK>],[SFBER=<SFBER>],[SDBER=<SDBER>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none"> • <AID> is a facility AID of an EC1 port and is from the “FACILITY” section on page 4-28 • <PJMON> is a SONET pointer number (0 or 1) of an EC1 port and is an integer • Valid values for <LBO> are shown in the “E_LBO” section on page 4-58 • <SOAK> OOS-AINS to IS transition soak time as measured in 15 minute intervals, so a value of 4 translates to a soak time of 1 hour. The allowable range is 0–192 intervals (maximum of 48 hours). <SOAK> is an integer • <SFBER> identifies port SFBER; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies port SDBER; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 | |
| Input Example | ED-EC1:CISCO:FAC-1-1:123:::PJMON=0,LBO=0-225,SOAK=10,SFBER=1E-4, SDBER=1E-6:OOS,AINS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.43 ED-EQPT: Edit Equipment

This command edits the attributes for a given equipment slot in the NE. If the card is in an equipment slot, this command is allowed only on the working AID.

The PROTID parameter indicates the unique identifier of the protection group (the protect card). “NULL” is a special value of the PROTID parameter and indicates absence of a protection group. For 1:1 protection type, RVRTV and RVTM parameters can be changed. For 1:1 protection type, if the PROTID parameter is entered as “NULL”, the protection group is deleted.

ED-EQPT:[<TID>]:SLOT-2:<CTAG>:::PROTID=NULL;

For 1:N protection type, if the PROTID is “NULL”, the AIDs in the list are removed from the protection group. If all the working cards are in the AID list, the protection group is deleted.

Example: if Slot-1, Slot-2 and Slot-4 were the only working cards in the protection group. The following command will remove Slot-4 from the protection group:

```
ED-EQPT:[<TID>]:SLOT-4:<CTAG>:::PROTID=NULL;
```

The protection group still has Slot-1 and Slot-2 as working cards.

The following command will remove all the other working cards in the above example and consequently, delete the protection group itself:

```
ED-EQPT:[<TID>]:SLOT-2&SLOT-1:<CTAG>:::PROTID=NULL;
```

The ED-EQPT command can be successfully executed on an already provisioned card to add a working card to or remove one from a protection group. This command is not valid on a protect card. Only cards can be added to or removed from a protection group. Protection type is immutable and is determined at the time of creation of a protection group (while adding the first working card). Once provisioned, the equipment type cannot be edited either.

Examples of adding an existing card to a protection group using the ED-EQPT command:

1:1 protection group

```
ED-EQPT::SLOT-2:12:::PROTID=SLOT-1,RVRTV=Y,RVTM=9.0;
```

1:N protection group

```
ED-EQPT::SLOT-2:12:::PROTID=SLOT-3,PRTYPE=1-N,RVTM=6.5;
```

Error conditions for editing a 1:1 or 1:N protection group may be:

1. Editing the PRTYPE or PROTID (non-NULL value) parameters.
2. Editing RVRTV or RVTM when no protection group exists.
3. Editing RVRTV for 1:N protection.
4. Failed to remove, currently switched to protect.
5. If the command mode (CMDMDE) is set to forced (FRCD) during the creation of a 1:1 or 1:N protection group, all cards must be physically plugged in and in the ready state (IS). If the cards are not physically plugged in, then the command is denied with an appropriate error message. When the command mode is set to normal (NORM) (which is the default) the cards do not have to be physically plugged in and in the ready state.
6. If the command mode is set to forced (FRCD) during the removal of a card in a 1:1 or 1:N protection group, there must be no cross-connects (i.e., services) present on the card. If there are cross-connects present on the card, the command is denied with an appropriate error message. If the command mode is set to normal (NORM) (which is the default), it does not require that cross-connects be deleted on the card.

| Section | ED-EQPT Description |
|----------|---------------------|
| Category | Equipment |
| Security | Provisioning |

| Section | ED-EQPT Description | |
|------------------|---|---|
| Related Messages | ALW-SWDX-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ENT-EQPT INH-SWDX-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT REPT ALM EQPT | REPT EVT EQPT REPT RMV EQPT REPT RST EQPT RTRV-ALM-EQPT RTRV-COND-EQPT RTRV-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | ED-EQPT:[<TID>]:<AID>:<CTAG>:::[PROTID=<PROTID>,<PRTYPE=<PRTYPE>,<RVRTV=<RVRTV>,<RVTM=<RVTM>,<CMDMDE=<CMDMDE>>][::]; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “EQPT” section on page 4-27• <PROTID> is the protecting card slot number of the protection group. <PROTID> is the AID from the “PRSLOT” section on page 4-31• <PRTYPE> is the protection group type; valid values for <PRTYPE> are shown in the “PROTECTION_GROUP” section on page 4-83• <RVRTV> is the revertive mode; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76• <RVTM> is the revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84• <CMDMDE> is the command mode. It is only applicable when creating or deleting a 1:1 or 1:N protection group and/or adding cards to an existing protection group (1:N). The default is NORM. Valid values are shown in the “CMD_MODE” section on page 4-54. If creating or adding cards to a protection group, specifying FRCD will require the card to be physically plugged in and in the ready state (IS). If removing cards from a 1:N protection group or deleting a 1:1 or 1:N protection group, specifying FRCD will require that there are no cross-connects (i.e., services) on the card. | |
| Input Example | ED-EQPT:CISCO:SLOT-2:123:::PROTID=SLOT-1,PRTYPE=1-1,RVRTV=Y,RVTM=9.0,CMDMDE=FRCD; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.44 ED-FC: Edit Fiber Channel Facility

This command edits the attributes related to the fiber channel facility.



Note The OOS,AINS is not supported on the FC port.

| Section | ED-FC Description |
|----------|-------------------|
| Category | Ports |
| Security | Provisioning |

| Section | ED-FC Description | |
|------------------|---|---|
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FAC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<OCN_TYPE> | RTRV-DS1 RTRV-EC1 RTRV-FAC RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |
| Input Format | ED-FC:[<TID>]:<AID>:<CTAG>:::[PAYLOAD=<PAYLOAD>],[LINKRCVRY=<LINKRCVRY>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none">• <AID> is the facility AID from the “FACILITY” section on page 4-28• <PAYLOAD> payload type. Can be 1GFC or 2GFC. Valid values are shown in the “FC_LINKRATE” section on page 4-65• <LINKRCVRY> link recovery; valid values are shown in the “ON_OFF” section on page 4-76• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 | |
| Input Example | ED-FC:CISCO1:FAC-6-1:1:::PAYLOAD=2GFC,LINKRCVRY=Y:OOS,MT; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.45 ED-FFP-<OCN_TYPE>: Edit Facility Protection Group (OC3, OC12, OC48, OC192)

See [Table 4-11](#) on page 4-5 for supported modifiers by platform.

This command edits the optical facility protection.



This command can be used on both protecting and working AIDs.

| Section | ED-FFP-<OCN_TYPE> Description | |
|------------------|---|---|
| Category | SONET Line Protection | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-CLNT ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT EX-SW-<OCN_BLSR> | OPR-PROTNST-<OCN_TYPE> RLS-PROTNST-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-PROTNST-<OCN_TYPE> |

| Section | ED-FFP-<OCN_TYPE> Description |
|---------------|---|
| Input Format | <p>ED-FFP-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>:::[PROTID=<PROTID>],[RVRTV=<RVRTV>],[RVTM=<RVTM>],[PSDIRN=<PSDIRN>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the facility AID from the “FACILITY” section on page 4-28 • <PROTID> is the protection group identifier (protection group name) and is a string; <PROTID> can have a maximum of 32 characters • <RVRTV> identifies a revertive mode; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies a revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 • <PSDIRN> identifies the switching mode; valid values for <PSDIRN> are shown in the “UNI_BI” section on page 4-96 |
| Input Example | ED-FFP-OC3:PETALUMA:FAC-1-1:1:::PROTID=PROT_NAME,RVRTV=Y,RVTM=1.0,PSDIRN=BI; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.46 ED-FFP-CLNT: Edit Facility Protection Group Client

(Cisco ONS 15454 only)

This command edits a Y cable protection group on client facilities.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | ED-FFP-CLNT Description |
|----------|-------------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | ED-FFP-CLNT Description |
|------------------|--|
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT ENT-LNK-<MOD2O> EX-SW-<OCN_BLSR> OPR-LASER-OTS OPR-PROTNSW-<OCN_TYPE> OPR-PROTNSW-CLNT |
| Input Format | ED-FFP-CLNT:[<TID>]:<AID>:<CTAG>:::[PROTID=<PROTID>],[RVRTV=<RVRTV>],[RVTM=<RVTM>],[PSDIRN=<PSDIRN>][[:]; where: <ul style="list-style-type: none"> • <AID> identifies a port in a protection group and is the AID from the “FACILITY” section on page 4-28 • <PROTID> is a protection group identifier (protection group name). It defaults to the protecting port AID of the protection group. It is a string and can have a maximum length of 32 characters. <PROTID> is a string • <RVRTV> identifies a revertive mode. The retrieve behavior defaults to N (non-revertive mode); valid values are shown in the “ON/OFF” section on page 4-76 • <RVTM> identifies a revertive time. The revertive time defaults to 5.0 minutes; valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <PSDIRN> identifies the switching mode and defaults to UNI. MXP_2.5G_10G/TXP_MR_10G cards do not support BI-DIRECTIONAL switching. Valid values for <PSDIRN> are shown in the “UNI_BI” section on page 4-96 |
| Input Example | ED-FFP-CLNT:CISCO:FAC-1-1:100:::PROTID=DC-METRO,RVRTV=N,RVTM=1.0,PSDIRN=BI; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.47 ED-FFP-OCH: Edit Facility Protection Group OCH

(Cisco ONS 15454 only)

This command changes the provisioning for the default protection group on the DWDM port of a TXP_MR_2.5G and TXPP_MR_2.5G card.

| Section | ED-FFP-OCH Description | |
|------------------|---|---|
| Category | DWDM | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT ENT-LNK-<MOD2O> EX-SW-<OCN_BLSR> OPR-LASER-OTS OPR-PROTNSTW-<OCN_TYPE> OPR-PROTNSTW-CLNT | OPR-PROTNSTW-OCH RLS-LASER-OTS RLS-PROTNSTW-<OCN_TYPE> RLS-PROTNSTW-CLNT RLS-PROTNSTW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-FPP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSTW-<OCN_TYPE> RTRV-PROTNSTW-CLNT RTRV-PROTNSTW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | ED-FFP-OCH:<TID>:<AID>:<CTAG>:::[PROTID=<PROTID>, [RVRTV=<RVRTV>,][RVTM=<RVTM>],[PSDIRN=<PSDIRN>][:]; where: <ul style="list-style-type: none">• <AID> is the AID from the “CHANNEL” section on page 4-19• <PROTID> is a protection group and is a string• <RVRTV> identifies a revertive mode; valid values are shown in the “ON_OFF” section on page 4-76• <RVTM> identifies a revertive time; valid values are shown in the “REVERTIVE_TIME” section on page 4-84• Valid values for <PSDIRN> are shown in the “TRANS_MODE” section on page 4-93 | |
| Input Example | ED-FFP-OCH:VA454-22:CHAN-2-2:100:::PROTID=“FIXED PROTECTION”,RVRTV=N,RVTM=1.0,PSDIRN=BI; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.48 ED-G1000: Edit G1000

This command edits the attributes related to a G1000 port.

**Note**

The state OOS-AINS is not supported on the G1000.

| Section | ED-G1000 Description | |
|------------------|---|---|
| Category | Ports | |
| Security | Provisioning | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-T1 ED-T3 INIT-REG-G1000 RMV-<MOD2_IO> RST-<MOD2_IO> RTRV-<OCN_TYPE> | RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |
| Input Format | ED-G1000:[<TID>]:<AID>:<CTAG>:::[MFS=<MFS>],[FLOW=<FLOW>], [LOWMRK=<LOWMRK>],[HIWMRK=<HIWMRK>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none"> • <AID> is the AID facility from the “FACILITY” section on page 4-28 • Valid values for <MFS> are shown in the “MFS_TYPE” section on page 4-68 • Valid values for <FLOW> are shown in the “ON_OFF” section on page 4-76 • <LOWMRK> low watermark value and an integer • <HIWMRK> high watermark value and an integer • <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 | |
| Input Example | ED-G1000:TID:FAC-1-1:CTAG:::MFS=1548,FLOW=Y,LOWMRK=20, HIWMRK=492:OOS,AINS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.49 ED-LNK-<MOD20>: Edit Link (OCH, OMS, OTS)

(Cisco ONS 15454 only)

This command edits an optical link state.

| Section | ED-LNK-<MOD20> Description |
|----------------|---|
| Category | DWDM |
| Security | Provisioning |

| Section | ED-LNK-<MOD2O> Description | |
|------------------|--|---|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSTW-CLNT OPR-PROTNSTW-OCH | RLS-LASER-OTS RLS-PROTNSTW-CLNT RLS-PROTNSTW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OTS RTRV-OMS RTRV-PROTNSTW-CLNT RTRV-PROTNSTW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | ED-LNK-<MOD2O>:[<TID>]:<FROM>,<TO>:<CTAG>:::<PST>,[<SST>]; where: <ul style="list-style-type: none">• <FROM> indicates an identifier at one end of the optical link and is the AID from the “BAND” section on page 4-18• <TO> indicates an identifier at the other end of the optical link and is the AID from the “BAND” section on page 4-18• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 | |
| Input Example | ED-LNK-OMS: PENNGROVE:BAND-6-1-TX,BAND-13-1-RX:114:::OOS,AINS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.50 ED-NE-GEN: Edit Network Element General

This command edits the node attributes of the NE.

Notes:

1. Only the IPADDR, IPMASK, DEFTRR, IIOP PORT and node name can be modified with this command.
2. The node name can be a maximum of 20 characters. If the entered name exceeds 20 characters, an IPNV (Node Name Too Long) error message is returned.
3. An existing timing source can be removed by setting the address to 0.0.0.0.



Changing the IPADDR, IPMASK, or IIOP Port will cause a reset of the TCC2.

| Section | ED-NE-GEN Description |
|----------|-----------------------|
| Category | System |
| Security | Superuser |

| Section | ED-NE-GEN Description |
|------------------|---|
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-DAT ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG INIT-SYS RTRV-HDR |
| Input Format | ED-NE-GEN:[<TID>]::<CTAG>:::[NAME=<NAME>],[IPADDR=<IPADDR>],[IPMASK=<IPMASK>],[DEFRTR=<DEFRTR>],[IOPPORT=<IOPPORT>],[NTP=<NTP>]; where: <ul style="list-style-type: none">• <NAME> indicates the node name and is a string• <IPADDR> indicates the node IP address and is a string• <IPMASK> indicates the node IP mask and is a string• <DEFRTR> indicates the node default router and is a string• <IOPPORT> indicates the node IOPPORT and is an integer• <NTP> indicates the node's NTP timing origin address and is a string |
| Input Example | ED-NE-GEN:CISCO::123:::NAME=NODENAME,IPADDR=192.168.100.52,IPMASK=255.255.255.0,DEFRTR=192.168.100.1,IOPPORT=57790,NTP=192.168.100.52; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.51 ED-NE-PATH: Edit Network Element Paths

This command edits the path attributes of the NE.

| Section | ED-NE-PATH Description |
|------------------|--|
| Category | System |
| Security | Provisioning |
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-DAT ED-NE-GEN ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG INIT-SYS RTRV-HDR |
| | RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |

| Section | ED-NE-PATH Description |
|---------------|--|
| Input Format | ED-NE-PATH:<TID>::<CTAG>[::PDIP=<PDIP>]; where: <ul style="list-style-type: none">• <PDIP> flag used to indicate whether PDI-P should be generated on the outgoing VT-structured STSs. PDI-P is specified in GR-253 (Issue2 Rev2 1999) CR6-261 (6.2.1.4.1); valid values are shown in the “ON_OFF” section on page 4-76 |
| Input Example | ED-NE-PATH:::CTAG:::PDIP=Y; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.52 ED-NE-SYNCN: Edit Network Element Synchronization

This command edits the synchronization attributes of the NE.

Notes:

1. Although mixed mode timing is supported in this release, it is not recommended. See the “[Mixed Mode Timing Support](#)” section on page 1-19 for more information.
2. The existing external and line modes have the same functionality in all ONS 15454 4.x releases:
External mode: the node derives its timing from the BITS inputs.
Line mode: the node derives its timing from the SONET line(s).
Mixed mode: the node derives its timing from the BITS input or SONET lines.

| Section | ED-NE-SYNCN Description | |
|------------------|--|---|
| Category | Synchronization | |
| Security | Provisioning | |
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-BITS ED-DAT ED-NE-GEN ED-NE-PATH ED-SYNCN INH-MSG-ALL INH-MSG-DBCHG INIT-SYS OPR-SYNCNSW REPT ALM BITS REPT ALM SYNCN REPT EVT BITS REPT EVT SYNCN RLS-SYNCNSW | RTRV-ALM-BITS RTRV-ALM-SYNCN RTRV-BITS RTRV-COND-BITS RTRV-COND-SYNCN RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-SYNCN RTRV-TOD SET-TOD |

| Section | ED-NE-SYNCN Description |
|---------------|---|
| Input Format | <p>ED-NE-SYNCN:[<TID>]::<CTAG>:::[TMMD=<TMMD>,<SSMGEN=<SSMGEN>,<QRES=<QRES>,<RVRTV=<RVRTV>,<RVTM=<RVTM>>;</p> <p>where:</p> <ul style="list-style-type: none"> • <TMMD> is the timing mode; valid values for <TMMD> are shown in the “TIMING_MODE” section on page 4-92 • <SSMGEN> is the SSM message set; valid values for <SSMGEN> are shown in the “SYNC_GENERATION” section on page 4-89 • <QRES> is the quality of the RES; valid values for <QRES> are shown in the “SYNC_QUALITY_LEVEL” section on page 4-89 • <RVRTV> is the revertive mode; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 • <RVTM> is the revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 |
| Input Example | ED-NE-SYNCN:CISCO::123:::TMMD=LINE,SSMGEN=GEN1,QRES=ABOVE-PRS,RVRTV=Y,RVTM=8.0; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.53 ED-OCH: Edit Optical Channel

(Cisco ONS 15454 only)

This command edits the attributes (service parameters) and state of an OCH facility.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | ED-OCH Description |
|----------|--------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | ED-OCH Description | |
|------------------|--|---|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSTW-CLNT OPR-PROTNSTW-OCH | RLS-LASER-OTS RLS-PROTNSTW-CLNT RLS-PROTNSTW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OTS RTRV-OMS RTRV-OTS RTRV-PROTNSTW-CLNT RTRV-PROTNSTW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | ED-OCH:[<TID>]:<AID>:<CTAG>:::[RDIRN=<RDIRN>,<EXPWLEN=<EXPWLEN>,<VOAATTN=<VOAATTN>,<VOAPWR=<VOAPWR>,<CALOPWR=<CALOPWR>,<CHPOWER=<CHPOWER>,<NAME=<PORTNAME>,<SFBER=<SFBER>,<SDBER=<SDBER>,<ALSMODE=<ALSMODE>,<ALSRCINT=<ALSRCINT>,<ALSRCPW=<ALSRCPW>,<COMM=<COMM>,<GCCRATE=<GCCRATE>,<OSDBER=<OSDBER>,<DWRAP=<DWRAP>,<FEC=<FEC>,<MACADDR=<MACADDR>,<SYNCMSG=<SYNCMSG>,<SENDDUS=<SENDDUS>,<RLASER=<RLASER>,<SOAK=<SOAK>,<OSPF=<OSPF>]:<PST>,<SST>]; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “CHANNEL” section on page 4-19• <RDIRN> identifies the ring directionality of the optical line; valid values are shown in the “RDIRN_MODE” section on page 4-83• <EXPWLEN> identifies the expected value of wavelength for this port. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. Valid values are shown in the “OPTICAL_WLEN” section on page 4-78• <VOAATTN> indicates the value of calibrated attenuation for the VOA. It is expressed in dBm. For the following cards: optical service channel, optical amplifier, dispersion compensation units, multiplexor and demultiplexor and OADM, the range is 0.0 to +30.0. <VOAATTN> is a float• <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as a result of its attenuation. Applicable only to the following cards: optical service channel, optical amplifier, dispersion compensation units, multiplexor and demultiplexor and OADM. <VOAPWR> is a float• <CALOPWR> indicates the value of the calibrated optical power expected for the output line added to the calculated value which equals the total expected output power; <CALOPWR> is a float expressed in dBm. | |

| Section | ED-OCH Description |
|-----------------------------|---|
| Input Format (continued) | <ul style="list-style-type: none"> • <CHPOWER> indicates the value of per channel optical power expected to the OCH drop port of an AD-4C unit. <CHPOWER> is a float expressed in dBm. Valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <PORTNAME> identifies a port name and is a string • <SFBER> identifies the SFBER for the SONET payload; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies the SDBER for the SONET payload; valid values are shown in the “SD_BER” section on page 4-85 • <ALSMODE> indicates if the Automatic Laser Shutdown is enabled or disabled; valid values are shown in the “ALS_MODE” section on page 4-49 • <ALSRCINT> indicates the ALS recovery interval. Range is 100–300 seconds; <ALSRCINT> is an integer • <ALSRCPW> indicates the ALS recovery pulse width. The range is 2–100 seconds, in increments of 100ms, e.g. 30.1; <ALSRCPW> is a float • <COMM> indicates if the GCC or DCC is enabled or disabled. The GCC can be enabled only if the digital wrapper has been enabled for the card. The default is NONE. Valid values are shown in the “COMM_TYPE” section on page 4-54. Rules for an MXP_2.5G_10G/TXP_MR_10G client port are; only the DCC can be provisioned, if the termination mode is not transparent and the payload is SONET. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the DCC can be enabled only if the G.709 is not enabled and if the payload is SONET and the termination mode is not transparent. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the GCC can be enabled if there is no DCC and the G.709 flag is enabled. • <GCCRATE> indicates the data rate of the GCC traffic. Valid values are shown in the “GCCRATE” section on page 4-66. The default is 192Kbps. For MXP_2.5G_10G/TXP_MR_10G cards this applies only to the DWDM port. The 576K option is not supported for this release. • <OSDBER> identifies the signal degrade threshold setting for the OTN level. Applicable only if the G.709 is enabled; valid values are shown in the “SD_BER” section on page 4-85 |

| Section | ED-OCH Description |
|-----------------------------|---|
| Input Format (continued) | <ul style="list-style-type: none"> • <DWRAP> is the G.709 digital wrapper. It is either on or off. The system default is ON. For MXP_2.5G_10G/TXP_MR_10G cards, this applies only to the DWDM port. To enable G.709 there should be no GCC on the DWDM port. To disable G.709 there should be no GCC on the DWDM port. The FEC should be turned to off; valid values are shown in the “ON/OFF” section on page 4-76 • <FEC> is the Forward Error Correction. It can be enabled only if the G.709 is turned ON. It is either on or off. The system default is ON. For MXP_2.5G_10G/TXP_MR_10G cards this applies only to the DWDM port. The FEC level PM and thresholds apply if the FEC is turned on; valid values are shown in the “ON/OFF” section on page 4-76 • <MACADDR> identifies the MAC address for the 10GE payload; <MACADDR> is a string • <SYNCMSG> indicates that the facility be enabled to provide the synchronization clock. This does not apply to a TXP_MR-10G card. This applies to an MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT - All Client ports are available for all timing selections. All Trunk ports are not available. LINE - All ports are available for all-timing selections. Valid values are shown in the “ON/OFF” section on page 4-76 • <SENDDUS> indicates that the facility send out a Do not Use for Sync message. This does not apply to a TXP card. This applies to an MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT- All Client ports are available for all timing selections. All Trunk ports are not available. LINE - All ports are available for all-timing selections. Valid values are shown in the “ON/OFF” section on page 4-76 • <RLASER> indicates if the laser should be restarted. This is applicable only if the ALSMODE is not automatic; valid values are shown in the “ON/OFF” section on page 4-76 • <SOAK> OOS-AINS to IS transition soak time as measured in 15-minute intervals. A value of 4 translates to a soak time of one hour. The allowable range is 0–192 intervals (maximum of 48-hours). <SOAK> is an integer • <OSPF> indicates the OSPF discovery. <OSPF> can be edited only if the DCC is enabled; valid values are shown in the “ON/OFF” section on page 4-76 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ED-OCH:CISCO:CHAN-6-2:114:::RDIRN=W-E,EXPWLEN=1530.32, VOAATTN=2.5,VOAPWR=7.5,CALOPWR=0.0,CHPOWER=2.0, NAME="NY LINE",SFBER=1E-5,SDBER=1E-6,ALSMODE=Y, ALSRCINT=30,ALSRCPW=35.1,COMM=DCC,GCCRATE=192K, OSDBER=1E-5,DWRAP=Y,FEC=Y,MACADDR=00-0E-AA-BB-CC-DD, SYNCMSG=N,SENDDUS=Y,RLASER=Y,SOAK=10,OSPF=Y:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.54 ED-OMS: Edit Optical Multiplex Section

(Cisco ONS 15454 only)

This command edits the attributes (service parameters) and state of an OMS facility.

| Section | ED-OMS Description | |
|------------------|--|---|
| Category | DWDM | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT OPR-PROTNSW-OCH | RLS-LASER-OTS RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |

| Section | ED-OMS Description |
|---------------|---|
| Input Format | <p>ED-OMS:[<TID>]:<AID>:<CTAG>:::[RDIRN=<RDIRN>,<EXPBAND=<EXPBAND>,>][VOAATTN=<VOAATTN>,>][VOAPWR=<VOAPWR>,>][CALOPWR=<CALOPWR>,>][CHPOWER=<CHPOWER>]:<PST>],<SST>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “BAND” section on page 4-18 • <RDIRN> identifies the ring directionality of the optical line; valid values are shown in the “RDIRN_MODE” section on page 4-83 • <EXPBAND> identifies the expected value of band for this port; valid values are shown in the “OPTICAL_BAND” section on page 4-76 • <VOAATTN> indicates the value of calibrated attenuation for the VOA. The range is 0,0 to +3.0. <VOAATTN> is a float • <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as a result of its attenuation. <VOAPWR> is a float • <CALOPWR> indicates the value of the calibrated optical power expected for the output line which you provide to sum with the calculated value to have the total expected output power; <CALOPWR> is a float expressed in dBm • <CHPOWER> indicates the value of per channel optical power expected to the OMS port in a DROP port of an AD-1B or AD-4B unit; <CHPOWER> is a float expressed in dBm • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ED-OMS:PENNGROVE:BAND-6-1:114:::RDIRN=W-E, EXPBAND=1530.32-1532.68,VOAATTN=2.5,VOAPWR=7.5,CALOPWR=0.0, CHPOWER=2.0:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.55 ED-OSC: Edit Optical Service Channel

(Cisco ONS 15454 only)

This command edits the OSC (optical service channel) group attributes.

| Section | ED-OSC Description |
|------------------|-------------------------------|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | ENT-OSC DLT-OSC RTR-OSC |

| Section | ED-OSC Description |
|---------------|--|
| Input Format | <p>ED-OSC:[<TID>]:<AID>:<CTAG>:::[RINGID=<RINGID>,<NODEID=<NODEID>>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the OSC group of the NE and is the AID from the “OSC section on page 4-30” • <RINGID> identifies the OSC ring ID of the NE. <RINGID> is a string of up to six characters. Valid characters are [A-Z, 0-9]. <RINGID> is a string and the default value is “# of AID OSC-#”. <RINGID> is an integer • <NODEID> identifies the OSC node ID of the NE. <NODEID> ranges from 0 to 31 and is an integer |
| Input Example | ED-OSC: PENNGROVE:OSC-1:114:::RINGID=1,NODEID=10; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.56 ED-OTS: Edit OTS

(Cisco ONS 15454 only)

This command edits the attributes (service parameters) and state of an OTS facility.

| Section | ED-OTS Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------|--|--------------|---------------|-----------------|-------------------|---------|------------------|---------|-----------|-------------|-----------|------------|---------------|----------------|--------------|--------|------------------|--------|----------|-------------|----------|------------|----------|--------------|--------------------|-----------------|-------------------|---------------|---------------|-------------------|--------------|------------------|--|
| Category | DWDM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Security | Provisioning | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tbody> <tr> <td>DLT-FFP-CLNT</td> <td>RLS-LASER-OTS</td> </tr> <tr> <td>DLT-LNK-<MOD2O></td> <td>RLS-PROTNSTW-CLNT</td> </tr> <tr> <td>ED-CLNT</td> <td>RLS-PROTNSTW-OCH</td> </tr> <tr> <td>ED-DWDM</td> <td>RTRV-CLNT</td> </tr> <tr> <td>ED-FFP-CLNT</td> <td>RTRV-DWDM</td> </tr> <tr> <td>ED-FFP-OCH</td> <td>RTRV-FFP-CLNT</td> </tr> <tr> <td>ED-LNK-<MOD2O></td> <td>RTRV-FFP-OCH</td> </tr> <tr> <td>ED-OCH</td> <td>RTRV-LNK-<MOD2O></td> </tr> <tr> <td>ED-OMS</td> <td>RTRV-OCH</td> </tr> <tr> <td>ED-TRC-CLNT</td> <td>RTRV-OMS</td> </tr> <tr> <td>ED-TRC-OCH</td> <td>RTRV-OTS</td> </tr> <tr> <td>ENT-FFP-CLNT</td> <td>RTRV-PROTNSTW-CLNT</td> </tr> <tr> <td>ENT-LNK-<MOD2O></td> <td>RTRV-PROTNSTW-OCH</td> </tr> <tr> <td>OPR-LASER-OTS</td> <td>RTRV-TRC-CLNT</td> </tr> <tr> <td>OPR-PROTNSTW-CLNT</td> <td>RTRV-TRC-OCH</td> </tr> <tr> <td>OPR-PROTNSTW-OCH</td> <td></td> </tr> </tbody> </table> | DLT-FFP-CLNT | RLS-LASER-OTS | DLT-LNK-<MOD2O> | RLS-PROTNSTW-CLNT | ED-CLNT | RLS-PROTNSTW-OCH | ED-DWDM | RTRV-CLNT | ED-FFP-CLNT | RTRV-DWDM | ED-FFP-OCH | RTRV-FFP-CLNT | ED-LNK-<MOD2O> | RTRV-FFP-OCH | ED-OCH | RTRV-LNK-<MOD2O> | ED-OMS | RTRV-OCH | ED-TRC-CLNT | RTRV-OMS | ED-TRC-OCH | RTRV-OTS | ENT-FFP-CLNT | RTRV-PROTNSTW-CLNT | ENT-LNK-<MOD2O> | RTRV-PROTNSTW-OCH | OPR-LASER-OTS | RTRV-TRC-CLNT | OPR-PROTNSTW-CLNT | RTRV-TRC-OCH | OPR-PROTNSTW-OCH | |
| DLT-FFP-CLNT | RLS-LASER-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DLT-LNK-<MOD2O> | RLS-PROTNSTW-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-CLNT | RLS-PROTNSTW-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-DWDM | RTRV-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFP-CLNT | RTRV-DWDM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFP-OCH | RTRV-FFP-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-LNK-<MOD2O> | RTRV-FFP-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OCH | RTRV-LNK-<MOD2O> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OMS | RTRV-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-CLNT | RTRV-OMS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-OCH | RTRV-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-FFP-CLNT | RTRV-PROTNSTW-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-LNK-<MOD2O> | RTRV-PROTNSTW-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-LASER-OTS | RTRV-TRC-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-PROTNSTW-CLNT | RTRV-TRC-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-PROTNSTW-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Section | ED-OTS Description |
|---------------|---|
| Input Format | <p>ED-OTS:[<TID>]:<AID>:<CTAG>:::[RDIRN=<RDIRN>],[VOAATTN=<VOAATTN>],[VOAPWR=<VOAPWR>],[CALOPWR=<CALOPWR>],[CALTILT=<CALTILT>],[OSRI=<OSRI>],[ALSMODE=<ALSMODE>],[ALSRCINT=<ALSRCINT>],[ALSRCPW=<ALSRCPW>],[EXPGAIN=<EXPGAIN>]:[<PST>],[<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “LINE” section on page 4-29 • <RDIRN> identifies the ring directionality of the optical line; valid values are shown in the “RDIRN_MODE” section on page 4-83 • <VOAATTN> indicates the value of calibrated attenuation for the VOA. The range is 0.0 to +3.0. <VOAATTN> is a float • <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as a result of its attenuation. <VOAPWR> is a float • <CALOPWR> indicates the value of the calibrated optical power expected for the output line added to the calculated value which equals the total expected output power; <CALOPWR> is a float • <CALTILT> indicates the amplifier calibration tilt offset added to the calculated reference value. <CALTILT> is an integer and optional • <OSRI> indicates the OSRI enable or disable feature. <OSRI> is optional and present only on a port where the safety is supported; valid values are shown in the “ON_OFF” section on page 4-76 • <ALSMODE> indicates if the Automatic Laser Shutdown is enabled or disabled. It is an optional parameter present only on the port where the safety is supported; valid values are shown in the “ALS_MODE” section on page 4-49 • <ALSRCINT> indicates the ALS recovery interval. The range is 100–300 seconds. <ALSRCINT> is optional, present only on the port where the safety is supported; <ALSRCINT> is an integer • <ALSRCPW> indicates the ALS recovery pulse width. The range is 2–100 seconds, in increments of 100ms, e.g. 30.1. <ALSRCPW> is optional, present only on the port where the safety is supported; <ALSRCPW> is a float • <EXPGAIN> indicates the gain expected value to be reached from an amplifier when the node works in a DWDM access network. <EXPGAIN> is a float expressed in dBm and is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ED-OTS: PENNGROVE:LINE-6-1:114:::RDIRN=W-E, VOAATTN=5.0, VOAPWR=10.0, CALOPWR=0, CALTILT=0, OSRI=N, ALSMODE=Y, ALSRCINT=30, ALSRCPW=35.1, EXPGAIN=-5.0:OOS, AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.57 ED-PID: Edit Password

This command allows a user to change his or her own password.

Notes:

1. Passwords are masked for the following security commands: ACT-USER, ED-PID, ENT-USER-SECU and ED-USER-SECU. Access to a TL1 session via any means will have the password masked. The CTC Request History and Message Log will also show the masked commands. When a password-masked command is re-issued by double-clicking the command from CTC Request History, the password will still be masked in the CTC Request History and Message Log. The actual password that was previously issued will be sent to the NE. To use a former command as a template only, single-click the command in CTC Request History. The command will be placed in the Command Request text box, where you can edit the appropriate fields prior to re-issuing it.
2. The password will not appear in the TL1 log on the NE.
3. For the ED-PID command:

`ED-PID:[TID]:<UID>:[CTAG]::<OLDPID>,<NEWPID>;`

the syntax of <OLDPID> is not checked. The <NEWPID> is required to follow Telcordia standards (i.e., 10 characters maximum including 1 letter, 1 number, and any one of the following characters: #, %, or +). The <OLDPID> must match what is in the database.

| Section | ED-PID Description | | | | | | | | | | | | | | | | | | | | |
|------------------|--|----------|--------------|--------------|---------------|---------------|---------------|------|---------------|-----------|------------------|----------------|---------------|---------------|----------------|-------------|----------------|--------------|-------------------|---------------|--|
| Category | Security | | | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ACT-USER</td> <td>INH-MSG-SECU</td> </tr> <tr> <td>ALW-MSG-SECU</td> <td>INH-USER-SECU</td> </tr> <tr> <td>ALW-USER-SECU</td> <td>REPT ALM SECU</td> </tr> <tr> <td>CANC</td> <td>REPT EVT SECU</td> </tr> <tr> <td>CANC-USER</td> <td>REPT EVT SESSION</td> </tr> <tr> <td>CANC-USER-SECU</td> <td>RTRV-CMD-SECU</td> </tr> <tr> <td>DLT-USER-SECU</td> <td>RTRV-DFLT-SECU</td> </tr> <tr> <td>ED-CMD-SECU</td> <td>RTRV-USER-SECU</td> </tr> <tr> <td>ED-USER-SECU</td> <td>SET-ATTR-SECUDFLT</td> </tr> <tr> <td>ENT-USER-SECU</td> <td></td> </tr> </table> | ACT-USER | INH-MSG-SECU | ALW-MSG-SECU | INH-USER-SECU | ALW-USER-SECU | REPT ALM SECU | CANC | REPT EVT SECU | CANC-USER | REPT EVT SESSION | CANC-USER-SECU | RTRV-CMD-SECU | DLT-USER-SECU | RTRV-DFLT-SECU | ED-CMD-SECU | RTRV-USER-SECU | ED-USER-SECU | SET-ATTR-SECUDFLT | ENT-USER-SECU | |
| ACT-USER | INH-MSG-SECU | | | | | | | | | | | | | | | | | | | | |
| ALW-MSG-SECU | INH-USER-SECU | | | | | | | | | | | | | | | | | | | | |
| ALW-USER-SECU | REPT ALM SECU | | | | | | | | | | | | | | | | | | | | |
| CANC | REPT EVT SECU | | | | | | | | | | | | | | | | | | | | |
| CANC-USER | REPT EVT SESSION | | | | | | | | | | | | | | | | | | | | |
| CANC-USER-SECU | RTRV-CMD-SECU | | | | | | | | | | | | | | | | | | | | |
| DLT-USER-SECU | RTRV-DFLT-SECU | | | | | | | | | | | | | | | | | | | | |
| ED-CMD-SECU | RTRV-USER-SECU | | | | | | | | | | | | | | | | | | | | |
| ED-USER-SECU | SET-ATTR-SECUDFLT | | | | | | | | | | | | | | | | | | | | |
| ENT-USER-SECU | | | | | | | | | | | | | | | | | | | | | |
| Input Format | <p><code>ED-PID:[<TID>]:<UID>:[CTAG]::<OLDPID>,<NEWPID>;</code></p> <p>where:</p> <ul style="list-style-type: none"> • <UID> is the user identifier and is a string; <UID> is any combination of up to 10 alphanumeric characters • <OLDPID> is the old password and is a string; <OLDPID> is any combination of up to 10 alphanumeric characters. The syntax of <OLDPID> is not checked for backwards compatibility • <NEWPID> is the user login password and is a string; <NEWPID> is a minimum of 6, maximum of 10 alphanumeric characters including at least one digit and one special character (%), (#, or +) <p>Note CTC allows <UID> and <PID> of up to 20 characters. The 20 character CTC-entered <UID> and <PID> are not valid TL1 <UID> and <PID>.</p> | | | | | | | | | | | | | | | | | | | | |
| Input Example | <code>ED-PID:CISCO:UID:123::OLDPWD,NEWPWD;</code> | | | | | | | | | | | | | | | | | | | | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | | | | | | | | | | | | | | | | | | | | |

3.4.58 ED-SYNCN: Edit Synchronization

This command edits the synchronization reference list used to determine the sources for the NE's reference clock and the BITS output clock. For each clock, up to three synchronization sources may be specified (e.g., PRIMARY, SECOND, THIRD). To view or edit the system timing mode, use the RTRV-NE-SYNCN or ED-NE-SYNCN commands.

**Note**

To retrieve/set the timing mode, SSM message Set or Quality of RES information, use the RTRV-NE-SYNCN and ED-NE-SYNCN commands.

| Section | ED-SYNCN Description | |
|------------------|--|--|
| Category | Synchronization | |
| Security | Provisioning | |
| Related Messages | ED-BITS ED-NE-SYNCN OPR-SYNCNSW REPT ALM BITS REPT ALM SYNCN REPT EVT BITS REPT EVT SYNCN RLS-SYNCNSW | RTRV-ALM-BITS RTRV-ALM-SYNCN RTRV-BITS RTRV-COND-BITS RTRV-COND-SYNCN RTRV-NE-SYNCN RTRV-SYNCN |
| Input Format | ED-SYNCN:[<TID>]:<AID>:<CTAG>:::[PRI=<PRI>],[SEC=<SEC>],[THIRD=<THIRD>][:]; where: <ul style="list-style-type: none"> • <AID> is the synchronization reference to be modified and is from the “SYNC_REF” section on page 4-34 • <PRI> is the primary reference of the synchronization and is the AID from the “SYN_SRC” section on page 4-34 • <SEC> is the secondary reference of the synchronization and is the AID from the “SYN_SRC” section on page 4-34 • <THIRD> is the third reference of the synchronization and is the AID from the “SYN_SRC” section on page 4-34 | |
| Input Example | ED-SYNCN:BOYES:SYNC-NE:112:::PRI=INTERNAL,SEC=INTERNAL, THIRD=INTERNAL; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.59 ED-T1: Edit T1

This command edits the attributes related to a DS1/T1 port.

Notes:

1. The T1 facilities on the ONS 15327 are on the XTC card.
2. This command is not allowed if the card is a protecting card.

3. If sending this command to edit TACC and any other attribute(s), and the port having the cross-connection, the (Parameters Not compatible) error message will be returned.
4. Editing TACC via an ED-xxx command is only allowed when there is no circuit/cross-connection on this port and the port/VT does not have a test access point (TAP or TACC number). Otherwise, an error message (e.g. VT in Use) will be returned.
5. TACC creation will also be denied on the protect ports/cards.

| Section | ED-T1 Description | |
|---------------------|--------------------------|-----------------|
| Category | Ports | |
| Security | Provisioning | |
| Related Messages | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> |
| | ED-DS1 | RTRV-DS1 |
| | ED-EC1 | RTRV-EC1 |
| | ED-FC | RTRV-FC |
| | ED-G1000 | RTRV-FSTE |
| | ED-T3 | RTRV-G1000 |
| | INIT-REG-G1000 | RTRV-GIGE |
| | REPT RMV <MOD2_IO> | RTRV-POS |
| | REPT RST <MOD2_IO> | RTRV-T1 |
| | RMV-<MOD2_IO> | RTRV-T3 |
| | RST-<MOD2_IO> | |

| Section | ED-T1 Description |
|---------------|---|
| Input Format | <p>ED-T1:[<TID>]:<AID>:<CTAG>:::[LINECDE=<LINECDE>],[FMT=<FMT>],[LBO=<LBO>],[TACC=<TACC>],[TAPTYPE=<TAPTYPE>],[SOAK=<SOAK>],[SFBER=<SFBER>],[SDBER=<SDBER>]:[<PST>],[<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 • <LINECDE> is a line code; valid values for <LINECDE> are shown in the “LINE_CODE” section on page 4-68 • <FMT> is a frame format; valid values for <FMT> are shown in the “FRAME_FORMAT” section on page 4-65 • <LBO> is a line build out; valid values for <LBO> are shown in the “LINE_BUILDOUT” section on page 4-67 • <TACC> defines the STS as a test access port with a selected unique TAP number. The TAP number ranges from 0–999. When TACC is 0, the TAP is deleted; <TACC> is an integer. • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92. The default value is DUAL • <SOAK> OOS-AINS to IS transition soak time as measured in 15 minute intervals, so a value of 4 translates to a soak time of 1 hour. The allowable range is 0–192 intervals (maximum of 48 hours); <SOAK> is an integer • <SFBER> identifies port SFBER; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies port SDBER; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |
| Input Example | ED-T1:CISCO:FAC-2-1:1223:::LINECDE=AMI,FMT=ESF,LBO=0-131,TACC=8,TAPTYPE=SINGLE,SOAK=10,SFBER=1E-4,SDBER=1E-6:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.60 ED-T3: Edit T3

This command edits the attributes related to a DS3/T3 port.

Notes:

1. T3 facilities on the ONS 15327 are on the XTC card.
2. This command is not allowed if the card is a protecting card.
3. Both FMT and Line code are not supported for T3/DS3 facility. They are supported on both the DS3XM and DS3E card. The unframed value of the framing format is only supported on the DS3E facility.

4. If sending this command to edit TACC and any other attribute(s), and the port having the cross-connection or the port/VT has a test access point (TAP or TACC number), the (Parameters Not compatible) error message will be returned.
5. Editing TACC via an ED-xxx command is only allowed when there is no circuit/cross-connection on the port and the port/VT does not have a test access point (TAP or TACC number). Otherwise, an error message (e.g. VT in Use) will be returned.
6. TACC creation will also be denied on the protect ports/cards.
7. Automatic application of loopbacks originating from the far end can be initiated on the T3 ports of a DS3E, DS3NE, or DS3XM card.

| Section | ED-T3 Description | |
|------------------|--------------------|-----------------|
| Category | Ports | |
| Security | Provisioning | |
| Related Messages | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> |
| | ED-DS1 | RTRV-DS1 |
| | ED-EC1 | RTRV-EC1 |
| | ED-FC | RTRV-FC |
| | ED-G1000 | RTRV-FSTE |
| | ED-T1 | RTRV-G1000 |
| | INIT-REG-G1000 | RTRV-GIGE |
| | REPT RMV <MOD2_IO> | RTRV-POS |
| | REPT RST <MOD2_IO> | RTRV-T1 |
| | RMV-<MOD2_IO> | RTRV-T3 |
| | RST-<MOD2_IO> | |

| Section | ED-T3 Description |
|---------------|---|
| Input Format | <p>ED-T3:[<TID>]:<AID>:<CTAG>:::[FMT=<FMT>],[LINECDE=<LINECDE>],[LBO=<LBO>],[INHFELPBK=<INHFELPBK>],[TACC=<TACC>],[TAPTYPE=<TAPTYPE>],[SOAK=<SOAK>],[SFBER=<SFBER>],[SDBER=<SDBER>]:[<PST>],[<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> indicates a facility AID from the “FACILITY” section on page 4-28 • <FMT> is a frame format and the unframed value of the framing format is only supported for the DS3E; valid values for <FMT> are shown in the “DS_LINE_TYPE” section on page 4-57 • <LINECDE> is a line code; valid values for <LINECDE> are shown in the “DS_LINE_CODE” section on page 4-57 • <LBO> is a line buildup; valid values for <LBO> are shown in the “E_LBO” section on page 4-58 • <INHFELPBK> identifies the Far End Loopback Inhibition attribute of the port. If it is Y, then automatic far end loopbacks are inhibited. It is either on or off. The system default is Y. Valid values are shown in the “ON_OFF” section on page 4-76; <INHFELPBK> is optional • <TACC> defines the STS as a test access port with a selected unique TAP number. The TAP number ranges from 0–999. When TACC is 0, the TAP is deleted; <TACC> is an integer • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 and the default is DUAL • <SOAK> OOS-AINS to IS transition soak time as measured in 15 minute intervals, so a value of 4 translates to a soak time of 1 hour. The allowable range is 0–192 intervals (maximum of 48 hours); <SOAK> is an integer • <SFBER> identifies port SFBER; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies port SDBER; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |
| Input Example | ED-T3:CISCO:FAC-1-2:123:::FMT=C-BIT,LINECDE=B3ZS,LBO=0-225,INHFELPBK=N,TACC=8,TAPTYPE=SINGLE,SOAK=10,SFBER=1E-4,SDBER=1E-6:OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.61 ED-TRC-CLNT: Edit Trace Client

(Cisco ONS 15454 only)

This command edits trace-related attributes on client facilities.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | ED-TRC-CLNT Description | |
|------------------|---|---|
| Category | DWDM | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSTW-CLNT OPR-PROTNSTW-OCH | RLS-LASER-OTS RLS-PROTNSTW-CLNT RLS-PROTNSTW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSTW-CLNT RTRV-PROTNSTW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | <p>ED-TRC-CLNT:[<TID>]:<SRC>:<CTAG>:::[EXPTRC=<EXPTRC>, [TRC=<TRC>],[TRCMODE=<TRCMODE>],[TRCLEVEL=<TRCLEVEL>, [TRCFORMAT=<TRCFORMAT>]][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <SRC> is the AID from the “FACILITY” section on page 4-28 and must not be null • <EXPTRC> indicates the expected path trace message (OTUK-path,J0-section, for example) contents. <EXPTRC> is any 64-character string, including the termination CR (carriage return) and LF (line feed). <EXPTRC> is a string and a null value is equivalent to ALL • <TRC> identifies the path trace message to be transmitted. The TRC is any combination of 64 characters, including the terminating CR and LF. The trace byte (OTUK-path,J0-section, for example) continuously transmits a 64-byte string, one byte at a time. A null value defaults to the NE transmitting null characters (Hex 00). <TRC> is a string and a null value is equivalent to ALL • <TRCMODE> indicates the trace mode and defaults to the OFF mode; valid values are shown in the “TRCMODE” section on page 4-94 and a null value is equivalent to ALL • <TRCLEVEL> indicates the level of trace; valid values are shown in the “TRCLEVEL” section on page 4-93 and a null value is equivalent to ALL • <TRCFORMAT> indicates the trace message size; valid values are shown in the “TRCFORMAT” section on page 4-93. A null value is equivalent to ALL | |

| Section | ED-TRC-CLNT Description |
|---------------|--|
| Input Example | ED-TRC-CLNT:CISCO:FAC-6-1:10:::EXPTRC="AAA",TRC="AAA", TRCMODE=MAN,TRCLEVEL=J0,TRCFORMAT=16-BYTE; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.62 ED-TRC-OCH: Edit Trace Optical Channel Facilities

(Cisco ONS 15454 only)

The command edits trace-related optical channel facilities.

See the “Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards” section on page 1-8 and the “Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards” section on page 1-13 for specific card provisioning rules.

| Section | ED-TRC-OCH Description | |
|---------------------|-------------------------------|--------------------|
| Category | DWDM | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-CLNT | RLS-LASER-OTS |
| | DLT-LNK-<MOD2O> | RLS-PROTNSTW-CLNT |
| | ED-CLNT | RLS-PROTNSTW-OCH |
| | ED-DWDM | RTRV-CLNT |
| | ED-FFP-CLNT | RTRV-DWDM |
| | ED-FFP-OCH | RTRV-FFP-CLNT |
| | ED-LNK-<MOD2O> | RTRV-FFP-OCH |
| | ED-OCH | RTRV-LNK-<MOD2O> |
| | ED-OMS | RTRV-OCH |
| | ED-OTS | RTRV-OMS |
| | ED-TRC-CLNT | RTRV-OTS |
| | ENT-FFP-CLNT | RTRV-PROTNSTW-CLNT |
| | ENT-LNK-<MOD2O> | RTRV-PROTNSTW-OCH |
| | OPR-LASER-OTS | RTRV-TRC-CLNT |
| | OPR-PROTNSTW-CLNT | RTRV-TRC-OCH |
| | OPR-PROTNSTW-OCH | |

| Section | ED-TRC-OCH Description |
|---------------|---|
| Input Format | <p>ED-TRC-OCH:[<TID>]:<SRC>:<CTAG>:::[EXPTRC=<EXPTRC>,:] [TRC=<TRC>],[TRCMODE=<TRCMODE>],[TRCLEVEL=<TRCLEVEL>],[TRCFORMAT=<TRCFORMAT>][[:]];</p> <p>where:</p> <ul style="list-style-type: none"> • <SRC> is the AID from the “CHANNEL” section on page 4-19 • <EXPTRC> indicates the expected path trace message (OTUK-path,J0-section, for example) contents. The <EXPTRC> is any 64-character string, including the termination CR (carriage return) and LF (line feed). <EXPTRC> is a string • <TRC> identifies the path trace message to be transmitted. The TRC is any combination of 64 characters, including the terminating CR and LF. The trace byte (OTUK-path, J0-section, for example) continuously transmits a 64-byte string, one byte at a time. A null value defaults to the NE transmitting null characters (Hex 00). <TRC> is a string • <TRCMODE> identifies the trace mode and defaults to the OFF mode; valid values are shown in the “TRCMODE” section on page 4-94 • <TRCLEVEL> is a string • <TRCFORMAT> indicates the size of the trace message: valid values are shown in the “TRCFORMAT” section on page 4-93 |
| Input Example | ED-TRC-OCH:CISCO:CHAN-6-2:10:::EXPTRC=“AAA”,TRC=“AAA”,TRCMODE=MAN,TRCLEVEL=TTI-PM,TRCFORMAT=64-BYTE; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.63 ED-UCP-CC: Edit Unified Control Plane Control Channel

(Cisco ONS 15454 only)

This command edits UCP IP control channel attributes.

Notes:

1. If sending this command with invalid data, an IIAC (Status, Invalid Data) error message is returned.
2. If sending this command to provision MTU, CRCMD, or both while the IPCC type is routed (CCTYPE=ROUTED), an IIAC (Routed CC Is Not Allowed to Provision MTU & CRCMD) error message is returned.

| Section | ED-UCP-CC Description |
|----------|-----------------------|
| Category | UCP |
| Security | Provisioning |

| Section | ED-UCP-CC Description | |
|------------------|--|--|
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR | REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |
| Input Format | ED-UCP-CC:<TID>:<AID>:<CTAG>:::[LOCALIPCC=<LOCALIPCC>,<REMOTEIPCC=<REMOTEIPCC>,<LMPHELLOINT=<LMPHELLOINT>,<LMPHELLODEADINT=<LMPHELLODEADINT>,<MTU=<MTU>,<CRCMD=<CRCMD>>]; where: <ul style="list-style-type: none">• <AID> indicates an individual IPCC ID; <AID> is the AID from the “IPCC section on page 4-29”• <LOCALIPCC> indicates the local IP address of the control channel and is a string• <REMOTEIPCC> indicates the remote IP address of the control channel and is a string• <LMPHELLOINT> indicates the LMP (line management protocol) interval (in milliseconds) and is an integer. It is the time between hello messages sent by this node.• <LMPHELLODEADINT> indicates the control channel time-out interval (in milliseconds) by the neighbor if the neighbor does not receive the hello message; <LMPHELLODEADINT> is an integer• <MTU> indicates the MTU size of this control channel and is an integer• <CRCMD> indicates the CRC mode for this control channel. It is applicable to IPCCs in SDCC type. Valid values for <CRCMD> are shown in the “UCP_CRC_MODE section on page 4-96” | |
| Input Example | ED-UCP-CC:CISCO:CC-9:CTAG:::LOCALIPCC=172.20.209.31,REMOTEIPCC=172.20.209.15,LMPHELLOINT=1,LMPHELLODEADINT=5,MTU=1500,CRCMD=16-BIT; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.64 ED-UCP-IF: Edit Unified Control Plane Interface

(Cisco ONS 15454 only)

This command edits UCP interface attributes.



Note

If you send invalid data with this command, an IIAC (Status, Invalid Data) error message is returned.

| Section | ED-UCP-IF Description | |
|------------------|---|--|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR | REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |
| Input Format | ED-UCP-IF:[<TID>]:<AID>:<CTAG>:::[TNATYPE=<TNATYPE>, [TNAADDR=<TNAADDR>],[CORENETWORKID=<CORENETWORKID>][:]; where: <ul style="list-style-type: none"> • <AID> indicates the interface port index of the data link; <AID> is the AID from the “FACILITY” section on page 4-28 • <TNATYPE> indicates the TNA (transport network administered) type; valid values for <TNATYPE> are shown in the “UCP_TNA_TYPE” section on page 4-96 • <TNAADDR> indicates the TNA (transport network administered) IP address and is a string • <CORENETWORKID> is an integer | |
| Input Example | ED-UCP-IF:CISCO:FAC-2-1:CTAG:::TNATYPE=IPV4, TNAADDR=172.20.209.73,CORENETWORKID=9; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.65 ED-UCP-NBR: Edit Unified Control Plane Neighbor

(Cisco ONS 15454 only)

This command edits a UCP neighbor.

The default value of the node name can be overwritten by the TL1 user to a string in a maximum size of 20 characters. If the node name includes non-identified TL1 characters (e.g. space), the text string format with the double quotes is required.

Example:

```
ENT-UCP-NBR::NBR-18:CTAG:::NBRIX=18,NODEID=192.168.101.18,  
NAME=NeibhgorName,NDEN=N,HELLOEN=Y,HELLOINT=5, REFREDEN=Y;
```

Notes:

1. If this command is sent twice or input with invalid data, a SRQN (Status, Invalid Request) error message is returned.
2. If sending this command without neighbor node name in the “NAME” field, an IIAC (Neighbor Name Cannot Be Empty) error message is returned.

3. If sending this command to set the hello interval while the RSVP hello is disabled, an IIAC (HELLOINT Is Not Allowed If HELLOEN Is Disabled) error message is returned.

| Section | ED-UCP-NBR Description |
|------------------|---|
| Category | UCP |
| Security | Provisioning |
| Related Messages | DLT-UCP-CC REPT ALM UCP |
| | DLT-UCP-IF REPT EVT UCP |
| | DLT-UCP-NBR RTRV-ALM-UCP |
| | ED-UCP-CC RTRV-COND-UCP |
| | ED-UCP-IF RTRV-UCP-CC |
| | ED-UCP-NODE RTRV-UCP-IF |
| | ENT-UCP-CC RTRV-UCP-NBR |
| | ENT-UCP-IF RTRV-UCP-NODE |
| | ENT-UCP-NBR |
| Input Format | <p>ED-UCP-NBR:[<TID>]:<AID>:<CTAG>:::[NAME=<NAME>, [HELLOEN=<HELLOEN>],[HELLOINT=<HELLOINT>], [REFREDEN=<REFREDEN>][:];</p> <p>where:</p> <ul style="list-style-type: none"> <AID> indicates an individual neighbor index of the UCP. An available neighbor index will be assigned internally while sending this command without AID; <AID> is the AID from the “NBR” section on page 4-30 <NAME> indicates the neighbor node name. It defaults to the ASCII representation of the node ID in this command. The default value of this node name can be overwritten by the TL1 user to a string in a maximum size of 20 characters. If the node name includes non-identified TL1 characters (e.g. space), the text string format with the double quotes is required. Node name is a string. The default value is “defaults to the nodeid ASCII representation”. <NAME> is a string. The default value is “the ASCII representation of the nodeid”. <NAME> is a string <HELLOEN> indicates if the RSVP hello enabled to this neighbor or not; valid values for <HELLOEN> are shown in the “ON_OFF” section on page 4-76 <HELLOINT> indicates the interval between hello messages to neighbor; <HELLOINT> is an integer <REFREDEN> indicates if the refresh reduction is enabled or not; valid values for <REFREDEN> are shown in the “EXT_RING” section on page 4-65 |
| Input Example | ED-UCP-NBR:CISCO:NBR-8:CTAG:::NAME=NODE-B,HELLOEN=Y, HELLOINT=20,REFREDEN=N; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.66 ED-UCP-NODE: Edit Unified Control Plane Node

(Cisco ONS 15454 only)

This command edits the UCP node level attributes.

The nodeid is the unique number used to identify the local node in LMP, RSVP messages sent to the neighbors. It defaults to the local ethernet interface address (ISA).

The retry initial interval (in seconds) is used for that have been released by the net work side. This interval has a range of 60 seconds (1 minute) to 1800 seconds (30 minutes), with a default value of 180 seconds.

The retry max interval (in seconds) is used for released circuits. The node will back off exponentially from the initial retry interval to this maximum value of 600 seconds (10 minutes).

The restart time is used to be signaled to neighbors. It indicates the time taken by this node (in seconds) to restart. This timer has a range of 1 second to 10 seconds with a default of 5 seconds.

The recovery time is used to be signaled to neighbors. It indicates the time taken by this node (in seconds) to re-sync path, reservation state with a given neighbor. This timer has a range of 300 seconds (5 minutes) to 1800 seconds (30 minutes) and a default value of 600 seconds (10 minutes).

The transmit interval is used to retransmit un-acknowledged messages. This timer has a range of 1 second to 7 seconds with a default value of 1 second.

The refresh interval is used to refresh path, reservation state. This interval has a range of 30 seconds to 4060800 seconds (47 days) with a default value of 30 seconds.

The timeout RESV CONF interval is used to wait for a RESV CONF message in response to a RESV message. This interval has a range of 10–180 seconds with a default value of 60 seconds.

The Source Deletion in Progress is a timeout interval while the source is in the process of cleanly deleting a call. This interval has a range of 1–180 seconds with a default value of 60 seconds.

The Destination Deletion progress is a timeout interval while the destination is in the progress of cleanly deleting a call. This interval has a range of 1–180 seconds with a default value of 60 seconds.

Notes:

1. If the retry initial interval is set to zero, it will be interpreted as having the retry procedure disable.
2. The retry maximum interval has to be set to a higher value than the initial retry interval.

| Section | ED-UCP-NODE Description | |
|---------------------|-------------------------|---------------|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC | REPT ALM UCP |
| | DLT-UCP-IF | REPT EVT UCP |
| | DLT-UCP-NBR | RTRV-ALM-UCP |
| | ED-UCP-CC | RTRV-COND-UCP |
| | ED-UCP-IF | RTRV-UCP-CC |
| | ED-UCP-NBR | RTRV-UCP-IF |
| | ENT-UCP-CC | RTRV-UCP-NBR |
| | ENT-UCP-IF | RTRV-UCP-NODE |
| | ENT-UCP-NBR | |

| Section | ED-UCP-NODE Description |
|---------------|---|
| Input Format | <p>ED-UCP-NODE:[<TID>]::<CTAG>:::[NODEID=<NODEID>,<INITRETRY>=<INITRETRY>,<MAXRETRY>=<MAXRETRY>,<RESTARTTM>=<RESTARTTM>,<RECOVTM>=<RECOVTM>,<RXMTINT>=<RXMTINT>,<RFRSHINT>=<RFRSHINT>,<RESVTIMEOUT>=<RESVTIMEOUT>,<RESVCONF TIMEOUT>=<RESVCONF TIMEOUT>,<SOURCEDIP>=<SOURCEDIP>,<DESTINATIONDIP>=<DESTINATIONDIP>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <NODEID> indicates the node IP address and is a string • <INITRETRY> indicates the circuit retry initial interval (in seconds) and is an integer • <MAXRETRY> indicates the circuit maximum retry initial interval (in seconds) and is an integer • <RESTARTTM> indicates the restart time taken by this local node; <RESTARTTM> is an integer and the default value is 5 seconds. • <RECOVTM> indicates the circuit retry maximum interval (in seconds) and is an integer • <RXMTINT> indicates the interval for re-transmitting un-acknowledged messages and is an integer • <RFRSHINT> indicates the interval for refreshing path, reservation state and is an integer • <RESVTIMEOUT> indicates the timeout interval for waiting for a reservation message in response to a PATH message; <RESVTIMEOUT> is an integer • <RESVCONF TIMEOUT> indicates the timeout interval for waiting for a RESV CONF message in response to a RESV message; <RESVCONF TIMEOUT> is an integer • <SOURCEDIP> indicates the timeout interval of the SourceDip (Source Deletion in Progress) while the source is in the process of cleanly deleting a call; <SOURCEDIP> is an integer • <DESTINATIONDIP> indicates the timeout interval of the DestinationDip (Destination Deletion in Progress) while the destination is in the process of cleanly deleting a call; <DESTINATIONDIP> is an integer |
| Input Example | ED-UCP-NODE:CISCO::CTAG:::NODEID=192.168.100.52,INITRETRY=180,MAXRETRY=600,RESTARTTM=5,RECOVTM=600,RXMTINT=1,RFRSHINT=30,RESVTIMEOUT=60,RESVCONF TIMEOUT=60,SOURCEDIP=60,DESTINATIONDIP=60; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.67 ED-USER-SECU: Edit User Security

This command edits a user's privileges, password, or ID. Only a Superuser may perform this operation. Privilege levels are described in the ENT-USER-SECU command.

Notes:

1. Passwords are masked for the following security commands: ACT-USER, ED-PID, ENT-USER-SECU and ED-USER-SECU. Access to a TL1 session via any means will have the password masked. The CTC Request History and Message Log will also show the masked commands. When a password-masked command is re-issued by double-clicking the command from CTC Request History, the password will still be masked in the CTC Request History and Message Log. The actual password that was previously issued will be sent to the NE. To use a former command as a template only, single-click the command in CTC Request History. The command will be placed in the Command Request text box, where you can edit the appropriate fields prior to re-issuing it.
2. Although the CTC allows both <UID> and <PID> of up to 20 characters, the CTC-entered users (<UID>, <PID>) are not valid TL1 users (e.g., if issuing an ACT-USER command and using the CTC-entered <UID> that is greater than 10 characters long, TL1 will respond with DENY).
3. For the ED-USER-SECU command;

ED-USER-SECU:[TID]:<UID>:[CTAG]:::<NEWUID>,<NEWPID>,<UAP>:;

 - a. If the <NEWPID> is specified, the syntax is checked.
 - b. The syntax of <UID> is not checked.
 - c. Old users can change their password without changing their userid, but the new password must meet the new requirements.
 - d. The <NEWPID> is required when changing the <USERID>.

| Section | ED-USER-SECU Description | |
|------------------|--------------------------|-------------------|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER | INH-MSG-SECU |
| | ALW-MSG-SECU | INH-USER-SECU |
| | ALW-USER-SECU | REPT ALM SECU |
| | CANC | REPT EVT SECU |
| | CANC-USER | REPT EVT SESSION |
| | CANC-USER-SECU | RTRV-CMD-SECU |
| | DLT-USER-SECU | RTRV-DFLT-SECU |
| | ED-CMD-SECU | RTRV-USER-SECU |
| | ED-PID | SET-ATTR-SECUDFLT |
| | ENT-USER-SECU | |

| Section | ED-USER-SECU Description |
|---------------|---|
| Input Format | <p>ED-USER-SECU:[<TID>]:<UID>:<CTAG>::[<NEWUID>],[<NEWPID>],,[<UAP>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <UID> is the user identifier and is a string. The minimum <UID> size is 6, the maximum UID size is 10 • <NEWUID> is the new user identifier and is a string. The minimum <UID> size is 6, the maximum PID size is 10 • <NEWPID> is a new password and is a string; <NEWPID> is a minimum of 6, maximum of 10 • <UAP> is a user access privilege; valid values for <UAP> are shown in the “PRIVILEGE” section on page 4-82 <p>Note CTC allows <UID> and <PID> of up to 20 characters. The 20 character CTC-entered <UID> and <PID> are not valid TL1 <UID> and <PID>.</p> |
| Input Example | ED-USER-SECU:PETALUMA:CISCO15:123::NEWUID,NEWPID,,MAINT; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.68 ED-WDMANS: Edit Wavelength Division Multiplexing Automatic Node Setup

(Cisco ONS 15454 only)

This command edits the optical node setup application (AONS) attributes.

| Section | ED-WDMANS Description |
|------------------|-----------------------|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | RTRV-WDMANS |

| Section | ED-WDMANS Description |
|---------------|---|
| Input Format | <p>ED-WDMANS:[<TID>]:<AID>:<CTAG>:::[POWER-IN=<POWERIN>],[POWER-OUT=<POWEROUT>],[POWER-EXP=<POWEREXP>],[POWER-DROP=<POWERDROP>],[SYS-TYPE=<SYSTYPE>],[RING-TYPE=<RINGTYPE>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “WDMANS” section on page 4-36 • <POWERIN> is the input power for OADM section of an OADM optical network element; <POWERIN> is a float expressed in dBm • <POWEROUT> output power for OADM section or Mux/Demux of HUB, TERMINAL, or OADM optical network elements; <POWEROUT> is a float expressed in dBm • <POWEREXP> is the express power for mux/demux section of a HUB or TERMINAL optical network element; <POWEREXP> is a float expressed in dBm • <POWERDROP> is the drop power for mux/demux section of a HUB or TERMINAL optical network element; <POWERDROP> is a float expressed in dBm • <SYSTYPE> is the type of interconnected fiber between two adjacent nodes and the length category between them; valid values are shown in “SYS_TYPE” section on page 4-90 • <RINGTYPE> is the type of network where the DWDM node is installed; valid values are shown in the “DWDM_RING_TYPE” section on page 4-58 |
| Input Example | ED-WDMANS: PENNGROVE: WDMANS-W:114:::POWER-IN=10.0, POWER-OUT=10.0,POWER-EXP=10.0,POWER-DROP=10.0, SYS-TYPE=SMF-28-SR,RING-TYPE=METRO-CORE; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.69 ED-WLEN: Edit Wavelength

(Cisco ONS 15454 only)

This command edits WLEN (wavelength) provisioning.

Notes:

1. The fields after CTAG (trailing colons) are optional.
2. This command does not support multiple editing of WLEN provisioning.

| Section | ED-WLEN Description |
|------------------|-----------------------------------|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | ENT-WLEN DLT-WLEN RTRV-WLEN |

| Section | ED-WLEN Description |
|---------------|--|
| Input Format | ED-WLEN:[<TID>]:<AID>:<CTAG>:::[SIZE=<SIZE>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none">• <AID> is the AID from the “WLEN” section on page 4-37• <SIZE> is the circuit size allocated on this wavelength; valid values are shown in the “CIRCUIT_SIZE” section on page 4-53. <SIZE> is optional• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ED-WLEN: PENNGROVE: WLEN-W-ADD-1530.33:1:::SIZE=NOT-SPEC: OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.70 ENT-<MOD_RING>: Enter BLSR

This command creates either a two-fiber or four-fiber BLSR.



Note The ONS 15327 does not support four-fiber BLSR.



Note <RINGID> defaults to the string of the AID format of BLSR-string.

Input examples:

Four-fiber BLSR:

ENT-BLSR:PETALUMA:BLSR-2:123:::RINGID=2,NODEID=3,MODE=4F,RVRTV=Y,RVTM=5.0,SRVRTV=Y,SRVTM=5.0,EASTWORK=FAC-5-1,WESTWORK=FAC-6-1,EASTPROT=FAC-12-1,WESTPROT=FAC-13-1:;

Two-fiber BLSR:

ENT-BLSR:PETALUMA:BLSR-4:123:::RINGID=4,NODEID=6,MODE=2F,RVRTV=Y,RVTM=5.0,EASTWORK=FAC-5-1,WESTWORK=FAC-6-1:;

Error conditions:

1. If RINGID is different from the string presented in the AID format, an IIAC (RingId Does Not Match With AID) error message is returned.
2. Both <EASTPROT> and <WESTPROT> are optional, but required for 4-fiber BLSR creation.
3. If sending this command to create a BLSR with an out of range nodeid or ringid, an IIAC (Invalid NodeId) or (Invalid RingId) error message will be returned.
4. If sending this command to create 4-fiber BLSR on OC12 cards, or 2-fiber BLSR on OC3 cards, an IIAC (Input, Invalid work/prot port) error message will be returned.
5. If sending this command to create a BLSR on an NE that already has five BLSRs, a SRQN (BLSR Creation Failed) error message will be returned because one NE is only allowed to have up to five BLSRs in this release (R4.6).

6. If sending this command to create a BLSR on a port with 1+1, a SRQN (BLSR Creation Failed) error message will be returned.
7. If the system fails on getting IOR, an SROF (Get IOR Failed) error message is returned.
8. If the AID is invalid, an IIAC (Invalid AID) error message is returned.
9. The ALL AID is invalid for this command.
10. If any facility requested in this command is in use, an SPLD (Facility is Busy) error message is returned.
11. The SRQN (BLSR Creation Failed) error message is returned for an invalid creation query.
12. If sending this command to provision the mode with an invalid BLSR mode, an IIDT (Invalid BSLR Mode) error message is returned.
13. If sending this command to modify SRVRTV or SRVTM on the two-fiber BLSR, an IDNV (Invalid Data for 2F-BLSR) error message is returned.
14. If sending this command to provision the nodeid with invalid data, an IIAC (Invalid NodeId) error message is returned.
15. If sending this command to provision the ringid with invalid data, an IIAC (Invalid RingId) error message is returned.
16. If sending this command with invalid working AID, an IIDT (Invalid BLSR Working Facility) error message is returned.
17. If sending this command with invalid protection AID, an IIDT (Invalid BLSR Protect Facility) error message is returned.
18. If changing the BLSR nodeid with a duplicated ID, a SROF (Cannot Set NodeId) error message is returned.

| Section | ENT-<MOD_RING> Description | |
|------------------|---|--|
| Category | BLSR | |
| Security | Provisioning | |
| Related Messages | DLT-<MOD_RING> ED-<MOD_RING> EX-SW-<OCN_BLSR> | RTRV-<MOD_RING> RTRV-TRC-<OCN_BLSR> |

| Section | ENT-<MOD_RING> Description |
|---------------|--|
| Input Format | <p>ENT-<MOD_RING>:[<TID>]:<AID>:<CTAG>:::[RINGID=<RINGID>,<NODEID=<NODEID>,<MODE=<MODE>,[RVRTV=<RVRTV>,<RVTM=<RVTM>],[SRVRTV=<SRVRTV>],[SRVTM=<SRVTM>],<EASTWORK=<EASTWORK>,<WESTWORK=<WESTWORK>,<EASTPROT=<EASTPROT>,<WESTPROT=<WESTPROT>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the BLSR of the NE. “ALL” or “BLSR-ALL” AID is not allowed for editing BLSR. This command only supports a single BLSR AID. <AID> is the AID from the “AidUnionId” section on page 4-15 • <RINGID> identifies the BLSR ring ID of the NE. It is a string of up to six characters, valid characters are [A-Z, 0-9]. The default value is “# of AID BLSR #” • <NODEID> identifies the BLSR node ID of the NE and is an integer. It ranges from 0-31 • <MODE> identifies the BLSR mode; valid values for <MODE> are shown in the “BLSR_MODE” section on page 4-50 • <RVRTV> identifies the revertive mode and defaults to Y (revertive mode). Valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76. The default value is Y. • <RVTM> identifies the revertive time and defaults to 5.0. Valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84; the default value is 5.0 • <SRVRTV> identifies the span revertive mode for 4-fiber BLSR only. <SRVRTV> defaults to Y (revertive mode); valid values are shown in the “ON_OFF” section on page 4-76. The default value is Y. • <SRVTM> identifies the span revertive time for 4-fiber BLSR only. <SRVTM> defaults to 5.0 and valid values are shown in the “REVERTIVE_TIME” section on page 4-84. The default value is 5.0 • <EASTWORK> identifies the east working facility and is the AID from the “FACILITY” section on page 4-28 • <WESTWORK> identifies the west working facility and is the AID from the “FACILITY” section on page 4-28 • <EASTPROT> identifies the east protecting facility and is the AID from the “FACILITY” section on page 4-28 • <WESTPROT> identifies the west protecting facility and is the AID from the “FACILITY” section on page 4-28 |
| Input Example | ENT-BLSR:PETALUMA:BLSR-2:123:::RINGID=2,NODEID=1,MODE=4F,RVRTV=Y,RVTM=5.0,SRVRTV=Y,SRVTM=5.0,EASTWORK=FAC-5-1,WESTWORK=FAC-6-1,EASTPROT=FAC-12-1,WESTPROT=FAC-13-1; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.71 ENT-CRS-<PATH>: Enter Cross Connection (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command creates an STS cross-connection with a cross-connection type (CCT).

When a path protection cross-connection is created, the path presented by the first AID is configured to be the preferred path. For example, the AID (F1) of the cross-connection (created by ENT-CRS-STS1::F1&F2,T1:123;) is the preferred path.

Notes:

1. The default cross-connection type is 2-way
2. If a path is already in a connection, it cannot be in another connection even if the other is a 1-way and the new one will be 1-way the other direction.
3. This command does not support creating multiple STS cross-connections.
4. The path protection cross STS connection can be created by using “&” in the AID fields of this command.
 - a. The following command is used to create a 1-way selector or 2-way selector and bridge with:
from points: F1, F2
to points: T1
ENT-CRS-{STS_PATH}:[<TID>]:F1&F2,T1:<CTAG>::[<CCT>];
 - b. The following command is used to create a 1-way bridge or 2-way selector and bridge with:
from point: F1
to points: T1, T2
ENT-CRS-{STS_PATH}:[<TID>]:F1,T1&T2:<CTAG>::[<CCT>];
 - c. The following command is used to create a 1-way subtending path protection connection or 2-way subtending path protection connection with:
from point: F1, F2
to points: T1, T2
ENT-CRS-{STS_PATH}:[<TID>]:F1&F2,T1&T2:<CTAG>::[<CCT>];
 - d. The following command is used to create a 2-way selector and bridge with:
from point: F1,F2 (F1 is the working side, F2 is the protect side)
selector points: S1, S2 (S1 is the working side, S2 is the protect side)
ENT-CRS-{STS_PATH}:[<TID>]:F1&F2,S1&S2:<CTAG>::2WAY;
 - e. The following command is used to create a path protection IDRI Cross-Connection:
ENT-CRS-{STS_PATH}:[<TID>]:A&B,C&D:<CTAG>::2WAYDC;
A–Path on ring X to which traffic from ring Y is bridged
B–Path on ring X to which traffic from the same ring is bridged
C–Path on ring Y to which traffic from ring X is bridged
D–Path on ring Y to which traffic from the same ring is bridged

A, B, C, and D have a positional meaning. Connection type 2WAYDC is used for path protection IDRI cross-connections.

- f. The following command is used to create a path protection DRI Cross-Connection:

ENT-CRS-{STS_PATH}:[<TID>]:A&B,C:<CTAG>::2WAYDC;

A—Path on ring X to which traffic from ring Y is bridged

B—Path on ring X to which traffic from the same ring is bridged

C—Traffic to and from ring Y

A, B, C, and D have a positional meaning. Connection type 2WAYDC is used for path protection DRI cross-connections.

5. All A&B AIDs in the TL1 cross-connection command are in the format of WorkingAID&ProtectAID.
6. To establish a cross-connection on a 2-fiber protection path or on a 4-fiber protection channel, the PCA connection type (1WAYPCA or 2WAYPCA) is required.
7. If you send a PCA cross-connection type on the non-PCA AIDs, the IIAC error message is returned.
8. If you send a non-PCA cross-connection type on the PCA AIDs, the IIAC error message is returned.
9. The facility AID is only valid on slots holding a G1000-4 card.
10. The virtual facility AID (VFAC) is only valid on slots holding an M-series card.

| Section | ENT-CRS-<PATH> Description |
|------------------|---|
| Category | Cross Connections |
| Security | Provisioning |
| Related Messages | DLT-CRS-<PATH> RTRV-CRS ED-CRS-<PATH> RTRV-CRS-<PATH> |
| Input Format | <p>ENT-CRS-<PATH>:[<TID>]:<AID>,<DST>:<CTAG>::[<CCT>]::[<PST>], [<SST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is from the “CrossConnectId1” section on page 4-23 • <DST> is from the “CrossConnectId1” section on page 4-23 • <CCT> identifies the cross-connection type; valid values for <CCT> are shown in the “CCT” section on page 4-53 • <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values for <SST> are shown in the “SST” section on page 4-86 |
| Input Example | ENT-CRS-STS3C:BODEGA:STS-5-1-1,STS-12-1-5:116::2WAY::OOS,AINS; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.72 ENT-EQPT: Enter Equipment

This command enters the card type and attributes for a given equipment slot in the NE. It also automatically enters all facilities supported by the card, assigning default values to all facility and path attributes.

The command supports optional parameters: RVTM (revertive time), RVRTV (revertive behavior), PROTID (unique protection ID) and PRTYPE (protection type) for configuring the card in an equipment protection group. PRTYPE can be 1:1 and 1:N. These parameters can only be entered for a working AID. The protect card must already be provisioned before creating the protection group.

1:1 protection involves the odd slot protecting the even slot. The work-protect pair is as follows (2-1, 4-3, 6-5, 16-17, 14-15, 12-13). DS1, DS3, DS3XM, DS3N, DS3E, EC1 and other electrical cards support 1:1 protection. The value of PROTID is the protecting slot and is of the form “slot-x”. This command creates a 1:1 protection group. If the command has the optional parameters for creating a protection group and the protection group cannot be created due to an error condition, provisioning of the equipment fails.

The PROTID slot must be provisioned first.

To create 1:1 with the ENT-EQPT command, the working card should not be provisioned first, so the AID type field should be presented in ENT-EQPT for the AID on this <AID>.

The following is an example for a 1:1 protection group:

```
ENT-EQPT:[<TID>]:SLOT-1:<CTAG>::DS1;
```

```
ENT-EQPT:[<TID>]:SLOT-2:<CTAG>::DS1:PROTID=SLOT-1,PRTYPE=1-1,RVTM=5.0,  
RVRTV=Y;
```

1:N protection is always revertive. For 1:N protection, the protect slot can only be Slot 3 or Slot 15. For a protect card in Slot 3, the working cards can be in any of the slots on Bank A. Slot 15 is for protection in Bank B. A DSXN (DS1N or DS3N) card must be provisioned in the protect slot. A 1:1 protection cannot be upgraded to 1:N protection. This command creates a 1:N protection group or adds a new card to an existing 1:N protection group. Multiple working AIDs can be entered in a protection group.

The following is an example of provisioning a 1:N protection group with the ENT-EQPT command:

```
ENT-EQPT:[<TID>]:SLOT-3:<CTAG>::DS1N;
```

```
ENT-EQPT:[<TID>]:SLOT-2&SLOT-1:<CTAG>::DS1:PROTID=SLOT-3,PRTYPE=1-N;
```

The following is an example of provisioning a 1:N protection group with the ED-EQPT command:

```
ENT-EQPT:[<TID>]:SLOT-1&SLOT-2:<CTAG>::DS1;
```

```
ENT-EQPT:[<TID>]:SLOT-3:<CTAG>::DS1N;
```

```
ED-EQPT:[<TID>]:SLOT-2&SLOT-1:<CTAG>:::PROTID=SLOT-1,PRTYPE=1-N;
```

If the provisioning fails for some AIDs, PRTL responses will be provided indicating failed AIDs. If the provisioning fails for all the AIDs, a DENY response will be provided. For both CMPLD and PRTL responses on creating protection group query, the protection group has been created for the successful AID(s) query.

The following is an example for 1:N protection. The RVRTV parameter is not valid for 1:N protection.

```
ENT-EQPT:[<TID>]:SLOT-2:<CTAG>:::PROTID=SLOT-3,PRTYPE=1-N,RVTM=5.0;
```

Both ENT-EQPT and ED-EQPT commands can provision all working AIDs (1-5) together for 1:N by using listed AIDs.

The ENT-EQPT command provisions a new card and adds it to the protection group. The ED-EQPT command adds the already provisioned cards to the protection group.

Protect AID should already be provisioned for either command because protection group parameters are not supported for the protect AID.

The ENT-EQPT command provisions an equipment successfully on an empty slot if the equipment type is compatible with the slot number. This command can have the optional parameters in the “f” block to provision a card as a working card. It has the effect of adding the protection behavior at the time of

provisioning itself. For the protection provisioning to succeed, the protect card should have already been provisioned. Trying to execute ENT-EQPT to provision a protection group on an already provisioned card will result in an error.

An example to provision a 1:1 protection group:

ENT-EQPT::SLOT-1:12::DS3;// provision the protect card

ENT-EQPT::SLOT-2:12::DS3:PROTID=SLOT-1,RVRTV=Y,RVTM=8.0; //provision a card and add it to the protection group.

An example to provision a 1:N protection group:

ENT-EQPT::SLOT-3:12::DS3N;//provision the protect card

ENT-EQPT::SLOT-1:12::DS3:PROTID=SLOT-3,RVTM=7.5,PRTYPE=1-N;//provision a card and add it to protection group.

Notes:

1. Sending this command to provision a DS3NE card on Slot {1,2,4,5,6,12,13,14,16,or 17}, the DS3E card type is provisioned instead because 1:N protect cards should be in Slot 3 or Slot 15.
2. Sending this command to provision a DS3N card on Slot {1,2,4,5,6,12,13,14,16,17}, the DS3 card type is provisioned instead because 1:N cards should be in Slot 3 or Slot 15.
3. Sending this command to provision a DS1N card on Slot-{1,2,4,5,6,12,13,14,16,17}, the DS1 card type is provisioned instead because 1:N protect cards should be in Slot 3 or Slot 15.

Error conditions for creating 1:1 or 1:N protection groups are:

1. AID sent to a non-working slot; the working cards must be in even slots for 1:1 and in the same bank for 1:N and not in Slot 3 or Slot 15 (ONS 15454).
2. Invalid AID chosen for protection slot.
3. Working AID is already in protection group.
4. AID is a protect AID.
5. The protect card has a circuit.
6. The equipment type does not match with the allowed AID.
7. The slot is already provisioned.
8. The protecting slot is not provisioned.
9. Multiple working AIDs for 1:1 protection.
10. If the command mode (CMDMDE) is set to forced (FRCD) during the creation of a 1:1 or 1:N protection group, all cards must be physically plugged in and in the ready state (IS). If the cards are not physically plugged in, then the command is denied with an appropriate error message. When the command mode is set to normal (NORM) (which is the default) the cards do not have to be physically plugged in and in the ready state.

| Section | ENT-EQPT Description |
|----------|----------------------|
| Category | Equipment |
| Security | Provisioning |

| Section | ENT-EQPT Description | |
|------------------|---|---|
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT REPT ALM EQPT | REPT EVT EQPT REPT RMV EQPT REPT RST EQPT RTRV-ALM-EQPT RTRV-COND-EQPT RTRV-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | ENT-EQPT:[<TID>]:<AID>:<CTAG>:<AIDTYPE>:[PROTID=<PROTID>,<PRTYPE=<PRTYPE>,<RVRTV=<RVRTV>,<RVTM=<RVTM>,<CMDMDE=<CMDMDE>>]; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “EQPT” section on page 4-27• <AIDTYPE> is the AID card type; valid values for <AIDTYPE> are shown in the “EQUIPMENT_TYPE” section on page 4-62• <PROTID> is the protecting card slot identifier of the protection group and is the AID from the “PRSLOT” section on page 4-31• <PRTYPE> is the protection group type; valid values for <PRTYPE> are shown in the “PROTECTION_GROUP” section on page 4-83• <RVRTV> is the revertive mode; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76• <RVTM> is the revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84• <CMDMDE> is the command mode. It is only applicable when creating a 1:1 or 1:N protection group and/or adding cards to an existing protection group (1:N). The default is NORM. Valid values are shown in the “CMD_MODE” section on page 4-54. If creating or adding cards to a protection group, specifying FRCD will require the card to be physically plugged in and in the ready state (IS). | |
| Input Example | ENT-EQPT:PETALUMA:SLOT-12:118::DS1:PROTID=SLOT-13,PRTYPE=1-1, RVRTV=Y,RVTM=8.5,CMDMDE=FRCD: | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.73 ENT-FFP-<OCN_TYPE>: Enter Facility Protection Group (OC3, OC12, OC48, OC192)

See Table 4-11 on page 4-5 for supported modifiers by platform.

This command creates an optical 1+1 protection.

Notes:

1. Protect AID must not be provisioned with traffic.
2. Work AID can be provisioned with traffic.
3. PROTID is a string and can have a maximum length of 32 characters.

| Section | ENT-FFP-<OCN_TYPE> Description | | |
|------------------|---|---|--|
| Category | SONET Line Protection | | |
| Security | Provisioning | | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ENT-FFP-CLNT EX-SW-<OCN_BLSR> | OPR-PROTNST-<OCN_TYPE> RLS-PROTNST-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-PROTNST-<OCN_TYPE> | |
| Input Format | ENT-FFP-<OCN_TYPE>:[<TID>]:<WORK>,<PROTECT>:<CTAG>::: [<PROTID=<PROTID>,>][<RVRTV=<RVRTV>,>][<RVTM=<RVTM>,>] [<PSDIRN=<PSDIRN>>]; where: <ul style="list-style-type: none"> • <WORK> identifies a working port and is the AID from the “FACILITY” section on page 4-28 • <PROTECT> identifies a protection port and is the AID from the “FACILITY” section on page 4-28 • <PROTID> is the protection group identifier (protection group name); <PROTID> defaults to the protecting port AID of the protection group, it is a string and can have a maximum length of 32 characters. • <RVRTV> identifies a revertive mode and defaults to N (non-revertive mode); valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies a revertive time and defaults to 5.0 minutes; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 • <PSDIRN> identifies the switching mode and defaults to UNI; valid values for <PSDIRN> are shown in the “UNI_BI” section on page 4-96 | | |
| Input Example | ENT-FFP-OC3:PETALUMA:FAC-2-1,FAC-1-1:1:::PROTID=PROT_NAME, RVRTV=Y,RVTM=1.0,PSDIRN=BI; | | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | | |

3.4.74 ENT-FFP-CLNT: Enter Facility Protection Group Client

(Cisco ONS 15454 only)

This command creates Y cable protection on client facilities.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | ENT-FFP-CLNT Description |
|----------|--------------------------|
| Category | DWDM |
| Security | Provisioning |

| Section | ENT-FFP-CLNT Description |
|------------------|--|
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-LNK-<MOD2O> EX-SW-<OCN_BLSR> OPR-LASER-OTS OPR-PROTNSW-<OCN_TYPE> OPR-PROTNSW-CLNT |
| Input Format | ENT-FFP-CLNT:[<TID>]:<WORKAID>,<PROTAID>:<CTAG>::: [PROTTYPE=<PROTTYPE>],[PROTID=<PROTID>],[RVRTV=<RVRTV>], [RVTM=<RVTM>],[PSDIRN=<PSDIRN>][:]; where: <ul style="list-style-type: none"> • <WORKAID> identifies a working port and is the AID from the “FACILITY” section on page 4-28 • <PROTAID> identifies a protection port and is the AID from the “FACILITY” section on page 4-28 • <PROTTYPE> identifies the type of facility protection; valid values are shown in the “PROTTYPE” section on page 4-83 • <PROTID> protection group identifier (protection group name). Defaults to the protecting port AID of the protection group. Is a string and can have a maximum length of 32 characters; <PROTID> is a string • <RVRTV> identifies the revertive mode. Defaults to N (non-revertive mode); valid values are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies the revertive time. Defaults to 5.0 minutes; valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <PSDIRN> identifies the switching mode and defaults to UNI. Release 4.0 MXP_2.5G_10G/TXP_MR_10G cards do not support BI-DIRECTIONAL switching. Valid values for <PSDIRN> are shown in the “UNI_BI” section on page 4-96 |
| Input Example | ENT-FFP-CLNT:CISCO:FAC-1-1,FAC-2-1:100:::PROTTYPE=Y-CABLE, PROTID=DC-METRO-1,RVRTV=Y,RVTM=1.0,PSDIRN=BI; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.75 ENT-LNK-<MOD2O>: Enter Optical Link (OCH, OMS, OTS)

(Cisco ONS 15454 only)

This command creates an optical link between two optical connection points. The optical links can be established between two OTS or two OMS of the same band, and two OCH of the same wavelength. The created optical link must be between points belonging to the same ring directionality. An optical link between two OMS or two OCH can be HITLESS if the connection is between two points from one drop to a consecutive add in the logical link.

| Section | ENT-LNK-<MOD2O> Description | |
|------------------|--|--------------------|
| Category | DWDM | |
| Security | Provisioning | |
| Related Messages | DLT-FFP-CLNT | RLS-LASER-OTS |
| | DLT-LNK-<MOD2O> | RLS-PROTNSTW-CLNT |
| | ED-CLNT | RLS-PROTNSTW-OCH |
| | ED-DWDM | RTRV-CLNT |
| | ED-FFP-CLNT | RTRV-DWDM |
| | ED-FFP-OCH | RTRV-FFP-CLNT |
| | ED-LNK-<MOD2O> | RTRV-FFP-OCH |
| | ED-OCH | RTRV-LNK-<MOD2O> |
| | ED-OMS | RTRV-OCH |
| | ED-OTS | RTRV-OMS |
| | ED-TRC-CLNT | RTRV-OTS |
| | ED-TRC-OCH | RTRV-PROTNSTW-CLNT |
| | ENT-FFP-CLNT | RTRV-PROTNSTW-OCH |
| | OPR-LASER-OTS | RTRV-TRC-CLNT |
| | OPR-PROTNSTW-CLNT | RTRV-TRC-OCH |
| | OPR-PROTNSTW-OCH | |
| Input Format | ENT-LNK-<MOD2O>:[<TID>]:<FROM>,<TO>:<CTAG>::::<PST>,[<SST>]; where: <ul style="list-style-type: none">• <FROM> indicates an identifier at one end of the optical link and is the AID from the “BAND” section on page 4-18• <TO> indicates an identifier at the other end of the optical link and is the AID from the “BAND” section on page 4-18• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 | |
| Input Example | ENT-LNK-OMS:PENNNGROVE:BAND-6-1-TX,BAND-13-1-RX: 114::::OOS,AINS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.76 ENT-OSC: Enter Optical Service Channel

(Cisco ONS 15454 only)

This command creates the OSC (optical service channel) group of the NE.

**Note**

RINGID defaults to the AID number.

| Section | ENT-OSC Description |
|------------------|--|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | DLT-OSC ED-OSC RTRV-OSC |
| Input Format | <p>ENT-OSC:[<TID>]:<AID>:<CTAG>:::[RINGID=<RINGID>,<NODEID>,[EAST=<EAST>],[WEST=<WEST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the OSC group of the NE and is the AID from the “OSC section on page 4-30 • <RINGID> identifies the OSC ring ID of the NE. It ranges from 1 to 9999. The default value is the AID number. <RINGID> is an integer • <NODEID> identifies the OSC node ID of the NE. It ranges from 0 to 31. <NODEID> is an integer • <EAST> identifies the east OC3 facility. In this release only one OC3 for east direction is supported. <EAST> is the AID from the “FACILITY section on page 4-28 • <WEST> identifies the east OC3 facility. In this release only one OC3 for west direction is supported. <WEST> is the AID from the “FACILITY section on page 4-28 |
| Input Example | ENT-OSC:PENNNGROVE:OSC-1:114:::RINGID=10,NODEID=1,EAST=FAC-8-1,WEST=FAC-10-1; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.77 ENT-UCP-CC: Enter Unified Control Plane Control Channel

(Cisco ONS 15454 only)

This command creates a UCP IP control channel.

If the CCTYPE is SCCC, the SDCC of the port should be created.

The LMP Hello parameters, CRC mode and MTU can be left NULL. The defaults will be assigned by the node.

The UCP remote cannot be provisioned by the user. The local CCID will be allocated by the node.

If the CCTYPE is routed, the remote IPCC defaults to its neighbor's nodeID.

Examples:

```
ENT-UCP-CC::CC-12:CTAG:::NBRIX=1,CCTYPE=SDCC,PORT=FAC-6-1,
LOCALCCID=12,LOCALIPCC=172.20.209.73,REMOTEIPCC=192.168.100.18,
LMPHELLOINT=2,LMPHELLODEADINT=6,MTU=1500,CRCMD=32-BIT;
```

ENT-UCP-CC::CC-15:CTAG:::NBRIX=8,CCTYPE=ROUTED,LOCALCCID=15,
 LOCALIPCC=172.20.209.73,REMOTEIPCC=192.168.100.18,LMPHELLOINT=2,
 LMPHELLODEADINT=6,MTU=1500,CRCMD=16-BIT;

ENT-UCP-CC::CC-16:CTAG:::NBRIX=8,CCTYPE=ROUTED,LOCALCCID=16,
 LOCALIPCC=172.20.209.73,LMPHELLOINT=2,LMPHELLODEADINT=6,
 MTU=1500,CRCMD=16-BIT;

Notes:

1. If this command is sent twice, or input with invalid data, a SRQN (Status, Invalid Request) error message is returned.
2. If sending this command to provision MTU, CRCMD, or both while the IPCC type is routed (CCTYPE=ROUTED), an IIAC (Routed CC Is Not Allowed to Provision MTU and CRCMD) error message is returned.
3. The LMPHELLODEADINT interval has to be larger than the hello interval and is normally set to 3 times the hello interval. Its range is 3 seconds to 30 seconds with a default of 15 seconds.
4. If sending this command to provision a ROUTED IPCC no matter if the neighbor discovery (NDEN) is Enabled or Disabled, the REMOTEIPCC has to be specified by the user with non zeros, otherwise, an error message will be returned.
5. If sending this command to provision an SDCC IPCC while the neighbor discovery (NDEN=Y) is Enabled, the REMOTEIPCC defaults to 0.0.0.0, and the user is not allowed to specify REMOTEIPCC, otherwise, and error message (SROF, Cannot specify Remote IPCC for SDCC-IPCC when ND is enabled) will be returned.
6. If sending this command to provision an SDCC IPCC while the neighbor discovery (NDEN=N) is Disabled, the REMOTEIPCC defaults to its neighbor's node ID (IP address).
7. If sending this command to provision an SDCC IPCC with a complete result, the SDCC of the specified SONET line is created (or enabled) automatically with a DB change reporting (if the DB change report is enabled).
8. If sending this command to provision more than 16 IPCC over one NE, a (Cannot create IPCC. Max. number (16) reached) error message is returned.

| Section | ENT-UCP-CC Description | |
|------------------|------------------------|---------------|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC | REPT ALM UCP |
| | DLT-UCP-IF | REPT EVT UCP |
| | DLT-UCP-NBR | RTRV-ALM-UCP |
| | ED-UCP-CC | RTRV-COND-UCP |
| | ED-UCP-IF | RTRV-UCP-CC |
| | ED-UCP-NBR | RTRV-UCP-IF |
| | ED-UCP-NODE | RTRV-UCP-NBR |
| | ENT-UCP-IF | RTRV-UCP-NODE |
| | ENT-UCP-NBR | |

| Section | ENT-UCP-CC Description |
|--------------|--|
| Input Format | <p>ENT-UCP-CC:[<TID>]:[<AID>]:<CTAG>:::[NBRIX=<NBRIX>,<CCTYPE=<CCTYPE>,<PORT=<PORT>,<LOCALCCID=<LOCALCCID>,<LOCALIPCC=<LOCALIPCC>,<REMOTCCID=<REMOTECCID>,<REMOTEIPCC=<REMOTEIPCC>,<LMPHELLOINT=<LMPHELLOINT>,<LMPHELLODEADINT=<LMPHELLODEADINT>,<MTU=<MTU>,<CRCMD=<CRCMD>,<TUNMD=<TUNMD>>]<:>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> indicates an individual IPCC ID and is the AID from the “IPCC section on page 4-29. The default value is “local IPCC ID” • <NBRIX> indicates a neighbor within the local node and is an integer • <CCTYPE> indicates the type of the control channel; valid values for <CCTYPE> are shown in the “UCP_IPCC_TYPE” section on page 4-96 • <PORT> indicates the port which the control channel is configured, while the CCTYPE is the type of SDCC. <PORT> is the AID from the “FACILITY section on page 4-28 and the default value is “applicable only if it is SDCC type” • <LOCALCCID> indicates the local control channel ID and is an integer. The default value is “local UCP node id” • <LOCALIPCC> indicates the local IP address of the control channel and is a string. The default value is “local node id (node IP address)” • <REMOTECCID> indicates the local control channel ID and is an integer. The default value is “– undefined until discovered by LMP” • <REMOTEIPCC> indicates the remote IP address of the control channel and is a string. The default value is “– undefined for SDCC IPCC and discovered by LMP” • <LMPHELLOINT> indicates the LMP (line management protocol) interval (in milliseconds). It is the time between hello messages sent by this node, defaults to 5 (with the range of 1–10). <LMPHELLOINT> is an integer and the default value is “5 seconds – (1–10 seconds)” • <LMPHELLODEADINT> indicates the control channel time-out interval (in milliseconds) by the neighbor if the neighbor does not receive the hello message, and defaults to 15 (with the range of 3–30). This interval has to be at least as large as the hello interval and is normally set to 3 times the hello interval. Its range is 3–30 seconds with a default of 15 seconds. <LMPHELLODEADINT> is an integer and its default value is “15 seconds – (3–30 seconds)” • <MTU> indicates the MTU size of this control channel. <MTU> is an integer and its default value is “1500 bytes” • <CRCMD> indicates the CRC mode for this control channel. It is applicable to IPCCs in SDCC type. Valid values for <CRCMD> are shown in the “UCP_CRC_MODE” section on page 4-96 • <TUNMD> indicates the IP Tunneling option. It defaults to disabled and valid values are shown in the “UCP_CC_TUN_MD” section on page 4-95 |

| Section | ENT-UCP-CC Description |
|---------------|---|
| Input Example | ENT-UCP-CC:CISCO:CC-9:CTAG:::NBRIX=8,CCTYPE=SDCC,PORT=FAC-2-1,LOCALCCID=9,LOCALIPCC=172.20.209.162,REMOTCCID=2,REMOTEIPCC=172.20.209.73,LMPHELLOINT=1,LMPHELLODEADINT=5,MTU=1500,CRCMD=16-BIT,TUNMD=DISABLED; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.78 ENT-UCP-IF: Enter Unified Control Plane Interface

(Cisco ONS 15454 only)

This command creates a UCP interface.

The CCID can be set to zero to request the use of any control channel to the neighbor for this UCP interface/data link.

The local interface ID (LOCALIFID) is used by LMP/RSVP (Line Management Protocol/Resource Reservation Protocol). If zero is passed in as the local Interface ID of the data link, then the node assigns a value for it. If the user specifies a non-zero value, then the node checks if that Interface ID is available and uses it.

If the UCP interface/data link control channel type is SDCC type, the local interface ID should be the same as CCID. Otherwise, an error message will be returned by the node.

The remote interface ID is allowed to be unspecified (by passing zero) if the NDEN is Enabled and there is a SDCC IPCC specified for this UPC Interface with the same Interface Index, or when Routed IPCC is used for this data link.

Examples:

ENT-UCP-IF::FAC-2-3:CTAG:::NBRIX=8,CCID=2,LOCALIFID=0,REMOTEIFID=4, TNATYPE=IPV4,TNAADDR=172.20.209.162,CORENETWORKID=3,ADMSTATE=UP;

ENT-UCP-IF::FAC-2-4:CTAG:::NBRIX=8,CCID=1,LOCALIFID=0,REMOTEIFID=4, TNATYPE=NSAP,TNAADDR=0102030405060708090A0B0C0D0E0F1011121314, CORENETWORKID=3,ADMSTATE=UP;



Note If this command is sent twice, or inputs invalid data, a SRQN (Status, Invalid Request) error message is returned.

| Section | ENT-UCP-IF Description | |
|------------------|---|--|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-NBR | REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE |

| Section | ENT-UCP-IF Description |
|---------------|---|
| Input Format | <p>ENT-UCP-IF:<TID>:<AID>:<CTAG>:::[NBRIX=<NBRIX>],[CCID=<CCID>], [LOCALIFID=<LOCALIFID>],[REMOTEIFID=<REMOTEIFID>],[TNATYPE=<TNATYPE>],[TNAADDR=<TNAADDR>],[CORENETWORKID=<CORENETWORKID>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> indicates the interface port index of the data link and is the AID from the “FACILITY” section on page 4-28 • <NBRIX> indicates a neighbor within the local node and is an integer • <CCID> indicates the control channel ID. It can be set to zero to request the use of any control channel to the neighbor for this UCP interface/ data link. <CCID> is an integer. A null value defaults to “any control channel to the neighbor” • <LOCALIFID> indicates the local interface ID used by LMP/RSVP (Line Management Protocol/Resource reservation Protocol). If this attribute value is assigned by the UI, it will be ignored. <LOCALIFID> is an integer • <REMOTEIFID> indicates the remote interface ID on the neighbor's side. If this attribute value is passed by UI, it will be ignored. <REMOTEIFID> is an integer • <TNATYPE> indicates the TNA (Transport Network Administered) type and defaults to IPv4. Valid values for <TNATYPE> are shown in the “UCP_TNA_TYPE” section on page 4-96. The default value is “IPv4” • <TNAADDR> indicates the TNA (Transport Network Administered) IP address and defaults to IPv4 0.0.0.0. <TNAADDR> is a string. The default value is “0” • <CORENETWORKID> indicates the core network ID and defaults to one (1) |
| Input Example | ENT-UCP-IF:CISCO:FAC-2-1:CTAG:::NBRIX=12,CCID=16,LOCALIFID=16, REMOTEIFID=0,TNATYPE=IPV4,TNAADDR=172.20.209.162, CORENETWORKID=7; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.79 ENT-UCP-NBR: Enter Unified Control Plane Neighbor

(Cisco ONS 15454 only)

This command creates a UCP neighbor.

The default value of the node name can be overwritten by the TL1 user to a string in a maximum size of 20 characters. If the node name includes non-identified TL1 characters (e.g. space), the text string format with the double quotes is required.

Notes:

1. If this command is sent twice or inputs invalid data, a SRQN (Status, Invalid Request) error message is returned.
2. If sending this command without neighbor node name in the “NAME” field, an IIAC (Neighbor Name Can Not be Empty) error message is returned.
3. If sending this command with nodeid while the neighbor discovery is enabled (NDEN=Y), an IIAC (NODEID Is Not Allowed If NDEN Is Enabled) error message is returned.
4. If sending this command to set the hello interval while the RSVP hello is disabled, an IIAC (HELLOINT Is Not Allowed If HELLOEN Is Disabled) error message is returned.

5. If provisioning a neighbor with disabled neighbor discovery (NDEN=N), and NULL nodeid, a SROF (UCP Neighbor's NodeID cannot be null when Neighbor Discovery is disabled) is returned.
6. If sending this command to create a neighbor with the neighbor node name string longer than 64 characters, an IIAC (Node Name Too Long) error message is returned.

| Section | ENT-UCP-NBR Description | |
|---------------------|--------------------------------|---------------|
| Category | UCP | |
| Security | Provisioning | |
| Related Messages | DLT-UCP-CC | REPT ALM UCP |
| | DLT-UCP-IF | REPT EVT UCP |
| | DLT-UCP-NBR | RTRV-ALM-UCP |
| | ED-UCP-CC | RTRV-COND-UCP |
| | ED-UCP-IF | RTRV-UCP-CC |
| | ED-UCP-NBR | RTRV-UCP-IF |
| | ED-UCP-NODE | RTRV-UCP-NBR |
| | ENT-UCP-CC | RTRV-UCP-NODE |
| | ENT-UCP-IF | |

| Section | ENT-UCP-NBR Description |
|---------------|---|
| Input Format | <p>ENT-UCP-NBR:[<TID>]:<AID>:<CTAG>:::[NBRIX=<NBRIX>,<NBRIX>],[NODEID=<NODEID>,<NAME>,[NDEN=<NDEN>,<HELLOEN>,<HELLOINT>,<REFREDEN>][NUMRXMTS=<NUMRXMTS>][:]];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> indicates an individual neighbor index of the UCP. An available neighbor index will be assigned internally while sending this command without AID; <AID> is the AID from the “NBR” section on page 4-30 • <NBRIX> indicates a neighbor within the local node. <NBRIX> is an integer and the default value is the AID number or undefined zero (0) • <NODEID> indicates the neighbor node ID as received in RSVP, LMP messages from that node and is a string • <NAME> indicates the neighbor node name. It defaults to the ASCII representation of the nodeid in this command. The default value of this node name can be overwritten by the TL1 user to a string in a maximum size of 20 characters. If the node name includes non-identified TL1 characters (e.g. space), the text string format with the double quotes is required. <NAME> is a String. The default value is “the ASCII representation of the nodeid” • <NDEN> indicates if the neighbor discovery is enabled or not for this neighbor and it defaults to enable (Y). The default value is “Y”. Valid values for <NDEN> are shown in the “ON_OFF” section on page 4-76 • <HELLOEN> indicates if the RSVP hello is enabled to this neighbor or not and defaults to enable (Y). The default value is “Y”. Valid values for <HELLOEN> are shown in the “ON_OFF” section on page 4-76 • <HELLOINT> indicates the interval between hello messages to neighbor and defaults to 5. The default value is “5”. <HELLOINT> is an integer • <REFREDEN> indicates if the refresh reduction is enabled or not and defaults to enable (Y). The default value is “Y”. Valid values for <REFREDEN> are shown in the “ON_OFF” section on page 4-76 • <NUMRXMTS> indicates the maximum number of retransmits of each message and defaults to 3. The default value is “3”. <NUMRXMTS> is an integer |
| Input Example | ENT-UCP-NBR:CISCO:NBR-8:CTAG:::NBRIX=8,NODEID=192.168.100.52,NAME=NODE-A,NDEN=Y,HELLOEN=Y,HELLOINT=20,REFREDEN=Y,NUMRXMTS=3; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.80 ENT-USER-SECU: Enter User Security

This command adds a user account. Only a Superuser can do this. Each user is configured as being at one of these four privilege levels:

1. Retrieve [RTRV]: Users possessing this security level can retrieve information from the node, but cannot modify anything. The default idle time for Retrieve is unlimited.

2. Maintenance [MAINT]: Users possessing this security level can retrieve information from the node and perform limited maintenance operations such as card resets, Manual/Force/Lockout on cross-connects or in protection groups, and BLSR maintenance. The default idle time for Maintenance is 60 minutes.
3. Provisioning [PROV]: Users possessing this security level can perform all maintenance actions, and all provisioning actions except those restricted to superusers. The default idle time for Provisioning is 30 minutes.
4. Superuser [SUPER]: Users possessing this security level can perform all PROV user actions, plus creating/deleting user security profiles, setting basic system parameters such as time/date, node name, and IP address, doing database backup & restore. The default idle time for Superuser is 15 minutes.

Notes:

1. Passwords are masked for the following security commands: ACT-USER, ED-PID, ENT-USER-SECU and ED-USER-SECU. Access to a TL1 session via any means will have the password masked. The CTC Request History and Message Log will also show the masked commands. When a password-masked command is re-issued by double-clicking the command from CTC Request History, the password will still be masked in the CTC Request History and Message Log. The actual password that was previously issued will be sent to the NE. To use a former command as a template only, single-click the command in CTC Request History. The command will be placed in the Command Request text box, where you can edit the appropriate fields prior to re-issuing it.
2. The <UID> can be any combination of up to 10 alphanumeric characters.
3. The <PID> is a string of up to 10 characters where at least 2 characters are non-alphabetic with at least one special character (+, %, or #).
4. Although the CTC allows both <UID> and <PID> of up to 20 characters, the CTC-entered users (<UID> and <PID>) may not be valid TL1 users (e.g. if issuing an ACT-USER command and using the CTC-entered <UID> that is greater than 10 characters long, TL1 will respond with DENY (Can't Login) error message).
5. The TL1 password security is enforced as follows:
 - a. The password <PID> cannot be the same as or contain the userid (UID), for example, if the userid is CISCO25 the password cannot be CISCO25#.
 - b. The password <PID> must have one non-alphabetic and one special (+, %, or #) character.
 - c. There is no password <PID> toggling; for example, if the current password is CISCO25#, the new password cannot be CISCO25#

| Section | ENT-USER-SECU Description |
|----------|---------------------------|
| Category | Security |
| Security | Superuser |

| Section | ENT-USER-SECU Description |
|------------------|--|
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU |
| Input Format | ENT-USER-SECU:[<TID>]:<UID>:<CTAG>::<PID>,,<UAP>[:]; where: <ul style="list-style-type: none">• <UID> is the user identifier. The minimum <UID> size is 6, the maximum <UID> size is 10; <UID> is a string.• <PID> is a string.• <UAP> is the user access privilege value; valid values for <UAP> are shown in the “PRIVILEGE” section on page 4-82 |
| Input Example | ENT-USER-SECU:PETALUMA:CISCO15:123::PSWD11#,,MAINT; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.81 ENT-VCG: Enter Virtual Concatenated Group

(Cisco ONS 15454 only)

This command creates a VCG object. VCG on ML-series cards supports two members and supported substrates are: STS1, STS3C, or STS12C. ML-series VCG also supports SW-LCAS or NONE. VCG on the FR_MR-4 card supports eight members and supported substrate is limited to STS3C. The FR_MR-4 card VCG has no LCAS support (NONE).

| Section | ENT-VCG Description |
|------------------|---------------------|
| Category | VCAT |
| Security | Provisioning |
| Related Messages | DLT-VCG RTRV-VCG |

| Section | ENT-VCG Description |
|---------------|--|
| Input Format | <p>ENT-VCG:[<TID>]:<SRC>:<CTAG>:::TYPE=<TYPE>, TXCOUNT=<TXCOUNT>,[CCT=<CCT>],[LCAS=<LCAS>][:]; where:</p> <ul style="list-style-type: none"> • <SRC> AID to address the VCG from the “FACILITY” section on page 4-28. ML-series cards use VFAC AID and the FC_MR-4 card uses FAC AID • <TYPE> type of member cross-connect; valid values are shown in the “MOD_PATH” section on page 4-73. ML-series supports STS1, STS3C, and STS12C. The FC_MR-4 card supports STS3C. • <TXCOUNT> the number of members in Tx direction; <TXCOUNT> is an integer. For ML-series cards, the valid value is two. For the FC_MR-4 card, the valid value is eight. • <CCT> cross-connect type for the VCG member cross-connects. <CCT> must be the same for all the member cross-connects of a VCG; valid values are shown in the “CCT” section on page 4-53 • <LCAS> link capacity adjustment scheme; valid values are shown in the “LCAS” section on page 4-67. ML-series supports NONE or SW-LCAS. The FC_MR-4 card supports NONE. |
| Input Example | ENT-VCG:NODE1:FAC-1-1:1234:::TYPE=STS3C,TCOUNT=8,CCT=2WAY, LCAS=LCAS; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.82 ENT-WLEN: Enter Wavelength

(Cisco ONS 15454 only)

This command allocates a wavelength.



Note

This command does not support allocating multiple wavelengths.

| Section | ENT-WLEN Description |
|------------------|----------------------------------|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | DLT-WLEN ED-WLEN RTRV-WLEN |

| Section | ENT-WLEN Description |
|---------------|--|
| Input Format | ENT-WLEN:[<TID>]:<AID>:<CTAG>:::[SIZE=<SIZE>]:[<PST>],[<SST>]; where: <ul style="list-style-type: none">• <AID> is the wavelength AID from the “WLEN” section on page 4-37• <SIZE> is the circuit size allocated on this wavelength; valid values are shown in the “CIRCUIT_SIZE” section on page 4-53• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Input Example | ENT-WLEN: PENNGROVE: WLEN-W-ADD-1530.33:114:::SIZE=MULTI-RATE: OOS,MT; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.83 EX-SW-<OCN_BLSR>: Operate Protection Switch (OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command exercises the algorithm for switching from a working facility to a protection facility without actually performing a switch. It is assumed that the facility being exercised is the working unit. The exercise switching success or failure result will be indicated by an automatic alarm.

Exercise switch for the SONET protection line is not supported in this release. If sending this command to the protection unit, an error message will be returned. In addition to all normal INPUT, EQUIPAGE, PRIVILEGE error codes, the following error codes are also included in this command:

SNVS (Status, Not in Valid State)

SROF (Status, Requested Operation Failed)

SSRD (Status, Switch Request Denied)

Notes:

- If you send the EX-SW-<OCN_BLSR> command to both east and west sides/spans of a two-fiber or four-fiber ring within a short time period (less than 30–45 seconds) the system will only execute one (WEST) side EXER-RING query, and preempt the other (EAST) side query. There will be no event messages reported for the preempted side, and it will be in APS-CLEAR switching state.

Examples of sending the EX-SW-<OCN_BLSR> command to both east and west sides/spans of a two-fiber or four-fiber ring within a short time period (less than 30–45 seconds) are: (a) A single command with both side/span AIDs (in the list AID format) of the same two-fiber or four-fiber ring or (b) Separate queries (via TL1 or CTC, or TL1 and CTC) on both sides/spans of the same two-fiber or four-fiber ring

- DIRN is an optional parameter. A NULL value of this parameter defaults to BTH for a two-fiber or four-fiber BLSR protection group.

DIRN follows these rules:

- TRMT will always fail for any kind of protection groups
- For two-fiber and four-fiber BLSR protection groups both the RCV and TRMT direction will fail.
- Only BTH is a valid parameter. EX-SW-<OCN_TYPE> can be operated only on BLSR protection groups.

| Section | EX-SW-<OCN_BLSR> Description | |
|------------------|--|---|
| Category | BLSR | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-<MOD_RING> ED-<MOD_RING> ENT-<MOD_RING> INH-Swdx-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT | OPR-LPBK-<MOD2> REPT SW RLS-LPBK-<MOD2> RTRV-<MOD_RING> RTRV-TRC-<OCN_BLSR> SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | EX-SW-<OCN_BLSR>:<TID>:<AID>:<CTAG>::,<SWITCHTYPE>, [<DIRECTION>]; where: <ul style="list-style-type: none"> • <AID> identifies the facility in the NE to which the switch request is directed. <AID> is from the “FACILITY” section on page 4-28. <AID> must not be null. • <SWITCHTYPE> is the BLSR switch type; valid values are shown in the “SWITCH_TYPE” section on page 4-88. <SWITCHTYPE> must not be null • <DIRECTION> valid values are shown in the “DIRECTION” section on page 4-56 and a null value defaults to RCV | |
| Input Example | EX-SW-OC48:CISCO:FAC-12-1:123::,SPAN,BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.84 INH-MSG-ALL: Inhibit Message All

This command inhibits all REPT ALM and REPT EVT autonomous messages from being transmitted. See the ALW-MSG-ALL to resume these autonomous messages. When a TL1 session starts, the REPT ALM and REPT EVT messages are allowed by default.



Note If this command is used twice in the same session, the SAIN (Already Inhibited) error message is reported.

| Section | INH-MSG-ALL Description |
|----------|-------------------------|
| Category | System |
| Security | Retrieve |

| Section | INH-MSG-ALL Description | |
|------------------|---|--|
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-DBCHG INIT-SYS RTRV-HDR | RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |
| Input Format | INH-MSG-ALL:<TID>::<CTAG>[::,]; | |
| Input Example | INH-MSG-ALL:PETALUMA::550; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.85 INH-MSG-DBCHG: Inhibit Database Change Message

This command disables REPT DBCHG.

| Section | INH-MSG-DBCHG Description | |
|------------------|---|--|
| Category | Log | |
| Security | Retrieve | |
| Related Messages | ALW-MSG-ALL ALW-MSG-DBCHG ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INIT-SYS REPT DBCHG RTRV-HDR | RTRV-INV RTRV-LOG RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |
| Input Format | INH-MSG-DBCHG:<TID>::<CTAG>[::,]; | |
| Input Example | INH-MSG-DBCHG:CISCO::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.86 INH-MSG-SECU: Inhibit Message Security

This command inhibits the REPT EVT SECU and REPT ALM SECU messages.

| Section | INH-MSG-SECU Description | |
|----------|--------------------------|--|
| Category | Security | |
| Security | Superuser | |

| Section | INH-MSG-SECU Description | |
|------------------|--|-------------------|
| Related Messages | ACT-USER | ENT-USER-SECU |
| | ALW-MSG-SECU | INH-USER-SECU |
| | ALW-USER-SECU | REPT ALM SECU |
| | CANC | REPT EVT SECU |
| | CANC-USER | REPT EVT SESSION |
| | CANC-USER-SECU | RTRV-CMD-SECU |
| | DLT-USER-SECU | RTRV-DFLT-SECU |
| | ED-CMD-SECU | RTRV-USER-SECU |
| | ED-PID | SET-ATTR-SECUDFLT |
| | ED-USER-SECU | |
| Input Format | INH-MSG-SECU:[<TID>]::<CTAG>; | |
| Input Example | INH-MSG-SECU:PETALUMA::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.87 INH-PMREPT-ALL: Inhibit Performance Report All

This command inhibits all scheduled PM reporting. The inhibitance of the PM reporting is session-based, which means the command is only effective to the TL1 session that issues this command. By default, the scheduled PM reporting is inhibited by a TL1 session.

A TL1 session for which PM reports are inhibited will include an INHMSG-PMREPT condition when issuing TL1 command RTRV-COND-ALL.

| Section | INH-PMREPT-ALL Description | |
|------------------|--|-----------------------|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL | RTRV-PMSCHED-<MOD2> |
| | INIT-REG-<MOD2> | RTRV-PMSCHED-ALL |
| | INIT-REG-G1000 | RTRV-TH-<MOD2> |
| | REPT PM <MOD2> | SCHED-PMREPT-<MOD2> |
| | RTRV-PM-<MOD2> | SET-PMMODE-<STS_PATH> |
| | RTRV-PMMODE-<STS_PATH> | SET-TH-<MOD2> |
| | | |
| Input Format | INH-PMREPT-ALL:[<TID>]::<CTAG>; | |
| Input Example | INH-PMREPT-ALL:NE-NAME::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.88 INH-Swdx-Eqpt: Inhibit Switch Duplex Equipment

(Cisco ONS 15454 only)

This command inhibits automatic or manual switching on a system containing duplex equipment. Use the ALW-Swdx command to release the inhibit. This command is not used for SONET line protection switching. For SONET line/path protection switching commands, use the OPR-PROTNSW and RLS-PROTNSW commands. This command is not used for 1:1 and 1:N equipment protection switching, use ALW-SWTOPROTN, ALW-SWTOWKG, INH-SWTOPROTN, INH-SWTOWKG commands.

Notes:

1. This command applies for XC, XCVT, or XC10G equipment units only in this release.
2. When sending this command to a TCC2 card, an error message will occur because the NE treats the TCC2 as a non-revertive protection group without user control.

| Section | INH-SWDX-EQPT Description | |
|------------------|---|-----------------|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-SWDX-EQPT | REPT EVT EQPT |
| | ALW-SWTOPROTN-EQPT | REPT SW |
| | ALW-SWTOWKG-EQPT | RTRV-ALM-EQPT |
| | DLT-EQPT | RTRV-ALMTH-EQPT |
| | ED-EQPT | RTRV-COND-EQPT |
| | ENT-EQPT | RTRV-EQPT |
| | EX-SW-<OCN_BLSR> | SET-ALMTH-EQPT |
| | INH-SWTOPROTN-EQPT | SW-DX-EQPT |
| | INH-SWTOWKG-EQPT | SW-TOPROTN-EQPT |
| | REPT ALM EQPT | SW-TOWKG-EQPT |
| Input Format | INH-SWDX-EQPT:[<TID>]:<AID>:<CTAG>[::]; where: <ul style="list-style-type: none">• <AID> is the XC/XCVT/XC10G equipment AID (Slot 8 or Slot 10) from the “EQPT” section on page 4-27 | |
| Input Example | INH-SWDX-EQPT:CISCO:SLOT-1:1234; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.89 INH-SWTOPROTN-EQPT: Inhibit Switch to Protection Equipment

(Cisco ONS 15454 only)

This command inhibits automatic or manual switching of an equipment unit to protection. Use the ALW-SWTOPROTN-EQPT command to release the inhibit.

INH-SWTOPROTN-EQPT is used for non-SONET line cards (e.g. DS1, DS3, DS3XM and EC1 cards). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection. When performing a lockout with this command, the traffic will be switched from the unit specified by the AID, unless the working unit being protected has failed or is missing. When performing a lock on with this command and the working unit specified in the AID is in standby, sending this command will also initiate a traffic switch. When traffic is locked on a working unit or locked out of the protection unit with this command, the protection unit will not carry traffic, even if the working unit is pulled from the system.

Sending this command to a working unit in a 1:N protection group does not prevent a protection switch from another working unit in the same protection group. All the working units must be sent this command to prevent a protection switch. If the command is sent only to a subset of the working units, only those working units will have traffic locked on.

The inhibit state is persistent over TCC2 side switches and removal/reboot of all the units in the protection group. The inhibit state can, but does not have to be persistent over a complete power cycle of the NE.

The unit specified by the AID will raise the condition of INHSWPR when this command is sent.

Notes:

1. This command only supports one value of the <DIRN> parameter - BTH. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message should be responded.
2. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will receive an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-Swdx-EQPT commands.
3. This command is not used for SONET (OCN) cards. A command on a SONET card will receive an IIAC (Input, Invalid Access Identifier) error message. To use a SONET card switching command, use the OPR-PROTNSW and RLS-PROTNSW commands.
4. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message should be received.
5. If this command is used on a card that is already in the inhibit state, the SAIN (Status, Already Inhibited) error message should be received.
6. If sending the inhibit switch to protection command to a working card when the protect card in the same protection group has already raised the condition of INHWWKG, the SPLD (Status, Protection unit Locked) error message should be responded.
7. If sending the inhibit switch to protection command to the protect card when a working card in the same protection group has already raised the condition of INHWWKG, the SWLD (Status, Working unit Locked) error message should be responded.
8. Sending the inhibit switch to protection command to an active protect card when the peer working card is failed or missing, the SWFA (Status, Working unit Failed) error message should be responded.
9. The following situation(s) are allowed and will not generate any error response: sending this command to missing cards as long as none of the previous error conditions apply.

| Section | INH-SWTOPROTN-EQPT Description | |
|------------------|--|---|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-SWTOWKG-EQPT REPT ALM EQPT | REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |

| Section | INH-SWTOPROTN-EQPT Description |
|---------------|---|
| Input Format | <p>INH-SWTOPROTN-EQPT:[<TID>]:<AID>:<CTAG>[::<DIRN>]; where:</p> <ul style="list-style-type: none"> • <AID> This parameter can either be the working unit for which switching to protection is inhibited (lock on) or the protection unit for which carrying traffic is to be inhibited (lockout); <AID> is from the “EQPT” section on page 4-27 • <DIRN> is the direction of the switching. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the DIRECTION, page 56 |
| Input Example | INH-SWTOPROTN-EQPT:CISCO:SLOT-2:123::BTH; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.90 INH-SWTOWKG-EQPT: Inhibit Switch to Working Equipment

(Cisco ONS 15454 only)

This command inhibits automatic or manual switching of an equipment unit back to the working unit. Use the ALW-SWTOWKG-EQPT command to release the inhibit.

INH-SWTOWKG-EQPT is used for non-SONET line cards (e.g. DS1, DS3, DS3XM and EC1 cards). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection. When performing a lock-out with this command, the traffic will be switched from the unit specified by the AID, unless the protection unit has failed or is missing. When performing a lock-on with this command and the protection unit specified in the AID is in standby, sending this command will initiate a traffic switch only when there is one working card in the protection group. In the case where there is more than one working card in the protection group, an error will be generated (see error conditions below). When traffic is locked on the protection unit or locked out of a working unit with this command, the working unit will not carry traffic, even if the protection unit is pulled from the system.

The inhibit state is persistent over TCC2 side switches and removal/reboot of all the units in the protection group. The inhibit state can but does not have to be persistent over a complete power cycle of the NE.

The unit specified by the AID will raise the condition of INHSWWKG when this command is sent.

Notes:

1. The command only supports one value of the <DIRN> parameter - BTH. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message should be responded.
2. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will receive an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-SWDX-EQPT commands.
3. This command is not used for SONET (OCN) cards. A command on a SONET card will receive an IIAC (Input, Invalid Access Identifier) error message. To use a SONET card switching command, use the OPR-PROTNSW and RLS-PROTNSW commands.
4. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message should be received.

5. If this command is used on a card that is already in the inhibit state, the SAIN (Status, Already Inhibited) error message should be received.
6. If sending this command to a working card when the protect card in the same protection group has already raised the condition of INHSWPR, the SPLD (Status, Protection unit Locked) error message should be received.
7. If sending the INH-SWTOWKG command to a protect card when a working card in the same protection group has already raised the condition of INHSWPR, the SWLD (Status, Working unit Locked) error message should be responded.
8. If sending the INH-SWTOWKG command to an active working card when the protect card has failed or is missing, the SPFA (Status, Protection unit Failed) error message should be received.
9. If sending the INH-SWTOWKG command to an active working card when the protect card is already carrying traffic (this only occurs in a 1:N protection group with N greater than one), the SPAC (Status, Protection unit Active) error message should be received.
10. The following situation is allowed and will not generate any error response: Sending this command to missing cards as long as none of the previous error conditions apply.

| Section | INH-SWTOWKG-EQPT Description | |
|------------------|--|---|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-Swtoprotn-EQPT REPT ALM EQPT | REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | INH-SWTOWKG-EQPT:[<TID>]:<AID>:<CTAG>[::<DIRN>]; where: <ul style="list-style-type: none"> • <AID> This parameter can either be the protection unit for which switching back to working is inhibited (lock-on) or the working unit for which carrying traffic is to be inhibited (lockout); <AID> is from the “EQPT” section on page 4-27 • <DIRN> is the direction of the switching. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the DIRECTION, page 56 | |
| Input Example | INH-SWTOWKG-EQPT:CISCO:SLOT-2:123::BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.91 INH-USER-SECU: Inhibit User Security

This command disables (without deleting) a userid, so the user is denied access to the NE. The user is disabled until re-enabled via the ALW-USER-SECU command.

**Note**

This command does not forcibly log a user off. If the user is logged in, changes do not apply until after the user has logged off.

| Section | INH-USER-SECU Description | |
|------------------|---|-------------------|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER | ENT-USER-SECU |
| | ALW-MSG-SECU | INH-MSG-SECU |
| | ALW-USER-SECU | REPT ALM SECU |
| | CANC | REPT EVT SECU |
| | CANC-USER | REPT EVT SESSION |
| | CANC-USER-SECU | RTRV-CMD-SECU |
| | DLT-USER-SECU | RTRV-DFLT-SECU |
| | ED-CMD-SECU | RTRV-USER-SECU |
| | ED-PID | SET-ATTR-SECUDFLT |
| | ED-USER-SECU | |
| Input Format | INH-USER-SECU:[<TID>]::<CTAG>::<UID>; where: | |
| | <ul style="list-style-type: none"> • <UID> is a string | |
| Input Example | INH-USER-SECU:PETALUMA::123::CISCO100; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.92 INIT-REG-<MOD2>: Initialize Register (CLNT, DS1, DS3I, EC1, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command initializes the performance monitoring (PM) registers.

Notes:

1. The time period is always the current time period, and the previous time period counts are not cleared; therefore, both <MONDAT> and <MONTM> are not supported in this command.
2. Unless otherwise stated, DS1 and EC1 cards are the only cards that support the BTH, RCV, and TRMT directions. All other cards support only the RCV direction.
3. G1000 only supports BTH for DIRN, 1-DAY for TMPER, and NEND for LOCN.

| Section | INIT-REG-<MOD2> Description |
|----------|-----------------------------|
| Category | Performance |
| Security | Maintenance |

| Section | INIT-REG-<MOD2> Description |
|------------------|---|
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-G1000 REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> |
| Input Format | INIT-REG-<MOD2>:[<TID>]:<AID>:<CTAG>::<MONTYPE>,,[<LOCN>], [<DIRN>],[<TMPER>][,,]; where: <ul style="list-style-type: none"> • <AID> is the access identifier. All the STS, VT1, facility and DS1 AIDs are supported; <AID> is from the “ALL” section on page 4-9 • <MONTYPE> indicates the type of monitored parameter; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <LOCN> indicates the location, in reference to the entity identified by the AID, valid values for <LOCN> are shown in the “LOCATION” section on page 4-68 • <DIRN> is the direction of PM relative to the entity identified by the AID. <DIRN> defaults to ALL, which means that the command initializes all the registers irrespective of the PM direction. Valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56. • <TMPER> indicates the accumulation time period for the PM information; valid values for <TMPER> are shown in the “TMPER” section on page 4-93. A null value of <TMPER> defaults to 15-MIN. The default value is 15-MIN. |
| Input Example | INIT-REG-OC3:CISCO:FAC-1-1:1234::CVL,,NEND,BTH,15-MIN; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.93 INIT-SYS: Initialize System

This command initializes the specified card and its associated subsystem(s).

Notes:

1. The SLOT-ALL AID and the list AID are not allowed in this command.
2. Only one level of restart is supported in this command.
3. It is important that the standby TCC2 should be up and running fully standby before this command is sent on the active TCC2 for a period of time. During this time, the system is vulnerable to traffic outages caused by timing disruptions or other causes.

| Section | INIT-SYS Description |
|----------|----------------------|
| Category | System |
| Security | Maintenance |

| Section | INIT-SYS Description | |
|------------------|--|--|
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG | INH-MSG-SECU RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |
| Input Format | INIT-SYS:[<TID>]:<AID>:<CTAG>[::]; where: • <AID> is the access identifier of the equipment unit or slot and is from the “EQPT” section on page 4-27 | |
| Input Example | INIT-SYS:HOTWATER:SLOT-8:201; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.94 OPR-ACO-ALL: Operate Alarm Cutoff All

This command cuts off the office audible alarm indication without changing the local alarm indications.

This command does not have any effect on future alarms at the NE, it directs the NE to provide conditioning only on those alarms that are currently active.

The ACO retires the Central Office (CO) alarm audible indicators without clearing the indicators that show the trouble still exists. There is no need for a RLS-ACO command.

| Section | OPR-ACO-ALL Description | |
|------------------|--|--|
| Category | Environment Alarms and Controls | |
| Security | Maintenance | |
| Related Messages | OPR-EXT-CONT REPT ALM ENV REPT EVT ENV RLS-EXT-CONT RTRV-ALM-ENV RTRV-ATTR-CONT | RTRV-ATTR-ENV RTRV-COND-ENV RTRV-EXT-CONT SET-ATTR-CONT SET-ATTR-ENV |
| Input Format | OPR-ACO-ALL:[<TID>]:<CTAG>; | |
| Input Example | OPR-ACO-ALL:CISCO::123; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.95 OPR-EXT-CONT: Operate External Control

This command operates an external control and closes the external control contact. The control can be operated momentarily or continuously.

Notes:

1. The duration has two values in this release:
 - MNTRY: Momentary duration
 - CONTS: Continuos duration
2. In an automatic state, the contact could be opened or closed depending on the provisioned trigger.
3. RLS-EXT-CONT changes the state to automatic. Therefore, issuing an OPR-EXT-CONT command when the control is manually open and then issuing a RLS-EXT-CONT will not revert the state back to Manual Open.
4. A NULL value for the duration parameter defaults to MNTRY in this release.
5. RLS-EXT-CONT is not allowed during the MNTRY duration, the command is allowed for the CONTS duration. The length of the MNTRY duration is set to be 2 seconds on Cisco ONS 15454.
6. RLS-EXT-CONT cannot change the state to automatic if the existing state is Manual Open.



Caution

Do not turn on external controls that activate a potential danger; such as, sprinklers or other controls connected to possibly hazardous systems or equipment.

| Section | OPR-EXT-CONT Description | |
|------------------|--|---------------|
| Category | Environment Alarms and Controls | |
| Security | Maintenance | |
| Related Messages | OPR-ACO-ALL | RTRV-ATTR-ENV |
| | REPT ALM ENV | RTRV-COND-ENV |
| | REPT EVT ENV | RTRV-EXT-CONT |
| | RLS-EXT-CONT | SET-ATTR-CONT |
| | RTRV-ALM-ENV | SET-ATTR-ENV |
| | RTRV-ATTR-CONT | |
| Input Format | OPR-EXT-CONT:[<TID>]:<AID>:<CTAG>::[<CONTTYPE>],[<DURATION>]; where: <ul style="list-style-type: none"> • <AID> is the access identifier environment AID from the “ENV” section on page 4-26 and must not be null • <CONTTYPE> is the type of control; valid values for <CONTTYPE> are shown in the “CONTTYPE” section on page 4-55. A null value is equivalent to ALL. • Valid values for <DUR> are shown in the “DURATION” section on page 4-57. A null value is equivalent to ALL. | |
| Input Example | OPR-EXT-CONT:CISCO:ENV-OUT-2:123::AIRCOND,CONTS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.96 OPR-LASER-OTS: Operate Laser Optical Transport Section

(Cisco ONS 15454 only)

This command instructs a laser to switch on.

| Section | OPR-LASER-OTS Description | |
|------------------|---|---|
| Category | DWDM | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-PROTNSTW-CLNT OPR-PROTNSTW-OCH | RLS-LASER-OTS RLS-PROTNSTW-CLNT RLS-PROTNSTW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSTW-CLNT RTRV-PROTNSTW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | OPR-LASER-OTS:[<TID>]:<AID>:<CTAG>; where: • <AID> indicates an identifier of an optical facility supporting laser; <AID> is the AID from the “LINE” section on page 4-29 | |
| Input Example | OPR-LASER-OTS::LINE-5-2-TX:3; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.97 OPR-LNK: Operate Link

(Cisco ONS 15454 only)

This command operates the optical link (OLNK) application inside the NE to calculate all the automatic optical links between end points which can be univocally identified by the NE.

| Section | OPR-LNK Description |
|------------------|--|
| Category | DWDM |
| Security | Maintenance |
| Related Messages | DLT-LNK-<MOD2O> ED-LNK-<MOD2O> ENT-LNK-<MOD2O> |
| Input Format | OPR-LNK:[<TID>]::<CTAG>; |
| Input Example | OPR-LNK:PENNNGROVE::114; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.98 OPR-LPBK-<MOD2>: Operate Loopback (CLNT, DS1, DS3I, EC1, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command operates a signal loopback on an I/O card or on a cross-connect.

The optional [<LPBKTYPE>] defaults to FACILITY in this command if it is given to a port entity. It defaults to CRS if given to an STS entity.

Notes:

1. The value CRS for the LPBKTYPE parameter is applicable only for the STS modifier. The FACILITY and TERMINAL values are applicable to the ports.
2. The TERMINAL loopback type is not supported for the DS1 line of a DS3XM card.
3. Loopbacks are only allowed to be setup if the port/interface/STS_PATH is in OOS-MT or in OOS-AINS state.
4. Cross-connect loopbacks cannot be applied to the destination end of any 1WAY cross-connect.:
5. A cross-connect loopback can be applied only on one STS path of a cross-connect.
6. FEAC loopbacks can be applied by using the LINE value for LPBKTYPE parameter and specifying the LOCN as FEND. The FEAC loopbacks are supported only on the DS3(T3) and DS1 interfaces on the DS3XM-6 card.
7. FEAC loopbacks can be applied only if the DS3 is in C-bit framing format. FEAC loopbacks will override existing loopbacks at the near end on the entity and vice-versa. This means that if a facility loopback has been applied on a port and if the FEAC loopback is applied, then the facility loopback is first released and then the far end loopback is applied.
8. The LINE value is supported only with the FEND value of the LOCN parameter. FACILITY, TERMINAL, and CRS values are not compatible with the FEND value for the LOCN parameter.
9. A Lockout of the protection command is required before putting the span of either two-fiber or four-fiber BLSR line in loopback. (a) A span lockout of one side (e.g. East side) of the two-fiber BLSR is required before operating a Facility (or Terminal) line Loopback on the same side (e.g.. East side) of the ring. (b) A span lockout of one Protection side (e.g. East Protection side) of the four-fiber BLSR is required before operating a Facility (or Terminal) line Loopback on the same side Working line (e.g. East Working side) of the ring.
10. FEAC loopbacks on the DS1 interface of a DS3XM card can be applied only if a VT connection has been created on it. An attempt to operate/release FEAC loopbacks in the absence of a VT connection will lead to an error message response.

| Section | OPR-LPBK-<MOD2> Description |
|------------------|-------------------------------------|
| Category | Testing |
| Security | Maintenance |
| Related Messages | EX-SW-<OCN_BLSR> RLS-LPBK-<MOD2> |

| Section | OPR-LPBK-<MOD2> Description |
|---------------|---|
| Input Format | <p>OPR-LPBK-<MOD2>:[<TID>]:<AID>:<CTAG>::[<LOCATION>],,,[<LPBKTYPE>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “ALL” section on page 4-9. Valid values for AID are facility, DS1, and STS • <LOCATION> indicates the location where the operation is to be carried out. It defaults to NEND; valid values are shown in the “LOCATION” section on page 4-68 • <LPBKTYPE> is a loopback type; valid values for <LPBKTYPE> are shown in the “LPBK_TYPE” section on page 4-68 |
| Input Example | OPR-LPBK-DS1:PTREYES:DS1-4-1-2-13:203::NEND,,,FACILITY; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.99 OPR-PROTNSTW-<OCN_TYPE>: Operate Protection Switch (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command initiates a SONET line protection switch request. User switch requests initiated with this command remain active until they are released via the RLS-PROTNSTW-OCN command or are overridden by a higher priority protection switch request.

The switch commands; MAN (Manual Switch), FRCD (Forced Switch) and LOCKOUT (Lockout) are supported by the ONS 15454.

Manual Switch of Protection Line (to Working Line). If the AID identifies the protection line, then (only in the 1+1 architecture) service will be transferred from the protection line to the working line, unless a request of equal or higher priority is in effect.

Manual Switch of Working Line (to Protection Line). If the AID identifies a working line, then service will be switched from the working line to the protection line unless a request of equal or higher priority is in effect.

Force Switch of Protection Line (to Working Line). If the AID identifies the protection line, then (only in the 1+1 architecture) service will be transferred from the protection line to the working line unless a request of equal or higher priority is in effect.

Force Switch of Working Line (to Protection Line). If the AID identifies a working line, then service will be transferred from the working line to the protection line unless a request of equal or higher priority is in effect. A lockout of protection and a signal fail of protection line have higher priority than this switch command.

Lockout of Protection Line. If the AID identifies the protection line, this switch command will prevent the working line from switching to protection line. If the working line is already on protection, then the working line will be switched back to its original working line.

Lockout of Working Line. If the AID identifies the working line, this switch command will prevent the working line from switching to protection line. If the working line is already on protection, then the working line will be switched back from protection line to its original working line.

Notes:

1. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A query on a common control card will generate an IIAC (Input, Invalid Access Identifier) error message. To use this command on the common control card switching commands, use the SW-DX-EQPT and ALW-Swdx-EQPT commands.
2. Sending this command on non-SONET (OCN) cards, an IIAC (Input, Invalid Access Identifier) error message should be received. To query on a non-SONET card switching command, use the ALW-SWTOPROTN/SWTOWKG-EQPT and INH-SWTOPROTN/SWTOWKG-EQPT commands.
3. When sending this command to query on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message will be returned.
4. When sending this command to a working card that is failed or missing, the SROF (Protection Switching Failed) error message will be returned.
5. When sending this command to a protect card that is failed or missing, the SROF (Protection Switching Failed) error message will be returned.
6. When sending this command to a card that is already in protection with a higher priority, the SSRD (Status, Switch Request Denied) error message will be returned.
7. Sending this command to an OCN line with a switching mode that is already in mode, will return a SAMS (Already in the Maintenance State) error message.
8. To get the protection switching state (manual, lockout, forced), use the RTRV-COND-ALL or RTRV-ALM-ALL commands.
9. If the far end of the same span has a higher protection switching state, for example, the near end is under Manual protection switching state, the far end is in the Forced protection switching state, the near end protection switching state will be preemptive and shown as APS_CLEAR switching state over the CTC/TL1 interface. The RTRV-PROTNSW-OCN command is used to retrieve the current switching state of a SONET line.
10. If sending this command with EXERCISE or APS_CLEAR switch operation, an error SROF (Invalid Protection Switch Operation) will be returned because these operations are not valid according to GR-833-CORE.

The EX-SW-<OCN_BLSR> is the correct command to perform the EXERCISE switch over the BLSR line.

11. Protection switch will be denied if SD/SF is already present on the switching path. If SD/SF is generated on the switching path after the switch is performed, the switch will be overwritten by the APS_CLEAR state. This does not apply for lockout of protection and forced switch which have higher priority than SD/SF.
12. Sending the following Manual Ring switching requests on both east and west sides/spans of a two-fiber or four-fiber ring in less than 30-45 seconds, such as: (a) A single TL1 command with both side/span AIDs (in the list AID format) of the same two-fiber or four-fiber ring; (b) The separated (via TL1, or CTC, or TL1 and CTC user interfaces) queries on the both sides/spans of the same two-fiber or four-fiber ring. The system will only execute one (WEST) side MS-RING query, and preempt the other (EAST) side query. There will be no event messages coming out for the preempted side, which switching state will be in APS-CLEAR state.
13. DIRN is an optional parameter. A NULL value defaults to BTH for a BLSR protection, BTH for 1+1 BI directional protection group, and RCV for 1+1 UNI directional protection group.

DIRN follows these rules: TRMT will always fail for any kind of protection groups. For two-fiber and four-fiber BLSR protection groups both the RCV and TRMT directions will fail.

14. DIRN is applicable for both 1+1 and BLSR protection groups. For example, OPR-PROTNSW can be performed on a BLSR span/ring as follows:
OPR-PROTNSW-OC48::FAC-5-1:A::LOCKOUT,SPAN:BTH;
15. A lockout of the protection command is required before putting the span of either two-fiber or four-fiber BLSR line in loopback. (a) A span lockout of one side (e.g. East side) of the two-fiber BLSR is required before operating a Facility (or Terminal) line Loopback on the same side (e.g. East side) of the ring. (b) A span lockout of one Protection side (e.g. East Protection side) of the four-fiber BLSR is required before operating a Facility (or Terminal) line Loopback on the same side Working line (e.g. East Working side) of the ring.
16. A span lockout on the working unit is not supported in ONS 15454 or ONS15327.

| Section | OPR-PROTNSW-<OCN_TYPE> Description | |
|------------------|--|---|
| Category | SONET Line Protection | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ENT-FFP-<OCN_TYPE> | ENT-FFP-CLNT EX-SW-<OCN_BLSR> RLS-PROTNSW-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-PROTNSW-<OCN_TYPE> |
| Input Format | OPR-PROTNSW-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>::<SW>, [<SWITCHTYPE>][:<DIRECTION>]; where: <ul style="list-style-type: none"> • <AID> identifies the facility in the NE to which the switch request is directed and is from the “FACILITY” section on page 4-28 • <SW> is the switch command on the facility; valid values for <SW> are shown in the “SW” section on page 4-88 • <SWITCHTYPE> BLSR switch type; valid values are shown in the “SWITCH_TYPE” section on page 4-88 • <DIRECTION> is the direction of transmission in which switching is to be made and is relative to the SONET line or path identified by the AID. Valid values are shown in the “DIRECTION” section on page 4-56. The default value is RCV | |
| Input Example | OPR-PROTNSW-OC48:CHICKALUMA:FAC-6-1:204::LOCKOUT,SPAN:BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.100 OPR-PROTNSW-<PATH>: Operate Protection Switch (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command initiates a SONET path protection switch request. User switch requests initiated with this command (forced switch, lockout, and manual switch) remain active until they are released through the RLS-PROTNSW-<PATH> command or overridden by a higher priority protection switch request.

Notes:

1. This command applies to path protection configuration only.

2. The VTAID should be working or protect AID only.
3. If you send this command on the Drop AID, a DENY (Invalid AID, should use working/protect AID) message will be returned.
4. To get the protection switching state (manual, lockout, forced), use the RTRV-COND-ALL or RTRV-ALM-ALL commands.
5. The GR-1400 does not allow the LOCKOUT_OF_WORKING on the path protection WORKING path/AID. Sending this command on the path protection WORKING path, a SROF (Invalid Protection Switch Operation) is returned.
6. If sending this command with EXERCISE or APS_CLEAR switch operation, an error SROF (Invalid Protection Switch Operation) will be returned because these operations are not valid according to GR-833-CORE.
7. Protection switch will be denied if SD/SF is already present on the switching path. If SD/SF is generated on the switching path after the switch is performed, the switch will be overwritten by the APS_CLEAR state. This does not apply for lockout of protection and forced switch which have higher priority than SD/SF.

| Section | OPR-PROTNSW-<PATH> Description |
|------------------|---|
| Category | Switch |
| Security | Maintenance |
| Related Messages | REPT SW RTRV-PROTNSW-<PATH> RLS-PROTNSW-<PATH> |
| Input Format | OPR-PROTNSW-<PATH>:[<TID>]:<SRC>:<CTAG>::<SC>[:]; where: <ul style="list-style-type: none">• <SRC> identifies the AID “CrossConnectId1” section on page 4-23• <SC> is the switch command that is to be initiated on the paths; valid values for <SC> are shown in the “SW” section on page 4-88 |
| Input Example | OPR-PROTNSW-STS1:CISCO:STS-2-1-1:123::MAN; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.101 OPR-PROTNSW-CLNT: Operate Protection Switch Client

(Cisco ONS 15454 only)

This command instructs the NE to initiate a Y cable protection switch request. User switch requests initiated with this command remain active until they are released via the RLS-PROTNSW-CLNT command or are overridden by a higher priority protection switch request.

The switch commands MAN (Manual Switch), FRCD (Forced Switch) and LOCKOUT (Lockout) switch command are supported by the Cisco ONS 15454.

Manual Switch of Protection Line (to Working Line) -- If the AID identifies the protection line, then service will be transferred from the protection line to the working line, unless a request of equal or higher priority is in effect.

Manual Switch of Working Line (to Protection Line) -- If the AID identifies a working line, then service will be switched from the working line to the protection line unless a request of equal or higher priority is in effect.

Force Switch of Protection Line (to Working Line) -- If the AID identifies the protection line, then service will be transferred from the protection line to the working line unless a request of equal or higher priority is in effect.

Force Switch of Working Line (to Protection Line) -- If the AID identifies a working line, then service will be transferred from the working line to the protection line unless a request of equal or higher priority is in effect. A lockout of protection and a signal fail of protection line have higher priority than this switch command.

Lockout of Protection Line -- If the AID identifies protection line, this switch command will prevent the working line from switching to protection line. If the working line is already on protection, then the working line will be switched back from protection line to its original working line.

Lockout of Working Line - If the AID identifies a working line, then this command prevents the working line from switching to protection. If the working line is already on protection, the working line will be switched back to its original working line.

If this command is used against pre-provisioned cards, the SROF (Protection Switching Failed) error will be returned.

| Section | OPR-PROTNSW-CLNT Description | |
|------------------|---|---|
| Category | DWDM | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-OCH | RLS-LASER-OTS RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | OPR-PROTNSW-CLNT:[<TID>]:<AID>:<CTAG>::<SC>[:]; where: <ul style="list-style-type: none">• <AID> is the AID from the “FACILITY” section on page 4-28• <SC> identifies the switch operation; valid values are shown in the “SW” section on page 4-88 | |
| Input Example | OPR-PROTNSW-CLNT:CISCO:FAC-1-1:100::FRCD; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.102 OPR-PROTNSW-OCH: Operate Protection Switch OCH

(Cisco ONS 15454 only)

This command operates a protection switch on the trunk port of a TXPP_MR_2.5G card.

| Section | OPR-PROTNSW-OCH Description | |
|------------------|---|-------------------|
| Category | DWDM | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-CLNT | RLS-LASER-OTS |
| | DLT-LNK-<MOD2O> | RLS-PROTNSW-CLNT |
| | ED-CLNT | RLS-PROTNSW-OCH |
| | ED-DWDM | RTRV-CLNT |
| | ED-FFP-CLNT | RTRV-DWDM |
| | ED-FFP-OCH | RTRV-FFP-CLNT |
| | ED-LNK-<MOD2O> | RTRV-FFP-OCH |
| | ED-OCH | RTRV-LNK-<MOD2O> |
| | ED-OMS | RTRV-OCH |
| | ED-OTS | RTRV-OMS |
| | ED-TRC-CLNT | RTRV-OTS |
| | ED-TRC-OCH | RTRV-PROTNSW-CLNT |
| | ENT-FFP-CLNT | RTRV-PROTNSW-OCH |
| | ENT-LNK-<MOD2O> | RTRV-TRC-CLNT |
| | OPR-LASER-OTS | RTRV-TRC-OCH |
| | OPR-PROTNSW-CLNT | |
| Input Format | OPR-PROTNSW-OCH:[<TID>]:<AID>:<CTAG>[::]; where: | |
| | <ul style="list-style-type: none"> <AID> indicates the trunk port and is the AID from the “CHANNEL” section on page 4-19 | |
| Input Example | OPR-PROTNSW-OCH:VA454-22:CHAN-2-2:100; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.103 OPR-SYNCNSW: Operate Synchronization Switch

This command initiates a switch to the reference specified by the synchronization reference number if the reference supplied is valid.

For manual types of switches the reference to which you want to switch should be of the same quality as the active reference source, otherwise the command will fail.

If you want to switch to a reference of lower quality, use the forced switch option.

The Operate Synchronization Switches are released by the RLS-SYNCNSW command or are overridden by a synchronization reference failure.

Once the switch is effective, a minor alarm “MANSWTOPRI” (Manual Switch to Primary or Secondary Reference...) will be raised for Manual switches and alarms like “FRCDSWTOPRI” (Forced Switch to Primary or Secondary Reference...) will be raised for Forced switches.

| Section | OPR-SYNCNSW Description |
|----------|--------------------------------|
| Category | Synchronization |
| Security | Maintenance |

| Section | OPR-SYNCNSW Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCRN ED-SYNCRN REPT ALM BITS REPT ALM SYNCNRN REPT EVT BITS REPT EVT SYNCNRN RLS-SYNCNSW |
| Input Format | OPR-SYNCNSW:[<TID>]:[<AID>]:<CTAG>::<SWITCHTO>,[<SC>]; where: <ul style="list-style-type: none"> • <AID> is the access identifier from the “SYNC_REF” section on page 4-34. The default value is SYNC-NE. • <SWITCHTO> identifies the new synchronization reference that will be used and is the AID from the “SYNCSW” section on page 4-34 • <SC> is the switch command to be issued. Only manual (MAN) and forced (FRCD) switches are allowed for this command. Valid values for <SC> are shown in the “SW” section on page 4-88. The default value is “MAN” |
| Input Example | OPR-SYNCNSW:CISCO:SYNC-NE:3::PRI,MAN; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.104 OPR-WDMANS: Operate Wavelength Division Multiplexing Automatic Node Setup

(Cisco ONS 15454 only)

This command operates the Automatic Optical Node Setup (AONS) application inside the NE to force a recompute of the value to be assigned to all VOAs representing the Optical Path inside the node.

| Section | OPR-WDMANS Description |
|------------------|--|
| Category | DWDM |
| Security | Maintenance |
| Related Messages | — |
| Input Format | OPR-WDMANS:[<TID>]:<CTAG> |
| Input Example | OPR-WDMANS:PENNGROVE::114; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.105 REPT ALM <MOD2ALM>: Report Alarm (CLNT, DS1, DS3I, E100, E1000, EC1, FSTE, G1000, GIGE, OC12, OC192, OC3, OC48, OCH, OMS, OSC, OTS, POS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, UDCDCC, UDCF, VT1, VT2, WLEN)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

Reports an alarm condition against a facility or a path.

| Section | REPT ALM <MOD2ALM> Description | |
|------------------|--------------------------------|---------------------|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM BITS | RTRV-ALM-BITS |
| | REPT ALM COM | RTRV-ALM-ENV |
| | REPT ALM ENV | RTRV-ALM-EQPT |
| | REPT ALM EQPT | RTRV-ALM-SYNCN |
| | REPT ALM SYNCN | RTRV-ALM-UCP |
| | REPT ALM UCP | RTRV-ATTR-CONT |
| | REPT EVT <MOD2ALM> | RTRV-ATTR-ENV |
| | REPT EVT BITS | RTRV-COND-<MOD2ALM> |
| | REPT EVT COM | RTRV-COND-ALL |
| | REPT EVT ENV | RTRV-COND-BITS |
| | REPT EVT EQPT | RTRV-COND-ENV |
| | REPT EVT FXFR | RTRV-COND-EQPT |
| | REPT EVT IOSCFG | RTRV-COND-SYNCN |
| | REPT EVT SYNCN | RTRV-COND-UCP |
| | REPT EVT UCP | SET-ATTR-CONT |
| | RTRV-ALM-<MOD2ALM> | SET-ATTR-ENV |
| | RTRV-ALM-ALL | |

| Section | REPT ALM <MOD2ALM> Description |
|----------------|--|
| Output Format | <p>SID DATE TIME</p> <p>** ATAG REPT ALM <MOD2ALM></p> <p>“<AID>:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,:[<DESC>],<AIDDET>”</p> <p>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “ALL” section on page 4-9 • <NTFCNCDE> indicates a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> indicates an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <DESC> is the condition description; <DESC> is a string and is optional • <AIDDET> specifies the AID type; valid values for <AIDDET> are shown in the “EQPT_TYPE” section on page 4-59, <AIDDET> is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00</p> <p>** 100.100 REPT ALM CLNT</p> <p>“FAC-2-1:MJ,LOS,SA,,,:“LOSS OF SIGNAL\”,OC12”</p> <p>;</p> |

3.4.106 REPT ALM BITS: Report Alarm Building Integrated Timing Supply

Reports an alarm condition on a BITS facility.

| Section | REPT ALM BITS Description |
|----------|---------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | REPT ALM BITS Description | |
|------------------|---|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME ** ATAG REPT ALM BITS “<AID>:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,:[<DESC>]” ; where: <ul style="list-style-type: none">• <AID> is the access identifier from the “BITS” section on page 4-19• <NTFCNCDE> identifies a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75• <CONDTYPE> indicates an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18• <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85• <DESC> is the condition description; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM BITS “BITS-1:MJ,SYNC,SA,,,:“LOSS OF TIMING\”” ; | |

3.4.107 REPT ALM COM: Report Alarm COM

Reports an alarm condition when an AID cannot be given, for example, a fan failure is reported using this message.

| Section | REPT ALM COM Description |
|----------|--------------------------|
| Category | Fault |
| Security | Retrieve |

| Section | REPT ALM COM Description | |
|------------------|--|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME ** ATAG REPT ALM COM “[<AID>]:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,:,[<DESC>]” ; where: <ul style="list-style-type: none">• <AID> indicates the alarm without AID; <AID> is a string and is optional• <NTFCNCDE> indicates a notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75• <CONDTYPE> indicates an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18• <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85• <DESC> is the condition description; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM COM “COM:MJ,FAN,NSA,,,:“FAN FAILURE\”” ; | |

3.4.108 REPT ALM ENV: Report Alarm Environment

Reports a customer-defined condition on an environmental alarm input.

| Section | REPT ALM ENV Description |
|----------|---------------------------------|
| Category | Environment Alarms and Controls |
| Security | Retrieve |

| Section | REPT ALM ENV Description | |
|------------------|---|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME ** ATAG REPT ALM ENV “<AID>:<NTFCNCDE>,<ALMTYPE>,,[<DESC>]” ; where: <ul style="list-style-type: none">• <AID> identifies an environmental input and is from the “ENV” section on page 4-26• <NTFCNCDE> identifies a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75• <ALMTYPE> abbreviated code identifying the alarm; valid values for <ALMTYPE> are shown in the “ENV_ALM” section on page 4-58• <DESC> is the alarm message; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM ENV “ENV-IN-1:MJ,OPENDR,,，“OPEN DOOR”” ; | |

3.4.109 REPT ALM EQPT: Report Alarm Equipment

Reports an alarm condition against an equipment unit or slot.

| Section | REPT ALM EQPT Description |
|----------|---------------------------|
| Category | Equipment |
| Security | Retrieve |

| Section | REPT ALM EQPT Description | |
|------------------|--|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME ** ATAG REPT ALM EQPT “<AID>:<NTFCNCDE>,<CONDITION>,<SRVEFF>,,:[<DESC>], [<AIDDET>]” ; where: <ul style="list-style-type: none">• <AID> is an equipment AID SLOT {1-17} from the “EQPT” section on page 4-27• <NTFCNCDE> is the notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75• <CONDITION> is the type of alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18• <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85• <DESC> is the condition description; <DESC> is a string and is optional• <AIDDET> specifies the type of AID; valid values for <AIDDET> are shown in the “EQPT_TYPE” section on page 4-59, <AIDDET> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM EQPT “SLOT-7:MJ,CONTR,NSA,,,:“CONTROLLER FAILURE\”,TCC” ; | |

3.4.110 REPT ALM SECU: Report Alarm Security

Reports the occurrence of an alarmed security event against the NE.

Based on TR-NWT-000835, the AID of the security alarm should be the Connection IDentifier (CID) which is not currently supported.

The COM or UID is an acceptable substitute for the AID.

**Note**

The INTRUSION-PSWD condition is the only condition that is reported as a standing condition instead of a transient condition. It defaults to NA and is reported by the REPT EVT SECU message. However, it can be reprovisioned to be reported at a higher severity. If the severity of this alarm is higher than NA, it is reported by the REPT ALM SECU message.

| Section | REPT ALM SECU Description | |
|------------------|--|---|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU | ENT-USER-SECU INH-MSG-SECU INH-USER-SECU REPT EVT SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-SECUDFLT |
| Output Format | SID DATE TIME ** ATAG REPT ALM SECU “<AID>:<NOTIFCODE>,<SECUALMTYPE>” ; where: <ul style="list-style-type: none"> • <AID> identifies an entity with the condition. It defaults to COM and is a string • <NOTIFCODE> indicates a 2-letter notification code; valid values for <NOTIFCODE> are shown in the “NOTIF_CODE” section on page 4-75 • <SECUALMTYPE> security alarm type; it is a subset of the CONDITION type. Valid values are shown in the “SECUALMTYPE” section on page 4-85. For R4.6 the only allowable type is INTRUSION-PSWD. | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM SECU “COM:CR,INTRUSION-PSWD” ; | |

3.4.111 REPT ALM SYNCN: Report Alarm Synchronization

Reports an alarm condition against a synchronization reference.

| Section | REPT ALM SYNCN Description |
|----------|----------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | REPT ALM SYNCN Description | |
|------------------|--|---|
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP | RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ALMTH-EQPT RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP RTRV-EQPT SET-ALMTH-EQPT SET-ATTR-CONT SET-ATTR-ENV SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Output Format | SID DATE TIME ** ATAG REPT ALM SYNCN “<AID>:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,:[<DESC>]” ; where: <ul style="list-style-type: none">• <AID> identifies a synchronization reference with alarm condition and is from the “SYNC_REF” section on page 4-34• <NTFCNCDE> indicates a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75• <CONDTYPE> indicates an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18• <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85• <DESC> is the condition description; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM SYNCN “SYNC-NE:MJ,MAN,SA,,,:“MANUAL SWITCH\”,” ; | |

3.4.112 REPT ALM UCP: Report Alarm Unified Control Plane

(Cisco ONS 15454 only)

Reports an alarm condition against a UCP object.

| Section | REPT ALM UCP Description | |
|---------------------|---|--|
| Category | UCP | |
| Security | Retrieve | |
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN | REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR RTRV-UCP-NODE SET-ATTR-CONT SET-ATTR-ENV |

| Section | REPT ALM UCP Description |
|----------------|--|
| Output Format | <p>SID DATE TIME ** ATAG REPT ALM UCP “<AID>:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,:[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> identifies a UCP object with alarm condition and is from the “ALL section on page 4-9” • <NTFCNCDE> is a notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE section on page 4-75” • <CONDTYPE> is the type of condition to be retrieved; valid values for <CONDTYPE> are shown in the “Conditions section on page 7-18” • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF section on page 4-85” • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 ** 100.100 REPT ALM UCP “CC-1:MJ,LMP-HELLODOWN,SA,,,: \“LMP HELLO FSM ON CONTROL CHANNEL DOWN\”,” ;</p> |

3.4.113 REPT DBCHG: Report Database Change Message

Reports any changes on the NE that result from:

1. TL1 provisioning commands or their GUI equivalents containing the verbs: ALW, DLT, ED, ENT, INH, INIT, OPR, RLS, SET, and SW (for example, DLT-EQPT, ENT-CRS-STS1)
2. External event such as a board insertion.

| Section | REPT DBCHG Description |
|------------------|--|
| Category | Log |
| Security | Retrieve |
| Related Messages | ALW-MSG-DBCHG INH-MSG-DBCHG RTRV-LOG |

| Section | REPT DBCHG Description |
|----------------|---|
| Output Format | <p>SID DATE TIME A ATAG REPT DBCHG “TIME=<TIME>,DATE=<DATE>,[SOURCE=<SOURCE>, [USERID=<USERID>],DBCHGSEQ=<DBCHGSEQ>:<COMMAND>:<VT>” ; where:</p> <ul style="list-style-type: none"> • <TIME> is the time of the message triggered by the NE; <TIME> is a time • <DATE> is the date of the message triggered by the NE; <DATE> is a date • <SOURCE> is an input command CTAG if present; <SOURCE> is an integer and is optional • <USERID> is the user name or user identifier; <USERID> is a string and is optional • <DBCHGSEQ> is a sequential number of the DBCHG message; <DBCHGSEQ> is an integer • <COMMAND> is the input command or substitute; <COMMAND> is a string • <VT> is the AID from the “Conditions” section on page 7-18 |
| Output Example | TID-000 1998-06-20 14:30:00 A 001 REPT DBCHG “TIME=14-35-46,DATE=99-07-28,SOURCE=123,USERID=CISCO15, DBCHGSEQ=456:ENT-CRS-VT1:VT1-4-1-2-6-4” ; |

3.4.114 REPT EVT <MOD2ALM>: Report Event (CLNT, DS1, DS3I, FSTE, G1000, GIGE, OC12, OC192, OC3, OC48, OCH, OMS, OSC, OTS, POS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, UDCDCC, UDCF, VT1, VT2, WLEN)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

Reports the occurrence of a non-alarmed event.

| Section | REPT EVT <MOD2ALM> Description |
|----------|--------------------------------|
| Category | Fault |
| Security | Retrieve |

| Section | REPT EVT <MOD2ALM> Description | |
|------------------|--|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME A ATAG REPT EVT <MOD2ALM> “<AID>:<CONDTYPE>,[<CONDEFF>],,,[<LOCN>],,,[<MONVAL>], [<THLEV>],[<TMPPER>]:[<DESC>],[<AIDDET>]” ; where: <ul style="list-style-type: none">• <AID> indicates an event with the condition type and is from the “ALL” section on page 4-9• <CONDTYPE> indicates an event with the condition type and is a string• <CONDEFF> is the effect of the condition on the NE; valid values are shown in the “COND_EFF” section on page 4-54. <CONDEFF> is optional• <LOCN> indicates the location; valid values for <LOCN> are shown in the “LOCATION” section on page 4-68. <LOCN> is optional• <MONVAL> is the monitored value and is a float; <MONVAL> is an integer and is optional• <THLEV> is the threshold value and is a float; <THLEV> is an integer and is optional• <TMPPER> is the accumulation time period for the PM information; valid values for <TMPPER> are shown in the “TMPPER” section on page 4-93. <TMPPER> is optional• <DESC> is the condition description; <DESC> is a string and is optional• <AIDDET> specifies the type of AID; valid values for <AIDDET> are shown in the “EQPT_TYPE” section on page 4-59. <AIDDET> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT DS1 “FAC-5-1:WKSWPR,TC,,,FEND,,12,13,15-MIN: \\“WORKING SWITCH TO PROTECTION\\”,OC48” ; | |

3.4.115 REPT EVT BITS: Report Event BITS

Reports a non-alarmed event against a BITS facility.

| Section | REPT EVT BITS Description | |
|------------------|---|---|
| Category | Synchronization | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME A ATAG REPT EVT BITS “<AID>:<CONDTYPE>,[<CONDEFF>],,,,:[<DESC>]” ; where: <ul style="list-style-type: none"> • <AID> indicates an access identifier and is from the “BITS” section on page 4-19 • <CONDTYPE> indicates a condition type and the valid values are shown in the “Conditions” section on page 7-18 • <CONDEFF> indicates an effect of the condition on the NE; valid values for are shown in the “COND_EFF” section on page 4-54, <CONDEFF> is optional • <DESC> is the condition description; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT BITS “BITS-1:SSM-STU,TC,,,:“SYNCHRONIZED - TRACEABILITY UNKNOWN\”” ; | |

3.4.116 REPT EVT COM: Report Event COM

Reports a non-alarmed event against an NE when there is no AID associated with it.

| Section | REPT EVT COM Description | |
|------------------|---|---|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | <p>SID DATE TIME A ATAG REPT EVT COM “[<AID>]:<CONDTYPE>,[<CONDEFF>],,,,:[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> indicates this event is from the NE. <AID> is a string and is optional. • <CONDTYPE> indicates an event condition type. Valid values are shown in the “Conditions” section on page 7-18 • <CONDEFF> indicates an effect of the condition on the NE; valid values for <CONDEFF> are shown in the “COND_EFF” section on page 4-54, <CONDEFF> is optional • <DESC> is the description message for the condition; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT COM “COM:CLDRESTART,TC,,,:“COLD RESTART”,” ; | |

3.4.117 REPT EVT ENV: Report Event Environment

Reports the occurrence of a non-alarmed event against an environment alarm input.

| Section | REPT EVT ENV Description |
|----------|---------------------------------|
| Category | Environment Alarms and Controls |
| Security | Retrieve |

| Section | REPT EVT ENV Description | |
|------------------|--|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME A ATAG REPT EVT ENV “<AID>:<ALMTYPE>,[<CONDEFF>],,,,:[<DESC>]” ; where: <ul style="list-style-type: none">• <AID> identifies an environmental input and is from the “ENV” section on page 4-26• <ALMTYPE> is an abbreviated code identifying the alarm and the valid values are shown in the “ENV_ALM” section on page 4-58• <CONDEFF> indicates an effect of the condition on the NE; valid values for <CONDEFF> are shown in the “COND_EFF” section on page 4-54, <CONDEFF> is optional• <DESC> is an alarm message; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT ENV “ENV-IN-2:OPENDR,TC,,,:“OPEN DOOR\”” ; | |

3.4.118 REPT EVT EQPT: Report Event Equipment

Reports the occurrence of a non-alarmed event against an equipment unit or slot.

| Section | REPT EVT EQPT Description |
|----------|---------------------------|
| Category | Equipment |
| Security | Retrieve |

| Section | REPT EVT EQPT Description | |
|------------------|--|---|
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT FXFR REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL | RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | SID DATE TIME A ATAG REPT EVT EQPT “<AID>:<CONDTYPE>,[<CONDEFF>],,,,:[<DESC>],[<AIDDET>]” ; where: <ul style="list-style-type: none">• <AID> indicates an equipment AID SLOT {1–17} and is from the “EQPT” section on page 4-27• <CONDTYPE> indicates an event condition type; <CONDTYPE> defaults to EQPT and the valid values are shown in the “Conditions” section on page 7-18• <CONDEFF> indicates an effect of the condition on the NE; valid values for <CONDEFF> are shown in the “COND_EFF” section on page 4-54, <CONDEFF> is optional• <DESC> is the condition description; <DESC> is a string and is optional• <AIDDET> specifies the type of AID; valid values for <AIDDET> are shown in the “EQPT_TYPE” section on page 4-59, <AIDDET> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT EQPT “SLOT-7:PLUGIN,TC,,,:\"EQUIPMENT PLUG-IN\",TCC” ; | |

3.4.119 REPT EVT FXFR: Report Event Software Download

Reports the FTP software download status of the start, completion, and completed percentage.

Notes:

1. The FXFR_RSLT is only sent when the FXFR_STATUS is COMPLD.
2. The BYTES_XFRD is only sent when the FXFR_STATUS is IP or COMPLD.

| Section | REPT EVT FXFR Description | |
|------------------|---|---|
| Category | File Transfer | |
| Security | Retrieve | |
| Related Messages | APPLY COPY-RFILE REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT IOSCFG REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> | RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV |
| Output Format | <p>SID DATE TIME A ATAG REPT EVT FXFR "<FILENAME>,<FXFR_STATUS>,[<FXFR_RSLT>],[<BYTES_XFRD>]" ; where:</p> <ul style="list-style-type: none"> • <FILENAME> when a package is being transferred between the FTP server and the controller cards, the <FILENAME> field will contain the string “active”. Following the transfer, if there is a second controller card on the node, the file will be copied over to the second card. While this is happening, REPT EVT FXFR messages will be generated with a filename of “standby”. <FILENAME> is a string • <FXFR_STATUS> indicates the file transferred status; START, or IP (In Progress), or COMPLD. Valid values for <FXFR_STATUS> are shown in the “TX_STATUS” section on page 4-94 • <FXFR_RSLT> indicates the file transferred result; SUCCESS or FAILURE. Valid values for <FXFR_RSLT> are shown in the “TX_RSLT” section on page 4-94 and <FXFR_RSLT> is optional • <BYTES_XFRD> indicates the transferred byte count; <BYTES_XFRD> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT FXFR "NEW.PKG,COMPLD,SUCCESS,21215147" ; | |

3.4.120 REPT EVT IOSCFG: Report Event IOS Config File

(Cisco ONS 15454 only)

Reports the status of copying the IOS configuration file when the COPY-IOSCFG command is issued.

Notes:

1. You can identify if this message is caused by an IOS config file downloading/uploading/merging by looking at the SRC and DEST field in the message. Refer to the COPY-IOSCFG command for more details.
2. There is no success/failure in the message to indicate the success or failure of the merge process when merging the startup IOS config file to the running config file.

| Section | REPT EVT IOSCFG Description | |
|------------------|---|---------------------|
| Category | IOS | |
| Security | Retrieve | |
| Related Messages | COPY-IOSCFG | RTRV-ALM-ALL |
| | REPT ALM <MOD2ALM> | RTRV-ALM-BITS |
| | REPT ALM BITS | RTRV-ALM-ENV |
| | REPT ALM COM | RTRV-ALM-EQPT |
| | REPT ALM ENV | RTRV-ALM-SYNCN |
| | REPT ALM EQPT | RTRV-ALM-UCP |
| | REPT ALM SYNCN | RTRV-ATTR-CONT |
| | REPT ALM UCP | RTRV-ATTR-ENV |
| | REPT EVT <MOD2ALM> | RTRV-COND-<MOD2ALM> |
| | REPT EVT BITS | RTRV-COND-ALL |
| | REPT EVT COM | RTRV-COND-BITS |
| | REPT EVT ENV | RTRV-COND-ENV |
| | REPT EVT EQPT | RTRV-COND-EQPT |
| | REPT EVT FXFR | RTRV-COND-SYNCN |
| | REPT EVT SYNCN | RTRV-COND-UCP |
| | REPT EVT UCP | SET-ATTR-CONT |
| | RTRV-ALM-<MOD2ALM> | SET-ATTR-ENV |
| Output Format | SID DATE TIME A ATAG REPT EVT IOSCFG "<AID>:<SRC>,<DEST>,<STATUS>,[<RESULT>]" ; where: <ul style="list-style-type: none"> • <AID> slot AID for the equipment and is from the AID “EQPT” section on page 4-27 • <SRC> specifies where the IOS config file is copied from and is a string • <DEST> specifies where the IOS config file is copied to and is a string • <STATUS> indicates the status of COPY-IOSCFG: Start, IP (In Process), or COMPLD; valid values are shown in the “TX_STATUS” section on page 4-94 • <RESULT> indicates the result of COPY-IOSCFG: Success or Failure; valid values are shown in the “TX_RSLT” section on page 4-94 and <RESULT> is optional | |

| Section | REPT EVT IOSCFG Description |
|----------------|---|
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT IOSCFG “SLOT-1:STARTUP,IOS-CONFIG-FILE-IN-NETWORK,COMPLD,SUCCESS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.121 REPT EVT SECU: Report Event Security

Reports the occurrence of a non-alarmed security event against the NE.

Based on TR-NWT-000835 in TR-NWT-000835 and the AID of the security alarm should be the Connection Identifier (CID) which is not supported in this release. The COM or UID is an acceptable substitute for the AID here. CID's will be supported in a future release.

For the rule of single failure, single message/alarm, the security alarm will not be reported as REPT ALM COM, because it is reported as REPT ALM SECU.

Because the NE sends this security message as a transient message, to make all TL1 autonomous messages consistent, the TL1 agent reports the security message into REPT EVT SECU.

| Section | REPT EVT SECU Description | |
|------------------|--|---|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU | ENT-USER-SECU INH-MSG-SECU INH-USER-SECU REPT ALM SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-SECUDFLT |

| Section | REPT EVT SECU Description |
|----------------|---|
| Output Format | <p>SID DATE TIME</p> <p>A ATAG REPT EVT SECU “<AID>:<DNFIELD>,[<CONDEFF>],,,,:<SECURITY>:<DNFIELD1>” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies an entity with the condition and defaults to “COM”; <AID> is a string • <DNFIELD> is a string • <CONDEFF> indicates an effect of the condition on the NE and valid values are shown in the “COND_EFF” section on page 4-54; <CONDEFF> is optional • <SECURITY> is a string • <DNFIELD1> is a string |
| Output Example | <p>TID-000 1998-06-20 14:30:00</p> <p>A 100.100 REPT EVT SECU “COM:LOGIN-FAILURE-PSWD,TC,,,:“SECURITY: INVALID LOGIN - PASSWORD - SEE AUDIT LOG\”” ;</p> |

3.4.122 REPT EVT SESSION: Report Event Session

Reports a non-alarmed event related to establishing a session with the NE.

Notes:

1. The WARN field may contain different information depending on the type of session-related event.
2. If the password aging feature has not been enabled (or the feature is enabled but the password is not close to expiring):


```
/*USER <UID> LOGGED IN <IP/SERIAL PORT*/
```
3. If the forced password feature is enforced and the user is logging in for the first time (or the password has expired):


```
/*PLEASE CHANGE PASSWORD BEFORE CONTINUING*/
```
4. If a session is terminated for any reason (except a user timeout), the reason for the session termination is indicated in the warning (<WARN>).

| Section | REPT EVT SESSION Description |
|----------|------------------------------|
| Category | Security |
| Security | Retrieve |

| Section | REPT EVT SESSION Description |
|------------------|---|
| Related Messages | ACT-USER ENT-USER-SECU ALW-MSG-SECU INH-MSG-SECU ALW-USER-SECU INH-USER-SECU CANC REPT ALM SECU CANC-USER REPT EVT SECU CANC-USER-SECU RTRV-CMD-SECU DLT-USER-SECU RTRV-DFLT-SECU ED-CMD-SECU RTRV-USER-SECU ED-PID SET-ATTR-SECUDFLT ED-USER-SECU |
| Output Format | <p>SID DATE TIME</p> <p>A ATAG REPT EVT SESSION</p> <p>“<AID>:<EXP>,[<PCN>]”</p> <p>“WARN”</p> <p>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the NE with which a session is being attempted; <AID> is a string • <EXP> indicates whether the password is “alive” (i.e., no password updating is required at the moment), has expired, or is about to expire. Valid values are shown in the “YES_NO” section on page 4-99 • <PCN> the number of days still remaining before the existing password expires This parameter appears in EXP=YES and either 1.) the warning period has not been exhausted or 2.) the user is a new user establishing a session for the first time and the forced password change policy has been turned on. <PCN> is a string • <WARN> Free format text containing additional information about the security event; <WARN> is a string |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT SESSION “TCCP:YES,5-DAY” “/* USER TERRI LOGGED IN TO TCCP */” |

3.4.123 REPT EVT SYNCN: Report Event Synchronization

Reports the occurrence of a non-alarmed event against a synchronization entity.

| Section | REPT EVT SYNCN Description |
|----------|----------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | REPT EVT SYNCN Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCN ED-SYNCN OPR-SYNCNSW REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT UCP RLS-SYNCNSW RTRV-ALM-<MOD2ALM> |
| Output Format | SID DATE TIME A ATAG REPT EVT SYNCN "<AID>:<CONDTYPE>,[<CONDEFF>],,,,:[<DESC>],[<AIDDET>]" ; where: <ul style="list-style-type: none"> • <AID> identifies the synchronization entity with the condition and is from the “SYNC_REF” section on page 4-34 • <CONDTYPE> indicates the condition type; <CONDTYPE> defaults to SYNCN and the valid values are shown in the “Conditions” section on page 7-18 • <CONDEFF> indicates the effect of the condition on the NE; valid values for <CONDEFF> are shown in the “COND_EFF” section on page 4-54, <CONDEFF> is optional • <DESC> is the condition description; <DESC> is a string and is optional • <AIDDET> specifies the type of AID; valid values for <AIDDET> are shown in the “EQPT_TYPE” section on page 4-59, <AIDDET> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 A 100.100 REPT EVT SYNCN “SYNC-NE:SWTOINT,SC,,,:“SWITCH TO INTERNAL CLOCK”,TCC” ; |

3.4.124 REPT EVT UCP: Report Event Unified Control Plane

(Cisco ONS 15454 only)

Reports the occurrence of a non-alarmed even against a UCP object.

| Section | REPT EVT UCP Description | |
|------------------|---|---------------------|
| Category | UCP | |
| Security | Retrieve | |
| Related Messages | DLT-UCP-CC | REPT EVT SYNCN |
| | DLT-UCP-IF | RTRV-ALM-<MOD2ALM> |
| | DLT-UCP-NBR | RTRV-ALM-ALL |
| | ED-UCP-CC | RTRV-ALM-BITS |
| | ED-UCP-IF | RTRV-ALM-ENV |
| | ED-UCP-NBR | RTRV-ALM-EQPT |
| | ED-UCP-NODE | RTRV-ALM-SYNCN |
| | ENT-UCP-CC | RTRV-ALM-UCP |
| | ENT-UCP-IF | RTRV-ATTR-CONT |
| | ENT-UCP-NBR | RTRV-ATTR-ENV |
| | REPT ALM <MOD2ALM> | RTRV-COND-<MOD2ALM> |
| | REPT ALM BITS | RTRV-COND-ALL |
| | REPT ALM COM | RTRV-COND-BITS |
| | REPT ALM ENV | RTRV-COND-ENV |
| | REPT ALM EQPT | RTRV-COND-EQPT |
| | REPT ALM SYNCN | RTRV-COND-SYNCN |
| | REPT ALM UCP | RTRV-COND-UCP |
| | REPT EVT <MOD2ALM> | RTRV-UCP-CC |
| | REPT EVT BITS | RTRV-UCP-IF |
| | REPT EVT COM | RTRV-UCP-NBR |
| | REPT EVT ENV | RTRV-UCP-NODE |
| | REPT EVT EQPT | SET-ATTR-CONT |
| | REPT EVT FXFR | SET-ATTR-ENV |
| | REPT EVT IOSCFG | |
| Output Format | SID DATE TIME | |
| | A ATAG REPT EVT UCP | |
| | “<AID>:<CONDTYPE>,<CONDEFF>,,,,,:[<DESC>]” | |
| | ; | |
| | where: | |
| | • <AID> identifies a UCP object with alarm condition and is from the “ ALL section on page 4-9 | |
| | • <CONDTYPE> is the type of condition to be retrieved. Valid values for <CONDTYPE> are shown in the “ Conditions ” section on page 7-18; <CONDTYPE> is optional | |
| | • <CONDEFF> is the effect on service caused by the alarm condition; valid values for <CONDEFF> are shown in the “ COND_EFF ” section on page 4-54 | |
| | • <DESC> is a condition description; <DESC> is a string and is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 | |
| | A 100.100 REPT EVT UCP | |
| | “CC-1:LMP-HELLODOWN,TC,,,:“LMP HELLO FSM ON CONTROL CHANNEL DOWN”,” | |
| | ; | |

3.4.125 REPT PM <MOD2>: Report Performance Monitoring (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

Reports autonomous monitoring statistics as a result of the schedule created by SCHEP-PMREPT.

| Section | REPT PM <MOD2> Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> INIT-REG-G1000 RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Output Format | SID DATE TIME A ATAG REPT PM <MOD2> “<AID>:<MONTYPE>,<MONVAL>,<VLDTY>,<LOCN>,<DIRN>, <TMPER>,<MONDAT>,<MONTM>” ; where: <ul style="list-style-type: none"> • <AID> access identifier from the “ALL” section on page 4-9 • <MONTYPE> type of monitored parameter; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <MONVAL> measured value of monitored parameter; <MONVAL> is a string • <VLDTY> validity indicator for the reported PM data; valid values for <VLDTY> are shown in the “VALIDITY” section on page 4-97 • <LOCN> indicates the location; valid values are shown in “LOCATION” section on page 4-68 • <DIRN> direction of PM relative to the entity identified by the AID; valid values are shown in the “DIRECTION” section on page 4-56 • <TMPER> indicates the accumulation time period for the PM data; valid values are shown in the “TMPER” section on page 4-93 • <MONDAT> is the date of the beginning of the PM period specified by the TMPER parameter; <MONDAT> is a string • <MONTM> is the beginning time of day of the PM period specified by the TMPER parameter; <MONTM> is a string | |
| Output Example | TID-000 1998-06-20 14:30:00 A 100 REPT PM CLNT “FAC-3-1:CVL,10,PRTL,NEND,BTH,15-MIN,05-25,14-46” ; | |

3.4.126 REPT SW: Report Switch

(Cisco ONS 15454 only)

Reports the autonomous switching of a unit in a duplex equipment pair to the standby state and its mate unit to the active state. An automatic report for the occurrence or clearance of an alarm or event that triggers the switch may be associated with the message.

| Section | REPT SW Description | |
|------------------|---|--|
| Category | Path Protection Switching | |
| Security | Retrieve | |
| Related Messages | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT | INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Output Format | SID DATE TIME A ATAG REPT SW "<ACTID>,<STDBYID>" ; where: <ul style="list-style-type: none"> • <ACTID> identifies the equipment unit that has been placed in the active state. Parameter grouping cannot be used with this parameter; <ACTID> is the AID from the “EQPT” section on page 4-27 • <STDBYID> identifies the equipment unit that was placed in the standby state. Parameter grouping cannot be used with this parameter; <STDBYID> is the AID from the “EQPT” section on page 4-27 | |
| Output Example | TID-000 1998-06-20 14:30:00 A 001 REPT SW "SLOT-8,SLOT-10" ; | |

3.4.127 RLS-EXT-CONT: Release External Control

This command releases a forced contact state and returns the control of the contact to an AUTOMATIC control state. In AUTOMATIC control state, the contact could be opened or closed depending on triggers that may or may not be provisioned in the NE. Therefore, issuing an RLS might not produce any contact state change.

The NE defaults to having no triggers provisioned for external controls which consequently produces default open contacts. An NE with this default provisioning will always produce an open contact with a RLS-EXT-CONT command.

Notes:

1. The duration is not supported, it defaults to CONTS.
2. In an automatic state, the contact could be opened or closed depending on the provisioned trigger. Therefore, issuing an OPR-EXT-CONT command followed by an RLS-EXT-CONT command might not produce any contact state change.

3. The RLS-EXT-CONT is not allowed during the MNTRY duration. The command is allowed for the CONTS duration. The length of MNTRY duration is set to be 2 seconds.
4. RLS-EXT-CONT cannot change the contact state to Automatic if the existing state is Manual Open.

| Section | RLS-EXT-CONT Description | |
|------------------|--|--|
| Category | Environment Alarms and Controls | |
| Security | Maintenance | |
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM ENV REPT EVT ENV RTRV-ALM-ENV RTRV-ATTR-CONT | RTRV-ATTR-ENV RTRV-COND-ENV RTRV-EXT-CONT SET-ATTR-CONT SET-ATTR-ENV |
| Input Format | RLS-EXT-CONT:[<TID>]:<AID>:<CTAG>[::,]; where: <ul style="list-style-type: none"> • <AID> identifies the external control being released and is from the “ENV” section on page 4-26 | |
| Input Example | RLS-EXT-CONT:CISCO:ENV-OUT-2:123; | |
| Errors | Table 7-33 on page 7-27 . | |

3.4.128 RLS-LASER-OTS: Release Laser Optical Transport Section

(Cisco ONS 15454 only)

This command instructs a laser to be switched off.

| Section | RLS-LASER-OTS Description | |
|------------------|---|---|
| Category | DWDM | |
| Security | Maintenance | |
| Related Messages | DLT-FFF-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFF-CLNT ED-FFF-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFF-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNST-CLNT | OPR-PROTNST-OCH RLS-PROTNST-CLNT RLS-PROTNST-OCH RTRV-CLNT RTRV-DWDM RTRV-FFF-CLNT RTRV-FFF-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNST-CLNT RTRV-PROTNST-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |

| Section | RLS-LASER-OTS Description |
|---------------|---|
| Input Format | RLS-LASER-OTS:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> indicates an identifier of an optical facility supporting laser and is the AID from the “LINE” section on page 4-29 |
| Input Example | RLS-LASER-OTS::LINE-5-2-TX:3; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.129 RLS-LPBK-<MOD2>: Release Loopback (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See Table 4-11 on page 4-5 for supported modifiers by platform.

This command releases a signal loopback on an I/O card or a cross-connect.

Notes:

1. The value CRS for the LPBKTYPE parameter is applicable only for the STS modifier. The FACILITY and TERMINAL values for LPBKTYPE parameter are applicable to the ports.
2. The optional [<LPBKTYPE>] field defaults to the current existing loopback type.
3. The TERMINAL loopback type is not supported for a DS3XM card.
4. FEAC loopbacks can be released by specifying LINE as the loopback type and FEND as the location.
5. FEAC loopbacks on the DS1 interface of a DS3XM card can be applied only if a VT connection has been created on it. An attempt to operate/release FEAC loopbacks in the absence of a VT connection will result in an error message.

| Section | RLS-LPBK-<MOD2> Description |
|------------------|---|
| Category | Testing |
| Security | Maintenance |
| Related Messages | EX-SW-<OCN_BLSR> OPR-LPBK-<MOD2> |
| Input Format | RLS-LPBK-<MOD2>:[<TID>]:<SRC>:<CTAG>::[<LOCATION>],,,[<LPBKTYPE>]; where: <ul style="list-style-type: none">• <SRC> is an access identifier from the “ALL” section on page 4-9; valid values for AID are facility, DS1, and STS• <LOCATION> indicates the location where the operation is to be carried out. It defaults to NEND; valid values are shown in the “LOCATION” section on page 4-68• <LPBKTYPE> indicates the loopback type; valid values for <LPBKTYPE> are shown in the “LPBK_TYPE” section on page 4-68 |

| Section | RLS-LPBK-<MOD2> Description |
|---------------|--|
| Input Example | RLS-LPBK-DS1:PTREYES:DS1-4-1-2-13:203::,,FACILITY; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.130 RLS-PROTNSW-<OCN_TYPE>: Release Protection Switch (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command releases a SONET line protection switch request.

The release of a protection switch request is applicable only to the OPR-PROTNSW protection switch commands, the user-initiated switch protection commands.

Notes:

1. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. Sending a command on a common control card will generate an IIAC (Input, Invalid Access Identifier) error message. To query the common control card switching commands, use SW-DX-EQPT, ALW-Swdx-EQPT commands.
2. When sending this command on non-SONET (OCN) cards, an IIAC (Input, Invalid Access Identifier) error message should be responded. To use this command on a non-SONET card switching command, use ALW-SWTOPROTN/SWTOWKG-EQPT and INH-SWTOPROTN/SWTOWKG-EQPT commands.
3. When sending this command to query on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message should be responded.
4. When sending this command to a working card that is failed or missing, the SWFA (Status, Working unit Failed) error message should be responded.
5. When sending this command to a protect card that is failed or missing, the SPFA (Status, Protection unit Failed) error message should be responded.
6. When sending this command to a card that is not in protection, the SNPR (Status, Not in Protection State) error message should be responded.
7. Sending this command to an OCN line that is already in clear mode will return a SAMS (Already in Clear Maintenance State) error message.
8. To get the protection switching state (manual, lockout, forced), use the RTRV-COND-ALL or RTRV-ALM-ALL command.
9. DIRN is an optional parameter. A NULL value defaults to BTH for a BLSR protection, BTH for 1+1 BI directional protection group, and RCV for 1+1 UNI directional protection group.
DIRN follows these rules: TRMT will always fail for any kind of protection groups. For two-fiber and four-fiber BLSR protection groups both the RCV and TRMT directions will fail.
10. DIRN is applicable for both 1+1 and BLSR protection groups. OPR-PROTNSW applies to a BLSR span/ring as shown by the following command:
“RLS-PROTNSW-OC48::FAC-5-1:A::BTH;” instructs the NE to release a line protection switch request between a working line and a protection line.

| Section | RLS-PROTNSW-<OCN_TYPE> Description | |
|------------------|--|---|
| Category | SONET Line Protection | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ENT-FFP-<OCN_TYPE> | ENT-FFP-CLNT EX-SW-<OCN_BLSR> OPR-PROTNSW-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-PROTNSW-<OCN_TYPE> |
| Input Format | RLS-PROTNSW-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>[::<DIRECTION>]; where: <ul style="list-style-type: none">• <AID> identifies the facility in the NE to which the switch request is directed and is from the “FACILITY” section on page 4-28• Valid values for <DIRECTION> are shown in the “DIRECTION” section on page 4-56. The default value is RCV | |
| Input Example | RLS-PROTNSW-OC48:PETALUMA:FAC-6-1:209::BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.131 RLS-PROTNSW-<PATH>: Release Protection Switch (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command releases a SONET path protection switch request that was established with the OPR-PROTNSW-<PATH> command. This command assumes that only one user-initiated switch is active per AID.

Notes:

1. This command applies to path protection configuration only.
2. The VTAID should be working or protect AID only.
3. If sending this command on the Drop AID, a DENY (Invalid AID, should use working/protect AID) message will be returned.
4. To get the protection switching state (manual, lockout, forced), use the RTRV-COND-ALL or RTRV-ALM-ALL command.

| Section | RLS-PROTNSW-<PATH> Description |
|------------------|---|
| Category | Switch |
| Security | Maintenance |
| Related Messages | — |
| Input Format | RLS-PROTNSW-<PATH>:[<TID>]:<SRC>:<CTAG>[::]; where: <ul style="list-style-type: none">• <SRC> is the AID from the “CrossConnectId1” section on page 4-23 |

| Section | RLS-PROTNSW-<PATH> Description |
|---------------|--|
| Input Example | RLS-PROTNSW-STS1:CISCO:STS-2-1-1:123; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.132 RLS-PROTNSW-CLNT: Release Protection Switch Client

(Cisco ONS 15454 only)

This command releases a Y cable protection switch on client facilities.

| Section | RLS-PROTNSW-CLNT Description | |
|------------------|---|--|
| Category | DWDM | |
| Security | Maintenance | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT | OPR-PROTNSW-OCH RLS-LASER-OTS RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | RLS-PROTNSW-CLNT:[<TID>]:<AID>:<CTAG>[:]; where: <ul style="list-style-type: none">• <AID> is from the “FACILITY” section on page 4-28 | |
| Input Example | RLS-PROTNSW-CLNT:CISCO:FAC-1-1:100; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.133 RLS-PROTNSW-OCH: Release Protection Switch OCH

(Cisco ONS 15454 only)

This command releases the protection switch on a TXPP_MR_2.5G card.

| Section | RLS-PROTNSW-OCH Description |
|----------|------------------------------------|
| Category | DWDM |
| Security | Maintenance |

| Section | RLS-PROTNSTW-OCH Description | |
|------------------|--|--------------------|
| Related Messages | DLT-FFP-CLNT | OPR-PROTNSTW-OCH |
| | DLT-LNK-<MOD2O> | RLS-LASER-OTS |
| | ED-CLNT | RLS-PROTNSTW-CLNT |
| | ED-DWDM | RTRV-CLNT |
| | ED-FFP-CLNT | RTRV-DWDM |
| | ED-FFP-OCH | RTRV-FFP-CLNT |
| | ED-LNK-<MOD2O> | RTRV-FFP-OCH |
| | ED-OCH | RTRV-LNK-<MOD2O> |
| | ED-OMS | RTRV-OCH |
| | ED-OTS | RTRV-OMS |
| | ED-TRC-CLNT | RTRV-OTS |
| | ED-TRC-OCH | RTRV-PROTNSTW-CLNT |
| | ENT-FFP-CLNT | RTRV-PROTNSTW-OCH |
| | ENT-LNK-<MOD2O> | RTRV-TRC-CLNT |
| | OPR-LASER-OTS | RTRV-TRC-OCH |
| | OPR-PROTNSTW-CLNT | |
| | | |
| Input Format | RLS-PROTNSTW-OCH:<TID>:<AID>:<CTAG>; | |
| | where: | |
| | <ul style="list-style-type: none"> • <AID> is the AID from the “CHANNEL” section on page 4-19 | |
| Input Example | RLS-PROTNSTW-OCH:VA454-22:CHAN-2-2:1; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.134 RLS-SYNCNSW: Release Synchronization Switch

This command releases the previous synchronization reference provided by the OPR-SYNCNSW command.

In a non-revertive system, the use of the RLS-SYNCNSW command may not be appropriate. All the switching between synchronization references should be initiated with the OPR-SYNCNSW command.

Once a switch is released, a minor alarm “MANSWTOPRI”, (Manual Switch to Primary Reference or Secondary...) or “FRDCSWTOPRI” (Forced Switch to Primary Reference or Secondary...), will be cleared.

| Section | RLS-SYNCNSW Description | |
|------------------|-------------------------|------------------|
| Category | Synchronization | |
| Security | Maintenance | |
| Related Messages | ED-BITS | RTRV-ALM-BITS |
| | ED-NE-SYNCRN | RTRV-ALM-SYNCRN |
| | ED-SYNCRN | RTRV-BITS |
| | OPR-SYNCNSW | RTRV-COND-BITS |
| | REPT ALM BITS | RTRV-COND-SYNCRN |
| | REPT ALM SYNCNR | RTRV-NE-SYNCRN |
| | REPT EVT BITS | RTRV-SYNCRN |
| | REPT EVT SYNCNR | |

| Section | RLS-SYNCNSW Description |
|---------------|--|
| Input Format | RLS-SYNCNSW:[<TID>]:[<AID>]:<CTAG>; where: <ul style="list-style-type: none">• <AID> is the access identifier from the “SYNC_REF” section on page 4-34. The default value is SYNC-NE. |
| Input Example | RLS-SYNCNSW:CISCO:SYNC-NE:3; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.135 RMV-<MOD2_IO>: Remove (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, T1, T3)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command removes a facility from service.

| Section | RMV-<MOD2_IO> Description | |
|------------------|--|---|
| Category | Ports | |
| Security | Maintenance | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 INIT-REG-G1000 RST-<MOD2_IO> RTRV-<OCN_TYPE> | RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |
| Input Format | RMV-<MOD2_IO>:[<TID>]:<AID>:<CTAG>::[<CMDMODE>],[<PST>], [<SST>]; where: <ul style="list-style-type: none">• <AID> is the access identifier from the “ALL” section on page 4-9• <CMDMODE> is the command mode; valid values are shown in the “CMD_MODE” section on page 4-54• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 | |
| Input Example | RMV-EC1:CISCO:FAC-1-1:1::NORM,OOS,AINS; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.136 RST-<MOD2_IO>: Restore (CLNT, DS1, DS3I, EC1, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, T1, T3)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command provisions a facility in service.

| Section | RST-<MOD2_IO> Description | |
|------------------|--|------------|
| Category | Ports | |
| Security | Maintenance | |
| Related Messages | ED-<OCN_TYPE> | RTRV-DS1 |
| | ED-DS1 | RTRV-EC1 |
| | ED-EC1 | RTRV-FC |
| | ED-FC | RTRV-FSTE |
| | ED-G1000 | RTRV-G1000 |
| | ED-T1 | RTRV-GIGE |
| | ED-T3 | RTRV-POS |
| | INIT-REG-G1000 | RTRV-T1 |
| | RMV-<MOD2_IO> | RTRV-T3 |
| | RTRV-<OCN_TYPE> | |
| Input Format | RST-<MOD2_IO>:[<TID>]:<AID>:<CTAG>[::]; where: | |
| | <ul style="list-style-type: none"> • <AID> is an access identifier from the “ALL” section on page 4-9 | |
| Input Example | RST-EC1:CISCO:FAC-1-1:1; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.137 RTRV-<MOD_RING>: Retrieve Bidirectional Line Switched Ring

This command retrieves the BLSR information of the NE. A two-fiber or four-fiber BLSR can be retrieved.

Cisco ONS 15327 does not support four-fiber BLSR.

Output examples:

4F BLSR

“BLSR-43::RINGID=43,NODEID=3,MODE=4F,RVRTV=Y,RVTM=5.0,SRVRTV=Y,
SRVTM=5.0,EASTWORK=FAC-5-1,WESTWORK=FAC-6-1,EASTPROT=FAC-12-1,
WESTPROT=FAC-13-1”

2F BLSR

“BLSR-12::RINGID=12,NODEID=2,MODE=2F,RVRTV=Y,RVTM=5.0,EASTWORK=FAC-5-1,
WESTWORK=FAC-6-1”

Error conditions:

1. Only ALL, NULL, BLSR-ALL, or BLSR-RINGID is allowed for this command.
2. A NULL AID defaults to the AID ALL.

3. The list AID format is supported.
4. If the system fails on getting IOR, a SROF (Get IOR Failed) error message is returned.
5. If the AID is invalid, an IIAC (Invalid AID) error message is returned.
6. If the BLSR does not exist, a SRQN (BLSR Does Not Exist) error message is returned.

| Section | RTRV-<MOD_RING> Description | |
|------------------|---|---|
| Category | BLSR | |
| Security | Retrieve | |
| Related Messages | DLT-<MOD_RING> ED-<MOD_RING> ENT-<MOD_RING> | EX-SW-<OCN_BLSR> RTRV-TRC-<OCN_BLSR> |
| Input Format | <p>RTRV-<MOD_RING>:[<TID>]:[<AID>]:<CTAG>[:::];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the BLSR of the NE. Only ALL, NULL, or a list of BLSR-# in <AID> is allowed; <AID> is from the “AidUnionId” section on page 4-15. A null value is equivalent to ALL. | |
| Input Example | RTRV-BLSR:PETALUMA:ALL:123; | |

| Section | RTRV-<MOD_RING> Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[RINGID=<RINGID>],[NODEID=<NODEID>], [MODE=<MODE>],[RVRTV=<RVRTV>],[RVTM=<RVTM>], [SRVRTV=<SRVRTV>],[SRVTM=<SRVTM>], [EASTWORK=<EASTWORK>],[WESTWORK=<WESTWORK>], [EASTPROT=<EASTPROT>],[WESTPROT=<WESTPROT>]” ; where:</p> <ul style="list-style-type: none"> • <AID> identifies the BLSR of the NE and is from the “AidUnionId” section on page 4-15 • <RINGID> identifies the BLSR ringid of the NE; <RINGID> is a string of up to six characters, valid characters are [A–Z, 0–9]. <RINGID> is optional • <NODEID> identifies the BLSR node ID of the NE and ranges from 0–31; <NODEID> is an integer • <MODE> identifies the BLSR mode and can be 2-fiber or 4-fiber; valid values for <MODE> are shown in the “BLSR_MODE” section on page 4-50 • <RVRTV> identifies the revertive mode; valid values are shown in the “ON_OFF” section on page 4-76 • <RVTM> identifies the revertive time; valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <SRVRTV> identifies the span revertive mode; valid values are shown in the “ON_OFF” section on page 4-76 and <SRVRTV> is optional • <SRVTM> identifies the span revertive time; valid values are shown in the “REVERTIVE_TIME” section on page 4-84. <SRVTM> is optional. • <EASTWORK> identifies the east working facility and is the AID from the “FACILITY” section on page 4-28 • <WESTWORK> identifies the west working facility and is the AID from the “FACILITY” section on page 4-28 • <EASTPROT> identifies the east protecting facility and is the AID from the “FACILITY” section on page 4-28; <EASTPROT> is optional • <WESTPROT> identifies the west protecting facility and is the AID from the “FACILITY” section on page 4-28; <WESTPROT> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BLSR-43::RINGID=43,NODEID=3,MODE=4F,RVRTV=Y,RVTM=5.0, SRVRTV=Y,SRVTM=5.0,EASTWORK=FAC-5-1,WESTWORK=FAC-6-1, EASTPROT=FAC-12-1,WESTPROT=FAC-13-1” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.138 RTRV-<OCN_TYPE>: Retrieve (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the attributes (i.e., service parameters) and the state of an OC-N facility.

Both RINGID and BLSRTYPE identify the OCN port connected with a BLSR. These attributes are only presented for the OC12, OC48, OC192 ports within a BLSR connection. The RTRV-<MOD_RING> command with the AID BLSR-RINGID, can provide more information on this BLSR.

**Note**

This command does not show the WVLEN attribute if the OCN port has zero value on WVLEN.

UNI-C DCC provisioning notes:

1. The attributes DCC(Y/N) and mode (SONET/SDH) remain the same in the ED/RTRV-OCN commands when the DCC is used for UNI-C, in which case the port attribute UNIC is enabled (UNIC=Y).
2. UNI-C DCC termination can not be deleted by the regular DCC de-provisioning command.
3. If the DCC is created under regular SONET provisioning, and this port is used by UNI-C, the port is converted as an UNI-C DCC automatically.
4. De-provisioning UNI-C IF/IB IPCC will free up DCC termination automatically.
5. The parameters ALSMODE, ALSRCINT, and ALSRPCW are only applicable for OC3-8, OC192 and OC48ELR cards.
6. SSMRCV will display the quality of the individual port.

| Section | RTRV-<OCN_TYPE> Description | |
|------------------|--|------------|
| Category | Ports | |
| Security | Retrieve | |
| Related Messages | ED-<OCN_TYPE> | RTRV-DS1 |
| | ED-DS1 | RTRV-EC1 |
| | ED-EC1 | RTRV-FC |
| | ED-FC | RTRV-FSTE |
| | ED-G1000 | RTRV-G1000 |
| | ED-T1 | RTRV-GIGE |
| | ED-T3 | RTRV-POS |
| | INIT-REG-G1000 | RTRV-T1 |
| | RMV-<MOD2_IO> | RTRV-T3 |
| | RST-<MOD2_IO> | |
| Input Format | RTRV-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none">• <AID> is the access identifier from the “FACILITY” section on page 4-28 and must not be null. | |
| Input Example | RTRV-OC48:PENNNGROVE:FAC-6-1:236; | |

| Section | RTRV-<OCN_TYPE> Description |
|---------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[,<ROLE>],[<STATUS>]:[DCC=<DCC>],[AREA=<AREA>],[[TMGREF=<TMGREF>],[SYNCMSG=<SYNCMSG>],[[SENDDUS=<SENDDUS>],[PJMON=<PJMON>],[SFBER=<SFBER>],[[SDBER=<SDBER>],[MODE=<MODE>],[WVLEN=<WVLEN>],[[RINGID=<RINGID>],[BLSRTYPE=<BLSRTYPE>],[MUX=<MUX>],[[UNIC=<UNIC>],[CCID=<CCID>],[NBRIX=<NBRIX>],[SOAK=<SOAK>],[[SOAKLEFT=<SOAKLEFT>],[SSMRCV=<SSMRCV>],[OSPF=<OSPF>],[[LDCC=<LDCC>],[ALSMODE=<ALSMODE>],[ALSRCINT=<ALSRCINT>],[[ALSRCPW=<ALSRCPW>]:<PST>,[<SST>]” ; where:<ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 • <ROLE> identifies the OCN port role (e.g. WORK or PROT); valid values for <ROLE> are shown in the “SIDE” section on page 4-86, <ROLE> is optional • <STATUS> identifies the OCN port status (e.g. Active or Standby); valid values for <STATUS> are shown in the “STATUS” section on page 4-86, <STATUS> is optional • <DCC> identifies the OCN port DCC connection and defaults to N; valid values for <DCC> are shown in the “EXT_RING” section on page 4-65, <DCC> is optional • <TMGREF> identifies if an OCN port has timing reference and defaults to N; valid values for <TMGREF> are shown in the “ON_OFF” section on page 4-76, <TMGREF> is optional • <SYNCMSG> indicates if sync status messaging is enabled or disabled on the facility; <SYNCMSG> defaults to Y and the valid values are shown in the “ON_OFF” section on page 4-76. <SYNCMSG> is optional. • <SENDDUS> indicates that the facility will send out the DUS (do not use for synchronization) value as the sync status message for that facility; <SENDDUS> defaults to N and the valid values are shown in the “ON_OFF” section on page 4-76. <SENDDUS> is optional • <PJMON> identifies the OCN port PJMON; <PJMON> defaults to 0 (zero), is an integer and is optional </p> |

| Section | RTRV-<OCN_TYPE> Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <SFBER> identifies the OCN port SFBER and defaults to 1E-4; valid values for <SFBER> are shown in the “SF_BER” section on page 4-86, <SFBER> is optional • <SDBER> identifies the OCN port SDBER and defaults to 1E-7; valid values for <SDBER> are shown in the “SD_BER” section on page 4-85, <SDBER> is optional • <MODE> identifies the OCN port mode (e.g. SONET, SDH) and defaults to SONET; valid values for <MODE> are shown in the “OPTICAL_MODE” section on page 4-77, <MODE> is optional • <WVLEN> identifies the OCN port wavelength; <WVLEN> is wavelength in nm (nanometer) for unit, e.g. WVLEN=1310.00 means it operates at 1310 nm in the DWM application. <WVLEN> is a float and is optional • <RINGID> identifies the BLSR RINGID with which the port is connected. The <RINGID> ranges from 0-9999; <RINGID> is an integer and is optional • <BLSRTYPE> identifies the BLSR type with which the port is connected. Valid values for <BLSRTYPE> are shown in the “BLSR_TYPE” section on page 4-51 and <BLSRTYPE> is optional. • <MUX> BLSR Extension Byte. Valid values for <MUX> are shown in the “MUX_TYPE” section on page 4-75; <MUX> is optional. • <UNIC> indicates if the port connects to the UCP; valid values are shown in the “ON_OFF” section on page 4-76 and <UNIC> is optional • <CCID> indicates the UCP control channel ID; <CCID> is an integer and is optional • <NBRIX> indicates the UCP neighbor ID. <NBRIX> is an integer and is optional • <SOAK> OOS-AINS to IS transition soak time measured in 15 minute intervals. <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional Rules for <SOAKLEFT> are as follows: <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. • <SSMRCV> displays the quality of the individual port and is optional; valid values are shown in the “SYNC_CLOCK_REF_QUALITY_LEVEL” section on page 4-89 • <OSPF> indicates the OSPF discovery and is optional; valid values are shown in the “ON_OFF” section on page 4-76 |

| Section | RTRV-<OCN_TYPE> Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> <LDCC> indicates the Line DCC connection of the port and is optional; valid values are shown in the “EXT_RING” section on page 4-65 <ALSMODE> this parameter is only applicable for OC3-8, OC192, and OC48ELR cards. It indicates the mode of operation for Automatic Laser Shutdown (ALS) and is optional; valid values are shown in the “ALS_MODE” section on page 4-49 <ALSRCINT> this parameter is only applicable for OC3-8, OC192, and OC48ELR cards. It indicates the ALS recovery interval which ranges from 100–300 seconds; <ALSRCINT> is an integer and is optional <ALSRCPW> this parameter is only applicable for OC3-8, OC192, and OC48ELR cards. It indicates the ALS recovery pulse width which ranges from 2–100 seconds; <ALSRCPW> is a float and is optional <PST> primary state; valid values for <PST> are shown in the “PST” section on page 4-83 <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-6-1:,WORK,ACT:DCC=Y,AREA=10.92.63.1,TMGREF=N,SYNCMSG=Y, SENDDUS=N,PJMON=48,SFBER=1E-4,SDBER=1E-6,MODE=SONET, WVLEN=1310.00,RINGID=43,BLSRTYPE=WESTWORK,MUX=E2,UNIC=Y, CCID=8,NBRIX=2,SOAK=52,SOAKLEFT=12-25,SSMRCV=STU,OSPF=Y, LDCC=Y,ALSMODE=DISABLED,ALSRCINT=100,ALSRCPW=2.0:OOS, AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.139 RTRV-<PATH>: Retrieve (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the attributes associated with an STS or VT path.

Supported AIDs are: ALL, SLOT-N (N=1,2,...,ALL), and STS/VT-specific AIDs

The SFBER, SDBER, RVRTV, RVTM, SWPDIP, HOLDOFFTIMER, and UPSRPTHSTATE parameters only apply to path protection.

The path trace message is a 64 character string including the terminating CR (carriage return) and LF (line feed) that is transported in the J1 byte of the SONET STS Path overhead.

The EXPTRC indicates the contents of the expected incoming path trace are provisioned by the user in the ED-STS_PATH command. The TRC indicates the contents of the outgoing path trace message. The INCTRCA indicates the contents of the incoming path trace message.

The path trace mode has three modes: OFF, MANUAL, and AUTO. The mode defaults to OFF. The MANUAL mode performs the comparison of the received string with the user entered expected string. The AUTO mode performs the comparison of the present received string with an expected string set to a previously received string. If there is a mismatch, the TIM-P alarm is raised. When the path trace mode is in OFF mode, there is no path trace processing, and all the alarm and state conditions are reset.

When the expected string is queried under the OFF path trace mode, the expected string is a copy of the provisioned string or NULL. When an expected string is queried under the MANUAL path trace mode, the expected string is a copy of the user entered string. When an expected string is queried under the AUTO path trace mode, the expected string is a copy of the acquired received string or NULL if the string has not been acquired.

When the incoming string is queried under the OFF path trace mode, the incoming string is NULL. When an incoming string is queried under the MANUAL or AUTO path trace mode, the incoming string is a copy of the received string or NULL if the string has not been received.

J1 (EXPTRC) is implemented on the DS1/DS1N, DS3E/DS3NE, DS3XM, EC1, OC3, OC48AS and OC192.

TRC and INCTRC are supported on DS1(N), DS3(N)E, and DS3XM cards.

Notes:

1. An optional parameter BLSRPTHTYPE is introduced into this command to provide more options to retrieve J1/C2 of a particular BLSR path. This field is valid only if the queried AID port has BLSR. The BLSRPTHTYPE defaults to “non-pca” path type if the BLSR is switched, or defaults to all BLSR path types if there is no BLSR switching.
2. Sending this command while BLSRPTHTYPE=PCA, whether there is BLSR switch or not, the PCA path J1/C2 data will be returned (if there is PCA circuit on the AID). Sending this command with an STS AID without circuits and no BLSR switched on the STS, an error message will be returned.
3. An optional output parameter BLSRPTHSTATE is introduced into this command output. Each J1/C2 output data of this command will include the BLSR path state information.
4. After the BLSR switching, the J1/IPPM/C2 data can be retrieved over the protection path, to provision J1 trace string, trace mode, or threshold is not allowed on the protection path.
5. HOLDOFFTIMER is not specific to a path. Instead, it is applicable to the path protection selector.

| Section | RTRV-<PATH> Description |
|------------------|---|
| Category | Paths |
| Security | Retrieve |
| Related Messages | ED-<MOD_PATH> RTRV-<PATH> RTRV-STS |
| Input Format | <p>RTRV-<PATH>:[<TID>]:<AID>:<CTAG>::: [BLSRPTHTYPE=<BLSRPTHTYPE>][:];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “CrossConnectId1” section on page 4-23 and must not be null • <BLSRPTHTYPE> indicates the BLSR path type only if the port is on the BLSR. It defaults to “non-pca”. Valid values are shown in the “BLSR_PTH_TYPE” section on page 4-51. A null value defaults to “non-pca” |
| Input Example | RTRV-STS1:FERNDALE:STS-2-1-4:238:::BLSRPTHTYPE=NON-PCA; |

| Section | RTRV-<PATH> Description |
|---------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[LEVEL=<LEVEL>],[SFBER=<SFBER>],[SDBER=<SDBER>], [RVRTV=<RVRTV>],[RVTM=<RVTM>],[SWPDIP=<SWPDIP>], [HOLDOFFTIMER=<HOLDOFFTIMER>],[EXPTRC=<EXPTRC>], [TRC=<TRC>],[INCTR= <INCTR>],[TRCMODE=<TRCMODE>], [TACC=<TACC>],[TAPTYPE=<TAPTYPE>], [UPSRPTHSTATE=<UPSRPTHSTATE>],[C2=<C2>], [BLSRPTHSTATE=<BLSRPTHSTATE>]:[<PST>],[<SST>]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “CrossConnectId1” section on page 4-23 • <LEVEL> indicates the rate of the cross connected channel; valid values for <LEVEL> are shown in the “PATH” section on page 4-81, <LEVEL> is optional • <SFBER> identifies the STS path SFBER which only applies to path protection; <SFBER> defaults to 1E-4 and valid values are shown in the “SF_BER” section on page 4-86, <SFBER> is optional • <SDBER> identifies the STS path SDBER which only applies to path protection; <SDBER> defaults to 1E-6 and valid values are shown in the “SD_BER” section on page 4-85, <SDBER> is optional • <RVRTV> identifies a revertive mode which only applies to path protection and defaults to N (non-revertive mode) when a path protection STSp is created; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 and <RVRTV> is optional • <RVTM> identifies a revertive time which only applies to path protection and defaults to empty because <RVRTV> is N when a path protection path is created; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 and <RVTM> is optional |

| Section | RTRV-<PATH> Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <SWPDIP> switch on PDI-P. Applicable only to STS-level paths; valid values are shown in the “ON_OFF” section on page 4-76; <SWDIP> is optional • <HOLDOFFTIMER> is an integer and is optional • <EXPTRC> indicates the expected path trace message (J1) contents. The EXPTRC is any 64 character string, including the terminating CR (carriage return) and LF (line feed); <EXPTRC> defaults to null when a path protection STSp is created. <EXPTRC> is a string and is optional • <TRC> identifies the path trace message to be transmitted. The TRC is any combination of 64 characters, including the terminating CR (carriage return) and LF (line feed). The trace byte (J1) continuously transmits a 64 byte string, one byte at a time. A null value defaults to the NE transmitting null characters (Hex 00); <TRC> defaults to null when a path protection path is created. <TRC> is a string and is optional • <INCTRCC> identifies the incoming path trace message contents. The INCTRCC is any combination of 64 characters; <INCTRCC> defaults to null when path protection STSp is created. <INCTRCC> is a string and is optional • <TRCMODE> indicates the path trace mode, and defaults to the OFF mode. Applicable only to STS-level paths; valid values for <TRCMODE> are shown in the “TRCMODE” section on page 4-94 and <TRCMODE> is optional • <TACC> is the AID from the “Conditions” section on page 7-18 and is optional • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 • <UPSRPTHSTATE> indicates whether the given AID is the working or standby path of a path protection cross-connect; valid values are shown in the “STATUS” section on page 4-86 • <C2> indicates C2 Byte Hex Code. Applicable only to STS-level paths; valid values are shown in the “C2_BYT” section on page 4-52 • <BLSRPTHSTATE> indicates the BLSR path state only if the port is on the BLSR. Applicable only to the STS-level paths; valid values are shown in the “BLSR_PTH_STATE” section on page 4-51 and <BLSRPTHSTATE> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83. <PST> is optional • <SST> secondary state; valid values are shown in the “SST” section on page 4-86. <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-2-1-4::LEVEL=STS1,SFBER=1E-3,SDBER=1E-5,RVRTV=Y,RVTM=1.0, SWPDIP=Y,HOLDOFFTIMER=2000,EXPTRC=“EXPTRCSTRING”, TRC=“TRCSTRING”,INCTRCC=“INCTRCCSTRING”,TRCMODE=AUTO, TACC=8,TAPTYPE=DUAL,UPSRPTHSTATE=ACT,C2=0X04, BLSRPTHSTATE=PROTPTHACT:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.140 RTRV-ALM-<MOD2ALM>:Retrieve Alarm (CLNT, DS1, DS3I, EC1, FC, FSTE, G1000, GIGE, OC12, OC192, OC3, OC48, OCH, OMS, OSC, OTS, POS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, UDCDCC, UDCF, VT1, VT2, WLEN)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves and sends the current status of alarm conditions. The alarm condition or severity to be retrieved can be specified by using the input parameters as a filter.

Notes:

1. VT1-n-n-n replaces PS_VT1-n-n-n for the VT1 alarm AID.
2. The [<AIDTYPE>] shows STS1 for STS alarms.

| Section | RTRV-ALM-<MOD2ALM> Description | |
|------------------|--------------------------------|---------------------|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> | RTRV-ALM-BITS |
| | REPT ALM BITS | RTRV-ALM-ENV |
| | REPT ALM COM | RTRV-ALM-EQPT |
| | REPT ALM ENV | RTRV-ALM-SYNCN |
| | REPT ALM EQPT | RTRV-ALM-UCP |
| | REPT ALM SYNCN | RTRV-ATTR-CONT |
| | REPT ALM UCP | RTRV-ATTR-ENV |
| | REPT EVT <MOD2ALM> | RTRV-COND-<MOD2ALM> |
| | REPT EVT BITS | RTRV-COND-ALL |
| | REPT EVT COM | RTRV-COND-BITS |
| | REPT EVT ENV | RTRV-COND-ENV |
| | REPT EVT EQPT | RTRV-COND-EQPT |
| | REPT EVT FXFR | RTRV-COND-SYNCN |
| | REPT EVT IOSCFG | RTRV-COND-UCP |
| | REPT EVT SYNCN | SET-ATTR-CONT |
| | REPT EVT UCP | SET-ATTR-ENV |
| RTRV-ALM-ALL | | |

| Section | RTRV-ALM-<MOD2ALM> Description |
|----------------|---|
| Input Format | <p>RTRV-ALM-<MOD2ALM>:[<TID>]:<AID>:<CTAG>::[<NTFCNCDE>], [<CONDTYPE>],[<SRVEFF>][,,];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “AidUnionId” section on page 4-15 and must not be null • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85. A null value is equivalent to ALL. |
| Input Example | RTRV-ALM-OC12:ELDRIDGE:FAC-5-1:225::MN,SD,SA; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>, [<OCRDAT>],[<OCRTM>],:[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “ALL” section on page 4-9 • <AIDTYPE> is the type of access identifier; valid values for <AIDTYPE> are shown in the “MOD2ALM” section on page 4-70, <AIDTYPE> is optional • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-5-1,OC12:MJ,SD,SA,09-05,12-30-20,,:\\" “BER AT SIGNAL DEGRADE LEVEL\\,” ; </p> |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.141 RTRV-ALM-ALL: Retrieve Alarm All

This command retrieves and sends the current status of all active alarm conditions. The alarm condition or severity to be retrieved is specified using the input parameters as a filter.

According to GR-833, the RTRV-ALM-ALL command only reports EQPT, COM, and rr (T1, T3, OCN, EC1, STSN, VT1, DS1, G1000, ML-series, TXP and MXP) alarms.

To retrieve all the NE alarms, issue all of the following commands:

RTRV-ALM-ALL
RTRV-ALM-BITS
RTRV-ALM-ENV
RTRV-ALM-SYNCN

| Section | RTRV-ALM-ALL Description | |
|------------------|---|--|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP | RTRV-ALM-<MOD2ALM> RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV SET-ATTR-SECUDFLT |
| Input Format | RTRV-ALM-ALL:[<TID>]::<CTAG>::[<NTFCNCDE>],[<CONDITION>], [<SRVEFF>][,,]; where: <ul style="list-style-type: none"> • <NTFCNCDE> is a notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <CONDITION> is the type of alarm condition; valid values for <CONDITION> are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85. A null value is equivalent to ALL. | |
| Input Example | RTRV-ALM-ALL:COTATI::229::MN,PWRRESTART,NSA; | |

| Section | RTRV-ALM-ALL Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “[<AID>],[<AIDTYPE>]:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,: [<DESC>],[<AIDDET>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the identifier that has an alarm condition and is from the “ALL” section on page 4-9, <AID> is optional • <AIDTYPE> is the type of access identifier; valid values for <AIDTYPE> are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <NTFCNCDE> is the notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is the single type of alarm condition being reported on this particular line; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <DESC> is the condition description; <DESC> is a string and is optional • <AIDDET> is the supplementary equipment identification; <AIDDET> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-2,EQPT:MN,PWRRESTART,NSA,,,:“POWER FAIL RESTART”, DS1-14” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.142 RTRV-ALM-BITS: Retrieve Alarm Building Integrated Timing Supply

This command retrieves and sends the current status of alarm conditions associated with the BITS facility. The alarm condition or severity retrieved is specified using the input parameters as a filter.

| Section | RTRV-ALM-BITS Description |
|----------|---------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | RTRV-ALM-BITS Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCN ED-SYNCRN OPR-SYNCNSW REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | RTRV-ALM-BITS:[<TID>]:<AID>:<CTAG>::[<NTFCNCDE>], [<CONDTYPE>],[<SRVEFF>][,,,]; where: <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition and is from the AID “BITS” section on page 4-19; <AID> must not be null • <NTFCNCDE> is a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <CONDTYPE> is an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85. A null value is equivalent to ALL. |
| Input Example | RTRV-ALM-BITS:ELVERANO:BITS-1:228::CR,LOS,SA; |

| Section | RTRV-ALM-BITS Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,: [<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the identifier that has an alarm condition and is from the “BITS” section on page 4-19 • <AIDTYPE> is the type of access identifier; valid values for <AIDTYPE> are shown in the “MOD2B” section on page 4-71 and <AIDTYPE> is optional • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “BITS-1,BITS:CR,LOS,SA,,,:“LOSS OF SIGNAL\”,” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.143 RTRV-ALM-ENV: Retrieve Alarm Environment

This command retrieves the environmental alarms.

| Section | RTRV-ALM-ENV Description |
|----------|---------------------------------|
| Category | Environment Alarms and Controls |
| Security | Retrieve |

| Section | RTRV-ALM-ENV Description |
|------------------|--|
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | <p>RTRV-ALM-ENV:[<TID>]:<AID>:<CTAG>::[<NTFCNCDE>],[<ALMTYPE>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “ENV” section on page 4-26; <AID> must not be null <p>Note For RTRV-ALM-ENV, only ENV-IN-{1-4} is a valid AID for ONS 15454 and only ENV-IN-{1-6} is a valid AID for ONS 15327. ENV-OUT-{1,6} is not a valid AID for RTRV-ALM-ENV.</p> <ul style="list-style-type: none"> • <NTFCNCDE> is a notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <ALMTYPE> is the alarm type for the environmental alarm; valid values for <ALMTYPE> are shown in the “ENV_ALM” section on page 4-58. A null value is equivalent to ALL. |
| Input Example | RTRV-ALM-ENV:CISCO:ENV-IN-1:123::MJ,OPENDR; |

| Section | RTRV-ALM-ENV Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<NTFCNCDE>,<ALMTYPE>,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “ENV” section on page 4-26 • <NTFCNCDE> is the notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <ALMTYPE> is the alarm type for the environmental alarm; valid values for <ALMTYPE> are shown in the “ENV_ALM” section on page 4-58 • <DESC> is the alarm message; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “ENV-IN-1:MJ,OPENDR,,,\“OPEN DOOR\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.144 RTRV-ALM-EQPT: Retrieve Alarm Equipment

This command retrieves and sends the current status of alarm conditions associated with the equipment units. The alarm condition or severity to be retrieved is specified using the input parameters as a filter.

| Section | RTRV-ALM-EQPT Description |
|----------|---------------------------|
| Category | Equipment |
| Security | Retrieve |

| Section | RTRV-ALM-EQPT Description |
|------------------|---|
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | RTRV-ALM-EQPT:<TID>:<AID>:<CTAG>::[<NTFCNCDE>],[<CONDTYPE>], [<SRVEFF>][,,]; where: <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition and is from the “EQPT” section on page 4-27; <AID> must not be null • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85. A null value is equivalent to ALL. |
| Input Example | RTRV-ALM-EQPT:TWOROCK:SLOT-7:227::MJ,HITEMP,NSA; |

| Section | RTRV-ALM-EQPT Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “[<AID>],[<AIDTYPE>]:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,„,: [<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition and is from the “EQPT” section on page 4-27; <AID> is optional • valid values for <AIDTYPE> are shown in the “MOD2B” section on page 4-71; <AIDTYPE> is optional • <NTFCNCDE> is a 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is an alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <DESC> is a condition description; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-7,EQPT:MJ,HITEMP,NSA,,,:“HI TEMPERATURE\”,” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.145 RTRV-ALM-SYNCN: Retrieve Alarm Synchronization

This command retrieves and sends the current status of alarm conditions associated with a synchronization facility. The alarm condition or severity to be retrieved can be specified by using the input parameters as a filter.

| Section | RTRV-ALM-SYNCN Description |
|----------|----------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | RTRV-ALM-SYNCN Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCN ED-SYNCN OPR-SYNCNSW REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | RTRV-ALM-SYNCN:[<TID>]:<AID>:<CTAG>::[<NTFCNCDE>], [<CONDTYPE>],[<SRVEFF>][,,,]; where: <ul style="list-style-type: none"> • <AID> identifies the access identifier from the “SYNC_REF” section on page 4-34, <AID> must not be null • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85. A null value is equivalent to ALL. |
| Input Example | RTRV-ALM-SYNCN:FULTON:SYNC-NE:226::CR,FAILTOSW,SA; |

| Section | RTRV-ALM-SYNCN Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<NTFCNCDE>,<CONDTYPE>, <SRVEFF>,,,:[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the identifier that has an alarm condition and is from the “SYN section on page 4-33 • <AIDTYPE> is the type of access identifier: valid values for <AIDTYPE> are shown in the “MOD2B” section on page 4-71 and <AIDTYPE> is optional • <NTFCNCDE> is the 2-letter notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is the alarm condition; valid values for <CONDTYPE> are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values for <SRVEFF> are shown in the “SERV_EFF” section on page 4-85 • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “SYNC-NE,SYNCN:CR,FAILTOSW,SA,,,: “FAILURE TO SWITCH TO PROTECTION”,” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.146 RTRV-ALM-UCP: Retrieve Alarm Unified Control Plane

(Cisco ONS 15454 only)

This retrieves and sends the current status of all active alarm conditions against a UCP object. The alarm condition or severity to be retrieved can be specified by using the input parameters as a filter.

| Section | RTRV-ALM-UCP Description |
|----------|--------------------------|
| Category | UCP |
| Security | Retrieve |

| Section | RTRV-ALM-UCP Description |
|------------------|--|
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU |
| Input Format | RTRV-ALM-UCP:<TID>:<AID>:<CTAG>:::<NTFCNCDE>], [<CONDTYPE>],[<SRVEFF>][,,,]; where: <ul style="list-style-type: none"> • <AID> identifies a UCP object with alarm condition; <AID> is from the “UCP section on page 4-35” and must not be null • <NTFCNCDE> is a notification code; valid values <NTFCNCDE> are shown in the “NOTIF_CODE section on page 4-75”. A null value is equivalent to ALL • <CONDTYPE> is the type of condition to be retrieved; valid values are shown in the “Conditions section on page 7-18”. A null value is equivalent to ALL • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF section on page 4-85”. A null value is equivalent to ALL |
| Input Example | RTRV-ALM-UCP:CISCO:CC-1:123::MJ,LMP-HELLODOWN,SA; |

| Section | RTRV-ALM-UCP Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<NTFCNCDE>,<CONDTYPE>,<SRVEFF>,,,:[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> identifies a UCP object with alarm condition; <AID> is from the “UCP” section on page 4-35 • <NTFCNCDE> is a notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75 • <CONDTYPE> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85 • <DESC> is a condition description; <DESC> is a string and is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “CC-1:MJ,LMP-HELLODOWN,SA,,,:\ “LMP HELLO FSM ON CONTROL CHANNEL DOWN\,” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.147 RTRV-ALMTH-<MOD2>: Retrieve Alarm Threshold (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STM1E, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

(Cisco ONS 15454 only)

This command retrieves the alarm threshold values. The only applicable MOD2 values are CLNT, OCH, OMS, and OTS.

| Section | RTRV-ALMTH-<MOD2> Description |
|------------------|--|
| Category | DWDM |
| Security | Retrieve |
| Related Messages | SET-ALMTH-<MOD2> |
| Input Format | <p>RTRV-ALMTH-<MOD2>:[<TID>]:<AID>:<CTAG>::<ALMTHR>[.,::]; where:</p> <ul style="list-style-type: none"> • <AID> is from the “ALL” section on page 4-9 and must not be null • Valid values for <ALMTHR> are shown in the “ALM_THR” section on page 4-48 and <ALMTHR> must not be null |
| Input Example | RTRV-ALMTH-:<MOD2>::CHAN-2-2:1::OPT-HIGH; |

| Section | RTRV-ALMTH-<MOD2> Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,<MOD>:<CONDTYPE>,<THLEVEL>” ; where:</p> <ul style="list-style-type: none"> • <AID> is from the “ALL” section on page 4-9 • <MOD> is the AID type; valid values are shown in the “MOD2” section on page 4-69 • <CONDTYPE> alarm threshold condition type; valid values are shown in the “ALM_THR” section on page 4-48 • <THLEVEL> is the threshold level and is a float |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-2-2,OCH:OPT-HIGH,20” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.148 RTRV-ALMTH-EQPT: Retrieve Alarm Threshold Equipment

This command retrieves the alarm thresholds for the power level monitoring on an NE.

| Section | RTRV-ALMTH-EQPT Description | |
|------------------|--|--|
| Category | Equipment | |
| Security | Retrieve | |
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT | REPT ALM EQPT REPT EVT EQPT RTRV-ALM-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | <p>RTRV-ALMTH-EQPT:[<TID>]::<CTAG>:<ALMTHR>[,,,:]; where:</p> <ul style="list-style-type: none"> • Valid values for <ALMTHR> are shown in the “ALM_THR” section on page 4-48 and <ALMTHR> must not be null | |
| Input Example | RTRV-ALMTH-EQPT:::1::BATV-HIGH; | |

| Section | RTRV-ALMTH-EQPT Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “,<MOD2B>:<ALMTHR>,,<DNFIELD>” ; where:</p> <ul style="list-style-type: none"> • Valid values for <MOD2B> are shown in the “MOD2B” section on page 4-71 • Valid values for <ALMTHR> are shown in the “ALM_THR” section on page 4-48 • <DNFIELD> is a float |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “,EQPT:BATV-HIGH,,,-52.0,” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.149 RTRV-ATTR-CONT: Retrieve Attribute Control

This command retrieves and sends the attributes associated with an external control. These attributes are used when an external control is operated or released. To set these attributes, use the SET-ATTR-CONT command.

| Section | RTRV-ATTR-CONT Description | |
|------------------|---|---|
| Category | Environment | |
| Security | Retrieve | |
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP | RLS-EXT-CONT RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP RTRV-EXT-CONT SET-ATTR-CONT SET-ATTR-ENV SET-ATTR-SECUDFLT |

| Section | RTRV-ATTR-CONT Description |
|----------------|--|
| Input Format | RTRV-ATTR-CONT:[<TID>]:<AID>:<CTAG>[::<CONTTYPE>]; where: <ul style="list-style-type: none">• <AID> identifies the external control for which attributes are being set; <AID> is from the “ENV” section on page 4-26 and must not be null• <CONTTYPE> is the type of external control; valid values for <CONTTYPE> are shown in the “CONTTYPE” section on page 4-55. A null value is equivalent to ALL |
| Input Example | RTRV-ATTR-CONT:CISCO:ENV-OUT-2:123::AIRCOND; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>:[<CONTTYPE>]” ; where: <ul style="list-style-type: none">• <AID> identifies the external control for which attributes are being set and is from the “ENV” section on page 4-26• <CONTTYPE> is the type of external control; valid values are shown in the “CONTTYPE” section on page 4-55 and <CONTTYPE> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “ENV-OUT-2:AIRCOND” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.150 RTRV-ATTR-ENV: Retrieve Attribute Environment

This command retrieves the attributes associated with an environmental alarm.

| Section | RTRV-ATTR-ENV Description |
|----------|---------------------------|
| Category | Environment |
| Security | Retrieve |

| Section | RTRV-ATTR-ENV Description |
|------------------|---|
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | <p>RTRV-ATTR-ENV:[<TID>]:<AID>:<CTAG>:[<NTFCNCDE>],[<ALMTYPE>]; where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “ENV” section on page 4-26 and must not be null • <NTFCNCDE> is the notification code for the environmental alarm; valid values are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL • <ALMTYPE> is the alarm type for the environmental alarm; valid values are shown in the “ENV_ALM” section on page 4-58. A null value is equivalent to ALL |
| Input Example | RTRV-ATTR-ENV:CISCO:ENV-IN-1:123::MJ,OPENDR; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[<NTFCNCDE>],[<ALMTYPE>],[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “ENV” section on page 4-26 • <NTFCNCDE> is the notification code for the environmental alarm; valid values are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <ALMTYPE> is the alarm type for the environmental alarm; valid values are shown in the “ENV_ALM” section on page 4-58, <ALMTYPE> is optional • <DESC> is the alarm description; <DESC> is a string and is optional |

| Section | RTRV-ATTR-ENV Description |
|----------------|--|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “ENV-IN-1:MJ,OPENDR,\“OPEN DOOR\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.151 RTRV-BITS: Retrieve Building Integrated Timing Supply

This command retrieves the BITS configuration command.

| Section | RTRV-BITS Description | | | | | | | | | | | | | | | | |
|------------------|---|---------|-------------|--------------|---------------|-----------|-----------------|-------------|----------------|---------------|------------------|------------------|----------------|---------------|-------------|------------------|--|
| Category | Synchronization | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ED-BITS</td> <td>RLS-SYNCNSW</td> </tr> <tr> <td>ED-NE-SYNCRN</td> <td>RTRV-ALM-BITS</td> </tr> <tr> <td>ED-SYNCRN</td> <td>RTRV-ALM-SYNCRN</td> </tr> <tr> <td>OPR-SYNCNSW</td> <td>RTRV-COND-BITS</td> </tr> <tr> <td>REPT ALM BITS</td> <td>RTRV-COND-SYNCRN</td> </tr> <tr> <td>REPT ALM SYNCNRN</td> <td>RTRV-NE-SYNCRN</td> </tr> <tr> <td>REPT EVT BITS</td> <td>RTRV-SYNCRN</td> </tr> <tr> <td>REPT EVT SYNCNRN</td> <td></td> </tr> </table> | ED-BITS | RLS-SYNCNSW | ED-NE-SYNCRN | RTRV-ALM-BITS | ED-SYNCRN | RTRV-ALM-SYNCRN | OPR-SYNCNSW | RTRV-COND-BITS | REPT ALM BITS | RTRV-COND-SYNCRN | REPT ALM SYNCNRN | RTRV-NE-SYNCRN | REPT EVT BITS | RTRV-SYNCRN | REPT EVT SYNCNRN | |
| ED-BITS | RLS-SYNCNSW | | | | | | | | | | | | | | | | |
| ED-NE-SYNCRN | RTRV-ALM-BITS | | | | | | | | | | | | | | | | |
| ED-SYNCRN | RTRV-ALM-SYNCRN | | | | | | | | | | | | | | | | |
| OPR-SYNCNSW | RTRV-COND-BITS | | | | | | | | | | | | | | | | |
| REPT ALM BITS | RTRV-COND-SYNCRN | | | | | | | | | | | | | | | | |
| REPT ALM SYNCNRN | RTRV-NE-SYNCRN | | | | | | | | | | | | | | | | |
| REPT EVT BITS | RTRV-SYNCRN | | | | | | | | | | | | | | | | |
| REPT EVT SYNCNRN | | | | | | | | | | | | | | | | | |
| Input Format | <p>RTRV-BITS:[<TID>]:<AID>:<CTAG>[::::];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is a bit access identifier from the “BITS” section on page 4-19 and must not be null | | | | | | | | | | | | | | | | |
| Input Example | RTRV-BITS:SONOMA:BITS-1:782; | | | | | | | | | | | | | | | | |

| Section | RTRV-BITS Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[LINECDE=<LINECDE>],[FMT=<FMT>],[LBO=<LBO>], [SYNCMSG=<SYNCMSG>],[AISTRSHLD=<AISTRSHLD>], [SABIT=<SABIT>],[IMPEDANCE=<IMPEDANCE>]:[<PST>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “BITS” section on page 4-19 • <LINECDE> is a line code; valid values for <LINECDE> are shown in the “LINE_CODE” section on page 4-68, <LINECDE> is optional • <FMT> is a frame format; valid values are shown in the “FRAME_FORMAT” section on page 4-65, <FMT> is optional • <LBO> indicates BITS line build-out; valid values are shown in the “BITS_LineBuildOut” section on page 4-50, <LBO> is optional • <SYNCMSG> indicates a sync messaging; <SYNCMSG> defaults to (Y) and valid values are shown in the “ON_OFF” section on page 4-76, <SYNCMSG> is optional • <AISTRSHLD> is the AIS threshold. Valid values are shown in the “SYNC_CLOCK_REF_QUALITY_LEVEL” section on page 4-89; <AISTRSHLD> is optional • <SABIT> when the frame format selection is E1, <SABIT> indicates the BIT used to receive and transmit the SSM; valid values are shown in the “SABITS” section on page 4-84. <SABIT> is optional • <IMPEDANCE> when the frame format selection is one of the E1 values, <IMPEDANCE> indicates the terminal impedance of the BITS-IN port; valid values are shown in the “IMPEDANCE” section on page 4-66. <IMPEDANCE> is optional • <PST> is the state; valid values are shown in the “PST” section on page 4-83, <PST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BITS-1::LINECDE=AMI,FMT=ESF,LBO=0-133,SYNCMSG=Y, AISTRSHLD=PRS,SABIT=BYTE-4,IMPEDANCE=120-OHM:IS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.152 RTRV-CLNT: Retrieve Client

(Cisco ONS 15454 only)

This command retrieves client facility attributes.

See the “Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards” section on page 1-8 and the “Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards” section on page 1-13 for specific card provisioning rules.



Note States of primary=OOS, secondary=AINS do not apply to Ethernet mode.

| Section | RTRV-CLNT Description | |
|------------------|--|--------------------|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-CLNT | OPR-PROTNSTW-OCH |
| | DLT-LNK-<MOD2O> | RLS-LASER-OTS |
| | ED-CLNT | RLS-PROTNSTW-CLNT |
| | ED-DWDM | RLS-PROTNSTW-OCH |
| | ED-FFP-CLNT | RTRV-DWDM |
| | ED-FFP-OCH | RTRV-FFP-CLNT |
| | ED-LNK-<MOD2O> | RTRV-FFP-OCH |
| | ED-OCH | RTRV-LNK-<MOD2O> |
| | ED-OMS | RTRV-OCH |
| | ED-OTS | RTRV-OMS |
| | ED-TRC-CLNT | RTRV-OTS |
| | ED-TRC-OCH | RTRV-PROTNSTW-CLNT |
| | ENT-FFP-CLNT | RTRV-PROTNSTW-OCH |
| | ENT-LNK-<MOD2O> | RTRV-TRC-CLNT |
| | OPR-LASER-OTS | RTRV-TRC-OCH |
| | OPR-PROTNSTW-CLNT | |
| Input Format | RTRV-CLNT:[<TID>]:<AID>:<CTAG>; where: | |
| | <ul style="list-style-type: none"> • <AID> is the AID from the “FACILITY” section on page 4-28 and must not be null | |
| Input Example | RTRV-CLNT:CISCO:FAC-1-1:100; | |

| Section | RTRV-CLNT Description |
|---------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[<ROLE>],<STATUS>:[NAME=<PORTNAME>,<COMM>=<COMM>],[SFBER=<SFBER>,<SDBER>=<SDBER>],[ALSMODE=<ALSMODE>],[ALSRCINT=<ALSRCINT>],[ALSRCPW=<ALSRCPW>],[SYNCMSG=<SYNCMSG>],[SENDDUS=<SENDDUS>],[LSRSTAT=<LSRSTAT>],[CLEI=<CLEI>],[PN=<PARTNUM>],[SN=<SERIALNUM>],[VENDORREV=<VENDORREV>],[PLGTYPE=<PLGTYPE>],[MACADDR=<MACADDR>],[SOAK=<SOAK>],[SOAKLEFT=<SOAKLEFT>],[OSPF=<OSPF>]:<PST>,[<SST>]”; ;</p> <ul style="list-style-type: none"> • <AID> is the facility AID from the “FACILITY” section on page 4-28 • <ROLE> identifies an OCn port role (i.e. WORK or PROT); valid values for are shown in the “SIDE” section on page 4-86 • <STATUS> identifies an OCn port status (i.e. Active or Standby); valid values are shown in the “STATUS” section on page 4-86 • <PORTNAME> identifies the port name; <PORTNAME> is a string and is optional • <COMM> indicates if the GCC or DCC is enabled or disabled. The GCC can be enabled only if the digital wrapper has been enabled for the card. The default is NONE. Valid values are shown in the “COMM_TYPE” section on page 4-54. Rules for an MXP_2.5G_10G/TXP_MR_10G client port are; only the DCC can be provisioned, if the termination mode is not transparent and the payload is SONET. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the DCC can be enabled only if the G.709 is not enabled and if the payload is SONET and the termination mode is not transparent. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the GCC can be enabled if there is no DCC and the G.709 flag is enabled. |

| Section | RTRV-CLNT Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> • <SFBER> signal fail bit error ration that defaults to 1E-4; valid values are shown in the “SF_BER” section on page 4-86 and <SFBER> is optional • <SDBER> signal degrade bit error ratio that defaults to 1E-7; valid values are shown in the “SD_BER” section on page 4-85 and <SDBER> is optional • <ALSMODE> automatic laser shutdown mode that defaults to DISABLED; valid values are shown in the “ALS_MODE” section on page 4-49 and <ALSMODE> is optional • <ALSRCINT> ALS interval; <ALSRCINT> is an integer and is optional • <ALSRCPW> ALS pulse width; <ALSRCPW> is a float and is optional • <SYNCMSG> indicates that the facility be enabled to provide the synchronization clock. This does not apply to a TXP_MR_10G card. This applies for a MXP_2.5G_10G card only if the payload is SONET and the card termination mode is as follows: TRANSPARENT—all client ports are available for all timing selections. All trunk ports are not available. LINE—all ports are available for all timing selections. Valid values are shown in the “ON_OFF” section on page 4-76 and <SYNCMSG> is optional • <SENDDUS> indicates that the facility send out a do not use for sync message. This does not apply to a TXP_MR_10G card. This applies for a MXP_2.5G_10G card only if the payload is SONET and the card termination mode is as follows: TRANSPARENT—All client ports are available for all timing selections. All trunk ports are not available. LINE—All ports are available for all timing selections. Valid values are shown in the “ON_OFF” section on page 4-76 and <SENDDUS> is optional • <LSRSTAT> displays the laser status; valid values are shown in the “UP_DOWN” section on page 4-97 and <LSRSTAT> is optional • <CLEI> is the CLEI code for the SFP for the MXP_2.5G_10G card; <CLEI> is a string and is optional • <PARTNUM> is the part number for the SFP for the MXP_2.5G_10G card; <PARTNUM> is a string and is optional • <SERIALNUM> is the serial number of the SFP for the MXP_2.5G_10G card; <SERIALNUM> is a string and is optional • <VENDORREV> is the vendor SFP revision number; <VENDORREV> is a string and is optional |

| Section | RTRV-CLNT Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <PLGTYPE> indicates the pluggable optics type; <PLGTYPE> is a string and is optional • <MACADDR> identifies the MAC address for the 10GE payload; <MACADDR> is a string and is optional • <SOAK> OOS-AINS to IS transition soak time as measured in 15-minute intervals. A value of 4 translates to a soak time of 1 hour. The allowable range is 0 to 480 intervals. <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional Rules for <SOAKLEFT> are as follows: <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. • <OSPF> indicates the OSPF discovery only if the port COMM is DCC or GCC; valid values are shown in the “ON_OFF” section on page 4-76 and <OSPF> is optional • <PST> is the primary state; valid values are shown in the “PST” section on page 4-83 • <SST> is the secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1:,ROLE,ACT:NAME=“NYPORT”,COMM=DCC,SFBER=1E-4, SDBER=1E-6,ALSMODE=Y,ALSRCINT=30,ALSRCPW=35.1, SYNCMSG=Y,SENDDUS=Y,LSRSTAT=UP,CLEI=ABC,PN=123,SN=123, VENDORREV=111,PLGTYPE=IC48-LR,MACADDR=00-11-22-33-44-55, SOAK=52,SOAKLEFT=12-25,OSPF=Y:IS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.153 RTRV-CMD-SECU: Retrieve Command Security

This command retrieves the current command security level of the command specified in the AID field.

| Section | RTRV-CMD-SECU Description |
|----------|---------------------------|
| Category | Security |
| Security | Administrator |

| Section | RTRV-CMD-SECU Description |
|------------------|--|
| Related Messages | ACT-USER ENT-USER-SECU ALW-MSG-SECU INH-MSG-SECU ALW-USER-SECU INH-USER-SECU CANC REPT ALM SECU CANC-USER REPT EVT SECU CANC-USER-SECU REPT EVT SESSION DLT-USER-SECU RTRV-DFLT-SECU ED-CMD-SECU RTRV-USER-SECU ED-PID SET-ATTR-SECUDFLT ED-USER-SECU |
| Input Format | RTRV-CMD-SECU:[<TID>]:<AID>:<CTAG> where: <ul style="list-style-type: none"> <AID> is the access identifier string. It is the command verb along with the verb modifier(s) as it currently exists. It may be a single command or a block of commands where the block may include all commands. Only INIT-REG is supported in this release (R4.6). <AID> is a string and must not be null |
| Input Example | RTRV-CMD-SECU::INIT-REG:1; |
| Output Format | SID DATE TIME M CTAG COMPLD "<AID>:<CAP>" ; where: <ul style="list-style-type: none"> <AID> is the access identifier string. It is the command verb along with the verb modifier(s) as it currently exists. Only INIT-REG is supported in this release (R4.6). <AID> is a string <CAP> is the command access privilege; valid values are shown in the "PRIVILEGE" section on page 4-82 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD "INIT-REG:MAINT" ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.154 RTRV-COND-<MOD2ALM>: Retrieve Condition (CLNT, DS1, EC1, FC, FSTE, G1000, GIGE, OC12, OC192, OC3, OC48, OCH, OMS, OSC, OTS, POS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, UDCDCC, UDCF, VT1, VT2, WLEN)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the current standing condition and state associated with an entity.

| Section | RTRV-COND-<MOD2ALM> Description | |
|------------------|---|---|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM RING REPT ALM SYNCN REPT ALM UCP REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> | RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-RING RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-RING RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV SET-ATTR-SECUDFLT |
| Input Format | RTRV-COND-<MOD2ALM>:[<TID>]:<AID>:<CTAG>::[<TYPEREQ>][,,,]; where: <ul style="list-style-type: none">• <AID> is the identifier that has an alarm condition; <AID> is from the “ALL” section on page 4-9 and must not be null• <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL. | |
| Input Example | RTRV-COND-T3:TID:FAC-2-1:229::LOS; | |

| Section | RTRV-COND-<MOD2ALM> Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>], [<OCRDAT>],[<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition and is from the “ALL” section on page 4-9 • Valid values for <AIDTYPE> are shown in the “MOD2ALM” section on page 4-70, <AIDTYPE> is optional • <NTFCNCDE> is a notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <TYPEREP> is the condition itself; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85, <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is a condition description; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1,T3:CR,LOS,SA,01-01,16-00-20,,,，“LOS OF SIGNAL”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.155 RTRV-COND-ALL: Retrieve Condition All

This command retrieves the current standing condition for all entities.

According to GR-833, the RTRV-COND-ALL command only reports EQPT, COM, and rr (T1, T3, OCN, EC1, STSN, VT1, DS1, ML-series, TXP and MXP) alarms.

To retrieve all the NE conditions, issue all of the following commands:

RTRV-COND-ALL
 RTRV-COND-ENV
 RTRV-COND-BITS
 RTRV-COND-SYNCN

RTRV-COND-ALL does not return all conditions that are returned by other, more specific RTRV-COND commands. Instead it returns a subset of those conditions. This is a requirement from section 6.2.1.8.4 of GR-253-CORE. The specific requirements are R6-288, R6-289 and R6-290. Section 6.2.1.8.4 states a retrieval that returns ALL conditions from a node (RTRV-COND-ALL) must omit any conditions that are “same root cause” as other raised conditions. The section also states any retrieval of a subset of the conditions from a node, regardless of how the subsetting occurs, should not omit these “same root cause” conditions. RTRV-COND-STS1, for example, must include “same root cause” conditions in the set it returns, while RTRV-COND-ALL must not.

| Section | RTRV-COND-ALL Description | |
|------------------|---|---|
| Category | Fault | |
| Security | Retrieve | |
| Related Messages | REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM RING REPT ALM SYNCN REPT ALM UCP REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> | RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-RING RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-COND-<MOD2ALM> RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-RING RTRV-COND-SYNCN RTRV-COND-UCP SET-ATTR-CONT SET-ATTR-ENV SET-ATTR-SECUDFLT |
| Input Format | RTRV-COND-ALL:[<TID>]::<CTAG>:[<TYPEREQ>][,,]; where: <ul style="list-style-type: none">• <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL | |
| Input Example | RTRV-COND-ALL:TID::229::LOS; | |

| Section | RTRV-COND-ALL Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>], [<OCRDAT>],[<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition; <AID> is from the “ALL” section on page 4-9 • <AIDTYPE> is the type of access identifier; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <NTFCNCDE> is the notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <TYPEREP> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85, <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1,OC3:CR,LOS,SA,01-01,16-02-15,,,，“LOS OF SIGNAL\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.156 RTRV-COND-BITS: Retrieve Condition Building Integrated Timing Supply

This command retrieves the standing conditions on BITS.

| Section | RTRV-COND-BITS Description |
|----------|----------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | RTRV-COND-BITS Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCN ED-SYNCN OPR-SYNCNSW REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | RTRV-COND-BITS:[<TID>]:<AID>:<CTAG>::[<TYPEREQ>][,,]; where: <ul style="list-style-type: none"> • <AID> is the access identifier from the “BITS” section on page 4-19 and must not be null • <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL |
| Input Example | RTRV-COND-BITS:TID:BITS-1:229::LOS; |

| Section | RTRV-COND-BITS Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>], [<OCRDAT>],[<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition and is from the “BITS” section on page 4-19 • <AIDTYPE> is the type of AID. It is always reported as BITS; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <NTFCNCDE> is the notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <TYPEREP> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85, <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BITS-1,BITS:CR,LOS,SA,01-01,16-02-15,,，“LOS OF SIGNAL\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.157 RTRV-COND-ENV: Retrieve Environmental Condition

This command retrieves the environmental conditions.

| Section | RTRV-COND-ENV Description |
|----------|---------------------------------|
| Category | Environment Alarms and Controls |
| Security | Retrieve |

| Section | RTRV-COND-ENV Description |
|------------------|--|
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | <p>RTRV-COND-ENV:<TID>:<AID>:<CTAG>::[<NTFCNCDE>],[<ALMTYPE>] [,,,];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “ENV” section on page 4-26 and must not be null <p>Note For RTRV-COND-ENV, only ENV-IN-{1-4} is a valid AID for ONS 15454 and only ENV-IN-{1-6} is a valid AID for ONS 15327. ENV-OUT-{1,6} is not a valid AID for RTRV-COND-ENV.</p> <ul style="list-style-type: none"> • <NTFCNCDE> is a notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75. A null value is equivalent to ALL. • <ALMTYPE> is the condition type for the environmental conditions; valid values are shown in the “ENV_ALM” section on page 4-58. A null value is equivalent to ALL. |
| Input Example | RTRV-COND-ENV:CISCO:ENV-IN-1:123::MJ,OPENDR; |

| Section | RTRV-COND-ENV Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<NTFCNCDE>,<ALMTYPE>,[<OCRDAT>], [<OCRTM>],,,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier and is from the “ENV” section on page 4-26 • <NTFCNCDE> is the notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75 • <ALMTYPE> is an alarm type for the environmental alarm; valid values are shown in the “ENV_ALM” section on page 4-58 • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is the description of the condition; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “ENV-IN-1:MJ,OPENDR,01-01,16-02-15,,,，“OPEN DOOR\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.158 RTRV-COND-EQPT: Retrieve Condition Equipment

This command retrieves the equipment conditions.

| Section | RTRV-COND-EQPT Description |
|----------|----------------------------|
| Category | Equipment |
| Security | Retrieve |

| Section | RTRV-COND-EQPT Description | |
|------------------|--|--|
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT Ioscfg REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN | REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ALMTH-EQPT RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-SYNCN RTRV-COND-UCP RTRV-EQPT SET-ALMTH-EQPT SET-ATTR-CONT SET-ATTR-ENV SET-ATTR-SECUDFLT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | RTRV-COND-EQPT:[<TID>]:<AID>:<CTAG>::[<TYPEREQ>][,,,]; where: <ul style="list-style-type: none">• <AID> is an identifier that has an alarm condition; <AID> is from the “EQPT” section on page 4-27 and must not be null• <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL | |
| Input Example | RTRV-COND-EQPT:TID:SLot-1:229::LOS; | |

| Section | RTRV-COND-EQPT Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>], [<OCRDAT>],[<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the identifier that has an alarm condition and is from the “EQPT” section on page 4-27 • <AIDTYPE> is the type of the AID. It is always reported as EQPT for the equipment condition; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <NTFCNCDE> is the notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <TYPEREP> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85, <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-1,EQPT:CR,LOS,SA,01-01,16-02-15,,,，“LOS OF SIGNAL\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.159 RTRV-COND-SYNCH: Retrieve Condition Synchronization

This command retrieves the synchronization condition.

| Section | RTRV-COND-SYNCH Description |
|----------|-----------------------------|
| Category | Synchronization |
| Security | Retrieve |

| Section | RTRV-COND-SYNCN Description |
|------------------|---|
| Related Messages | ED-BITS ED-NE-SYNCN ED-SYNCN OPR-SYNCNSW REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP |
| Input Format | RTRV-COND-SYNCN:[<TID>]:<AID>:<CTAG>::[<TYPEREQ>][,,,]; where: <ul style="list-style-type: none"> • <AID> is an identifier that has an alarm condition; <AID> is from the “SYNC_REF” section on page 4-34 and must not be null • <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18. A null value is equivalent to ALL |
| Input Example | RTRV-COND-SYNCN:TID:SYNC-NE:229::LOS; |

| Section | RTRV-COND-SYNCN Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>], [<OCRDAT>],[<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the identifier that has an alarm condition and is from the “SYN” section on page 4-33 • <AIDTYPE> is the type of AID. It is always reported as SYNCN; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <NTFCNCDE> is the notification code; valid values for <NTFCNCDE> are shown in the “NOTIF_CODE” section on page 4-75, <NTFCNCDE> is optional • <TYPEREP> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85, <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is the condition description; <DESC> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SYNC-NE,SYNCN:MJ,FRNGSYNC,SA,01-01,16-02-15,,, \“FREE RUNNING SYNCHRONIZATION MODE\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.160 RTRV-COND-UCP: Retrieve Condition Unified Control Plane

(Cisco ONS 15454 only)

This command retrieves the current standing condition against a UCP object.

| Section | RTRV-COND-UCP Description |
|----------|---------------------------|
| Category | UCP |
| Security | Retrieve |

| Section | RTRV-COND-UCP Description |
|------------------|---|
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU |
| Input Format | RTRV-COND-UCP:<TID>:<AID>:<CTAG>::[<TYPEREQ>][,,,]; where: <ul style="list-style-type: none"> • <AID> identifies a UCP object with alarm condition; <AID> is from the “UCP” section on page 4-35 and must not be NULL • <TYPEREQ> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 and a NULL value is equivalent to ALL |
| Input Example | RTRV-COND-UCP:CISCO:CC-18:123::LMP-HELLODOWN; |

| Section | RTRV-COND-UCP Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[<NTFCNCDE>],<TYPEREP>,[<SRVEFF>],[<OCRDAT>], [<OCRTM>],,,[<DESC>]” ; where:</p> <ul style="list-style-type: none"> • <AID> identifies a UCP object with alarm condition; <AID> is from the “UCP” section on page 4-35 • <NTFCNCDE> is a notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75 and <NTFCNCDE> is optional • <TYPEREP> is the type of condition to be retrieved; valid values are shown in the “Conditions” section on page 7-18 • <SRVEFF> is the effect on service caused by the alarm condition; valid values are shown in the “SERV_EFF” section on page 4-85 and <SRVEFF> is optional • <OCRDAT> is a date and is optional • <OCRTM> is a time and is optional • <DESC> is a condition description, a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CC-18:MN,LMP-HELLODOWN,SA,01-01,16-02-15,,, \“LMP HELLO FSM ON CONTROL CHANNEL DOWN\”, ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.161 RTRV-CRS: Retrieve Cross Connect

This command retrieves all the cross-connections based on the required PATH types.

Notes:

1. A NULL AID defaults to ALL (NE).
2. A NULL PATH defaults to all the existing cross-connections.
3. The level in the output field is an optional field, and is used to indicate the bandwidth of the PATH cross-connection.

| Section | RTRV-CRS Description | |
|------------------|---------------------------------|-----------------------------------|
| Category | Cross Connections | |
| Security | Retrieve | |
| Related Messages | DLT-CRS-<PATH> ED-CRS-<PATH> | ENT-CRS-<PATH> RTRV-CRS-<PATH> |

| Section | RTRV-CRS Description |
|----------------|--|
| Input Format | <p>RTRV-CRS:[<TID>]:<AID>:<CTAG>:::[CRSTYPE=<CRSTYPE>] [:]; where:</p> <ul style="list-style-type: none"> <AID> indicates the access identifier. It can be a facility AID, an STS AID, a VT AID, or ALL AID. The ALL AID defaults to NE, which reports all the existing cross-connections of the NE. <AID> is from the “CrossConnectId1” section on page 4-23 and must not be NULL <CRSTYPE> specifies the cross-connection type. It is STS or VT or both. It defaults to all existing cross-connections. Valid values for <CRSTYPE> are shown in the “CRS_TYPE” section on page 4-55 and a NULL value is equivalent to ALL |
| Input Example | RTRV-CRS:CISCO:ALL:123:::CRSTYPE=STS; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<CROSSCONNECTID>,<CROSSCONNECTID1>:<CCT>,<MOD>::<PST>,<SST>” ; where:</p> <ul style="list-style-type: none"> <CROSSCONNECTID> is the AID from the “CrossConnectId” section on page 4-20 <CROSSCONNECTID1> is the AID from the “CrossConnectId1” section on page 4-23 <CCT> identifies the cross-connection type; valid values are shown in the “CCT” section on page 4-53 Valid values for <MOD> are shown in the “MOD2” section on page 4-69 <PST> primary state; valid values are shown in the “PST” section on page 4-83 <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-6-1-1,STS-12-1-4:2WAY,STS3C::OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.162 RTRV-CRS-<PATH>: Retrieve Cross Connect (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves any connections associated with the entered AID(s) or AID range. The information on both ends is returned along with the type of connection.

Notes:

1. The path protection STS cross-connection can be retrieved by using “&” in the AID fields of this command.

- a. To retrieve a 1-way selector or 2-way selector and bridge cross-connection with:
 - from points: F1, F2
 - to points: T1
 - the output will be:
 - 1-way
 - “F1&F2,T1:CCT,STS3C”
 - 2-way
 - If retrieved on point F1 or F2, the output format is the same as the 1-way output.
 - If retrieved on point T1, the output will be:
 - “T1,F1&F2:CCT,STS3C”
- b. To retrieve a 1-way bridge or 2-way selector and bridge cross-connection with:
 - from point: F1
 - to points: T1, T2
 - the output will be:
 - 1-way
 - “F1,T1&T2:CCT,STS3C”
 - 2-way
 - “T1&T2,F1:CCT,STS3C”
- c. To retrieve a 1-way subtending path protection connection or 2-way subtending path protection cross-connection with:
 - from point: F1, F2
 - to points: T1, T2
 - the output will be:
 - 1-way:
 - “F1&F2,T1&T2:CCT,STS3C”
 - 2-way:
 - If retrieved on point F1 or F2, the output format is the same as the 1-way output.
 - If retrieved on point T1 or T2, the output will be:
 - “T1&T2,F1&F2:CCT,STS3C”
- d. To retrieve a 2-way selector and bridge cross-connection with:
 - ENT-CRS-<PATH>::F1&F2,S1&S2:<CTAG>::2WAY;
 - from points: F1, F2 (F1 is the working side, F2 is the protect side)
 - selector: S1, S2 (s1 is the working side, S2 is the protect side)
 - the output will be:
 - If retrieved on point F1 or F2, the output will be:
 - “F1&F2,S1&S2:CCT,STS3C”
 - If retrieved on selector S1 or S2, the output will be:
 - “S1&S2,F1&F2:CCT,STS3C”

- e. To retrieve a path protection IDRI cross-connect with:
from points: F1, F2
to points: T1, T2
the output will be:
“F1&F2,T1&T2:CCT,STS3C”
 - f. To retrieve a path protection DRI cross-connect with:
from points: F1, F2
to points: T1
the output will be:
“F1&F2,T1:CCT,STS3C”
2. All A&B AIDs in the TL1 cross-connection command are in the format of WorkingAID&ProtectAID.
 3. <PATH> does not include STS for the RTRV-CRS command because STS is not a standard designator as defined by GR-833 A-2.
 4. Both the 1WAYPCA and 2WAYPCA is used to specify a PCA cross-connection.
 5. The facility AID is only valid on slots with a G1000-4 card.
 6. The virtual facility AID (VFAC) is only valid on slots holding the ML-series card.

| Section | RTRV-CRS-<PATH> Description | |
|------------------|--|----------------------------|
| Category | Cross Connections | |
| Security | Retrieve | |
| Related Messages | DLT-CRS-<PATH> ED-CRS-<PATH> | ENT-CRS-<PATH> RTRV-CRS |
| Input Format | RTRV-CRS-<PATH>:[<TID>]:<SRC>:<CTAG>[:::]; where: • <AID> is from the AID “ CrossConnectId1 ” section on page 4-23 | |
| Input Example | RTRV-CRS-STS3C:KENWOOD:STS-6-1-1:223; | |

| Section | RTRV-CRS-<PATH> Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<CROSSCONNECTID>,<CROSSCONNECTID1>:<CCT>,<MOD>:: <PST>,[<SST>]” ; where:</p> <ul style="list-style-type: none"> • <CROSSCONNECTID> is the AID from the “CrossConnectId” section on page 4-20 • <CROSSCONNECTID1> is the AID from the “CrossConnectId1” section on page 4-23 • <CCT> identifies the cross-connection type; valid values are shown in the “CCT” section on page 4-53 • Valid values for <MOD> are shown in the “MOD2” section on page 4-69 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-6-1-1,STS-12-1-4:2WAY,STS3C::OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.163 RTRV-DFLT-SECU: Retrieve Default Security

(Cisco ONS 15454 only)

This command retrieves the system-wide default values associated with several security parameters.

| Section | RTRV-DS1 Description | |
|------------------|----------------------|-------------------|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER | ENT-USER-SECU |
| | ALW-MSG-SECU | INH-MSG-SECU |
| | ALW-USER-SECU | INH-USER-SECU |
| | CANC | REPT ALM SECU |
| | CANC-USER | REPT EVT SECU |
| | CANC-USER-SECU | REPT EVT SESSION |
| | DLT-USER-SECU | RTRV-CMD-SECU |
| | ED-CMD-SECU | RTRV-USER-SECU |
| | ED-PID | SET-ATTR-SECUDFLT |
| | ED-USER-SECU | |

| Section | RTRV-DS1 Description |
|---------------|---|
| Input Format | <p>RTRV-DFLT-SECU:[<TID>]:<AID>:<CTAG>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier. It identifies the NE/NS single equipment unit. ALL is the only acceptable value. <AID> is a string and must not be null |
| Input Example | RTRV-DFLT-SECU:CISCO:ALL:123; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<NE>:PAGE=<PAGE>,PCND=<PCND>,MXINV=<MXINV>, DURAL=<DURAL>,TMOUT=<TMOUT>,UOUT=<UOUT>, PFRCD=<PFRCD>,POLD=<POLD>,PINT=<PINT>,LOGIN=<LOGIN>, PRIVLVL=<UAP>” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <NE> is the node name of the NE from which the system values are retrieved; <NE> is a string • <PAGE> the password aging interval. It is the number of days left before a user is prompted to change their password. 0 indicates the policy is turned off; <PAGE> is an integer • <PCND> the number of days a password can be used before a new one is mandatory (i.e., the warning period); <PCND> is an integer • <MXINV> the maximum number of consecutive and invalid session setup attempts allowed to occur before an intrusion attempt is suspected (i.e., “Failed Logins Before Lockout” from CTC). 0 indicates the policy is turned off; <MXINV> is an integer • <DURAL> time interval (in seconds) during which a userid is locked out when an intrusion attempt is suspected (i.e., the “Lockout Duration” from CTC). If the user is locked out until unlocked by a superuser, <DURAL> = INFINITE; <DURAL> is a string • <TMOUT> an interval (in minutes) after which a session is terminated if no messages are exchanged between the user and the NE; <TMOUT> is an integer • <UOUT> the number of days a userid is allowed to exist, if it has never been used, before it must be suspended. If a userid has not been used in UOUT days, the user will be forced to change his password (or logout) at the next login. No other command is allowed until the password has been changed; <UOUT> is an integer |

| Section | RTRV-DS1 Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <PFRCD> indicates a password change is required when a new user establishes a session to the NE for the first time (i.e., “Require password change on 1st login” from CTC); valid values are shown in the “YES_NO” section on page 4-99 • <POLD> the number of prior passwords that cannot be reused (i.e., “Prevent reusing last X passwords” from CTC); <POLD> is an integer • <PINT> the number of days that must pass before a password can be changed. If PINT = 0, the policy is not enabled; <PINT> is an integer • <LOGIN> the number of times a user can log into an NE. <LOGIN> is either SINGLE or MULTIPLE. If <LOGIN> is SINGLE, a user can only log into an NE one time with any given userid, regardless of method of login (i.e., CTC, TL1); valid values are shown in the “USER_LOGINS” section on page 4-97 • <UAP> user access privilege; valid values are shown in the “PRIVILEGE” section on page 4-82 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “TCC2:PAGE=40,PCND=5,MXINV=5,DURAL=30,TMOUT=0,UOUT=60, PFRCD=NO,POLD=5,PINT=20,LOGIN=MULTIPLE,PRIVLVL=RTRV” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.164 RTRV-DS1: Retrieve DS1

(Cisco ONS 15454 only)

This command retrieves the test access attributes on a DS1 layer of a DS3XM card.

| Section | RTRV-DS1 Description | | | | | | | | | | | | | | | | | | |
|------------------|---|---------------|-----------------|--------|----------|--------|---------|-------|-----------|----------|------------|-------|-----------|-------|----------|---------------|---------|---------------|---------|
| Category | Ports | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ED-<OCN_TYPE></td> <td>RTRV-<OCN_TYPE></td> </tr> <tr> <td>ED-DS1</td> <td>RTRV-EC1</td> </tr> <tr> <td>ED-EC1</td> <td>RTRV-FC</td> </tr> <tr> <td>ED-FC</td> <td>RTRV-FSTE</td> </tr> <tr> <td>ED-G1000</td> <td>RTRV-G1000</td> </tr> <tr> <td>ED-T1</td> <td>RTRV-GIGE</td> </tr> <tr> <td>ED-T3</td> <td>RTRV-POS</td> </tr> <tr> <td>RMV-<MOD2_IO></td> <td>RTRV-T1</td> </tr> <tr> <td>RST-<MOD2_IO></td> <td>RTRV-T3</td> </tr> </table> | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | ED-DS1 | RTRV-EC1 | ED-EC1 | RTRV-FC | ED-FC | RTRV-FSTE | ED-G1000 | RTRV-G1000 | ED-T1 | RTRV-GIGE | ED-T3 | RTRV-POS | RMV-<MOD2_IO> | RTRV-T1 | RST-<MOD2_IO> | RTRV-T3 |
| ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | | | | | | | | | | | | | | | | | | |
| ED-DS1 | RTRV-EC1 | | | | | | | | | | | | | | | | | | |
| ED-EC1 | RTRV-FC | | | | | | | | | | | | | | | | | | |
| ED-FC | RTRV-FSTE | | | | | | | | | | | | | | | | | | |
| ED-G1000 | RTRV-G1000 | | | | | | | | | | | | | | | | | | |
| ED-T1 | RTRV-GIGE | | | | | | | | | | | | | | | | | | |
| ED-T3 | RTRV-POS | | | | | | | | | | | | | | | | | | |
| RMV-<MOD2_IO> | RTRV-T1 | | | | | | | | | | | | | | | | | | |
| RST-<MOD2_IO> | RTRV-T3 | | | | | | | | | | | | | | | | | | |
| Input Format | RTRV-DS1:[<TID>]:<SRC>:<CTAG>[::::]; where: <ul style="list-style-type: none"> • <SRC> is the access identifier from the “DS1” section on page 4-26 and must not be null | | | | | | | | | | | | | | | | | | |
| Input Example | RTRV-DS1:PETALUMA:DS1-2-6-12:123; | | | | | | | | | | | | | | | | | | |

| Section | RTRV-DS1 Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<DS1AID>::[TACC=<TACC>],[TAPTYPE=<TAPTYPE>]” ; where:</p> <ul style="list-style-type: none"> • <DS1AID> is the access identifier from the “DS1” section on page 4-26 • <TACC> is the TAP number; <TACC> is an integer and is optional • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “DS1-2-1-6-12::TACC=8,TAPTYPE=SINGLE” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.165 RTRV-DWDM: Retrieve Dense Wavelength Division Multiplexing

(Cisco ONS 15454 only)

This command retrieves DWDM card-level attributes.

| Section | RTRV-DWDM Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------|---|--------------|-----------------|-----------------|---------------|---------|------------------|---------|-----------------|-------------|-----------|------------|---------------|----------------|--------------|--------|------------------|--------|----------|--------|----------|-------------|----------|------------|-------------------|--------------|------------------|-----------------|---------------|---------------|--------------|------------------|--|
| Category | DWDM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tbody> <tr> <td>DLT-FFP-CLNT</td> <td>OPR-PROTNST-OCH</td> </tr> <tr> <td>DLT-LNK-<MOD2O></td> <td>RLS-LASER-OTS</td> </tr> <tr> <td>ED-CLNT</td> <td>RLS-PROTNST-CLNT</td> </tr> <tr> <td>ED-DWDM</td> <td>RLS-PROTNST-OCH</td> </tr> <tr> <td>ED-FFP-CLNT</td> <td>RTRV-CLNT</td> </tr> <tr> <td>ED-FFP-OCH</td> <td>RTRV-FFP-CLNT</td> </tr> <tr> <td>ED-LNK-<MOD2O></td> <td>RTRV-FFP-OCH</td> </tr> <tr> <td>ED-OCH</td> <td>RTRV-LNK-<MOD2O></td> </tr> <tr> <td>ED-OMS</td> <td>RTRV-OCH</td> </tr> <tr> <td>ED-OTS</td> <td>RTRV-OMS</td> </tr> <tr> <td>ED-TRC-CLNT</td> <td>RTRV-OTS</td> </tr> <tr> <td>ED-TRC-OCH</td> <td>RTRV-PROTNST-CLNT</td> </tr> <tr> <td>ENT-FFP-CLNT</td> <td>RTRV-PROTNST-OCH</td> </tr> <tr> <td>ENT-LNK-<MOD2O></td> <td>RTRV-TRC-CLNT</td> </tr> <tr> <td>OPR-LASER-OTS</td> <td>RTRV-TRC-OCH</td> </tr> <tr> <td>OPR-PROTNST-CLNT</td> <td></td> </tr> </tbody> </table> | DLT-FFP-CLNT | OPR-PROTNST-OCH | DLT-LNK-<MOD2O> | RLS-LASER-OTS | ED-CLNT | RLS-PROTNST-CLNT | ED-DWDM | RLS-PROTNST-OCH | ED-FFP-CLNT | RTRV-CLNT | ED-FFP-OCH | RTRV-FFP-CLNT | ED-LNK-<MOD2O> | RTRV-FFP-OCH | ED-OCH | RTRV-LNK-<MOD2O> | ED-OMS | RTRV-OCH | ED-OTS | RTRV-OMS | ED-TRC-CLNT | RTRV-OTS | ED-TRC-OCH | RTRV-PROTNST-CLNT | ENT-FFP-CLNT | RTRV-PROTNST-OCH | ENT-LNK-<MOD2O> | RTRV-TRC-CLNT | OPR-LASER-OTS | RTRV-TRC-OCH | OPR-PROTNST-CLNT | |
| DLT-FFP-CLNT | OPR-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DLT-LNK-<MOD2O> | RLS-LASER-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-CLNT | RLS-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-DWDM | RLS-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFP-CLNT | RTRV-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFP-OCH | RTRV-FFP-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-LNK-<MOD2O> | RTRV-FFP-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OCH | RTRV-LNK-<MOD2O> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OMS | RTRV-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OTS | RTRV-OMS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-CLNT | RTRV-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-OCH | RTRV-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-FFP-CLNT | RTRV-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-LNK-<MOD2O> | RTRV-TRC-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-LASER-OTS | RTRV-TRC-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Input Format | <p>RTRV-DWDM:[<TID>]:<AID>:<CTAG>; where:</p> <ul style="list-style-type: none"> • <AID> is access identifier from the “EQPT” section on page 4-27 and must not be null | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Section | RTRV-DWDM Description |
|---------------|---|
| Input Example | RTRV-DWDM:VA454-22:SLOT-1:100; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<EQPTTYPE>,<EQUIP>,,[<STATUS>]:[PEERID=<PEERID>,,] [NAME=<NAME>,,][TERMMODE=<TERMMODE>,,] [PAYLOAD=<PAYLOAD>,,][CARDNAME=<CARDNAME>,,][PWL=<PWL>,,] [TWL1=<TWL1>,,][TWL2=<TWL2>,,][TWL3=<TWL3>,,][TWL4=<TWL4>,,] [<PST>,,][<SST>,,]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “EQPT” section on page 4-27 <EQPTTYPE> indicates the equipment type; valid values are shown in the “EQPT_TYPE” section on page 4-59 • <EQUIP> indicates if the equipment unit is physically present; valid values are shown in the “EQUIP” section on page 4-62 • <STATUS> indicates a status. SONET card status is shown on its card level; valid values are shown in the “STATUS” section on page 4-86 and <STATUS> is optional • <PEERID> is the regeneration group peer card slot. <PEERID> is the AID from the “EQPT” section on page 4-27 and is optional • <NAME> is a string and is optional • <TERMMODE> is the termination mode of the card; valid values are shown in the “TERM_MODE” section on page 4-92 and <TERMMODE> is optional • <PAYLOAD> indicates the payload for the card; valid values are shown in the “PAYLOAD” section on page 4-81 and <PAYLOAD> is optional • <CARDNAME> is a string and is optional • <PWL> provisioned wavelength; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <PWL> is optional • <TWL> tunable wavelength 1; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL> is optional • <TWL1> tunable wavelength 2; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL1> is optional • <TWL2> tunable wavelength 3; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL2> is optional • <TWL3> tunable wavelength 4; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL3> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 and <PST> is optional • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |

| Section | RTRV-DWDM Description |
|----------------|---|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-1:TXP-MR-2.5G,EQUIP,,ACT:PEERID=SLOT-2, NAME=“NY GROUP”, TERMMODE=TRANS,PAYLOAD=OC48, CARDNAME=“TRUNK-1”,PWL=1530.33,TWL1=1530.33,TWL2=1531.12, TWL3=1532.68,TWL4=1533.47:IS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.166 RTRV-EC1: Retrieve EC1

(Cisco ONS 15454 only)

This command retrieves the facility status of an EC1 card.

| Section | RTRV-EC1 Description | |
|------------------|---|--|
| Category | Ports | |
| Security | Retrieve | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> | RTRV-<OCN_TYPE> RTRV-DS1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |
| Input Format | RTRV-EC1:[<TID>]:<AID>:<CTAG>[:::]; where: • <AID> is from the “ FACILITY ” section on page 4-28 and must not be null | |
| Input Example | RTRV-EC1:CISCO:FAC-1-1:1234; | |

| Section | RTRV-EC1 Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[PJMON=<PJMON>],[LBO=<LBO>],[RXEQUAL=<RXEQUAL>], [SOAK=<SOAK>],[SOAKLEFT=<SOAKLEFT>],[SFBER=<SFBER>], [SDBER=<SDBER>]:<PST>,[<SST>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the facility AID of an EC1 port and is from the “FACILITY” section on page 4-28 • <PJMON> is the SONET pointer monitor attribute of an EC1 port; <PJMON> is an integer and is optional • <LBO> is the line build-out value of an EC1 port; valid values for <LBO> are shown in the “E_LBO” section on page 4-58, <LBO> is optional • Valid values for <RXEQUAL> are shown in the “EXT_RING” section on page 4-65, <RXEQUAL> is optional • <SOAK> OOS-AINS to IS transition soak time measured in 15 minute intervals; <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional Rules for <SOAKLEFT> are as follows: <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. • <SFBER> identifies the port SFBER and defaults to 1E-4; valid values are shown in the “SF_BER” section on page 4-86 and <SFBER> is optional • <SDBER> identifies the port SDBER and defaults to 1E-7; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1::PJMON=0,LBO=0-225,RXEQUAL=Y,SOAK=52,SOAKLEFT=12-25, SFBER=1E-4,SDBER=1E-7:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.167 RTRV-EQPT: Retrieve Equipment

This command retrieves protection group information and status information for all cards.

This command returns the PRTYPE, PROTID, RVTM, and RVRTV parameters for a card inside of a protection group by the following scenario:

1. A working AID/card within a 1:1 protection group should return PRTYPE, PROTID, RVTM and RVRTV.
2. A protection/AID card within a 1:1 protection group should return PRTYPE, RVTM and RVRTV.
3. A working AID/card within a 1:N protection group should return PRTYPE, PROTID, RVTM and RVRTV=Y.
4. A protection AID/card of a 1:1 protection group should return PRTYPE, RVTM and RVRTV=Y.
5. An unprotected AID/card, the AID type, equip (equip/unequip), status (act/standby) and state (IS/OOS) values.
6. Pre-provisioned cards (without being plugged in) will display OOS,AINS for PST and SST. Once the card is plugged in and has gone through its initialization sequence the card automatically goes to IS (PST).

Error conditions:

1. The equipment is not provisioned.

| Section | RTRV-EQPT Description | |
|------------------|---|---|
| Category | Equipment | |
| Security | Retrieve | |
| Related Messages | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-SWTOPROTN-EQPT | INH-SWTOWKG-EQPT REPT ALM EQPT REPT EVT EQPT RTRV-ALM-EQPT RTRV-COND-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | RTRV-EQPT:[<TID>]:<AID>:<CTAG>[::::]; where: • <AID> is from the “EQPT” section on page 4-27 and must not be null | |
| Input Example | RTRV-EQPT:MIRABEL:SLOT-12:230; | |

| Section | RTRV-EQPT Description |
|---------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<AIDTYPE>,<EQUIP>,[<ROLE>],[<STATUS>]: [PROTID=<PROTID>],[PRTYPE=<PRTYPE>, [RVRTV=<RVRTV>],[RVTM=<RVTM>] [CARDNAME=<CARDNAME>, [IOSCFG=<IOSCFG>]:[<PST>],[<SST>]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the equipment unit identifier and is from the “EQPT” section on page 4-27 • <AIDTYPE> is a string • <EQUIP> indicates if the equipment unit is physically present; valid values are shown in the “EQUIP” section on page 4-62 • <ROLE> indicates if the card is a working unit or a protecting unit; valid values are shown in the “SIDE” section on page 4-86, <ROLE> is optional • <STATUS> indicates a status. SONET card status is shown on it’s line/port level. Valid values for <STATUS> are shown in the “STATUS” section on page 4-86, <STATUS> is optional • <PROTID> indicates the protecting identifier; <PROTID> is from the “PRSLOT” section on page 4-31 and is optional • <PRTYPE> indicates the protection type; valid values are shown in the “PROTECTION_GROUP” section on page 4-83, <PRTYPE> is optional • <RVRTV> indicates a revertive mode; valid values are shown in the “ON_OFF” section on page 4-76, <RVRTV> is optional • <RVTM> indicates the revertive time; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84, <RVTM> is optional • <CARDNAME> is a string and is optional • <IOSCFG> displays the information about startup IOS config file for the ML1000-2 and ML100T-12 cards. An example of this field is “TL1,11.22.33.44//DIR/IOS.CONF,2002/1/1 9:1:1 EST”. The following information is included in this field: <ol style="list-style-type: none"> 1) Where the config file is from: TL1, or CTC/CTM/CLI/TCC; 2) The host (IP address)/directory/file name, if the config file is downloaded from the network; 3) When the startup config file is created (by copying from the network, for example). This field only applies to ML1000-2 and ML100T-12 cards. <IOSCFG> is a String. <IOSCFG> is optional. • <PST> primary state; valid values are shown in the “PST” section on page 4-83, <PST> is optional • <SST> secondary state; valid values are shown in the “SST” section on page 4-86, <SST> is optional |

| Section | RTRV-EOPT Description |
|----------------|---|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-12:DS1,EQUIP,,ACT:PROTID=SLOT-13,PRTYPE=1-1,RVRTV=Y, RVTM=8.5,CARDNAME=DESCRIPTION,IOSCFG= “IOS CONFIG INFO FOR ML SERIES CARD”:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.168 RTRV-EXT-CONT: Retrieve External Control

This command retrieves the control state of an external control. The command can be used to audit the result of an OPR-EXT-CONT or a RLS-EXT-CONT command.

Notes:

1. If the CONNTYPE is null, the existing conttype on this AID will be returned.
2. The duration is not supported, it defaults to CONTS.

| Section | RTRV-EXT-CONT Description |
|------------------|--|
| Category | Environment Alarms and Controls |
| Security | Retrieve |
| Related Messages | OPR-ACO-ALL RTRV-ATTR-CONT OPR-EXT-CONT RTRV-ATTR-ENV REPT ALM ENV RTRV-COND-ENV REPT EVT ENV SET-ATTR-CONT RLS-EXT-CONT SET-ATTR-ENV RTRV-ALM-ENV |
| Input Format | RTRV-EXT-CONT:[<TID>]:<AID>:<CTAG>[::<CONNTYPE>]; where: <ul style="list-style-type: none"> • <AID> is from the “ENV” section on page 4-26 and must not be null. <p>Note For this command only ENV-OUT-{1-2} is a valid AID.</p> <ul style="list-style-type: none"> • Valid values for <CONNTYPE> are shown in the “CONNTYPE” section on page 4-55. A null value is equivalent to ALL |
| Input Example | RTRV-EXT-CONT:CISCO:ENV-OUT-2:123::AIRCOND; |

| Section | RTRV-EXT-CONT Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[<CONTTYPE>],<DUR>,[<CONTSTATE>]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> identifies the external control for which control state is being retrieved and is from the “ENV” section on page 4-26 • <CONTTYPE> is the type of control for which control state is being retrieved; valid values are shown in the “CONTTYPE” section on page 4-55, <CONTTYPE> is optional • <DUR> is the duration for which the external control can be operated; valid values are shown in the “DURATION” section on page 4-57 • <CONTSTATE> is the control of the external control; valid values are shown in the “CONT_MODE” section on page 4-55, <CONTSTATE> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “ENV-OUT-2:AIRCOND,CONTS,OPEN” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.169 RTRV-FC: Retrieve Fiber Channel Facility

This command retrieves the attributes related to the fiber channel facility.

| Section | RTRV-FC Description | | | | | | | | | | | | | | | | | | | | |
|------------------|---|---------------|----------|--------|----------|--------|----------|-------|---------|----------|-----------|-------|------------|-------|-----------|---------------|----------|---------------|---------|-----------------|---------|
| Category | Ports | | | | | | | | | | | | | | | | | | | | |
| Security | Provisioning | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tbody> <tr> <td>ED-<OCN_TYPE></td> <td>RTRV-DS1</td> </tr> <tr> <td>ED-DS1</td> <td>RTRV-EC1</td> </tr> <tr> <td>ED-EC1</td> <td>RTRV-FAC</td> </tr> <tr> <td>ED-FC</td> <td>RTRV-FC</td> </tr> <tr> <td>ED-G1000</td> <td>RTRV-FSTE</td> </tr> <tr> <td>ED-T1</td> <td>RTRV-G1000</td> </tr> <tr> <td>ED-T3</td> <td>RTRV-GIGE</td> </tr> <tr> <td>RMV-<MOD2_IO></td> <td>RTRV-POS</td> </tr> <tr> <td>RST-<MOD2_IO></td> <td>RTRV-T1</td> </tr> <tr> <td>RTRV-<OCN_TYPE></td> <td>RTRV-T3</td> </tr> </tbody> </table> | ED-<OCN_TYPE> | RTRV-DS1 | ED-DS1 | RTRV-EC1 | ED-EC1 | RTRV-FAC | ED-FC | RTRV-FC | ED-G1000 | RTRV-FSTE | ED-T1 | RTRV-G1000 | ED-T3 | RTRV-GIGE | RMV-<MOD2_IO> | RTRV-POS | RST-<MOD2_IO> | RTRV-T1 | RTRV-<OCN_TYPE> | RTRV-T3 |
| ED-<OCN_TYPE> | RTRV-DS1 | | | | | | | | | | | | | | | | | | | | |
| ED-DS1 | RTRV-EC1 | | | | | | | | | | | | | | | | | | | | |
| ED-EC1 | RTRV-FAC | | | | | | | | | | | | | | | | | | | | |
| ED-FC | RTRV-FC | | | | | | | | | | | | | | | | | | | | |
| ED-G1000 | RTRV-FSTE | | | | | | | | | | | | | | | | | | | | |
| ED-T1 | RTRV-G1000 | | | | | | | | | | | | | | | | | | | | |
| ED-T3 | RTRV-GIGE | | | | | | | | | | | | | | | | | | | | |
| RMV-<MOD2_IO> | RTRV-POS | | | | | | | | | | | | | | | | | | | | |
| RST-<MOD2_IO> | RTRV-T1 | | | | | | | | | | | | | | | | | | | | |
| RTRV-<OCN_TYPE> | RTRV-T3 | | | | | | | | | | | | | | | | | | | | |
| Input Format | <p>RTRV-FC:<TID>:<AID>:<CTAG>[:::];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “FACILITY” section on page 4-28 and must not be null | | | | | | | | | | | | | | | | | | | | |
| Input Example | RTRV-FC:CISCO:FAC-6-1:888; | | | | | | | | | | | | | | | | | | | | |

| Section | RTRV-FC Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::PAYLOAD=<PAYLOAD>,LINKRATE=<LINKRATE>, LINKSTATE=<LINKSTATE>,LINKRCVRY=<LINKRCVRY>:<PST>,[<SST>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 • <PAYLOAD> payload type provisioned on a fiber channel port; valid values are shown in the “PAYLOAD” section on page 4-81 • <LINKRATE> actual rate running on the fiber channel port. It can differ from the payload type provisioned; valid values are shown in the “FC_LINKRATE” section on page 4-65 • <LINKSTATE> link state; valid values are shown in the “DIRN” section on page 4-56 • <LINKRCVRY> link recovery enable or disabled; valid values are shown in the “ON_OFF” section on page 4-76 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <STS> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-6-1::PAYLOAD=1GFC,LINKRATE=1GFC,LINKSTATE=UP, LINKRCVRY=Y:OOS,MT” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.170 RTRV-FFP-<OCN_TYPE>: Retrieve Facility Protection Group (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the optical facility protection information.

| Section | RTRV-FFP-<OCN_TYPE> Description | |
|------------------|--|--|
| Category | SONET Line Protection | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ENT-FFP-<OCN_TYPE> | ENT-FFP-CLNT OPR-PROTNSW-<OCN_TYPE> RLS-PROTNSW-<OCN_TYPE> RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-PROTNSW-<OCN_TYPE> |

| Section | RTRV-FFP-<OCN_TYPE> Description |
|----------------|---|
| Input Format | RTRV-FFP-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none">• <AID> is the optical facility AID from the “FACILITY” section on page 4-28 and must not be null |
| Input Example | RTRV-FFP-OC3:PETALUMA:FAC-1-1:1; |
| Output Format | SID DATE TIME M CTAG COMPLD “<WORK>,<PROTECT>:[PROTID=<PROTID>],[RVRTV=<RVRTV>],[RVTM=<RVTM>],[PSDIRN=<PSDIRN>]” ; where: <ul style="list-style-type: none">• <WORK> identifies the working port and is the AID from the “FACILITY” section on page 4-28• <PROTECT> identifies the protection port and is the AID from the “FACILITY” section on page 4-28• <PROTID> the 1+1 protection group name; <PROTID> is a string and is optional• <RVRTV> identifies a revertive mode and defaults to N (non-revertive mode); valid values are shown in the “ON_OFF” section on page 4-76, <RVRTV> is optional• <RVTM> identifies the revertive time and defaults to 5.0 minutes; valid values are shown in the “REVERTIVE_TIME” section on page 4-84, <RVTM> is optional• <PSDIRN> indicates the switch mode and defaults to UNI. valid values are shown in the “UNI_BI” section on page 4-96, <PSDIRN> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1,FAC-1-1:[PROTID=PROT_NAME,RVRTV=Y,RVTM=1.0,PSDIRN=BI]” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.171 RTRV-FFP-CLNT: Retrieve Facility Protection Group Client

(Cisco ONS 15454 only)

This command retrieves Y cable protection on client facilities.

| Section | RTRV-FFP-CLNT Description |
|----------|---------------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-FFP-CLNT Description | |
|------------------|--|--|
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-<OCN_TYPE> | OPR-PROTNSW-CLNT OPR-PROTNSW-OCH RLS-LASER-OTS RLS-PROTNSW-<OCN_TYPE> RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-<OCN_TYPE> RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OTS RTRV-OMS RTRV-OTSN RTRV-PROTNSW-<OCN_TYPE> RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | RTRV-FFP-CLNT:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <AID> is the access identifier from the “FACILITY” section on page 4-28 and must not be null | |
| Input Example | RTRV-FFP-CLNT:CISCO:FAC-1-1:100; | |

| Section | RTRV-FFP-CLNT Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<WORKAID>,<PROTAID>::[PROTTYPE=<PROTTYPE>, [PROTID=<PROTID>],[RVRTV=<RVRTV>],[RVTM=<RVTM>, [PSDIRN=<PSDIRN>]” ; where:</p> <ul style="list-style-type: none"> • <WORKAID> identifies a working port and is the AID from the “FACILITY section on page 4-28 • <PROTAID> identifies a protection port and is the AID from the “FACILITY section on page 4-28 • <PROTTYPE> identifies the type of facility protection; valid values are shown in the “PROTTYPE” section on page 4-83 and <PROTTYPE> is optional • <PROTID> Y cable protection group name; <PROTID> is a string and is optional • <RVRTV> identifies the revertive mode. Defaults to N (non-revertive mode); valid values are shown in the “ON_OFF” section on page 4-76 and <RVRTV> is optional • <RVTM> identifies the revertive time. Defaults to 5.0 minutes; valid values are shown in the “REVERTIVE_TIME” section on page 4-84 and <RVTM> is optional • <PSDIRN> identifies the switching mode and defaults to UNI; valid values are shown in the “UNI_BI” section on page 4-96 and <PSDIRN> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1,FAC-2-1::PROTTYPE=Y-CABLE,PROTID=\“DC-METRO\”, RVRTV=N,RVTM=1.0,PSDIRN=BI” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.172 RTRV-FFP-OCH: Retrieve Facility Protection Group OCH

(Cisco ONS 15454 only)

This command retrieves the protection group information for the TXP_MR_2.5G and TXPP_MR_2.5G trunk port.

| Section | RTRV-FFP-OCH Description |
|----------|--------------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-FFP-OCH Description |
|------------------|---|
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-<OCN_TYPE> ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-<OCN_TYPE> |
| | OPR-PROTNSW-CLNT OPR-PROTNSW-OCH RLS-LASER-OTS RLS-PROTNSW-<OCN_TYPE> RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-LNK-<MOD2O> RTRV-OTS RTRV-OMS RTRV-OCH RTRV-PROTNSW-<OCN_TYPE> RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | RTRV-FFP-OCH:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none"> • <AID> is the access identifier from the “CHANNEL” section on page 4-19 and must not be null |
| Input Example | RTRV-FFP-OCH:VA454-22:CHAN-2-2:100; |
| Output Format | SID DATE TIME M CTAG COMPLD “<WORK>,<PROTECT>::[PROTTYPE=<PROTTYPE>],[PROTID=<PROTID>],[RVRTV=<RVRTV>],[RVTM=<RVTM>],[PSDIRN=<PSDIRN>]” ; where: <ul style="list-style-type: none"> • <WORK> identifies a working port and is the AID from the “CHANNEL” section on page 4-19 • <PROTECT> identifies a protection port and is the AID from the “CHANNEL” section on page 4-19 • <PROTTYPE> the protection group type and is optional • <PROTID> the protection group name; <PROTID> is a string and is optional • <RVRTV> the revertive mode; valid values are shown in the “ON_OFF” section on page 4-76 and <RVRTV> is optional • <RVTM> the revertive time; valid values are shown in the “REVERTIVE_TIME” section on page 4-84 and <RVTM> is optional • <PSDIRN> the direction of reversion; valid values are shown in the “UNI_BI” section on page 4-96 and <PSDIRN> is optional |

| Section | RTRV-FFP-OCH Description |
|----------------|--|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-2-2,CHAN-2-3::PROTTYPE=SPLITTER,PROTID=“TRUNK PROT”,RVRTV=Y,RVTM=1.0,PSDIRN=UNI” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.173 RTRV-FSTE: Retrieve Fast Ethernet

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the front end port information of the ML100T-12 Ethernet card.

| Section | RTRV-FSTE Description | | | | | | | | | | | | | | | | | | |
|------------------|--|---------------|-----------------|--------|----------|--------|----------|-------|---------|----------|------------|-------|-----------|-------|----------|---------------|---------|---------------|---------|
| Category | Ports | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ED-<OCN_TYPE></td> <td>RTRV-<OCN_TYPE></td> </tr> <tr> <td>ED-DS1</td> <td>RTRV-DS1</td> </tr> <tr> <td>ED-EC1</td> <td>RTRV-EC1</td> </tr> <tr> <td>ED-FC</td> <td>RTRV-FC</td> </tr> <tr> <td>ED-G1000</td> <td>RTRV-G1000</td> </tr> <tr> <td>ED-T1</td> <td>RTRV-GIGE</td> </tr> <tr> <td>ED-T3</td> <td>RTRV-POS</td> </tr> <tr> <td>RMV-<MOD2_IO></td> <td>RTRV-T1</td> </tr> <tr> <td>RST-<MOD2_IO></td> <td>RTRV-T3</td> </tr> </table> | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | ED-DS1 | RTRV-DS1 | ED-EC1 | RTRV-EC1 | ED-FC | RTRV-FC | ED-G1000 | RTRV-G1000 | ED-T1 | RTRV-GIGE | ED-T3 | RTRV-POS | RMV-<MOD2_IO> | RTRV-T1 | RST-<MOD2_IO> | RTRV-T3 |
| ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | | | | | | | | | | | | | | | | | | |
| ED-DS1 | RTRV-DS1 | | | | | | | | | | | | | | | | | | |
| ED-EC1 | RTRV-EC1 | | | | | | | | | | | | | | | | | | |
| ED-FC | RTRV-FC | | | | | | | | | | | | | | | | | | |
| ED-G1000 | RTRV-G1000 | | | | | | | | | | | | | | | | | | |
| ED-T1 | RTRV-GIGE | | | | | | | | | | | | | | | | | | |
| ED-T3 | RTRV-POS | | | | | | | | | | | | | | | | | | |
| RMV-<MOD2_IO> | RTRV-T1 | | | | | | | | | | | | | | | | | | |
| RST-<MOD2_IO> | RTRV-T3 | | | | | | | | | | | | | | | | | | |
| Input Format | <p>RTRV-FSTE:[<TID>]:<AID>:<CTAG>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the facility AID from the “FACILITY” section on page 4-28 and must not be null | | | | | | | | | | | | | | | | | | |
| Input Example | RTRV-FSTE:TID:FAC-1-1:CTAG; | | | | | | | | | | | | | | | | | | |

| Section | RTRV-FSTE Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:[ADMINSTATE=<ADMINSTATE>],[LINKSTATE=<LINKSTATE>], [MTU=<MTU>],[FLOWCTRL=<FLOWCTRL>],[DUPLEX=<DUPLEX>], [SPEED=<SPEED>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “FACILITY” section on page 4-28 • <ADMINSTATE> administration type; valid values are shown in the “UP_DOWN” section on page 4-97. <ADMINSTATE> is optional • <LINKSTATE> link protocol; valid values are shown in the “UP_DOWN” section on page 4-97. <LINKSTATE> is optional • <MTU> maximum transport unit; <MTU> is an integer and is optional • <FLOWCTRL> flow control; valid values are shown in the “FLOW” section on page 4-65. <FLOWCTRL> is optional • <DUPLEX> duplex mode; valid values are shown in the “ETHER_DUPLEX” section on page 4-64. <DUPLEX> is optional • <SPEED> Ethernet speed; valid values are shown in the “ETHER_SPEED” section on page 4-64. <SPEED> is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1::ADMINSTATE=DOWN,LINKSTATE=DOWN,MTU=1500, FLOWCTRL=SYMMETRIC,DUPLEX=AUTO,SPEED=AUTO” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.174 RTRV-G1000: Retrieve G1000 Facility

(Cisco ONS 15454 only)

This command retrieves the G1000 facilities configuration.

| Section | RTRV-G1000 Description | |
|------------------|--|--|
| Category | Ports | |
| Security | Retrieve | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> | RTRV-<OCN_TYPE> RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-GIGE RTRV-POS RTRV-T1 RTRV-T3 |

| Section | RTRV-G1000 Description |
|----------------|--|
| Input Format | RTRV-G1000:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is from the “FACILITY” section on page 4-28 and must not be null |
| Input Example | RTRV-G1000:TID:FAC-1-1:CTAG; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::[MFS=<MFS>],[FLOW=<FLOW>],[LAN=<LAN>],[OPTICS=<OPTICS>],[TRANS=<TRANS>],[TPORT=<TPORT>],[LOWMRK=<LOWMRK>],[HIWMRK=<HIWMRK>]:[<PST>],[<SST>]”; where: <ul style="list-style-type: none">• <AID> is from the “FACILITY” section on page 4-28• Valid values for <MFS> are shown in the “MFS_TYPE” section on page 4-68; <MFS> is optional• Valid values for <FLOW> are shown in the “ON_OFF” section on page 4-76; <FLOW> is optional• Valid values for <LAN> are shown in the “FLOW” section on page 4-65; <LAN> is optional• <OPTICS> GBIC type optics; valid values for are shown in the “OPTICS” section on page 4-79; <OPTICS> is optional• <TRANS> transponder mode; valid values are shown in the “TRANS_MODE” section on page 4-93 and <TRANS> is optional• <TPORT> transponding port; <TPORT> is from the “FACILITY” section on page 4-28 and is optional• <LOWMRK> low watermark; <LOWMRK> is an integer and is optional• <HIWMRK> high watermark: <HIWMRK> is an integer and is optional• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86; <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1::MFS=9032,FLOW=N,LAN=ASYMMETRIC,OPTICS=UNKNOWN,TRANS=NONE,TPORT=FAC-5-1,LOWMRK=20,HIWMRK=492:OOS,AINS”; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.175 RTRV-GIGE: Retrieve Gigabit Ethernet

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the front end port information for the ML1000-2 Ethernet card.

| Section | RTRV-GIGE Description | |
|------------------|---|---|
| Category | Ports | |
| Security | Retrieve | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> | RTRV-<OCN_TYPE> RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-POS RTRV-T1 RTRV-T3 |
| Input Format | <p>RTRV-GIGE:[<TID>]:<AID>:<CTAG>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is from the “FACILITY” section on page 4-28 and must not be null | |
| Input Example | RTRV-GIGE:TID:FAC-1-1:CTAG;; | |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[ADMINSTATE=<ADMINSTATE>],[LINKSTATE=<LINKSTATE>], [MTU=<MTU>],[FLOWCTRL=<FLOWCTRL>],[OPTICS=<OPTICS>], [DUPLEX=<DUPLEX>],[SPEED=<SPEED>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “FACILITY” section on page 4-28 • <ADMINSTATE> administration type; valid values are shown in the “UP_DOWN” section on page 4-97. <ADMINSTATE> is optional • <LINKSTATE> link protocol; valid values are shown in the “UP_DOWN” section on page 4-97. <LINKSTATE> is optional • <MTU> maximum transport unit; <MTU> is an integer and is optional • <FLOWCTRL> flow control; valid values are shown in the “FLOW” section on page 4-65. <FLOWCTRL> is optional • <OPTICS> is the optics type; valid values are shown in “OPTICS” section on page 4-79. <OPTICS> is optional • <DUPLEX> duplex mode; valid values are shown in the “ETHER_DUPLEX” section on page 4-64. <DUPLEX> is optional • <SPEED> Ethernet speed; valid values are shown in the “ETHER_SPEED” section on page 4-64. <SPEED> is optional | |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1::ADMINSTATE=DOWN,LINKSTATE=DOWN,MTU=1500, FLOWCTRL=SYMMETRIC,OPTICS=1000_BASE_SX,DUPLEX=AUTO, SPEED=AUTO” ; </p> | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.176 RTRV-HDR: Retrieve Header

This command retrieves the header of a TL1 response message. Used by TL1 clients to determine if the link to the NE is still active and if the NE is responding to commands.

| Section | RTRV-HDR Description | |
|------------------|--|----------------|
| Category | System | |
| Security | Retrieve | |
| Related Messages | ACT-USER | INH-MSG-SECU |
| | ALW-MSG-ALL | INIT-SYS |
| | ALW-MSG-DBCHG | RTRV-INV |
| | ALW-MSG-SECU | RTRV-NE-GEN |
| | ED-DAT | RTRV-NE-IPMAP |
| | ED-NE-GEN | RTRV-NE-PATH |
| | ED-NE-PATH | RTRV-NE-SYNCR |
| | ED-NE-SYNCR | RTRV-NE-WDMANS |
| | INH-MSG-ALL | RTRV-TOD |
| | INH-MSG-DBCHG | SET-TOD |
| Input Format | RTRV-HDR:[<TID>]::<CTAG>; | |
| Input Example | RTRV-HDR:SONOMA::232; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.177 RTRV-INV: Retrieve Inventory

This command retrieves a listing of the equipment inventory. For each unit in the system, it identifies the unit's firmware numbers and the unit's CLEI code.

| Section | RTRV-INV Description | |
|------------------|---|----------------|
| Category | System | |
| Security | Retrieve | |
| Related Messages | ACT-USER | INH-MSG-SECU |
| | ALW-MSG-ALL | INIT-SYS |
| | ALW-MSG-DBCHG | RTRV-HDR |
| | ALW-MSG-SECU | RTRV-NE-GEN |
| | ED-DAT | RTRV-NE-IPMAP |
| | ED-NE-GEN | RTRV-NE-PATH |
| | ED-NE-PATH | RTRV-NE-SYNCR |
| | ED-NE-SYNCR | RTRV-NE-WDMANS |
| | INH-MSG-ALL | RTRV-TOD |
| | INH-MSG-DBCHG | SET-TOD |
| Input Format | RTRV-INV:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “EQPT” section on page 4-27 and must not be null | |
| Input Example | RTRV-INV:OCCIDENTAL:SLOT-15:301; | |

| Section | RTRV-INV Description |
|---------------------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD</p> <p>“<AID>,<AIDTYPE>:[PLUGTYPE=<PLUGTYPE>],[PN=<PN>],[HWREV=<HWREV>],[FWREV=<FWREV>],[SN=<SN>],[CLEI=<CLEI>],[TWL1=<TWL>],[TWL2=<TWL1>],[TWL3=<TWL2>],[TWL4=<TWL3>],[PLUGINVENDORID=<PLUGINVENDORID>],[PLUGINPN=<PLUGINPN>],[PLUGINHWREV=<PLUGINHWREV>],[PLUGINFWREV=<PLUGINFWREV>],[PLUGINSN=<PLUGINSN>],[ILOSSREF=<ILOSSREF>],[PID=<PID>],[VID=<VID>],[FPGA=<FPGA>]”;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “EQPT” section on page 4-27 • <AIDTYPE> specifies the type of AID and is a string • <PLUGTYPE> describes the type of plug-in; <PLUGTYPE> is a string and is optional • <PN> is the HW part number; <PN> is a string and is optional • <HWREV> is the HW Rev; <HWREV> is a string and is optional • <FWREV> is the firmware Rev; <FWREV> is a string and is optional • <SN> is the serial number; <SN> is a string and is optional • <CLEI> is the CLEI code for the equipment, is a string and is optional |
| Output Format (continued) | <ul style="list-style-type: none"> • <TWL> tunable wavelength 1; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL> is optional • <TWL1> tunable wavelength 2; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL1> is optional • <TWL2> tunable wavelength 3; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL2> is optional • <TWL3> tunable wavelength 4; valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <TWL3> is optional • <PLUGINVERNDORID> is an integer and is optional • <PLUGINPN> is a third-party plug-in module HW part number. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <PLUGINPN> is a string and is optional • <PLUGINHWREV> is a third-party plug-in module hardware. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <PLUGINHWREV> is a string and is optional • <PLUGINFWREV> is a third-party plug-in module firmware. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <PLUGINFWREV> is a string and is optional |

| Section | RTRV-INV Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> • <PLUGINSN> is a third-party plug-in module serial number. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <PLUGINSN> is optional • <ILOSSREF> valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <PID> product ID of the module; <PID> is a string and is optional • <VID> is a string and is optional • <FPGA> FPGA version; <FPGA> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SLOT-15,OC3-IR-4::PLUGTYPE=SX-IR-SW-SN,PN=87-31-00002, HWREV=004K,FWREV=76-99-00009-004A,SN=013510, CLEI=NOCLEI,TWL1=1546.12,TWL2=1546.92,TWL3=1547.72, TWL4=1548.51,PLUGINVENDORID=012345,PLUGINPN=ABCDE, PLUGINHWREV=ABCDE,PLUGINFWREV=01-02-03,PLUGINSN=01234, ILOSSREF=1.0,PID=CISCO_ONS15454,VID=V01,FPGA=F451” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.178 RTRV-LNK: Retrieve Link

(Cisco ONS 15454 only)

This command retrieves all the (optical) links created in the NE. The ends information is returned along with the type of (optical) link.

| Section | RTRV-LNK Description | |
|------------------|----------------------------|-----------------------------------|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | OPR-LNK DLT-LNK-<MOD2O> | ED-LNK-<MOD2O> ENT-LNK-<MOD2O> |
| Input Format | RTRV-LNK:[<TID>]::<CTAG>; | |
| Input Example | RTRV-LNK:PENNGROVE::114; | |

| Section | RTRV-LNK Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<FROM>,<TO>::[OLNKT=<OLNKT>],[CTYPE=<CTYPE>], [RDIRN=<RDIRN>],[BAND=<BAND>],[WLEN=<WLEN>]:<PST>,[<SST>] ; where:</p> <ul style="list-style-type: none"> • <FROM> identifies an entity at one end of the optical link and is the AID from the “ALL” section on page 4-9 • <TO> identifies an entity at the other end of the optical link and is the AID from the “ALL” section on page 4-9 • <OLNKT> identifies the optical link type; valid values are shown in the “OPTICAL_LINK_TYPE” section on page 4-77 and <OLNKT> is optional • <CTYPE> indicates if the optical link is provisioned by a user or automatically created by the NE’ valid values are shown in the “CREATION_TYPE” section on page 4-55 and <CTYPE> is optional • <RDIRN> are shown in the “RDIRN_MODE” section on page 4-83 and <RDIRN> is optional • <BAND> identifies the optical band (group of four contiguous wavelengths) for this optical link. It is present only in case of a link between two OMS entities. Valid values for <BAND> are shown in the “OPTICAL_BAND” section on page 4-76 and <BAND> is optional • <WLEN> identifies the optical wavelength. It is present only in the case of a link between two OCH entities. Valid values for <WLEN> are shown in the “OPTICAL_WLEN” section on page 4-78 and <WLEN> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BAND-6-1-TX,BAND-13-1-RX::OLNKT=HITLESS,CTYPE=PROV, RDIRN=W_E,BAND=1530.32-1532.68,WLEN=1530.32:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.179 RTRV-LNK-<MOD20>: Retrieve Optical Link (OCH, OMS, OTS)

(Cisco ONS 15454 only)

This command retrieves any optical link associated with the entered AIDs or AID range. The ends information is returned along with the type of optical link.

| Section | RTRV-LNK-<MOD20> Description |
|----------|------------------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-LNK-<MOD2O> Description |
|------------------|--|
| Related Messages | DLT-FFP-CLNT OPR-PROTNST-OCH DLT-LNK-<MOD2O> RLS-LASER-OTS ED-CLNT RLS-PROTNST-CLNT ED-DWDM RLS-PROTNST-OCH ED-FFP-CLNT RTRV-CLNT ED-FFP-OCH RTRV-DWDM ED-LNK-<MOD2O> RTRV-FFP-CLNT ED-OCH RTRV-FFP-OCH ED-OMS RTRV-OCH ED-OTS RTRV-OMS ED-TRC-CLNT RTRV-OTS ED-TRC-OCH RTRV-PROTNST-CLNT ENT-FFP-CLNT RTRV-PROTNST-OCH ENT-LNK-<MOD2O> RTRV-TRC-CLNT OPR-LASER-OTS RTRV-TRC-OCH OPR-PROTNST-CLNT |
| Input Format | RTRV-LNK-<MOD2O>:[<TID>]:<AID>:<CTAG>:::[OLNKT=<OLNKT>,<OLNKT>],[CTYPE=<CTYPE>],[RDIRN=<RDIRN>]; where: <ul style="list-style-type: none"> • <AID> identifies facilities to check for optical link membership. It can be an OPTICAL_AID AID or ALL AID. The ALL AID defaults to NE which means to report all existing optical links of the NE. <AID> is the AID from the “BAND” section on page 4-18 and must not be null • <OLNKT> identifies the optical link type; valid values are shown in the “OPTICAL_LINK_TYPE” section on page 4-77 and <OLNKT> is optional • <CTYPE> indicates if the optical link is provisioned by a user or automatically created by the NE’ valid values are shown in the “CREATION_TYPE” section on page 4-55 and <CTYPE> is optional • <RDIRN> specifies the filter on ring directionality of the optical link; valid values are shown in the “RDIRN_MODE” section on page 4-83. A null value is equivalent to ALL |
| Input Example | RTRV-LNK-OMS:PENNGROVE:ALL:114:::OLNKT=HITLESS,CTYPE=AUTO,RDIRN=W-E; |

| Section | RTRV-LNK-<MOD20> Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<FROM>,<TO>::[OLNKT=<OPTICALLINKTYPE>,<OPTICALLINKTYPE>],[CTYPE=<CREATIONTYPE>],[RDIRN=<RDIRN>],[BAND=<BAND>],[WLEN=<WLEN>]:<PST>,[<SST>]; where:</p> <ul style="list-style-type: none"> • <FROM> identifies an entity at one end of the optical link and is the AID from the “BAND” section on page 4-18 • <TO> identifies an entity at the other end of the optical link and is the AID from the “BAND” section on page 4-18 • <OPTICALLINKTYPE> identifies the optical link type; valid values are shown in the “OPTICAL_LINK_TYPE” section on page 4-77 and <OPTICALLINKTYPE> is optional • <CREATIONTYPE> indicates if the optical link is provisioned by a user or automatically created by the NE; valid values are shown in the “CREATION_TYPE” section on page 4-55 and <CREATIONTYPE> is optional • Valid values for <RDIRN> are shown in the “RDIRN_MODE” section on page 4-83 and <RDIRN> is optional • <BAND> identifies the optical band (group of four contiguous wavelengths) for this optical link. It is present only in case of a link between two OMS entities. Valid values for <BAND> are shown in the “OPTICAL_BAND” section on page 4-76 and <BAND> is optional • <WLEN> identifies the optical wavelength. It is present only in the case of a link between two OCH entities. Valid values for <WLEN> are shown in the “OPTICAL_WLEN” section on page 4-78 and <WLEN> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BAND-6-1-TX,BAND-13-1-RX::OLNKT=HITLESS,CTYPE=PROV, RDIRN=W_E,BAND=1530.32,WLEN=1530.32:OOS,AINS”; ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.180 RTRV-LOG: Retrieve Log

This command retrieves the alarm log of the NE.



The only option reported for LOGNM is ALARM.

| Section | RTRV-LOG Description |
|------------------|---|
| Category | Log |
| Security | Superuser |
| Related Messages | ALW-MSG-DBCHG INH-MSG-DBCHG REPT DBCHG |
| Input Format | RTRV-LOG:[<TID>]::<CTAG>::<LOGNM>; where: <ul style="list-style-type: none">• <LOGNM> is the log name - ALARM; <LOGNM> is a string and must not be null |
| Input Example | RTRV-LOG:CISCO::123::ALARM; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>,<ALMNUMBER>:CURRENT=<CURRENT>, [PREVIOUS=<PREVIOUS>],<CONDITION>,<SRVEFF>,[TIME=<OCRTIME>], [DATE=<OCRDAT>]:<ALMDESCR>” ; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “ALL” section on page 4-9• <ALMNUMBER> is an alarm number of the log and is an integer• <CURRENT> is a current severity; valid values are shown in the “NOTIF_CODE” section on page 4-75• <PREVIOUS> is a previous severity; valid values are shown in the “COND_EFF” section on page 4-54, <PREVIOUS> is optional• <CONDITION> is a condition; valid values are shown in the “Conditions” section on page 7-18• <SRVEFF> is a service effect; valid values are shown in the “SERV_EFF” section on page 4-85• <OCRTIME> is the time an alarm is triggered and is optional• <OCRDAT> is the date an alarm is triggered and is optional• <ALMDESCR> is the alarm description and is a string |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-3-1,18:CURRENT=MJ,PREVIOUS=CL,EOC,NSA, TIME=16-33-04,DATE=1971-02-03:\“SDCC TERMINATION FAILURE\”” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.181 RTRV-MAP-NETWORK: Retrieve Map Network

This command retrieves all the NE attributes which are reachable from the GNE (gateway NE). The NE attributes include the node IP address (IPADDR), node name (TID), and the product type of the NE (PRODUCT).

**Note**

The product type field in the response will be displayed as “unknown” for nodes that are not running the same version of software.

| Section | RTRV-MAP-NETWORK Description |
|------------------|---|
| Category | Network |
| Security | Retrieve |
| Related Messages | RTRV-MAP-IPMAP |
| Input Format | RTRV-MAP-NETWORK:[<TID>]::<CTAG>; |
| Input Example | RTRV-MAP-NETWORK:CISCO::123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<IPADDR>,<NODENAME>,<PRODUCT>" ; where: <ul style="list-style-type: none"> • <IPADDR> indicates the node IP address and is a string • <NODENAME> indicates the node name (TID) and is a string • <PRODUCT> indicates the product type of the NE; valid values are shown in the “PRODUCT_TYPE” section on page 4-82 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD "172.20.222.225,TID-000,15454" ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.182 RTRV-NE-GEN: Retrieve Network Element General

This command retrieves the general NE attributes.

| Section | RTRV-NE-GEN Description |
|------------------|---|
| Category | System |
| Security | Retrieve |
| Related Messages | ACT-USER INH-MSG-SECU ALW-MSG-ALL INIT-SYS ALW-MSG-DBCHG RTRV-HDR ALW-MSG-SECU RTRV-INV ED-DAT RTRV-NE-IPMAP ED-NE-GEN RTRV-NE-PATH ED-NE-PATH RTRV-NE-SYNCN ED-NE-SYNCN RTRV-NE-WDMANS INH-MSG-ALL RTRV-TOD INH-MSG-DBCHG SET-TOD |

| Section | RTRV-NE-GEN Description |
|----------------|--|
| Input Format | RTRV-NE-GEN:[<TID>]::<CTAG>; |
| Input Example | RTRV-NE-GEN:CISCO::123; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “[IPADDR=<IPADDR>],[IPMASK=<IPMASK>],[DEFRTR=<DEFRTR>], [IIOPPORT=<IIOPPORT>],[NTP=<NTP>],[NAME=<NAME>], [SWVER=<SWVER>],[LOAD=<LOAD>],[PROTSWVER=<PROTSWVER>], [PROTLOAD=<PROTLOAD>],[DEFDESC=<DEFDESC>] [PLATFORM=<PLATFORM>]” ; where:</p> <ul style="list-style-type: none"> • <IPADDR> indicates the node IP address; <IPADDR> is a string and is optional • <IPMASK> indicates the node IP mask; <IPMASK> is a string and is optional • <DEFRTR> indicates the node default router; <DEFRTR> is a string and is optional • <IIOPPORT> indicates the node IIOP port; <IIOPPORT> is an integer and is optional • <NTP> indicates the node's NTP timing source address; <NTP> is a string and is optional • <NAME> is the node name; <NAME> is a string and is optional • <SWVER> is the software version; <SWVER> is a string and is optional • <LOAD> is a string and is optional • <PROTSWVER> is protect software version; <PROTSWVER> is a string and is optional • <PROTLOAD> is a string and is optional • <DEFDESC> is a string and is optional • <PLATFORM> is the NE platform type; <PLATFORM> is a string and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “IPADDR=192.168.100.52,IPMASK=255.255.255.0,DEFRTR=192.168.100.1, IIOPPORT=57970,NTP=192.168.100.52,NAME=“NODENAME”, SWVER=2.01.03,LOAD=02.13-E09A-08.15,PROTSWVER=2.01.02, PROTLOAD=02.12-E09A-09.25,DEFDESC=“NE DEFAULTS FEATURE”, PLATFORM=15454-ANSI” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.183 RTRV-NE-IPMAP: Retrieve Network Element IPMAP

This command retrieves the IP address and node name of the NEs that have the DCC connection with this NE.

**Note**

This command only reports the active DCC link. If there is no active DCC link on the port (or the node), the command will return COMPLD without IPMAP information.

| Section | RTRV-NE-IPMAP Description | |
|------------------|---|---|
| Category | Network | |
| Security | Retrieve | |
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG INH-MSG-SECU | INIT-SYS RTRV-HDR RTRV-INV RTRV-MAP-NETWORK RTRV-NE-GEN RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD SET-TOD |
| Input Format | RTRV-NE-IPMAP:[<TID>]:[<AID>]:<CTAG>; where: <ul style="list-style-type: none"> • <AID> is the port of an NE carrying the DCC connection; <AID> is from the “FACILITY” section on page 4-28 and a null value is equivalent to ALL | |
| Input Example | RTRV-NE-IPMAP:CISCO:FAC-12-1:123; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>:<IPADDR>,<NODENAME>” ; where: <ul style="list-style-type: none"> • <AID> is the port of an NE carrying a DCC connection and is from the “FACILITY” section on page 4-28 • <IPADDR> indicates the NE IP address and is a string • <NODENAME> indicates the NE node name and is a string | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-12-1:172.20.208.225,NODENAME2” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.184 RTRV-NE-PATH: Retrieve Network Element Path

This command retrieves the path-level attributes on an NE.

| Section | RTRV-NE-PATH Description | |
|------------------|---|----------------|
| Category | System | |
| Security | Retrieve | |
| Related Messages | ACT-USER | INH-MSG-SECU |
| | ALW-MSG-ALL | INIT-SYS |
| | ALW-MSG-DBCHG | RTRV-HDR |
| | ALW-MSG-SECU | RTRV-INV |
| | ED-DAT | RTRV-NE-GEN |
| | ED-NE-GEN | RTRV-NE-IPMAP |
| | ED-NE-PATH | RTRV-NE-SYNCN |
| | ED-NE-SYNCN | RTRV-NE-WDMANS |
| | INH-MSG-ALL | RTRV-TOD |
| | INH-MSG-DBCHG | SET-TOD |
| Input Format | RTRV-NE-PATH:[<TID>]::<CTAG>[:::]; | |
| Input Example | RTRV-NE-PATH:::CTAG; | |
| Output Format | SID DATE TIME M CTAG COMPLD “[PDIP=<PDIP>]” ; where: • <PDIP> flag used to indicate whether PDI-P should be generated on the outgoing VT-structured STSs. PDI-P is specified in GR-253 (Issue2 Rev2 1999) CR6-261 (6.2.1.4.1); valid values are shown in the “ON/OFF” section on page 4-76. <PDIP> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “PDIP=Y” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.185 RTRV-NE-SYNCN: Retrieve Network Element Synchronization

This command retrieves the synchronization attributes of the NE.

Notes:

1. Although mixed mode timing is supported in this release, it is not recommended. See the “[Mixed Mode Timing Support](#)” section on page 1-19 for more information.
2. The existing external and line modes have the same functionality in all 3.x releases:
 - External mode: the node derives its timing from the BITS inputs.
 - Line mode: the node derives its timing from the SONET line(s).
 - Mixed mode: the node derives its timing from the BITS input or SONET lines.

| Section | RTRV-NE-SYNCN Description | |
|------------------|---|--|
| Category | Synchronization | |
| Security | Retrieve | |
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-BITS ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN ED-SYNCN INH-MSG-ALL INH-MSG-DBCHG INH-MSG-SECU INIT-SYS OPR-SYNCNSW REPT ALM BITS REPT ALM SYNCN | REPT EVT BITS REPT EVT SYNCN RLS-SYNCNSW RTRV-ALM-BITS RTRV-ALM-SYNCN RTRV-BITS RTRV-COND-BITS RTRV-COND-SYNCN RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-WDMANS RTRV-SYNCN RTRV-TOD SET-TOD |
| Input Format | RTRV-NE-SYNCN:[<TID>]::<CTAG>[:::]; | |
| Input Example | RTRV-NE-SYNCN:CISCO::123; | |
| Output Format | SID DATE TIME M CTAG COMPLD “::[TMMD=<TMMD>],[SSMGEN=<SSMGEN>],[QRES=<QRES>],[RVRTV=<RVRTV>],[RVTM=<RVTM>]” ; where: <ul style="list-style-type: none"> • <TMMD> is a timing mode; valid values are shown in the “TIMING_MODE section on page 4-92, <TMMD> is optional • <SSMGEN> is an SSM generator; valid values are shown in the “SYNC_GENERATION” section on page 4-89, <SSMGEN> is optional • <QRES> is a quality of RES; valid values are shown in the “SYNC_QUALITY_LEVEL” section on page 4-89, <QRES> is optional • <RVRTV> is a revertive mode; valid values are shown in the “ON_OFF” section on page 4-76, <RVRTV> is optional • <RVTM> is a revertive time; valid values are shown in the “REVERTIVE_TIME” section on page 4-84, <RVTM> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “::TMMD=LINE,SSMGEN=GEN1,QRES=ABOVE-PRS,RVRTV=Y,RVTM=8.0” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.186 RTRV-NE-WDMANS: Retrieve NE Wavelength Division Multiplexing Automatic Node Setup

(Cisco ONS 15454 only)

This command retrieves the optical node setup (WDMANS) application ports involved in node setup regulation.

| Section | RTRV-NE-WDMANS Description | |
|------------------|--|--|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG | INH-MSG-SECU INIT-SYS RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-TOD SET-TOD |
| Input Format | RTRV-NE-WDMANS:[<TID>]::<CTAG>; | |
| Input Example | RTRV-NE-WDMANS:PENNGROVE::114; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>,<AIDTYPE>::[REGULATED=<REGULATED>]” ; where: <ul style="list-style-type: none">• <AID> is the port regulated AID from the “ALL” section on page 4-9• <AIDTYPE> is the type of AID of the retrieved port; valid values are shown in the “MOD2” section on page 4-69• <REGULATED> is the status of the port after a node setup regulation that states if it was regulated or not; valid values are shown in the “ON_OFF” section on page 4-76 and <REGULATED> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-16-1-RX,OCH::REGULATED=Y” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.187 RTRV-OCH: Retrieve Optical Channel

(Cisco ONS 15454 only)

This command retrieves the attributes (service parameters) and state of an OCH facility.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.



Note States of primary=OOS and secondary=AINS do not apply to Ethernet mode.

| Section | RTRV-OCH Description | |
|------------------|---|--|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT | OPR-PROTNSW-OCH RLS-LASER-OTS RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-PROTNSW-OCH RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | RTRV-OCH:<TID>:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “CHANNEL” section on page 4-19 and must not be null | |
| Input Example | RTRV-OCH:PENNGROVE:CHAN-6-2:236; | |

| Section | RTRV-OCH Description |
|---------------|--|
| Output Format | <p>SID DATE TIME</p> <p>M CTAG COMPLD</p> <p>“<AID>:,,[<ROLE>],[<STATUS>]:[RDIRN=<RDIRN>, [OPTYPE=<OPTICALPORTTYPE>],[OPWR=<POWER>, [EXPWLEN=<EXPWLEN>],[ACTWLEN=<ACTWLEN>],[ILOSS=<ILOSS>, [VOAMODE=<VOAMODE>],[VOAATTN=<VOAATTN>, [VOAPWR=<VOAPWR>],[VOAREFATTN=<VOAREFATTN>, [VOAREFPWR=<VOAREFPWR>],[REFOPWR=<REFOPWR>, [CALOPWR=<CALOPWR>],[CHPOWER=<CHPOWER>, [NAME=<PORTNAME>],[SFBER=<SFBER>],[SDBER=<SDBER>, [ALSMODE=<ALSMODE>],[ALSRCINT=<ALSRCINT>, [ALSRCPW=<ALSRCPW>],[COMM=<COMM>],[GCCRATE=<GCCRATE>, [DWRAP=<DWRAP>],[FEC=<FEC>],[OSFBER=<OSFBER>, [OSDBER=<OSDBER>],[MACADDR=<MACADDR>, [SYNCMSG=<SYNCMSG>],[SENDDUS=<SENDDUS>, [LSRSTAT=<LSRSTAT>],[SOAK=<SOAK>],[SOAKLEFT=<SOAKLEFT>, [OSPF=<OSPF>]:<PST>,[<SST>]” ;</p> |

| Section | RTRV-OCH Description |
|------------------------------|--|
| Output Format (continued) | <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier and is from the “CHANNEL” section on page 4-19 • <ROLE> identifies an OCH port role (WORK or PROT); valid values are shown in the “SIDE” section on page 4-86 and <ROLE> is optional • <STATUS> the port status; valid values are shown in the “STATUS” section on page 4-86 and <STATUS> is optional • <RDIRN> identifies the ring directionality of the optical channel; valid values are shown in the “RDIRN_MODE” section on page 4-83 and <RDIRN> is optional • <OPTICALPORTTYPE> identifies the optical port type. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. Valid values are shown in the “OPTICAL_PORT_TYPE” section on page 4-77 and <OPTICALPORTTYPE> is optional • <POWER> identifies the optical power measured at this port. It can be input or output power according to port type. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <POWER> is a string and is optional • <EXPWLEN> defines the expected value of wavelength for this port. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. Valid values for <EXPWLEN> are shown in the “OPTICAL_WLEN” section on page 4-78 and <EXPWLEN> is optional • <ACTWLEN> identifies the manufacturing optical wavelength for this port. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. Valid values are shown in the “OPTICAL_WLEN” section on page 4-78 and <ACTWLEN> is optional • <ILOSS> identifies the insertion loss. It applies only to output ports. <ILOSS> is expressed in dBm. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <ILOSS> is a string and is optional • <VOAMODE> identifies the working control mode of the VOA. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. Valid values are shown in the “VOA_CNTR_MODE” section on page 4-97 and <VOAMODE> is optional • <VOAATTN> identifies the transmit power attenuation for the variable optical attenuation (VOA). It is expressed in dBm. The range for MXP_2.5G_10G/TXP_MR_10G cards is -24.0 to +2.0 dBm. <VOAATTN> is a string and is optional |

| Section | RTRV-OCH Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> • <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as result of its attenuation. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <VOAPWR> is a float expressed in dBm, is a string and is optional • <VOAREFATTN> indicates the value of reference attenuation for the VOA. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <VOAREFATTN> is a float expressed in dBm, is a string and is optional • <VOAREFPWR> indicates the value of reference output power that the VOA is going to set as result of its attenuation. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <VOAREFPWR> is a float expressed in dBm, is a string and is optional • <REFOPWR> indicates the value of the calculated optical power expected for the output line which is added to the user-provided calibration value to have the total expected output power. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <REFOPWR> is a float expressed in dBm, is a string and is optional • <CALOPWR> indicates the value of the calibrated optical power expected for the output channel which is provided by the user to add to the calculated value to have the total expected output power. Applicable only to the following cards: optical service channel cards, optical amplifier cards, dispersion compensation units, multiplexor and demultiplexor cards and OADM cards. <CALOPWR> is a float expressed in dBm, is a string and is optional. The default is 0 dBm • <CHPOWER> indicates the value of per channel optical power expected to the OCH DROP port in an optical AD-4C unit; <CHPOWER> is a float expressed in dBm, and is optional. Valid values are shown in the “REVERTIVE_TIME” section on page 4-84 • <PORTNAME> indicates the port name. <PORTNAME> is a string and is optional • <SFBER> identifies the SFBER for the SONET payload; valid values are shown in the “SF_BER” section on page 4-86 • <SDBER> identifies the SDBER for the SONET payload; valid values are shown in the “SD_BER” section on page 4-85 • <ALSMODE> indicates if the Automatic Laser Shutdown is enabled or disabled; valid values are shown in the “ALS_MODE” section on page 4-49 and <ALSMODE> is optional • <ALSRCINT> indicates the ALS recovery interval. Range is 20–300 seconds; <ALSRCINT> is an integer and is optional • <ALSRCPW> indicates the ALS recovery pulse width. The range is 2–100 seconds, in increments of 100ms, e.g. -30.1; <ALSRCPW> is a float and is optional |

| Section | RTRV-OCH Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <COMM> indicates if the GCC or DCC is enabled or disabled. The GCC can be enabled only if the digital wrapper has been enabled for the card. The default is NONE. Valid values are shown in the “COMM_TYPE” section on page 4-54. Rules for an MXP_2.5G_10G/TXP_MR_10G client port are; only the DCC can be provisioned, if the termination mode is not transparent and the payload is SONET. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the DCC can be enabled only if the G.709 is not enabled and if the payload is SONET and the termination mode is not transparent. On an MXP_2.5G_10G/TXP_MR_10G DWDM port, the GCC can be enabled if there is no DCC and the G.709 flag is enabled. <COMM> is optional • <GCCRATE> indicates the data rate of the GCC traffic. Valid values are shown in the “GCCRATE” section on page 4-66. The default is 192Kbps. For MXP_2.5G_10G/TXP_MR_10G cards this applies only to the DWDM port. The 576K option is not supported for this release. <GCCRATE> is optional • <DWRAP> is the G.709 digital wrapper. It is either on or off. The system default is ON. For MXP_2.5G_10G/TXP_MR_10G cards, this applies only to the DWDM port. To enable G.709 there should be no GCC on the DWDM port. To disable G.709 there should be no GCC on the DWDM port. The FEC should be turned to off; valid values are shown in the “ON_OFF” section on page 4-76 and <DWRAP> is optional • <FEC> is the Forward Error Correction. It can be enabled only if the G.709 is turned ON. The system default is ON. For MXP_2.5G_10G/TXP_MR_10G cards this applies only to the DWDM port. The FEC level PM and thresholds apply if the FEC is turned on; valid values are shown in the “ON_OFF” section on page 4-76 and <FEC> is optional • <OSFBER> identifies the SFBER for the OTN level; valid values are shown in the “SF_BER” section on page 4-86 and <OSFBER> is optional • <OSDBER> identifies the SDBER for the OTN level; valid values are shown in the “SD_BER” section on page 4-85 and <OSDBER> is optional • <MACADDR> identifies the MAC address for the 10GE payload; <MACADDR> is a string and is optional • <SYNCMSG> indicates that the facility be enabled to provide the synchronization clock. This does not apply to a TXPD-10G card. This applies to an MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT - All Client ports are available for all timing selections. All Trunk ports are not available. LINE - All ports are available for all-timing selections. Valid values for <SYNCMSG> are shown in the “ON_OFF” section on page 4-76 and <SYNCMSG> is optional • <SENDDUS> indicates that the facility send out a Do not Use for Sync message. This does not apply to a TXPD-10G card. This applies to a MXP_2.5G_10G card, only if the payload is SONET and the card termination mode is as follows: TRANSPARENT - All Client ports are available for all timing selections. All Trunk ports are not available. LINE - All ports are available for all-timing selections. Valid values are shown in the “ON_OFF” section on page 4-76 and <SENDDUS> is optional |

| Section | RTRV-OCH Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> • <LSRSTAT> indicates the laser status. If the laser is shut down it shows DOWN. If it has not been shut down it shows UP. Valid values are shown in the “UP_DOWN” section on page 4-97 and <LSRSTAT> is optional • <SOAK> OOS-AINS to IS transition soak time measured in 15-minute intervals; <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional Rules for <SOAKLEFT> are as follows: <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. • <OSPF> indicates the OSPF discovery (only if the port COMM is DCC or GCC); valid values are shown in the “ON_OFF” section on page 4-76 and <OSPF> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-6-1:,,WORK,ACT:RDIRN=W-E,OPTYPE=DROP,OPWR=10.0, EXPWLEN=1530.33,ACTWLEN=1530.33,ILOSS=1.0,VOAMODE=ATTN, VOAATTN=0.5,VOAPWR=0.0,VOAREFATTN=3.5,VOAREFPWR=5.0, REFOPWR=10.5,CALOPWR=0,CHPOWER=2.0,NAME=“NYPORT”, SFBER=1E-4,SDBER=1E-5,ALSMODE=MAN,ALSRCINT=30, ALSRCPW=40.1,COMM=GCC,GCCRATE=192K,DWRAP=Y,FEC=Y, OSFBER=1E-4,OSDBER=1E-5,MACADDR=00-0E-AA-BB-CC-FF, SYNCMSG=Y,SENDDUS=Y,LSRSTAT=UP,SOAK=52,SOAKLEFT=12-25, OSPF=Y:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.188 RTRV-OMS: Retrieve Optical Multiplex Section

(Cisco ONS 15454 only)

This command retrieves the attributes (service parameters) and state of an OMS facility.

| Section | RTRV-OMS Description |
|----------|----------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-OMS Description |
|------------------|---|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT |
| Input Format | RTRV-OMS:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none"> • <AID> is the AID from the “BAND” section on page 4-18 and must not be null |
| Input Example | RTRV-OMS:PENNGROVE:BAND-6-1-RX:236; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::RDIRN=<RDIRN>,OPTYPE=<OPTICALPORTTYPE>, [OPWR=<POWER>],[EXPBAND=<EXPBAND>],[ACTBAND=<ACTBAND>], [ILOSS=<ILOSS>],[VOAMODE=<VOAMODE>],[VOAATTN=<VOAATTN>], [VOAPWR=<VOAPWR>],[VOAREFATTN=<VOAREFATTN>], [VOAREFPWR=<VOAREFPWR>],[REFOPWR=<REFOPWR>], [CALOPWR=<CALOPWR>],[CHPOWER=<CHPOWER>]:<PST>,[<SST>] ; where: <ul style="list-style-type: none"> • <AID> is an AID from the “BAND” section on page 4-18 • <RDIRN> identifies the ring directionality of the optical line; valid values are shown in the “RDIRN_MODE” section on page 4-83 • <OPTICALPORTTYPE> identifies the optical port type; valid values are shown in the “OPTICAL_PORT_TYPE” section on page 4-77 • <POWER> identifies the optical power measured at this port. It can be the input or output power according to port type. <POWER> is expressed in dBm, is a string and is optional • <EXPBAND> identifies the expected value of band for this port; valid values are shown in the “OPTICAL_BAND” section on page 4-76 and <BAND> is optional • <ACTBAND> identifies the manufacturing optical band (group of four contiguous wavelengths) for this port; valid values are shown in the “OPTICAL_BAND” section on page 4-76 and <ACTBAND> is optional |

| Section | RTRV-OMS Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <ILOSS> identifies the insertion loss. It is applicable to output ports. <ILOSS> is expressed in dBm, is a string and is optional • <VOAMODE> identifies the working control mode of the VOA; valid values are shown in the “VOA_CNTR_MODE” section on page 4-97 and <VOAMODE> is optional • <VOAATTN> indicates the value of calibrated attenuation for the VOA; <VOAATTN> is a float expressed in dBm, is a string and is optional • <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as a result of its attenuation; <VOAPWR> is a float expressed in dBm, is a string and is optional • <VOAREFATTN> indicates the value of reference attenuation for the VOA; <VOAREFATTN> is a float expressed in dBm, is a string and is optional • <VOAREFPWR> indicates the value of reference output power that the VOA is going to sent as a result of its attenuation; <VOAREFPWR> is a float expressed in dBm, is a string and is optional • <REFOPWR> indicates the value of the calculated optical power expected for the output line which is added to the user-provided calibration value to have the total expected output power; <REFOPWR> is a float expressed in dBm, is a string and is optional • <CALOPWR> indicates the value of the calibrated optical power expected for the output line added to the calculated value which equals the total expected output power; <CALOPWR> is a float expressed in dBm, is a string and is optional • <CHPOWER> indicates the value of per channel optical power expected to the OMS port in an optical Mux/Demux unit; <CHPOWER> is a float expressed in dBm, is a string and is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “BAND-6-1-RX::RDIRN=W-E,OPTYPE=ADD,OPWR=10.0, EXPBAND=UNKNOWN,ACTBAND=1530.33_1531.12,ILOSS=1.0, VOAMODE=ATTN,VOAATTN=0.5,VOAPWR=0.0, VOAREFATTN=3.5,VOAREFPWR=5.0,REFOPWR=10.5,CALOPWR=0.5, CHPOWER=2.0:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.189 RTRV-OSC: Retrieve Optical Service Channel

(Cisco ONS 15454 only)

This command retrieves all the OSC (optical service channel) information of the NE.

| Section | RTRV-OSC Description |
|------------------|---|
| Category | DWDM |
| Security | Retrieve |
| Related Messages | DLT-OSC ED-OSC ENT-OSC |
| Input Format | RTRV-OSC:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> identifies the OSC group of the NE. Only ALL or Null or a single “OSC-#” in “AID” is allowed. A null value is equivalent to ALL. <AID> is from the “OSC” section on page 4-30 and must not be null |
| Input Example | RTRV-OSC:PENNGROVE:OSC-1:114; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::[RINGID=<RINGID>],[NODEID=<NODEID>],[EAST=<EAST>],[WEST=<WEST>]” ; where: <ul style="list-style-type: none">• <AID> identifies the OSC group of the NE and is from the “OSC” section on page 4-30• <RINGID> identifies the OSC ring ID of the NE. <RINGID> is a string of up to six characters, valid characters are [A-Z,0-9]. <RINGID> is a string and the default value is “# of aid OSC-#”. <RINGID> is a integer and is optional• <NODEID> identifies the OSC node ID of the NE. It ranges from 0 to 31. <NODEID> is an integer and is optional• <EAST> identifies the east OC3 facility and is the AID from the “FACILITY” section on page 4-28. In this release, only one OC3 for the east direction is supported; <EAST> is optional• <WEST> identifies the east OC3 facility and is the AID from the “FACILITY” section on page 4-28. In this release only one OC3 for the west direction is supported; <WEST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “OSC-1::RINGID=10,NODEID=1,EAST=FAC-8-1,WEST=FAC-10-1” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.190 RTRV-OTS: Retrieve Optical Transport System

(Cisco ONS 15454 only)

This command retrieves the attributes (service parameters) and state of an OTS facility.

| Section | RTRV-OTS Description | |
|--|---|-------------------|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-CLNT | OPR-PROTNST-OCH |
| | DLT-LNK-<MOD2O> | RLS-LASER-OTS |
| | ED-CLNT | RLS-PROTNST-CLNT |
| | ED-DWDM | RLS-PROTNST-OCH |
| | ED-FFP-CLNT | RTRV-CLNT |
| | ED-FFP-OCH | RTRV-DWDM |
| | ED-LNK-<MOD2O> | RTRV-FFP-CLNT |
| | ED-OCH | RTRV-FFP-OCH |
| | ED-OMS | RTRV-LNK-<MOD2O> |
| | ED-OTS | RTRV-OCH |
| | ED-TRC-CLNT | RTRV-OMS |
| | ED-TRC-OCH | RTRV-PROTNST-CLNT |
| | ENT-FFP-CLNT | RTRV-PROTNST-OCH |
| | ENT-LNK-<MOD2O> | RTRV-TRC-CLNT |
| | OPR-LASER-OTS | RTRV-TRC-OCH |
| | OPR-PROTNST-CLNT | |
| Input Format | RTRV-OTS:[<TID>]:<AID>:<CTAG>; | |
| | where: | |
| <ul style="list-style-type: none"> • <AID> is the AID from the “LINE” section on page 4-29 and must not be null | | |
| Input Example | RTRV-OTS:PENNNGROVE:LINE-6-1-RX:236; | |
| Output Format | SID DATE TIME M CTAG COMPLD "<AID>:RDIRN=<RDIRN>,OPTYPE=<OPTICALPORTTYPE>, [OPWR=<POWER>],[ILOSS=<ILOSS>],[VOAMODE=<VOAMODE>], [VOAATTN=<VOAATTN>],[VOAPWR=<VOAPWR>], [VOAREFATTN=<VOAREFATTN>],[VOAREFPWR=<VOAREFPWR>], [LASERST=<LASERST>],[OSRI=<OSRI>],[ALSMODE=<ALSMODE>], [ALSRCINT=<ALSRCINT>],[ALSRCPW=<ALSRCPW>], [AMPLMODE=<AMPLMODE>],[GAIN=<GAIN>],[EXPGAIN=<EXPGAIN>], [REFOPWR=<REFOPWR>],[CALOPWR=<CALOPWR>], [REFTILT=<REFTILT>],[CALTILT=<CALTILT>],[DCULOSS=<DCULOSS>], [AWGST=<AWGST>],[HEATST=<HEATST>]:<PST>,[<SST>] ; | |

| Section | RTRV-OTS Description |
|------------------------------|--|
| Output Format (continued) | <p>where:</p> <ul style="list-style-type: none"> • <AID> is the AID from the “LINE” section on page 4-29 • <RDIRN> identifies the ring directionality of the optical line; valid values are shown in the “RDIRN_MODE” section on page 4-83 • <OPTICALPORTTYPE> identifies the optical port type; valid values are shown in the “OPTICAL_PORT_TYPE” section on page 4-77 • <POWER> identifies the optical power measured at this port. It can be the input or output power according to port type; <POWER> is a string and is optional • <ILOSS> identifies the insertion loss. It applies only to output ports; <ILOSS> is a string and is optional • <VOAMODE> identifies the working control mode of the VOA; valid values are shown in the “VOA_CNTR_MODE” section on page 4-97 and <VOAMODE> is optional • <VOAATTN> indicates the value of calibrated attenuation for the VOA; <VOAATTN> is a float expressed in dBm, is a string and is optional • <VOAPWR> indicates the value of calibrated output power that the VOA is going to set as a result of its attenuation; <VOAPWR> is a float expressed in dBm, is a string and is optional • <VOAREFATTN> indicates the value of reference attenuation for the VOA; <VOAREFATTN> is a float expressed in db, is a string and is optional • <VOAREFPWR> indicates the value of reference output power that the VOA is going to set as a result of its attenuation; <VOAREFPWR> is a float expressed in dBm, a string and is optional • <LASERST> indicates the value of the laser status; valid values are shown in the “LASER_STATUS” section on page 4-67 and <LASERST> is optional • <OSRI> indicates the OSRI enable or disable feature. It is an optional parameter present only on a port where the safety is supported; valid values are shown in the “ON_OFF” section on page 4-76 and <OSRI> is optional • <ALSMODE> indicates if the Automatic Laser Shutdown is enabled or disabled; valid values are shown in the “ALS_MODE” section on page 4-49; <ALSMODE> is optional • <ALSRCINT> indicates the ALS recovery interval. The range is 20–300 seconds; <ALSRCINT> is an integer and is optional • <ALSRCPW> indicates the ALS recovery pulse width. The range is 2–100 seconds, in increments of 100ms, e.g. 30.1; <ALSRCPW> is a string and is optional |

| Section | RTRV-OTS Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> • <AMPLMODE> indicates the optical amplification control mode; valid values are shown in the “AMPL_MODE” section on page 4-50 and <AMPLMODE> is optional • <GAIN> indicates the value of the gain of the amplifier. <GAIN> defaults to 21 dB for pre-amplifier and to 20 dB for booster amplifier. <GAIN> is a string and is optional. • <EXPGAIN> indicates the gain expected value to be reached from an amplifier when the node works in a DWDM access network; <EXPGAIN> is a float expressed in dB, is a string and is optional • <REFOPWR> indicates the value of the calculated optical power expected for the output line which is added to the user-provided calibration value to have the total expected output power; <REFOPWR> is a float expressed in dBm, a string and optional • <CALOPWR> indicates the value of the calibrated optical power expected for the output line added to the calculated value which equals the total expected output power; <CALOPWR> is a float expressed in dBm, is a string and is optional. The default is 0 dBm • <REFTILT> indicates the calculated tilt value to be added with the user-provided calibration value; <REFTILT> is a float expressed in dBm, is a string and is optional • <CALTILT> indicates the amplifier calibration tilt offset to be added to the calculated reference value; <CALTILT> is a float expressed in dBm and is optional. Defaults to 0 dBm • <DCULOSS> indicates the value of insertion loss associated to DCU in between the two stages of a pre-amplifier unit; <DCULOSS> is a float expressed in dBm and is optional • <AWGST> indicates the status assumed by AWG; valid values are shown in the “AWG_STATUS” section on page 4-50 and <AWGST> is optional • <HEATST> indicates the status assumed by the heater; valid values are shown in the “HEATER_STATUS” section on page 4-66 and <HEATST> is optional • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “LINE-6-1-RX:RDIRN=W-E,OPTYPE=IN,OPWR=10.0,ILOSS=1.0, VOAMODE=ATTN,VOAATTN=0.5,VOAPWR=0.0,VOAREFATTN=3.5, VOAREFPWR=5.0,LASERST=APR,OSRI=Y,ALSMODE=Y,ALSRCINT=30, ALSRCPW=40.1,AMPLMODE=GAIN,GAIN=3.0,EXPGAIN=3.0, REFOPWR=10.0,CALOPWR=0.0,REFTILT=3.0,CALTILT=0.0,DCULOSS=1.2, AWGST=WARM-UP,HEATST=ON:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.191 RTRV-PM-<MOD2>: Retrieve Performance (CLNT, DS1, DS3I, EC1, FC, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the values of PM parameters for a specified card type.

<MONTYPE>, <MONLEV>, <MONDAT> and <MONTM> are supported in this release.

<MONLEV> is in the format of LEV-DIRN. Valid values for <DIRN> are shown in the “[DIRN](#)” section on page 4-56.

The format of <MONDAT> is MM-DD, where MM (month of the year) ranges from 1–12 and DD (day of the month) ranges from 1–31.

The format for <MONTM> is HH-MM, where HH (hour of the day) ranges from 0–23 and MM (minute of the hour) ranges from 0–59.

Notes:

1. If there are no errors to report, the response will be COMPLD (completed).
2. If the <TMPPER> is 1-DAY, <MONTM> is not applicable (null), and is treated as null if <MONTM> is not null.
3. A null value for <MONLEV> defaults to 1-UP.
4. A null value for <MONDAT> defaults to the current date (MM-DD).
5. A null value for <MONTM> defaults to the current time (HH-MM).
6. Unless otherwise stated, DS1 cards are the only cards that support the BTH, RCV, and TRMT directions. All other cards only support the RCV direction.
7. After the BLSR switching, the working path is switched out, the traffic goes through the protection path, and the IPPM can be retrieved from the protection STS path.
8. If there is a STS PCA on the protection path, during the BLSR switching, the PCA path is pre-emptive; sending this command on the protection path after BLSR switch, the command returns the PMs off the protection path, not from the PCA path.
9. Some MOD2 entities; for example, OCH, CLNT, and Optical (OCn), support negative MONTYPE values. By default, this command defaults to 0-UP (return MONTYPES where the MONVAL is 0 or higher). To retrieve the negative values, you must issue 0-DN in the MONLEV field.

The rules are as follows: Client port only—Laser and SONET PM’s are applicable and will be displayed. If the card payload is in SONET mode, then SONET PM’s will be displayed, provided the MONLEV criteria is met.

Trunk port Laser PM’s are always available. Laser PM’s are only for Near End. If G.709 is enabled, then the OTN PM’s will be displayed. If G.709 is enabled and FEC is enabled, then the FEC PM’s will be displayed. If the card payload is in SONET mode, then SONET PM’s will be displayed. All PM MONVALUES should pass the MONLEV filter criteria.

10. For DWDM cards, the MONLEV filter criteria will not support a floating point. It will be returned and interpreted as an integer.

| Section | RTRV-PM-<MOD2> Description |
|----------|----------------------------|
| Category | Performance |
| Security | Retrieve |

| Section | RTRV-PM-<MOD2> Description |
|------------------|--|
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> INIT-REG-G1000 REPT PM <MOD2> RTRV-PMMODE-<STS_PATH> |
| Input Format | <p>RTRV-PM-<MOD2>:[<TID>]:<AID>:<CTAG>::[<MONTYPE>], [<MONLEV>],[<LOCN>],[<DIRN>],[<TMPER>],[<DATE>],[<TIME>]; where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier. All the STS, VT1, FACILITY and DS1 AIDs are supported; <AID> is from the “ALL” section on page 4-9 and must not be null • <MONTYPE> indicates the type of the monitored parameter; valid values are shown in the “ALL_MONTYPE” section on page 4-39. A null value is equivalent to ALL • <MONLEV> specifies the discriminating level for the requested monitored parameter. <MONLEV> is in the format of LEVEL-DIRN where LEVEL is the measured value of the monitored parameter (MONVAL) and valid values for DIRN are shown in the “DIRN” section on page 4-56. A null value for <MONLEV> defaults to 1-UP. <MONLEV> is a string • <LOCN> indicates the location; valid values are shown in the “LOCATION” section on page 4-68. A null value defaults to NEND • <DIRN> is the direction of PM relative to the entity identified by the AID. <DIRN> defaults to ALL, which means that the command initializes all the registers irrespective of the PM direction. Valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56. • <TMPER> indicates the accumulation time period for the PM information. If the <TMPER> is 1-DAY, <MONTM> is not applicable (null), and is treated as null if <MONTM> is not null. Valid values for <TMPER> are shown in the “TMPER” section on page 4-93. A null value defaults to 15-MIN • <DATE> is the beginning date of the PM or storage register period specified in <TMPER>. The format of <MONDAT> is MM-DD, where MM (month of year) ranges from 1–12 and DD (day of month) ranges from 1–31. A null value for <MONDAT> defaults to the current date • <TIME> is the beginning time of day of the PM or storage register period specified in <TMPER>. The format for <MONTM> is HH-MM, where HH (hour of day) ranges from 0–23 and MM (minute of hour) ranges from 0–59. A null value for <MONTM> defaults to the current time (HH-MM) |
| Input Example | RTRV-PM-T1:TID:FAC-2-1:123::CVL,10-UP,NEND,BTH,15-MIN,04-11,12-45; |

| Section | RTRV-PM-<MOD2> Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<MONTYPE>,<MONVAL>,[<VLDTY>], [<LOCN>],[<DIRN>],[<TMPPER>],[<MONDAT>],[<MONTM>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “ALL” section on page 4-9 • <AIDTYPE> specifies the type of AID; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <MONTYPE> indicates the type of monitored parameter; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <MONVAL> is the measured value of the monitored parameter and is a string • <VLDTY> is the validity indicator of historical monitoring information; valid values are shown in the “VALIDITY” section on page 4-97, <VLDTY> is optional • <LOCN> indicates the location; valid values are shown in the “LOCATION” section on page 4-68, <LOCN> is optional • <DIRN> is the direction of PM relative to the entity identified by the AID; valid values are shown in the “DIRECTION” section on page 4-56, <DIRN> is optional • <TMPPER> indicates the accumulation time period for the PM information; valid values are shown in the “TMPPER” section on page 4-93, <TMPPER> is optional • <MONDAT> is the beginning date of the PM or storage register period specified in <TMPPER>. The format of <MONDAT> is MM-DD, where MM (month of year) ranges from 1–12 and DD (day of month) ranges from 1–31. <MONDAT> is a string and is optional • <MONTM> is the beginning time of the day of the PM or storage register period specified in <TMPPER>. The format for <MONTM> is HH-MM, where HH (hour of day) ranges from 0–23 and MM (minute of hour) ranges from 0–59. <MONTM> is a string and is optional. |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1,DS1-14:CVL,21,COMPL,NEND,BTN,15-MIN,04-11,12-45” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.192 RTRV-PMMODE-<STS_PATH>: Retrieve Performance Mode of PM Data Collection (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the type of PM mode that has been previously set in the NE. This command can be used to identify whether the PM parameters are Section, Line or Path type, and to identify whether or not the PM are being collected by the NE.

This command returns the categories that are enabled only.

The PM mode and state of an entity is set by using the SET-PMMODE command.

Notes:

1. This near end monitoring of the intermediate-path PM (IPPM) only supports OC-3, OC-12, OC-48, OC-48AS, OC-192, and EC-1 on STS Path.
2. The far end PM data collection is not supported in this release (R4.6).
3. This release of software will support only the Path (P) mode type PM parameters with this command, that is, this command will not be applicable for Line (L) and Section (S) mode types. It should be noted that the PM monitoring for Line (L) and Section (S) are supported by the ONS 15454, and the storing PM data is always performed.
4. This command only returns the categories that are enabled (pmstate is ON), and does not return the categories that are disabled (pmstate is OFF).

| Section | RTRV-PMMODE-<STS_PATH> Description | |
|------------------|---|--|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> INIT-REG-G1000 REPT PM <MOD2> RTRV-PM-<MOD2> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | RTRV-PMMODE-<STS_PATH>:[<TID>]:<SRC>:<CTAG>::<LOCN>; where: <ul style="list-style-type: none"> • <SRC> is the AID from the “CrossConnectId” section on page 4-20; <SRC> must not be null • <LOCN> identifies the location from where the PM mode is being retrieved; valid values are shown in the “LOCATION” section on page 4-68. <LOCN> must not be null | |
| Input Example | RTRV-PMMODE-STS1:CISCO:STS-4-1-2:123::NEND; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<CROSSCONNECTID>:[<LOCN>],<MODETYPE>” ; where: <ul style="list-style-type: none"> • <CROSSCONNECTID> is the AID from the “CrossConnectId” section on page 4-20 • <LOCN> identifies the location from where the PM mode is being retrieved; valid values are shown in the “LOCATION” section on page 4-68. <LOCN> is optional. • <MODETYPE> identifies whether or not the PM mode type is turned on or off; valid values are shown in the “PM_MODE” section on page 4-82 | |

| Section | RTRV-PMMODE-<STS_PATH> Description |
|----------------|--|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-4-1-2:NEND,P” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.193 RTRV-PMSCHED-<MOD2>:Retrieve Performance Monitoring Schedule (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the PM reporting schedule that was set for the NE by the SCHED-PMREPT command.

| Section | RTRV-PMSCHED-<MOD2> Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-ALL RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | RTRV-PMSCHED-<MOD2>:[<TID>];<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “ALL” section on page 4-9; <AID> must not be null | |
| Input Example | RTRV-PMSCHED-OC3:CISCO-NODE:FAC-3-1:123; | |

| Section | RTRV-PMSCHED-<MOD2> Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<REPTINVL>,<REPTDAT>,<REPTTM>, [<NUMINVL>,,[<MONLEV>],<LOCN>,,[<TMPER>],[<TMOFST>], [<INHMODE>]” ; where:</p> <ul style="list-style-type: none"> • <AID> access identifier from the “ALL” section on page 4-9 • <AIDTYPE> type of access identifier; valid values are shown in the “MOD2” section on page 4-69. <AIDTYPE> is optional • <REPTINVL> interval between PM reports; <REPTINVL> is a string • <REPTDAT> date for the next report; <REPTDAT> is a string • <REPTTM> the time of day for the next PM report; <REPTTM> is a string • <NUMINVL> remaining number of intervals over which PM is being reported; <NUMINVL> is an integer and is optional • <MONLEV> discriminating level for the requested monitored parameter; <MONLEV> is a string and is optional • <LOCN> location being performance-monitored and refers to the entity identified by the AID; valid values are shown in the “LOCATION” section on page 4-68 • <TMPER> accumulation time period for the PM information; valid values are shown in the “TMPER” section on page 4-93 and <TMPER> is optional • <TMOFST> is the time offset from the end of the last complete accumulation time period to the beginning of the accumulation period specified by TMPER parameter. <TMOFST> is a string and is optional • <INHMODE> describes whether the reporting of PM data is inhibited (via the INH-PMREPT-ALL command) or is allowed (via the ALW-PMREPT-ALL command); valid values are shown in the “INH_MODE” section on page 4-66 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-3-1,OC3:30-MIN,5-25,14-46,100,,1-UP,NEND,,15-MIN,0-0-15,ALW” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.194 RTRV-PMSCHED-ALL: Retrieve Performance Schedule All

This command retrieves all the PM reporting schedules that were set for the NE by the SCHED-PMREPT command.

| Section | RTRV-PMSCHED-ALL Description |
|----------|------------------------------|
| Category | Performance |
| Security | Retrieve |

| Section | RTRV-PMSCHED-ALL Description | |
|------------------|--|---|
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | RTRV-PMSCHED-ALL:<TID>::<CTAG>; | |
| Input Example | RTRV-PMSCHED-ALL:CISCO-NODE::123; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<REPTINVL>,<REPTDAT>,<REPTTM>, [<NUMINVL>],[<MONLEV>],<LOCN>,,[<TMPER>],<TMOFST>, [<INHMODE>]” ; where: <ul style="list-style-type: none">• <AID> access identifier from the “ALL” section on page 4-9• <AIDTYPE> type of access identifier; valid values are shown in the “MOD2” section on page 4-69. <AIDTYPE> is optional• <REPTINVL> interval between PM reports; <REPTINVL> is a string• <REPTDAT> date for the next report; <REPTDAT> is a string• <REPTTM> the time of day for the next PM report; <REPTTM> is a string• <NUMINVL> remaining number of intervals over which PM is being reported; <NUMINVL> is and integer and is optional• <MONLEV> discriminating level for the requested monitored parameter; <MONLEV> is a string and is optional• <LOCN> location being performance-monitored and refers to the entity identified by the AID; valid values are shown in the “LOCATION” section on page 4-68• <TMPER> accumulation time period for the PM information; valid values are shown in the “TMPER” section on page 4-93 and <TMPER> is optional• <TMOFST> is the time offset from the end of the last complete accumulation time period to the beginning of the accumulation time period specified by the TMPER parameter; <TMOFST> is a string• <INHMODE> describes whether the reporting of PM data is inhibited (via the INH-PMREPT-ALL command) or is allowed (via the ALW-PMREPT-ALL command); valid values are shown in the “INH_MODE” section on page 4-66 | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-3-1,OC3:30-MIN,5-25,14-46,100,,1-UP,NEND,,15-MIN,0-0-15,ALW” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.195 RTRV-POS: Retrieve Packet Over SONET

This command retrieves the back end port information for the ML-series Ethernet cards when the back end port is working in POS mode.



Note Because the back end port is virtual, the Virtual Facility (VFAC) AID should be used when issuing the command.

| Section | RTRV-POS Description | | | | | | | | | | | | | | | | | | | | |
|------------------|---|---------------|-----------------|--------|----------|--------|----------|--------|----------|-------|---------|----------|-----------|-------|------------|-------|-----------|---------------|---------|---------------|---------|
| Category | Ports | | | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ED-<OCN_TYPE></td> <td>RTRV-<OCN_TYPE></td> </tr> <tr> <td>ED-DS1</td> <td>RTRV-DS1</td> </tr> <tr> <td>ED-EC1</td> <td>RTRV-EC1</td> </tr> <tr> <td>ED-FAC</td> <td>RTRV-FAC</td> </tr> <tr> <td>ED-FC</td> <td>RTRV-FC</td> </tr> <tr> <td>ED-G1000</td> <td>RTRV-FSTE</td> </tr> <tr> <td>ED-T1</td> <td>RTRV-G1000</td> </tr> <tr> <td>ED-T3</td> <td>RTRV-GIGE</td> </tr> <tr> <td>RMV-<MOD2_IO></td> <td>RTRV-T1</td> </tr> <tr> <td>RST-<MOD2_IO></td> <td>RTRV-T3</td> </tr> </table> | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | ED-DS1 | RTRV-DS1 | ED-EC1 | RTRV-EC1 | ED-FAC | RTRV-FAC | ED-FC | RTRV-FC | ED-G1000 | RTRV-FSTE | ED-T1 | RTRV-G1000 | ED-T3 | RTRV-GIGE | RMV-<MOD2_IO> | RTRV-T1 | RST-<MOD2_IO> | RTRV-T3 |
| ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | | | | | | | | | | | | | | | | | | | | |
| ED-DS1 | RTRV-DS1 | | | | | | | | | | | | | | | | | | | | |
| ED-EC1 | RTRV-EC1 | | | | | | | | | | | | | | | | | | | | |
| ED-FAC | RTRV-FAC | | | | | | | | | | | | | | | | | | | | |
| ED-FC | RTRV-FC | | | | | | | | | | | | | | | | | | | | |
| ED-G1000 | RTRV-FSTE | | | | | | | | | | | | | | | | | | | | |
| ED-T1 | RTRV-G1000 | | | | | | | | | | | | | | | | | | | | |
| ED-T3 | RTRV-GIGE | | | | | | | | | | | | | | | | | | | | |
| RMV-<MOD2_IO> | RTRV-T1 | | | | | | | | | | | | | | | | | | | | |
| RST-<MOD2_IO> | RTRV-T3 | | | | | | | | | | | | | | | | | | | | |
| Input Format | <p>RTRV-POS:[<TID>]:<AID>:<CTAG>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 and must not be null | | | | | | | | | | | | | | | | | | | | |
| Input Example | RTRV-POS:TID:VFAC-1-1:CTAG; | | | | | | | | | | | | | | | | | | | | |
| Output Format | <p>SID DATE TIME</p> <p>M CTAG COMPLD</p> <p>“<AID>::[ADMINSTATE=<ADMINSTATE>],[LINKSTATE=<LINKSTATE>],[MTU=<MTU>]”</p> <p>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 • <ADMINSTATE> administration speed; valid values are shown in the “UP_DOWN” section on page 4-97 and <ADMINSTATE> is optional • <MTU> maximum transport unit; <MTU> is an integer and is optional | | | | | | | | | | | | | | | | | | | | |
| Output Example | <p>TID-000 1998-06-20 14:30:00</p> <p>M 001 COMPLD</p> <p>“VFAC-1-1::ADMINSTATE=DOWN,LINKSTATE=DOWN,MTU=1500”</p> <p>;</p> | | | | | | | | | | | | | | | | | | | | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | | | | | | | | | | | | | | | | | | | | |

3.4.196 RTRV-PROTNSW-<OCN_TYPE>: Retrieve Protection Switch (OC3, OC12, OC48, OC192)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the switching state of a SONET line specified in the AID.

| Section | RTRV-PROTNSW-<OCN_TYPE> Description | |
|------------------|--|--|
| Category | SONET Line Protection | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-<OCN_TYPE> DLT-FFP-CLNT ED-FFP-<OCN_TYPE> ED-FFP-CLNT ED-FFP-OCH ENT-FFP-<OCN_TYPE> | ENT-FFP-CLNT OPR-PROTNSW-<OCN_TYPE> RLS-PROTNSW-<OCN_TYPE> RTRV-FFP-<OCN_TYPE> RTRV-FFP-CLNT RTRV-FFP-OCH |
| Input Format | RTRV-PROTNSW-<OCN_TYPE>:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none"> <AID> indicates the entity in the NE and is from the “FACILITY” section on page 4-28; <AID> must not be null | |
| Input Example | RTRV-PROTNSW-OC48:CISCO:FAC-5-1:123; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>:<SC>,[<SWITCHTYPE>]” ; where: <ul style="list-style-type: none"> <AID> indicates the entity in the NE and is from the “FACILITY” section on page 4-28 <SC> is the switch operation on the path/AID; valid values are shown in the “SW” section on page 4-88 Valid values for <SWITCHTYPE> are shown in the “SWITCH_TYPE” section on page 4-88: <SWITCHTYPE> is optional | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-5-1:MAN,MANWKSWBK” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.197 RTRV-PROTNSW-<PATH>: Retrieve Protection Switch (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the switching state of a SONET path protection STS or VT path specified in the AID. Because the GR-1400 does not allow the LOCKOUT_OF_WORKING on the path protection WORKING path/AID, the “AID:LOCKOUT,LOCKOUTOFWK” is not presented in this protection switch retrieval result.

| Section | RTRV-PROTNSW-<PATH> Description |
|------------------|--|
| Category | Switch |
| Security | Retrieve |
| Related Messages | OPR-PROTNSW-<PATH> RLS-PROTNSW-<PATH> REPT SW |
| Input Format | RTRV-PROTNSW-<PATH>:[<TID>]:<SRC>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <SRC> is the AID from the “CrossConnectId” section on page 4-20; <SRC> must not be null |
| Input Example | RTRV-PROTNSW-STS1:CISCO:STS-5-1-1:123; |
| Output Format | SID DATE TIME M CTAG COMPLD “<CROSSCONNECTID>:<SC>,[<SWITCHTYPE>]” ; where: <ul style="list-style-type: none">• <CROSSCONNECTID> is the AID from the “CrossConnectId” section on page 4-20• <SC> is the switch operation on the path/AID; valid values are shown in the “SW” section on page 4-88• Valid values for <SWITCHTYPE> are shown in the “SWITCH_TYPE” section on page 4-88: <SWITCHTYPE> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-5-1-1:MAN,MANWKSWBK” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.198 RTRV-PROTNSW-CLNT: Retrieve Protection Switch Client

(Cisco ONS 15454 only)

This command retrieves protection switch status of client facilities.

| Section | RTRV-PROTNSW-CLNT Description |
|----------|-------------------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-PROTNSW-CLNT Description |
|------------------|---|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT |
| Input Format | RTRV-PROTNSW-CLNT:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none"> • <AID> is from the “FACILITY” section on page 4-28 and must not be null |
| Input Example | RTRV-PROTNSW-CLNT:CISCO:FAC-1-1:100; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>:<SC>,[<SWITCHTYPE>]” ; where: <ul style="list-style-type: none"> • <AID> is from the “FACILITY” section on page 4-28 • Valid values for <SC> are shown in the “SW” section on page 4-88 • Valid values for <SWITCHTYPE> are shown in the “SWITCH_TYPE” section on page 4-88 and <SWITCHTYPE> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1:FRCD,MANWKSWBK” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.199 RTRV-PROTNSW-OCH: Retrieve Protection Switch OCH

(Cisco ONS 15454 only)

This command retrieves the protection switch status of a TXPP_MR_2.5G card.

| Section | RTRV-PROTNSW-OCH Description |
|----------|------------------------------|
| Category | DWDM |
| Security | Retrieve |

| Section | RTRV-PROTNSW-OCH Description | |
|------------------|--|--|
| Related Messages | DLT-FFP-CLNT DLT-LNK-<MOD2O> ED-CLNT ED-DWDM ED-FFP-CLNT ED-FFP-OCH ED-LNK-<MOD2O> ED-OCH ED-OMS ED-OTS ED-TRC-CLNT ED-TRC-OCH ENT-FFP-CLNT ENT-LNK-<MOD2O> OPR-LASER-OTS OPR-PROTNSW-CLNT | OPR-PROTNSW-OCH RLS-LASER-OTS RLS-PROTNSW-CLNT RLS-PROTNSW-OCH RTRV-CLNT RTRV-DWDM RTRV-FFP-CLNT RTRV-FFP-OCH RTRV-LNK-<MOD2O> RTRV-OCH RTRV-OMS RTRV-OTS RTRV-PROTNSW-CLNT RTRV-TRC-CLNT RTRV-TRC-OCH |
| Input Format | RTRV-PROTNSW-OCH:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is from the “CHANNEL” section on page 4-19 and must not be null | |
| Input Example | RTRV-PROTNSW-OCH:VA454-22:CHAN-2-2:100; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>:<SW>,<SWTYPE>” ; where: <ul style="list-style-type: none">• <AID> is from the “CHANNEL” section on page 4-19• <SW> indicates the switch operation; valid value are shown in the “SW” section on page 4-88• <SWTYPE> indicates the switch type operation; valid values are shown in the “SWITCH_TYPE” section on page 4-88 | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-2-2:FRCD,FRCDWKSWBK” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.200 RTRV-PTHTRC-<STS_PATH>: Retrieve Path Trace (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the contents of the SONET path trace message that is transported in the J1 byte of the SONET STS Path.

The path trace message is a 64-character string with the last two characters reserved for the terminating CR (carriage return) and the LF (line feed). The message can be an incoming path trace message, an expected incoming path trace message, or an outgoing path trace message which is inserted into the path overhead of the outgoing signal.

The path trace mode has three modes: OFF, MANUAL, and AUTO. The path trace mode defaults to OFF mode. The MANUAL mode performs the comparison of the received string with the user-entered expected string. The AUTO mode performs the comparison of the present received string with an expected string set to a previously received string. If there is a mismatch, the TIM-P alarm is raised. When the path trace mode is in OFF mode, there is no path trace processing, and all the alarm and state conditions are reset.

When the expected string is queried under the OFF path trace mode, the expected string is a copy of the provisioned string or NULL. When an expected string is queried under the MANUAL path trace mode, the expected string is a copy of the user-entered string. When an expected string is queried under the AUTO path trace mode, the expected string is a copy of the acquired received string or NULL if the string has not been acquired.

When the incoming string is queried under the OFF path trace mode, the incoming string is NULL. When an incoming string is queried under the MANUAL or AUTO path trace mode, the incoming string is a copy of the received string or NULL if the string has not been received.

When the transmitted string is queried under the OFF, MANUAL or AUTO path trace mode, the transmitted string is the provisioned transmit string.

Notes:

1. A null value for the <MSGTYPE> defaults to INCTRC.
2. Only the NEND of the <LOCN> value is supported. A null value of the <LOCN> defaults to NEND.
3. Sending a FEND of the <LOCN> with this command, an “unsupported locn value” error message will display.
4. J1 (EXPTRC/INCTRC) is implemented on the DS1/DS1N, DS3E/DS3NE, DS3XM, EC1, OC3, OC48AS and OC192 cards.
5. TRC is supported only on DS1(N), DS3(N)E, and DS3XM cards.
6. The virtual facility AID (VFAC) is only valid on slots holding ML-series cards.
7. After the BLSR switch, the working path is switched out and the traffic goes through the protection path. The J1 trace message can be retrieved from the protection STS path.
8. If there is an STS PCA on the protection path during the BLSR switch, the PCA path is pre-emptive. If this command is sent on the protection path after a BLSR switch, the command will return the trace message off of the protection path and not from the PCA path.

| Section | RTRV-PTHTRC-<STS_PATH> Description |
|------------------|------------------------------------|
| Category | Trace |
| Security | Retrieve |
| Related Messages | — |

| Section | RTRV-PTHTRC-<STS_PATH> Description |
|----------------|--|
| Input Format | <p>RTRV-PTHTRC-<STS_PATH>:[<TID>]:<SRC>:<CTAG>::[<MSGTYPE>][:<LOCN>];</p> <p>where:</p> <ul style="list-style-type: none"> • <SRC> is an access identifier from the “CrossConnectId” section on page 4-20 and must not be null • <MSGTYPE> is the type of trace message to be retrieved; valid values are shown in the “MSGTYPE” section on page 4-74 and a null value defaults to INCTR. A null value is equivalent to ALL. • <LOCN> is the location of the trace message; valid values are shown in the “LOCATION” section on page 4-68. A null value is equivalent to ALL. |
| Input Example | RTRV-PTHTRC-STS1:CISCO:STS-2-1-1:123::EXPTRC:NEND; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<TRACMSG>” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <TRACMSG> is the Path Trace message returned to the requester. The message should be up 64 characters in length. The user is allowed to enter up to 62 characters, the last two characters are reserved for the terminating CR (carriage return) and LF (line feed); <TRACMSG> is a string |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “TRACMSG” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.201 RTRV-STS: Retrieve STS

This command retrieves the attributes associated with an STS path based on the granularity level of NE/SLOT-specific STSs.

Supported AIDs are ALL, SLOT-N (N=1,2,...,ALL), STS-<SLOT>[-<PORT>]-<STS NUMBER>.

The SFBER, SDBER, RVRTV, RVTM, SWPDIP, HOLDOFFTIMER, AND UPSRPTHSTATE parameters only apply to path protection.

The path trace message is a 64 character string including the terminating CR (carriage return) and LF (line feed) that is transported in the J1 byte of the SONET STS Path overhead.

The EXPTRC indicates the contents of the expected incoming path trace are provisioned by the user in the ED-STS_PATH command. The TRC indicates the contents of the outgoing path trace message. The INCTR indicates the contents of the incoming path trace message.

The path trace mode has three modes: OFF, MANUAL, and AUTO. The mode defaults to OFF. The MANUAL mode performs the comparison of the received string with the user entered expected string. The AUTO mode performs the comparison of the present received string with an expected string set to a previously received string. If there is a mismatch, the TIM-P alarm is raised. When the path trace mode is in OFF mode, there is no path trace processing, and all the alarm and state conditions are reset.

When the expected string is queried under the OFF path trace mode, the expected string is a copy of the provisioned string or NULL. When an expected string is queried under the MANUAL path trace mode, the expected string is a copy of the user entered string. When an expected string is queried under the AUTO path trace mode, the expected string is a copy of the acquired received string or NULL if the string has not been acquired.

When the incoming string is queried under the OFF path trace mode, the incoming string is NULL. When an incoming string is queried under the MANUAL or AUTO path trace mode, the incoming string is a copy of the received string or NULL if the string has not been received.

J1 (EXPTRC) is implemented on the DS1/DS1N, DS3E/DS3NE, DS3XM, EC1, OC3, OC48AS and OC192.

TRC and INCTRC are supported on DS1(N), DS3(N)E, and DS3XM cards.

| Section | RTRV-STS Description |
|------------------|--|
| Category | Paths |
| Security | Retrieve |
| Related Messages | RTRV-PTHTRC-<STS_PATH> |
| Input Format | RTRV-STS:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “AidUnionId” section on page 4-15 and must not be null |
| Input Example | RTRV-STS:TID:STS-2-1-1:1; |

| Section | RTRV-STS Description |
|---------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[LEVEL=<LEVEL>],[SFBER=<SFBER>],[SDBER=<SDBER>], [RVRTV=<RVRTV>],[RVTM=<RVTM>],[SWPDIP=<SWPDIP>], [HOLDOFFTIMER=<HOLDOFFTIMER>], [EXPTRC=<EXPTRC>],[TRC=<TRC>],[INCTRC=<INCTRC>], [TRCMODE=<TRCMODE>],[TACC=<TACC>],[TAPTYPE=<TAPTYPE>], [UPSRPTHSTATE=<UPSRPTHSTATE>],[C2=<C2>], [BLSRPTHSTATE=<BLSRPTHSTATE>]:[<PST>],[<SST>]” ; where:<ul style="list-style-type: none"> • <AID> is an access identifier from the “AidUnionId” section on page 4-15 • <LEVEL> indicates the rate of the cross connected channel. Applicable only to STS paths (STS_n); valid values for <LEVEL> are shown in the Table 7-33 on page 7-27, <LEVEL> is optional • <SFBER> identifies the STS path SFBER which only applies to path protection; <SFBER> defaults to 1E-4 and valid values are shown in the Table 7-33 on page 7-27, <SFBER> is optional • <SDBER> identifies the STS path SDBER which only applies to path protection; <SDBER> defaults to 1E-6 and valid values are shown in the Table 7-33 on page 7-27, <SDBER> is optional • <RVRTV> identifies a revertive mode which only applies to path protection and defaults to N (non-revertive mode) when a path protection STSp is created; valid values for <RVRTV> are shown in the Table 7-33 on page 7-27 and <RVRTV> is optional • <RVTM> identifies a revertive time which only applies to path protection and defaults to empty because <RVTM> is N when a path protection STSp is created; valid values for <RVTM> are shown in the Table 7-33 on page 7-27 and <RVTM> is optional </p> |

| Section | RTRV-STS Description |
|------------------------------|--|
| Output Format (continued) | <ul style="list-style-type: none"> Valid values for <SWPDIP> are shown in the Table 7-33 on page 7-27; <SWDIP> is optional <HOLDOFFTIMER> is an integer and is optional <EXPTRC> indicates the expected path trace message (J1) contents. The EXPTRC is any 64 character string, including the terminating CR (carriage return) and LF (line feed); <EXPTRC> defaults to null when a path protection STSp is created. <EXPTRC> is a string and is optional <TRC> identifies the path trace message to be transmitted. The TRC is any combination of 64 characters, including the terminating CR (carriage return) and LF (line feed). The trace byte (J1) continuously transmits a 64 byte string, one byte at a time. A null value defaults to the NE transmitting null characters (Hex 00); <TRC> defaults to null when a path protection STSp is created. <TRC> is a string and is optional <INCTRCC> identifies the incoming path trace message contents. The INCTRCC is any combination of 64 characters; <INCTRCC> defaults to null when path protection STSp is created. <INCTRCC> is a string and is optional <TRCMODE> indicates the path trace mode, and defaults to the OFF mode when a path protection STSp is created; valid values for <TRCMODE> are shown in the Table 7-33 on page 7-27 and <TRCMODE> is optional <TACC> is the AID from the Table 7-33 on page 7-27 and is optional <TAPTYPE> is the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 <UPSRPTHSTATE> indicates whether the given AID is the working or standby path of a path protection cross-connect; valid values are shown in the Table 7-33 on page 7-27 and <UPSRPTHSTATE> is optional <C2> indicates C2 Byte Hex Code and is only applicable to STS-level paths; valid values are shown in the Table 7-33 on page 7-27 and <C2> is optional <BLSRPTHSTATE> indicates the BLSR path state only if the port is on the BLSR. Applicable only to STS-level paths; valid values are shown in the Table 7-33 on page 7-27 and <BLSRPTHSTATE> is optional <PST> primary state; valid values are shown in the Table 7-33 on page 7-27 <SST> secondary state; valid values are shown in the Table 7-33 on page 7-27. <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-2-1-4::LEVEL=STS3C,SFBER=1E-3,SDBER=1E-5,RVRTV=Y, RVTM=1.0,SWPDIP=Y,HOLDOFFTIMER=2000, EXPTRC=“EXPTRCSTRING”,TRC=“TRCSTRING”, INCTRCC=“INCTRCCSTRING”,TRCMODE=AUTO,TACC=8, TAPTYPE=SINGLE,UPSRPTHSTATE=ACT,C2=0X04, BLSRPTHSTATE=PROTPTHACT:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.202 RTRV-SYNCN: Retrieve Synchronization

This command retrieves the synchronization reference list used to determine the sources for the NE's reference clock and the BITS output clock. For each clock, up to three synchronization sources may be specified (e.g. PRIMARY, SECOND, THIRD).

Notes:

1. To retrieve/set the timing mode, SSM message Set or Quality of RES information, use the RTRV-NE-SYNCN and ED-NE-SYNCN commands.
2. The output example shown here is under line timing mode.

| Section | RTRV-SYNCN Description | |
|------------------|--|-----------------|
| Category | Synchronization | |
| Security | Retrieve | |
| Related Messages | ED-BITS | RLS-SYNCNSW |
| | ED-NE-SYNCN | RTRV-ALM-BITS |
| | ED-SYNCN | RTRV-ALM-SYNCN |
| | OPR-SYNCNSW | RTRV-BITS |
| | REPT ALM BITS | RTRV-COND-BITS |
| | REPT ALM SYNCN | RTRV-COND-SYNCN |
| | REPT EVT BITS | RTRV-NE-SYNCN |
| | REPT EVT SYNCN | |
| Input Format | RTRV-SYNCN:[<TID>]:<AID>:<CTAG>[::::]; where: <ul style="list-style-type: none">• <AID> identifies the synchronization reference to retrieve; <AID> is from the “SYNC_REF” section on page 4-34, is listable and must not be null | |
| Input Example | RTRV-SYNCN:BOYES:SYNC-NE:234; | |

| Section | RTRV-SYNCN Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>:<REF>,<REFVAL>,[<PROTECTSTATUS>],[<QREF>],[<STATUS>]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the synchronization reference to be modified and is from the “SYNC_REF” section on page 4-34 • <REF> is the rank of the synchronization reference and is from the “SYNC_SW” section on page 4-34 • <REFVAL> is the value of the synchronization reference and is from the “SYN_SRC” section on page 4-34 • <PROTECTSTATUS> indicates whether the working or protect card (in a protection group) provides timing. This parameter has no significance if the reference source is BITS or INTERNAL and is left blank. Valid values are shown in the “SIDE” section on page 4-86 and <PROTECTSTATUS> is optional • <QREF> is the quality of the reference source; valid values are shown in the “SYNC_CLOCK_REF_QUALITY_LEVEL” section on page 4-89, <QREF> is optional • <STATUS> is the active status of the synchronization source; valid values are shown in the “STATUS” section on page 4-86, <STATUS> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “SYNC-NE:PRI,FAC-1-2,WORK,PRS,ACT” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.203 RTRV-T1: Retrieve T1 Facility

This command retrieves the DS-1 facilities configuration.

(The facilities are on the XTC card for the ONS 15327)

| Section | RTRV-T1 Description | | | | | | | | | | | | | | | | | | |
|------------------|--|---------------|-----------------|--------|----------|--------|----------|-------|---------|----------|-----------|-------|------------|-------|-----------|---------------|----------|---------------|---------|
| Category | Ports | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tr> <td>ED-<OCN_TYPE></td> <td>RTRV-<OCN_TYPE></td> </tr> <tr> <td>ED-DS1</td> <td>RTRV-DS1</td> </tr> <tr> <td>ED-EC1</td> <td>RTRV-EC1</td> </tr> <tr> <td>ED-FC</td> <td>RTRV-FC</td> </tr> <tr> <td>ED-G1000</td> <td>RTRV-FSTE</td> </tr> <tr> <td>ED-T1</td> <td>RTRV-G1000</td> </tr> <tr> <td>ED-T3</td> <td>RTRV-GIGE</td> </tr> <tr> <td>RMV-<MOD2_IO></td> <td>RTRV-POS</td> </tr> <tr> <td>RST-<MOD2_IO></td> <td>RTRV-T3</td> </tr> </table> | ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | ED-DS1 | RTRV-DS1 | ED-EC1 | RTRV-EC1 | ED-FC | RTRV-FC | ED-G1000 | RTRV-FSTE | ED-T1 | RTRV-G1000 | ED-T3 | RTRV-GIGE | RMV-<MOD2_IO> | RTRV-POS | RST-<MOD2_IO> | RTRV-T3 |
| ED-<OCN_TYPE> | RTRV-<OCN_TYPE> | | | | | | | | | | | | | | | | | | |
| ED-DS1 | RTRV-DS1 | | | | | | | | | | | | | | | | | | |
| ED-EC1 | RTRV-EC1 | | | | | | | | | | | | | | | | | | |
| ED-FC | RTRV-FC | | | | | | | | | | | | | | | | | | |
| ED-G1000 | RTRV-FSTE | | | | | | | | | | | | | | | | | | |
| ED-T1 | RTRV-G1000 | | | | | | | | | | | | | | | | | | |
| ED-T3 | RTRV-GIGE | | | | | | | | | | | | | | | | | | |
| RMV-<MOD2_IO> | RTRV-POS | | | | | | | | | | | | | | | | | | |
| RST-<MOD2_IO> | RTRV-T3 | | | | | | | | | | | | | | | | | | |

| Section | RTRV-T1 Description |
|---------------|--|
| Input Format | RTRV-T1:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “FACILITY” section on page 4-28 and must not be null |
| Input Example | RTRV-T1:TID:FAC-2-1:1223; |

| Section | RTRV-T1 Description |
|---------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD</p> <p>“<AID>:[LINECDE=<LINECDE>],[FMT=<FMT>],[LBO=<LBO>, [TAPTYPE=<TAPTYPE>],[SOAK=<SOAK>],[SOAKLEFT=<SOAKLEFT>, [SFBER=<SFBER>],[SDBER=<SDBER>]:<PST>,[<SST>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “FACILITY” section on page 4-28 • <LINECDE> is a line code; valid values are shown in the “LINE_CODE” section on page 4-68, <LINECDE> is optional • <FMT> is a frame format; valid values are shown in the “FRAME_FORMAT” section on page 4-65, <FMT> is optional • <LBO> is a line buildout; valid values are shown in the “LINE_BUILDOUT” section on page 4-67, <LBO> is optional • <TACC> defines the STS as a test access port with a selected unique TAP number. The TAP number ranges from 1–999. When TACC is 0, the TAP is deleted. <TACC> is from the “Conditions” section on page 7-18 and <TACC> is optional • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 and <TAPTYPE> is optional • <SOAK> OOS-AINS to IS transition soak time measured in 15 minute intervals; <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional <p>Rules for <SOAKLEFT> are as follows:</p> <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. <ul style="list-style-type: none"> • <SFBER> identifies the port SFBER and defaults to 1E-4; valid values are shown in the “SF_BER” section on page 4-86 and <SFBER> is optional • <SDBER> identifies the port SDBER and defaults to 1E-7; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 and <SST> is optional |

| Section | RTRV-T1 Description |
|----------------|--|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1::LINECDE=AMI,FMT=ESF,LBO=0-131,TACC=8,TAPTYPE=DUAL, SOAK=52,SOAKLEFT=12-25,SFBER=1E-4,SDBER=1E-7:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.204 RTRV-T3: Retrieve T3

This command retrieves the facility properties of a DS3 and a DS3XM card.

(The facilities are on the XTC card for the ONS 15327)

Notes:

1. CTC can set the FMT attribute of a DS3(N)E line to autoprovision to set the framing based on the framing is coming in. This would result in the FMT field being blanked out for a few seconds blanked forever for a preprovisioned DS3(N)E card on CTC.
2. The autoprovision is not considered a valid DS3 framing type. It is used only to trigger an autosense and subsequent autoprovisioning of a valid DS3 framing type (unframed, M23, C-BIT).
3. TL1 does not have the autoprovision mode according to GR-199. TL1 maps/returns the autoprovision to be unframed.

| Section | RTRV-T3 Description | |
|------------------|--|---|
| Category | Ports | |
| Security | Retrieve | |
| Related Messages | ED-<OCN_TYPE> ED-DS1 ED-EC1 ED-FC ED-G1000 ED-T1 ED-T3 RMV-<MOD2_IO> RST-<MOD2_IO> | RTRV-<OCN_TYPE> RTRV-DS1 RTRV-EC1 RTRV-FC RTRV-FSTE RTRV-G1000 RTRV-GIGE RTRV-POS RTRV-T1 |
| Input Format | RTRV-T3:[<TID>]:<AID>:<CTAG>[:::]; where: <ul style="list-style-type: none"> • <AID> is the access identifier from the “FACILITY” section on page 4-28 and must not be null | |
| Input Example | RTRV-T3:CISCO:FAC-1-2:123; | |

| Section | RTRV-T3 Description |
|---------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD</p> <pre><AID>:[FMT=<FMT>],[LINECDE=<LINECDE>],[LBO=<LBO>, [INHFELPBK=<INHFELPBK>],[TACC=<TAP>],[TAPTYPE=<TAPTYPE>, [SOAK=<SOAK>],[SOAKLEFT=<SOAKLEFT>, [SFBER=<SFBER>],[SDBER=<SDBER>]:<PST>,[<SST>]"</pre> <p>;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “FACILITY” section on page 4-28 • <FMT> is a frame format; valid values are shown in the “DS_LINE_TYPE” section on page 4-57, <FMT> is optional • <LINECDE> is a line code; valid values are shown in the “DS_LINE_CODE” section on page 4-57, <LINECDE> is optional • <LBO> is a line buildout; valid values are shown in the “E_LBO” section on page 4-58, <LBO> is optional • <INHFELPBK> identifies the far end loopback inhibition attribute of the port. If it is Y, the automatic far end loopbacks are inhibited. It is either on or off. The system default is Y. <INHFELPBK> is optional and valid values are shown in the “ON_OFF” section on page 4-76 • <TACC> defines the STS as a test access port with a selected unique TAP number. The TAP number ranges from 1–999. When TACC is 0, the TAP is deleted. <TACC> is from the “Conditions” section on page 7-18 and is optional • <TAPTYPE> indicates the TAP type; valid values are shown in the “TAPTYPE” section on page 4-92 and <TAPTYPE> is optional • <SOAK> OOS-AINS to IS transition soak time measured in 15 minute intervals; <SOAK> is an integer and is optional • <SOAKLEFT> time remaining for the transition from OOS-AINS to IS measured in 1 minute intervals. The format is HH-MM where HH ranges from 00 to 48 and MM ranges from 00 to 59. <SOAKLEFT> is optional <p>Rules for <SOAKLEFT> are as follows:</p> <ul style="list-style-type: none"> – When the port is in OOS, OOS_MT or IS state, the parameter will not be displayed. – When the port is in OOS_AINS, but the countdown has not started due to fault signal the value will be SOAKLEFT=NOT-STARTED. – When the port is in OOS_AINS state and the countdown has started the value will be shown in HH-MM format. <ul style="list-style-type: none"> • <SFBER> identifies the port SFBER and defaults to 1E-4; valid values are shown in the “SF_BER” section on page 4-86 and <SFBER> is optional • <SDBER> identifies the port SDBER and defaults to 1E-7; valid values are shown in the “SD_BER” section on page 4-85 • <PST> primary state; valid values are shown in the “PST” section on page 4-83 • <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |

| Section | RTRV-T3 Description |
|----------------|---|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-2::FMT=C-BIT,LINECDE=B3ZS,LBO=0-225,INHFELPBK=N, TACC=8,TAPTYPE=SINGLE,SOAK=52,SOAKLEFT=12-25, SFBER=1E-4,SDBER=1E-7:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.205 RTRV-TACC: Retrieve Test Access

This command retrieves details associated with a TAP. The TAP is identified by the TAP number. The ALL input TAP value means that the command will return all the configured TACCs in the NE.

| Section | RTRV-TACC Description |
|------------------|---|
| Category | Test Access |
| Security | Retrieve |
| Related Messages | CHG-ACCMD-<MOD_TACC> CONN-TACC-<MOD_TACC> DISC-TACC |
| Input Format | RTRV-TACC:[<TID>]:<TAP>:<CTAG>; where: <ul style="list-style-type: none">• <TAP> indicates the assigned numeric number for the AID being used as a TAP. The TAP number must be an integer with a range of 1–999. The ALL TAP value means that the command will return all the configured TACCs in the NE. <TAP> is a string and must not be null |
| Input Example | RTRV-TACC:CISCO:241:CTAG; |

| Section | RTRV-TACC Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<TAP>:<TACC_AIDA>,<TACC_AIDB>,[<MD>],[<CROSSCONNECTID1>],<CROSSCONNECTID2>” ; where:</p> <ul style="list-style-type: none"> • <TAP> indicates the assigned numeric number for the AID being used as a TAP; <TAP> is a string • <TACC_AIDA> is the A path of the test access point, i.e., the first STS/VT path of the TAP; <TACC_AIDA> is from the “CrossConnectId” section on page 4-20 • <TACC_AIDB> is the B path of the test access point, i.e., the second STS/VT path of the TAP. For a single FAD TAP this path will be empty; <TACC_AIDB> is from the “CrossConnectId” section on page 4-20 • <MD> indicates the test access mode. It identifies the status of the circuit connected to the TACC. Valid values are shown in the “TACC_MODE” section on page 4-91 • <CROSSCONNECTID1> is the E path of the cross-connect; CROSSCONNECTID1> is the AID from the “CrossConnectId” section on page 4-20 and is optional • <CROSSCONNECTID2> is the F path of the cross-connect; <CROSSCONNECTID2> is the AID from the “CrossConnectId” section on page 4-20 and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “241:STS-2-1-1,STS-2-2,MONE,STS-12-1-1,STS-13-1-1” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.206 RTRV-TH-<MOD2>: Retrieve Threshold (CLNT, DS1, DS3I, EC1, FC, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the threshold level of one or more monitored parameters.

Notes:

1. After the BLSR switching, the working path is switched out, the traffic goes through the protection path and the threshold can be retrieved from the protection path.
2. If there is a STS PCA on the protection path, during the BLSR switching, the PCA path is pre-emptive; sending this command on the protection path after BLSR switch, the command returns the PMs off the protection path, not from the PCA path.

The message is issued to retrieve the thresholds for PM and the alarm thresholds. If it is used to retrieve the alarm thresholds, the time-period is not applicable.

The presentation rules are as follows: Client port only—Laser, Alarm and SONET Thresholds are applicable and will be displayed. Laser and alarm thresholds are only for Near End. If the card payload is in SONET mode, then SONET Thresholds will be displayed. The Receiver Temperature Montypes (RXT) are only applicable to the Trunk Port. The Transceiver Voltage Montypes (XCVR) are not applicable, though it is displayed or handled.

Laser and Alarm thresholds are always available. Laser and alarm thresholds are only for Near End. If G.709 is enabled, then the OTN thresholds will be displayed. If G.709 is enabled and FEC is enabled, then the FEC thresholds will be displayed. If the card payload is in SONET mode, then SONET Thresholds will be displayed. The Transceiver Voltage Montypes (XCVR) are not applicable, though it is displayed or handled.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | RTRV-TH-<MOD2> Description | |
|------------------|---|---|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | RTRV-TH-<MOD2>:[<TID>]:<AID>:<CTAG>:: [<MONTYPE>],[<LOCN>],<TMPPER>[::]; where: <ul style="list-style-type: none"> • <AID> is an access identifier from the “ALL” section on page 4-9 and must not be null • <MONTYPE> is the monitored type and defaults to CVL; valid values are shown in the “ALL_MONTYPE” section on page 4-39. A null value is equivalent to ALL. <p>Note <MONTYPE> defaults to: CVL for OCN, EC1 and DSN, ESP for STSp, UASV for VT1, AISSP for DS1 layer of DS3XM. LOCN defaults to NEND. TMPPER defaults to 15 minutes.</p> <ul style="list-style-type: none"> • <LOCN> is the location; valid values are shown in the “LOCATION” section on page 4-68. A null value is equivalent to ALL • <TMPPER> indicates the accumulation time period; valid values are shown in the “TMPPER” section on page 4-93 and <TMPPER> must not be null | |
| Input Example | RTRV-TH-T3:CISCO:FAC-1-3:1234::CVL,NEND,15-MIN; | |

| Section | RTRV-TH-<MOD2> Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,[<AIDTYPE>]:<MONTYPE>,[<LOCN>],,<THLEV>,[<TMPPER>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is from the “ALL” section on page 4-9 • <AIDTYPE> specifies the type of AID; valid values are shown in the “MOD2B” section on page 4-71, <AIDTYPE> is optional • <MONTYPE> indicates the monitored type; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <LOCN> is a location; valid values are shown in the “LOCATION” section on page 4-68, <LOCN> is optional • <THLEV> is the threshold value and is a float; <THLEV> is an integer • <TMPPER> is the accumulation time period for the PM information; valid values are shown in the “TMPPER” section on page 4-93, <TMPPER> is optional |
| Output Example | TID-0001998-06-20 14:30:00 M 001 COMPLD “FAC-1-3,DS3:CVL,NEND,,1,15-MIN” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.207 RTRV-TH-ALL: Retrieve Threshold ALL

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the threshold level of all monitored parameters on the NE.

Notes:

1. After the BLSR switching, the working path is switched out, the traffic goes through the protection path and the threshold can be retrieved from the protection STS path.
2. If there is a STS PCA on the protection path, during the BLSR switching, the PCA path is pre-emptive; sending this command on the protection path after BLSR switch, the command returns the PMs off the protection path, not from the PCA path.
3. Multiple RTRV completion codes will be seen after the execution of this command according to GR-1831-CORE for bulk retrievals. The final completion code after the multiple RTRV codes is COMPLD.
4. Some monitored types are not available for some cards or cross-connect types. In that case, a 0 value will be displayed for the monitored type. This will happen only in the scenario where a user requests the thresholds of a specific monitored parameter on the NE and the monitored type does not apply to that card or cross-connect type. When the user does not filter by monitored type, the applicable thresholds will be retrieved.
5. If the user requests the thresholds of a particular monitored type and if the monitored type is not applicable to some of the entities, DENY will not be returned.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | RTRV-TH-ALL Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Retrieve | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> SET-TH-<MOD2> |
| Input Format | RTRV-TH-ALL:[<TID>]:<AID>::<CTAG>:: [<MONTYPE>],[<LOCATION>],[<TMPER>][::]; where: <ul style="list-style-type: none"> • <MONTYPE> is the monitored type; valid values are shown in the “ALL_MONTYPE” section on page 4-39. A null value defaults to ALL. • <LOCATION> is the location; valid values are shown in the “LOCATION” section on page 4-68. A null value defaults to NEND • <TMPER> indicates the accumulation time period; valid values are shown in the “TMPER” section on page 4-93 and a null value defaults to 15-MIN | |
| Input Example | RTRV-TH-ALL:CHARGERS6::123::CVL,NEND,15-MIN; | |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>,<AIDTYPE>:<MONTYPE>,<LOCATION>,,<THLEV>,<TMPER>” ; where: <ul style="list-style-type: none"> • <AID> is the AID from the “AidUnionId” section on page 4-15 • <AIDTYPE> specifies the type of AID; valid values are shown in the “MOD2B” section on page 4-71 • <MONTYPE> indicates the monitored type; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <LOCATION> is a location; valid values are shown in the “LOCATION” section on page 4-68 • <THLEV> is the threshold value and is a float • <TMPER> is the accumulation time period for the PM information; valid values are shown in the “TMPER” section on page 4-93 | |
| Output Example | TID-0001998-06-20 14:30:00 M 001 COMPLD “FAC-1-1,DS3:CVL,NEND,,1,15-MIN” ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.208 RTRV-TOD: Retrieve Time of Day

This command retrieves the system date and time at the instant when the command was executed. The time returned is in Coordinated Universal Time (UTC).

| Section | RTRV-TOD Description | |
|------------------|---|--|
| Category | System | |
| Security | Retrieve | |
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG | INH-MSG-SECU INIT-SYS RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS SET-TOD |
| Input Format | RTRV-TOD:[<TID>]::<CTAG>; | |
| Input Example | RTRV-TOD:CAZADERO::230;; | |
| Output Format | SID DATE TIME M CTAG COMPLD "<YEAR>,<MONTH>,<DAY>,<HOUR>, <MINUTE>,<SECOND>,<TMTYPE>" ; where: <ul style="list-style-type: none"> • <YEAR> is the current calendar year and is a string • <MONTH> is the month of the year and ranges from 01–12; <MONTH> is a string • <DAY> is the day of the month and ranges from 01–31; <DAY> is a string • <HOUR> is the hour of the day and ranges from 00–23; <HOUR> is a string • <MINUTE> is the minute of the hour and ranges from 00–59; <MINUTE> is a string • <SECOND> is the second of the minute and ranges from 00–59; <SECOND> is a string • <TMTYPE> identifies the time zone and is a string | |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD "1998,05,08,17,01,33,UTC" ; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.209 RTRV-TRC-<OCN_BLSR>: Retrieve Trace Client (OC12, OC192, OC48)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command retrieves the valid J1 expected trace string, retrieved trace string, trace mode, C2 byte, and STS bandwidth of the OCn port only if the port has a BLSR.


Note

This command only applies to OC48AS and OC192 cards.


Note

Sending this command over unsupported BLSR path trace cards, or unequipped cards will result in a J1 Trace Not Supported On This Card (IIAC) error.

| Section | RTRV-TRC-<OCN_BLSR> Description |
|------------------|---|
| Category | BLSR |
| Security | Retrieve |
| Related Messages | DLT-<MOD_RING> EX-SW-<OCN_BLSR> ED-<MOD_RING> RTRV-<MOD_RING> ENT-<MOD_RING> |
| Input Format | RTRV-TRC-<OCN_BLSR>:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is the AID from the “FACILITY” section on page 4-28 and must not be null |
| Input Example | RTRV-TRC-OC48:CISCO:FAC-6-1:238; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::[LEVEL=<LEVEL>],[EXPTRC=<EXPTRC>],[INCTR= <INCTR>],[[TRCMODE=<TRCMODE>],[C2=<C2>]” ; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “STS” section on page 4-31• <LEVEL> indicates the rate of the cross connected channel; valid values are shown in the Table 7-33 on page 7-27. <LEVEL> is optional• <EXPTRC> indicates the expected path trace message (J1) contents. <EXPTRC> is any 64-character string, including the terminating CR (carriage return) and LF (line feed). <EXPTRC> is a string and is optional• <INCTR> indicates the incoming path trace message contents. <INCTR> is any 64-character string, including the CR and LF. <INCTR> is a string and is optional• <TRCMODE> indicates the trace mode; valid values are shown in the “TRCMODE” section on page 4-94 and <TRCMODE> is optional• <C2> indicates C2 Byte Hex Code; valid values are shown in the “C2_BYTE” section on page 4-52 and <C2> is optional |

| Section | RTRV-TRC-<OCN_BLSR> Description |
|----------------|---|
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “STS-6-1-25::LEVEL=STS1,EXPTRC=“EXPTRCSTRING”,INCTRCC=“INCTRCCSTRING”,TRCMODE=AUTO,C2=0X04” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.210 RTRV-TRC-CLNT: Retrieve Trace Client

(Cisco ONS 15454 only)

This command retrieves the SONET J0 Section sent trace string, expected trace string, received trace string, trace mode, and the trace level for the client facility.

The following rules apply: Client port-only J0 Section trace applies.

Depending on the settings, the following filtering applies: If no TRCLEVEL is provided, all TRCLEVELS are reported as applicable. If TRCLEVEL is provided and no MSGTYPE is provided, all applicable MSGTYPES for the given level is displayed. If no MSGTYPE is provided, all MSGTYPES are reported as applicable. If a MSGTYPE is provided without a TRCLEVEL, then the given MSGTYPE for all TRCLEVELS are displayed.

| Section | RTRV-TRC-CLNT Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------|---|--------------|-----------------|-----------------|---------------|---------|------------------|---------|-----------------|-------------|-----------|------------|-----------|----------------|---------------|--------|--------------|--------|------------------|--------|----------|-------------|----------|------------|----------|--------------|-------------------|-----------------|------------------|---------------|--------------|------------------|--|
| Category | DWDM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Security | Retrieve | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Related Messages | <table> <tbody> <tr> <td>DLT-FFF-CLNT</td> <td>OPR-PROTNST-OCH</td> </tr> <tr> <td>DLT-LNK-<MOD2O></td> <td>RLS-LASER-OTS</td> </tr> <tr> <td>ED-CLNT</td> <td>RLS-PROTNST-CLNT</td> </tr> <tr> <td>ED-DWDM</td> <td>RLS-PROTNST-OCH</td> </tr> <tr> <td>ED-FFF-CLNT</td> <td>RTRV-CLNT</td> </tr> <tr> <td>ED-FFF-OCH</td> <td>RTRV-DWDM</td> </tr> <tr> <td>ED-LNK-<MOD2O></td> <td>RTRV-FFF-CLNT</td> </tr> <tr> <td>ED-OCH</td> <td>RTRV-FFF-OCH</td> </tr> <tr> <td>ED-OMS</td> <td>RTRV-LNK-<MOD2O></td> </tr> <tr> <td>ED-OTS</td> <td>RTRV-OCH</td> </tr> <tr> <td>ED-TRC-CLNT</td> <td>RTRV-OMS</td> </tr> <tr> <td>ED-TRC-OCH</td> <td>RTRV-OTS</td> </tr> <tr> <td>ENT-FFF-CLNT</td> <td>RTRV-PROTNST-CLNT</td> </tr> <tr> <td>ENT-LNK-<MOD2O></td> <td>RTRV-PROTNST-OCH</td> </tr> <tr> <td>OPR-LASER-OTS</td> <td>RTRV-TRC-OCH</td> </tr> <tr> <td>OPR-PROTNST-CLNT</td> <td></td> </tr> </tbody> </table> | DLT-FFF-CLNT | OPR-PROTNST-OCH | DLT-LNK-<MOD2O> | RLS-LASER-OTS | ED-CLNT | RLS-PROTNST-CLNT | ED-DWDM | RLS-PROTNST-OCH | ED-FFF-CLNT | RTRV-CLNT | ED-FFF-OCH | RTRV-DWDM | ED-LNK-<MOD2O> | RTRV-FFF-CLNT | ED-OCH | RTRV-FFF-OCH | ED-OMS | RTRV-LNK-<MOD2O> | ED-OTS | RTRV-OCH | ED-TRC-CLNT | RTRV-OMS | ED-TRC-OCH | RTRV-OTS | ENT-FFF-CLNT | RTRV-PROTNST-CLNT | ENT-LNK-<MOD2O> | RTRV-PROTNST-OCH | OPR-LASER-OTS | RTRV-TRC-OCH | OPR-PROTNST-CLNT | |
| DLT-FFF-CLNT | OPR-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DLT-LNK-<MOD2O> | RLS-LASER-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-CLNT | RLS-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-DWDM | RLS-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFF-CLNT | RTRV-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-FFF-OCH | RTRV-DWDM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-LNK-<MOD2O> | RTRV-FFF-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OCH | RTRV-FFF-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OMS | RTRV-LNK-<MOD2O> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-OTS | RTRV-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-CLNT | RTRV-OMS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ED-TRC-OCH | RTRV-OTS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-FFF-CLNT | RTRV-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENT-LNK-<MOD2O> | RTRV-PROTNST-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-LASER-OTS | RTRV-TRC-OCH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPR-PROTNST-CLNT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Section | RTRV-TRC-CLNT Description |
|----------------|---|
| Input Format | <p>RTRV-TRC-CLNT:[<TID>]:<SRC>:<CTAG>::[<MSGTYPE>], [<TRCLEVEL>][::];</p> <p>where:</p> <ul style="list-style-type: none"> • <SRC> is the AID from the “FACILITY” section on page 4-28 and must not be null • <MSGTYPE> is the type of trace message to be retrieved; valid values for are shown in the “MSGTYPE” section on page 4-74. A null value is equivalent to ALL • <TRCLEVEL> is the level at which the trace information is handled; valid values are shown in the “TRCLEVEL” section on page 4-93 and a null value is equivalent to ALL |
| Input Example | RTRV-TRC-CLNT:CISCO:FAC-2-1:100::EXPTRC,J0; |
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>,<MOD>:[TRCLEVEL=<TRCLEVEL>],[EXPTRC=<EXPTRC>], [TRC=<TRC>],[INCTR=*<INCTR>],[TRCMODE=<TRCMODE>], [TRCFORMAT=<TRCFORMAT>]” ;</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is from the “FACILITY” section on page 4-28 • <MOD> indicates the AID type which is CLNT in this instance; valid values are shown in the “MOD2” section on page 4-69 • Valid values for <TRCLEVEL> are shown in the “TRCLEVEL” section on page 4-93 and <TRCLEVEL> is optional • <EXPTRC> is a string and is optional • <TRC> is a string and is optional • <INCTR> is a string and is optional • <TRCMODE> identifies the trace mode; valid values are shown in the “TRCMODE” section on page 4-94 and <TRCMODE> is optional • <TRCFORMAT> identifies the trace format; valid values are shown in the “TRCFORMAT” section on page 4-93 and <TRCFORMAT> is optional |
| Output Example | <p>TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-2-1,CLNT::TRCLEVEL=J0,EXPTRC=\“AAA\”,TRC=\“AAA\”, INCTR=\“AAA\”,TRCMODE=MAN,TRCFORMAT=16-BYTE” ;</p> |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.211 RTRV-TRC-OCH: Retrieve Trace Optical Channel

(Cisco ONS 15454 only)

This command retrieves the sent trace string, expected trace string, received trace string, trace mode, and the trace level for the SONET J0 Section, the TTI PATH and SECTION monitoring levels of the DWDM facility.

The following rules apply: Client port—only the J0 Section trace applies. The J0 Section trace applies only if the card termination mode is not transparent and the payload is SONET/SDH. On the DWDM port the J0 Section trace, the TTI Path, Section trace monitoring point traces are allowed. The J0 Section trace is allowed only if the payload for the card is set to SONET/SDH. The J0 Section trace is allowed only if the card termination mode is not transparent. The TTI Path, Section trace is allowed only if the G.709 (DWRAP) is enabled.

Depending on the settings, the following filtering applies: If no TRCLEVEL is provided, all TRCLEVELS are reported as applicable. If TRCLEVEL is provided and no MSGTYPE is provided, all applicable MSGTYPES for the given level is displayed. If no MSGTYPE is provided, all MSGTYPES are reported as applicable. If a MSGTYPE is provided with out a TRCLEVEL, then the given MSGTYPE for all TRCLEVELS are displayed.

| Section | RTRV-TRC-OCH Description | |
|------------------|--|--------------------|
| Category | DWDM | |
| Security | Retrieve | |
| Related Messages | DLT-FFP-CLNT | OPR-PROTNSTW-OCH |
| | DLT-LNK-<MOD2O> | RLS-LASER-OTS |
| | ED-CLNT | RLS-PROTNSTW-CLNT |
| | ED-DWDM | RLS-PROTNSTW-OCH |
| | ED-FFP-CLNT | RTRV-CLNT |
| | ED-FFP-OCH | RTRV-DWDM |
| | ED-LNK-<MOD2O> | RTRV-FFP-CLNT |
| | ED-OCH | RTRV-FFP-OCH |
| | ED-OMS | RTRV-LNK-<MOD2O> |
| | ED-OTS | RTRV-OCH |
| | ED-TRC-CLNT | RTRV-OMS |
| | ED-TRC-OCH | RTRV-OTS |
| | ENT-FFP-CLNT | RTRV-PROTNSTW-CLNT |
| | ENT-LNK-<MOD2O> | RTRV-PROTNSTW-OCH |
| | OPR-LASER-OTS | RTRV-TRC-CLNT |
| | OPR-PROTNSTW-CLNT | |
| Input Format | RTRV-TRC-OCH:[<TID>]:<SRC>:<CTAG>::[<MSGTYPE>],[<TRCLEVEL>][::]; where: | |
| | <ul style="list-style-type: none"> • <SRC> is the AID from the “CHANNEL” section on page 4-19 and must not be null • <MSGTYPE> is the type of trace message to be retrieved. Valid values for <MSGTYPE> are shown in the “MSGTYPE” section on page 4-74. A null value is equivalent to ALL • <TRCLEVEL> is the level at which the trace information is handled. Valid values are shown in the “TRCLEVEL” section on page 4-93 and a null value is equivalent to ALL | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| Input Example | RTRV-TRC-OCH:CISCO:CHAN-2-2:100::EXPTRC,TTI-PM; | |

| Section | RTRV-TRC-OCH Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<CHANNEL>,<MOD>::[TRCLEVEL=<TRCLEVEL>,<EXPTRC>,[TRC=<TRC>],[INCTRC=<INCTRC>],[TRCMODE=<TRCMODE>],[TRCFORMAT=<TRCFORMAT>]”; where:</p> <ul style="list-style-type: none"> • <CHANNEL> is the AID from the “CHANNEL” section on page 4-19 • <MOD> indicates the AID type; valid values are shown in the “MOD2” section on page 4-69 • Valid values for <TRCLEVEL> are shown in the “TRCLEVEL” section on page 4-93 and <TRCLEVEL> is optional • <EXPTRC> is a string and is optional • <TRC> is a string and is optional • <INCTRC> is a string and is optional • <TRCMODE> indicates the trace mode; valid values are shown in the “TRCMODE” section on page 4-94 and <TRCMODE> is optional • <TRCFORMAT> is the size of the trace message. In SONET mode, only 1 or 16 bytes are applicable for the J0 section trace. The TT1 level trace is only 64 bytes. Valid values are shown in the “TRCFORMAT” section on page 4-93 and <TRCFORMAT> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CHAN-2-2,OCH:::TRCLEVEL=TTI-PM,EXPTRC=\“AAA\”,TRC=\“AAA\”,INCTRC=\“AAA\”,TRCMODE=MAN,TRCFORMAT=64-BYTE”; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.212 RTRV-UCP-CC: Retrieve Unified Control Plane Control Channel

(Cisco ONS 15454 only)

This command creates a UCP IP control channel attributes.

The ALL AID is used for UCP retrieving command input only. A NULL AID in the IPCC’s retrieval command defaults to the ALL AID, which returns all the IPCCs of the node.

Retrieve all of the UCP IPCCs example:

RTRV-UCP-CC:::A;

Notes:

1. If the control channel is not found, a SRQN (Status, Invalid Request) error message is returned.
2. If the IPCC type is ROUTED (CCTYPE=ROUTED), both MTU and CRCMD fields are grayed out.

| Section | RTRV-UCP-CC Description | |
|------------------|---|---------------|
| Category | UCP | |
| Security | Retrieve | |
| Related Messages | DLT-UCP-CC | ENT-UCP-NBR |
| | DLT-UCP-IF | REPT ALM UCP |
| | DLT-UCP-NBR | REPT EVT UCP |
| | ED-UCP-CC | RTRV-ALM-UCP |
| | ED-UCP-IF | RTRV-COND-UCP |
| | ED-UCP-NBR | RTRV-UCP-IF |
| | ED-UCP-NODE | RTRV-UCP-NBR |
| | ENT-UCP-CC | RTRV-UCP-NODE |
| | ENT-UCP-IF | |
| Input Format | RTRV-UCP-CC:[<TID>]:[<AID>]:<CTAG>[::::]; where: <AID> indicates an individual IPCC ID. The ALL AID is used for UCP retrieving command input only. A NULL AID in the IPCCs retrieval command defaults to the ALL AID which returns all the IPCCs of the node. <AID> is from the “ IPCC section on page 4-29 ” and a null value is equivalent to ALL | |
| | RTRV-UCP-CC:CISCO:CC-9:CTAG; | |

| Section | RTRV-UCP-CC Description |
|---------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “[<AID>]:NBRIX=<NBRIX>,CCTYPE=<CCTYPE>,[PORT=<PORT>,<LOCALCCID>=<LOCALCCID>,<LOCALIPCC>=<LOCALIPCC>,<REMOTECCID>=<REMOTECCID>,[<REMOTEIPCC>=<REMOTEIPCC>,<LMPHELLOINT>=<LMPHELLOINT>,<OPERLMPHELLOINT>=<OPERLMPHELLOINT>,<LMPHELLODEADINT>=<LMPHELLODEADINT>,<OPERLMPHELLODEADINT>=<OPERLMPHELLODEADINT>,[<TUNMD>=<TUNMD>],[<MTU>=<MTU>],[<CRCMD>=<CRCMD>]” ; where:<ul style="list-style-type: none"> • <AID> indicates an individual IPCC ID; <AID> is from the “IPCC” section on page 4-29 and <AID> is optional • <NBRIX> indicates the neighbor node index and is an integer • <CCTYPE> indicates the type of the control channel; valid values are shown in the “UCP_IPCC_TYPE” section on page 4-96 • <PORT> indicates the port which the control channel is configured, while the CCTYPE is the type of SDCC; <PORT> is from the “FACILITY” section on page 4-28 and is optional • <LOCALCCID> indicates the local control channel ID and is an integer • <LOCALIPCC> indicates the local IP address of the control channel and is a string • <REMOTECCID> indicates the remote control channel ID and is an integer • <REMOTEIPCC> indicates the remote IP address of the control channel; <REMOTEIPCC> is a string and is optional • <LMPHELLOINT> indicates the provisioned interval between hello messages sent by this node. <LMPHELLOINT> has a range of 1–10 seconds with a default of 5 seconds; <LMPHELLOINT> is an integer • <OPERLMPHELLOINT> indicates the LMP hello interval negotiated between a node and its neighbor and the negotiated value is used during operation. This value is the negotiated, operational value of LMP Hello interval. This value is initialized to the hello Interval at the time of IPCC creation and is updated after the negotiation is done with the neighbor; <OPERLMPHELLOINT> is a float • <LMPHELLODEADINT> indicates the control channel time-out interval (in milliseconds) by the neighbor if the neighbor does not receive the hello message, and defaults to 15 (with the range of 3–30). This interval has to be at least as large as the hello interval and is normally set to 3 times the hello interval. Its range is 3 seconds to 30 seconds with a default of 15 seconds. <LMPHELLODEADINT> is an integer • <OPERLMPHELLODEADINT> indicates the operational value of the LMP interval negotiated between this node and its neighbor. This value is initialized to the helloDeadInterval at the time of IPCC creation and is updated after the negotiation is done with the neighbor; <OPERLMPHELLODEADINT> is a float </p> |

| Section | RTRV-UCP-CC Description |
|------------------------------|---|
| Output Format (continued) | <ul style="list-style-type: none"> • <TUNMD> indicates the IP tunneling option. It defaults to disabled; valid values are shown in the “UCP_CC_TUN_MD” section on page 4-95 and <TUNMD> is optional • <MTU> indicates the MTU size of this control channel; <MTU> is an integer and is optional • <CRCMD> indicates the CRC mode for this control channel. It is applicable to IPCCs in SDCC type; valid values are shown in the “UCP_CRC_MODE” section on page 4-96 and <CRCMD> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CC-9::NBRIX=8,CCTYPE=SDCC,PORT=FAC-2-1,LOCALCCID=9, LOCALIPCC=172.20.209.31,REMOTECCID=2, REMOTEIPCC=172.20.209.15,LMPHELLOINT=10, OPERLMPHELLOINT=10.00,LMPHELLODEADINT=30, OPERLMPHELLODEADINT=30.00,TUNMD=DISABLED, MTU=1500,CRCMD=16-BIT” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.213 RTRV-UCP-IF: Retrieve Unified Control Plane Interface

(Cisco ONS 15454 only)

This command retrieves UCP interface attributes.

The local interface ID (LOCALIFID) is used by LMP/RSVP (Line Management Protocol/Resource reservation Protocol). If zero is passed in as the local Interface ID of the data link, then the node assigns a value for it. If the user specifies a non-zero value, then the node checks if that Interface ID is available and uses it.

If the UCP interface/data link control channel type is SDCC type, the local interface ID should be same as CCID.

Retrieve all of the UCP interfaces example:

RTRV-UCP-IF:::A;



Note If this command is sent twice or inputs invalid data, as SRQN (Status, Invalid Request) error message is returned.

| Section | RTRV-UCP-IF Description |
|----------|-------------------------|
| Category | UCP |
| Security | Retrieve |

| Section | RTRV-UCP-IF Description |
|------------------|---|
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF ENT-UCP-NBR |
| Input Format | RTRV-UCP-IF:[<TID>]:[<AID>]:<CTAG>[::::]; where: <ul style="list-style-type: none"> • <AID> indicates the interface port index of the data link; <AID> is from the “FACILITY” section on page 4-28 and a null value is equivalent to ALL |
| Input Example | RTRV-UCP-IF:CISCO:FAC-2-1:CTAG; |
| Output Format | SID DATE TIME M CTAG COMPLD “[<AID>]:NBRIX=<NBRIX>,CCID=<CCID>,LOCALIFID=<LOCALIFID>, REMOTEIFID=<REMOTEIFID>,TNATYPE=<TNATYPE>, TNAADDR=<TNAADDR>,CORENETWORKID=<CORENETWORKID>” ; |
| Output Example | where: <ul style="list-style-type: none"> • <AID> indicates the interface port index of the data link; <AID> is from the “FACILITY” section on page 4-28 and is optional • <NBRIX> indicates a neighbor within the local node; <NBRIX> is an integer • <CCID> indicates the control channel ID and is an integer • <LOCALIFID> indicates the local interface ID used by LMP/RSVP (line management protocol/resource reservation protocol); <LOCALIFID> is an integer • <REMOTEIFID> indicates the interface ID on the neighbor’s side and is an integer • <TNATYPE> indicates the TNA (transport network administered) type; valid values are shown in the “UCP_TNA_TYPE” section on page 4-96 • <TNAADDR> indicates the TNA IP address and is a string • <CORENETWORKID> indicates the core network ID and is an integer |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.214 RTRV-UCP-NBR: Retrieve Unified Control Plane Neighbor

(Cisco ONS 15454 only)

This command retrieves a UCP neighbor.

The default value of the node name can be overwritten by the TL1 user to a string in a maximum size of 20 characters. If the node name includes non-identified TL1 characters (e.g. space), the text string format with the double quotes is required.

The ALL AID is used for UCP retrieving command input only. A NULL AID in the retrieval command defaults to the ALL AID, which returns all the UCP neighbors of the node.

Retrieve all the UCP neighbors example:

RTRV-UCP-NBR:::A;

| Section | RTRV-UCP-NBR Description | |
|------------------|---|---------------|
| Category | UCP | |
| Security | Retrieve | |
| Related Messages | DLT-UCP-CC | ENT-UCP-NBR |
| | DLT-UCP-IF | REPT ALM UCP |
| | DLT-UCP-NBR | REPT EVT UCP |
| | ED-UCP-CC | RTRV-ALM-UCP |
| | ED-UCP-IF | RTRV-COND-UCP |
| | ED-UCP-NBR | RTRV-UCP-CC |
| | ED-UCP-NODE | RTRV-UCP-IF |
| | ENT-UCP-CC | RTRV-UCP-NODE |
| | ENT-UCP-IF | |
| Input Format | RTRV-UCP-NBR:[<TID>]:[<AID>]:<CTAG>[::::]; where: | |
| | <ul style="list-style-type: none"> • <AID> indicates an individual neighbor AID of the UCP; <AID> is from the “NBR” section on page 4-30 and a null value is equivalent to ALL | |
| Input Example | RTRV-UCP-NBR:CISCO:NBR-8:CTAG; | |

| Section | RTRV-UCP-NBR Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[NBRIX=<NBRIX>],[NODEID=<NODEID>],[NAME=<NAME>,<NDEN=<NDEN>],[HELLOEN=<HELLOEN>],[HELLOINT=<HELLOINT>],[REFREDEN=<REFREDEN>],[NUMRXMTS=<NUMRXMTS>]” ; where:</p> <ul style="list-style-type: none"> • <AID> indicates an individual neighbor AID of the UCP. The ALL AID and NODEID (IP address, e.g. “AAA.BB.CC.D”) are used for UCP retrieving command input only; <AID> is from the “NBR” section on page 4-30 • <NBRIX> indicates a neighbor within the local node; <NBRIX> is an integer and is optional • <NODEID> indicates the neighbor node ID as received in RSVP, LMP messages from that node; <NODEID> is a string and is optional • <NAME> is a string and is optional • <NDEN> indicates if the neighbor discovery is enabled or not for this neighbor; valid values are shown in the “ON_OFF” section on page 4-76 and <NDEN> is optional • <HELLOEN> indicates if the RSVP hello is enabled to this neighbor or not; valid values are shown in the “ON_OFF” section on page 4-76 and <HELLOEN> is optional • <HELLOINT> indicates the interval between hello messages to the neighbor; <HELLOINT> is an integer and is optional • <REFREDEN> indicates if the refresh reduction is enabled or not; valid values are shown in the “ON_OFF” section on page 4-76 and <REFREDEN> is optional • <NUMRXMTS> indicates the maximum number of retransmits of each message; <NUMRXMTS> is not editable, is an integer and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “NBR-8::NBRIX=8,NODEID=192.168.100.52,NAME=NODE-B, NDEN=Y,HELLOEN=Y,HELLOINT=20,REFREDEN=N,NUMRXMTS=3” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.215 RTRV-UCP-NODE: Retrieve Unified Control Plane Node

(Cisco ONS 15454 only)

This command retrieves UCP node level attributes.

The NODEID is the unique number used to identify the local node in LMP, RSVP messages sent to the neighbors. It defaults to the local ethernet interface address (ISA).

The retry initial interval (in seconds) is used for that have been released by the net work side. This interval has a range of 60 seconds (1 minute) to 1800 seconds (30 minutes), with a default value of 180 seconds.

The retry max interval (in seconds) is used for released circuits. The node will back off exponentially from the initial retry interval to this maximum value of 600 seconds (10 minutes).

The restart time is used to be signaled to neighbors. It indicates the time taken by this node (in seconds) to restart. This timer has a range of 1 second to 10 seconds with a default of 5 seconds.

The recovery time is used to be signaled to neighbors. It indicates the time taken by this node (in seconds) to re-sync path, reservation state with a given neighbor. This timer has a range of 300 seconds (5 minutes) to 1800 seconds (30 minutes) and a default value of 600 seconds (10 minutes).

The transmit interval is used to retransmit un-acknowledged messages. This timer has a range of 1 second to 7 seconds with a default value of 1 second.

The refresh interval is used to refresh path, reservation state. This interval has a range of 30 seconds to 4060800 seconds (47 days) with a default value of 30 seconds.

The timeout RESV interval is used to wait for a reservation message in response to a PATH message. This interval has a range of 10–180 seconds with a default value of 60 seconds.

The timeout RESV CONF interval is used to wait for a RESV CONF message in response to a RESV message. This interval has a range of 10–180 seconds with a default value of 60 seconds.

The Source Deletion in progress is a timeout interval while the source is in the progress of cleanly deleting a call. This interval has a range of 10–180 seconds with a default of 60 seconds.

The Destination Deletion progress is a timeout interval while the destination is in the progress of cleanly deleting a call. This interval has a range of 10–180 seconds with a default value of 60 seconds.

Notes:

1. If the retry initial interval is set to zero, it will be interpreted as having the retry procedure disable.
2. The retry maximum interval has to be set to a higher value than the initial retry interval.

| Section | RTRV-UCP-NODE Description | |
|------------------|--|--|
| Category | UCP | |
| Security | Retrieve | |
| Related Messages | DLT-UCP-CC DLT-UCP-IF DLT-UCP-NBR ED-UCP-CC ED-UCP-IF ED-UCP-NBR ED-UCP-NODE ENT-UCP-CC ENT-UCP-IF | ENT-UCP-NBR REPT ALM UCP REPT EVT UCP RTRV-ALM-UCP RTRV-COND-UCP RTRV-UCP-CC RTRV-UCP-IF RTRV-UCP-NBR |
| Input Format | RTRV-UCP-NODE:[<TID>]:<CTAG>[:::]; | |
| Input Example | RTRV-UCP-NODE:CISCO::CTAG; | |

| Section | RTRV-UCP-NODE Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “:::[NODEID=<NODEID>],[INITRETRY=<INITRETRY>], [MAXRETRY=<MAXRETRY>],[RESTARTTM=<RESTARTTM>], [RECOVTM=<RECOVTM>],[RXMTINT=<RXMTINT>], [RFRSHINT=<RFRSHINT>],[RESVTIMEOUT=<RESVTIMEOUT>], [RESVCONF TIMEOUT=<RESVCONF TIMEOUT>], [SOURCEDIP=<SOURCEDIP>],[DESTINATIONDIP=<DESTINATIONDIP>]” ; where:</p> <ul style="list-style-type: none"> • <NODEID> indicates the node IP address, is a string and is optional • <INITRETRY> indicates the circuit retry initial interval (in seconds); <INITRETRY> is an integer and is optional • <MAXRETRY> indicates the circuit retry maximum retry interval (in seconds); <MAXRETRY> is an integer and is optional • <RESTARTTM> indicates the restart time taken by the local node; <RESTARTTM> is an integer and is optional • <RECOVTM> indicates the time taken by the local node to re-synchronize the path, reservation state with a given neighbor; <RECOVTM> is an integer and is optional • <RXMTINT> indicates the interval for re-transmitting un-acknowledged messages; <RXMTINT> is an integer and is optional • <RFRSHINT> indicates the interval for refreshing path, reservation state; <RFRSHINT> is an integer and is optional • <RESVTIMEOUT> indicates the timeout interval for waiting for a reservation message in response to a PATH message; <RESVTIMEOUT> is an integer and is optional • <RESVCONF TIMEOUT> indicates the timeout interval for waiting for a RESV CONF message in response to a RESV message; <RESVCONF TIMEOUT> is an integer and is optional • <SOURCEDIP> indicates the timeout interval of the SourceDip (Source Deletion in Progress) while the source is in the process of cleanly deleting a call; <SOURCEDIP> is an integer and is optional • <DESTINATIONDIP> indicates the timeout interval of the DestinationDip (Destination Deletion in Progress) while the destination is in the process of cleanly deleting a call; <DESTINATIONDIP> is an integer and is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “:::NODEID=192.168.100.52,INITRETRY=180,MAXRETRY=600, RESTARTTM=5,RECOVTM=600,RXMTINT=1,RFRSHINT=30, RESVTIMEOUT=60,RESVCONF TIMEOUT=60, SOURCEDIP=60,DESTINATIONDIP=60” |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.216 RTRV-USER-SECU: Retrieve User Security

This command retrieves the security information of a specified user or list of users. The keyword ALL can be used to obtain a list of all users. For security reasons the password cannot be retrieved.

A Superuser can retrieve any user's security information. A user with MAINT, PROV, or RTRV privileges can only retrieve their own information.


Note

When using the keyword ALL, all users created for the system are displayed. This includes users created outside of the TL1 environment (i.e., userids/passwords greater than 10 characters in length). Although displayed via the RTRV-USER-SECU command, these users will not be able to log into the TL1 environment.

| Section | RTRV-USER-SECU Description | |
|------------------|--|--|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU | ENT-USER-SECU INH-MSG-SECU INH-USER-SECU REPT ALM SECU REPT EVT SECU REPT EVT SESSION RTRV-CMD-SECU RTRV-DFLT-SECU SET-ATTR-SECUDFLT |
| Input Format | RTRV-USER-SECU:[<TID>]:<UID>:<CTAG>; where: <ul style="list-style-type: none"> • <UID> the user ID or the keyword ALL. A non-superuser can only specify their own user ID; <UID> is a string and must not be null | |
| Input Example | RTRV-USER-SECU::CISCO15:1; | |

| Section | RTRV-USER-SECU Description |
|----------------|--|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<UID>;<PRIVILEGE>:LOGGEDIN=<LOGGEDIN>, [NUMSESSIONS=<NUMSESS>],[LOCKEDOUT=<LOCKEDOUT>], [DISABLED=<DISABLED>]” ; where:</p> <ul style="list-style-type: none"> • <UID> the user ID that was retrieved; <UID> is a string • <PRIVILEGE> the privilege of the user; valid values are shown in the “PRIVILEGE” section on page 4-82 • <LOGGEDIN> indicates if the user is logged in to the NE; valid values are shown in the “YES_NO” section on page 4-99 • <NUMSESS> the number of active sessions for that user (the number of times the user is currently logged into the NE). If <LOGGEDIN> is NO, then <NUMSESS> is not present. <NUMSESS> is an integer and is optional • <LOCKEDOUT> indicates if the user is locked out of the NE; valid values are shown in the “YES_NO” section on page 4-99 • <DISABLED> indicates if the user is disabled; valid values are shown in the “YES_NO” section on page 4-99. <DISABLED> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “CISCO15:,SUPER:LOGGEDIN=YES,NUMSESSIONS=1,LOCKEDOUT=NO, DISABLED=NO” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.217 RTRV-VCG: Retrieve Virtual Concatenated Group

(Cisco ONS 15454 only)

This command retrieves all the attributes provisioned for a VCG.

| Section | RTRV-VCG Description |
|------------------|--|
| Category | VCAT |
| Security | Retrieve |
| Related Messages | DLT-VCG ENT-VCG |
| Input Format | <p>RTRV-VCG:[<TID>]:<SRC>:<CTAG>[:::]; where:</p> <ul style="list-style-type: none"> • <SRC> AID to address the VCG from the “FACILITY” section on page 4-28; <SRC> must not be null |
| Input Example | RTRV-VCG:NODE1:FAC-1-1:1234; |

| Section | RTRV-VCG Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<SRC>::TYPE=<TYPE>,TXCOUNT=<TXCOUNT>,CCT=<CCT>,LCAS=<LCAS>” ; where:</p> <ul style="list-style-type: none"> • <SRC> AID to address the VCG from the “FACILITY” section on page 4-28. The ML-series cards use the VFAC AID and the FC-MR4 card uses the FAC AID • <TYPE> type of VCG member cross-connect; valid values are shown in the “MOD_PATH” section on page 4-73 • <TXCOUNT> the number of VCG members in Tx direction; <TXCOUNT> is an integer. For the ML-series cards the only valid value is 2. For the FC-MR4 card the only valid value is 8 • <CCT> cross-connect type for the VCG member cross-connect; valid values are shown in the “CCT” section on page 4-53 • <LCAS> line capacity adjustment scheme mode of the VCG; valid values are shown in the “LCAS” section on page 4-67. The ML-series cards support NONE or SW-LCAS. The FC-MR4 card supports NONE |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “FAC-1-1::TYPE=STS3C,TCOUNT=8,CCT=2WAY,LCAS=LCAS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.218 RTRV-VT: RTRV VT

This command retrieves the attributes associated with a VT path based on the granularity level of NE/Slot-specific VTs.

Supported AIDs are ALL, SLOT-N (N=1,2,...ALL), VT-<SLOT>[-<PORT>]-<STS NUMBER>-<VT GROUP>-<VT NUMBER>.



The RVRTV, RVTM, HOLDOFFTIMER and UPSRPTHSTATE parameters only apply to path protection.

| Section | RTRV-VT Description |
|------------------|---------------------|
| Category | Paths |
| Security | Retrieve |
| Related Messages | — |

| Section | RTRV-VT Description |
|----------------|--|
| Input Format | RTRV-VT:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “AidUnionId” section on page 4-15 and must not be null |
| Input Example | RTRV-VT:TID:VT1-1-1-1-1:1; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::[LEVEL=<LEVEL>],[RVRTV=<RVRTV>],[RVTM=<RVTM>], [HOLDOFFTIMER=<HOLDOFFTIMER>],[TACC=<TACC>], [TAPTYPE=<TAPTYPE>],[UPSRPTHSTATE=<UPSRPTHSTATE>]:[<PST>], [<SST>]” ; where: <ul style="list-style-type: none">• <AID> is an access identifier from the “AidUnionId” section on page 4-15• <LEVEL> indicates the rate of the cross-connected channel. Applicable only to VT1 path; valid values are shown in the “VT_PATH” section on page 4-98• <RVRTV> identifies a revertive mode which only applies to path protection and defaults to N (non-revertive mode) when a path protection is created; valid values for <RVRTV> are shown in the “ON_OFF” section on page 4-76 and <RVRTV> is optional• <RVTM> identifies a revertive time which only applies to path protection and defaults to empty because <RVRTV> is N when a path protection is created; valid values for <RVTM> are shown in the “REVERTIVE_TIME” section on page 4-84 and <RVTM> is optional• <HOLDOFFTIMER> is an integer and is optional• <TACC> test access; <TACC> is an integer and is optional• <TAPTYPE> indicates TAP type; valid values are shown in the “TAPTYPE” section on page 4-92. <TAPTYPE> is optional• <UPSRPTHSTATE> indicates whether a given AID is the working or standby path of a path protection cross-connect; valid values are shown in the “STATUS” section on page 4-86 and <UPSRPTHSTATE> is optional• <PST> primary state; valid values are shown in the “PST” section on page 4-83. <PST> is optional• <SST> secondary state; valid values are shown in the “SST” section on page 4-86. <SST> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “VT1-1-1-1-1::LEVEL=VT1,RVRTV=Y,RVTM=1.0, HOLDOFFTIMER=2000,TACC=8,TAPTYPE=SINGLE, UPSRPTHSTATE=ACT:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.219 RTRV-WDMANS: Retrieve Wavelength Division Multiplexing Automatic Node Setup

(Cisco ONS 15454 only)

This command edits the automatic optical node setup (AONS) application attributes.

| Section | RTRV-WDMANS Description |
|------------------|--|
| Category | DWDM |
| Security | Retrieve |
| Related Messages | ED-WDMANS RTRV-NE-WDMANS |
| Input Format | RTRV-WDMANS:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is the AID from the “WDMANS” section on page 4-36 and must not be null |
| Input Example | RTRV-WDMANS:PENNGROVE:WDMANS-W:114; |

| Section | RTRV-WDMANS Description |
|----------------|---|
| Output Format | <p>SID DATE TIME M CTAG COMPLD “<AID>::[POWER-IN=<POWERIN>],[POWER-OUT=<POWEROUT>,<POWEREXP=<POWEREXP>],[POWER-DROP=<POWERDROP>,<SYS-TYPE=<SYSTYPE>],[APC-ENABLE=<APCENABLE>,<RING-TYPE=<RINGTYPE>]” ; where:</p> <ul style="list-style-type: none"> • <AID> is the WDMANS AID from the “WDMANS” section on page 4-36 • <POWERIN> input power for the OADM section of an OADM optical network element; <POWERIN> is a float expressed in dBm, is a string and is optional • <POWEROUT> is the output power for OADM or Mux/Demux of HUB, TERMINAL or OADM optical NE; <POWEROUT> is a float expressed in dBm, is a string and is optional • <POWEREXP> is the express power for the Mux/Demux section of HUB or TERMINAL optical NE; <POWEREXP> is a float expressed in dBm, is a string and is optional • <POWERDROP> is the drop power for the Mux/Demux section of a HUB or TERMINAL optical NE; <POWERDROP> is a float expressed in dBm, is a string and is optional • <SYSTYPE> is the type of interconnected fiber between two adjacent nodes and the length category between them; valid values are shown in the “SYS_TYPE” section on page 4-90 and <SYSTYPE> is optional • <APCENABLE> is the enable/disable of the automatic power control application; valid values are shown in the “EXT_RING” section on page 4-65 and <APCENABLE> is optional • <RINGTYPE> is the type of the network where the DWDM node is installed; valid values are shown in the “DWDM_RING_TYPE” section on page 4-58 and <RINGTYPE> is optional |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “WDMANS-W::POWER-IN=10.0,POWER-OUT=10.0,POWER-EXP=10.0, POWER-DROP=10.0, SYS-TYPE=SMF-28-SR,APC-ENABLE=Y, RING-TYPE=METRO-CORE” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.220 RTRV-WLEN: Retrieve Wavelength

(Cisco ONS 15454 only)

This command retrieves the wavelength provisioning information.

| Section | RTRV-WLEN Description |
|------------------|--|
| Category | DWDM |
| Security | Retrieve |
| Related Messages | DLT-WLEN ED-WLEN ENT-WLEN |
| Input Format | RTRV-WLEN:[<TID>]:<AID>:<CTAG>; where: <ul style="list-style-type: none">• <AID> is the wavelength AID from the “WLEN” section on page 4-37 and must not be null |
| Input Example | RTRV-WLEN: PENNGROVE: WLEN-W-ADD-1530.33:114; |
| Output Format | SID DATE TIME M CTAG COMPLD “<AID>::[SIZE=<SIZE>]:[<PST>],[<SST>]” ; where: <ul style="list-style-type: none">• <AID> is the wavelength AID from the “WLEN” section on page 4-37• <SIZE> is the circuit size allocates on this wavelength; valid values are shown in the “CIRCUIT_SIZE” section on page 4-53 and <SIZE> is optional• <PST> primary state; valid values are shown in the “PST” section on page 4-83• <SST> secondary state; valid values are shown in the “SST” section on page 4-86 |
| Output Example | TID-000 1998-06-20 14:30:00 M 001 COMPLD “WLEN-W-ADD-1530.33::SIZE=MULTI-RATE:OOS,AINS” ; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.221 SCHED-PMREPT-<MOD2>: Schedule Performance Monitoring Report (CLNT, DS1, DS3I, FC, EC1, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STM1E, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

See Table 4-11 on page 4-5 for supported modifiers by platform.

This command schedules/reschedules the NE to report the performance monitoring data for a line facility or for an STS/VT path periodically, using the automatic REPT PM message. This command can also remove the previously created schedule.

The automatic performance monitoring reporting scheduled by this command is inhibited by default. ALW-PMREPT-ALL can be used to allow the NE to send the performance monitoring report.

INH-PMREPT-ALL can be used to stop the NE from sending the performance monitoring report. The schedules created for the NE can be retrieved by RTRV-PMSCHED command.

The deletion of the schedule for the automatic performance monitoring reporting can be done by issuing SCHED-PMREPT-<MOD2> with the <NUMREPT> parameter equal to zero.

Notes:

1. The current maximum number of schedules allowed to be created for a NE is 1000. If this number of schedules has been created for the NE, an error message “Reach Limits Of MAX Schedules Allowed. Can Not Add More” will be returned if another schedule creation is attempted on the NE. Frequent use of automatic performance monitoring reporting will significantly degrade the performance of the NE.
2. A schedule cannot be created if the card associated with the schedule is not provisioned, or if the cross-connection associated with the schedule has not been created. However, a schedule is allowed to be deleted even if a card is not provisioned, or if the cross-connection has not been created.
3. The number of outstanding performance monitoring reports counter <NUMREPT> will not be decremented, and the scheduled automatic performance monitoring reporting will not start if the card associated with the schedule is not physically plugged into the slot.
4. An expired schedule would not be automatically removed. The SCHED-PMREPT command has to be issued with the <NUMREPT> parameter equal to zero in order to delete the expired schedule.
5. Identical schedules for an NE is not allowed. Two schedules are considered identical if they have the same AID, MOD2 type, performance monitor type, performance monitor level, location, direction and time period.

An error message “Duplicate Schedule” is returned when trying to create a schedule which is a duplicate of a existing schedule. However, if the existing schedule expires (with the parameter <NUMINVL> equal to zero when retrieved by the RTRV-PMSCHED command, i.e., no more performance monitoring reporting sent) the new schedule with the identical parameter will replace the existing schedule.

6. When a electrical or optical card is unprovisioned by the DLT-EQPT command, or a cross-connection is deleted by the DLT-CRS command, the schedules associated with that card or that cross-connection will be removed silently by the NE. This removal prevents another type of card or cross-connection with the same AID to be provisioned on the NE, and prevents the NE from trying to send automatic performance monitoring reports based on the existing schedules.

The card or cross connect can be unprovisioned or deleted through CTC. The schedules associated with that card or that cross-connection will also be removed silently by the NE.

7. When creating schedules on an ONS 15327 XTC card, only schedules against the working XTC card (in Slot 6) are allowed. An error message “Can Not Create Schedule On Protect Card” will be returned if you try to create a schedule on protect XTC card in Slot 5.

| Section | SCHED-PMREPT-<MOD2> Description | |
|------------------|---------------------------------|-----------------------|
| Category | Performance | |
| Security | Maintenance | |
| Related Messages | ALW-PMREPT-ALL | RTRV-PMSCHED-<MOD2> |
| | INH-PMREPT-ALL | RTRV-PMSCHED-ALL |
| | INIT-REG-<MOD2> | RTRV-TH-<MOD2> |
| | REPT PM <MOD2> | RTRV-TH-ALL |
| | RTRV-PM-<MOD2> | SET-PMMODE-<STS_PATH> |
| | RTRV-PMMODE-<STS_PATH> | SET-TH-<MOD2> |

| Section | SCHED-PMREPT-<MOD2> Description |
|--------------|---|
| Input Format | <p>SCHED-PMREPT-<MOD2>:[<TID>]:<SRC>:<CTAG>::[<REPTINVL>], [<REPTSTATM>],[<NUMREPT>],,[<MONLEV>],[<LOCN>],,[<TMPER>], [<TMOFST>];</p> <p>where:</p> <ul style="list-style-type: none"> • <SRC> is from the “ALL” section on page 4-9 • <REPTINVL> specifies how often a performance monitoring report is generated. The format for <REPTINVL> is VAL-UN; valid values for VAL (value) are: <ul style="list-style-type: none"> – 1–31 if UN (units of time) is DAY – 1–24 if UN is HR – 1–1440 if UN is MIN <p>Examples are: 10-DAY, 12-HR, or 100-MIN. A null value for the input would default to 15-MIN. <REPTINVL> is a string</p> <p>Note The minimum time for processing PM schedules is every five minutes. A <REPTINVL> value of less than five minutes will process every five minutes.</p> <ul style="list-style-type: none"> • <REPTSTATM> starting time for the performance monitoring report. The format is HOD-MOH, where HOD (hour of day) ranges from 0–25, and MOH (minute of hour) ranges from 0–59. If the input value of the starting time is smaller than the current time; for example, the input value is 5-30 (5:30 in the morning) and the current time is 10:30, then the reporting will be scheduled to start at 5:30 the next day. A null value defaults to the current time of day; <REPTSTATM> is a string |

| Section | SCED-PMREPT-<MOD2> Description |
|-----------------------------|---|
| Input Format (continued) | <ul style="list-style-type: none"> • <NUMREPT> the number of reports that the schedule is expected to produce. A value of 0 is used to delete an existing identical schedule (see Note 5 above). If <NUMREPT> is null the schedule will be in effect forever until it is deleted. The value of <NUMREPT> will continue to be decremented even though the automatic performance monitoring reporting is inhibited; <NUMREPT> is an integer • <MONLEV> discriminating level for the requested monitored parameter. It applies to all MONTYPE of the scheduled performance monitoring report. The format is LEV-DIRN; valid values for LEV are decimal numbers, and valid values for DIRN are as follows: UP Monitored parameter with values equal to or greater than the value of LEV will be reported. DN Monitored parameter with values equal to or less than the value of LEV will be reported. The null input defaults to 1-UP; <MONLEV> is a string • <LOCN> the location being performance-monitored. The valid value is NEND or FEND. A null input defaults to NEND. FEND is not supported by all MOD2 types; valid values are shown in the “LOCATION” section on page 4-68 • <TMPPER> the accumulation time period. It defaults to 15-MIN; valid values are shown in the “TMPPER” section on page 4-93 • <TMOFST> the time offset from the end of the last complete accumulation time period to the beginning of the accumulation time period specified in TMPPER. The format for is DAY-HR-MIN, where DAYS (days) range from 0-99, HR (hours) range from 0-23, and MIN (minutes) range from 0-59. A null value defaults to 0-0-0. Grouping of this parameter is not supported. <TMOFST> is a String. |
| Input Example | SCED-PMREPT-OC3:NE-NAME:FAC-3-1: 123::60-MIN,15-30,100,,1-UP,NEND,,15-MIN,0-0-15; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.222 SET-ALMTH-<MOD2>: Set Alarm Threshold (CLNT, DS1, DS3I, FC, EC1, G1000, OC12, OC192, OC3, OC48, OCH, OMS, OTS, STM1E, STS1, STS12C, STS192C, STS24C, STS3C, STS48C, STS6C, STS9C, T1, T3, VT1, VT2)

(Cisco ONS 15454 only)

This command sets the alarm thresholds on the following cards/ports/channels: MXP_2.5G_10G/TXP_MR_10G, optical service channel, optical amplifier, dispersion compensation units, multiplex/demultiplex and OADM.

The only applicable MOD2 values are CLNT/OCH/OMS/OTS.

| Section | SET-ALMTH-<MOD2> Description |
|------------------|---|
| Category | DWDM |
| Security | Provisioning |
| Related Messages | RTRV-ALMTH-<MOD2> |

| Section | SET-ALMTH-<MOD2> Description |
|---------------|--|
| Input Format | <p>SET-ALMTH-<MOD2>:[<TID>]:<AID>:<CTAG>::<CONDTYPE>,<THLEV>[,,,];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is from the “ALL” section on page 4-9 • <CONDTYPE> is the alarm threshold montype; valid values are shown in the “ALM_THR” section on page 4-48 • <THLEV> is the threshold value and is a float |
| Input Example | SET-ALMTH-<MOD2>::FAC-1-1:1::OPT-LOW,10; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.223 SET-ALMTH-EQPT: Set Alarm Equipment

(Cisco ONS 15454 only)

This command sets the alarm thresholds to manage the power level monitoring on an NE.

| Section | SET-ALMTH-EQPT Description | |
|------------------|---|--|
| Category | Equipment | |
| Security | Provisioning | |
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT REPT | ALM EQPT REPT EVT EQPT RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SW-DX-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | <p>SET-ALMTH-EQPT:[<TID>]::<CTAG>::<ALMTHTYPE>,<THLEV>[,,,];</p> <p>where:</p> <ul style="list-style-type: none"> • Valid values for <ALMTHTYPE> are shown in the “ALM_THR” section on page 4-48 • <THLEV> is a float | |
| Input Example | SET-ALMTH-EQPT::1::BATV-HIGH,-53.5; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.224 SET-ATTR-CONT: Set Attribute Control

This command sets the attributes associated with an external control. The attributes are used when an external control is operated or released. To send the attributes, use the RTRV-ATTR-CONT command.

Notes:

1. If the <CONNTYPE> parameter is not specified, the control specified by <AID> is unprovisioned.

2. A control should be unprovisioned before it is reprovisioned to another type of control.

| Section | SET-ATTR-CONT Description | |
|---------------------|--|---------------------|
| Category | Environment | |
| Security | Provisioning | |
| Related Messages | OPR-ACO-ALL | RLS-EXT-CONT |
| | OPR-EXT-CONT | RTRV-ALM-<MOD2ALM> |
| | REPT ALM <MOD2ALM> | RTRV-ALM-ALL |
| | REPT ALM BITS | RTRV-ALM-BITS |
| | REPT ALM COM | RTRV-ALM-ENV |
| | REPT ALM ENV | RTRV-ALM-EQPT |
| | REPT ALM EQPT | RTRV-ALM-SYNCH |
| | REPT ALM SECU | RTRV-ALM-UCP |
| | REPT ALM SYNCN | RTRV-ATTR-CONT |
| | REPT ALM UCP | RTRV-ATTR-ENV |
| | REPT EVT <MOD2ALM> | RTRV-COND-<MOD2ALM> |
| | REPT EVT BITS | RTRV-COND-ALL |
| | REPT EVT COM | RTRV-COND-BITS |
| | REPT EVT ENV | RTRV-COND-ENV |
| | REPT EVT EQPT | RTRV-COND-EQPT |
| | REPT EVT FXFR | RTRV-COND-SYNCH |
| | REPT EVT IOSCFG | RTRV-COND-UCP |
| | REPT EVT SECU | RTRV-EXT-CONT |
| | REPT EVT SESSION | SET-ATTR-ENV |
| | REPT EVT SYNCN | SET-ATTR-SECUDFLT |
| | REPT EVT UCP | |
| Input Format | SET-ATTR-CONT:[<TID>]:<AID>:<CTAG>[::<CONTTYPE>]; where: <ul style="list-style-type: none">• <AID> identifies the external control for which attributes are being retrieved and is from the “ENV” section on page 4-26• <CONTTYPE> is the type of control for which the attribute is being retrieved; valid values are shown in the “CONTTYPE” section on page 4-55. The default value is MISC | |
| Input Example | SET-ATTR-CONT:CISCO:ENV-OUT-1:123::AIRCOND; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.225 SET-ATTR-ENV: Set Attribute Environment

This command sets the attributes associated with an external control.

Notes:

1. If the <NTFCNCDE>, <ALMTYPE>, and <ALMMSG> parameters are omitted, the environmental alarm specified by <AID> is unprovisioned.
2. An alarm should be unprovisioned and you should wait for any raised alarm to clear before reprovisioning the alarm to another alarm type.

| Section | SET-ATTR-ENV Description | |
|------------------|---|---|
| Category | Environment | |
| Security | Provisioning | |
| Related Messages | OPR-ACO-ALL OPR-EXT-CONT REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SECU REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP | RLS-EXT-CONT RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP RTRV-EXT-CONT SET-ATTR-CONT SET-ATTR-SECUDFLT |
| Input Format | <p>SET-ATTR-ENV:[<TID>]:<AID>:<CTAG>::[<NTFCNCDE>], [<ALMTYPE>],[<ALMMSG>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is an access identifier from the “ENV” section on page 4-26 and must not be null • <NTFCNCDE> is a notification code; valid values are shown in the “NOTIF_CODE” section on page 4-75. <NTFCNCDE> must not be null • <ALMTYPE> is an alarm type for the environmental alarm; valid values are shown in the “ENV_ALM” section on page 4-58. <ALMTYPE> must not be null • <ALMMSG> is an alarm message and is a string. <ALMMSG> must not be null | |
| Input Example | SET-ATTR-ENV:CISCO:ENV-IN-1:123::MJ,OPENDR,\“OPEN DOOR\” | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.226 SET-ATTR-SECUDFLT: Set Attribute Security Default

This command sets the system-wide default values associated with several security parameters.

The following parameters are set on a system-wide basis for all users and all privilege levels: MXINV, DURAL, UOUT, PFRCD, POLD, PINT, and LOGIN. The PRIVLVL keyword cannot be used to set these parameters for a specific privilege level.

The following parameters are set on a privilege-level basis: PAGE, PCND, and TMOUT. If any of these values are specified, the PRIVLVL keyword must also be present. If none of these parameters are specified, the PRIVLVL keyword cannot be used.



Note Password aging can only be enabled/disabled for all privilege levels. The PRIVLVL keyword cannot be used with PAGE=0 to disable a specific user privilege level.

When system-level and privilege-level keywords are combined in the same command, system-level parameters are still set for all privilege levels, regardless of the value specified by PRIVLVL. Privilege-level parameters are only set for the privilege level specified by PRIVLVL.



Note If PAGE and PINT both have values greater than 0, PINT must be less than PAGE.

The order of keywords is not restricted. Commas are only needed to separate keywords. If no keywords are specified, all parameters are left as is.

| Section | SET-ATTR-SECUDFLT Description | |
|------------------|---|--|
| Category | Security | |
| Security | Superuser | |
| Related Messages | ACT-USER ALW-MSG-SECU ALW-USER-SECU CANC CANC-USER CANC-USER-SECU DLT-USER-SECU ED-CMD-SECU ED-PID ED-USER-SECU ENT-USER-SECU INH-MSG-SECU INH-USER-SECU REPT ALM <MOD2ALM> REPT ALM BITS REPT ALM COM REPT ALM ENV REPT ALM EQPT REPT ALM SYNCN REPT ALM UCP REPT EVT <MOD2ALM> REPT EVT BITS REPT EVT COM REPT EVT ENV REPT EVT EQPT REPT EVT FXFR | REPT EVT IOSCFG REPT EVT SECU REPT EVT SESSION REPT EVT SYNCN REPT EVT UCP RTRV-ALM-<MOD2ALM> RTRV-ALM-ALL RTRV-ALM-BITS RTRV-ALM-ENV RTRV-ALM-EQPT RTRV-ALM-SYNCN RTRV-ALM-UCP RTRV-ATTR-CONT RTRV-ATTR-ENV RTRV-CMD-SECU RTRV-COND-<MOD2ALM> RTRV-COND-ALL RTRV-COND-BITS RTRV-COND-ENV RTRV-COND-EQPT RTRV-COND-SYNCN RTRV-COND-UCP RTRV-DFLT-SECU RTRV-USER-SECU SET-ATTR-CONT SET-ATTR-ENV |

| Section | SET-ATTR-SECUDFLT Description |
|---------------|---|
| Input Format | <p>SET-ATTR-SECUDFLT:[<TID>]::<CTAG>::[PAGE=<PAGE>],[PCND=<PCND>], [MXINV=<MXINV>],[DURAL=<DURAL>],[TMOUT=<TMOUT>], [UOUT=<UOUT>],[PFRCD=<PFRCD>],[POLD=<POLD>],[PINT=<PINT>], [LOGIN=<LOGIN>],[PRIVLVL=<UAP>];</p> <p>where:</p> <ul style="list-style-type: none"> • <PAGE> the password aging interval. It is the number of days left before a user is prompted to change their password. 0 indicates the policy is turned off; <PAGE> is an integer • <PCND> the number of days a password can be used before a new one is mandatory (i.e., the warning period); <PCND> is an integer • <MXINV> the maximum number of consecutive and invalid session setup attempts allowed to occur before an intrusion attempt is suspected (i.e., “Failed Logins Before Lockout” from CTC). 0 indicates the policy is turned off; <MXINV> is an integer • <DURAL> time interval (in seconds) during which a userid is locked out when an intrusion attempt is suspected (i.e., the “Lockout Duration” from CTC). If the user is locked out until unlocked by a superuser, <DURAL>=INFINITE; <DURAL> is a string • <TMOUT> an interval (in minutes) after which a session is terminated if no messages are exchanged between the user and the NE; <TMOUT> is an integer • <UOUT> the number of days a userid is allowed to exist, if it has never been used, before it must be suspended. If a userid has not been used in UOUT days, the user will be forced to change his password (or logout) at the next login. No other command is allowed until the password has been changed; <UOUT> is an integer • <PFRCD> indicates a password change is required when a new user establishes a session to the NE for the first time (i.e., “Require password change on 1st login” from CTC); valid values are shown in the “YES_NO” section on page 4-99 • <POLD> the number of prior passwords that cannot be reused (i.e., “Prevent reusing last X passwords” from CTC); <POLD> is an integer • <PINT> the number of days that must pass before a password can be changed. If PINT=0, the policy is not enabled; <PINT> is an integer • <LOGIN> the number of times a user can log into an NE. <LOGIN> is either SINGLE or MULTIPLE. If <LOGIN> is SINGLE, a user can only log into an NE one time with any given userid, regardless of method of login (i.e., CTC, TL1); valid values are shown in the “USER_LOGINS” section on page 4-97 • <UAP> user access privilege; valid values are shown in the “PRIVILEGE” section on page 4-82 |
| Input Example | SET-ATTR-SECUDFLT:CISCO::123::PAGE=45,PCND=5,MXINV=5,DURAL=30, TMOUT=0,UOUT=20,PFRCD=NO,POLD=5,PINT=20,LOGIN=MULTIPLE, PRIVLVL=RTRV; |
| Errors | Errors are listed in Table 7-33 on page 7-27 . |

3.4.227 SET-PMMODE-<STS_PATH>: Set Performance Mode of PM Data Collection (STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command sets the mode and turns the PM data collection mode on or off. The Cisco ONS 15454 is capable of collecting and storing section, line and path PM data.

The PM mode and state of an entity are retrieved by using the RTRV-PMMODE command.

Notes:

1. The near end monitoring of the intermediate-path PM (IPPM) only supports OC-3, OC-12, OC-48, OC-48AS, OC-192, and EC-1 on STS Path.
2. The far end PM data collection is not supported for the ONS 15454 in this release.
3. This release of software will support only the Path (P) mode type PM parameters with this command, that is, this command is not applicable for Line (L) and Section (S) mode types.

The PM monitoring for Line (L) and Section (S) are supported by the ONS 15454, and the storing PM data is always performed.

| Section | SET-PMMODE-<STS_PATH> Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Provisioning | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-TH-<MOD2> |
| Input Format | SET-PMMODE-<STS_PATH>:[<TID>]:<SRC>: <CTAG>::<LOCN>,<MODETYPE>,[<PMSTATE>]; where: <ul style="list-style-type: none"> • <SRC> is the AID from the “CrossConnectId” section on page 4-20 • <LOCN> identifies the location to which the PM mode is to be set and only supports near end PM data collection; valid values are shown in the “LOCATION” section on page 4-68 • <MODETYPE> identifies the type of PM parameters; only the Path (P) PM parameter is supported and valid values are shown in the “PM_MODE” section on page 4-82 • <PMSTATE> directs the named PM mode type to turn On or Off and a null value defaults to On; valid values are shown in the “PM_STATE” section on page 4-82 | |
| Input Example | SET-PMMODE-STS1:CISCO:STS-4-1-2:123::NEND,P,ON; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.228 SET-TH-<MOD2>: Set Threshold (CLNT, DS1, DS3I, EC1, FC, G1000, OC3, OC12, OC48, OC192, OCH, OMS, OTS, STS1, STS3C, STS6C, STS9C, STS12C, STS24C, STS48C, STS192C, T1, T3, VT1)

See [Table 4-11 on page 4-5](#) for supported modifiers by platform.

This command sets the threshold for PM and sets the alarm thresholds for the MXP_2.5G_10G/TXP_MR_10G cards. If this command is used to set the alarm thresholds, the time-period is not applicable.

The rules are as follows: The PM Thresholds have a default of NEND for the location. The Alarm Thresholds do not require or interpret the location. The TMPER is not applicable to alarm thresholds. The TMPER default is 15-MIN. The client ports only accept SONET, Laser and alarm MONTYPES. The trunk ports accept SONET, Laser, alarm, FEC, OTN and 8B10B MONTYPES.

See the “[Provisioning Rules for MXP_2.5G_10G and TXP_MR_10G Cards](#)” section on page 1-8 and the “[Provisioning Rules for TXP_MR_2.5G and TXPP_MR_2.5G Cards](#)” section on page 1-13 for specific card provisioning rules.

| Section | SET-TH-<MOD2> Description | |
|------------------|--|--|
| Category | Performance | |
| Security | Provisioning | |
| Related Messages | ALW-PMREPT-ALL INH-PMREPT-ALL INIT-REG-<MOD2> REPT PM <MOD2> RTRV-PM-<MOD2> RTRV-PMMODE-<STS_PATH> | RTRV-PMSCHED-<MOD2> RTRV-PMSCHED-ALL RTRV-TH-<MOD2> RTRV-TH-ALL SCHED-PMREPT-<MOD2> SET-PMMODE-<STS_PATH> |
| Input Format | <p>SET-TH-<MOD2>:[<TID>]:<AID>:<CTAG>:: <MONTYPE>,<THLEV>,[<LOCN>],,[<TMPER>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> indicates the access identifier. All the STS, VT1, Facility and DS1 AIDs are supported and <AID> is from the “ALL” section on page 4-9 • <MONTYPE> is the monitored value; valid values are shown in the “ALL_MONTYPE” section on page 4-39 • <THLEV> is the threshold value and is a float; <THLEV> is an integer • <LOCN> is the location; valid values are shown in the “LOCATION” section on page 4-68 • <TMPER> indicates the accumulation time period for the PM information; valid values are shown in the “TMPER” section on page 4-93 | |
| Input Example | SET-TH-T3:CISCO:FAC-1-1:123::CVL,12,NEND,,15-MIN; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.229 SET-TOD: Set Time of Day

This command sets the system date and time for the NE. The year should be entered using four digits while the hour should be entered using a 24-hour time period (i.e., military time).

| Section | SET-TOD Description | |
|------------------|---|---|
| Category | System | |
| Security | Provisioning | |
| Related Messages | ACT-USER ALW-MSG-ALL ALW-MSG-DBCHG ALW-MSG-SECU ED-DAT ED-NE-GEN ED-NE-PATH ED-NE-SYNCN INH-MSG-ALL INH-MSG-DBCHG | INH-MSG-SECU INIT-SYS RTRV-HDR RTRV-INV RTRV-NE-GEN RTRV-NE-IPMAP RTRV-NE-PATH RTRV-NE-SYNCN RTRV-NE-WDMANS RTRV-TOD |
| Input Format | <p>SET-TOD:[<TID>]::<CTAG>:&:<YEAR>,<MONTH>,<DAY>,<HOUR>,<MINUTE>,<SECOND>,[<DIFFERENCE>][:<DST=<DST>>];</p> <p>where:</p> <ul style="list-style-type: none"> • <YEAR> is the current calendar year and is an integer • <MONTH> is the month of the year and ranges from 01–12; <MONTH> is an integer • <DAY> is the day of the month and ranges from 01–31; <DAY> is an integer • <HOUR> is the hour of the day and ranges from 00–24; <HOUR> is an integer • <MINUTE> is the minute of the hour and ranges from 00–60; <MINUTE> is an integer • <SECOND> is the second of the minute and ranges from 00–59; second is an integer • <DIFFERENCE> is the number of minutes off UTC and is an integer • <DST> identifies if the time is a Daylight Saving Time (Y) or not (N); valid values are shown in the “ON/OFF” section on page 4-76 | |
| Input Example | SET-TOD:CAZADERO::240::1998,05,08,13,18,55,480:DST=Y; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |

3.4.230 SW-DX-EQPT: Switch Duplex Equipment

(Cisco ONS 15454 only)

This command switches an XC/XCVT/XC10G card with the mate card within the NE.



Note

If sending a mode parameter with a value other than NORM, FRCD, or NULL, the IDNV (Input, Data Not Valid) error message will be returned.

| Section | SW-DX-EQPT Description | |
|------------------|---|--|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-Swtoprotn-EQPT ALW-Swtowkg-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-Swtoprotn-EQPT INH-Swtowkg-EQPT | REPT ALM EQPT REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-TOPROTN-EQPT SW-TOWKG-EQPT |
| Input Format | SW-DX-EQPT:[<TID>]:<AID>:<CTAG>:::<MODE>][,]; where: <ul style="list-style-type: none"> <AID> identifies the equipment (XC/XCVT/XC10G) unit in the NE that is to be switched with its mate unit; <AID> is from the “EQPT” section on page 4-27 Valid values for <MODE> are shown in the “CMD_MODE” section on page 4-54 | |
| Input Example | SW-DX-EQPT:CISCO:SLOT-1:123::FRCD; | |
| Errors | Errors are listed in Table 7-33 on page 7-27. | |

3.4.231 SW-TOPROTN-EQPT: Switch to Protection Equipment

(Cisco ONS 15454 only)

This command performs an equipment unit protection switch.

This command is used for non-SONET line cards (e.g. DS1, DS3, DS3XM, and EC1). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection.

This command will switch the traffic from the working card specified in the AID to the protect card.

There is a priority for the switch to protection commands. In a 1:N protection group with N > 1, consider two working cards - A and B. Card A is switched to the protect card with the SW-TOPROTN command. If card B is pulled from the system, the protect card will carry the traffic of card B and card A will raise the FAILTOSW condition and carry traffic. When card B is replaced and the revert timer expires, card B will carry traffic and card A will switch to the protect card. The FAILTOSW condition on card A will be cleared. Note: 1:N protection groups in the system are always revertive.

In a revertive protection group, the unit specified by the AID will raise the standing condition of WKSMPR if the command were executed without an error. In a non-revertive protection group, the unit specified by the AID will raise the transient condition of WKSMPR if the command were executed without an error.

Notes:

- The default PROTID is the protecting unit if there is only one protection unit per protection group in the NE, otherwise a DENY error message will be responded.

2. This command only supports one value of the <DIRN> parameter - BTH or null. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message will be responded.
3. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will generate an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-Swdx-EQPT commands.
4. This command is not used for SONET (OCN) cards. A command on a SONET card will generate an IIAC (Input, Invalid Access Identifier) error message. To use a SONET card switching command, use the OPR-PROTNSW and RLS-PROTNSW commands.
5. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message will be responded.
6. If this command is sent to a missing working card, the SWFA (Status, Working Unit Failed) error message will be responded.
7. If this command is used on a protection card, the IIAC (Input, Invalid Access Identifier) error message will be responded.
8. If sending a mode parameter with a value other than NORM, FRCD, or null, the IDNV (Input, Data Not Valid) error message will be responded.
9. If sending the SW-TOPROTN command to a working card when the working card has raised INHSWPR, the SWLD (Status, Working Unit Locked) error message will be responded.
10. If sending the SW-TOPROTN command to a working card when the protection card has raised INHSWPR, the SPLD (Status, Protection Unit Locked) error message will be responded.
11. If sending the SW-TOPROTN command to an active working card when the protect card is already carrying traffic. This only occurs in a 1:N protection group with N greater than one, the SNVS (Status, Not in Valid State) error message will be responded.
12. If sending the SW-TOPROTN command to an active working card when the protect card is failed or missing, the SPFA (Status, Protection Unit Failed) error message will be responded.
13. If sending this command to a standby working card, the SNVS (Status, Not in Valid State) error message will be responded.

| Section | SW-TOPROTN-EQPT Description | |
|------------------|-----------------------------|-----------------|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT | REPT ALM EQPT |
| | ALW-SWTOPROTN-EQPT | REPT EVT EQPT |
| | ALW-SWTOWKG-EQPT | REPT SW |
| | DLT-EQPT | RTRV-ALM-EQPT |
| | ED-EQPT | RTRV-ALMTH-EQPT |
| | ENT-EQPT | RTRV-COND-EQPT |
| | EX-SW-<OCN_BLSR> | RTRV-EQPT |
| | INH-Swdx-EQPT | SET-ALMTH-EQPT |
| | INH-SWTOPROTN-EQPT | SW-DX-EQPT |
| | INH-SWTOWKG-EQPT | SW-TOWKG-EQPT |

| Section | SW-TOPROTN-EQPT Description |
|---------------|--|
| Input Format | <p>SW-TOPROTN-EQPT:[<TID>]:<AID>:<CTAG>::[<MODE>], [<PROTID>],[<DIRN>];</p> <p>where:</p> <ul style="list-style-type: none"> • <AID> is the parameter that specifies the working unit which will have traffic switched to protection and is from the “EQPT” section on page 4-27 • <MODE> is the parameter that will only support the NORM value. The null value for <MODE> will default to NORM. Sending the FRCD value for <MODE> will generate the same switching behavior as sending the NORM value. Valid values are shown in the “CMD_MODE” section on page 4-54 • <PROTID> identifies the protection unit to be switched when there is more than one protection unit within the NE; <PROTID> is from the “PRSLOT” section on page 4-31 • <DIRN> is the direction of transmission in which switching is to be made. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56 |
| Input Example | SW-TOPROTN-EQPT:CISCO:SLOT-1:123::FRCD,SLOT-3,BTH; |
| Errors | Errors are listed in Table 7-33 on page 7-27. |

3.4.232 SW-TOWKG-EQPT: Switch to Working Equipment

(Cisco ONS 15454 only)

This command switches the protected working unit back to working unit.

This command is used for non-SONET line cards (e.g. DS1, DS3, DS3XM, and EC1). DS1 and DS3 cards have 1:1 and 1:N equipment protection. DS3XM and EC1 cards have only 1:1 equipment protection cards.

This command will switch the traffic from the protection card to the working card specified by the AID.

In a revertive protection group, the unit specified by the AID will clear the standing condition of WKS WPR if the command were executed without an error. In a non-revertive protection group, the unit specified by the AID will raise the transient condition of WKS WBK if the command were executed without an error.

Notes:

1. This command only supports one value of the <DIRN> parameter - BTH or null. A command with any other value is considered an incorrect use of the command. An IDNV (Input, Data Not Valid) error message should be responded
2. This command is not used for the common control (TCC2 or XC/XCVT/XC10G) cards. A command on a common control card will generate an IIAC (Input, Invalid Access Identifier) error message. To use the common control card switching commands, use the SW-DX-EQPT and ALW-Swdx-EQPT commands.
3. This command is not used for SONET (OCN) cards. A command on a SONET card will generate an IIAC (Input, Invalid Access Identifier) error message. To use a SONET card switching command, use the OPR-PROTNSW and RLS-PROTNSW commands.

4. If this command is used on a card that is not in a protection group, the SNVS (Status, Not in Valid State) error message will be responded.
5. If this command is sent to a missing working card, the SWFA (Status, Working Unit Failed) error message will be responded.
6. If this command is used on a protection card, the IIAC (Input, Invalid Access Identifier) error message will be responded.
7. If sending a mode parameter with a value other than NORM, FRCD, or null, the IDNV (Input, Data Not Valid) error message will be responded.
8. If sending the SW-TOWKG command to a working card when the working card has raised INHSWWKG, the SWLD (Status, Working Unit Locked) error message will be responded.
9. If sending the SW-TOWKG command to a working card when the protection card has raised INHSWWKG, the SPLD (Status, Protection Unit Locked) error message will be responded.
10. If sending the SW-TOWKG command to an active working card, the SNVS (Status, Not in Valid State) error message will be responded.

| Section | SW-TOWKG-EQPT Description | |
|------------------|---|---|
| Category | Equipment | |
| Security | Maintenance | |
| Related Messages | ALW-Swdx-EQPT ALW-SWTOPROTN-EQPT ALW-SWTOWKG-EQPT DLT-EQPT ED-EQPT ENT-EQPT EX-SW-<OCN_BLSR> INH-Swdx-EQPT INH-SWTOPROTN-EQPT INH-SWTOWKG-EQPT | REPT ALM EQPT REPT EVT EQPT REPT SW RTRV-ALM-EQPT RTRV-ALMTH-EQPT RTRV-COND-EQPT RTRV-EQPT SET-ALMTH-EQPT SW-DX-EQPT SW-TOPROTN-EQPT |
| Input Format | <p>SW-TOWKG-EQPT:<TID>:<AID>:<CTAG>:::<MODE>,[<DIRN>]; where:</p> <ul style="list-style-type: none"> • <AID> identifies the working unit that is to be released from protection. <AID> is from the “PRSLOT” section on page 4-31 • <MODE> will only support the NORM value. The null value will default to NORM. Sending the FRCD value will generate the same switching behavior as sending the NORM value. Valid values for <MODE> are shown in the “CMD_MODE” section on page 4-54 • <DIRN> is the direction of transmission. The command only supports one value of the <DIRN> parameter - BTH. This parameter defaults to BTH; valid values for <DIRN> are shown in the “DIRECTION” section on page 4-56 | |
| Input Example | SW-TOWKG-EQPT:CISCO:SLOT-2:123::FRCD,BTH; | |
| Errors | Errors are listed in Table 7-33 on page 7-27 . | |