



## **QoS: Policing and Shaping Configuration Guide, Cisco IOS XE Release 3S (Cisco ASR 920 Series)**

**First Published:** 2014-07-29

**Last Modified:** 2014-11-22

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CONTENTS

---

### CHAPTER 1

#### **Class-Based Policing 1**

Feature Overview 1

Benefits 1

Restrictions 2

Prerequisites 3

Configuration Tasks 3

Configuring Traffic Policing 3

Verifying Traffic Policing 3

Troubleshooting Tips 4

Monitoring and Maintaining Traffic Policing 4

Configuration Examples 4

Example Configuring a Service Policy that Includes Traffic Policing 4

Additional References 6

---

### CHAPTER 2

#### **Punt Policing and Monitoring 9**

Information About Punt Policing and Monitoring 9

Overview of Punt Policing and Monitoring 9

How to Configure Punt Policing and Monitoring 10

Configuring Punt Policing 10

Verifying Punt Policing 11

Verifying Queue-Based Punt Policing 11

Verifying Punt Policing Statistics 11

Configuration Examples for Punt Policing and Monitoring 15

Example: Configuring Punt Policing 15

Additional References 15

---

<b>CHAPTER 3</b>	<b>Port-Shaper and LLQ in the Presence of EFPs</b>	<b>17</b>
	Restrictions for Port-Shaper and LLQ in the Presence of EFPs	17
	Information About Port-Shaper and LLQ in the Presence of EFPs	17
	Ethernet Flow Points and LLQ	17
	How to Configure Port-Shaper and LLQ in the Presence of EFPs	18
	Configuring Hierarchical Policy Maps	18
	Configuring an LLQ Policy Map	20
	Configuring Port Level Shaping on the Main Interface with Ethernet Flow Points	22
	Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs	24
	Example: Configuring Hierarchical QoS Port Level Shaping on the Main Interface with EFPs	24
	Example: Configuring Port Level Shaping on the Main Interface with EFPs	25
	Additional References	26

---

<b>CHAPTER 4</b>	<b>Control Plane Policing</b>	<b>27</b>
	Information About Control Plane Policing	27
	Control Plane Policing Overview	27
	Benefits of Control Plane Policing	28
	Control Plane Terms to Understand	28
	Supported Protocols	29
	Input Rate-Limiting and Silent Mode Operation	34
	Restrictions for Control Plane Policing	34
	IP Access List Overview	35
	Benefits	35
	IP Address Range-Based Filtering Support for CoPP ACL	36
	How to Use Control Plane Policing	37
	Defining Control Plane Services	37
	Verifying Control Plane Services	38
	Configuring Control Plane Policing to Mitigate Denial-of-Service Attacks	39
	Configuring CoPP ACL	41
	Verifying CoPP ACL	42
	Configuration Examples for Control Plane Policing	42
	Example: Configuring Control Plane Policing on Input Telnet Traffic	42
	Additional References	43

---

**CHAPTER 5****Priority Shaper 45**

- Restrictions for Priority Shaper 45
- Configuring Priority Shaper 45
  - Configuration Examples for Priority Shaper 47
  - Example: Configuring Priority Shaper 47
- Verifying Priority Shaper 48

---

**CHAPTER 6****Hierarchical Color-Aware Policing 49**

- Prerequisites for Hierarchical Color-Aware Policing 49
- Restrictions for Hierarchical Color-Aware Policing 49
- Information About Hierarchical Color-Aware Policing 51
  - Hierarchical Order Policing 51
  - Limited Color-Aware Policing 52
  - Policing Traffic in Child Classes and Parent Classes 53
- How to Configure Hierarchical Color-Aware Policing 54
  - Configuring the Hierarchical Color-Aware Policing Feature 54
- Configuration Examples for Hierarchical Color-Aware Policing 57
  - Example Enabling the Hierarchical Color-Aware Policing Feature 57
  - Example Disallowing the Removal of an Active Color-Aware Class Map 57
  - Example Dismantling a Configuration of the Hierarchical Color-Aware Policing Feature 57
  - Example Applying show Command with Hierarchical Color-Aware Policing 58
- Additional References 59





# CHAPTER 1

## Class-Based Policing

---

- [Feature Overview, on page 1](#)
- [Prerequisites, on page 3](#)
- [Configuration Tasks, on page 3](#)
- [Monitoring and Maintaining Traffic Policing, on page 4](#)
- [Configuration Examples, on page 4](#)
- [Additional References, on page 6](#)

### Feature Overview

Class-Based Policing allows you to control the maximum rate of traffic transmitted or received on an interface. The Class-Based Policing feature is applied when you attach a traffic policy contain the Class-Based Policing configuration to an interface.

The Class-Based Policing feature performs the following functions:

- Limits the input or output transmission rate of a class of traffic based on user-defined criteria
- Marks packets by setting the ATM Cell Loss Priority (CLP) bit, Frame Relay Discard Eligibility (DE) bit, IP precedence value, IP differentiated services code point (DSCP) value, MPLS experimental value, and Quality of Service (QoS) group.

### Benefits

#### Bandwidth Management Through Rate Limiting

Class-Based Policing allows you to control the maximum rate of traffic transmitted or received on an interface. Class-Based Policing is often configured on interfaces at the edge of a network to limit traffic into or out of the network. In most Class-Based Policing configurations, traffic that falls within the rate parameters is transmitted, whereas traffic that exceeds the parameters is dropped or transmitted with a different priority.

#### Packet Marking

Packet marking allows you to partition your network into multiple priority levels or classes of service (CoS). A packet is marked and these markings can be used to identify and classify traffic for downstream devices.

In some cases, such as ATM Cell Loss Priority (CLP) marking or Frame Relay Discard Eligibility (DE) marking, the marking is used to classify traffic.

- Use Class-Based Policing to set the IP precedence or DSCP values for packets entering the network. Networking devices within your network can then use the adjusted IP precedence values to determine how the traffic should be treated. For example, the Weighted Random Early Detection (WRED) feature uses the IP precedence values to determine the probability that a packet will be dropped.
- Use Class-Based Policing to assign packets to a QoS group. The router uses the QoS group to determine how to prioritize packets within the router.

Traffic can be marked without using the Class-Based Policing feature. If you want to mark traffic but do not want to use Class-Based Policing, see the "Marking Network Traffic" module.

### Packet Prioritization for Frame Relay Frames

The Class-Based Policing feature allows users to mark the Frame Relay DE bit of the Frame Relay frame. The Frame Relay DE bit is one bit and, therefore, can be set to either 0 or 1. In congested environments, frames with the DE bit set to 1 are discarded before frames with the DE bit set to 0.

### Packet Prioritization for ATM Cells

The Class-Based Policing feature allows users to mark the ATM CLP bit in ATM cells. The ATM CLP bit is used to prioritize packets in ATM networks. The ATM CLP bit is one bit and, therefore, can be set to either 0 or 1. In congested environments, cells with the ATM CLP bit set to 1 are discarded before cells with the ATM CLP bit set to 0.

## Restrictions

- To use the *set-clp-transmit* action available with this feature, the Enhanced ATM Port Adapter (PA-A3) is required. Therefore, the *set-clp-transmit* action is not supported on any platform that does not support the PA-A3 adapter. For more information, see the documentation for your specific device.
- On a Cisco ASR 920 Series router in egress, 1R2C means confirm-action transmit and exceed-action drop. By configuring exceed-action transmit on egress will drop those packets.
- On a Cisco ASR 920 Series router, Class-Based Policing can monitor Cisco Express Forwarding (CEF) switching paths only. In order to use the Class-Based Policing feature, Cisco Express Forwarding must be configured on both the interface receiving the packet and the interface sending the packet.
- On a Cisco ASR 920 Series router, Class-Based Policing cannot be applied to packets that originated from or are destined to a device.
- Class-Based Policing can be configured on an interface or a subinterface.
- As Policer actions and Table-Map configurations are not mutually exclusive, dynamic modifications of these parameters is not supported.
- Class-Based Policing is not supported on the following interfaces:
  - Fast EtherChannel
  - PRI
  - Any interface on a Cisco ASR 920 Series router that does not support Cisco Express Forwarding



- Tunnel



**Note** Class-Based Policing is supported on tunnels that are using the Cisco generic routing encapsulation (GRE) tunneling protocol.

## Prerequisites

On a Cisco ASR 920 Series router, Cisco Express Forwarding (CEF) must be configured on the interface before Class-Based Policing can be used.

## Configuration Tasks

### Configuring Traffic Policing

Command	Purpose
Device(config-pmap-c)# <b>police</b> <i>bps burst-normal burst-max conform-action action exceed-action action violate-action action</i>	Specifies a maximum bandwidth usage by a traffic class.  <b>Note</b> The Class-Based Policing feature works with a token bucket mechanism. There are currently two types of token bucket algorithms: a single token bucket algorithm and a two token bucket algorithm. A single token bucket system is used when the <b>violate-action</b> option is not specified, and a two token bucket system is used when the <b>violate-action</b> option is specified.

### Verifying Traffic Policing

Use the **show policy-map interface EXEC** command to verify that the Class-Based Policing feature is configured on your interface. If the feature is configured on your interface, the **show policy-map interface** command output displays policing statistics:

```
Device# show policy-map interface
Ethernet1/7
  service-policy output: x
    class-map: a (match-all)
      0 packets, 0 bytes
      5 minute rate 0 bps
      match: ip precedence 0
      police:
        1000000 bps, 10000 limit, 10000 extended limit
        conformed 0 packets, 0 bytes; action: transmit
        exceeded 0 packets, 0 bytes; action: drop
        conformed 0 bps, exceed 0 bps, violate 0 bps
```

## Troubleshooting Tips

- Check the interface type. Verify that your interface is not mentioned in the nonsupported interface description in the [Restrictions, on page 2](#) section of this module.
- For input Class-Based Policing on a Cisco ASR 920 Series router, verify that CEF is configured on the interface where Class-Based Policing is configured.
- For output Class-Based Policing on a Cisco ASR 920 Series router, ensure that the incoming traffic is CEF-switched. Class-Based Policing cannot be used on the switching path unless CEF switching is enabled.

## Monitoring and Maintaining Traffic Policing

Command	Purpose
Device# <b>show policy-map</b>	Displays all configured policy maps.
Device# <b>show policy-map</b> <i>policy-map-name</i>	Displays the user-specified policy map.
Device# <b>show policy-map interface</b>	Displays statistics and configurations of all input and output policies that are attached to an interface.
Device# <b>show policy-map interface service instance</b>	Displays the policy map information for a given service instance under a port channel.

## Configuration Examples

### Example Configuring a Service Policy that Includes Traffic Policing

In the following example, Class-Based Policing is configured with the average rate at 8000 bits per second, the normal burst size at 1000 bytes, and the excess burst size at 1000 bytes for all packets leaving Fast Ethernet interface 0/0.

```
class-map access-match
match access-group 1
exit
policy-map police-setting
class access-match
police 8000 1000 1000 conform-action transmit exceed-action set-qos-transmit 1 violate-action
drop
exit
exit
service-policy output police-setting
```

The treatment of a series of packets leaving Fast Ethernet interface 0/0 depends on the size of the packet and the number of bytes remaining in the conform and exceed token buckets. The series of packets are policed based on the following rules:

- If the previous arrival of the packet was at  $T1$  and the current arrival of the packet is at  $T$ , the bucket is updated with  $T - T1$  worth of bits based on the token arrival rate. The refill tokens are placed in the conform bucket. If the tokens overflow the conform bucket, the overflow tokens are placed in the exceed bucket. The token arrival rate is calculated as follows:

$(\text{time between packets} <\text{which is equal to } T - T1> * \text{policer rate})/8 \text{ bytes}$

- If the number of bytes in the conform bucket  $B$  is greater than or equal to 0, the packet conforms and the conform action is taken on the packet. If the packet conforms,  $B$  bytes are removed from the conform bucket and the conform action is taken. The exceed bucket is unaffected in this scenario.
- If the number of bytes in the conform bucket  $B$  is less than 0, the excess token bucket is checked for bytes by the packet. If the number of bytes in the exceed bucket  $B$  is greater than or equal to 0, the exceed action is taken and  $B$  bytes are removed from the exceed token bucket. No bytes are removed from the conform bucket in this scenario.
- If the number bytes in the exceed bucket  $B$  is fewer than 0, the packet violates the rate and the violate action is taken. The action is complete for the packet.

In this example, the initial token buckets starts full at 1000 bytes. If a 450-byte packet arrives, the packet conforms because enough bytes are available in the conform token bucket. The conform action (send) is taken by the packet and 450 bytes are removed from the conform token bucket (leaving 550 bytes).

If the next packet arrives 0.25 seconds later, 250 bytes are added to the conform token bucket

$((0.25 * 8000)/8)$ , leaving 800 bytes in the conform token bucket. If the next packet is 900 bytes, the packet does not conform because only 800 bytes are available in the conform token bucket.

The exceed token bucket, which starts full at 1000 bytes (as specified by the excess burst size) is then checked for available bytes. Because enough bytes are available in the exceed token bucket, the exceed action (set the QoS transmit value of 1) is taken and 900 bytes are taken from the exceed bucket (leaving 100 bytes in the exceed token bucket).

If the next packet arrives 0.40 seconds later, 400 bytes are added to the token buckets  $((.40 * 8000)/8)$ . Therefore, the conform token bucket now has 1000 bytes (the maximum number of tokens available in the conform bucket) and 200 bytes overflow the conform token bucket (because it only 200 bytes were needed to fill the conform token bucket to capacity). These overflow bytes are placed in the exceed token bucket, giving the exceed token bucket 300 bytes.

If the arriving packet is 1000 bytes, the packet conforms because enough bytes are available in the conform token bucket. The conform action (transmit) is taken by the packet, and 1000 bytes are removed from the conform token bucket (leaving 0 bytes).

If the next packet arrives 0.20 seconds later, 200 bytes are added to the token bucket  $((.20 * 8000)/8)$ . Therefore, the conform bucket now has 200 bytes. If the arriving packet is 400 bytes, the packet does not conform because only 200 bytes are available in the conform bucket. Similarly, the packet does not exceed because only 300 bytes are available in the exceed bucket. Therefore, the packet violates and the violate action (drop) is taken.

# Additional References

## Related Documents

Related Topic	Document Title
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<i>Cisco IOS Quality of Service Solutions Command Reference</i>
Modular Quality of Service (QoS) Command-Line Interface (CLI) (MQC), hierarchical policies, policy maps	"Applying QoS Features Using the MQC" module
Policing and shaping traffic	"Policing and Shaping Overview" module

## Standards

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	--

## MIBs

MIB	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL:  <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

## RFCs

RFC	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	--

**Technical Assistance**

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>





## CHAPTER 2

# Punt Policing and Monitoring

Punt policing protects the Route Processor (RP) from having to process noncritical traffic, which increases the CPU bandwidth available to critical traffic. Traffic is placed into different CPU queues based on various criteria. The Punt Policing and Monitoring feature allows you to police the punt rate on a per-queue basis.

- [Information About Punt Policing and Monitoring, on page 9](#)
- [How to Configure Punt Policing and Monitoring, on page 10](#)
- [Configuration Examples for Punt Policing and Monitoring, on page 15](#)
- [Additional References, on page 15](#)

## Information About Punt Policing and Monitoring

### Overview of Punt Policing and Monitoring

Packets received on an interface are punted to the Router Processor (RP) for various reasons. Some examples of these various reasons include, unicast and multicast control plane traffic that are destined for a routing protocol process running on the RP, and IP packets that generate Internet Control Message Protocol (ICMP) exceptions such as a Time to live (TTL) expiration. The RP has a limited capacity to process the punted packets, and while some of them are critical for the router operation and should not be dropped, some can be dropped without impacting the router operation.

Punt policing frees the RP from having to process noncritical traffic. Traffic is placed in queues based on various criteria, and you can configure the maximum punt rate for each queue which allows you to configure the system so that packets are less likely to be dropped from queues that contain critical traffic.



---

**Note** Traffic on certain CPU queues could still be dropped, regardless of the configured punt rate, based on other criteria such as the queue priority, queue size, and traffic punt rate.

---

#### Per-Interface Per-Cause Punt Policer

Per-interface per-cause (PIPC) punt policing is an enhancement to the Punt Policing and Monitoring feature that allows you to control and limit traffic per interface. From Cisco IOS XE Release 17.5.1, you can set the PIPC rate for all the control plane-punted traffic. When you set the PIPC rate, any traffic beyond the set limit is dropped, thereby enabling you to control the traffic during conditions such as L2 storming.

The PIPC punt policer configuration is supported for the following interfaces:

- Main interface
- Subinterface
- Port channel
- Port channel subinterface
- Tunnels
- PPPoE interface

# How to Configure Punt Policing and Monitoring

## Configuring Punt Policing



**Note** Traffic on a specific CPU queue may be dropped irrespective of the configured maximum punt rate, based on the queue priority, queue size, and the configured traffic punt rate.

Perform this task to specify the maximum punt rate on the specified queue.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **platform qos-policer queue *queue-id* *cir bc***
4. **end**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters the global configuration mode.
<b>Step 3</b>	<b>platform qos-policer queue <i>queue-id</i> <i>cir bc</i></b>  <b>Example:</b> Device(config)# platform qos-policer queue 20 384000 8000	Enables punt policing on a queue, and specifies the maximum punt rate on a per-queue basis.  <i>cir</i> — Indicates Committed Information Rate (CIR). The range is 384000-20000000 bps.  <i>bc</i> — Indicates Committed Bursts (BC). The range is 8000-16000000 bps.



	Command or Action	Purpose
Step 4	<b>end</b>  <b>Example:</b> Device(config)# end	(Optional) Returns to privileged EXEC mode.

## Verifying Punt Policing

### Verifying Queue-Based Punt Policing

Use the **show platform software infrastructure punt statistics** to display punt police statistics:

```
Router# show platform software infrastructure punt statistics
UEA Punt Statistics
```

```
Global drops : 0
```

Queue Name	Rx count	Drop count
SW FORWARDING Q	0	0
ROUTING PROTOCOL Q	0	0
ICMP Q	0	0
HOST Q	57115	0
ACL LOGGING Q	0	0
STP Q	0	0
L2 PROTOCOL Q	6571	0
MCAST CONTROL Q	208839	0
BROADCAST Q	4	0
REP Q	0	0
CFM Q	0	0
CONTROL Q	0	0
IP MPLS TTL Q	0	0
DEFAULT MCAST Q	0	0
MCAST ROUTE DATA Q	0	0
MCAST MISMATCH Q	0	0
RPF FAIL Q	0	0
ROUTING THROTTLE Q	87	0
MCAST Q	0	0
MPLS OAM Q	0	0
IP MPLS MTU Q	0	0
PTP Q	0	0
LINUX ND Q	0	0
KEEPALIVE Q	0	0
ESMC Q	0	0
FPGA BFD Q	0	0
FPGA CCM Q	0	0
FPGA CFE Q	0	0
L2PT DUP Q	0	0

### Verifying Punt Policing Statistics

Use the **show platform hardware pp active infrastructure pi npd rx policer** command to display the punt policing statistics for all queues.

Ring	Queue Name	Punt rate	Burst rate
0	SW FORWARDING Q	500	1000

1		ROUTING PROTOCOL Q		500		1000
2		ICMP Q		500		1000
3		HOST Q		1000		2000
4		ACL LOGGING Q		500		1000
5		STP Q		3000		6000
6		L2 PROTOCOL Q		1000		2000
7		MCAST CONTROL Q		1000		2000
8		BROADCAST Q		1000		2000
9		REP Q		3000		6000
10		BGP LDP Q		3000		6000
11		CONTROL Q		1000		2000
12		IP MPLS TTL Q		1000		2000
13		DEFAULT MCAST Q		500		1000
14		MCAST ROUTE DATA Q		500		1000
15		MCAST HIGH PRI Q		1000		2000
16		RPF FAIL Q		500		1000
17		ROUTING THROTTLE Q		500		1000
18		MCAST Q		500		1000
19		MPLS OAM Q		1000		2000
20		IP MPLS MTU Q		500		1000
21		PTP Q		3000		6000
22		LINUX ND Q		500		1000
23		KEEPALIVE Q		1000		2000
24		ESMC Q		3000		6000
25		FPGA BFD Q		4000		8000
26		FPGA CCM Q		4000		8000
27		FPGA CFE Q		1000		2000
28		L2PT DUP Q		4000		8000
29		TDM CTRL Q		3000		6000
30		ICMP UNREACHABLE Q		500		1000
31		SSFPD Q		6000		12000

Router# **show platform hardware pp active infrastructure pi npd rx policer**  
PUNT POLICER

Ring	Queue Name	Punt rate	Burst rate
0	SW FORWARDING Q	500	1000
1	ROUTING PROTOCOL Q	500	1000
2	ICMP Q	500	1000
3	HOST Q	1000	2000
4	ACL LOGGING Q	500	1000
5	STP Q	3000	6000
6	L2 PROTOCOL Q	1000	2000
7	MCAST CONTROL Q	1000	2000
8	BROADCAST Q	500	1000
9	REP Q	3000	6000
10	CFM Q	3000	6000
11	CONTROL Q	1000	2000
12	IP MPLS TTL Q	1000	2000
13	DEFAULT MCAST Q	500	1000
14	MCAST ROUTE DATA Q	500	1000
15	MCAST MISMATCH Q	500	1000
16	RPF FAIL Q	500	1000
17	ROUTING THROTTLE Q	500	1000
18	MCAST Q	500	1000
19	MPLS OAM Q	1000	2000
20	IP MPLS MTU Q	500	1000
21	PTP Q	3000	6000
22	LINUX ND Q	500	1000
23	KEEPALIVE Q	1000	2000
24	ESMC Q	3000	6000
25	FPGA BFD Q	3000	6000
26	FPGA CCM Q	3000	6000

```

27 |          FPGA CFE Q |          3000 |          6000
28 |          L2PT DUP Q |          4000 |          8000

```

```

Router#show platform hardware pp active infrastructure pi npd rx policer
PUNT POLICER

```

Ring	Queue Name	Punt rate	Burst rate
0	SW FORWARDING Q	500	1000
1	ROUTING PROTOCOL Q	500	1000
2	ICMP Q	500	1000
3	HOST Q	1000	2000
4	ACL LOGGING Q	500	1000
5	STP Q	3000	6000
6	L2 PROTOCOL Q	1000	2000
7	MCAST CONTROL Q	1000	2000
8	BROADCAST Q	500	1000
9	REP Q	3000	6000
10	CFM Q	3000	6000
11	CONTROL Q	1000	2000
12	IP MPLS TTL Q	1000	2000
13	DEFAULT MCAST Q	500	1000
14	MCAST ROUTE DATA Q	500	1000
15	MCAST MISMATCH Q	500	1000
16	RPF FAIL Q	500	1000
17	ROUTING THROTTLE Q	500	1000
18	MCAST Q	500	1000
19	MPLS OAM Q	1000	2000
20	IP MPLS MTU Q	9000	10000
21	PTP Q	3000	6000
22	LINUX ND Q	500	1000
23	KEEPALIVE Q	1000	2000
24	ESMC Q	3000	6000
25	FPGA BFD Q	4000	8000
26	FPGA CCM Q	2000	4000
27	FPGA CFE Q	3000	6000
28	L2PT DUP Q	4000	8000

Use the **show platform software infrastructure punt statistics** command to view the statistics on the RSP3 module.

```
Router#
```

```
Global drops : 0
```

Queue Name	Rx count	Drop count
SW FORWARDING Q	0	0
ROUTING PROTOCOL Q	0	0
ICMP Q	0	0
HOST Q	0	0
ACL LOGGING Q	0	0
STP Q	0	0
L2 PROTOCOL Q	0	0
MCAST CONTROL Q	0	0
BROADCAST Q	0	0
REP Q	0	0
BGP LDP Q	0	0
CONTROL Q	0	0
IP MPLS TTL Q	0	0
DEFAULT MCAST Q	0	0
MCAST ROUTE DATA Q	0	0
MCAST MISMATCH Q	0	0

```

RPF FAIL Q          | 0          | 0
ROUTING THROTTLE Q | 0          | 0

MCAST Q            | 0          | 0
MPLS OAM Q         | 0          | 0
IP MPLS MTU Q      | 0          | 0
PTP Q              | 0          | 0
LINUX ND Q         | 0          | 0
KEEPALIVE Q        | 0          | 0
ESMC Q             | 0          | 0
FPGA BFD Q         | 0          | 0
FPGA CCM Q         | 0          | 0
FPGA CFE Q         | 0          | 0
L2PT DUP Q         | 0          | 0
TDM CTRL Q         | 0          | 0
ICMP UNREACHABLE Q | 0          | 0
SSFP Q             | 0          | 0
MIRROT Q           | 0          | 0

```

Use the **show platform hardware pp active feature qos policer cpu all 1** command to clear the statistics of all the CPU queues.

Use the **show platform hardware pp active feature qos policer cpu all 0** command to clear the statistics of a particular CPU queue.

```

##### Stats for CPU queue 0 #####
Internal Qnum: 1      Queue Name: SW FORWARDING Q
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
RM Drops: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000, Policer burst commit is 100000

##### Stats for CPU queue 1 #####
Internal Qnum: 2      Queue Name: ROUTING PROTOCOL Q
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
RM Drops: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000, Policer burst commit is 100000

-----

##### Stats for CPU queue 30 #####
Internal Qnum: 31     Queue Name: ICMP UNREACHABLE Q
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
RM Drops: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000, Policer burst commit is 100000

##### Stats for CPU queue 31 #####
Internal Qnum: 32     Queue Name: SSFPD Q
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
RM Drops: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000, Policer burst commit is 100000

```

Use **show platform hardware pp active feature qos policer cpu 3 0** to display the queue specific statistics.

```

##### Stats for CPU queue 3 #####
Internal Qnum: 4      Queue Name: HOST Q
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
RM Drops: 0 (packets) 0 (bytes)
Policer commit rate is: 12000000, Policer burst commit is 3000000

3 — queueId of CPU   and 0 - show stats

```

Use the **show platform hardware pp active feature qos policer cpu all 0** to display the output after adding the drop cause. Following commands are applicable only for RSP3 module:

```
##### Stats for CPU queue 0 #####
Internal Qnum: 8000CPU
Port num: 0
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
Policer commit rate is: 500000 bps, Policer burst commit is 16000 bytes
##### Stats for CPU queue 1 #####
Internal Qnum: 8008CPU
Port num: 0
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000 bps, Policer burst commit is 100000 bytes
##### Stats for CPU queue 2 #####
Internal Qnum: 8016CPU
Port num: 0
Policer conform: 0 (packets) 0 (bytes)
Policer exceed: 0 (packets) 0 (bytes)
Policer commit rate is: 1000000 bps, Policer burst commit is 100000 bytes
```

## Configuration Examples for Punt Policing and Monitoring

### Example: Configuring Punt Policing

The following example shows how to enable punt-policing:

```
Router# enable
Router# configure terminal
Router(config)# platform qos-policer queue 3 384000 8000
```

## Additional References

### Related Documents

Related Topic	Document Title
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<i>Cisco IOS Quality of Service Solutions Command Reference</i>
Traffic marking	“Marking Network Traffic” module
Traffic policing	“Traffic Policing” module
Traffic policing and shaping concepts and overview information	“Policing and Shaping Overview” module

Related Topic	Document Title
Modular quality of service command-line interface (MQC)	“Applying QoS Features Using the MQC” module

### Standards

Standard	Title
None	—

### MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco IOS XE Software releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

### RFCs

RFC	Title
None	

### Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>



## CHAPTER 3

# Port-Shaper and LLQ in the Presence of EFPs

The Port-Shaper and LLQ in the Presence of EFPs feature allows network designers to configure port and class policies on ports that contain Ethernet Flow Points (EFPs). These policies support Low Latency Queuing (LLQ) and traffic prioritization across the EFPs.

- [Restrictions for Port-Shaper and LLQ in the Presence of EFPs, on page 17](#)
- [Information About Port-Shaper and LLQ in the Presence of EFPs, on page 17](#)
- [How to Configure Port-Shaper and LLQ in the Presence of EFPs, on page 18](#)
- [Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs, on page 24](#)
- [Additional References, on page 26](#)

## Restrictions for Port-Shaper and LLQ in the Presence of EFPs

- If you configure port level shaper with the policy applied at EFP level, then port shaper does not work. However, 3 level HQoS policy with port and logical shaper can be applied at the EFP level. Logical shaper that is configured at logical level does work but port shaper does not work.
- If you configure a class-based policy on the port, then you cannot configure service-policies on Ethernet Flow Points (EFPs).
- Attaching a service policy to the BDI is not supported.
- ACL based shaping policy-map cannot be applied to the EFP and/or egress interface.
- Usage of bandwidth remaining percentage (BRP) in the absence of priority class, allocates the available bandwidth in an iterative way. For example, the bandwidth is allocated for the first BRP class as per the percentage of share that is configured in the respective class-map and the remaining bandwidth is iteratively allocated to all other BRP classes until the bandwidth is exhausted.
- 

## Information About Port-Shaper and LLQ in the Presence of EFPs

### Ethernet Flow Points and LLQ

An Ethernet Flow Point (EFP) is a forwarding decision point in the provider edge (PE) router, which gives network designers flexibility to make many Layer 2 flow decisions within the interface. Many EFPs can be

configured on a single physical port. (The number varies from one device to another.) EFPs are the logical demarcation points of an Ethernet virtual connection (EVC) on an interface. An EVC that uses two or more User-Network Interfaces (UNIs) requires an EFP on the associated ingress and egress interfaces of every device that the EVC passes through.

The Egress HQoS with Port Level Shaping feature allows network designers to configure port and class policies on ports that contain EFPs. These policies support Low Latency Queueing (LLQ) and traffic prioritization across the EFPs.

For information on how to configure LLQ, see the *QoS Congestion Management Configuration Guide*.

## How to Configure Port-Shaper and LLQ in the Presence of EFPs

To configure the Port-Shaper and LLQ in the Presence of EFPs feature, you first create either a hierarchical or flat policy map that supports Low Latency Queueing (LLQ), which you then attach to an EFP interface.

### Configuring Hierarchical Policy Maps

To configure hierarchical policy maps, you create child policies which you then attach to a parent policy. The parent policy is then attached to an interface.

#### Step 1 **enable**

##### Example:

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

#### Step 2 **configure terminal**

##### Example:

```
Device# configure terminal
```

Enters global configuration mode.

#### Step 3 **policy-map *policy-map-name***

##### Example:

```
Device(config)# policy-map child-llq
```

Creates or modifies the child policy and enters QoS policy-map configuration mode.

- child-llq is the name of the child policy map.

#### Step 4 **class *class-map-name***

##### Example:

```
Device(config-pmap)# class precedenc-1
```



Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.

- `precedenc-1` is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.

**Step 5**      **set cos** *value*

**Example:**

```
Device(config-pmap-c)# set cos 5
```

(Optional) Sets the Layer 2 class of service (CoS) value of an outgoing packet.

- The value is a specific IEEE 802.1Q CoS value from 0 to 7.

**Step 6**      **bandwidth percent** *percent*

**Example:**

```
Device(config-pmap-c)# bandwidth percent 20
```

(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to nonpriority queues.

**Step 7**      **exit**

**Example:**

```
Device(config-pmap-c)# exit
```

Exits QoS policy-map class configuration mode.

**Step 8**      **class** *class-map-name*

**Example:**

```
Device(config-pmap)# class precedenc-2
```

Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.

- `precedenc-2` is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.

**Note**      `match on qos-group` is supported on the Cisco RSP3 Module.

**Step 9**      **bandwidth percent** *percent*

**Example:**

```
Device(config-pmap-c)# bandwidth percent 80
```

(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to nonpriority queues.

**Step 10**     **exit**

**Example:**

```
Device(config-pmap-c)# exit
```

Exits QoS policy-map class configuration mode.

**Step 11** `policy-map` *policy-map-name*

**Example:**

```
Device(config-pmap)# policy-map parent-llq
```

Creates or modifies the parent policy.

- parent-llq is the name of the parent policy map.

**Step 12** `class` *class-default*

**Example:**

```
Device(config-pmap)# class class-default
```

Configures or modifies the parent class-default class and enters QoS policy-map class configuration mode.

- You can configure only the class-default class in a parent policy. Do not configure any other traffic class.

**Step 13** `service-policy` *policy-map-name*

**Example:**

```
Device(config-pmap-c)# service-policy child-llq
```

Applies the child policy to the parent class-default class.

- child-llq is the name of the child policy map configured in step 1.

## Configuring an LLQ Policy Map

**Step 1** `enable`

**Example:**

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

**Step 2** `configure terminal`

**Example:**

```
Device# configure terminal
```

Enters global configuration mode.

**Step 3** `policy-map` *policy-map-name*

**Example:**

```
Device(config)# policy-map llq-flat
```

Creates a policy and enters QoS policy-map configuration mode.

**Step 4** `class class-map-name`**Example:**

```
Device(config-pmap)# class dscp-af1
```

Assigns the traffic class you specify to the policy map and enters policy-map class configuration mode.

**Step 5** `priority`**Example:**

```
Device(config-pmap-c)# priority
```

Configures LLQ, providing strict priority queueing (PQ) for class-based weighted fair queueing (CBWFQ).

**Step 6** `exit`**Example:**

```
Device(config-pmap-c)# exit
```

Exits QoS policy-map class configuration mode.

**Step 7** `class class-map-name`**Example:**

```
Device(config-pmap)# class dscp-af2
```

Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.

**Step 8** `shape average value`**Example:**

```
Device(config-pmap-c)# shape average 200000000
```

Configures a shape entity with a Comitted Information Rate of 200 Mb/s.

**Step 9** `exit`**Example:**

```
Device(config-pmap-c)# exit
```

Exits QoS policy-map class configuration mode.

**Step 10** `class class-map-name`**Example:**

```
Device(config-pmap)# class dscp-af3
```

Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.

**Step 11**     **bandwidth** *percent***Example:**

```
Device(config-pmap-c)# bandwidth 4000000
```

(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to non-priority queues.

**Step 12**     **exit****Example:**

```
Device(config-pmap-c)# exit
```

Exits QoS policy-map class configuration mode.

---

## Configuring Port Level Shaping on the Main Interface with Ethernet Flow Points

To configure port level shaping on the main interface with EFPS, first you enable the autonegotiation protocol on the interface, then you attach a policy map to the interface and finally you configure the Ethernet service instance.

---

**Step 1**     **enable****Example:**

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

**Step 2**     **configure terminal****Example:**

```
Device# configure terminal
```

Enters global configuration mode.

**Step 3**     **interface** *type number***Example:**

```
Device(config)# interface GigabitEthernet 0/0/1
```

Configures an interface type and enters interface configuration mode.

- Enter the interface type number.

**Step 4**     **no ip address**

**Example:**

```
Device(config-if)# no ip address
```

Disables IP routing on the interface.

**Step 5 negotiation auto****Example:**

```
Device(config-if)# negotiation auto
```

Enables the autonegotiation protocol to configure the speed, duplex, and automatic flow control of the Gigabit Ethernet interface.

**Step 6 service-policy output *policy-map-name*****Example:**

```
Device(config-if)# service-policy output parent-llq
```

Specifies the name of the policy map to be attached to the input or output direction of the interface.

- You can enter the name of a hierarchical or a flat policy map.

**Step 7 service instance *id* ethernet****Example:**

```
Device(config-if)# service instance 1 ethernet
```

Configures an Ethernet service instance on an interface and enters service instance configuration mode.

**Step 8 encapsulation dot1q *vlan-id*****Example:**

```
Device(config-if-srv)# encapsulation dot1q 100
```

Defines the matching criteria to map 802.1Q frames' ingress on an interface to the service instance.

**Step 9 bridge-domain *bridge-domain-id*****Example:**

```
Device(config-if-srv)# bridge-domain 100
```

Binds the bridge domain to the service instance.

**Step 10 exit****Example:**

```
Device(config-if-srv)# exit
```

Exits service instance configuration mode.

**Step 11 service instance *id* ethernet****Example:**

```
Device(config-if)# service instance 2 ethernet
```

Configures an Ethernet service instance on an interface and enters service instance configuration mode.

**Step 12**     **encapsulation dot1q *vlan-id***

**Example:**

```
Device(config-if-srv)# encapsulation dot1q 101
```

Defines the matching criteria to map 802.1Q frames' ingress on an interface to the service instance.

**Step 13**     **bridge-domain *bridge-domain-id***

**Example:**

```
Device(config-if-srv)# bridge-domain 101
```

Binds the bridge domain to the service instance.

**Step 14**     **exit**

**Example:**

```
Device(config-if-srv)# exit
```

Exits QoS policy-map class configuration mode.

**Step 15**     **end**

**Example:**

```
Device(config-if)# end
```

(Optional) Exits interface configuration mode.

## Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs

### Example: Configuring Hierarchical QoS Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure hierarchical QoS port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all EFPs configured on the interface:

```
policy-map parent-llq
  class class-default
    service-policy child-llq
```

```

policy-map child-llq
  class precedenc-1
    set cos 5
  bandwidth percent 20
  class precedenc-2
    bandwidth percent 80

interface GigabitEthernet 0/0/1
  no ip address
  negotiation auto
  service-policy output parent-llq
  service instance 1 ethernet
    encapsulation dot1q 100
    bridge-domain 100
  !
  service instance 2 ethernet
    encapsulation dot1q 101
    bridge-domain 101

```




---

**Note** Only match EFP and match qos-group is supported on RSP3 in egress policy map.

---

## Example: Configuring Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all Ethernet Flow Points (EFPs) configured on the interface:

```

policy-map llq_flat
  class dscp-af1
    priority
  class dscp-af2
    shape average 200000000
  class dscp-af3
    bandwidth 400000

interface GigabitEthernet 0/0/1
  no ip address
  negotiation auto
  service-policy output llq_flat
  service instance 1 ethernet
    encapsulation dot1q 100
    bridge-domain 100
  !
  service instance 2 ethernet
    encapsulation dot1q 101
    bridge-domain 101

```

# Additional References

## Related Documents

Related Topic	Document Title
Cisco IOS commands	<a href="#">Cisco IOS Master Commands List, All Releases</a>
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<a href="#">Cisco IOS QoS Command Reference</a>
Policing and shaping	"Policing and Shaping Overview" module
Class maps	"Applying QoS Features Using the MQC" module
Policy maps	"Applying QoS Features Using the MQC" module
Low Latency Queueing	<a href="#">QoS Congestion Management Configuration Guide</a>

## Standards and RFCs

Standard	Title
No new or modified standards are supported, and support for existing standards has not been modified.	--

## MIBs

MIB	MIBs Link
No new or modified MIBs are supported, and support for existing MIBs has not been modified.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL:  <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

## Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>





## CHAPTER 4

# Control Plane Policing

The Control Plane Policing feature allows you to configure a quality of service (QoS) filter that manages the traffic flow of control plane packets to protect the control plane of routers and switches against reconnaissance and denial-of-service (DoS) attacks. In this way, the control plane (CP) can help maintain packet forwarding and protocol states despite an attack or heavy traffic load on the router or switch.

- [Information About Control Plane Policing, on page 27](#)
- [How to Use Control Plane Policing, on page 37](#)
- [Configuration Examples for Control Plane Policing, on page 42](#)
- [Additional References, on page 43](#)

## Information About Control Plane Policing

### Control Plane Policing Overview

To protect the control plane on a router from DoS attacks and to provide fine-control over the traffic to the control plane, the Control Plane Policing feature treats the control plane as a separate entity with its own interface for ingress (input) and egress (output) traffic. This interface is called the punt or inject interface, and it is similar to a physical interface on the router. Along this interface, packets are punted from the forwarding plane to the RP (in the input direction) and injected from the RP to the forwarding plane (in the output direction). A set of quality of service (QoS) rules can be applied on this interface (in the input direction) in order to achieve CoPP.


These QoS rules are applied only after the packet has been determined to have the control plane as its destination. You can configure a service policy (QoS policy map) to prevent unwanted packets from progressing after a specified rate limit has been reached; for example, a system administrator can limit all TCP/TELNET packets that are destined for the control plane.

You can use the **platform qos-feature copp-mpls enable** command to enable the Control Plane Policing feature on the device for MPLS explicit null scenario, control packets destined to the device is punted to proper control CPU Q. If CoPP-MPLS remains disabled, then self destined control packets like BGP, LDP, telnet and so on, that are MPLS explicit null tagged are not classified by CoPP and is punted to HOST\_Q instead of CFM\_Q/CONTROL\_Q.



**Note** The command **platform qos-feature copp-mpls enable** is supported only on Cisco ASR 920 platform.

**Figure 1: Abstract Illustration of a Router with a Single RP and Forwarding Plane**



The figure provides an abstract illustration of the router with a single RP and forwarding plane. Packets that are destined to the control plane come in through the carrier card and then go through the forwarding plane before being punted to the RP. When an input QoS policy map is configured on the control plane, the forwarding plane performs the QoS action (for example, a transmit or drop action) before punting packets to the RP in order to achieve the best protection of the control plane in the RP.



**Note** The figure is not applicable to the RSP3 module.



**Note** As mentioned in this section, the control plane interface is directly connected to the RP, so all traffic through the control plane interface to or from the control-plane is not subject to the CoPP function performed by the forwarding plane.

## Benefits of Control Plane Policing

Configuring the Control Plane Policing feature on your Cisco router or switch provides the following benefits:

- Protection against DoS attacks at infrastructure routers and switches
- QoS control for packets that are destined to the control plane of Cisco routers or switches
- Ease of configuration for control plane policies
- Better platform reliability and availability

## Control Plane Terms to Understand

On the router, the following terms are used for the Control Plane Policing feature:

- Control plane—A collection of processes that run at the process level on the Route Processor (RP). These processes collectively provide high-level control for most Cisco IOS XE functions. The traffic sent to or sent by the control plane is called control traffic.

- Forwarding plane—A device that is responsible for high-speed forwarding of IP packets. Its logic is kept simple so that it can be implemented by hardware to do fast packet-forwarding. It punts packets that require complex processing (for example, packets with IP options) to the RP for the control plane to process them.

## Supported Protocols

The following table lists the protocols supported on Control Plane Policing feature. It is mandatory that the IP address should match the source or destination IP address.

Supported Protocols	Criteria	Match	Queue#
TFTP - Trivial FTP	IP/Port Match	<pre>permit udp 64.202.160.0 0.0.1.255 eq 69 any  permit udp 64.202.160.0 0.0.1.255 any eq 69</pre>	NQ_CPU_HOST_Q
TELNET	IP/Port Match	<pre>permit tcp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq telnet  permit tcp 169.223.252.0 0.0.3.255 eq telnet host 169.223.253.1</pre>	NQ_CPU_CONTROL_Q
NTP - Network Time Protocol	IP/Port Match	<pre>permit udp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq ntp  permit udp 169.223.252.0 0.0.3.255 eq ntp host 169.223.253.1</pre>	NQ_CPU_HOST_Q
FTP - File Transfer Protocol	IP/Port Match	<pre>permit tcp host &lt;FTP server&gt; eq ftp &lt;loopback block&gt;  permit tcp host &lt;FTP server&gt; &lt;loopback block&gt; eq ftp</pre>	NQ_CPU_HOST_Q
SNMP - Simple Network Management Protocol	IP/Port Match	<pre>permit udp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq snmp  permit udp 169.223.252.0 0.0.3.255 eq snmp host 169.223.253.1</pre>	NQ_CPU_HOST_Q

Supported Protocols	Criteria	Match	Queue#
TACACS - Terminal Access Controller Access-Control System	IP/Port Match	<pre> permit tcp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq tacacs  permit tcp 169.223.252.0 0.0.3.255 eq tacacs host 169.223.253.1  permit udp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq tacacs  permit udp 169.223.252.0 0.0.3.255 eq tacacs host 169.223.253.1 </pre>	NQ_CPU_HOST_Q
FTP-DATA	IP/Port Match	<pre> permit tcp any any eq 20 permit tcp any eq 20 any permit udp any any eq 20 permit udp any eq 20 any </pre>	NQ_CPU_HOST_Q
HTTP - Hypertext Transfer Protocol	IP/Port Match	<pre> permit tcp any any eq www  permit tcp any eq www any </pre>	NQ_CPU_HOST_Q
WCCP - Web Cache Communication Protocol	IP/Port Match	<pre> IP access list copp-system-acl-wccp  10 permit udp any eq 2048 any eq 2048 </pre>	NQ_CPU_HOST_Q
BGP - Border Gateway Protocol	IP/Port Match	<pre> permit tcp 169.223.252.0 0.0.3.255 host 169.223.253.1 eq bgp  permit tcp 169.223.252.0 0.0.3.255 eq bgp host 169.223.253.1 </pre>	NQ_CPU_CFM_Q

Supported Protocols	Criteria	Match	Queue#
SSH - Secure Shell	IP/Port Match	<pre> permit udp [remote vty mgmt subnet] 0.0.0.255 any eq 22  permit udp [remote vty mgmt subnet] 0.0.0.255 eq 22 any  permit tcp [remote vty mgmt subnet] 0.0.0.255 any eq 22  permit tcp [remote vty mgmt subnet] 0.0.0.255 eq 22 any </pre>	NQ_CPU_HOST_Q
ICMP - Internet Control Message Protocol	Protocol Match	<pre> access-list 110 permit icmp any 169.223.253.1 </pre>	NQ_CPU_HOST_Q
ISAKMP - Internet Security Association and Key Management Protocol	IP/Port Match	<pre> permit udp any host x.x.x.x eq isakmp  permit udp any eq isakmp host x.x.x.x  permit udp any host x.x.x.x eq non500-isakmp  permit udp any eq non500-isakmp host x.x.x.x </pre>	NQ_CPU_HOST_Q
SAA - Service Assurance Agent	IP/Port Match	<pre> permit icmp host 10.2.2.4 host 10.1.1.1 </pre>	NQ_CPU_HOST_Q
DHCP - Dynamic Host Configuration Protocol	IP/Port Match	<pre> permit udp host 0.0.0.0 host 255.255.255.255 eq bootps  permit udp any eq bootps any eq bootps  permit udp host 0.0.0.0 host 255.255.255.255 eq bootpc  permit udp any eq bootpc any eq bootpc </pre>	NQ_CPU_HOST_Q

Supported Protocols	Criteria	Match	Queue#
DNS - Domain Name System	IP/Port Match	permit udp host <DNS server> eq domain any permit udp host <DNS server> any eq domain permit tcp host <DNS server> eq domain any permit tcp host <DNS server> any eq domain	NQ_CPU_HOST_Q
DLSw - Data-Link Switching	IP/Port Match	permit any any eq 2065 permit any eq 2065 any	NQ_CPU_HOST_Q
LDP - Label Distribution Protocol	IP/Port Match	permit tcp any any eq 646 permit tcp any eq 646 any permit udp any any eq 646 permit udp any eq 646 any	NQ_CPU_CFM_Q

Supported Protocols	Criteria	Match	Queue#
RADIUS - Remote Authentication Dial In User Service	IP/Port Match	permit udp 64.202.160.0 0.0.1.255 eq 1645 any permit udp 64.202.160.0 0.0.1.255 any eq 1645 permit udp 64.202.160.0 0.0.1.255 eq 1646 any permit udp 64.202.160.0 0.0.1.255 any eq 1646 permit udp 64.202.160.0 0.0.1.255 eq 1812 any permit udp 64.202.160.0 0.0.1.255 any eq 1812 permit udp 64.202.160.0 0.0.1.255 eq 1813 any permit udp 64.202.160.0 0.0.1.255 any eq 1813 permit tcp 64.202.160.0 0.0.1.255 eq 1645 any permit tcp 64.202.160.0 0.0.1.255 any eq 1645 permit tcp 64.202.160.0 0.0.1.255 eq 1646 any permit tcp 64.202.160.0 0.0.1.255 any eq 1646 permit tcp 64.202.160.0 0.0.1.255 eq 1812 any permit tcp 64.202.160.0 0.0.1.255 any eq 1812 permit tcp 64.202.160.0 0.0.1.255 eq 1813 any permit tcp 64.202.160.0 0.0.1.255 any eq 1813	NQ_CPU_HOST_Q
HSRP - Hot Standby Router Protocol	IP/Port Match	permit udp any 224.0.0.0/24 eq 1985 permit udp any eq 1985 224.0.0.0/24	NQ_CPU_HOST_Q

Supported Protocols	Criteria	Match	Queue#
Network Configuration Protocol (NETCONF)	IP/Port Match	IP access list ext copp-system-acl-telnet permit tcp any any eq 830 - NETCONF	NQ_CPU_HOST_Q
PostgreSQL Support	IP/Port Match	IP access list ext copp-system-acl-telnet PostgreSQL IP/Port Match permit tcp 169.223.252.0.0 0.0.3.255 host 169.223.253.1 eq 5432	NQ_CPU_HOST_Q
Source IP or Destination IP	IP Match only	Permit IP host 10.1.1.1 or 10.1.1.2  <b>Note</b> The <b>permit ip any any</b> command is not supported.	NQ_CPU_HOST_Q

## Input Rate-Limiting and Silent Mode Operation

A router is automatically enabled to silently discard packets when you configure input policing on control plane traffic using the **service-policy input** *policy-map-name* command.

Rate-limiting (policing) of input traffic from the control plane is performed in silent mode. In silent mode, a router that is running Cisco IOS XE software operates without receiving any system messages. If a packet that is entering the control plane is discarded for input policing, you do not receive an error message.

## Restrictions for Control Plane Policing

### Input Rate-Limiting Support

Input rate-limiting is performed in silent (packet discard) mode. Silent mode enables a router to silently discard packets using policy maps applied to input control plane traffic with the **service-policy input** command. For more information, see the “Input Rate-Limiting and Silent Mode Operation” section.

### MQC Restrictions

The Control Plane Policing feature requires the Modular QoS CLI (MQC) to configure packet classification and traffic policing. All restrictions that apply when you use the MQC to configure traffic policing also apply when you configure control plane policing.

### Match Criteria Support

Only the extended IP access control lists (ACLs) classification (match) criteria is supported.



### Restrictions for CoPP

- IPv6 is not supported.
- Port range ACL is not supported.
- To filter MPLS labeled packets, use the **platform qos-feature copp-mpls enable** command.
- Due to hardware limitation, to match the control plane packets against CoPP, ACL rules that match with IP addresses should be added, since adding generic ACL rules with any any matches both the data plane and control plane traffic.

## IP Access List Overview

Access control lists (ACLs) perform packet filtering to control which packets move through the network and where. Such control provides security by helping to limit network traffic, restrict the access of users and devices to the network, and prevent traffic from leaving a network. IP access lists can reduce the chance of spoofing and denial-of-service attacks and allow dynamic, temporary user access through a firewall.

IP access lists can also be used for purposes other than security, such as bandwidth control, restricting the content of routing updates, redistributing routes, triggering dial-on-demand (DDR) calls, limiting debug output, and identifying or classifying traffic for quality of service (QoS) features. This module provides an overview of IP access lists.

## Benefits

### Improved Traffic Flow

This feature improves the Turbo ACL processing process in PXF by more expediently removing older entries. As a result, more Turbo ACL processing can be done in the PXF processing path, thereby allowing more router traffic to be accelerated using the PXF processing path.

### Configuration of Route Processor Memory Limits for ACL Processing

This feature allows users to set the amount of memory reserved for ACL processes (such as compilation, storage, and classification) in the RP path. Users who need more memory for ACL processes now have the ability to set aside additional memory resources in the RP path for ACL processes. Users who need more memory for other processes in the RP path now can set aside less memory for ACL processes.

### Benefits of IP Access Lists

Access control lists (ACLs) perform packet filtering to control the flow of packets through a network. Packet filtering can restrict the access of users and devices to a network, providing a measure of security. Access lists can save network resources by reducing traffic. The benefits of using access lists are as follows:

- Authenticate incoming rsh and rcp requests—Access lists can simplify the identification of local users, remote hosts, and remote users in an authentication database that is configured to control access to a device. The authentication database enables Cisco software to receive incoming remote shell (rsh) and remote copy (rcp) protocol requests.
- Block unwanted traffic or users—Access lists can filter incoming or outgoing packets on an interface, thereby controlling access to a network based on source addresses, destination addresses, or user authentication. You can also use access lists to determine the types of traffic that are forwarded or blocked

at device interfaces. For example, you can use access lists to permit e-mail traffic to be routed through a network and to block all Telnet traffic from entering the network.

- Control access to vty—Access lists on an inbound vty (Telnet) can control who can access the lines to a device. Access lists on an outbound vty can control the destinations that the lines from a device can reach.
- Identify or classify traffic for QoS features—Access lists provide congestion avoidance by setting the IP precedence for Weighted Random Early Detection (WRED) and committed access rate (CAR). Access lists also provide congestion management for class-based weighted fair queueing (CBWFQ), priority queueing, and custom queueing.
- Limit debug command output—Access lists can limit debug output based on an IP address or a protocol.
- Provide bandwidth control—Access lists on a slow link can prevent excess traffic on a network.
- Provide NAT control—Access lists can control which addresses are translated by Network Address Translation (NAT).
- Reduce the chance of DoS attacks—Access lists reduce the chance of denial-of-service (DoS) attacks. Specify IP source addresses to control traffic from hosts, networks, or users from accessing your network. Configure the TCP Intercept feature to can prevent servers from being flooded with requests for connection.
- Restrict the content of routing updates—Access lists can control routing updates that are sent, received, or redistributed in networks.
- Trigger dial-on-demand calls—Access lists can enforce dial and disconnect criteria.

## IP Address Range-Based Filtering Support for CoPP ACL

IP Access Control Lists are a set of rules that perform packet filtering to control the flow of packets through a network. Packet filtering provides security by the following features:

- Limiting the access of traffic into a network.
- Restricting user and device access to a network.
- Preventing traffic from leaving a network.
- Reduce the chance of spoofing and denial-of-service attacks.

**Table 1: Feature History Table**

Feature Name	Release Information	Description
IP Address Range-Based Filtering Support for CoPP ACL	Cisco IOS XE Bengaluru 17.5.1	The CoPP ACL Template feature supports Ingress on In-band Management Loopback interface and Ingress on Data plane interface to block traffic using MPLS. CoPP ACL supports Source IP based filtering on the Cisco router.

Prior to the Cisco IOS XE Bengaluru 17.5.1 release, IP address Range-Based Filtering for CoPP ACL was not supported. Effective Cisco IOS XE Bengaluru 17.5.1 this feature enables you to securely manage MPLS traffic by supporting the following requirements:

- Ingress on In-Band Management Loopback interface.
- Ingress on Data plane interface to block MGMT Traffic on MPLS.

# How to Use Control Plane Policing

## Defining Control Plane Services

Perform this task to define control plane services, such as packet rate control and silent packet discard for the RP.

### Before you begin

Before you enter control-plane configuration mode to attach an existing QoS policy to the control plane, you must first create the policy using MQC to define a class map and policy map for control plane traffic.

- Platform-specific restrictions, if any, are checked when the service policy is applied to the control plane interface.
- Input policing does not provide any performance benefits. It simply controls the information that is entering the device.

---

### Step 1 enable

#### Example:

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

### Step 2 configure terminal

#### Example:

```
Device# configure terminal
```

Enters global configuration mode.

### Step 3 control-plane

#### Example:

```
Device(config)# control-plane
```

Enters control-plane configuration mode (which is a prerequisite for defining control plane services).

### Step 4 service-policy [input |output] policy-map-name

#### Example:

```
Device(config-cp)# service-policy input control-plane-policy
```

Attaches a QoS service policy to the control plane.

- **input**—Applies the specified service policy to packets received on the control plane.

- *policy-map-name*—Name of a service policy map (created using the **policy-map** command) to be attached.

**Step 5** end**Example:**

```
Device(config-cp) # end
```

(Optional) Returns to privileged EXEC mode.

## Verifying Control Plane Services

**Step 1** enable**Example:**

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

**Step 2** show policy-map control-plane [all] [input |output [class *class-name*]]**Example:**

```
Device# show policy-map control-plane all
```

Displays information about the control plane.

- **all**—(Optional) Displays service policy information about all QoS policies used on the CP.
- **input**—(Optional) Displays statistics for the attached input policy.
- **class *class-name***—(Optional) Specifies the name of the traffic class whose configuration and statistics are displayed.

**Step 3** exit**Example:**

```
Device# exit
```

(Optional) Exits privileged EXEC mode.

### Examples

The following example shows that the policy map TEST is associated with the control plane.

```
Router# show policy-map control-plane
Control Plane
```

```
Service-policy input: copp-ftp
```

```
Class-map: copp-ftp (match-any)
2234 packets, 223400 bytes
```

```

5 minute offered rate 0000 bps, drop rate 0000 bps
Match: access-group name copp-ftp
police:
cir 10000000 bps, be 312500 bytes
conformed 2234 packets, 223400 bytes; actions:
transmit
exceeded 0 packets, 0 bytes; actions:
drop
conformed 0000 bps, exceeded 0000 bps

Class-map: class-default (match-any)
0 packets, 0 bytes
5 minute offered rate 0000 bps, drop rate 0000 bps
Match: any

```

## Configuring Control Plane Policing to Mitigate Denial-of-Service Attacks

Apply control plane policing (CoPP) to ICMP packets to mitigate denial of service (DoS) attacks.

- 
- Step 1**     **enable**
- Example:**  
Device> enable  
Enables privileged EXEC mode.
- Step 2**     **configure terminal**
- Example:**  
Device# configure terminal  
Enters global configuration mode.
- Step 3**     **access-list *access-list-number* permit protocol {*tcd* | *udp*} {*any* | *host* {*source-addr* | *name*}} eq port number {*any* | *host* {*source-addr* | *name*}} eq port number**
- Example:**  
Device(config)# access-list 111 permit udp any eq 1699 any eq 1698  
Configures an access list for filtering frames by UDP protocol and matches only packets with a given port number.
- Step 4**     **class-map [*match-any* | *match-all* | *type*] *class-map-name***
- Example:**  
Device(config)# class-map match-any MyClassMap  
Creates a class-map and enters QoS class-map configuration mode.
- Step 5**     **match access-group [*access-list-index* | *access-group-name*]**
- Example:**  
Device(config-cmap)# match access-group 111  
Specifies access groups to apply to an identity policy. The range of valid values is 1-2799.
- Step 6**     **exit**
- Example:**

```
Device(config-cmap)# exit
```

Exits QoS class-map configuration mode and returns to global configuration mode.

### Step 7 **policy-map** *policy-map-name*

#### Example:

```
Device(config)# policy-map Policy1
```

Specifies a service policy and enters QoS policy-map configuration mode.

### Step 8 **class** [*class-map-name* | *class-default*]

#### Example:

```
Device(config-pmap)# class MyClassMap
```

Enters QoS policy-map class configuration mode

### Step 9 **police** {*rate-bps* | **cir** {*cir-bps* | **percent percent**} } [**bc burst-bytes**] [**conform-action** | **exceed-action** | **violate-action**]*action*] [ ]

#### Example:

```
police cir 10000000 bc 8000 pir 12000000 be 8000 conform-action transmit exceed-action transmit violate-action drop
```

Configure a traffic policer based on the traffic rate or committed information rate (CIR). By default, no policer is defined.

- **rate-bps**—Specifies average traffic rate in bits per second (b/s). The range is 64000 to 10000000000. Supply an optional postfix (K, M, G). Decimal point is allowed.
- **cir**—Specifies a committed information rate (CIR).
- **cir-bps**—Specifies a CIR in bits per second (b/s). The range is 64000 to 10000000000. Supply an optional postfix (K, M, G). Decimal point is allowed.
- **bc burst-bytes**—(Optional) Specifies the conformed burst (be) or the number of acceptable burst bytes. The range is 8000 to 16000000.
- **conform-action action**— (Optional) Specifies action to take on packets that conform to the specified rate limit.
- **pir pir-bps**—(Optional) Specifies the peak information rate (PIR).

**Note** **cir percent percent** option is not supported on the router.

### Step 10 **exit**

#### Example:

```
Device(config-pmap-c-police)# exit
```

Exits policy-map class police configuration mode

### Step 11 **exit**

#### Example:

```
Device(config-pmap-c)# exit
```

Exits policy-map class configuration mode

**Step 12**     **exit****Example:**

```
Device(config-pmap)# exit
```

Exits policy-map configuration mode

**Step 13**     **control-plane****Example:**

```
Device(config)# control-plane
```

Enters control plane configuration mode.

**Step 14**     **service-policy** *input policy-map-name***Example:**

```
Device(config-cp)# service-policy input Policy1
```

Attaches a policy map to a control plane.

**Step 15**     **exit****Example:**

```
Device(config-cp)# exit
```

Exits control plane configuration mode and returns to global configuration mode.

**Step 16**     **exit****Example:**

```
Device(config)# exit
```

Exits global configuration mode returns to privileged EXEC mode.

## Configuring CoPP ACL

### Before you begin

- To filter MPLS labelled packets, use the **platform qos-feature copp-mpls enable** command.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **platform qos-feature copp-mpls enable**
4. **exit**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enter privileged EXEC mode.

	Command or Action	Purpose
	<b>Example:</b> Device> enable	<ul style="list-style-type: none"> <li>Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Router# <b>configure terminal</b>	Enter global configuration mode.
<b>Step 3</b>	<b>platform qos-feature copp-mpls enable</b> <b>Example:</b> Router(config)#platform qos-feature copp-mpls enable	Configure the CoPP MPLS command on the Cisco Router.
<b>Step 4</b>	<b>exit</b> <b>Example:</b> Router(config)#exit	Exit global configuration mode.

## Verifying CoPP ACL

The following example shows how to verify the CoPP ACL on the Cisco Router.

```
Router(config)#sdm prefer enable_acl_copp
COPP ACL template change.
Current template = disable_acl_copp
Updated template = enable_acl_copp
Standby is reloaded, it will come up with in it required for new template
once standby comes up Please trigger SSO
```

# Configuration Examples for Control Plane Policing

## Example: Configuring Control Plane Policing on Input Telnet Traffic

The following example shows how to apply a QoS policy for aggregate control plane services to Telnet traffic that is received on the control plane. Trusted hosts with source addresses 10.1.1.1 and 10.1.1.2 forward Telnet packets to the control plane but are still policed for a maximum rate.

All remaining Telnet packets are dropped by the control-plane.

```
! Define trusted host traffic.
DEVICE(config)#ip access-list extended telnet-trust
DEVICE(config-ext-nacl)#10 permit tcp host 10.1.1.1 any eq telnet
DEVICE(config-ext-nacl)#20 permit tcp host 10.1.1.2 any eq telnet
DEVICE(config-ext-nacl)#exit

! Define all other Telnet traffic.
DEVICE(config)#ip access-list extended telnet-drop
DEVICE(config-ext-nacl)#10 permit tcp any any eq telnet
DEVICE(config-ext-nacl)#exit

! Define class map for trusted hosts
DEVICE(config)#class-map match-all copp-trust
```



```

DEVICE(config-cmap)#match access-group name telnet-trust
DEVICE(config-cmap)#exit

! Define class map for un-trusted hosts
DEVICE(config)#class-map match-all copp-drop
DEVICE(config-cmap)#match access-group name telnet-drop
DEVICE(config-cmap)#exit

! Define the policy-map for both type of hosts
DEVICE(config)#policy-map control-plane-in
DEVICE(config-pmap)#class copp-trust
DEVICE(config-pmap-c)#police 1000000 conform-action transmit exceed-action drop
DEVICE(config-pmap-c-police)#class copp-drop
DEVICE(config-pmap-c-police)#exit
DEVICE(config-pmap-c)#police 1000000 conform-action drop exceed-action drop
DEVICE(config-pmap-c-police)#exit
DEVICE(config-pmap-c)#exit
DEVICE(config-pmap-c)#exit
DEVICE(config-pmap)#exit

! Define aggregate control plane service for the active route processor.
DEVICE((config)#control-plane
DEVICE(config-cp)#service-policy input control-plane-in
DEVICE(config-cp)#end

! Rate-limit all other Telnet traffic.
Device(config)# access-list 140 permit tcp any any eq telnet

! Define class-map "telnet-class."
Device(config)# class-map telnet-class
Device(config-cmap)# match access-group 140
Device(config-cmap)# exit
Device(config)# policy-map control-plane-in
Device(config-pmap)# class telnet-class
Device(config-pmap-c)# police 80000 conform transmit exceed drop
Device(config-pmap-c)# exit
Device(config-pmap-c)# exit
Device(config-pmap)# exit

! Define aggregate control plane service for the active route processor.
Device(config)# control-plane
Device(config-cp)# service-policy input control-plane-in
Device(config-cp)# end

```

## Additional References

### Related Documents

Related Topic	Document Title
Cisco IOS commands	<a href="https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/mcl/allreleasemcl/all-book.html">https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/mcl/allreleasemcl/all-book.html</a>

### Standards and RFCs

Standard/RFC	Title
No specific Standards and RFCs are supported by the features in this document.	—

**MIBs**

<b>MB</b>	<b>MIBs Link</b>
—	<p>To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p><a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a></p>

**Technical Assistance**

<b>Description</b>	<b>Link</b>
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<p><a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a></p>



## CHAPTER 5

# Priority Shaper

Earlier, when the priority of a queue at Per-Hop Behavior (PHB) was propagated all the way up the hierarchy towards the channel level, the PHB classes that had priority at PHB level would only be prioritized over other classes of subchannels. To avoid this, Priority Shaper feature is implemented.

Priority Shaper feature helps to balance the packet drops between the streams when multiple streams egress out of a priority queue. Egress QoS policy is supported on Priority Shaper.

- [Restrictions for Priority Shaper, on page 45](#)
- [Configuring Priority Shaper, on page 45](#)

## Restrictions for Priority Shaper

- Priority Shaper is supported only for PHB level classes.
- Egress QoS Policy map with Priority Shaper can be applied only on the member interface of port channel and not at the logical level.
- Policer configuration is not supported with the Priority Shaper configuration under same class map.
- Priority Traffic Latency is increased during congestion with Priority Shaper configuration at Q level. Configure the queue limit with a lesser value for the priority queue to reduce the latency of priority traffic.
- If the packet is from a 10G interface to a 1G interface, the burstiness is introduced. Due to this, dequeuing rate of this strict priority queue may be sometimes more than enqueueing. As a result, very few packet counters are seen in other queues.

## Configuring Priority Shaper

Perform the following steps to configure Priority Shaper.

### Step 1

**enable**

#### Example:

```
Device> enable
```

Enables privileged EXEC mode.

- Enter your password if prompted.

## Step 2 **configure terminal**

### Example:

```
Device# configure terminal
```

Enters global configuration mode.

## Step 3 **class-map** *class-map-name*

### Example:

```
Device(config)#class-map class_priority
```

Configures class map and specifies the name of the class map to be created.

## Step 4 **match cos** *number*

### Example:

```
Device(config-cmap)# match cos 1
```

Matched different PHBs for different class maps.

## Step 5 **policy-map** *policy-map-name*

### Example:

```
Device(config)#policy-map shape_priority
```

Configures the policy map.

## Step 6 **class** *class-map-name*

### Example:

```
Device(config-pmap)#class class_priority
```

Specifies the name of the class whose policy you want to create and enters policy-map class configuration mode. This class is associated with the class map that is created earlier.

## Step 7 **priority level** *<level 1/2 >* **percent** *<percentage 1-100 >* or **priority level** *<level 1/2>* *<kbps>* *<burst size>*

### Example:

```
Device(config-pmap-c)# priority <1-10000000> Kilo Bits per second
Device(config-pmap-c)# priority Percent <1-100>
Device(config-pmap-c)# priority level <1-2> <1-10000000> Kilo Bits per second
Device(config-pmap-c)# priority level <1-2> percent <1-100>
```

Assigns priority to a traffic class at the priority level specified.

**Note** **level** is the level of priority assigned to the priority class. Valid values are 1 (high priority) and 2 (low priority). The default value is 1. Do not specify the same priority level for two different classes in the same policy map.

## Step 8 **interface** *interface-type interface-number*

### Example:

```
Device(config)# interface gigabitethernet 0/0/1
```

Specifies the port to attach to the policy map and allows to enter the interface configuration mode. Valid interfaces are physical ports.

## Step 9 **service-policy output** *policy-map-name*

**Example:**

```
Device(config-if)# service instance 1 ethernet
Device(config-if-srv)# service-policy output shape_priority
```

Applies output policy to the interface.

**Note** You can also attach the service policy over the service instance.

**Step 10**

```
end
```

**Example:**

```
Device(config)#end
```

Returns to privileged EXEC mode.

## Configuration Examples for Priority Shaper

This section shows sample configurations for Priority Shaper.

### Example: Configuring Priority Shaper

The following is a sample configuration for priority shaper.

```
Device(config)#class-map match-any class_level1
Device(config-cmap)#match cos 1
Device(config-cmap)#match cos 2
Device(config-cmap)#class-map match-any class_level2
Device(config-cmap)#match cos 3
Device(config-cmap)#match cos 4
Device(config-cmap)#class-map match-any class_bw
Device(config-cmap)#match cos 5
Device(config-cmap)#end

.
Device(config)#policy-map shape_priority
Device(config-pmap)#class class_level1
Device(config-pmap-c)#priority level 1 per 10
Device(config-pmap-c)#class class_level2
Device(config-pmap-c)#priority level 2 per 20
Device(config-pmap-c)#class class_bw
Device(config-pmap-c)#bandwidth remaining percent 70
Device(config-pmap-c)#end

Device(config)#interface GigabitEthernet0/0/3
Device(config-if)#load-interval 30
Device(config-if)#service-policy output shape_priority
Device(config-if)#end
```



**Note** The match cos is *not* supported at egress on the Cisco RSP3 Module.

## Verifying Priority Shaper

Use the following command to verify that the Priority Shaper feature is configured on your interface.

```
Device# show policy-map interface TenGigabitEthernet0/0/2
show policy-map interface TenGigabitEthernet0/0/2
TenGigabitEthernet0/0/2

Service-policy output: shape_priority

queue stats for all priority classes:
  Queueing
  priority level 1
  queue limit 3932 us/ 49152 bytes
  (queue depth/total drops/no-buffer drops) 49476/44577300/0
  (pkts output/bytes output) 2348138/1202246656

queue stats for all priority classes:
  Queueing
  priority level 2
  queue limit 1966 us/ 49152 bytes
  (queue depth/total drops/no-buffer drops) 51072/42228358/0
  (pkts output/bytes output) 4697080/2404904960

Class-map: class_priority (match-any)
  46925438 packets, 24025824256 bytes
  30 second offered rate 1871849000 bps, drop rate 1778171000 bps
  Match: cos 1
  Match: cos 2
  Priority: 10% (100000 kbps), burst bytes 2500000, b/w exceed drops: 44577300

  Priority Level: 1

Class-map: class_priority_level2 (match-any)
  46925438 packets, 24025824256 bytes
  30 second offered rate 1871849000 bps, drop rate 1684485000 bps
  Match: cos 3
  Match: cos 4
  Priority: 20% (200000 kbps), burst bytes 5000000, b/w exceed drops: 42228358

  Priority Level: 2

Class-map: class_bw (match-any)
  23462719 packets, 12012912128 bytes
  30 second offered rate 935925000 bps, drop rate 281045000 bps
  Match: cos 5
  Queueing
  queue limit 393 us/ 49152 bytes
  (queue depth/total drops/no-buffer drops) 49476/7045085/0
  (pkts output/bytes output) 16417634/8405828608
  bandwidth remaining 70%

Class-map: class-default (match-any)
  0 packets, 0 bytes
  30 second offered rate 0000 bps, drop rate 0000 bps
  Match: any

  queue limit 393 us/ 49152 bytes
  (queue depth/total drops/no-buffer drops) 0/0/0
  (pkts output/bytes output) 0/0
```



## CHAPTER 6

# Hierarchical Color-Aware Policing

The Hierarchical Color-Aware Policing feature provides two levels of policing where the policer ordering is evaluated from child to parent, and there is preferential treatment of certain traffic at the parent level.

- [Prerequisites for Hierarchical Color-Aware Policing, on page 49](#)
- [Restrictions for Hierarchical Color-Aware Policing, on page 49](#)
- [Information About Hierarchical Color-Aware Policing, on page 51](#)
- [How to Configure Hierarchical Color-Aware Policing, on page 54](#)
- [Configuration Examples for Hierarchical Color-Aware Policing, on page 57](#)
- [Additional References, on page 59](#)

## Prerequisites for Hierarchical Color-Aware Policing

You must have Cisco IOS XE Release 3.15S or a later version installed and running on your router.

You must already be familiar with relevant features and technologies including modular QoS CLI (MQC) and the master control processor (MCP) software and hardware architecture. The [Additional References, on page 43](#) section provides pointers to relevant feature and technology documents.

## Restrictions for Hierarchical Color-Aware Policing

The following restrictions apply to the Hierarchical Color-Aware Policing feature:

- Color-aware class maps support only QoS group matching.
- Color-aware statistics are not supported, only existing policer statistics.
- Color-aware class map removal (using the **no class-map***class-map-name* command) is not allowed while the class map is being referenced in a color-aware policer. It must be removed from all color-aware policers (using either the **no conform-color***class-map-name* or **no exceed-color***class-map-name* command first).
- By default, the child policer is color-blind. If any control traffic is classified as default class then it may be dropped.
- For dual policers in HQoS policy, if parent policer is color-aware, child level policer cannot be configured as color-aware and is rejected.
- When parent policer is color-aware, child cannot be configured with PIR, it can only be a 1R2C policer.

- QoS-group can be set in child policer through tablemap, but complete child class classification should map either to *conform class qos-group* or *exceed class qos-group*.
- When a parent has a color-aware policy, packets to the parent take the color marking of the child policer.

**The colors for a parent policy using a single rate, three color-policer (1r3c) or dual rate three color-policer (2r3c) scheme are:**

- **green for conform-action**
- **yellow for exceed-action**
- **red for violate-action.**


However, the policer at the child level only supports single rate, two color-policer (1r2c) scheme, and the colors are green for conform-action, and red for exceed-action.

So, even if the exceed action of a child policer is ‘transmit’, all exceed (red) packets from the child policer will always fall into the red bucket of the parent.

You must, therefore, ensure that the conform-color and exceed-color classes together form a superset of the respective class matches so as to avoid packets being treated as red and therefore, being dropped.


See the following images for more information.

Single-Rate, Color-Aware, Three-Color Policer



Dual-Rate, Color-Aware, Three-Color Policer





3164-683

# Information About Hierarchical Color-Aware Policing


## Hierarchical Order Policing

Policers are evaluated from child to parent in QoS policies. This ordering is not configurable for both ingress and egress directions.

The following sample configuration for a simple two-level policer would result in the changed behavior shown in the figure below:

```

policy-map child
  class user1
    police 100k
  class user2
    police 100k
policy-map parent
  class class-default
    police 150k
  service-policy child
    
```




2491833

## Limited Color-Aware Policing

The following sample configuration for a simple two-level color-aware policer would result in the changed behavior shown in the figure below:

```
ip access-list extended user1-acl
 permit ip host 192.168.1.1 any
 permit ip host 192.168.1.2 any
ip access-list extended user2-acl
 permit ip host 192.168.2.1 any
 permit ip host 192.168.2.2 any
class-map match-all user1-acl-child
 match access-group name user1-acl
class-map match-all user2-acl-child
 match access-group name user2-acl
class-map match-all hipri-conform
 match qos-group 5
policy-map child-policy
 class user1-acl-child
  police 10000 bc 1500
  conform-action set-qos-transmit 5
 class user2-acl-child
  police 20000 bc 1500
  conform-action set-qos-transmit 5
 class class-default
  police 50000 bc 1500
policy-map parent-policy
 class class-default
  police 50000 bc 3000
  conform-action transmit
  exceed-action transmit
  violate-action drop
  conform-color hipri-conform
  service-policy child-policy
```

**Figure 2: Simple Two-Level Color-Aware Policer**






**Note** To avoid drops at the parent level for "conformed" child traffic, the parent policer must have a rate and burst that are equal to or greater than the sum of the child conform rates and burst sizes. There is no check for inappropriate (parent-to-child) rates and burst sizes in code. You must be aware of this limitation and configure appropriately. In the following example, explicit marking actions are supported in conjunction with color-aware policing and operate similarly color-aware policer marking actions. If these marking actions ("set qos-group," for example) are present in the child policies, the resulting bit values are evaluated by the parent color-aware policer (same as for child policer marking actions):  $50k \geq 10k \text{ (user1-acl-child)} + 20k \text{ (user2-acl-child)}$

## Policing Traffic in Child Classes and Parent Classes


Prior to the release of the Hierarchical Color-Aware Policing feature, policing and marking were typically used as input QoS options. For example, a voice customer was limited to 112 kb/s for voice control and 200 kb/s for voice traffic. The class-default class has no policer. The only limit is the physical bandwidth of the xDSL connection. As shown in the figure below, a customer could send up to 1000 kb/s. However, this involved sending more voice and voice-control packets, which required policing the traffic for both classes.

**Figure 3: Policing Traffic in Child Classes**



As shown in the figure below, it is important to control the overall input bandwidth. The important requirement is that the premium traffic in the overall limit is not affected. In the figure below, voice and voice-control packets are not dropped in the overall limit. Only packets from the child class-default class are dropped to fulfill the limit.

**Figure 4: Policing Traffic in Parent Classes**



The first classes function the same way. Voice and voice-control are policed to the allowed level and the class-default class is not affected. In the next level, the overall bandwidth is forced to 500 kb/s and must only drop packets from the class-default class. Voice and voice-control must remain unaffected.

The order of policer execution is as follows:

1. Police the traffic in the child classes, as shown in the figure above, police VoIP-Control class to 112 kb/s, police VoIP class to 200 kb/s, and police class-default to 500 kb/s.
2. Police the traffic in the class default of the parent policy map, but only drop the traffic from the child class default, and do not drop the remaining child classes. As shown in the figure above, 112 kb/s VoIP-Control and 200 kb/s VoIP traffic are unaffected at the parent policer, but 500 kb/s class default from the child is policed to 188kb/s to meet the overall police policy of 500 kb/s at the parent level.

# How to Configure Hierarchical Color-Aware Policing

## Configuring the Hierarchical Color-Aware Policing Feature

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **policy-map** *policy-map-name*
4. **class** {*class-name* | **class-default**}
5. **conform-color** *class-map-name* [**exceed-color** *class-map-name*]
6. **police** [**cir** *cir*] [**bc conform-burst**] [**pir** *pir*] [**be peak-burst**] [**conform-action** *action*] [**exceed-action** *action*] [**violate-action** *action*]] [**conform-color** **hipri-conform**] [**exceed-color** **lipri-exceed**]
7. **service-policy** *policy-map-name*
8. **end**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b> <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b> <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>policy-map</b> <i>policy-map-name</i> <b>Example:</b> Router(config)# policy-map child-policy	Enters policy-map configuration mode and creates a policy map.

	Command or Action	Purpose
Step 4	<p><b>class</b> {<i>class-name</i>   <b>class-default</b>}</p> <p><b>Example:</b></p> <pre>Router(config-pmap)# class user1-acl-child</pre>	<p>Enters policy-map class configuration mode.</p> <p>Specifies the name of the class whose policy you want to create or change or specifies the default class (commonly known as the class-default class) before you configure its policy. Repeat this command as many times as necessary to specify the child or parent classes that you are creating or modifying:</p> <ul style="list-style-type: none"> <li>• <b>class name</b>—Name of the class to be configured or whose policy is to be modified. The class name is used for both the class map and to configure a policy for the class in the policy map.</li> <li>• <b>class-default</b>—Specifies the default class so that you can configure or modify its policy.</li> </ul>
Step 5	<p><b>conform-color</b> <i>class-map-name</i> [<b>exceed-color</b> <i>class-map-name</i>]</p> <p><b>Example:</b></p> <pre>Router(config-pmap-c-police)# conform-color c1 exceed-color c2</pre>	<p>Enables color-aware traffic policing and creates the conform-color and exceed-color class-maps used for color-aware traffic policing.</p> <p>The <b>conform-color</b> <i>class-map-name</i> command creates the conform-color class. The <b>exceed-color</b> <i>class-map-name</i> option creates the exceed-color class.</p>
Step 6	<p><b>police</b> [<b>cir</b> <i>cir</i>] [<b>bc</b> <i>conform-burst</i>] [<b>pir</b> <i>pir</i>] [<b>be</b> <i>peak-burst</i>] [<b>conform-action</b> <i>action</i>] [<b>exceed-action</b> <i>action</i>] [<b>violate-action</b> <i>action</i>]]] [<b>conform-color</b> <i>hipri-conform</i>] [<b>exceed-color</b> <i>lipri-exceed</i>]</p> <p><b>Example:</b></p> <pre>Router(config-pmap-c)# police 10000 bc 1500</pre> <p><b>Example:</b></p> <pre>Router(config-pmap-c-police)# conform-action set-qos-transmit 5</pre>	<p>Configures traffic policing and specifies multiple actions applied to packets marked as conforming to, exceeding, or violating a specific rate.</p> <p>Enters policy-map class police configuration mode. Use one line per action that you want to specify:</p> <ul style="list-style-type: none"> <li>• <b>cir</b>—Committed information rate. Indicates that the CIR will be used for policing traffic.</li> <li>• <b>conform-action</b>—(Optional) Action to take on packets when the rate is less than the conform burst.</li> <li>• <b>exceed-action</b>—(Optional) Action to take on packets whose rate is within the conform and conform plus exceed burst.</li> <li>• <b>violate-action</b>—(Optional) Action to take on packets whose rate exceeds the conform plus exceed burst. You must specify the exceed action before you specify the violate action.</li> <li>• <b>conform-color</b>—(Optional) Enables color-aware policing (on the policer being configured) and assigns the class map to be used for conform color determination. The <b>hipri-conform</b> keyword is the class map (previously configured via the <b>class-map</b> command) to be used.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>exceed-color</b>—(Optional) Enables color-aware policing (on the policer being configured) and assigns the class map to be used for exceed color determination. The <b>lipri-exceed</b> keyword is the class map (previously configured via the <b>class-map</b> command) to be used.</li> </ul>
<b>Step 7</b>	<b>service-policy</b> <i>policy-map-name</i> <b>Example:</b> <pre>Router(config-pmap-c-police)# service-policy child-policy</pre>	Specifies a service policy as a QoS policy within a policy map (called a hierarchical service policy). <ul style="list-style-type: none"> <li>• <i>policy-map-name</i>—Name of the predefined policy map to be used as a QoS policy. The name can be a maximum of 40 alphanumeric characters.</li> </ul>
<b>Step 8</b>	<b>end</b> <b>Example:</b> <pre>Router(config-pmap-c-police)# end</pre>	Exits the current configuration mode.

### Example

The following is a sample configuration for the Hierarchical Color-Aware Policing feature:

```
class-map qos_group1
match qos_group 1

class-map qos_group2
match qos_group 2

Class-map cos1
match cos 1

class-map cos 2
match cos 2

policy-map tc001_ch
class cos1
police cir 20000000 bc 625000
conform-action set-qos-transmit 1
exceed-action drop
class cos2
police cir 50000000 bc 1562500
conform-action set-qos-transmit 2
exceed-action drop

policy-map tc001_parent
class class-default
police cir 70000000 bc 2187500 pir 100000000 be 3125000
conform-color qos_group1 exceed-color qos_group2
conform-action transmit
exceed-action transmit
violate-action drop
service-policy tc001_child
```

# Configuration Examples for Hierarchical Color-Aware Policing

## Example Enabling the Hierarchical Color-Aware Policing Feature

The following example shows a sample configuration that enables the Hierarchical Color-Aware Policing feature:

```
class-map qos_group1
match qos_group 1

class-map qos_group2
match qos_group 2

class-map cos1
match cos 1

class-map cos 2
match cos 2

policy-map tc001_ch
class cos1
police cir 20000000 bc 625000
conform-action set-qos-transmit 1
exceed-action drop
class cos2
police cir 50000000 bc 1562500
conform-action set-qos-transmit 2
exceed-action drop

policy-map tc001_parent
class class-default
police cir 70000000 bc 2187500 pir 100000000 be 3125000
conform-color qos_group1 exceed-color qos_group2
conform-action transmit
exceed-action transmit
violate-action drop
service-policy tc001_child
```

## Example Disallowing the Removal of an Active Color-Aware Class Map

The following example shows that an active color-aware class map cannot be disallowed:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# no class-map hipri-conform
Class-map hipri-conform is being used
```

## Example Dismantling a Configuration of the Hierarchical Color-Aware Policing Feature

The following example shows how to dismantle the configuration of the Hierarchical Color-Aware Policing feature:

```

Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# no policy-map parent-policy
Router(config)# no policy-map child-policy
Router(config)# no class-map hipri-conform
Router(config)# no class-map user1-acl-child
Router(config)# no class-map user2-acl-child

```

## Example Applying show Command with Hierarchical Color-Aware Policing

The following is sample output from the **show policy-map interface** command when a policy with hierarchical color-aware policing is applied:

```

Router# show policy-map interface
GigabitEthernet0/0/0
Service-policy input: parent-policy
Class-map: class-default (match-any)
 0 packets, 0 bytes
 5 minute offered rate 0000 bps, drop rate 0000 bps
Match: any
police:
  cir 50000 bps, bc 3000 bytes, be 3000 bytes
  conformed 0 packets, 0 bytes; actions:
  transmit
  exceeded 0 packets, 0 bytes; actions:
  transmit
  violated 0 packets, 0 bytes; actions:
  drop
No color-aware policing statistics available
  conformed 0000 bps, exceed 0000 bps, violate 0000 bps
Service-policy : child-policy
Class-map: user1-acl-child (match-all)
 0 packets, 0 bytes
 5 minute offered rate 0000 bps, drop rate 0000 bps
Match: access-group name user1-acl
police:
  cir 10000 bps, bc 1500 bytes
  conformed 0 packets, 0 bytes; actions:
  set-qos-transmit 5
  exceeded 0 packets, 0 bytes; actions:
  drop
  conformed 0000 bps, exceed 0000 bps
Class-map: user2-acl-child (match-all)
 0 packets, 0 bytes
 5 minute offered rate 0000 bps, drop rate 0000 bps
Match: access-group name user2-acl
police:
  cir 20000 bps, bc 1500 bytes
  conformed 0 packets, 0 bytes; actions:
  set-qos-transmit 5
  exceeded 0 packets, 0 bytes; actions:
  drop
  conformed 0000 bps, exceed 0000 bps
Class-map: class-default (match-any)
 0 packets, 0 bytes
 5 minute offered rate 0000 bps, drop rate 0000 bps
Match: any
police:
  cir 50000 bps, bc 1500 bytes
  conformed 0 packets, 0 bytes; actions:

```



```

transmit
exceeded 0 packets, 0 bytes; actions:
drop
conformed 0000 bps, exceed 0000 bps

```

## Additional References

### Related Documents

Related Topic	Document Title
Cisco IOS commands	<a href="https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/mcl/allreleasemcl/all-book.html">https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/mcl/allreleasemcl/all-book.html</a>

### Standards and RFCs

Standard/RFC	Title
No specific Standards and RFCs are supported by the features in this document.	—

### MIBs

MB	MIBs Link
—	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:  <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

### Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>

