



SNMP

This chapter describes how to configure Simple Network Management Protocol (SNMP) to monitor the Cisco ASA.

- [About SNMP, on page 1](#)
- [Guidelines for SNMP, on page 28](#)
- [Configure SNMP, on page 31](#)
- [Monitoring SNMP, on page 40](#)
- [Examples for SNMP, on page 41](#)
- [History for SNMP, on page 42](#)

About SNMP

SNMP is an application-layer protocol that facilitates the exchange of management information between network devices and is part of the TCP/IP protocol suite. The ASA provides support for network monitoring using SNMP Versions 1, 2c, and 3, and support the use of all three versions simultaneously. The SNMP agent running on the ASA interface lets you monitor the network devices through network management systems (NMSes), such as HP OpenView. The ASA support SNMP read-only access through issuance of a GET request. SNMP write access is not allowed, so you cannot make changes with SNMP. In addition, the SNMP SET request is not supported.

You can configure the ASA to send traps, which are unsolicited messages from the managed device to the management station for certain events (event notifications) to an NMS, or you can use the NMS to browse the Management Information Bases (MIBs) on the security devices. MIBs are a collection of definitions, and the ASA maintain a database of values for each definition. Browsing a MIB means issuing a series of GET-NEXT or GET-BULK requests of the MIB tree from the NMS to determine values.

The ASA have an SNMP agent that notifies designated management stations if events occur that are predefined to require a notification, for example, when a link in the network goes up or down. The notification it sends includes an SNMP OID, which identifies itself to the management stations. The ASA agent also replies when a management station asks for information.

SNMP Terminology

The following table lists the terms that are commonly used when working with SNMP.

Table 1: SNMP Terminology

| Term | Description |
|-------------------------------------|---|
| Agent | The SNMP server running on the ASA. The SNMP agent has the following features: <ul style="list-style-type: none"> • Responds to requests for information and actions from the network management station. • Controls access to its Management Information Base, the collection of objects that the SNMP manager can view or change. • Does not allow SET operations. |
| Browsing | Monitoring the health of a device from the network management station by polling required information from the SNMP agent on the device. This activity may include issuing a series of GET-NEXT or GET-BULK requests of the MIB tree from the network management station to determine values. |
| Management Information Bases (MIBs) | Standardized data structures for collecting information about packets, connections, buffers, failovers, and so on. MIBs are defined by the product, protocols, and hardware standards used by most network devices. SNMP network management stations can browse MIBs and request specific data or events be sent as they occur. |
| Network management stations (NMSs) | The PCs or workstations set up to monitor SNMP events and manage devices, such as the ASA. |
| Object identifier (OID) | The system that identifies a device to its NMS and indicates to users the source of information monitored and displayed. |
| Trap | Predefined events that generate a message from the SNMP agent to the NMS. Events include alarm conditions such as linkup, linkdown, coldstart, warmstart, authentication, or syslog messages. |

MIBs and Traps

MIBs are either standard or enterprise-specific. Standard MIBs are created by the IETF and documented in various RFCs. A trap reports significant events occurring on a network device, most often errors or failures. SNMP traps are defined in either standard or enterprise-specific MIBs. Standard traps are created by the IETF and documented in various RFCs. SNMP traps are compiled into the ASA software.

If needed, you can also download RFCs, standard MIBs, and standard traps from the following locations:

<http://www.ietf.org/>

Browse the complete list of Cisco MIBs, traps, and OIDs from the following location:

<ftp://ftp.cisco.com/pub/mibs/supportlists/asa/asa-supportlist.html>

In addition, download Cisco OIDs by FTP from the following location:

<ftp://ftp.cisco.com/pub/mibs/oid/oid.tar.gz>



Note In software versions 7.2(1), 8.0(2), and later, the interface information accessed through SNMP refreshes about every 5 seconds. As a result, we recommend that you wait for at least 5 seconds between consecutive polls.

Not all OIDs in MIBs are supported. To obtain a list of the supported SNMP MIBs and OIDs for a specific ASA, enter the following command:

```
ciscoasa(config)# show snmp-server oidlist
```



Note Although the **oidlist** keyword does not appear in the options list for the **show snmp-server** command help, it is available. However, this command is for Cisco TAC use only. Contact the Cisco TAC before using this command.

The following is sample output from the **show snmp-server oidlist** command:

```
ciscoasa(config)# show snmp-server oidlist
[0]      1.3.6.1.2.1.1.1.      sysDescr
[1]      1.3.6.1.2.1.1.2.      sysObjectID
[2]      1.3.6.1.2.1.1.3.      sysUpTime
[3]      1.3.6.1.2.1.1.4.      sysContact
[4]      1.3.6.1.2.1.1.5.      sysName
[5]      1.3.6.1.2.1.1.6.      sysLocation
[6]      1.3.6.1.2.1.1.7.      sysServices
[7]      1.3.6.1.2.1.2.1.      ifNumber
[8]      1.3.6.1.2.1.2.2.1.1.  ifIndex
[9]      1.3.6.1.2.1.2.2.1.2.  ifDescr
[10]     1.3.6.1.2.1.2.2.1.3.  ifType
[11]     1.3.6.1.2.1.2.2.1.4.  ifMtu
[12]     1.3.6.1.2.1.2.2.1.5.  ifSpeed
[13]     1.3.6.1.2.1.2.2.1.6.  ifPhysAddress
[14]     1.3.6.1.2.1.2.2.1.7.  ifAdminStatus
[15]     1.3.6.1.2.1.2.2.1.8.  ifOperStatus
[16]     1.3.6.1.2.1.2.2.1.9.  ifLastChange
[17]     1.3.6.1.2.1.2.2.1.10. ifInOctets
[18]     1.3.6.1.2.1.2.2.1.11. ifInUcastPkts
[19]     1.3.6.1.2.1.2.2.1.12. ifInNUcastPkts
[20]     1.3.6.1.2.1.2.2.1.13. ifInDiscards
[21]     1.3.6.1.2.1.2.2.1.14. ifInErrors
[22]     1.3.6.1.2.1.2.2.1.16. ifOutOctets
[23]     1.3.6.1.2.1.2.2.1.17. ifOutUcastPkts
[24]     1.3.6.1.2.1.2.2.1.18. ifOutNUcastPkts
[25]     1.3.6.1.2.1.2.2.1.19. ifOutDiscards
[26]     1.3.6.1.2.1.2.2.1.20. ifOutErrors
[27]     1.3.6.1.2.1.2.2.1.21. ifOutQLen
[28]     1.3.6.1.2.1.2.2.1.22. ifSpecific
[29]     1.3.6.1.2.1.4.1.      ipForwarding
[30]     1.3.6.1.2.1.4.20.1.1.  ipAdEntAddr
[31]     1.3.6.1.2.1.4.20.1.2.  ipAdEntIfIndex
[32]     1.3.6.1.2.1.4.20.1.3.  ipAdEntNetMask
[33]     1.3.6.1.2.1.4.20.1.4.  ipAdEntBcastAddr
[34]     1.3.6.1.2.1.4.20.1.5.  ipAdEntReasmMaxSize
[35]     1.3.6.1.2.1.11.1.      snmpInPkts
[36]     1.3.6.1.2.1.11.2.      snmpOutPkts
[37]     1.3.6.1.2.1.11.3.      snmpInBadVersions
[38]     1.3.6.1.2.1.11.4.      snmpInBadCommunityNames
[39]     1.3.6.1.2.1.11.5.      snmpInBadCommunityUses
[40]     1.3.6.1.2.1.11.6.      snmpInASNParseErrs
[41]     1.3.6.1.2.1.11.8.      snmpInTooBigS
[42]     1.3.6.1.2.1.11.9.      snmpInNoSuchNames
[43]     1.3.6.1.2.1.11.10.     snmpInBadValues
[44]     1.3.6.1.2.1.11.11.     snmpInReadOnlyS
[45]     1.3.6.1.2.1.11.12.     snmpInGenErrs
```

```

[46] 1.3.6.1.2.1.11.13. snmpInTotalReqVars
[47] 1.3.6.1.2.1.11.14. snmpInTotalSetVars
[48] 1.3.6.1.2.1.11.15. snmpInGetRequests
[49] 1.3.6.1.2.1.11.16. snmpInGetNexts
[50] 1.3.6.1.2.1.11.17. snmpInSetRequests
[51] 1.3.6.1.2.1.11.18. snmpInGetResponses
[52] 1.3.6.1.2.1.11.19. snmpInTraps
[53] 1.3.6.1.2.1.11.20. snmpOutTooBig
[54] 1.3.6.1.2.1.11.21. snmpOutNoSuchNames
[55] 1.3.6.1.2.1.11.22. snmpOutBadValues
[56] 1.3.6.1.2.1.11.24. snmpOutGenErrs
[57] 1.3.6.1.2.1.11.25. snmpOutGetRequests
[58] 1.3.6.1.2.1.11.26. snmpOutGetNexts
[59] 1.3.6.1.2.1.11.27. snmpOutSetRequests
[60] 1.3.6.1.2.1.11.28. snmpOutGetResponses
[61] 1.3.6.1.2.1.11.29. snmpOutTraps
[62] 1.3.6.1.2.1.11.30. snmpEnableAuthenTraps
[63] 1.3.6.1.2.1.11.31. snmpSilentDrops
[64] 1.3.6.1.2.1.11.32. snmpProxyDrops
[65] 1.3.6.1.2.1.31.1.1.1.1. ifName
[66] 1.3.6.1.2.1.31.1.1.1.2. ifInMulticastPkts
[67] 1.3.6.1.2.1.31.1.1.1.3. ifInBroadcastPkts
[68] 1.3.6.1.2.1.31.1.1.1.4. ifOutMulticastPkts
[69] 1.3.6.1.2.1.31.1.1.1.5. ifOutBroadcastPkts
[70] 1.3.6.1.2.1.31.1.1.1.6. ifHCInOctets
--More--

```

SNMP Object Identifiers

Each Cisco system-level product has an SNMP object identifier (OID) for use as a MIB-II sysObjectID. The CISCO-PRODUCTS-MIB and the CISCO-ENTITY-VENDORTYPE-OID-MIB includes the OIDs that can be reported in the sysObjectID object in the SNMPv2-MIB, Entity Sensor MIB and Entity Sensor Threshold Ext MIB. You can use this value to identify the model type. The following table lists the sysObjectID OIDs for ASA and ISA models.

Table 2: SNMP Object Identifiers

| Product Identifier | sysObjectID | Model Number |
|--|--------------------------------------|------------------------------|
| ASA 5506 Adaptive Security Appliance | ciscoASA5506 (ciscoProducts 2114) | ASA 5506-X |
| ASA 5506 Adaptive Security Appliance Security Context | ciscoASA5506sc (ciscoProducts 2115) | ASA 5506-X security context |
| ASA 5506 Adaptive Security Appliance System Context | ciscoASA5506sy (ciscoProducts 2116) | ASA 5506-X system context |
| ASA 5506W Adaptive Security Appliance | ciscoASA5506W (ciscoProducts 2117) | ASA 5506W-X |
| ASA 5506W Adaptive Security Appliance Security Context | ciscoASA5506Wsc (ciscoProducts 2118) | ASA 5506W-X security context |
| ASA 5506W Adaptive Security Appliance System Context | ciscoASA5506Wsy (ciscoProducts 2119) | ASA 5506W-X system context |
| ASA 5508 Adaptive Security Appliance | ciscoASA5508 (ciscoProducts 2120) | ASA 5508-X |

| Product Identifier | sysObjectID | Model Number |
|--|--|--|
| ASA 5508 Adaptive Security Appliance Security Context | ciscoASA5508sc (ciscoProducts 2121) | ASA 5508-X security context |
| ASA 5508 Adaptive Security Appliance System Context | ciscoASA5508sy (ciscoProducts 2122) | ASA 5508-X system context |
| ASA 5506 Adaptive Security Appliance with No Payload Encryption | ciscoASA5506K7 (ciscoProducts 2123) | ASA 5506-X Adaptive Security Appliance with No Payload Encryption |
| ASA 5506 Adaptive Security Appliance Security Context with No Payload Encryption | ciscoASA5506K7sc (ciscoProducts 2124) | ASA 5506-X Adaptive Security Appliance Security Context with No Payload Encryption |
| ASA 5506 Adaptive Security Appliance System Context with No Payload Encryption | ciscoASA5506K7sy (ciscoProducts 2125) | ASA 5506-X Adaptive Security Appliance System Context with No Payload Encryption |
| ASA 5508 Adaptive Security Appliance with No Payload Encryption | ciscoASA5508K7 (ciscoProducts 2126) | ASA 5508-X Adaptive Security Appliance System Context with No Payload Encryption |
| ASA 5508 Adaptive Security Appliance Security Context with No Payload Encryption | ciscoASA5508K7sc (ciscoProducts 2127) | ASA 5508-X Adaptive Security Appliance Security Context with No Payload Encryption |
| ASA 5508 Adaptive Security Appliance System Context with No Payload Encryption | ciscoASA5508K7sy (ciscoProducts 2128) | ASA 5508-X Adaptive Security Appliance System Context with No Payload Encryption |
| ASA5585-SSP10 | ciscoASA5585Ssp10 (ciscoProducts 1194) | ASA 5585-X SSP-10 |
| ASA5585-SSP20 | ciscoASA5585Ssp20 (ciscoProducts 1195) | ASA 5585-X SSP-20 |
| ASA5585-SSP40 | ciscoASA5585Ssp40 (ciscoProducts 1196) | ASA 5585-X SSP-40 |
| ASA5585-SSP60 | ciscoASA5585Ssp60 (ciscoProducts 1197) | ASA 5585-X SSP-60 |
| ASA5585-SSP10 | ciscoASA5585Ssp10sc (ciscoProducts 1198) | ASA 5585-X SSP-10 security context |
| ASA5585-SSP20 | ciscoASA5585Ssp20sc (ciscoProducts 1199) | ASA 5585-X SSP-20 security context |
| ASA5585-SSP40 | ciscoASA5585Ssp40sc (ciscoProducts 1200) | ASA 5585-X SSP-40 security context |
| ASA5585-SSP60 | ciscoASA5585Ssp60sc (ciscoProducts 1201) | ASA 5585-X SSP-60 security context |
| ASA5585-SSP10 | ciscoASA5585Ssp10sy (ciscoProducts 1202) | ASA 5585-X SSP-10 system context |

| Product Identifier | sysObjectID | Model Number |
|--|--|--|
| ASA5585-SSP20 | ciscoASA5585Ssp20sy (ciscoProducts 1203) | ASA 5585-X SSP-20 system context |
| ASA5585-SSP40 | ciscoASA5585Ssp40sy (ciscoProducts 1204) | ASA 5585-X SSP-40 system context |
| ASA5585-SSP60 | ciscoASA5585Ssp60sy (ciscoProducts 1205) | ASA 5585-X SSP-60 system context |
| ASA Services Module for Catalyst switches/7600 routers | ciscoAaSml (ciscoProducts 1277) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers |
| ASA Services Module for Catalyst switches/7600 routers security context | ciscoAaSmlsc (ciscoProducts 1275) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers security context |
| ASA Services Module for Catalyst switches/7600 routers security context with No Payload Encryption | ciscoAaSmlK7sc (ciscoProducts 1334) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers security context with No Payload Encryption |
| ASA Services Module for Catalyst switches/7600 routers system context | ciscoAaSmlsy (ciscoProducts 1276) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers system context |
| ASA Services Module for Catalyst switches system context/7600 routers with No Payload Encryption | ciscoAaSmlK7sy (ciscoProducts 1335) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers system context with No Payload Encryption |
| ASA Services Module for Catalyst switches/7600 routers system context with No Payload Encryption | ciscoAaSmlK7 (ciscoProducts 1336) | Adaptive Security Appliance (ASA) Services Module for Catalyst switches/7600 routers with No Payload Encryption |
| ASA 5512 | ciscoASA5512 (ciscoProducts 1407) | ASA 5512 Adaptive Security Appliance |
| ASA 5525 | ciscoASA5525 (ciscoProducts 1408) | ASA 5525 Adaptive Security Appliance |
| ASA 5545 | ciscoASA5545 (ciscoProducts 1409) | ASA 5545 Adaptive Security Appliance |
| ASA 5555 | ciscoASA5555 (ciscoProducts 1410) | ASA 5555 Adaptive Security Appliance |
| ASA 5512 Security Context | ciscoASA5512sc (ciscoProducts 1411) | ASA 5512 Adaptive Security Appliance Security Context |
| ASA 5525 Security Context | ciscoASA5525sc (ciscoProducts 1412) | ASA 5525 Adaptive Security Appliance Security Context |
| ASA 5545 Security Context | ciscoASA5545sc (ciscoProducts 1413) | ASA 5545 Adaptive Security Appliance Security Context |

| Product Identifier | sysObjectID | Model Number |
|--|-------------------------------------|---|
| ASA 5555 Security Context | ciscoASA5555sc (ciscoProducts 1414) | ASA 5555 Adaptive Security Appliance Security Context |
| ASA 5512 System Context | ciscoASA5512sy (ciscoProducts 1415) | ASA 5512 Adaptive Security Appliance System Context |
| ASA 5515 System Context | ciscoASA5515sy (ciscoProducts 1416) | ASA 5515 Adaptive Security Appliance System Context |
| ASA 5525 System Context | ciscoASA5525sy (ciscoProducts1417) | ASA 5525 Adaptive Security Appliance System Context |
| ASA 5545 System Context | ciscoASA5545sy (ciscoProducts 1418) | ASA 5545 Adaptive Security Appliance System Context |
| ASA 5555 System Context | ciscoASA5555sy (ciscoProducts 1419) | ASA 5555 Adaptive Security Appliance System Context |
| ASA 5515 Security Context | ciscoASA5515sc (ciscoProducts 1420) | ASA 5515 Adaptive Security Appliance System Context |
| ASA 5515 | ciscoASA5515 (ciscoProducts 1421) | ASA 5515 Adaptive Security Appliance |
| ASAv | ciscoASAv (ciscoProducts 1902) | Cisco Adaptive Security Virtual Appliance (ASAv) |
| ASAv System Context | ciscoASAvsy (ciscoProducts 1903) | Cisco Adaptive Security Virtual Appliance (ASAv) System Context |
| ASAv Security Context | ciscoASAvsc (ciscoProducts 1904) | Cisco Adaptive Security Virtual Appliance (ASAv) Security Context |
| ISA 30004C Industrial Security Appliance | ciscoProducts 2268 | ciscoISA30004C |
| CISCO ISA30004C with 4 GE Copper Security Context | ciscoProducts 2139 | ciscoISA30004Csc |
| CISCO ISA30004C with 4 GE Copper System Context | ciscoProducts 2140 | ciscoISA30004Csy |
| ISA 30002C2F Industrial Security Appliance | ciscoProducts 2267 | ciscoISA30002C2F |
| CISCO ISA30002C2F with 2 GE Copper ports + 2 GE Fiber Security Context | ciscoProducts 2142 | ciscoISA30002C2Fsc |
| CISCO ISA30002C2F with 2 GE Copper ports + 2 GE Fiber System Context | ciscoProducts 2143 | ciscoISA30002C2Fsy |
| Cisco Industrial Security Appliance (ISA) 30004C Chassis | cevChassis 1677 | cevChassisISA30004C |

| Product Identifier | sysObjectID | Model Number |
|--|-------------------------------------|-----------------------------------|
| Cisco Industrial Security Appliance (ISA) 30002C2F Chassis | cevChassis 1678 | cevChassisISA30002C2F |
| Central Processing Unit Temperature Sensor for ISA30004C Copper SKU | cevSensor 187 | cevSensorISA30004CCpuTempSensor |
| Central Processing Unit Temperature Sensor for ISA30002C2F Fiber | cevSensor 189 | cevSensorISA30002C2FCpuTempSensor |
| Processor Card Temperature Sensor for ISA30004C Copper SKU | cevSensor 192 | cevSensorISA30004CPTS |
| Processor Card Temperature Sensor for ISA30002C2F Fiber SKU | cevSensor 193 | cevSensorISA30002C2FFPTS |
| Power Card Temperature Sensor for ISA30004C Copper SKU | cevSensor 197 | cevSensorISA30004CPowercardTS |
| Power Card Temperature Sensor for ISA30002C2F Fiber SKU | cevSensor 198 | cevSensorISA30002C2FPowercardTS |
| Port Card Temperature Sensor for ISA30004C | cevSensor 199 | cevSensorISA30004CPortcardTS |
| Port Card Temperature Sensor for ISA30002C2F | cevSensor 200 | cevSensorISA30002C2FPortcardTS |
| Central Processing Unit for ISA30004C Copper SKU | cevModuleCpuType 329 | cevCpuISA30004C |
| Central Processing Unit for ISA30002C2F Fiber SKU | cevModuleCpuType 330 | cevCpuISA30002C2F |
| Modules ISA30004C, ISA30002C2F | cevModule 111 | cevModuleISA3000Type |
| 30004C Industrial Security Appliance Solid State Drive | cevModuleISA3000Type 1 | cevModuleISA30004C SSD64 |
| 30002C2F Industrial Security Appliance Solid State Drive | cevModuleISA3000Type 2 | cevModuleISA30002C2F SSD64 |
| Cisco ISA30004C/ISA30002C2F Hardware Bypass | cevModuleISA3000Type 5 | cevModuleISA3000HardwareBypass |
| FirePOWER 4140 Security Appliance, 1U with embedded security module 36 | ciscoFpr4140K9 (ciscoProducts 2293) | FirePOWER 4140 |
| FirePOWER 4120 Security Appliance, 1U with embedded security module 24 | ciscoFpr4120K9 (ciscoProducts 2294) | FirePOWER 4120 |
| FirePOWER 4110 Security Appliance, 1U with embedded security module 12 | ciscoFpr4110K9 (ciscoProducts 2295) | FirePOWER 4110 |

| Product Identifier | sysObjectID | Model Number |
|--|---------------------------------------|-----------------------------------|
| FirePOWER 4110 Security Module 12 | ciscoFpr4110SM12 (ciscoProducts 2313) | FirePOWER 4110 Security Module 12 |
| FirePOWER 4120 Security Module 24 | ciscoFpr4120SM24 (ciscoProducts 2314) | FirePOWER 4110 Security Module 24 |
| FirePOWER 4140 Security Module 36 | ciscoFpr4140SM36 (ciscoProducts 2315) | FirePOWER 4110 Security Module 36 |
| FirePOWER 4110 Chassis | cevChassis 1714 | cevChassisFPR4110 |
| FirePOWER 4120 Chassis | cevChassis 1715 | cevChassisFPR4120 |
| FirePOWER 4140 Chassis | cevChassis 1716 | cevChassisFPR4140 |
| FirePOWER 4K Fan Bay | cevContainer 363 | cevContainerFPR4KFanBay |
| FirePOWER 4K Power Supply Bay | cevContainer 364 | cevContainerFPR4KPowerSupplyBay |
| FirePOWER 4120 Supervisor Module | cevModuleFPRType 4 | cevFPR4120SUPFixedModule |
| FirePOWER 4140 Supervisor Module | cevModuleFPRType 5 | cevFPR4140SUPFixedModule |
| FirePOWER 4110 Supervisor Module | cevModuleFPRType 7 | cevFPR4110SUPFixedModule |
| Cisco FirePOWER 4110 Security Appliance, Threat Defense | cevChassis 1787 | cevChassisCiscoFpr4110td |
| Cisco FirePOWER 4120 Security Appliance, Threat Defense | cevChassis 1788 | cevChassisCiscoFpr4120td |
| Cisco FirePOWER 4140 Security Appliance, Threat Defense | cevChassis 1789 | cevChassisCiscoFpr4140td |
| Cisco Firepower 9000 Security Module 24, Threat Defense | cevChassis 1791 | cevChassisCiscoFpr9000SM24td |
| Cisco Firepower 9000 Security Module 24 NEBS, Threat Defense | cevChassis 1792 | cevChassisCiscoFpr9000SM24Ntd |
| Cisco Firepower 9000 Security Module 36, Threat Defense | cevChassis 1793 | cevChassisCiscoFpr9000SM36td |
| Cisco Firepower Threat Defense Virtual, VMware | cevChassis 1795 | cevChassisCiscoFTDVVMW |
| Cisco Firepower Threat Defense Virtual, AWS | cevChassis 1796 | cevChassisCiscoFTDVAWS |

Physical Vendor Type Values

Each Cisco chassis or standalone system has a unique type number for SNMP use. The entPhysicalVendorType OIDs are defined in the CISCO-ENTITY-VENDORTYPE-OID-MIB. This value is returned in the entPhysicalVendorType object from the ASA, ASAv, or ASASM SNMP agent. You can use this value to

identify the type of component (module, power supply, fan, sensors, CPU, and so on). The following table lists the physical vendor type values for the ASA models.

Table 3: Physical Vendor Type Values

| Item | entPhysicalVendorType OID Description |
|---|--|
| ASA Services Module for Catalyst switches/7600 routers | cevCat6kWsSvcAsaSm1 (cevModuleCat6000Type 169) |
| ASA Services Module for Catalyst switches/7600 routers with No Payload Encryption | cevCat6kWsSvcAsaSm1K7 (cevModuleCat6000Type 186) |
| Accelerator for 5506 Adaptive Security Appliance | cevAcceleratorAsa5506 (cevOther 10) |
| Accelerator for 5506W Adaptive Security Appliance | cevAcceleratorAsa5506W (cevOther 11) |
| Accelerator for 5508 Adaptive Security Appliance | cevAcceleratorAsa5508 (cevOther 12) |
| Accelerator for 5506 with No Payload Encryption Adaptive Security Appliance | cevAcceleratorAsa5506K7 (cevOther 13) |
| Accelerator for 5508 with No Payload Encryption Adaptive Security Appliance | cevAcceleratorAsa5508K7 (cevOther 14) |
| Cisco Adaptive Security Appliance (ASA) 5506 Chassis | cevChassisAsa5506 (cevChassis 1600) |
| Cisco Adaptive Security Appliance (ASA) 5506W Chassis | cevChassisAsa5506W (cevChassis 1601) |
| Cisco Adaptive Security Appliance (ASA) 5508 Chassis | cevChassisAsa5508 (cevChassis 1602) |
| Cisco Adaptive Security Appliance (ASA) 5506 Chassis with No Payload Encryption | cevChassisAsa5506K7 (cevChassis 1603) |
| Cisco Adaptive Security Appliance (ASA) 5508 Chassis with No Payload Encryption | cevChassisAsa5508K7 (cevChassis 1604) |
| Central Processing Unit for 5506 Adaptive Security Appliance | cevCpuAsa5506 (cevModuleCpuType 312) |
| Central Processing Unit for 5506W Adaptive Security Appliance | cevCpuAsa5506W (cevModuleCpuType 313) |
| Central Processing Unit for 5508 Adaptive Security Appliance | cevCpuAsa5508 ((cevModuleCpuType 314) |
| Central Processing Unit for 5506 with No Payload Encryption Adaptive Security Appliance | cevCpuAsa5506K7 (cevModuleCpuType 315) |
| Central Processing Unit for 5508 with No Payload Encryption Adaptive Security Appliance | cevCpuAsa5508K7 (cevModuleCpuType 316) |
| cevModuleASA5506 Type chassis | cevModuleASA5506Type (cevModule 107) |
| 5506 Adaptive Security Appliance Field-Replaceable Solid State Drive | cevModuleAsa5506SSD (cevModuleASA5506Type 1) |
| 5506W Adaptive Security Appliance Field-Replaceable Solid State Drive | cevModuleAsa5506WSSD (cevModuleASA5506Type 2) |

| Item | entPhysicalVendorType OID Description |
|--|---|
| 5506 with No Payload Encryption Adaptive Security Appliance Field-Replaceable Solid State Drive | cevModuleAsa5506K7SSD (cevModuleASA5506Type 3) |
| cevModuleASA5508 Type chassis | cevModuleASA5508Type (cevModule 108) |
| 5508 Adaptive Security Appliance Field-Replaceable Solid State Drive | cevModuleAsa5508SSD (cevModuleASA5508Type 1) |
| 5508 with No Payload Encryption Adaptive Security Appliance Field-Replaceable Solid State Drive | cevModuleAsa5508K7SSD (cevModuleASA5508Type 2) |
| Chassis Cooling Fan for Adaptive Security Appliance 5508 | cevFanAsa5508ChassisFan (cevFan 247) |
| Chassis Cooling Fan for Adaptive Security Appliance 5508 with No Payload Encryption | cevFanAsa5508K7ChassisFan (cevFan 248) |
| Chassis Cooling Fan Sensor for Adaptive Security Appliance 5508 | cevSensorAsa5508ChassisFanSensor (cevSensor 162) |
| Chassis Cooling Fan Sensor for Adaptive Security Appliance 5508 with No Payload Encryption | cevSensorAsa5508K7ChassisFanSensor (cevSensor 163) |
| Central Processing Unit Temperature Sensor for 5506 Adaptive Security Appliance | cevSensorAsa5506CpuTempSensor (cevSensor 164) |
| Central Processing Unit Temperature Sensor for 5506W Adaptive Security Appliance | cevSensorAsa5506WCpuTempSensor (cevSensor 165) |
| Central Processing Unit Temperature Sensor for 5508 Adaptive Security Appliance | cevSensorAsa5508CpuTempSensor (cevSensor 166) |
| Central Processing Unit Temperature Sensor for 5506 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5506K7CpuTempSensor (cevSensor 167) |
| Central Processing Unit Temperature Sensor for 5508 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5508K7CpuTempSensor (cevSensor 168) |
| Accelerator Temperature Sensor for 5506 Adaptive Security Appliance | cevSensorAsa5506AcceleratorTempSensor (cevSensor 169) |
| Accelerator Temperature Sensor for 5506W Adaptive Security Appliance | cevSensorAsa5506WAcceleratorTempSensor (cevSensor 170) |
| Accelerator Temperature Sensor for 5508 Adaptive Security Appliance | cevSensorAsa5508AcceleratorTempSensor (cevSensor 171) |
| Accelerator Temperature Sensor for 5506 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5506K7AcceleratorTempSensor (cevSensor 172) |
| Accelerator Temperature Sensor for 5508 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5508K7AcceleratorTempSensor (cevSensor 173) |

Physical Vendor Type Values

| Item | entPhysicalVendorType OID Description |
|---|---|
| Chassis Ambient Temperature Sensor for 5506 Adaptive Security Appliance | cevSensorAsa5506ChassisTempSensor (cevSensor 174) |
| Chassis Ambient Temperature Sensor for 5506W Adaptive Security Appliance | cevSensorAsa5506WChassisTempSensor (cevSensor 175) |
| Chassis Ambient Temperature Sensor for 5508 Adaptive Security Appliance | cevSensorAsa5508ChassisTempSensor (cevSensor 176) |
| Chassis Ambient Temperature Sensor for 5506 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5506K7ChassisTempSensor (cevSensor 177) |
| Chassis Ambient Temperature Sensor for 5508 with No Payload Encryption Adaptive Security Appliance | cevSensorAsa5508K7ChassisTempSensor (cevSensor 178) |
| Cisco Adaptive Security Appliance (ASA) 5512 Adaptive Security Appliance | cevChassisASA5512 (cevChassis 1113) |
| Cisco Adaptive Security Appliance (ASA) 5512 Adaptive Security Appliance with No Payload Encryption | cevChassisASA5512K7 (cevChassis 1108) |
| Cisco Adaptive Security Appliance (ASA) 5515 Adaptive Security Appliance | cevChassisASA5515 (cevChassis 1114) |
| Cisco Adaptive Security Appliance (ASA) 5515 Adaptive Security Appliance with No Payload Encryption | cevChassisASA5515K7 (cevChassis 1109) |
| Cisco Adaptive Security Appliance (ASA) 5525 Adaptive Security Appliance | cevChassisASA5525 (cevChassis 1115) |
| Cisco Adaptive Security Appliance (ASA) 5525 Adaptive Security Appliance with No Payload Encryption | cevChassisASA5525K7 (cevChassis 1110) |
| Cisco Adaptive Security Appliance (ASA) 5545 Adaptive Security Appliance | cevChassisASA5545 (cevChassis 1116) |
| Cisco Adaptive Security Appliance (ASA) 5545 Adaptive Security Appliance with No Payload Encryption | cevChassisASA5545K7 (cevChassis 1111) |
| Cisco Adaptive Security Appliance (ASA) 5555 Adaptive Security Appliance | cevChassisASA5555 (cevChassis 1117) |
| Cisco Adaptive Security Appliance (ASA) 5555 Adaptive Security Appliance with No Payload Encryption | cevChassisASA5555K7 (cevChassis 1112) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5512 | cevCpuAsa5512 (cevModuleCpuType 229) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5512 with no Payload Encryption | cevCpuAsa5512K7 (cevModuleCpuType 224) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5515 | cevCpuAsa5515 (cevModuleCpuType 230) |

| Item | entPhysicalVendorType OID Description |
|---|---|
| Central Processing Unit for Cisco Adaptive Security Appliance 5515 with no Payload Encryption | cevCpuAsa5515K7 (cevModuleCpuType 225) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5525 | cevCpuAsa5525 (cevModuleCpuType 231) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5525 with no Payload Encryption | cevCpuAsa5525K7 (cevModuleCpuType 226) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5545 | cevCpuAsa5545 (cevModuleCpuType 232) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5545 with no Payload Encryption | cevCpuAsa5545K7 (cevModuleCpuType 227) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5555 | cevCpuAsa5555 (cevModuleCpuType 233) |
| Central Processing Unit for Cisco Adaptive Security Appliance 5555 with no Payload Encryption | cevCpuAsa5555K7 (cevModuleCpuType 228) |
| CPU for ASA 5585 SSP-10 | cevCpuAsa5585Ssp10 (cevModuleCpuType 204) |
| CPU for ASA 5585 SSP-10 No Payload Encryption | cevCpuAsa5585Ssp10K7 (cevModuleCpuType 205) |
| CPU for ASA 5585 SSP-20 | cevCpuAsa5585Ssp20 (cevModuleCpuType 206) |
| CPU for ASA 5585 SSP-20 No Payload Encryption | cevCpuAsa5585Ssp20K7 (cevModuleCpuType 207) |
| CPU for ASA 5585 SSP-40 | cevCpuAsa5585Ssp40 (cevModuleCpuType 208) |
| CPU for ASA 5585 SSP-40 No Payload Encryption | cevCpuAsa5585Ssp40K7 (cevModuleCpuType 209) |
| CPU for ASA 5585 SSP-60 | cevCpuAsa5585Ssp60 (cevModuleCpuType 210) |
| CPU for ASA 5585 SSP-60 No Payload Encryption | cevCpuAsa5585Ssp60K (cevModuleCpuType 211) |
| CPU for Cisco ASA Services Module for Catalyst switches/7600 routers | cevCpuAsaSm1 (cevModuleCpuType 222) |
| CPU for Cisco ASA Services Module with No Payload Encryption for Catalyst switches/7600 routers | cevCpuAsaSm1K7 (cevModuleCpuType 223) |
| Chassis Cooling Fan in Adaptive Security Appliance 5512 | cevFanASA5512ChassisFan (cevFan 163) |
| Chassis Cooling Fan in Adaptive Security Appliance 5512 with No Payload Encryption | cevFanASA5512K7ChassisFan (cevFan 172) |
| Chassis Cooling Fan in Adaptive Security Appliance 5515 | cevFanASA5515ChassisFan (cevFan 164) |
| Chassis Cooling Fan in Adaptive Security Appliance 5515 with No Payload Encryption | cevFanASA5515K7ChassisFan (cevFan 171) |
| Chassis Cooling Fan in Adaptive Security Appliance 5525 | cevFanASA5525ChassisFan (cevFan 165) |

Physical Vendor Type Values

| Item | entPhysicalVendorType OID Description |
|--|--|
| Chassis Cooling Fan in Adaptive Security Appliance 5525 with No Payload Encryption | cevFanASA5525K7ChassisFan (cevFan 170) |
| Chassis Cooling Fan in Adaptive Security Appliance 5545 | cevFanASA5545ChassisFan (cevFan 166) |
| Chassis Cooling Fan in Adaptive Security Appliance 5545 with No Payload Encryption | cevFanASA5545K7ChassisFan (cevFan 169) |
| Power Supply Fan in Adaptive Security Appliance 5545 with No Payload Encryption | cevFanASA5545K7PSFan (cevFan 161) |
| Power Supply Fan in Adaptive Security Appliance 5545 | cevFanASA5545PSFan (cevFan 159) |
| Chassis Cooling Fan in Adaptive Security Appliance 5555 | cevFanASA5555ChassisFan (cevFan 167) |
| Chassis Cooling Fan in Adaptive Security Appliance 5555 with No Payload Encryption | cevFanASA5555K7ChassisFan (cevFan 168) |
| Power Supply Fan in Adaptive Security Appliance 5555 | cevFanASA5555PSFan (cevFan 160) |
| Power Supply Fan in Adaptive Security Appliance 5555 with No Payload Encryption | cevFanASA5555PSFanK7 (cevFan 162) |
| Power supply fan for ASA 5585-X | cevFanASA5585PSFan (cevFan 146) |
| 10-Gigabit Ethernet interface | cevPort10GigEthernet (cevPort 315) |
| Gigabit Ethernet port | cevPortGe (cevPort 109) |
| Power Supply unit in Adaptive Security Appliance 5545 | cevPowerSupplyASA5545PSInput (cevPowerSupply 323) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5545 | cevPowerSupplyASA5545PSPresence (cevPowerSupply 321) |
| Power Supply unit in Adaptive Security Appliance 5555 | cevPowerSupplyASA5555PSInput (cevPowerSupply 324) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5555 | cevPowerSupplyASA5555PSPresence (cevPowerSupply 322) |
| Power supply input for ASA 5585 | cevPowerSupplyASA5585PSInput (cevPowerSupply 304) |
| Cisco Adaptive Security Appliance (ASA) 5512 Chassis Fan sensor | cevSensorASA5512ChassisFanSensor (cevSensor 120) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5512 | cevSensorASA5512ChassisTemp (cevSensor 107) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5512 | cevSensorASA5512CPUTemp (cevSensor 96) |
| Cisco Adaptive Security Appliance (ASA) 5512 with No Payload Encryption Chassis Fan sensor | cevSensorASA5512K7ChassisFanSensor (cevSensor 125) |

| Item | entPhysicalVendorType OID Description |
|--|--|
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5512 with No Payload Encryption | cevSensorASA5512K7CPUtemp (cevSensor 102) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5512 with No Payload Encryption | cevSensorASA5512K7PSFanSensor (cevSensor 116) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5512 | cevSensorASA5512PSFanSensor (cevSensor 119) |
| Cisco Adaptive Security Appliance (ASA) 5515 Chassis Fan sensor | cevSensorASA5515ChassisFanSensor (cevSensor 121) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5515 | cevSensorASA5515ChassisTemp (cevSensor 98) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5515 | cevSensorASA5515CPUtemp (cevSensor 97) |
| Cisco Adaptive Security Appliance (ASA) 5515 with No Payload Encryption Chassis Fan sensor | cevSensorASA5515K7ChassisFanSensor (cevSensor 126) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5515 with No Payload Encryption | cevSensorASA5515K7CPUtemp (cevSensor 103) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5515 with No Payload Encryption | cevSensorASA5515K7PSFanSensor (cevSensor 115) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5515 | cevSensorASA5515PSFanSensor (cevSensor 118) |
| Cisco Adaptive Security Appliance (ASA) 5525 Chassis Fan sensor | cevSensorASA5525ChassisFanSensor (cevSensor 122) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5525 | cevSensorASA5525ChassisTemp (cevSensor 108) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5525 | cevSensorASA5525CPUtemp (cevSensor 99) |
| Cisco Adaptive Security Appliance (ASA) 5525 with No Payload Encryption Chassis Fan sensor | cevSensorASA5525K7ChassisFanSensor (cevSensor 127) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5525 with No Payload Encryption | cevSensorASA5525K7CPUtemp (cevSensor 104) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5525 with No Payload Encryption | cevSensorASA5525K7PSFanSensor (cevSensor 114) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5525 | cevSensorASA5525PSFanSensor (cevSensor 117) |
| Cisco Adaptive Security Appliance (ASA) 5545 Chassis Fan sensor | cevSensorASA5545ChassisFanSensor (cevSensor 123) |

Physical Vendor Type Values

| Item | entPhysicalVendorType OID Description |
|--|--|
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5545 | cevSensorASA5545ChassisTemp (cevSensor 109) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5545 | cevSensorASA5545CPUTemp (cevSensor 100) |
| Cisco Adaptive Security Appliance (ASA) 5545 with No Payload Encryption Chassis Fan sensor | cevSensorASA5545K7ChassisFanSensor (cevSensor 128) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545K7ChassisTemp (cevSensor 90) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545K7CPUTemp (cevSensor 105) |
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545K7PSFanSensor (cevSensor 113) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545K7PSPresence (cevSensor 87) |
| Temperature Sensor for Power Supply Fan in Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545K7PSTempSensor (cevSensor 94) |
| Sensor for Power Supply Fan in Adaptive Security Appliance 5545 with No Payload Encryption | cevSensorASA5545PSFanSensor (cevSensor 89) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5545 | cevSensorASA5545PSPresence (cevSensor 130) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5555 | cevSensorASA5545PSPresence (cevSensor 131) |
| Temperature Sensor for Power Supply Fan in Adaptive Security Appliance 5545 | cevSensorASA5545PSTempSensor (cevSensor 92) |
| Cisco Adaptive Security Appliance (ASA) 5555 Chassis Fan sensor | cevSensorASA5555ChassisFanSensor (cevSensor 124) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5555 | cevSensorASA5555ChassisTemp (cevSensor 110) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5555 | cevSensorASA5555CPUTemp (cevSensor 101) |
| Cisco Adaptive Security Appliance (ASA) 5555 with No Payload Encryption Chassis Fan sensor | cevSensorASA5555K7ChassisFanSensor (cevSensor 129) |
| Chassis Ambient Temperature Sensor for Cisco Adaptive Security Appliance 5555 with No Payload Encryption | cevSensorASA5555K7ChassisTemp (cevSensor 111) |
| Central Processing Unit Temperature Sensor for Cisco Adaptive Security Appliance 5555 with No Payload Encryption | cevSensorASA5555K7CPUTemp (cevSensor 106) |

| Item | entPhysicalVendorType OID Description |
|--|---|
| Sensor for Chassis Cooling Fan in Adaptive Security Appliance 5555 with No Payload Encryption | cevSensorASA5555K7PSFanSensor (cevSensor 112) |
| Presence Sensor for Power Supply input in Adaptive Security Appliance 5555 with No Payload Encryption | cevSensorASA5555K7PSPresence (cevSensor 88) |
| Temperature Sensor for Power Supply Fan in Adaptive Security Appliance 5555 with No Payload Encryption | cevSensorASA5555K7PSTempSensor (cevSensor 95) |
| Sensor for Power Supply Fan in Adaptive Security Appliance 5555 | cevSensorASA5555PSFanSensor (cevSensor 91) |
| Temperature Sensor for Power Supply Fan in Adaptive Security Appliance 5555 | cevSensorASA5555PSTempSensor (cevSensor 93) |
| Sensor for power supply fan for ASA 5585-X | cevSensorASA5585PSFanSensor (cevSensor 86) |
| Sensor for power supply input for ASA 5585-X | cevSensorASA5585PSInput (cevSensor 85) |
| CPU temperature sensor for ASA 5585 SSP-10 | cevSensorASA5585SSp10CPUTemp (cevSensor 77) |
| CPU temperature sensor for ASA 5585 SSP-10 No Payload Encryption | cevSensorASA5585SSp10K7CPUTemp (cevSensor 78) |
| CPU temperature sensor for ASA 5585 SSP-20 | cevSensorASA5585SSp20CPUTemp (cevSensor 79) |
| CPU temperature sensor for ASA 5585 SSP-20 No Payload Encryption | cevSensorASA5585SSp20K7CPUTemp (cevSensor 80) |
| CPU temperature sensor for ASA 5585 SSP-40 | cevSensorASA5585SSp40CPUTemp (cevSensor 81) |
| CPU temperature sensor for ASA 5585 SSP-40 No Payload Encryption | cevSensorASA5585SSp40K7CPUTemp (cevSensor 82) |
| CPU temperature sensor for ASA 5585 SSP-60 | cevSensorASA5585SSp60CPUTemp (cevSensor 83) |
| CPU temperature sensor for ASA 5585 SSP-60 No Payload Encryption | cevSensorASA5585SSp60K7CPUTemp (cevSensor 84) |
| Adaptive Security Appliance 5555-X Field-Replaceable Solid State Drive | cevModuleASA5555XFRSSD (cevModuleCommonCards 396) |
| Adaptive Security Appliance 5545-X Field-Replaceable Solid State Drive | cevModuleASA5545XFRSSD (cevModuleCommonCards 397) |
| Adaptive Security Appliance 5525-X Field-Replaceable Solid State Drive | cevModuleASA5525XFRSSD (cevModuleCommonCards 398) |
| Adaptive Security Appliance 5515-X Field-Replaceable Solid State Drive | cevModuleASA5515XFRSSD (cevModuleCommonCards 399) |
| Adaptive Security Appliance 5512-X Field-Replaceable Solid State Drive | cevModuleASA5512XFRSSD (cevModuleCommonCards 400) |

| Item | entPhysicalVendorType OID Description |
|---|---------------------------------------|
| Cisco Adaptive Security Virtual Appliance | cevChassisASAv (cevChassis 1451) |

Supported Tables and Objects in MIBs

The following table lists the supported tables and objects for the specified MIBs.

In multi-context mode, these tables and objects provide information for a single context. If you want data across contexts, you need to sum them. For example, to get overall memory usage, sum the cempMemPoolHCUsed values for each context.

Table 4: Supported Tables and Objects in MIBs

| MIB Name | Supported Tables and Objects |
|---|---|
| CISCO-ENHANCED-MEMPOOL-MIB | <p>cempMemPoolTable, cempMemPoolIndex, cempMemPoolType, cempMemPoolName, cempMemPoolAlternate, cempMemPoolValid, cempMemPoolUsed, cempMemPoolFree, cempMemPoolUsedOvrflw, cempMemPoolHCUsed, cempMemPoolFreeOvrflw, cempMemPoolHCFree</p> <p>cempMemPoolPlatformMemory, cempMemPoolLargestFree, cempMemPoolLowestFree, cempMemPoolUsedLowWaterMark, cempMemPoolAllocHit, cempMemPoolAllocMiss, cempMemPoolFreeHit, cempMemPoolFreeMiss, cempMemPoolShared, cempMemPoolLargestFreeOvrflw, cempMemPoolHCLargestFree, cempMemPoolLowestFreeOvrflw, cempMemPoolHCLowestFree, cempMemPoolUsedLowWaterMarkOvrflw, cempMemPoolHCUsedLowWaterMark, cempMemPoolSharedOvrflw, cempMemPoolHCShared</p> |
| CISCO-ENTITY-SENSOR-EXT-MIB | ceSensorExtThresholdTable |
| Note Not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers. | |
| CISCO-L4L7MODULE-RESOURCE-LIMIT-MIB | ciscoL4L7ResourceLimitTable |
| CISCO-TRUSTSEC-SXP-MIB | ctsxSxpGlobalObjects, ctsxSxpConnectionObjects, ctsxSxpSgtObjects |
| Note Not supported on the Cisco Adaptive Security Virtual Appliance (ASAv). | |
| DISMAN-EVENT-MIB | mteTriggerTable, mteTriggerThresholdTable, mteObjectsTable, mteEventTable, mteEventNotificationTable |
| DISMAN-EXPRESSION-MIB | expExpressionTable, expObjectTable, expValueTable |
| Note Not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers. | |

| MIB Name | Supported Tables and Objects |
|--|---|
| ENTITY-SENSOR-MIB Note Not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers. Note Provides information related to physical sensors, such as chassis temperature, fan RPM, power supply voltage, etc. Not supported on the Cisco ASAv platform. | entPhySensorTable |
| NAT-MIB | natAddrMapTable, natAddrMapIndex, natAddrMapName, natAddrMapGlobalAddrType, natAddrMapGlobalAddrFrom, natAddrMapGlobalAddrTo, natAddrMapGlobalPortFrom, natAddrMapGlobalPortTo, natAddrMapProtocol, natAddrMapAddrUsed, natAddrMapRowStatus |
| CISCO-PTP-MIB Note Only MIBs corresponding to E2E Transparent Clock mode are supported. | ciscoPtpMIBSystemInfo, cPtpClockDefaultDSTable, cPtpClockTransDefaultDSTable, cPtpClockPortTransDSTable |

Supported Traps (Notifications)

The following table lists the supported traps (notifications) and their associated MIBs.

Table 5: Supported Traps (Notifications)

| Trap and MIB Name | Varbind List | Description |
|--|--------------|--|
| authenticationFailure (SNMPv2-MIB) | — | For SNMP Version 1 or 2, the community string provided in the SNMP request is incorrect. For SNMP Version 3, a report PDU is generated instead of a trap if the auth or priv passwords or usernames are incorrect. The snmp-server enable traps snmp authentication command is used to enable and disable transmission of these traps. |
| ccmCLIRunningConfigChanged (CISCO-CONFIG-MAN-MIB) | — | The snmp-server enable traps config command is used to enable transmission of this trap. |
| cefcFRUInserted (CISCO-ENTITY-FRU-CONTROL-MIB) | — | The snmp-server enable traps entity fru-insert command is used to enable this notification. This trap does not apply to the ASA 5506-X and ASA 5508-X. |

| Trap and MIB Name | Varbind List | Description |
|---|--------------|---|
| cefcFRURemoved (CISCO-ENTITY-FRU-CONTROL -MIB) | — | The snmp-server enable traps entity fru-remove command is used to enable this notification. This trap does not apply to the ASA 5506-X and ASA 5508-X. |

| Trap and MIB Name | Varbind List | Description |
|---|---|-------------|
| <p>ceSensorExtThresholdNotification (CISCO-ENTITY-SENSOR-EXT -MIB)</p> <p>Note Not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers.</p> | entPhysicalName, entPhysicalDescr, entPhySensorValue, entPhySensorType, ceSensorExtThresholdValue | |

| Trap and MIB Name | Varbind List | Description |
|-------------------|--------------|---|
| | | <p>The snmp-server enable traps entity [power-supply-failure fan-failure cpu-temperature] command is used to enable transmission of the entity threshold notifications. This notification is sent for a power supply failure. The objects sent identify the fan and CPU temperature.</p> <p>The snmp-server enable traps entity fan-failure command is used to enable transmission of the fan failure trap. This trap does not apply to the ASA 5506-X and ASA 5508-X.</p> <p>The snmp-server enable traps entity power-supply-failure command is used to enable transmission of the power supply failure trap. This trap does not apply to the ASA 5506-X and ASA 5508-X.</p> <p>The snmp-server enable traps entity chassis-fan-failure command is used to enable transmission of the chassis fan failure trap. This trap does not apply to the ASA 5506-X and ASA 5508-X.</p> <p>The snmp-server enable traps entity cpu-temperature command is used to enable transmission of the high CPU temperature trap.</p> <p>The snmp-server enable traps entity power-supply-presence command is used to enable transmission of the power supply presence failure trap. This trap does not apply to the ASA 5506-X and ASA 5508-X.</p> <p>The snmp-server enable traps entity power-supply-temperature command is used to enable transmission of the power supply temperature threshold trap. This trap does not apply to the ASA 5506-X and ASA 5508-X.</p> <p>The snmp-server enable traps entity chassis-temperature command is used to enable transmission of the chassis ambient temperature trap.</p> <p>The snmp-server enable traps entity accelerator-temperature command is used to enable transmission of the chassis</p> |

| Trap and MIB Name | Varbind List | Description |
|--|---|---|
| | | accelerator temperature trap. This trap does not apply to the ASA 5506-X and ASA 5508-X. |
| cipSecTunnelStart (CISCO-IPSEC-FLOW-MONITOR -MIB) | cipSecTunLifeTime, cipSecTunLifeSize | The snmp-server enable traps ipsec start command is used to enable transmission of this trap. |
| cipSecTunnelStop (CISCO-IPSEC-FLOW-MONITOR -MIB) | cipSecTunActiveTime | The snmp-server enable traps ipsec stop command is used to enable transmission of this trap. |
| ciscoConfigManEvent (CISCO-CONFIG-MAN-MIB) | — | The snmp-server enable traps config command is used to enable transmission of this trap. |
| ciscoRasTooManySessions (CISCO-REMOTE-ACCESS-MONITOR-MIB) | crasNumSessions, crasNumUsers, crasMaxSessionsSupportable, crasMaxUsersSupportable, crasThrMaxSessions | The snmp-server enable traps remote-access session-threshold-exceeded command is used to enable transmission of these traps. |
| clogMessageGenerated (CISCO-SYSLOG-MIB) | clogHistFacility, clogHistSeverity, clogHistMsgName, clogHistMsgText, clogHistTimestamp | Syslog messages are generated. The value of the clogMaxSeverity object is used to decide which syslog messages are sent as traps. The snmp-server enable traps syslog command is used to enable and disable transmission of these traps. |
| clrResourceLimitReached (CISCO-L4L7MODULE-RESOURCE-LIMIT-MIB) | clrResourceLimitValueType, clrResourceLimitMax, clogOriginIDType, clogOriginID | The snmp-server enable traps connection-limit-reached command is used to enable transmission of the connection-limit-reached notification. The clogOriginID object includes the context name from which the trap originated. |
| coldStart (SNMPv2-MIB) | — | The SNMP agent has started. The snmp-server enable traps snmp coldstart command is used to enable and disable transmission of these traps. |
| cpmCPURisingThreshold (CISCO-PROCESS-MIB) | cpmCPURisingThresholdValue, cpmCPUTotalMonIntervalValue, cpmCPUInterruptMonIntervalValue, cpmCPURisingThresholdPeriod, cpmProcessTimeCreated, cpmProcExtUtil5SecRev | The snmp-server enable traps cpu threshold rising command is used to enable transmission of the CPU threshold rising notification. The cpmCPURisingThresholdPeriod object is sent with the other objects. |

| Trap and MIB Name | Varbind List | Description |
|--|--|---|
| entConfigChange (ENTITY-MIB) | — | The snmp-server enable traps entity config-change fru-insert fru-remove command is used to enable this notification. Note This notification is only sent in multimode when a security context is created or removed. |
| linkDown (IF-MIB) | ifIndex, ifAdminStatus, ifOperStatus | The linkdown trap for interfaces. The snmp-server enable traps snmp linkdown command is used to enable and disable transmission of these traps. |
| linkUp (IF-MIB) | ifIndex, ifAdminStatus, ifOperStatus | The linkup trap for interfaces. The snmp-server enable traps snmp linkup command is used to enable and disable transmission of these traps. |
| mteTriggerFired (DISMAN-EVENT-MIB) | mteHotTrigger, mteHotTargetName, mteHotContextName, mteHotOID, mteHotValue, cempMemPoolName, cempMemPoolHCUsed | The snmp-server enable traps memory-threshold command is used to enable the memory threshold notification. The mteHotOID is set to cempMemPoolHCUsed. The cempMemPoolName and cempMemPoolHCUsed objects are sent with the other objects. |
| mteTriggerFired (DISMAN-EVENT-MIB) Note Not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers. | mteHotTrigger, mteHotTargetName, mteHotContextName, mteHotOID, mteHotValue, ifHCInOctets, ifHCOctets, ifHighSpeed, entPhysicalName | The snmp-server enable traps interface-threshold command is used to enable the interface threshold notification. The entPhysicalName objects are sent with the other objects. |
| natPacketDiscard (NAT-MIB) | ifIndex | The snmp-server enable traps nat packet-discard command is used to enable the NAT packet discard notification. This notification is rate limited for 5 minutes and is generated when IP packets are discarded by NAT because mapping space is not available. The ifIndex gives the ID of the mapped interface. |
| warmStart (SNMPv2-MIB) | — | The snmp-server enable traps snmp warmstart command is used to enable and disable transmission of these traps. |

Interface Types and Examples

The interface types that produce SNMP traffic statistics include the following:

- Logical—Statistics collected by the software driver, which are a subset of physical statistics.
- Physical—Statistics collected by the hardware driver. Each physical named interface has a set of logical and physical statistics associated with it. Each physical interface may have more than one VLAN interface associated with it. VLAN interfaces only have logical statistics.



Note For a physical interface that has multiple VLAN interfaces associated with it, be aware that SNMP counters for ifInOctets and ifOutOctets OIDs match the aggregate traffic counters for that physical interface.

- VLAN-only—SNMP uses logical statistics for ifInOctets and ifOutOctets.

The examples in the following table show the differences in SNMP traffic statistics. Example 1 shows the difference in physical and logical output statistics for the **show interface** command and the **show traffic** command. Example 2 shows output statistics for a VLAN-only interface for the **show interface** command and the **show traffic** command. The example shows that the statistics are close to the output that appears for the **show traffic** command.

Table 6: SNMP Traffic Statistics for Physical and VLAN Interfaces

| Example 1 | Example 2 |
|---|---|
| <pre> ciscoasa# show interface GigabitEthernet3/2 interface GigabitEthernet3/2 description fullt-mgmt nameif mgmt security-level 10 ip address 10.7.14.201 255.255.255.0 management-only ciscoasa# show traffic (Condensed output) Physical Statistics GigabitEthernet3/2: received (in 121.760 secs) 36 packets 3428 bytes 0 pkts/sec 28 bytes/sec Logical Statistics mgmt: received (in 117.780 secs) 36 packets 2780 bytes 0 pkts/sec 23 bytes/sec The following examples show the SNMP output statistics for the management interface and the physical interface. The ifInOctets value is close to the physical statistics output that appears in the show traffic command output but not to the logical statistics output. ifIndex of the mgmt interface: IF-MIB::ifDescr.6 = Adaptive Security Appliance 'mgmt' interface ifInOctets that corresponds to the physical interface statistics: IF-MIB::ifInOctets.6 = Counter32:3246 </pre> | <pre> ciscoasa# show interface GigabitEthernet0/0.100 interface GigabitEthernet0/0.100 vlan 100 nameif inside security-level 100 ip address 10.7.1.101 255.255.255.0 standby 10.7.1.102 ciscoasa# show traffic inside received (in 9921.450 secs) 1977 packets 126528 bytes 0 pkts/sec 12 bytes/sec transmitted (in 9921.450 secs) 1978 packets 126556 bytes 0 pkts/sec 12 bytes/sec ifIndex of VLAN inside: IF-MIB::ifDescr.9 = Adaptive Security Appliance 'inside' interface IF-MIB::ifInOctets.9 = Counter32: 126318 </pre> |

SNMP Version 3 Overview

SNMP Version 3 provides security enhancements that are not available in SNMP Version 1 or Version 2c. SNMP Versions 1 and 2c transmit data between the SNMP server and SNMP agent in clear text. SNMP Version 3 adds authentication and privacy options to secure protocol operations. In addition, this version controls access to the SNMP agent and MIB objects through the User-based Security Model (USM) and View-based Access Control Model (VACM). The ASA also supports the creation of SNMP groups and users, as well as hosts, which is required to enable transport authentication and encryption for secure SNMP communications.

Security Models

For configuration purposes, the authentication and privacy options are grouped together into security models. Security models apply to users and groups, which are divided into the following three types:

- NoAuthPriv—No Authentication and No Privacy, which means that no security is applied to messages.
- AuthNoPriv—Authentication but No Privacy, which means that messages are authenticated.
- AuthPriv—Authentication and Privacy, which means that messages are authenticated and encrypted.

SNMP Groups

An SNMP group is an access control policy to which users can be added. Each SNMP group is configured with a security model, and is associated with an SNMP view. A user within an SNMP group must match the security model of the SNMP group. These parameters specify what type of authentication and privacy a user within an SNMP group uses. Each SNMP group name and security model pair must be unique.

SNMP Users

SNMP users have a specified username, a group to which the user belongs, authentication password, encryption password, and authentication and encryption algorithms to use. The authentication algorithm options are MD5 and SHA. The encryption algorithm options are DES, 3DES, and AES (which is available in 128, 192, and 256 versions). When you create a user, you must associate it with an SNMP group. The user then inherits the security model of the group.

SNMP Hosts

An SNMP host is an IP address to which SNMP notifications and traps are sent. To configure SNMP Version 3 hosts, along with the target IP address, you must configure a username, because traps are only sent to a configured user. SNMP target IP addresses and target parameter names must be unique on the ASA. Each SNMP host can have only one username associated with it. To receive SNMP traps, after you have added the **snmp-server host** command, make sure that you configure the user credentials on the NMS to match the credentials for the ASA.

Implementation Differences Between the ASA and Cisco IOS Software

The SNMP Version 3 implementation in the ASA differs from the SNMP Version 3 implementation in the Cisco IOS software in the following ways:

- The local-engine and remote-engine IDs are not configurable. The local engine ID is generated when the ASA starts or when a context is created.
- No support exists for view-based access control, which results in unrestricted MIB browsing.
- Support is restricted to the following MIBs: USM, VACM, FRAMEWORK, and TARGET.
- You must create users and groups with the correct security model.
- You must remove users, groups, and hosts in the correct sequence.
- Use of the **snmp-server host** command creates an ASA rule to allow incoming SNMP traffic.

SNMP Syslog Messaging

SNMP generates detailed syslog messages that are numbered 212 nnn . Syslog messages indicate the status of SNMP requests, SNMP traps, SNMP channels, and SNMP responses from the ASA or ASASM to a specified host on a specified interface.

For detailed information about syslog messages, see the syslog messages guide.



Note SNMP polling fails if SNMP syslog messages exceed a high rate (approximately 4000 per second).

Application Services and Third-Party Tools

For information about SNMP support, see the following URL:

http://www.cisco.com/en/US/tech/tk648/tk362/tk605/tsd_technology_support_sub-protocol_home.html

For information about using third-party tools to walk SNMP Version 3 MIBs, see the following URL:

http://www.cisco.com/en/US/docs/security/asa/asa83/snmp/snmpv3_tools.html

Guidelines for SNMP

This section includes the guidelines and limitations that you should review before configuring SNMP.

Failover and Clustering Guidelines

- The SNMP client in each ASA shares engine data with its peer. Engine data includes the engineID, engineBoots, and engineTime objects of the SNMP-FRAMEWORK-MIB. Engine data is written as a binary file to flash:/snmp/*contextname*.
- When using SNMPv3 with clustering or failover, if you add a new cluster unit after the initial cluster formation or you replace a failover unit, then SNMPv3 users are not replicated to the new unit. You must re-add the SNMPv3 users to the control/active unit to force the users to replicate to the new unit; or you can add the users directly on the new unit (SNMPv3 users and groups are an exception to the rule that you cannot enter configuration commands on a cluster data unit). Reconfigure each user by entering the **snmp-server user *username group-name v3*** command on the control/active unit or directly to the data/standby unit with the *priv-password* option and *auth-password* option in their unencrypted forms.

Additional Guidelines

- Power supply traps are not issued for systems operating in appliance mode.
- You must have Cisco Works for Windows or another SNMP MIB-II compliant browser to receive SNMP traps or browse a MIB.
- For secure SNMP polling over a site-to-site VPN, include the IP address of the outside interface in the crypto map access-list as part of the VPN configuration.
- Does not support view-based access control, but the VACM MIB is available for browsing to determine default view settings.

- The ENTITY-MIB is not available in the non-admin context. Use the IF-MIB instead to perform queries in the non-admin context.
- The ENTITY-MIB is not available for the Firepower 9300. Instead, use CISCO-FIREPOWER-EQUIPMENT-MIB and CISCO-FIREPOWER-SM-MIB.
- On some devices, the order of interfaces (ifDescr) in the output of **snmpwalk** has been observed to change after a reboot. The ASA uses an algorithm to determine the ifIndex table that SNMP queries. When the ASA is booted up, the interfaces are added to the ifIndex table in the order loaded as the ASA reads the configuration. New interfaces added to the ASA are appended to the list of interfaces in the ifIndex table. As interfaces are added, removed, or renamed, it can affect the order of interfaces on reboot.
- Does not support SNMP Version 3 for the AIP SSM or AIP SSC.
- Does not support SNMP debugging.
- Does not support retrieval of ARP information.
- Does not support SNMP SET commands.
- When using NET-SNMP Version 5.4.2.1, only supports the encryption algorithm version of AES128. Does not support the encryption algorithm versions of AES256 or AES192.
- Changes to the existing configuration are rejected if the result places the SNMP feature in an inconsistent state.
- For SNMP Version 3, configuration must occur in the following order: group, user, host.
- Before a group is deleted, you must ensure that all users associated with that group are deleted.
- Before a user is deleted, you must ensure that no hosts are configured that are associated with that username.
- If users have been configured to belong to a particular group with a certain security model, and if the security level of that group is changed, you must do the following in this sequence:
 - Remove the users from that group.
 - Change the group security level.
 - Add users that belong to the new group.
- The creation of custom views to restrict user access to a subset of MIB objects is not supported.
- All requests and traps are available in the default Read/Notify View only.
- The connection-limit-reached trap is generated in the admin context. To generate this trap, you must have at least one SNMP server host configured in the user context in which the connection limit has been reached.
- You cannot query for the chassis temperature on the ASA 5585 SSP-40 (NPE).
- You can add up to 4000 hosts. However, only 128 of this number can be for traps.
- The total number of supported active polling destinations is 128.
- You can specify a network object to indicate the individual hosts that you want to add as a host group.
- You can associate more than one user with one host.

- You can specify overlapping network objects in different **host-group** commands. The values that you specify for the last host group take effect for the common set of hosts in the different network objects.
- If you delete a host group or hosts that overlap with other host groups, the hosts are set up again using the values that have been specified in the configured host groups.
- The values that the hosts acquire depend on the specified sequence that you use to run the commands.
- The limit on the message size that SNMP sends is 1472 bytes.
- The ASA supports an unlimited number of SNMP server trap hosts per context. The **show snmp-server host** command output displays only the active hosts that are polling the ASA, as well as the statically configured hosts.

Troubleshooting Tips

- To ensure that the SNMP process that receives incoming packets from the NMS is running, enter the following command:

```
ciscoasa(config)# show process | grep snmp
```

- To capture syslog messages from SNMP and have them appear on the ASA console, enter the following commands:

```
ciscoasa(config)# logging list snmp message 212001-212015
ciscoasa(config)# logging console snmp
```

- To make sure that the SNMP process is sending and receiving packets, enter the following commands:

```
ciscoasa(config)# clear snmp-server statistics
ciscoasa(config)# show snmp-server statistics
```

The output is based on the SNMP group of the SNMPv2-MIB.

- To make sure that SNMP packets are going through the ASA and to the SNMP process, enter the following commands:

```
ciscoasa(config)# clear asp drop
ciscoasa(config)# show asp drop
```

- If the NMS cannot request objects successfully or is not handing incoming traps from the ASA correctly, use a packet capture to isolate the problem, by entering the following commands:

```
ciscoasa (config)# access-list snmp permit udp any eq snmptrap any
ciscoasa (config)# access-list snmp permit udp any any eq snmp
ciscoasa (config)# capture snmp type raw-data access-list snmp interface mgmt
ciscoasa (config)# copy /pcap capture:snmp tftp://192.0.2.5/example-dir/snmp.pcap
```

- If the ASA is not performing as expected, obtain information about network topology and traffic by doing the following:

- For the NMS configuration, obtain the following information:

Number of timeouts

Retry count

Engine ID caching

Username and password used

- Issue the following commands:

show block

show interface

show process

show cpu

show vm

- If a fatal error occurs, to help in reproducing the error, send a traceback file and the output of the **show tech-support** command to Cisco TAC.
- If SNMP traffic is not being allowed through the ASA interfaces, you might also need to permit ICMP traffic from the remote SNMP server using the **icmp permit** command.
- For additional troubleshooting information, see the following URL:
<http://www.cisco.com/c/en/us/support/docs/security/asa-5500-x-series-next-generation-firewalls/116423-troubleshoot-asa-smmp.html>

Configure SNMP

This section describes how to configure SNMP.

Procedure

- Step 1** Enable the SNMP Agent and SNMP server.
 - Step 2** Configure SNMP traps.
 - Step 3** Configure SNMP Version 1 and 2c parameters or SNMP Version 3 parameters.
-

Enable the SNMP Agent and SNMP Server

To enable the SNMP agent and SNMP server, perform the following steps:

Procedure

Enable the SNMP agent and SNMP server on the ASA. By default, the SNMP server is enabled.

snmp-server enable

Example:

```
ciscoasa(config)# snmp-server enable
```

Configure SNMP Traps

To designate which traps that the SNMP agent generates and how they are collected and sent to NMSs, perform the following steps:

Procedure

Send individual traps, sets of traps, or all traps to the NMS.

```
snmp-server enable traps [all | syslog | snmp [authentication | linkup | linkdown | coldstart | warmstart]
| config | entity [config-change | fru-insert | fru-remove | fan-failure | cpu-temperature | chassis-fan-failure
| power-supply] | chassis-temperature | power-supply-presence | power-supply-temperature |
accelerator-temperature | I1-bypass-status] | ikev2 [start | stop] | ipsec [start | stop] | remote-access
[session-threshold-exceeded] | connection-limit-reached | cpu threshold rising | interface-threshold |
memory-threshold | nat [packet-discard]
```

Example:

```
ciscoasa(config)# snmp-server enable traps snmp authentication
linkup linkdown coldstart warmstart
```

This command enables syslog messages to be sent as traps to the NMS. The default configuration has all SNMP standard traps enabled, as shown in the example. To disable these traps, use the **no snmp-server enable traps snmp** command.

If you enter this command and do not specify a trap type, the default is the **syslog** trap. By default, the **syslog** trap is enabled. The default SNMP traps continue to be enabled with the **syslog** trap.

You need to configure both the **logging history** command and the **snmp-server enable traps syslog** command to generate traps from the syslog MIB.

To restore the default enabling of SNMP traps, use the **clear configure snmp-server** command. All other traps are disabled by default.

Traps available in the admin context only:

- **connection-limit-reached**
- **entity**
- **memory-threshold**

Traps generated through the admin context only for physically connected interfaces in the system context:

- **interface-threshold**

All other traps are available in the admin and user contexts in single mode.

In multiple context mode, the **fan-failure** trap, the **power-supply** trap, and the **cpu-temperature** trap are generated only from the admin context, and not the user contexts (applies only to the ASA 5512-X, 5515-X, 5525-X, 5545-X, and 5555-X).

The **config** trap enables the ciscoConfigManEvent notification and the ccmCLIRunningConfigChanged notification, which are generated after you have exited configuration mode.

If the CPU usage is greater than the configured threshold value for the configured monitoring period, the **cpu threshold rising** trap is generated.

When the used system context memory reaches 80 percent of the total system memory, the **memory-threshold** trap is generated from the admin context. For all other user contexts, this trap is generated when the used memory reaches 80 percent of the total system memory in that particular context.

Some traps are not applicable to certain hardware models. Use ? in place of a trap keyword to determine which traps are available for your device. For example:

- The **interface-threshold** trap is not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers.
- The **accelerator-temperature** threshold trap applies only to the ASA 5506-X and ASA 5508-X.
- The **chassis-fan-failure** trap does not apply to the ASA 5506-X.
- The following traps do not apply to the ASA 5506-X and ASA 5508-X: **fan-failure**, **fru-insert**, **fru-remove**, **power-supply**, **power-supply-presence**, and **power-supply-temperature**.

Note SNMP does not monitor voltage sensors.

Configure a CPU Usage Threshold

To configure a CPU usage threshold, perform the following steps:

Procedure

Configure the threshold value for a high CPU threshold and the threshold monitoring period.

snmp cpu threshold rising *threshold_value monitoring_period*

Example:

```
ciscoasa(config)# snmp cpu threshold rising 75% 30 minutes
```

To clear the threshold value and monitoring period of the CPU utilization, use the **no** form of this command. If the **snmp cpu threshold rising** command is not configured, the default for the high threshold level is over 70 percent, and the default for the critical threshold level is over 95 percent. The default monitoring period is set to 1 minute.

You cannot configure the critical CPU threshold level, which is maintained at a constant 95 percent. Valid threshold values for a high CPU threshold range from 10 to 94 percent. Valid values for the monitoring period range from 1 to 60 minutes.

Configure a Physical Interface Threshold

To configure the physical interface threshold, perform the following steps:

Procedure

Configure the threshold value for an SNMP physical interface.

snmp interface threshold *threshold_value*

Example:

```
ciscoasa(config)# snmp interface threshold 75%
```

To clear the threshold value for an SNMP physical interface, use the **no** form of this command. The threshold value is defined as a percentage of interface bandwidth utilization. Valid threshold values range from 30 to 99 percent. The default value is 70 percent.

The **snmp interface threshold** command is available only in the admin context.

Physical interface usage is monitored in single mode and multimode, and traps for physical interfaces in the system context are sent through the admin context. Only physical interfaces are used to compute threshold usage.

Note This command is not supported on the ASA Services Module for Catalyst 6500 switches/7600 routers.

Configure Parameters for SNMP Version 1 or 2c

To configure parameters for SNMP Version 1 or 2c, perform the following steps:

Procedure

Step 1

Specify the recipient of an SNMP notification, indicate the interface from which traps are sent, and identify the name and IP address of the NMS or SNMP manager that can connect to the ASA.

snmp-server host {*interface hostname* | *ip_address*} [**trap**] **poll**] [**community** *community-string*] [**version** {**1** **2c** | *username*}] [**udp-port** *port*]

Example:

The **trap** keyword limits the NMS to receiving traps only. The **poll** keyword limits the NMS to sending requests (polling) only. By default, SNMP traps are enabled. By default, the UDP port is 162. The community

string is a shared secret key between the ASA and the NMS. The key is a case-sensitive value up to 32 alphanumeric characters long. Spaces are not permitted. The default community string is public. The ASA uses this key to determine whether or not the incoming SNMP request is valid. For example, you could designate a site with a community string and then configure the ASA and the management station with the same string. The ASA uses the specified string and do not respond to requests with an invalid community string. After you have used an encrypted community string, only the encrypted form is visible to all systems (for example, CLI, ASDM, CSM, and so on). The clear text password is not visible. The encrypted community string is always generated by the ASA; you normally enter the clear text form.

To receive traps after you have added the **snmp-server host** command, make sure that you configure the user on the NMS with the same credentials as the credentials configured on the ASA.

Step 2 Set the community string, which is for use *only* with SNMP Version 1 or 2c.

snmp-server community *community-string*

Example:

```
ciscoasa(config)# snmp-server community onceuponatime
```

Note You should avoid the use of special characters (!, @, #, \$, %, ^, &, *, \) in community strings. In general, using any special characters reserved for functions used by the operating system can cause unexpected results. For example, the backslash (\) is interpreted as an escape character and should not be used in the community string.

Step 3 Set the SNMP server location or contact information.

snmp-server [contact | location] *text*

Example:

```
ciscoasa(config)# snmp-server location building 42
ciscoasa(config)# snmp-server contact EmployeeA
```

The *text* argument specifies the name of the contact person or the ASA system administrator. The name is case sensitive and can be up to 127 characters. Spaces are accepted, but multiple spaces are shortened to a single space.

Step 4 Set the listening port for SNMP requests.

snmp-server listen-port *lport*

Example:

```
ciscoasa(config)# snmp-server lport 192
```

The *lport* argument is the port on which incoming requests are accepted. The default listening port is 161. The **snmp-server listen-port** command is only available in admin context, and is not available in the system context. If you configure the **snmp-server listen-port** command on a port that is currently in use, the following message appears:

```
The UDP port port is in use by another feature. SNMP requests to the device
will fail until the snmp-server listen-port command is configured to use a different port.
```

The existing SNMP thread continues to poll every 60 seconds until the port is available, and issues syslog message %ASA-1-212001 if the port is still in use.

Configure Parameters for SNMP Version 3

To configure parameters for SNMP Version 3, perform the following steps:

Procedure

Step 1 Specify a new SNMP group, which is for use *only* with SNMP Version 3.

```
snmp-server group group-name v3 [auth | noauth | priv]
```

Example:

```
ciscoasa(config)# snmp-server group testgroup1 v3 auth
```

When a community string is configured, two additional groups with the name that matches the community string are autogenerated: one for the Version 1 security model and one for the Version 2 security model. The **auth** keyword enables packet authentication. The **noauth** keyword indicates no packet authentication or encryption is being used. The **priv** keyword enables packet encryption and authentication. No default values exist for the **auth** or **priv** keywords.

Step 2 Configure a new user for an SNMP group, which is for use only with SNMP Version 3.

```
snmp-server user username group_name v3 [engineID engineID] [encrypted] [auth {md5 | sha}
auth_password [priv {des | 3des | aes {128 | 192 | 256}} priv_password]]
```

Example:

```
ciscoasa(config)# snmp-server user testuser1 testgroup1 v3 auth md5 testpassword
aes 128 mypassword
ciscoasa(config)# snmp-server user testuser1 public v3 encrypted auth md5
00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF
```

The username argument is the name of the user on the host that belongs to the SNMP agent. The group-name argument is the name of the group to which the user belongs. The **v3** keyword specifies that the SNMP Version 3 security model should be used and enables the use of the **encrypted**, **priv**, and the **auth** keywords. The **engineID** keyword is optional and specifies the engineID of the ASA which was used to localize the user's authentication and encryption information. The engineID argument must specify a valid ASA engineID.

The **encrypted** keyword specifies the password in encrypted format. Encrypted passwords must be in hexadecimal format.

The **auth** keyword specifies which authentication level (**md5** or **sha**) should be used. The **priv** keyword specifies the encryption level. No default values for the **auth** or **priv** keywords, or default passwords exist.

For the encryption algorithm, you can specify the **des**, **3des**, or **aes** keyword. You can also specify which version of the AES encryption algorithm to use: **128**, **192**, or **256**. The auth-password argument specifies the authentication user password. The priv-password argument specifies the encryption user password.

If you forget a password, you cannot recover it and you must reconfigure the user. You can specify a plain-text password or a localized digest. The localized digest must match the authentication algorithm selected for the user, which can be MD5 or SHA. When the user configuration is displayed on the console or is written to a file (for example, the startup-configuration file), the localized authentication and privacy digests are always displayed instead of a plain-text password (see the second example). The minimum length for a password is 1 alphanumeric character; however, we recommend that you use at least 8 alphanumeric characters for security.

When using SNMPv3 with clustering, if you add a new cluster unit after the initial cluster formation, then SNMPv3 users are not replicated to the new unit. You must re-add the SNMPv3 users to the control unit to force the users to replicate to the new unit; or you can add the users directly on the new unit (SNMPv3 users and groups are an exception to the rule that you cannot enter configuration commands on a cluster data unit). Reconfigure each user by entering the **snmp-server user *username group-name v3*** command on the control unit or directly to the data unit with the *priv-password* option and *auth-password* option in their unencrypted forms.

If you enter a user on the control unit with the **encrypted** keyword, an error message appears to inform you that the SNMPv3 user commands will not be replicated. This behavior also means that existing SNMPv3 user and group commands are not cleared during replication.

For example, a control unit using commands entered with encrypted keys:

```
ciscoasa(config)# snmp-server user defe abc v3 encrypted auth sha
c0:e7:08:50:47:eb:2e:e4:3f:a3:bc:45:f6:dd:c3:46:25:a0:22:9a
priv aes 256 cf:ad:85:5b:e9:14:26:ae:8f:92:51:12:91:16:a3:ed:de:91:6b:f7:
f6:86:cf:18:c0:f0:47:d6:94:e5:da:01
ERROR: This command cannot be replicated because it contains localized keys.
```

For example, a data unit during cluster replication (appears only if an **snmp-server user** commands exist in the configuration):

```
ciscoasa(cfg-cluster)#
Detected Cluster Master.
Beginning configuration replication from Master.
WARNING: existing snmp-server user CLI will not be cleared.
```

Step 3 Specify the recipient of an SNMP notification. Indicate the interface from which traps are sent. Identify the name and IP address of the NMS or SNMP manager that can connect to the ASA.

```
snmp-server host interface {hostname | ip_address} [trap|poll] [community community-string] [version
{1 | 2c | 3 username}] [udp-port port]
```

Example:

The **trap** keyword limits the NMS to receiving traps only. The **poll** keyword limits the NMS to sending requests (polling) only. By default, SNMP traps are enabled. By default, the UDP port is 162. The community string is a shared secret key between the ASA and the NMS. The key is a case-sensitive value up to 32 alphanumeric characters. Spaces are not permitted. The default community-string is public. The ASA uses this key to determine whether the incoming SNMP request is valid. For example, you could designate a site with a community string and then configure the ASA and the NMS with the same string. The ASA uses the specified string and do not respond to requests with an invalid community string. After you have used an encrypted community string, only the encrypted form is visible to all systems (for example, CLI, ASDM, CSM, and so on). The clear text password is not visible. The encrypted community string is always generated by the ASA; you normally enter the clear text form.

The **version** keyword specifies the SNMP trap version. The ASA does not support filtering based on SNMP requests (polling).

When SNMP Version 3 hosts are configured on the ASA, a user must be associated with that host.

To receive traps after you have added the **snmp-server host** command, make sure that you configure the user on the NMS with the same credentials as the credentials configured on the ASA.

Step 4 Set the SNMP server location or contact information.

snmp-server [contact | location] text

Example:

```
ciscoasa(config)# snmp-server location building 42
ciscoasa(config)# snmp-server contact EmployeeA
```

The *text* argument specifies the name of the contact person or the ASA system administrator. The name is case sensitive and can be up to 127 characters. Spaces are accepted, but multiple spaces are shortened to a single space.

Step 5 Set the listening port for SNMP requests.

snmp-server listen-port lport

Example:

```
ciscoasa(config)# snmp-server lport 192
```

The *lport* argument is the port on which incoming requests are accepted. The default listening port is 161. The **snmp-server listen-port** command is only available in admin context, and is not available in the system context. If you configure the **snmp-server listen-port** command on a port that is currently in use, the following message appears:

```
The UDP port port is in use by another feature. SNMP requests to the device
will fail until the snmp-server listen-port command is configured to use a different port.
```

The existing SNMP thread continues to poll every 60 seconds until the port is available, and issues syslog message %ASA-1-212001 if the port is still in use.

Configure a Group of Users

To configure an SNMP user list with a group of specified users in it, perform the following steps:

Procedure

Configure an SNMP user list.

snmp-server user-list list_name username user_name

Example:

```
ciscoasa(config)# snmp-server user-list engineering username user1
```

The *listname* argument specifies the name of the user list, which may be up to 33 characters long. The **username** *user_name* keyword-argument pair specifies the users who may be configured in the user list. You configure the users in the user list with the **snmp-server user** *username* command, which is available only if you are using SNMP Version 3. The user list must have more than one user in it and can be associated with a hostname or a range of IP addresses.

Associate Users with a Network Object

To associate a single user or a group of users in a user list with a network object, perform the following steps:

Procedure

Associate a single user or a group of users in a user list with a network object.

```
snmp-server host-group net_obj_name [trap | poll] [community community-string] [version {1 | 2c | 3} {username | user-list list_name}] [udp-port port]
```

Example:

```
ciscoasa(config)# snmp-server host-group inside net1 trap community public version 1
ciscoasa(config)# snmp-server host-group inside net1 trap community public version 2c
ciscoasa(config)# snmp-server host-group inside net1 trap version 3 user1
ciscoasa(config)# snmp-server host-group inside net1 trap version 3 user-list engineering
```

The *net_obj_name* argument specifies the interface network object name with which a user or group of users is associated.

The **trap** keyword specifies that only traps can be sent, and that this host is not allowed to browse (poll). SNMP traps are enabled by default.

The **poll** keyword specifies that the host is allowed to browse (poll), but no traps can be sent.

The **community** keyword specifies that a non-default string is required for requests from the NMS, or when generating traps sent to the NMS. You can use this keyword only for SNMP Version 1 or 2c. The *community-string* argument specifies the password-like community string that is sent with the notification or in a request from the NMS. The community string can have a maximum of 32 characters.

The **version** keyword sets the SNMP notification version to Version 1, 2c, or 3 to use for sending traps and accepting requests (polling). The default version is 1.

The *username* argument specifies the name of the user if you are using SNMP Version 3.

The **user-list** *list_name* keyword-argument pair specifies the name of the user list.

The **udp-port** *port* keyword-argument pair specifies that SNMP traps must be sent to an NMS host on a non-default port and sets the UDP port number of the NMS host. The default UDP port is 162.

Monitoring SNMP

See the following commands for monitoring SNMP.

- **show running-config snmp-server [default]**
This command shows all SNMP server configuration information.
- **show running-config snmp-server group**
This command shows SNMP group configuration settings.
- **show running-config snmp-server host**
This command shows configuration settings used by SNMP to control messages and notifications sent to remote hosts.
- **show running-config snmp-server host-group**
This command shows SNMP host group configurations.
- **show running-config snmp-server user**
This command shows SNMP user-based configuration settings.
- **show running-config snmp-server user-list**
This command shows SNMP user list configurations.
- **show snmp-server engineid**
This command shows the ID of the SNMP engine configured.
- **show snmp-server group**
This command shows the names of configured SNMP groups. If the community string has already been configured, two extra groups appear by default in the output. This behavior is normal.
- **show snmp-server statistics**
This command shows the configured characteristics of the SNMP server. To reset all SNMP counters to zero, use the **clear snmp-server statistics** command.
- **show snmp-server user**
This command shows the configured characteristics of users.

Examples

The following example shows how to display SNMP server statistics:

```
ciscoasa(config)# show snmp-server statistics
0 SNMP packets input
  0 Bad SNMP version errors
  0 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  0 Number of requested variables
  0 Number of altered variables
```



```
0 Get-request PDUs
0 Get-next PDUs
0 Get-bulk PDUs
0 Set-request PDUs (Not supported)
0 SNMP packets output
  0 Too big errors (Maximum packet size 512)
  0 No such name errors
  0 Bad values errors
  0 General errors
  0 Response PDUs
  0 Trap PDUs
```

The following example shows how to display the SNMP server running configuration:

```
ciscoasa(config)# show running-config snmp-server
no snmp-server location
no snmp-server contact
snmp-server enable traps snmp authentication linkup linkdown coldstart
```

Examples for SNMP

The following section provides examples that you can use as reference for all SNMP versions.

SNMP Versions 1 and 2c

The following example shows how the ASA can receive SNMP requests from host 192.0.2.5 on the inside interface but does not send any SNMP syslog requests to any host:

```
ciscoasa(config)# snmp-server host 192.0.2.5
ciscoasa(config)# snmp-server location building 42
ciscoasa(config)# snmp-server contact EmployeeA
ciscoasa(config)# snmp-server community ohwhatakeyisthee
```

SNMP Version 3

The following example shows how the ASA can receive SNMP requests using the SNMP Version 3 security model, which requires that the configuration follow this specific order: group, followed by user, followed by host:

```
ciscoasa(config)# snmp-server group v3 vpn-group priv
ciscoasa(config)# snmp-server user admin vpn group v3 auth sha letmein priv 3des cisco123
ciscoasa(config)# snmp-server host mgmt 10.0.0.1 version 3 priv admin
```

History for SNMP

Table 7: History for SNMP

| Feature Name | Version | Description |
|----------------------------|-------------------|--|
| SNMP Versions 1 and 2c | 7.0(1) | Provides ASA network monitoring and event information by transmitting data between the SNMP server and SNMP agent through the clear text community string. |
| SNMP Version 3 | 8.2(1) | <p>Provides 3DES or AES encryption and support for SNMP Version 3, the most secure form of the supported security models. This version allows you to configure users, groups, and hosts, as well as authentication characteristics by using the USM. In addition, this version allows access control to the agent and MIB objects and includes additional MIB support.</p> <p>We introduced or modified the following commands: show snmp-server engineid, show snmp-server group, show snmp-server user, snmp-server group, snmp-server user, snmp-server host.</p> |
| Password encryption | 8.3(1) | <p>Supports password encryption.</p> <p>We modified the following commands: snmp-server community, snmp-server host.</p> |
| SNMP traps and MIBs | 8.4(1) | <p>Supports the following additional keywords: connection-limit-reached, cpu threshold rising, entity cpu-temperature, entity fan-failure, entity power-supply, ikev2 stop start, interface-threshold, memory-threshold, nat packet-discard, warmstart.</p> <p>The entPhysicalTable reports entries for sensors, fans, power supplies, and related components.</p> <p>Supports the following additional MIBs: CISCO-ENTITY-SENSOR-EXT-MIB, CISCO-ENTITY-FRU-CONTROL-MIB, CISCO-PROCESS-MIB, CISCO-ENHANCED-MEMPOOL-MIB, CISCO-L4L7MODULE-RESOURCE-LIMIT-MIB, DISMAN-EVENT-MIB, DISMAN-EXPRESSION-MIB, ENTITY-SENSOR-MIB, NAT-MIB.</p> <p>Supports the following additional traps: ceSensorExtThresholdNotification, clrResourceLimitReached, cpmCPURisingThreshold, mteTriggerFired, natPacketDiscard, warmStart.</p> <p>We introduced or modified the following commands: snmp cpu threshold rising, snmp interface threshold, snmp-server enable traps.</p> |
| IF-MIB ifAlias OID support | 8.2(5)/ 8.4(2) | The ASA now supports the ifAlias OID. When you browse the IF-MIB, the ifAlias OID will be set to the value that has been set for the interface description. |

| Feature Name | Version | Description |
|-----------------------------|---------|--|
| ASA Services Module (ASASM) | 8.5(1) | <p>The ASASM supports all MIBs and traps that are present in 8.4(1), except for the following:</p> <p>Unsupported MIBs in 8.5(1):</p> <ul style="list-style-type: none"> • CISCO-ENTITY-SENSOR-EXT-MIB (Only objects under the entPhySensorTable group are supported). • ENTITY-SENSOR-MIB (Only objects in the entPhySensorTable group are supported). • DISMAN-EXPRESSION-MIB (Only objects in the expExpressionTable, expObjectTable, and expValueTable groups are supported). <p>Unsupported traps in 8.5(1):</p> <ul style="list-style-type: none"> • ceSensorExtThresholdNotification (CISCO-ENTITY-SENSOR-EXT-MIB). This trap is only used for power supply failure, fan failure, and high CPU temperature events. • InterfacesBandwidthUtilization. |
| SNMP traps | 8.6(1) | <p>Supports the following additional keywords for the ASA 5512-X, 5515-X, 5525-X, 5545-X, and 5555-X: entity power-supply-presence, entity power-supply-failure, entity chassis-temperature, entity chassis-fan-failure, entity power-supply-temperature.</p> <p>We modified the following command: snmp-server enable traps.</p> |
| VPN-related MIBs | 9.0(1) | <p>An updated version of the CISCO-IPSEC-FLOW-MONITOR-MIB.my MIB has been implemented to support the next generation encryption feature.</p> <p>The following MIBs have been enabled for the ASASM:</p> <ul style="list-style-type: none"> • ALTIGA-GLOBAL-REG.my • ALTIGA-LBSSF-STATS-MIB.my • ALTIGA-MIB.my • ALTIGA-SSL-STATS-MIB.my • CISCO-IPSEC-FLOW-MONITOR-MIB.my • CISCO-REMOTE-ACCESS-MONITOR-MIB.my |
| Cisco TrustSec MIB | 9.0(1) | Support for the following MIB was added: CISCO-TRUSTSEC-SXP-MIB. |
| SNMP OIDs | 9.1(1) | Five new SNMP Physical Vendor Type OIDs have been added to support the ASA 5512-X, 5515-X, 5525-X, 5545-X, and 5555-X. |
| NAT MIB | 9.1(2) | Added the cnatAddrBindNumberOfEntries and cnatAddrBindSessionCount OIDs to support the xlate_count and max_xlate_count entries, which are the equivalent to allowing polling using the show xlate count command. |

| Feature Name | Version | Description |
|---|---------|--|
| SNMP hosts, host groups, and user lists | 9.1(5) | <p>You can now add up to 4000 hosts. The number of supported active polling destinations is 128. You can specify a network object to indicate the individual hosts that you want to add as a host group. You can associate more than one user with one host.</p> <p>We introduced or modified the following commands: snmp-server host-group, snmp-server user-list, show running-config snmp-server, clear configure snmp-server.</p> |
| SNMP message size | 9.2(1) | The limit on the message size that SNMP sends has been increased to 1472 bytes. |
| SNMP OIDs and MIBs | 9.2(1) | <p>The ASA now supports the cpmCPUTotal5minRev OID.</p> <p>The ASAv has been added as a new product to the SNMP sysObjectID OID and entPhysicalVendorType OID.</p> <p>The CISCO-PRODUCTS-MIB and CISCO-ENTITY-VENDORTYPE-OID-MIB have been updated to support the new ASAv platform.</p> <p>A new SNMP MIB for monitoring VPN shared license usage has been added.</p> |
| SNMP OIDs and MIBs | 9.3(1) | CISCO-REMOTE-ACCESS-MONITOR-MIB (OID 1.3.6.1.4.1.9.9.392) support has been added for the ASASM. |
| SNMP MIBs and traps | 9.3(2) | <p>The CISCO-PRODUCTS-MIB and CISCO-ENTITY-VENDORTYPE-OID-MIB have been updated to support the ASA 5506-X.</p> <p>The ASA 5506-X has been added as new products to the SNMP sysObjectID OID and entPhysicalVendorType OID tables.</p> <p>The ASA now supports the CISCO-CONFIG-MAN-MIB, which enables you to do the following:</p> <ul style="list-style-type: none"> • Know which commands have been entered for a specific configuration. • Notify the NMS when a change has occurred in the running configuration. • Track the time stamps associated with the last time that the running configuration was changed or saved. • Track other changes to commands, such as terminal details and command sources. <p>We modified the following command: snmp-server enable traps.</p> |
| SNMP MIBs and traps | 9.4(1) | The ASA 5506W-X, ASA 5506H-X, ASA 5508-X, and ASA 5516-X have been added as a new product to the SNMP sysObjectID OID and entPhysicalVendorType OID tables. |

| Feature Name | Version | Description |
|---|------------|---|
| Unlimited SNMP server trap hosts per context | 9.4(1) | The ASA supports unlimited SNMP server trap hosts per context. The show snmp-server host command output displays only the active hosts that are polling the ASA, as well as the statically configured hosts. We modified the following command: show snmp-server host . |
| Added support for ISA 3000 | 9.4(1.225) | The ISA 3000 family of products is now supported for SNMP. We added new OIDs for this platform. The snmp-server enable traps entity command has been modified to include a new variable <i>ll-bypass-status</i> . This enables hardware bypass status change. We modified the following command: snmp-server enable traps entity . |
| Support for the cempMemPoolTable in the CISCO-ENHANCED-MEMPOOL-MIB | 9.6(1) | The cempMemPoolTable of the CISCO-ENHANCED-MEMPOOL-MIB is now supported. This is a table of memory pool monitoring entries for all physical entities on a managed system. Note The CISCO-ENHANCED-MEMPOOL-MIB uses 64-bit counters and supports reporting of memory on platforms with more than 4GB of RAM. |
| Support for E2E Transparent Clock Mode MIBs for the Precision Time Protocol (PTP) | 9.7(1) | MIBs corresponding to E2E Transparent Clock mode are now supported. Note Only SNMP get, bulkget, getnext, and walk operations are supported. |

