



Troubleshooting Users

This chapter contains the following sections:

- [Troubleshooting Cisco ACI Multi-Site External User Authentication, on page 1](#)

Troubleshooting Cisco ACI Multi-Site External User Authentication

Use the following tips to troubleshoot external user authentication problems.

-
- Step 1** To investigate the error `Authentication method failed`, verify the following:
- The key given in the Provider configuration is correct
 - The Multi-Site (client) IP address is registered in the remote Cisco ACS server
- Step 2** To investigate the error `Invalid user credentials`, verify the following:
- The username entered on the Multi-Site login screen is correct and matches one that is configured on the Cisco ACS server
 - The password entered on the Multi-Site login screen is correct and matches one that is configured on the Cisco ACS server
- Step 3** If the user sees a Loading icon, followed by the errors `Loading ...` and `Authentication method failed`, verify the following:
- The IP address in the Provider configuration is correct
 - The IP addresses for the Provider and Cisco ACS are reachable
 - The port and protocol in the Provider configuration is correct
 - The correct authentication method (TACACS+ or RADIUS) is selected on the remote ACS server under **...Network Devices and AAA Clients > Authentication Options**
 - The correct shared secret is provided in the remote ACS server user configuration, and it is not empty

Step 4 If the user is able to login, but is not able to see anything or is not able to see any tabs on the Multi-Site GUI, verify that the Cisco AV Pair and the roles are configured correctly for that user, on the remote ACS server.
