



Configuring VLANs

This chapter contains the following sections:

- [Information About VLANs, page 1](#)
- [Guidelines and Limitations, page 2](#)
- [Default Settings, page 3](#)
- [Configuring a VLAN, page 4](#)
- [Verifying the Configuration, page 8](#)
- [Feature History for VLANs, page 8](#)

Information About VLANs

Physical NICs are always assigned as trunk ports that transmit either VLAN tagged or untagged packets. A vswitch can have the following VLAN configurations:

Configuration	Description
External Switch Tagging (EST)	Physical NICs are untagged and all vNICs are access ports. EST is enabled by default and is used when the VLAN for the vNIC is set to 0 or left blank.
Virtual Switch Tagging (VST)	All physical NIC ports are tagged and vNICs are access ports. VST is enabled whenever the vNIC's VLAN is set to any value between 1 and 4094, inclusive.
Virtual Machine Guest Tagging (VGT)	All physical NIC ports are tagged. vNICs are trunk ports. To configure VGT, the VLAN is set to 4095 on the vNIC that is connected to the Virtual Machine (VM).

Physical ports are always trunk ports by default. The VM interfaces can be either access ports or trunk ports.

vEthernet interfaces that are assigned to specific VLANs are tagged with the VLAN when transmitted. A vEthernet interface that is not assigned to a specific VLAN, or assigned to VLAN 0, is transmitted as untagged on the physical NIC interfaces. When the VLAN is not specified, it is assumed to be 1.

The following table summarizes the actions taken on packets that are received by the Virtual Ethernet Module (VEM) based on VLAN tagging.

Table 1: VEM Action on VLAN Tagging

Port Type	Packet received	Action
Access	Tagged	The packet is dropped.
Access	Untagged	The VEM adds access VLAN to the packet.
Trunk	Tagged	No action is taken on the packet.
Trunk	Untagged	The VEM adds native VLAN tag to packet.

Guidelines and Limitations

In accordance with the IEEE 802.1Q standard, up to 4094 VLANs (from 1 to 4094) are supported in the Cisco Nexus 1000V, and are listed in the following table.



Note

For VLAN configuration limits, see [Layer 2 Switching Configuration Limits](#).

Table 2: Cisco Nexus 1000V VLAN Numbering

VLAN Numbers	Range	Usage
1	Normal	Cisco Nexus 1000V default. You can use this VLAN, but you cannot modify or delete it.
2 to 1005	Normal	You can create, use, modify, or delete these VLANs.

VLAN Numbers	Range	Usage
1006 to 4094	Extended	<p>You can create, name, or use these VLANs. You cannot change the following parameters:</p> <ul style="list-style-type: none"> • The state is always active. • These VLANs are always enabled. You cannot shut down these VLANs. <p>The extended system ID is always automatically enabled.</p>
3968 to 4047 and 4094	Internally allocated	<p>You cannot use, create, delete, or modify these VLANs. You can display these VLANs.</p> <p>The Cisco Nexus 1000V allocates these 80 VLANs, plus VLAN 4094, for features, like diagnostics, that use internal VLANs for their operation.</p>

Default Settings

Table 3: Default VLAN Settings

Parameters	Default
VLAN assignment for all interfaces and all ports configured as switchports	VLAN 1
VLAN name	VLANxxxx where xxxx represent four numeric digits (including leading zeroes) equal to the VLAN ID number
Shut state	No shutdown
Operational state	Active
External Switch Tagging (EST)	Enabled
Physical ports	Trunk ports
IGMP snooping	Enabled

Configuring a VLAN

Creating a VLAN

You can do one of the following:

- Create a single VLAN that does not already exist.
- Create a range of VLANs that does not already exist.
- Delete an existing VLAN.


Note

All interfaces and all ports configured as switchports are in VLAN 1 by default.

Before You Begin

- Log in to the CLI in EXEC mode.
- Know that VLAN characteristics are configured in the VLAN configuration mode. To configure a VLAN that is already created, see [Configuring VLAN Characteristics, on page 6](#).
- Be familiar with the VLAN numbering in the [Guidelines and Limitations, on page 2](#).
- Know that newly created VLANs remain unused until Layer 2 ports are assigned to them.
- Know that when you delete a specified VLAN, the ports associated to that VLAN are shut down and no traffic flows. When you delete a specified VLAN from a trunk port, only that VLAN is shut down and traffic continues to flow on all the other VLANs through the trunk port. However, the system retains all the VLAN-to-port mapping for that VLAN, and when you reenables, or re-creates, that specified VLAN, the system automatically reinstates all the original ports to that VLAN. Note that the static MAC addresses and aging time for that VLAN are not restored when the VLAN is reenables.


Note

Be aware that the Cisco NX-OS commands may differ from those commands used in Cisco IOS.

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# show vlan	Displays the VLANs that already exist.
Step 3	switch(config)# [no] vlan { <i>vlan-id</i> <i>vlan-range</i> }	Creates or deletes, and saves in the running configuration, a VLAN or a range of VLANs. To configure the VLAN, see Configuring VLAN Characteristics, on page 6 .

	Command or Action	Purpose
		<p>Note If you enter a VLAN ID that is assigned to an internally allocated VLAN, the system returns an error message. From the VLAN configuration mode, you can also create and delete VLANs.</p> <p>For information about Assigning Layer 2 interfaces to VLANs (access or trunk ports), see the <i>Cisco Nexus 1000V Interface Configuration Guide</i>.</p> <p>For information about configuring ports as VLAN access or trunk ports and assigning ports to VLANs, see the <i>Cisco Nexus 1000V Interface Configuration Guide</i>.</p>
Step 4	switch(config-vlan)# show vlan id <i>vlan-id</i>	(Optional) Displays the VLAN configuration.
Step 5	switch(config-vlan)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

In this example, VLAN 5 is created and you are automatically placed into the VLAN configuration mode for VLAN 5:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)#
```

This example shows the range, VLAN 15 to 20, being created. The VLANs in the range are activated, and you are automatically placed into VLAN configuration mode for VLANs 15 to 20.



Note

If you create a range of VLANs that includes an unusable VLAN, all VLANs in the range are created except those that are unusable; and Cisco Nexus 1000V returns a message listing the failed VLANs.

```
switch# configure terminal
switch(config)# vlan 15-20
switch(config-vlan)#
```

This example shows how to delete VLAN 3967:

```
switch# configure terminal
switch(config)# no vlan 3967
switch(config)#
```

This example shows how to display the VLAN 5 configuration:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# show vlan id 5
```

```
VLAN Name                Status    Ports
-----                -
5      VLAN0005                active
```

```
VLAN Type
----
5      enet
```

Remote SPAN VLAN

```

-----
Disabled
-----
Primary  Secondary  Type           Ports
-----  -
n1000v(config-vlan)# copy run start
[#####] 100%
n1000v(config)#

```

Configuring VLAN Characteristics

You can do the following for a VLAN that has already been created:



Note

Commands entered in the VLAN configuration mode are immediately saved to the running configuration.

- Name the VLAN.
- Configure the operational state (active or suspend) of the VLAN.
- Configure the VLAN media type (Ethernet).
- Shut down switching on the VLAN.

Before You Begin

Log in to the CLI in EXEC mode.



Note

Some characteristics cannot be modified on some VLANs. For more information, see the VLAN numbering described in the [Guidelines and Limitations, on page 2](#).

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# vlan {vlan-id vlan-range}	Enters VLAN configuration mode for the specified VLAN. Note If the VLAN does not already exist, the system creates it and then enters the VLAN configuration mode for that VLAN.
Step 3	switch(config-vlan)# name vlan-name	Adds a name to the VLAN of up to 32 alphanumeric characters. <ul style="list-style-type: none"> • You cannot change the name of VLAN1 or the VLANs that are reserved for internal use. • The default name is VLANxxxx where xxxx represent four numeric digits (including leading zeroes) equal to the VLAN ID number.

	Command or Action	Purpose
Step 4	switch(config-vlan)# state { active suspend }	<p>Changes the operational state of the VLAN and saves it in the running configuration.</p> <p>Allowable entries are as follows:</p> <ul style="list-style-type: none"> • active (default) • suspend <p>While the VLAN state is suspended, the ports associated with this VLAN are shut down, and that VLAN does not pass any traffic.</p> <p>Note You cannot suspend the state for the default VLAN or VLANs 1006 to 4094.</p>
Step 5	switch(config-vlan)# no shutdown	<p>Enables VLAN switching in the running configuration.</p> <p>Allowable entries are as follows:</p> <ul style="list-style-type: none"> • no shutdown (default) • shutdown <p>Note You cannot shut down the default VLAN, VLAN1, or VLANs 1006 to 4094.</p>
Step 6	switch(config-vlan)# show vlan [<i>id vlan-id</i>]	(Optional) Displays the VLAN configuration.
Step 7	switch(config-vlan)# copy running-config startup-config	(Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

This example shows how to configure VLAN characteristics:

```
n1000v# configure terminal
n1000v(config)# vlan 5
n1000v(config-vlan)# name accounting
n1000v(config-vlan)# state active
n1000v(config-vlan)# no shutdown
n1000v(config-vlan)# show vlan brief
```

VLAN	Name	Status	Ports
1	default	active	Eth2/1, Eth2/2, Eth2/3, Eth2/5 Eth2/7, Eth2/8, Eth2/9, Eth2/10 Eth2/15, Eth2/21, Eth2/22 Eth2/23, Eth2/24, Eth2/25 Eth2/46, Eth2/47, Eth2/48
5	accounting	active	
6	VLAN0006	active	
7	VLAN0007	active	
8	test	active	
9	VLAN0009	active	
10	VLAN0010	active	
50	VLAN0050	active	Eth2/6
100	trunked	active	
200	VLAN0200	active	

```

201 VLAN0201          active
202 VLAN0202          active
3966 VLAN3966        active
n1000v(config)#

```

Verifying the Configuration

Use one of the following commands to verify the configuration:

Command	Purpose
<code>show running-config vlan <i>vlan-id</i></code>	Displays VLAN information in the running configuration.
<code>show vlan [all-ports brief id <i>vlan-id</i> name <i>name</i> dot1q tag native]</code>	Displays the specified VLAN information.
<code>show vlan summary</code>	Displays a summary of VLAN information.

Feature History for VLANs

Feature Name	Feature Name	Releases
VLANs	4.0(4)SV1(1)	This feature was introduced.