



Port Profiles

This chapter describes how to identify and resolve problems with port profiles and includes the following topics:

- [Information About Port Profiles, page 9-1](#)
- [Problems with Port Profiles, page 9-2](#)
- [Port Profile Logs, page 9-5](#)
- [Port Profile Troubleshooting Commands, page 9-5](#)

Information About Port Profiles

Port profiles are used to configure interfaces. A port profile can be assigned to multiple interfaces giving them all the same configuration. Changes to the port profile are propagated automatically to the configuration of any interface assigned to it.

In the VMware vCenter Server, a port profile is represented as a port group. The vEthernet or Ethernet interfaces are assigned in vCenter Server to a port profile for:

- Defining port configuration by policy.
- Applying a single policy across a large number of ports.
- Supporting both vEthernet and Ethernet ports.

vEthernet port profiles can be assigned by the server administrator to physical ports (a VMNIC or a PNIC). Port profiles not configured as vEthernet can be assigned to a VM virtual port.



Note

While manual interface configuration overrides that of the port profile, it is not recommended. Manual interface configuration is only used, for example, to quickly test a change or allow a port to be disabled without having to change the inherited port profile.

For more information about assigning port profiles to physical or virtual ports, see your VMware documentation.

To verify that the profiles are assigned as expected to physical or virtual ports, use the following show commands:

- **show port-profile virtual usage**
- **show running-config interface *interface-id***

■ Problems with Port Profiles

To verify port profile inheritance, use the following command:

- **show running-config interface *interface-id***



Note Inherited port profiles cannot be changed or removed from an interface from the Cisco Nexus 1000V CLI. This can only be done from vCenter Server.



Note Inherited port profiles are automatically configured by the Cisco Nexus 1000V when the ports are attached on the hosts. This is done by matching up the VMware port group assigned by the system administrator with the port profile that created it.

For detailed information about port profiles, see the *Cisco Nexus 1000V Port Profile Configuration Guide*.

Problems with Port Profiles

The following are symptoms, possible causes, and solutions for problems with port profiles.

Table 9-1 Problems with Port Profiles

Symptom	Possible Causes	Solution
You do not see the port group on vCenter Server or the following message is displayed: Warning: Operation succeeded locally but update failed on vCenter server. Please check if you are connected to vCenter Server.	The connection to vCenter server is down.	<ol style="list-style-type: none"> 1. Verify that the connection to the vCenter Server is Enabled and Connected. show svs connections 2. Reconnect to vCenter server. For detailed instructions, see the <i>Connecting to vCenter Server</i> procedure in the <i>Cisco Nexus 1000V System Management Configuration Guide</i>.
	The domain configuration was not successfully pushed to vCenter server.	<ol style="list-style-type: none"> 1. Verify that the domain configuration was successfully pushed to vCenter Server. show svs domain 2. Fix any problems with the domain configuration. For information about configuring the domain, see the <i>Cisco Nexus 1000V System Management Configuration Guide</i>.
	The port profile is configured incorrectly.	<ol style="list-style-type: none"> 1. Verify that the vmware port-group is configured for the port profile and that the port profile is enabled. show port profile name <i>name</i> 2. Fix the port profile using the procedures in the <i>Cisco Nexus 1000V Port Profile Configuration Guide</i>.

Table 9-1 Problems with Port Profiles (continued)

Symptom	Possible Causes	Solution
A port configuration is not applied to an interface.	Management connectivity between the vCenter server and the VSM has prevented the port profile assignment from being sent or received.	<ol style="list-style-type: none"> Display the port profile usage by interface. show port-profile virtual usage Verify that the interface level configuration did not overwrite the port profile configuration. show run show port-profile expand-interface If the show command output is incorrect, then on vCenter server, reassign the port group to the interface.
An Ethernet interface or vEthernet interface is administratively down. A system message similar to the following is logged: %VMS-3-DVPG_NICS_MOVED: '1' nics have been moved from port-group 'Access483' to 'Unused_Or_Quarantine_Veth'.	The interface is inheriting a quarantined port profile. A configuration was not saved prior to rebooting the VSM, the configuration was lost, and the interfaces were moved to one of the following port profiles: <ul style="list-style-type: none"> Unused_Or_Quarantine_Uplink for ethernet types Unused_Or_Quarantine_Veth for Vethernet types 	<ol style="list-style-type: none"> Verify the port profile-to-interface mapping. show port-profile virtual usage Reassign the VMNIC or PNIC to a non-quarantined port group to enable the interface to be up and forwarding traffic. This requires changing the port group on vCenter Server.
After applying a port profile, an online interface is quarantined. A system message similar to the following is logged: %PORT-PROFILE-2-INTERFACE_QUARANTINED: Interface Ethernet3/3 has been quarantined due to Cache Overrun	The assigned port profile is incorrectly configured. The incorrect command fails when the port profile is applied to an interface. Although a specific command fails, the port profile-to-interface mapping is created.	<ol style="list-style-type: none"> Identify the command that failed. show accounting log grep FAILURE Verify the interface is quarantined. show port-profile sync-status Verify the port profile-to-interface mapping. show port-profile virtual usage Fix the error in the port profile using the procedures in the <i>Cisco Nexus 1000V Port Profile Configuration Guide</i>. Bring the interface out of quarantine. no shutdown The interface comes back online. Return shutdown control to the port-profile. default shutdown

■ Problems with Port Profiles

Table 9-1 Problems with Port Profiles (continued)

Symptom	Possible Causes	Solution
After modifying a port profile, an assigned offline interface is quarantined. A system message similar to the following is logged: %PORT-PROFILE-2-INTERFACE_QUARANTINED: Interface Ethernet4/3 has been quarantined due to Cache Overrun	The interface has been removed from the DVS.	To bring the interface back online:, use the “Recovering a Quarantined Offline Interface” procedure on page 9-4.
A module and all associated interfaces are offline. A system message similar to the following is logged: 2011 Mar 2 22:28:50 n1000v %VEM_MGR-2-VEM_REMOVE_NO_HB: Removing VEM 3 (heartbeats lost) 2011 Mar 2 22:29:00 n1000v %VEM_MGR-2-MOD_OFFLINE: Module 3 is offline	The interface carrying system VLANs for the module has gone down for one of the following reasons: <ul style="list-style-type: none"> • System interfaces were removed from the DVS on the vCenter Server. • The module was powered down. • There is general loss of connectivity to the module. 	Follow VEM troubleshooting guide to bring module back online To bring the interface back online, use the “Recovering a Quarantined Offline Interface” procedure on page 9-4.

Recovering a Quarantined Offline Interface

You can use this procedure to recover and bring online an interface that is offline and has been quarantined.

BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.

DETAILED STEPS

-
- Step 1** Verify the interface has is quarantined. The interface appears in the show command output.
show port-profile sync-status
- Step 2** On the vCenter server, add or associate the PNIC to a port profile (either the original port profile or a different port profile).
The interface comes back online.
- Step 3** Verify that the interface has come back online.
show interface brief
- Step 4** Verify the port profile-to-interface mapping.
show port-profile virtual usage

Step 5 Verify the interface has come out of quarantine automatically. The interface should no longer appear in the show command output.

```
show port-profile sync-status
```

Step 6 Return shutdown control to the port-profile.

```
default shutdown
```

Port Profile Logs

To enable and collect detailed logs for port profiles, use the following commands:

- **debug port-profile trace**
- **debug port-profile error**
- **debug port-profile all**
- **debug msp all**

After enabling the debug log, the results of any subsequent port profile configuration are captured in the log file.

Port Profile Troubleshooting Commands

You can use the commands in this section to troubleshoot problems related to port profiles.

Command	Purpose
show port-profile	Displays the port profile configuration. See Example 9-1 on page 9-6 .
show port-profile name name	Displays the configuration for a named port profile. See Example 9-2 on page 9-7 .
show port-profile brief	Displays tabular view of all configured port profiles. See Example 9-3 on page 9-8 .
show port-profile expand-interface	Displays all configured port profiles expanded to include the interfaces assigned to them. See Example 9-4 on page 9-8 .
show port-profile expand-interface name name	Displays a named port profile expanded to include the interfaces assigned to it. See Example 9-5 on page 9-10 .

■ Port Profile Troubleshooting Commands

Command	Purpose
show port-profile-role [name <i>port-profile-role-name</i>]	Displays the port profile role configuration, including role names, descriptions, assigned users, and assigned groups. See Example 9-7 on page 9-11 .
show running-config port-profile [profile-name]	Displays the port profile configuration. See Example 9-6 on page 9-11 .
show port-profile-role	Displays the port profile role configuration. See Example 9-7 on page 9-11 .
show port-profile-role users	Displays available users and groups. See Example 9-8 on page 9-11 .
show port-profile sync-status [interface <i>if-name</i>]	Displays interfaces that are out of sync with the port profile. See Example 9-9 on page 9-11 .
show port-profile virtual usage [name <i>profile-name</i>]	Displays the port profile usage by interface. See Example 9-10 on page 9-12 .
show msp internal info	Displays port profile mappings on vCenter server and configured roles. See Example 9-11 on page 9-12
show system internal port-profile profile-fsm	Displays port profile activity on the Cisco Nexus 1000V, including transitions such as inherits and configurations. If the following displays, then all inherits are processed: Curr state: [PPM_PROFILE_ST_SIDLE] See Example 9-12 on page 9-16
show system internal port-profile event-history msgs	Displays the messages logged about port profile events within the Cisco Nexus 1000V. See Example 9-13 on page 9-16

For detailed information about show command output, see the *Cisco Nexus 1000V Command Reference*.

EXAMPLES

Example 9-1 show port-profile

```
n1000v# show port-profile
port-profile vEthProfile1
  description:
  type: vethernet
  status: disabled
  capability l3control: no
  pinning control-vlan: -
  pinning packet-vlan: -
  system vlans: none
  port-group:
```

```
max ports: 32
inherit:
config attributes:
    channel-group auto mode on mac-pinning
evaluated config attributes:
    channel-group auto mode on mac-pinning
assigned interfaces:
port-profile vEthProfile2
description:
type: vethernet
status: disabled
capability l3control: no
pinning control-vlan: -
pinning packet-vlan: -
system vlans: none
port-group:
max ports: 32
inherit:
config attributes:
    channel-group auto mode on sub-group cdp
evaluated config attributes:
    channel-group auto mode on sub-group cdp
assigned interfaces:
port-profile vEthProfile3
description:
type: vethernet
status: disabled
capability l3control: no
pinning control-vlan: -
pinning packet-vlan: -
system vlans: none
port-group:
max ports: 32
inherit:
config attributes:
    channel-group auto mode on sub-group manual
evaluated config attributes:
    channel-group auto mode on sub-group manual
assigned interfaces:n1000v#
```

Example 9-2 show port-profile name

```
n1000v# show port-profile name vEthProfile3
port-profile vEthProfile3
description:
type: vethernet
status: disabled
capability l3control: no
pinning control-vlan: -
pinning packet-vlan: -
system vlans: none
port-group:
max ports: 32
inherit:
config attributes:
    channel-group auto mode on sub-group manual
evaluated config attributes:
    channel-group auto mode on sub-group manual
assigned interfaces:
n1000v#
```

■ Port Profile Troubleshooting Commands

Example 9-3 show port-profile brief

```
n1000v# show port-profile brief
-----
Port Profile Profile Type Conf Eval Assigned Child
Profile State Items Items Intfs Profs
-----
AccessProf Vethernet 0 0 0 0 0
PP1027 Vethernet 1 0 0 0 0
PP1028 Vethernet 1 0 0 0 0
Unused_Or_Quarantine_Uplink Ethernet 1 1 0 0 0
Unused_Or_Quarantine_Veth Vethernet 1 1 0 0 0
accessprof Vethernet 0 3 3 0 0
portp1 Vethernet 0 0 0 0 0
-----
Profile Total
Type Intfs
-----
Vethernet 8
Ethernet 10
n1000v#
```

Example 9-4 show port-profile expand-interface

```
n1000v# show port-profile expand-interface
port-profile AccessProf
  id: 1
  capability: 0x0
  state: 0x0
  type: 0x0
  system vlan mode: -
  system vlans:
  port-binding: static
  bind_opts: 0
  max ports: 32
  min ports: 32
  used ports: 0
  vmware config information
    pg name: AccessProf
    dvs: (ignore)
    reserved ports: 32
  port-profile role:
  alias information:
port-profile PP1027
  id: 4
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  bind_opts: 1
  max ports: 64
  min ports: 32
  used ports: 0
  vmware config information
    pg name: PP1027
    dvs: (ignore)
    reserved ports: 16
  port-profile role:
  alias information:
    pg id: PP1027
    dvs uuid:
```

```
type: 1
pg id: dvportgroup-3180
dvs uuid: 12 98 0e 50 6b 78 6f c5-74 af b2 3a 16 6e 45 10
type: 2
port-profile PP1028
  id: 3
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: dynamic
  bind_opts: 1
  max ports: 64
  min ports: 32
  used ports: 0
  vmware config information
    pg name: PP1028
    dvs: (ignore)
    reserved ports: 16
  port-profile role:
  alias information:
    pg id: PP1028
    dvs uuid:
    type: 1
    pg id: dvportgroup-3181
    dvs uuid: 12 98 0e 50 6b 78 6f c5-74 af b2 3a 16 6e 45 10
    type: 2
port-profile Unused_Or_Quarantine_Uplink
  id: 6
  capability: 0x1
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: dynamic
  bind_opts: 1
  max ports: 32
  min ports: 32
  used ports: 0
  vmware config information
    pg name: Unused_Or_Quarantine_Uplink
    dvs: (ignore)
    reserved ports: 0
  port-profile role:
  alias information:
    pg id: Unused_Or_Quarantine_Uplink
    dvs uuid:
    type: 1
    pg id: dvportgroup-3182
    dvs uuid: 12 98 0e 50 6b 78 6f c5-74 af b2 3a 16 6e 45 10
    type: 2
port-profile Unused_Or_Quarantine_Veth
  id: 7
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: dynamic
  bind_opts: 1
  max ports: 32
  min ports: 32
  used ports: 0
```

■ Port Profile Troubleshooting Commands

```

vmware config information
  pg name: Unused_Or_Quarantine_Veth
  dvs: (ignore)
  reserved ports: 32
port-profile role:
alias information:
  pg id: Unused_Or_Quarantine_Veth
  dvs uuid:
  type: 1
  pg id: dvportgroup-3183
  dvs uuid: 12 98 0e 50 6b 78 6f c5-74 af b2 3a 16 6e 45 10
  type: 2
port-profile accessprof
  id: 5
  capability: 0x0
  state: 0x0
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: dynamic
  bind_opts: 1
  max ports: 32
  min ports: 32
  used ports: 0
  vmware config information
    pg name: accessprof
    dvs: (ignore)
    reserved ports: 32
port-profile role:
alias information:
  pg id: accessprof
  dvs uuid:
  type: 1
port-profile portp1
  id: 2
  capability: 0x0
  state: 0x0
  type: 0x0
  system vlan mode: -
  system vlans:
  port-binding: static
  bind_opts: 0
  max ports: 32
  min ports: 32
  used ports: 0
  vmware config information
    pg name: portp1
    dvs: (ignore)
    reserved ports: 32
port-profile role:
alias information:
pending binds:
n1000v#

```

Example 9-5 show port-profile expand-interface name UplinkProfile1

```

n1000v# show port-profile expand-interface name UplinkProfile1
port-profile EthProfile1
Ethernet2/2
  switchport mode trunk
  switchport trunk allowed vlan 110-119
  no shutdown
n1000v#

```

Example 9-6 show running-config port-profile

```
n1000v# show running-config port-profile
port-profile type ethernet UplinkProfile1
  description "Profile for critical system ports"
  vmware port-group
  switchport mode access
  switchport access vlan 113
  switchport trunk native vlan 113
  channel-group auto mode on
  no shutdown
port-profile type vethernet vEthProfile2
  vmware port-group
  vmware max-ports 5
  switchport mode trunk
  switchport trunk native vlan 112
  channel-group auto mode on sub-group cdp
  no shutdown
n1000v#
```

Example 9-7 show port-profile-role

```
n1000v# show port-profile-role name adminUser

Name: adminUser
Description: adminOnly
Users:
  hdbaar (user)
Assigned port-profiles:
  allaccess2
n1000v#
```

Example 9-8 show port-profile-role users

```
switch# show port-profile-role users
Groups:
  Administrators
  TestGroupB
Users:
  hdbaar
  fgreen
  suchen
  mariofr
switch#
```

Example 9-9 show port-profile sync-status

```
n1000v# show port-profile sync-status interface ethernet 3/2
Ethernet3/2
  port-profile: uplink
  interface status: quarantine
  sync status: out of sync
  cached commands:
  errors:
    command cache overrun
  recovery steps:
    bring interface online
n1000v#
```

■ Port Profile Troubleshooting Commands

Example 9-10 show port-profile virtual usage

```
n1000v# show port-profile virtual usage
-----
Port Profile          Port      Adapter        Owner
-----
n1kv-uplink0          Po1
                      Eth3/2    vmnic1        localhost.
                      Eth3/3    vmnic2        localhost.
vlan1767              Veth7     Net Adapter 1 all-tool-7
                      Veth8     Net Adapter 1 all-tool-8
aipc1765              Veth4     Net Adapter 1 bl-h-s
inband1766             Veth6     Net Adapter 3 bl-h-s
mgmt1764              Veth5     Net Adapter 2 bl-h-s
vpc-mac-uplink         Po7
                      Eth5/2    vmnic1        localhost.
                      Eth5/3    vmnic2        localhost.
ch-vpc-mac-uplink     Po2
                      Po3
                      Eth4/2    vmnic1        VDANIKLNCOS
                      Eth4/3    vmnic2        VDANIKLNCOS
ch-aipc1765            Veth1     Net Adapter 1 bl-h-p
ch-mgmt1764            Veth2     Net Adapter 2 bl-h-p
ch-inband1766           Veth3     Net Adapter 3 bl-h-p
n1000v#
```

Example 9-11 show msp internal info

```
n1000v# show msp internal info
port-profile Access484
  id: 5
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 256
  vmware config information
    pg name: Access484
    dvs: (ignore)
  port-profile role:
  alias information:
    pg id: Access484
    dvs uuid:
    type: 1
    pg id: dvportgroup-3285
    dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
    type: 2
    pg id: dvportgroup-3292
    dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
    type: 2
  port-profile Unused_Or_Quarantine_Uplink
    id: 1
    capability: 0x1
    state: 0x1
    type: 0x1
    system vlan mode: -
    system vlans:
    port-binding: static
    max ports: 32
    vmware config information
      pg name: Unused_Or_Quarantine_Uplink
```

```
dvs: (ignore)
port-profile role:
alias information:
  pg id: Unused_Or_Quarantine_Uplink
  dvs uuid:
  type: 1
  pg id: dvportgroup-2444
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile Unused_Or_Quarantine_Veth
  id: 2
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 32
  vmware config information
    pg name: Unused_Or_Quarantine_Veth
    dvs: (ignore)
port-profile role:
alias information:
  pg id: Unused_Or_Quarantine_Veth
  dvs uuid:
  type: 1
  pg id: dvportgroup-2445
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile eth-break-deinherit
  id: 10
  capability: 0x1
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 32
  vmware config information
    pg name: eth-break-deinherit
    dvs: (ignore)
port-profile role:
alias information:
  pg id: eth-break-deinherit
  dvs uuid:
  type: 1
  pg id: dvportgroup-3286
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
  pg id: dvportgroup-3293
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile eth-break-inherit
  id: 9
  capability: 0x1
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 32
  vmware config information
    pg name: eth-break-inherit
    dvs: (ignore)
```

■ Port Profile Troubleshooting Commands

```

port-profile role:
alias information:
  pg id: eth-break-inherit
  dvs uuid:
  type: 1
  pg id: dvportgroup-3287
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
  pg id: dvportgroup-3294
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile uplink
  id: 3
  capability: 0x3
  state: 0x1
  type: 0x1
  system vlan mode: trunk
  system vlans: 480-481
  port-binding: static
  max ports: 32
  vmware config information
    pg name: uplink
    dvs: (ignore)
port-profile role:
alias information:
  pg id: uplink
  dvs uuid:
  type: 1
  pg id: dvportgroup-3283
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile uplink-quar
  id: 12
  capability: 0x1
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 32
  vmware config information
    pg name: uplink-quar
    dvs: (ignore)
port-profile role:
alias information:
  pg id: uplink-quar
  dvs uuid:
  type: 1
  pg id: dvportgroup-3288
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
  pg id: dvportgroup-3295
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile veth-break-deinherit
  id: 8
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 256
  vmware config information

```

```
pg name: veth-break-deinherit
dvs: (ignore)
port-profile role:
alias information:
  pg id: veth-break-deinherit
  dvs uuid:
  type: 1
  pg id: dvportgroup-3289
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
  pg id: dvportgroup-3296
  dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
  type: 2
port-profile veth-break-inherit
  id: 7
  capability: 0x0
  state: 0x1
  type: 0x1
  system vlan mode: -
  system vlans:
  port-binding: static
  max ports: 256
  vmware config information
    pg name: veth-break-inherit
    dvs: (ignore)
  port-profile role:
  alias information:
    pg id: veth-break-inherit
    dvs uuid:
    type: 1
    pg id: dvportgroup-3290
    dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
    type: 2
    pg id: dvportgroup-3297
    dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
    type: 2
  port-profile vpc-uplink
    id: 6
    capability: 0x3
    state: 0x1
    type: 0x1
    system vlan mode: trunk
    system vlans: 480-481
    port-binding: static
    max ports: 32
    vmware config information
      pg name: vpc-uplink
      dvs: (ignore)
    port-profile role:
    alias information:
      pg id: vpc-uplink
      dvs uuid:
      type: 1
      pg id: dvportgroup-3291
      dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
      type: 2
      pg id: dvportgroup-3298
      dvs uuid: 44 dc 3b 50 53 11 b7 ac-ef ed ef 46 ee df c2 d5
      type: 2
  pending binds:
  port-profile-role adfd
    id: 0
    desc:
    num users: 1
```

■ Port Profile Troubleshooting Commands

```
group GROUP
n1000v#
```

Example 9-12 show system internal port-profile profile-fsm

```
n1000v# show system internal port-profile profile-fsm
>>>FSM: <PROFILE_FSM:1> has 4 logged transitions<<<
1) FSM:<PROFILE_FSM:1> Transition at 856903 usecs after Tue Mar  8 19:11:47 2011
   Previous state: [PPM_PROFILE_ST_SIDLE]
   Triggered event: [PPM_PROFILE_EV{EIF_STATUS_CHANGE}]
   Next state: [PPM_PROFILE_ST_SIDLE]

2) FSM:<PROFILE_FSM:1> Transition at 858442 usecs after Tue Mar  8 19:11:47 2011
   Previous state: [PPM_PROFILE_ST_SIDLE]
   Triggered event: [PPM_PROFILE_EV_ELEARN]
   Next state: [PPM_PROFILE_ST_SIF_CREATE]

3) FSM:<PROFILE_FSM:1> Transition at 842710 usecs after Tue Mar  8 19:12:04 2011
   Previous state: [PPM_PROFILE_ST_SIF_CREATE]
   Triggered event: [PPM_PROFILE_EV_EACKNOWLEDGE]
   Next state: [FSM_ST_NO_CHANGE]

4) FSM:<PROFILE_FSM:1> Transition at 873872 usecs after Tue Mar  8 19:12:04 2011
   Previous state: [PPM_PROFILE_ST_SIF_CREATE]
   Triggered event: [PPM_PROFILE_EV_ESUCCESS]
   Next state: [PPM_PROFILE_ST_SIDLE]

   Curr state: [PPM_PROFILE_ST_SIDLE]
n1000v#
```

Example 9-13 show system internal port-profile event-history msgs

```
n1000v# show system internal port-profile event-history msgs
1) Event:E_MTS_RX, length:60, at 538337 usecs after Tue Mar  8 19:13:02 2011
   [NOT] Opc:MTS_OPC_IM_IF_CREATED(62467), Id:0X0000B814, Ret:SUCCESS
   Src:0x00000101/175, Dst:0x00000101/0, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00000000, Sync:UNKNOWN, Payloadsize:120
   Payload:
   0x0000: 00 00 00 02 00 00 00 02 00 00 00 00 0c 00 00 00 29

2) Event:E_MTS_RX, length:60, at 515030 usecs after Tue Mar  8 19:13:02 2011
   [NOT] Opc:MTS_OPC_LC_ONLINE(1084), Id:0X0000B7E8, Ret:SUCCESS
   Src:0x00000101/744, Dst:0x00000101/0, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00000000, Sync:UNKNOWN, Payloadsize:234
   Payload:
   0x0000: 02 00 00 03 00 00 00 00 00 00 03 02 03 02 00 00

3) Event:E_MTS_RX, length:60, at 624319 usecs after Tue Mar  8 19:12:05 2011
   [NOT] Opc:MTS_OPC_PPM_INTERFACE_UPDATE(152601), Id:0X00003908, Ret:SUCCESS
   Src:0x00000101/489, Dst:0x00000101/0, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00000000, Sync:UNKNOWN, Payloadsize:107
   Payload:
   0x0000: 00 00 00 02 00 00 00 02 00 00 00 00 0c 00 00 00 26

4) Event:E_MTS_RX, length:60, at 624180 usecs after Tue Mar  8 19:12:05 2011
   [NOT] Opc:MTS_OPC_PPM_INTERFACE_UPDATE(152601), Id:0X00003905, Ret:SUCCESS
   Src:0x00000101/489, Dst:0x00000101/0, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00000000, Sync:UNKNOWN, Payloadsize:107
   Payload:
   0x0000: 00 00 00 02 00 00 00 02 00 00 00 00 0c 00 00 00 26
```

```
5) Event:E_MTS_RX, length:60, at 624041 usecs after Tue Mar  8 19:12:05 2011
   [NOT] Opc:MTS_OPC_PPM_INTERFACE_UPDATE(152601), Id:0x00003903, Ret:SUCCESS
   Src:0x00000101/489, Dst:0x00000101/0, Flags:None
   HA_SEQNO:0x00000000, RRtoken:0x00000000, Sync:UNKNOWN, Payloadsize:107
   Payload:
0x0000:  00 00 00 02 00 00 00 02 00 00 00 00 0c 00 00 00 26
...
...
```

■ Port Profile Troubleshooting Commands