



Show Commands

This chapter describes the Cisco NX-OS multicast routing **show** commands.

■ **show forwarding distribution ip igmp snooping**

show forwarding distribution ip igmp snooping

To display information about Layer 2 IGMP snooping multicast FIB distribution, use the **show forwarding distribution ip igmp snooping** command.

show forwarding distribution ip igmp snooping [vlan *vlan-id* [group *group-addr* [source *source-addr*]]]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093. group <i>group-addr</i> (Optional) Specifies a group address. source <i>source-addr</i> (Optional) Specifies a source address.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about Layer 2 IGMP snooping multicast FIB distribution:
-----------------	---

```
switch(config)# show forwarding distribution ip igmp snooping
Vlan: 1, Group: 0.0.0.0, Source: 0.0.0.0
  Outgoing Interface List Index: 65535
  Reference Count: 5
  Platform Index: 0x0
  Number of Outgoing Interfaces: 0

Vlan: 3, Group: 0.0.0.0, Source: 0.0.0.0
  Outgoing Interface List Index: 65535
  Reference Count: 5
  Platform Index: 0x0
  Number of Outgoing Interfaces: 0
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
Vlan: 13, Group: 0.0.0.0, Source: 0.0.0.0
  Outgoing Interface List Index: 65535
  Reference Count: 5
  Platform Index: 0x0
  Number of Outgoing Interfaces: 0

Vlan: 200, Group: 0.0.0.0, Source: 0.0.0.0
  Outgoing Interface List Index: 65535
  Reference Count: 5
  Platform Index: 0x0
  Number of Outgoing Interfaces: 0

Vlan: 1001, Group: 0.0.0.0, Source: 0.0.0.0
  Outgoing Interface List Index: 65535
  Reference Count: 5
  Platform Index: 0x0
  Number of Outgoing Interfaces: 0
```

■ show forwarding distribution ipv6 multicast route

show forwarding distribution ipv6 multicast route

To display information about the multicast IPv6 FIB routes, use the **show forwarding distribution ipv6 multicast route** command.

show forwarding distribution ipv6 multicast route [table *table_id* | vrf *vrf-name*] [group [*source*] | summary]

Syntax	Description
	table <i>table_id</i> (Optional) Specifies a table ID. The range is from 0x0 to 0xffffffff.
	vrf <i>vrf-name</i> (Optional) Specifies a virtual routing and forwarding (VRF) name.
	group (Optional) IPv6 group address.
	source (Optional) IPv6 source address.
	summary (Optional) Specifies route counts.

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about the multicast IPv6 FIB routes:
	<pre>switch(config)# show forwarding distribution ipv6 multicast route IPv6 Multicast Routing table table-id:0x80000001 Total number of groups: 5 Legend: C = Control Route D = Drop Route G = Local Group (directly connected receivers) O = Drop on RPF Fail P = Punt to supervisor (*, ff00::/8), RPF Interface: NULL, flags: D</pre>

Send document comments to nexus7k-docfeedback@cisco.com.

```
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, ff01::/16), RPF Interface: NULL, flags: D
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, ff02::/16), RPF Interface: NULL, flags: CP
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, ff11::/16), RPF Interface: NULL, flags: D
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, ff12::/16), RPF Interface: NULL, flags: CP
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List
switch#
```

 show forwarding distribution l2 multicast vlan

show forwarding distribution l2 multicast vlan

To display platform independent database in Layer 2 multicast, use the **show forwarding distribution l2 multicast vlan** command.

```
show forwarding distribution l2 multicast [vlan vlan-id [{group grpaddr [source srcaddr] } | destination-mac dmac]]
```

Syntax Description	
<i>vlan-id</i>	(Optional) VLAN ID. The range is from 1 to 3967 and from 4048 to 4093.
group	(Optional) Displays the group specific information.
<i>grpaddr</i>	(Optional) Group address.
source	(Optional) Displays the (G,S) specific information.
<i>srcaddr</i>	(Optional) Source address.
destination-mac	(Optional) Displays the destination MAC specific information
<i>dmac</i>	(Optional) Destination MAC address.

Defaults	None				
Command Modes	Global configuration mode				
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>5.2(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	5.2(1)	This command was introduced.
Release	Modification				
5.2(1)	This command was introduced.				

Usage Guidelines	If the VLAN is configured for MAC based lookup, then the display will show MAC entries, else it will show IP entries. User can explicitly display an IP (BD,S,G) entry or MAC entry by specifying Group address or MAC address. If the lookup mode is IP and the user specifies MAC, show will return null and prints a message “Snooping lookups in group IP mode”. Similarly If the user specifies MAC and the lookup is IP, show command will return null and prints “Snooping lookups in group MAC mode” This command does not require a license.
-------------------------	---

Examples	This example shows how to display platform independent database information for a specific VLAN: switch# show forwarding distribution l2 multicast vlan 1 Vlan: 1, Group: 0.0.0.0, Source: 0.0.0.0
-----------------	--

Send document comments to nexus7k-docfeedback@cisco.com.

Outgoing Interface List Index: 65535
Reference Count: 1
Platform Index: 0x0
Number of Outgoing Interfaces: 0

Related Commands

Command	Description
show forwarding distribution multicast	Displays the information about multicast distribution messages.

■ **show forwarding distribution multicast**

show forwarding distribution multicast

To display information about multicast distribution messages, use the **show forwarding distribution multicast** command.

show forwarding distribution multicast [messages]

Syntax	Description				
	messages (Optional) Displays message information.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command does not require a license.				
Examples	<p>This example shows how to display information about multicast distribution messages:</p> <pre>switch(config)# show forwarding distribution multicast Number of Multicast FIB Processes Active: 2 Slot FIB State 2 ACTIVE 7 ACTIVE switch#</pre>				

Send document comments to nexus7k-docfeedback@cisco.com.

show forwarding distribution multicast client

To display information about the multicast FIB distribution client, use the **show forwarding distribution multicast client** command.

show forwarding distribution multicast client

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to display information about the multicast distribution client:

```
switch(config)# show forwarding distribution multicast client

Number of Clients Registered: 3
Client-name Client-id Shared Memory Name
m6rib      1       m6rib-mfdm
mrib       2       mrib-mfdm
igmp       3       N/A
switch#
```

Related Commands	Command	Description
	show forwarding distribution multicast	Displays the information about multicast distribution messages.

■ **show forwarding distribution multicast outgoing-interface-list**

show forwarding distribution multicast outgoing-interface-list

To display information about the multicast outgoing interface (OIF) list, use the **show forwarding distribution multicast outgoing-interface-list** command.

show forwarding distribution multicast outgoing-interface-list {L2 | L3} [index]

Syntax Description	L2 Specifies the Layer 2 OIF list. L3 Specifies the Layer 3 OIF list. index (Optional) OIF list index.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about the multicast OIF list for Layer 3: <pre>switch(config)# show forwarding distribution multicast outgoing-interface-list L3 Outgoing Interface List Index: 1 Reference Count: 1 Platform Index: 0x7ffe Number of Outgoing Interfaces: 1 mgmt0 switch#</pre>
-----------------	---

Related Commands	Command	Description
	show forwarding distribution multicast	Displays the information about multicast distribution messages.

Send document comments to nexus7k-docfeedback@cisco.com.

show forwarding distribution multicast route

To display information about the multicast FIB distribution routes, use the **show forwarding distribution multicast route** command.

```
show forwarding distribution [ip | ipv4] multicast route [table id | vrf vrf_name] [[group
    {group-addr [mask] | group-prefix}]] [source {source-addr [source-mask] | source-prefix}] | 
    summary]
```

Syntax Description	ip	(Optional) Specifies IPV4 information.
	ipv4	(Optional) Specifies IPV4 information.
	table id	(Optional) Specifies the multicast routing table ID. The range is from 0 to 2147483647.
	vrf vrf_name	(Optional) Specifies a virtual routing and forwarding (VRF) name.
	group	(Optional) Specifies IPv4 multicast group.
	group-addr	IPv4 multicast group address.
	mask	(Optional) Mask for the group address.
	group-prefix	(Optional) IPv4 multicast group prefix.
	source	(Optional) Specifies IPv4 multicast source.
	source-addr	IPv4 source address.
	source-mask	(Optional) Mask for the group address.
	source-prefix	(Optional) IPv4 multicast source prefix.
	summary	(Optional) Displays the route counts.

Defaults	None	
Command Modes	Any command mode	
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator	
Command History	Release	Modification
	4.0(1)	This command was introduced.
Usage Guidelines	This command does not require a license.	

■ **show forwarding distribution multicast route**

Examples

This example shows how to display information about all the multicast FIB distribution routes:

```
switch(config)# show forwarding distribution multicast route
IPv4 Multicast Routing Table for table-id: 1
Total number of groups: 4
Legend:
  C = Control Route
  D = Drop Route
  G = Local Group (directly connected receivers)
  O = Drop on RPF Fail
  P = Punt to supervisor

(*, 224.0.0.0/4), RPF Interface: NULL, flags: D
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, 224.0.0.0/24), RPF Interface: NULL, flags: CP
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, 224.0.1.39/32), RPF Interface: NULL, flags: CP
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List

(*, 224.0.1.40/32), RPF Interface: NULL, flags: CP
Received Packets: 0 Bytes: 0
Number of Outgoing Interfaces: 0
Null Outgoing Interface List
switch#
```

Related Commands

Command	Description
show forwarding distribution multicast	Displays the information about multicast distribution messages.

Send document comments to nexus7k-docfeedback@cisco.com.

show forwarding ipv6 multicast route

To display information about the IPv6 multicast routes, use the **show forwarding ipv6 multicast route** command.

```
show forwarding [vrf {vrf-name | all}] ipv6 multicast route {[group {group | group-addr} | source {source | source-addr} | module num | vrf {vrf-name | all}] | summary [module num | vrf {vrf-name | all}]}
```

Syntax Description	vrf	(Optional) Displays routes for a specific virtual routing and forwarding (VRF) instance.
	vrf-name	VRF name.
	all	Displays information for all VRFs.
	group	(Optional) Specifies multicast IPv6 group address.
	group	Multicast IPv6 group address with prefix.
	group-addr	Multicast IPv6 group address.
	source	Specifies multicast IPv6 source address.
	source	Multicast IPv6 source address with prefix.
	source-addr	Multicast IPv6 source address.
	module num	(Optional) Specifies module number.
	summary	Displays route counts.

Defaults	None	
Command Modes	Any command mode	
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator	
Command History	Release	Modification
	4.0(1)	This command was introduced.
	4.1(3)	Added the <i>group-addr</i> and <i>source-addr</i> arguments.
Usage Guidelines	This command does not require a license.	
Examples	This example shows how to display information about the IPv6 multicast routes:	

■ **show forwarding ipv6 multicast route**

```
switch(config)# show forwarding ipv6 multicast route

IPv6 Multicast Routing table table-id:0x80000001
Total number of groups: 0
Legend:
  C = Control Route
  D = Drop Route
  G = Local Group (directly connected receivers)
  O = Drop on RPF failure
  P = Punt to Supervisor

(*, ff00::/8), RPF Interface: NULL, flags: DW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, ff01::/16), RPF Interface: NULL, flags: DW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, ff02::/16), RPF Interface: NULL, flags: CPW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, ff11::/16), RPF Interface: NULL, flags: DW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, ff12::/16), RPF Interface: NULL, flags: CPW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List
switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

show forwarding l2 multicast vlan

To display platform independent database in Layer 2 multicast with MFDM information, use the **show forwarding distribution l2 multicast vlan** command.

```
show forwarding l2 multicast [vlan vlan-id [{source source-ip group group-ip} |  
destination-mac dmac]] [module number]
```

Syntax Description	
vlan-id	(Optional) VLAN ID. The range is from 1 to 3967 and from 4048 to 4093.
group	(Optional) Displays the group specific information.
grpaddr	(Optional) Group address.
source	(Optional) Displays the (G,S) specific information.
srcaddr	(Optional) Source address.
destination-mac	(Optional) Displays the destination MAC specific information
dmac	(Optional) Destination MAC address.
module	(Optional) Module
number	(Optional) Slot number. The range is from 0 to 18.

Defaults	None
-----------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines	This command is same as show forwarding distribution l2 multicast vlan command but it displays MFDM information. If the VLAN is configured for MAC based lookup, then the display will show MAC entries, else it will show IP entries.
-------------------------	---

User can explicitly display an IP (BD,S,G) entry or MAC entry by specifying Group address or MAC address. If the lookup mode is IP and the user specifies MAC, show will return null and prints a message “Snooping lookups in group IP mode”. Similarly If the user specifies MAC and the lookup is IP, show command will return null and prints “Snooping lookups in group MAC mode”

This command does not require a license.

■ **show forwarding l2 multicast vlan**

Examples

This example shows how to display platform independent database information for a specific VLAN with MFDM information:

```
switch# show forwarding l2 multicast vlan 1
Vlan: 1, Group: 0.0.0.0, Source: 0.0.0.0
    Outgoing Interface List Index: 65535
    Reference Count: 1
    Platform Index: 0x0
    Number of Outgoing Interfaces: 0
```

Related Commands

Command	Description
show forwarding distribution multicast	Displays the information about multicast distribution messages.

Send document comments to nexus7k-docfeedback@cisco.com.

show forwarding multicast outgoing-interface-list

To display information about the multicast outgoing interface (OIF) list, use the **show forwarding multicast outgoing-interface-list** command.

show forwarding multicast outgoing-interface-list [module num] [index]

Syntax Description	module num (Optional) Specifies the module number. index (Optional) OIF list index.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command does not require a license.				
Examples	<p>This example shows how to display information about the multicast outgoing interface (OIF) list:</p> <pre>switch(config)# show forwarding multicast outgoing-interface-list Outgoing Interface List Index: 65535 Reference Count: 9 switch(config)#End</pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>show forwarding distribution multicast</td><td>Displays the information about multicast distribution messages.</td></tr> </tbody> </table>	Command	Description	show forwarding distribution multicast	Displays the information about multicast distribution messages.
Command	Description				
show forwarding distribution multicast	Displays the information about multicast distribution messages.				

 show forwarding multicast route

show forwarding multicast route

To display information about the IPv4 multicast routes, use the **show forwarding multicast route** command.

```
show forwarding [vrf {vrf-name | all}] [ip | ipv4] multicast route {[group {group-addr  
[group-mask] | group-prefix} | source {source-addr [source-mask] | source-prefix} | module  
num | vrf {vrf-name | all}}]+ | summary [module num | vrf {vrf-name | all}]}
```

Syntax Description	vrf (Optional) Displays information for a specified virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Displays information for all VRFs. ip (Optional) Specifies IPv4. ipv4 (Optional) Specifies IPv4. group (Optional) Specifies IPv4 multicast group address. group-addr IPv4 multicast group address. group-mask (Optional) IPv4 multicast group address mask. group-prefix (Optional) IPv4 multicast group prefix. source (Optional) Specifies IPv4 multicast source address. source-addr IPv4 multicast source address. source-mask (Optional) IPv4 multicast source address mask. source-prefix (Optional) IPv4 multicast source prefix. module num (Optional) Specifies the module number. summary Displays route counts.
--------------------	---

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
--------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Send document comments to nexus7k-docfeedback@cisco.com.

Examples

This example shows how to display information about the IPv4 multicast routes:

```
switch(config)# show forwarding multicast route
IPv4 Multicast Routing table table-id:1
Total number of groups: 0
Legend:
  C = Control Route
  D = Drop Route
  G = Local Group (directly connected receivers)
  O = Drop on RPF failure
  P = Punt to Supervisor
  W = Wildcard

(*, 224.0.0.0/4), RPF Interface: NULL, flags: DW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, 224.0.0.0/24), RPF Interface: NULL, flags: CPW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, 224.0.1.39/32), RPF Interface: NULL, flags: CPW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List

(*, 224.0.1.40/32), RPF Interface: NULL, flags: CPW
  Received Packets: 0 Bytes: 0
  Number of Outgoing Interfaces: 0
  Null Outgoing Interface List
```

Related Commands

Command	Description
show forwarding distribution multicast	Displays the information about multicast distribution messages.

 show ip igmp event-history

show ip igmp event-history

To display information in the IGMP event history buffers, use the **show ip igmp event-history** command.

```
show ip igmp event-history {clis | debugs | errors | events | ha | igmp-internal | msgs | mtrace | policy | statistics | vrf}
```

Syntax Description	clis	Displays events of type CLI.
	debugs	Displays events of type debug.
	errors	Displays events of type error.
	events	Displays events of type event.
	ha	Displays events of type HA.
	igmp-internal	Displays events of type IGMP internal.
	msgs	Displays events of type msg.
	mtrace	Displays events of type mtrace.
	policy	Displays events of type policy.
	statistics	Displays events of type statistics.
	vrf	Displays events of type VRF.

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
--------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to display information in the IGMP HA event history buffer: switch(config)# show ip igmp event-history ha ha events for IGMP process 1) Event:E_DEBUG, length:44, at 423337 usecs after Mon Dec 22 12:24:49 2008
----------	---

Send document comments to nexus7k-docfeedback@cisco.com.

```
[121] : Updated entry in Route count database
2) Event:E_DEBUG, length:45, at 423072 usecs after Mon Dec 22 12:24:49 2008
   [121] : Updating entry in Route count database
3) Event:E_DEBUG, length:49, at 943183 usecs after Mon Dec 22 12:24:41 2008
   [121] : Recovered all route count entries from PSS
4) Event:E_DEBUG, length:38, at 943133 usecs after Mon Dec 22 12:24:41 2008
   [121] : Recovering Route count database
5) Event:E_DEBUG, length:55, at 943124 usecs after Mon Dec 22 12:24:41 2008
   [121] : Attempting IGMP SNOOP database stateful recovery
switch(config)#
```

Related Commands

Command	Description
clear ip igmp event-history	Clears the contents of the IGMP event history buffers.
ip igmp event-history	Configures the size of IGMP event history buffers.

show ip igmp groups

show ip igmp groups

To display information about IGMP-attached group membership, use the **show ip igmp groups** command.

```
show ip igmp groups [{source [group]} | {group [source]}] [if-type if-number] [vrf {vrf-name | all}]
```

Syntax Description	
<i>source</i>	Source IP address.
<i>group</i>	(Optional) Multicast IP address of the single group to display.
<i>if-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>if-number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
----------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	The show ip igmp route command is an alternative form of this command. This command does not require a license.
------------------	---

Examples	This example shows how to display information about the IGMP-attached group membership: <pre>switch(config)# show ip igmp groups IGMP Connected Group Membership for Context "default" - 2 total entries Type: S - Static, D - Dynamic, L - Local, T - SSM Translated Group Address Type Interface Uptime Expires Last Reporter 224.1.1.1 L GigabitEthernet2/8 00:00:04 00:04:15 1.0.8.3</pre>
----------	--

Send document comments to nexus7k-docfeedback@cisco.com.

```
224.1.1.2          L    GigabitEthernet2/8  00:00:02  00:04:17  1.0.8.3
switch(config)#
```

Related Commands

Command	Description
show ip igmp route	Displays information about the IGMP-attached group membership.

 show ip igmp interface

show ip igmp interface

To display information about IGMP on interfaces, use the **show ip igmp interface** command.

show ip igmp interface *if-type if-number*

show ip igmp interface [brief**] [**vrf {vrf-name | all}**]**

Syntax Description	
<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
brief	(Optional) Displays one line status per interface.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.
	4.1(3)	Changed output to include vPC information when IGMP is in vPC mode.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about IGMP on an interface (if IGMP is not in vPC mode, the vPC information is not displayed):
-----------------	--

```
switch(config)# show ip igmp interface vlan 5
IGMP Interfaces for VRF "default"
Vlan5, Interface status: protocol-up/link-up/admin-up
  IP address: 2.4.0.4, IP subnet: 2.4.0.0/24
  Active querier: 2.4.0.4, version: 2, next query sent in: 00:01:02
  Membership count: 0
  Old Membership count 0
  IGMP version: 2, host version: 2
```

Send document comments to nexus7k-docfeedback@cisco.com.

```

IGMP query interval: 125 secs, configured value: 125 secs
IGMP max response time: 10 secs, configured value: 10 secs
IGMP startup query interval: 31 secs, configured value: 31 secs
IGMP startup query count: 2
IGMP last member mrt: 1 secs
IGMP last member query count: 2
IGMP group timeout: 260 secs, configured value: 260 secs
IGMP querier timeout: 255 secs, configured value: 255 secs
IGMP unsolicited report interval: 10 secs
IGMP robustness variable: 2, configured value: 2
IGMP reporting for link-local groups: disabled
IGMP interface enable refcount: 1
IGMP Report Policy: None
IGMP State Limit: None
IGMP interface statistics:
  General (sent/received):
    v1-reports: 0/0
    v2-queries: 574/574, v2-reports: 0/3, v2-leaves: 0/3
    v3-queries: 0/0, v3-reports: 0/0
  Errors:
    Checksum errors: 0, Packet length errors: 0
    Packets with Local IP as source: 2, Source subnet check failures: 0
    Query from non-querier:0
    Report version mismatch: 0, Query version mismatch: 0
    Unknown IGMP message type: 0
    Invalid v1 reports: 0, Invalid v2 reports: 0, Invalid v3 reports: 0
    Packets dropped due to router-alert check: 0
Interface PIM DR: vPC Peer
Interface vPC CFS statistics:
  DR queries sent: 2
  DR queries rcvd: 0
  DR queries fail: 0
  DR updates sent: 4
  DR updates rcvd: 0
  DR updates fail: 0
switch(config)#

```

This example shows how to display information about IGMP on an interface in a brief format:

```

switch(config)# show ip igmp interface brief
IGMP Interfaces for VRF "default", count: 2
Interface          IP Address      IGMP Querier    Membership  Version
                  Count
Ethernet2/11       192.168.1.222  0.0.0.0        0           v2
Ethernet2/12       unassigned     0.0.0.0        0           v2
switch(config)#

```

Related Commands

Command	Description
show ip igmp route	Displays information about the IGMP-attached group membership.

 show ip igmp local-groups

show ip igmp local-groups

To display information about IGMP local groups, use the **show ip igmp local-groups** command.

show ip igmp local-groups [if-type if-number] [vrf {vrf-name | all}]

Syntax Description	<table border="0"> <tr> <td><i>if-type</i></td><td>(Optional) Interface type. For more information, use the question mark (?) online help function.</td></tr> <tr> <td><i>if-number</i></td><td>(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.</td></tr> <tr> <td>vrf</td><td>(Optional) Applies to a virtual routing and forwarding (VRF) instance.</td></tr> <tr> <td><i>vrf-name</i></td><td>VRF name.</td></tr> <tr> <td>all</td><td>Specifies all VRFs.</td></tr> </table>	<i>if-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.	<i>if-number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	<i>vrf-name</i>	VRF name.	all	Specifies all VRFs.
<i>if-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.										
<i>if-number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.										
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.										
<i>vrf-name</i>	VRF name.										
all	Specifies all VRFs.										

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about IGMP local groups:
	<pre>switch(config)# show ip igmp local-groups IGMP Locally Joined Group Membership for VRF "default" Group Address Source Address Type Interface Last Reported 230.0.0.0 * Static Eth2/11 4d04h 224.0.1.39 * Local Eth2/11 4d04h 224.0.1.40 * Local Eth2/11 4d04h switch(config)# </pre>

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	show ip igmp route	Displays information about the IGMP-attached group membership.

■ **show ip igmp**

show ip igmp

To display IGMP status and configuration, use the **show ip igmp** command.

```
show ip igmp {groups | route} [{source [group]} | {group [source]}] [interface] [summary] [vrf {vrf-name | vrf-known-name | all}]
```

Syntax Description	groups Displays IGMP attached group membership information.
route	Displays IGMP attached group membership information.
<i>source</i>	Source IP address.
<i>group</i>	(Optional) Multicast IP address of single group to display.
<i>interface</i>	Displays port channel interface.
summary	Displays group summary.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	6.1(1)	changed the position of the summary option in the show ip igmp groups and show ip igmp route set of commands (The summary option used to be after the vrf option and now it will be precede it).
	4.0(1)	This command was introduced.

Usage Guidelines	The show ip igmp groups command is an alternative form of this command. This command does not require a license.
-------------------------	--

Send document comments to nexus7k-docfeedback@cisco.com.

Examples

This example shows how to display information about the IGMP-attached group membership:

```
switch(config)# show ip igmp route
IGMP Connected Group Membership for Context "default" - 2 total entries
Type: S - Static, D - Dynamic, L - Local, T - SSM Translated
Group Address      Type Interface          Uptime    Expires   Last Reporter
224.1.1.1          L    GigabitEthernet2/8  00:00:04  00:04:15  1.0.8.3
224.1.1.2          L    GigabitEthernet2/8  00:00:02  00:04:17  1.0.8.3
switch(config)#

```

Related Commands

Command	Description
show ip igmp groups	Displays information about the IGMP-attached group membership.

■ **show ip igmp snooping**

show ip igmp snooping

To display information about IGMP snooping, use the **show ip igmp snooping** command.

show ip igmp snooping [vlan *vlan-id*]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093. The default is all VLANs.				
Defaults	Displays all VLANs.				
Command Modes	Any command mode				
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command does not require a license.				
Examples	<p>This example shows how to display information about IGMP snooping for a VLAN:</p> <pre>switch(config)# show ip igmp snooping vlan 1 IGMP Snooping information for vlan 1 IGMP snooping enabled IGMP querier none Switch-querier disabled Explicit tracking enabled Fast leave enabled Report suppression enabled Router port detection using PIM Hellos, IGMP Queries Number of router-ports: 0 Number of groups: 0 switch(config)# </pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>show ip igmp route</td><td>Displays information about the IGMP-attached group membership.</td></tr> </tbody> </table>	Command	Description	show ip igmp route	Displays information about the IGMP-attached group membership.
Command	Description				
show ip igmp route	Displays information about the IGMP-attached group membership.				

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping event-history

To display information in the IGMP snooping event history buffers, use the **show ip igmp snooping event-history** command.

```
show ip igmp snooping event-history { vpc | igmp-snoop-internal | mfdm | mfdm-sum | vlan |
vlan-events }
```

Syntax Description	
vpc	Displays the event history buffer of type virtual port channel (vPC).
igmp-snoop-internal	Displays the event history buffer of type IGMP snooping internal.
mfdm	Displays the event history buffer of type multicast FIB distribution (MFDM).
mfdm-sum	Displays the event history buffer of type MFDM sum.
vlan	Displays the event history buffer of type VLAN.
vlan-events	Displays the event history buffer of type VLAN events.

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information in the IGMP snooping VLAN event history buffer: switch(config)# show ip igmp snooping event-history vlan vlan Events for IGMP snoopprocess switch(config)#
-----------------	--

■ **show ip igmp snooping event-history**

Related Commands	Command	Description
	ip igmp snooping event-history	Configures the size of the IGMP snooping event history buffers.
	clear ip igmp snooping event-history	Clears information in the IGMP snooping event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping explicit-tracking

To display information about explicit tracking for IGMP snooping, use the **show ip igmp snooping explicit-tracking** command.

show ip igmp snooping explicit-tracking [vlan *vlan-id*]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.						
Defaults	None						
Command Modes	Any command mode						
Supported User Roles	network-admin network-operator vdc-admin vdc-operator						
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> <tr> <td>4.2(2)</td><td>This command was changed to make the vlan argument optional.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.	4.2(2)	This command was changed to make the vlan argument optional.
Release	Modification						
4.0(1)	This command was introduced.						
4.2(2)	This command was changed to make the vlan argument optional.						
Usage Guidelines	When you use this command without the optional vlan argument, the system displays information for all VLANs. This command does not require a license.						
Examples	This example shows how to display information about explicit tracking for IGMP snooping for VLAN 33: <pre>switch(config)# show ip igmp snooping explicit-tracking vlan 33 IGMPv3 Snooping Explicit-tracking information Source/Group Intf Reporter Uptime Last-Join Expires 1.1.1.1 232.1.1.1 Eth2/1 3.3.3.3 00:01:33 00:04:27 00:01:44 switch(config)#</pre>						

 show ip igmp snooping groups

show ip igmp snooping groups

To display information about group membership for IGMP snooping, use the **show ip igmp snooping groups** command.

show ip igmp snooping groups [{source [group]} | {group [source]}] [vlan *vlan-id*] [detail]

Syntax Description

<i>source</i>	(Optional) Source address for route.
<i>group</i>	(Optional) Group address for route.
vlan <i>vlan-id</i>	(Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.
detail	(Optional) Displays detailed information for the group.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.
4.1(2)	Arguments <i>source</i> and <i>group</i> were added.

Usage Guidelines

This command does not require a license.

Examples

This example shows how to display information about group membership for IGMP snooping:

```
switch(config)# show ip igmp snooping groups
Type: S - Static, D - Dynamic, R - Router port

Vlan  Group Address      Ver  Type   Port list
33    225.1.1.1          v3   S     Eth2/1
switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping look-up mode

To display IGMP snooping lookup mode information, use the **show ip igmp snooping lookup-mode** command.

show ip igmp snooping look-up mode [vlan *vlan-id*]

Syntax Description	vlan (Optional) Displays the VLAN information. vlan-id (Optional) VLAN ID. The range is from 1 to 3967 and from 4048 to 4093.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines	If the VLAN is configured for MAC based lookup, then the display will show MAC entries, else it will show IP entries.
-------------------------	---

User can explicitly display an IP (BD,S,G) entry or MAC entry by specifying Group address or MAC address. If the lookup mode is IP and the user specifies MAC, show will return null and prints a message “Snooping lookups in group IP mode”. Similarly If the user specifies MAC and the lookup is IP, show command will return null and prints “Snooping lookups in group MAC mode”

This command does not require a license.

Examples	This example shows how to display IGMP snooping lookup mode information:
-----------------	--

```
switch(config)# show ip igmp snooping lookup-mode vlan 1
Global lookup-mode:
  configured : IP
  operational: MAC
VLAN lookup-mode
  1 IP
  10 MAC
  11 IP
switch(config)#

```

■ **show ip igmp snooping look-up mode**

Related Commands	Command	Description
	show ip igmp snooping mac-oif	Displays the IGMP Snooping static MAC OIF information.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping mac-oif

To display IGMP Snooping static MAC OIF information, use the **show ip igmp snooping mac-oif** command.

show ip igmp snooping mac-oif [vlan *vlan-id*] [detail]

Syntax Description	detail (Optional) Displays the detail static MAC OIF, M2RIB OIF information. vlan (Optional) Displays VLAN information. vlan-id (Optional) VLAN ID. The range is from 1 to 3967 and from 4048 to 4093.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display IGMP snooping MAC OIF information:
	<pre>switch(config)# show ip igmp snooping mac-oif Total Mac OIF: 0 VLAN Count MAC-ADDR OIFs 1 0 switch(config)# </pre>

This example shows how to display detailed IGMP snooping MAC OIF and M2RIB OIF information:

```
switch(config)# show ip igmp snooping mac-oif detail
Total Mac OIF: 0
VLAN Count MAC-ADDR          OIFs
      1      0
switch(config)#

```

■ **show ip igmp snooping mac-oif**

Related Commands	Command	Description
	show ip igmp snooping lookup-mode	Displays the IGMP snooping lookup mode information.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping mrouter

To display the multicast routers detected by IGMP snooping, use the **show ip igmp snooping mrouter** command.

show ip igmp snooping mrouter [vlan *vlan-id*]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.						
Defaults	None						
Command Modes	Any command mode						
Supported User Roles	network-admin network-operator vdc-admin vdc-operator						
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> <tr> <td>4.1(3)</td><td>Changed output to include vPC information.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.	4.1(3)	Changed output to include vPC information.
Release	Modification						
4.0(1)	This command was introduced.						
4.1(3)	Changed output to include vPC information.						
Usage Guidelines	This command does not require a license.						
Examples	<p>This example shows how to display the multicast routers detected by IGMP snooping:</p> <pre>switch(config)# show ip igmp snooping mrouter Type: S - Static, D - Dynamic, V - vPC Peer Link Vlan Router-port Type Uptime Expires 1 Po88 SV 00:00:51 never 2 Po88 SV 00:00:51 never 3 Po88 SV 00:00:51 never 4 Po88 SV 00:00:51 never 5 Vlan5 D 18:02:38 00:04:40 switch(config)# </pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>show ip igmp snooping lookup-mode</td><td>Displays the IGMP snooping lookup mode information.</td></tr> </tbody> </table>	Command	Description	show ip igmp snooping lookup-mode	Displays the IGMP snooping lookup mode information.		
Command	Description						
show ip igmp snooping lookup-mode	Displays the IGMP snooping lookup mode information.						

■ **show ip igmp snooping querier**

show ip igmp snooping querier

To display information about IGMP snooping queriers, use the **show ip igmp snooping querier** command.

show ip igmp snooping querier [vlan *vlan-id*]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information about IGMP snooping queriers:
-----------------	---

```
switch(config)# show ip igmp snooping querier
Vlan  IP Address      Version  Port
1    172.20.50.11     v3      fa2/1
2    172.20.40.20     v2      Router
switch(config)#

```

Related Commands	Command	Description
	show ip igmp snooping lookup-mode	Displays the IGMP snooping lookup mode information.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip igmp snooping statistics

To display information about IGMP snooping statistics, use the **show ip igmp snooping statistics** command.

show ip igmp snooping statistics [vlan *vlan-id* | global]

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN. The range is from 1 to 3967 and 4048 to 4093. global (Optional) Specifies the global statistics.										
Defaults	None										
Command Modes	Any command mode										
Supported User Roles	network-admin network-operator vdc-admin vdc-operator										
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> <tr> <td>4.1(3)</td><td>Changed output to include vPC information.</td></tr> <tr> <td>4.2(1)</td><td>Enhanced output for vPC information.</td></tr> <tr> <td>4.2(2)</td><td>Changed command to make the vlan argument optional and to introduce the optional global argument.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.	4.1(3)	Changed output to include vPC information.	4.2(1)	Enhanced output for vPC information.	4.2(2)	Changed command to make the vlan argument optional and to introduce the optional global argument.
Release	Modification										
4.0(1)	This command was introduced.										
4.1(3)	Changed output to include vPC information.										
4.2(1)	Enhanced output for vPC information.										
4.2(2)	Changed command to make the vlan argument optional and to introduce the optional global argument.										
Usage Guidelines	When you use this command without any options, the system prints statistics for all VLANs. This command does not require a license.										
Examples	<p>This example shows how to display information about IGMP snooping statistics for VLAN 1:</p> <pre>switch(config)# show ip igmp snooping statistics vlan 1 Global IGMP snooping statistics: Packets received: 78 Packet errors: 0 Packets for non-snooped vlans : 0 Packets flooded: 41 vPC PIM DR queries sent: 0 vPC PIM DR queries rcvd: 0 vPC PIM DR queries fail: 0 vPC PIM DR updates sent: 4 vPC PIM DR updates rcvd: 0</pre>										

show ip igmp snooping statistics

```

vPC PIM DR updates fail: 0
vPC CFS send fail: 0
vPC CFS message response sent: 13
vPC CFS message response rcvd: 16
vPC CFS message response fail: 0
vPC CFS message response fail peer-link down: 0
vPC CFS unreliable message sent: 35
vPC CFS unreliable message rcvd: 37
vPC CFS unreliable message fail: 0
vPC CFS reliable message sent: 16
vPC CFS reliable message rcvd: 13
vPC CFS reliable message fail: 0
STP TCN messages rcvd: 22
IM api failed: 0
VLAN 2 IGMP snooping statistics, last reset: never
  Packets received: 29
    IGMPv1 reports received: 0
    IGMPv2 reports received: 13
    IGMPv3 reports received: 0
    IGMPv1 queries received: 0
    IGMPv2 queries received: 14
    IGMPv3 queries received: 0
    IGMPv2 leaves received: 0
    PIM Hellos received: 0
    Invalid reports received: 0
    Invalid queries received: 0
    IGMPv1 reports suppressed: 0
    IGMPv2 reports suppressed: 0
    IGMPv2 leaves suppressed: 0
    IGMPv3 group records suppressed: 0
    Queries originated: 0
    IGMPv2 proxy-reports originated: 0
    IGMPv2 proxy-leaves originated: 0
    IGMPv3 proxy-reports originated: 0
  Packets sent to routers: 13
  STP TCN received: 9
  Report version mismatch: 0
  Unknown packets received: 0
  vPC Peer Link CFS packet statistics:
    IGMP packets (sent/recv/fail): 11/16/0
    MRD updates (sent/recv/fail): 0/0/0

```

Related Commands

Command	Description
show ip igmp snooping lookup-mode	Displays the IGMP snooping lookup mode information.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip mroute

To display information about IPv4 multicast routes, use the **show ip mroute** command.

```
show ip mroute {group | {source group} | {group [source]} } [summary [software-forwarded]]  
[vrf {vrf-name | all}]
```

Syntax Description

<i>group</i>	Group address for route.
<i>source</i>	Source address for route.
summary	(Optional) Displays route counts and packet rates.
software-forwarded	(Optional) Displays software-switched route counts only.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about multicast routes:

```
switch(config)# show ip mroute
IP Multicast Routing Table for VRF "default"

(*, 224.1.1.1/32), uptime: 13:00:28, igmp ip pim
  Incoming interface: Loopback1 (iod: 3), RPF nbr: 2.2.2.2
  Outgoing interface list: (count: 1)
    GigEther2/0/1 (iod 4), uptime: 13:00:28, igmp

(*, 226.1.1.1/32), uptime: 13:00:32, igmp ip pim
  Incoming interface: Loopback1 (iod: 3), RPF nbr: 2.2.2.2
```

show ip mroute

```

Outgoing interface list: (count: 1)
  GigEther2/0/1 (iod 4), uptime: 13:00:32, igmp

(*, 228.2.2.2/32), uptime: 13:00:27, igmp ip pim
  Incoming interface: Loopback1 (iod: 3), RPF nbr: 2.2.2.2
  Outgoing interface list: (count: 1)
    GigEther2/0/1 (iod 4), uptime: 13:00:27, igmp

(*, 232.0.0.0/8), uptime: 13:01:27, pim ip
  Incoming interface: Null (iod: 0), RPF nbr: 0.0.0.0
  Outgoing interface list: (count: 0)

switch(config)#

```

The display specifies the interface established for each one and shows the router owners. In the case of the first paragraph in the display, the route owner is **igmp ip pim**. **iod** is an internal representation the device uses for the interface.

Related Commands	Command	Description
	show ip mroute summary	Displays summary information about IPv4 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip mroute summary

To display summary information about IPv4 multicast routes, use the **show ip mroute summary** command.

show ip mroute summary [count | software-forwarded]] [vrf {vrf-name | all}]

show ip mroute {group} summary [software-forwarded] [vrf {vrf-name | all}]

Syntax Description	count (Optional) Displays only route counts. software-forwarded (Optional) Displays software-switched route counts only. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs. group Specifies a group address for a route.
Defaults	None
Command Modes	Any command mode
Supported User Roles	network-admin network-operator vdc-admin vdc-operator
Command History	Release Modification 4.0(1) This command was introduced.
Usage Guidelines	This command requires the Enterprise Services license.
Examples	This example shows how to display summary information about multicast routes: <pre>switch(config)# show ip mroute summary IP Multicast Routing Table for VRF "default" Total number of routes: 6 Total number of (*,G) routes: 4 Total number of (S,G) routes: 1 Total number of (*,G-prefix) routes: 1 Group count: 4, rough average sources per group: 0.2</pre>

show ip mroute summary

```

Group: 225.0.0.1/32, Source count: 0
Source      packets      bytes      aps      pps      bit-rate   oifs
(*,G)        0          0          0          0      0 bps      1

Group: 225.0.1.1/32, Source count: 0
Source      packets      bytes      aps      pps      bit-rate   oifs
(*,G)        0          0          0          0      0 bps      1

Group: 225.1.1.1/32, Source count: 1
Source      packets      bytes      aps      pps      bit-rate   oifs
(*,G)        0          0          0          0      0 bps      4
2.1.1.2      0          0          0          0      0 bps      4

Group: 226.1.1.1/32, Source count: 0
Source      packets      bytes      aps      pps      bit-rate   oifs
(*,G)        0          0          0          0      0 bps      1

Group: 232.0.0.0/8, Source count: 0
Source      packets      bytes      aps      pps      bit-rate   oifs
(*,G)        0          0          0          0      0 bps      0
0 bps      0
switch(config)#

```

Related Commands

Command	Description
show ip mroute	Displays information about IPv4 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp count

To display information about Multicast Source Discovery Protocol (MSDP) counts, use the **show ip msdp count** command.

show ip msdp count [asn] [vrf {vrf-name | all}]

Syntax Description

asn	(Optional) Autonomous systems (AS) number.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display MSDP counts:

```
switch(config)# show ip msdp count
SA State per ASN, context "default" - 2134 total entries
<asn>: <(S,G) count>/<group count>
 3:   5/4      8:   4/4      9:   7/6      12:   1/1
 14:  18/14    17:   4/3      18:  11/3     25:  331/290
 26:  10/6     27:   1/1      32:   4/4      38:   8/5
 52:  11/2     55:  13/2     59:  12/9     70:   6/4
 73:  10/10    81:  30/13    87:   1/1     103:  11/10
 109: 46/23   111:   1/1     131:  21/3    137:   8/8
 159:  9/6     160:   2/2     194:   2/1     195:   2/1
 217:  1/1     224:  24/13    225:   1/1     237:  38/31
 271:  8/7     291:   1/1     292:   2/2     293:   5/4
 297:  6/6     549:   3/2     553:   1/1     559:  23/18
 668:  2/1     680:  26/21    683:  16/10    704:  18/15
 766:  18/17    776:   2/2     786:  123/49   818:   2/2
 1103: 46/37   1161:   2/2    1224:  10/8    1239:   9/9
```

■ **show ip msdp count**

```

1273:    1/1      1312:    1/1      1657:    6/6      1706:    7/6
1725:    1/1      1739:    3/3      1741:   11/11     1742:    6/5
1835:    1/1      1851:    2/1      1935:    1/1      1998:    6/6
2055:    7/6      2107:    2/2      2152:    7/5      2200:   46/29
2259:  168/4     2381:    8/4      2422:    5/5      2594:   25/25
2607:  64/59     2611:   45/37     2637:    5/4      2701:    1/1
2852:  117/16     2914:    2/2      3323:    2/2      3582:   27/24
3676:    7/3      3685:    9/8      3851:    1/1      3912:    5/3
3948:    1/1      3999:    6/4      4130:    4/4      4201:    5/4
4385:    9/5      5050:    1/1      5408:    4/3      5520:    3/3
5640:   26/6      5661:   14/10     5664:    3/3      5719:    2/2
5739:    1/1      6192:    5/2      6200:    2/2      6263:    8/5
6360:    3/1      6366:    8/6      6481:   15/12     6509:   31/9
7082:    4/1      7212:    4/3      7377:   10/9      7539:   63/37
7570:    3/3      7571:    1/1      7572:    1/1      7575:   20/11
7610:    1/1      7660:    1/1      7774:    2/1      7896:    2/2
8071:    5/3      8111:   22/22     9112:    5/2      9270:    2/1
9821:    1/1      10546:   2/2      10764:   1/1      10886:   2/2
11050:   2/2      11078:   2/1      11279:   13/3     11537:   8/3
11546:   1/1      11808:   1/1      12005:   2/2      12173:   1/1
13476:   1/1      13501:   5/4      14077:   3/3      15474:   1/1
15725:   1/1      16430:   2/1      16517:   2/2      17055:   3/2
18047:  14/14     18062:  111/41     18297:   2/2      20965:  24/1
22168:   2/2      23366:   6/2      23504:   5/1      23719:  11/8
24433:   6/3      24434:   5/2      24437:   1/1      25656:   1/1
25689:   3/3      26002:   5/3      26367:   1/1      26934:   3/3
26971:   1/1      29825:   1/1      32666:   5/5      65028:   1/1
switch(config)#

```

Related Commands

Command	Description
clear ip msdp event-history	Clears the contents of the MSDP event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp event-history

To display information in the Multicast Source Discovery Protocol (MSDP) event history buffers, use the **show ip msdp event-history** command.

show ip msdp event-history {errors | msgs | statistics}

Syntax Description

errors	Displays events of type error.
msgs	Displays events of type msg.
statistics	Displays events of type statistics.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.1(2)	This command was introduced.

Usage Guidelines

This command does not require a license.

Examples

This example shows how to display information in the MSDP msgs event history buffer:

```
switch(config)# show ip msdp event-history msgs

Msg events for MSDP Process
1) Event:E_DEBUG, length:38, at 198828 usecs after Wed Jan  7 17:24:45 2009
   [100] : nvdb: transient thread created

2) Event:E_DEBUG, length:38, at 197333 usecs after Wed Jan  7 17:24:45 2009
   [100] : nvdb: create transient thread

3) Event:E_DEBUG, length:77, at 197327 usecs after Wed Jan  7 17:24:45 2009
   [100] : comp-mts-rx opc - from sap 27315 cmd msdp_show_internal_event_hist_cmd

4) Event:E_DEBUG, length:35, at 277809 usecs after Wed Jan  7 17:24:40 2009
   [100] : nvdb: terminate transaction

5) Event:E_DEBUG, length:60, at 277696 usecs after Wed Jan  7 17:24:40 2009
   [100] : nvdb: msdp_show_internal_event_hist_cmd returned 0x0
```

show ip msdp event-history

```

6) Event:E_DEBUG, length:38, at 277243 usecs after Wed Jan  7 17:24:40 2009
   [100] : nvdb: transient thread created

7) Event:E_DEBUG, length:38, at 275631 usecs after Wed Jan  7 17:24:40 2009
   [100] : nvdb: create transient thread

8) Event:E_DEBUG, length:77, at 275625 usecs after Wed Jan  7 17:24:40 2009
   [100] : comp-mts-rx opc - from sap 27315 cmd msdp_show_internal_event_hist_cmd

9) Event:E_DEBUG, length:47, at 93136 usecs after Wed Jan  7 17:24:32 2009
   [100] : nvdb: _cli_send_my_command returned 0x0
switch(config)#

```

Related Commands

Command	Description
clear ip msdp event-history	Clears the contents of the MSDP event history buffers.
ip msdp event-history	Configures the size of MSDP event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp mesh-group

To display information about Multicast Source Discovery Protocol (MSDP) mesh groups, use the **show ip msdp mesh-group** command.

show ip msdp mesh-group [mesh-group] [vrf {vrf-name | all}]

Syntax Description	<p>mesh-group (Optional) Mesh group name.</p> <p>vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance.</p> <p>vrf-name VRF name.</p> <p>all Specifies all VRFs.</p>						
Defaults	None						
Command Modes	Any command mode						
Supported User Roles	network-admin network-operator vdc-admin vdc-operator						
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.		
Release	Modification						
4.0(1)	This command was introduced.						
Usage Guidelines	This command requires the Enterprise Services license.						
Examples	<p>This example shows how to display information about MSDP mesh groups:</p> <pre>switch(config)# show ip msdp mesh-group MSDP Mesh-Group Membership for VRF "default" Mesh-group: my_mesh_group Peer: 192.168.1.10, AS: 8, description: engineering peer</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>clear ip msdp route</td><td>Clears routes in the MSDP Source-Active cache.</td></tr> <tr> <td>show ip msdp sa-cache</td><td>Displays information about the MSDP SA cache.</td></tr> </tbody> </table>	Command	Description	clear ip msdp route	Clears routes in the MSDP Source-Active cache.	show ip msdp sa-cache	Displays information about the MSDP SA cache.
Command	Description						
clear ip msdp route	Clears routes in the MSDP Source-Active cache.						
show ip msdp sa-cache	Displays information about the MSDP SA cache.						

 show ip msdp peer

show ip msdp peer

To display information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp peer** command.

show ip msdp peer [peer-address] [vrf {vrf-name | all}]

Syntax Description

peer-address	(Optional) IP address of an MSDP peer.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about MSDP peers:

```
switch(config)# show ip msdp peer
MSDP peer 192.168.1.10 for VRF "default"
AS 8, local address: 192.168.1.222 (Ethernet2/11)
  Description: engineering peer
  Connection status: Listening
  Uptime(Downtime): 01:14:30
  Last reset reason: Connect source interface address changed
  Password: not set
  Keepalive Interval: 10 sec
  Keepalive Timeout: 20 sec
  Reconnection Interval: 20 sec
  Policies:
    SA in: my_incoming_sa_policy, SA out: none
    SA limit: unlimited
  Member of mesh-group: my_mesh_group
  Statistics (in/out):
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
Last message received: never
SAs: 0/0, SA-Requests: 0/0, SA-Responses: 0/0
Keepalives: 0/0, Notifications: 0/0
switch(config)#
```

Related Commands

Command	Description
clear ip msdp route	Clears routes in the MSDP Source-Active cache.
show ip msdp sa-cache	Displays information about the MSDP SA cache.

■ show ip msdp policy statistics sa-policy

show ip msdp policy statistics sa-policy

To display information about Multicast Source Discovery Protocol (MSDP) Source-Active (SA) policies, use the **show ip msdp policy statistics sa-policy** command.

show ip msdp policy statistics sa-policy peer-address {in | out} [vrf {vrf-name}]

Syntax Description	<p>peer-address IP address of the MSDP peer for the SA policy.</p> <p>in Specifies the input policy.</p> <p>out Specifies the output policy.</p> <p>vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance.</p> <p>vrf-name VRF name.</p>
---------------------------	---

Defaults None

Command Modes Any command mode

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines This command requires the Enterprise Services license.

This example shows how to display information about MSDP SA policies:

```
switch(config)# show ip msdp policy statistics sa-policy 192.168.1.10 in
C: No. of comparisions, M: No. of matches

route-map rmap1 permit 10
  match ip multicast group 225.1.1.0/24                                C: 0      M:
Total accept count for policy: 12
Total reject count for policy: 21
switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	clear ip msdp route	Clears routes in the MSDP Source-Active cache.

 show ip msdp route

show ip msdp route

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp route** command.

```
show ip msdp route [{source [group]} | {group [source]}] [asn] [peer peer] [detail] [vrf {vrf-name | all}]
```

Syntax Description	<i>source</i> Source address for SA cache information. <i>group</i> (Optional) Group address for SA cache information. <i>asn</i> (Optional) AS number. <i>peer peer</i> (Optional) Specifies the IP address of a peer. <i>detail</i> (Optional) Displays detailed information. <i>vrf</i> (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. <i>all</i> Specifies all VRFs.
--------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	The show ip msdp sa-cache command is an alternative form of this command. This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the MSDP SA cache:
-----------------	--

```
switch(config)# show ip msdp route
MSDP SA Route Cache for Context "default" - 2138 entries
Source          Group          RP           ASN      Uptime
24.124.36.130  224.0.1.1    144.228.240.250 1239   17:35:19
64.104.160.29  224.0.1.1    204.69.199.17   109    17:35:19
128.59.21.232  224.0.1.1    128.59.0.51     14     03:33:59
128.117.37.217 224.0.1.1    128.117.243.9   194    04:07:17
```

Send document comments to nexus7k-docfeedback@cisco.com.

```

128.117.37.220  224.0.1.1      128.117.243.9    194   04:08:45
129.49.88.9     224.0.1.1      199.109.44.1     5719  17:34:48
130.18.14.12    224.0.1.1      192.208.151.9   10546 17:35:19
130.37.20.4     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.20.5     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.20.7     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.64.252   224.0.1.1      145.145.255.6   1103  17:35:21
130.88.20.1     224.0.1.1      194.66.25.224   786   17:35:19
130.159.54.4    224.0.1.1      194.81.62.54    786   17:35:19
130.159.228.48  224.0.1.1      194.81.62.54    786   17:35:19
130.159.248.12  224.0.1.1      194.81.62.54    786   17:35:19
132.234.1.1    224.0.1.1      132.234.251.232  7575  13:40:17
134.174.190.41 224.0.1.1      192.5.66.202    1742  17:34:45
--More--q
switch(config)#

```

Related Commands

Command	Description
clear ip msdp route	Clears routes in the MSDP Source-Active cache.
show ip msdp sa-cache	Displays information about the MSDP SA cache.

 show ip msdp rpf

show ip msdp rpf

To display information about the Multicast Source Discovery Protocol (MSDP) next-hop autonomous system (AS) on the BGP path to an RP address, use the **show ip msdp rpf** command.

show ip msdp rpf rp-address [vrf {vrf-name all}]

Syntax Description	
rp-address	IP address of the RP.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
vrf-name	VRF name.
all	Specifies all VRFs.
Defaults	
	None
Command Modes	
	Any command mode
SupportedUserRoles	
	network-admin network-operator vdc-admin vdc-operator
Command History	
Release	Modification
4.0(1)	This command was introduced.
Usage Guidelines	
	This command requires the Enterprise Services license.
Examples	
	This example shows how to display information about MSDP RPF peers:
<pre>switch(config)# show ip msdp rpf 192.168.1.10 MSDP RPF-Peer for RP 192.168.1.10, VRF default: Mesh-group check: Peer 192.168.1.10, mesh-group member of my_mesh_group Peer/route-lookup check: Peer 192.168.1.10, only MSDP peer configured, peer is RP switch(config)#+</pre>	
Related Commands	
Command	Description
clear ip msdp route	Clears routes in the MSDP Source-Active cache.
show ip msdp sa-cache	Displays information about the MSDP SA cache.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp sa-cache

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp sa-cache** command.

```
show ip msdp {sa-cache | route} [{source [group]} | {group [source]}] [asn] [peer peer] [detail]
[vrf {vrf-name | all}]
```

Syntax Description

<i>source</i>	Source address for SA cache information.
<i>group</i>	(Optional) Group address for SA cache information.
<i>asn</i>	(Optional) AS number.
peer <i>peer</i>	(Optional) Specifies the IP address of a peer.
detail	(Optional) Displays detailed information.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

Supported User Roles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

The **show ip msdp route** command is an alternative form of this command.

This command requires the Enterprise Services license.

Examples

This example shows how to display information about the MSDP SA cache:

```
switch(config)# show ip msdp sa-cache
MSDP SA Route Cache for Context "default" - 2138 entries
Source          Group          RP           ASN      Uptime
24.124.36.130  224.0.1.1    144.228.240.250 1239   17:35:19
64.104.160.29  224.0.1.1    204.69.199.17   109    17:35:19
128.59.21.232  224.0.1.1    128.59.0.51     14     03:33:59
128.117.37.217 224.0.1.1    128.117.243.9   194    04:07:17
```

■ **show ip msdp sa-cache**

```

128.117.37.220  224.0.1.1      128.117.243.9    194   04:08:45
129.49.88.9     224.0.1.1      199.109.44.1    5719  17:34:48
130.18.14.12    224.0.1.1      192.208.151.9   10546 17:35:19
130.37.20.4     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.20.5     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.20.7     224.0.1.1      145.145.255.6   1103  17:35:21
130.37.64.252   224.0.1.1      145.145.255.6   1103  17:35:21
130.88.20.1     224.0.1.1      194.66.25.224   786   17:35:19
130.159.54.4    224.0.1.1      194.81.62.54    786   17:35:19
130.159.228.48  224.0.1.1      194.81.62.54    786   17:35:19
130.159.248.12  224.0.1.1      194.81.62.54    786   17:35:19
132.234.1.1    224.0.1.1      132.234.251.232  7575  13:40:17
134.174.190.41 224.0.1.1      192.5.66.202    1742  17:34:45
--More--q
switch(config)#

```

Related Commands

Command	Description
clear ip msdp sa-cache	Clears routes in the MSDP Source-Active cache.
show ip msdp route	Displays information about the MSDP SA cache.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp sources

To display information about Multicast Source Discovery Protocol (MSDP) learned sources, use the **show ip msdp sources** command.

show ip msdp sources [vrf {*vrf-name* | all}]

Syntax Description

vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about MSDP learned sources:

```
switch(config)# show ip msdp sources

MSDP Learned Sources and Group-Limit Information for VRF "default"
Source      Group Count  Group Limit  Source Prefix      Violations
18.7.25.94   1          unlimited    --           0
18.39.0.30   1          unlimited    --           0
18.62.10.96  1          unlimited    --           0
18.62.10.177 1          unlimited    --           0
18.89.2.245  1          unlimited    --           0
24.124.36.130 1          unlimited    --           0
62.40.98.21  1          unlimited    --           0
62.40.98.52  1          unlimited    --           0
62.40.98.75  1          unlimited    --           0
62.40.98.117 1          unlimited    --           0
62.40.98.139 1          unlimited    --           0
62.40.98.140 1          unlimited    --           0
62.40.98.152 1          unlimited    --           0
```

■ show ip msdp sources

```
62.40.98.171      1          unlimited    --          0
62.40.98.202      1          unlimited    --          0
62.40.98.212      1          unlimited    --          0
--More--q
switch(config)#
```

Related Commands

Command	Description
clear ip msdp route	Clears routes in the MSDP Source-Active cache.
show ip msdp sa-cache	Displays information about the MSDP SA cache.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip msdp summary

To display summary information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp summary** command.

show ip msdp summary [vrf {vrf-name | all}]

Syntax Description	vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display summary information about MSDP peers:
-----------------	---

```
switch(config)# show ip msdp summary
MSDP Peer Status Summary for VRF "default"
Local ASN: 0, originator-id: 0.0.0.0

Number of configured peers: 1
Number of established peers: 0
Number of shutdown peers: 0

Peer          Peer      Connection      Uptime/    Last msg   (S,G)s
Address       ASN       State         Downtime   Received  Received
192.168.1.10  8         Listening     01:35:13  never     0
switch(config)#

```

 show ip netstack mroute

show ip netstack mroute

To show IPv4 multicast routes in the Network Stack cache, use the **show ip netstack mroute** command.

show ip netstack mroute [vrf *vrf-name*]

Syntax Description	vrf <i>vrf-name</i> (Optional) Specifies the VRF name.				
Defaults	None				
Command Modes	Any command mode				
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(3)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(3)	This command was introduced.
Release	Modification				
4.0(3)	This command was introduced.				
Usage Guidelines	This command does not require a license.				
Examples	<p>This example shows how to display multicast routes in the Network Stack cache:</p> <pre>switch(config)# show ip netstack mroute (0.0.0.0/0, 225.1.1.1/32) Software switched packets: 1, bytes: 84 (4.1.1.2/32, 225.1.1.1/32), data-created Software switched packets: 2, bytes: 168 (0.0.0.0/0, 225.1.1.2/32) Software switched packets: 0, bytes: 0 (4.1.1.2/32, 225.1.1.2/32), data-created Software switched packets: 5, bytes: 420 (0.0.0.0/0, 225.1.1.3/32) Software switched packets: 0, bytes: 0 (4.1.1.2/32, 225.1.1.3/32), data-created Software switched packets: 2, bytes: 168 (0.0.0.0/0, 225.1.1.4/32) Software switched packets: 0, bytes: 0 (4.1.1.2/32, 225.1.1.4/32), data-created Software switched packets: 2, bytes: 168 (0.0.0.0/0, 225.1.1.5/32) Software switched packets: 0, bytes: 0 (4.1.1.2/32, 225.1.1.5/32), data-created Software switched packets: 2, bytes: 168 (0.0.0.0/0, 226.1.1.1/32)</pre>				

Send document comments to nexus7k-docfeedback@cisco.com.

```
Software switched packets: 0, bytes: 0  
(0.0.0.0/0, 226.2.2.2/32)  
Software switched packets: 0, bytes: 0  
(0.0.0.0/0, 232.0.0.0/8)  
Software switched packets: 0, bytes: 0  
switch(config) #
```

 show ip pim df

show ip pim df

To display information about the designated forwarders (DFs) for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim df** command.

show ip pim df [rp-or-group] [vrf {vrf-name | all}]

Syntax Description	<p><i>rp-or-group</i> (Optional) RP or group address.</p> <p>vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance.</p> <p><i>vrf-name</i> VRF name.</p> <p>all Specifies all VRFs.</p>
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM DFs:
-----------------	--

```
switch(config)# show ip pim df
Bidir-PIM Designated Forwarder Information for VRF "default"

RP Address (ordinal)    DF-bits          RP Metric   Group Range
2.2.2.2 (2)              00000002 (1)    [0/0]        224.128.0.0/9

Interface                DF Address      DF State     DF Metric   DF Uptime
Loopback0                 1.1.1.1         Winner       [0/0]      00:28:14
Ethernet2/2                10.2.0.2        Lose        [0/0]      00:28:14

switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim event-history

To display information in the IPv4 Protocol Independent Multicast (PIM) event history buffers, use the **show ip pim event-history** command.

show ip pim event-history {errors | msgs | statistics}

Syntax Description	errors Displays events of type error. msgs Displays events of type msg. statistics Displays events of type statistics.						
Defaults	None						
Command Modes	Any command mode						
Supported User Roles	network-admin network-operator vdc-admin vdc-operator						
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.1(2)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.1(2)	This command was introduced.		
Release	Modification						
4.1(2)	This command was introduced.						
Usage Guidelines	This command does not require a license.						
Examples	<p>This example shows how to display information in the PIM msgs event history buffer:</p> <pre>switch(config)# show ip pim event-history msgs Note: PIM process currently not running switch(config)# </pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>clear ip pim event-history</td><td>Clears the contents of the PIM event history buffers.</td></tr> <tr> <td>ip pim event-history</td><td>Configures the size of PIM event history buffers.</td></tr> </tbody> </table>	Command	Description	clear ip pim event-history	Clears the contents of the PIM event history buffers.	ip pim event-history	Configures the size of PIM event history buffers.
Command	Description						
clear ip pim event-history	Clears the contents of the PIM event history buffers.						
ip pim event-history	Configures the size of PIM event history buffers.						

 show ip pim group-range

show ip pim group-range

To display information about the group ranges for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim group-range** command.

show ip pim group-range [group] [vrf {vrf-name | all}]

Syntax Description

group	(Optional) Group address.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about PIM group ranges:

```
switch(config)# show ip pim group-range
PIM Group-Range Configuration for VRF "default"
Group-range      Mode      RP-address      Shared-tree-only range
239.128.1.0/24   SSM       -              -
224.0.0.0/9      ASM       192.0.2.33    -
switch(config)#

```

Related Commands

Command	Description
ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim interface

To display information about the enabled interfaces for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim interface** command.

show ip pim interface [brief] [vrf {vrf-name | all}]

show ip pim interface if-type if-number

Syntax Description	brief (Optional) Specifies a brief format for display. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs. if-type Interface type. For more information, use the question mark (?) online help function. if-number Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.
	5.0(2)	Information on Bidirectional Forwarding Detection (BFD) was added.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM-enabled interfaces:
	<pre>switch(config)# show ip pim interface ethernet 2/11 PIM Interface Status for VRF "default" Ethernet2/11, Interface status: protocol-down/link-down/admin-up IP address: 192.168.1.222, IP subnet: 192.168.1.0/24 PIM DR: 192.168.1.222, DR's priority: 5 PIM neighbor count: 0 PIM hello interval: 30 secs, next hello sent in: 00:00:03 PIM neighbor holdtime: 105 secs</pre>

show ip pim interface

```

PIM configured DR priority: 5
PIM border interface: no
PIM GenID sent in Hellos: 0x112ba48b
PIM Hello MD5-AH Authentication: enabled
PIM Neighbor policy: my_neighbor_policy
PIM Join-Prune policy: none configured
PIM BFD Enabled: Yes
PIM Interface Statistics, last reset: never
    General (sent/received):
        Hellos: 3145/0, JPs: 0/0, Asserts: 0/0
        Grafts: 0/0, Graft-Acks: 0/0
        DF-Offers: 0/0, DF-Winners: 0/0, DF-Backoffs: 0/0, DF-Passes: 0/0
    Errors:
        Checksum errors: 0, Invalid packet types/DF subtypes: 0/0
        Authentication failed: 0
        Packet length errors: 0, Bad version packets: 0, Packets from self: 0
        Packets from non-neighbors: 0
        JPs received on RPF-interface: 0
        (*,G) Joins received with no/wrong RP: 0/0
        (*,G)/(S,G) JPs received for SSM/Bidir groups: 0/0
        JPs policy filtered: 0
switch(config)#

```

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim neighbor

To display information about IPv4 Protocol Independent Multicast (PIM) neighbors, use the **show ip pim neighbor** command.

show ip pim neighbor {[if-type if-number] | [neighbor-addr]} [vrf {vrf-name | all}]

Syntax Description	<p>if-type (Optional) Interface type. For more information, use the question mark (?) online help function.</p> <p>if-number (Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.</p> <p>neighbor-addr (Optional) IP address of a neighbor.</p> <p>vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance.</p> <p>vrf-name VRF name.</p> <p>all Specifies all VRFs.</p>
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.
	5.0(2)	Information on Bidirectional Forwarding Detection (BFD) was added.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM neighbors:
	<pre>switch(config)# show ip pim neighbor PIM Neighbor Status for VRF "default" Neighbor Interface Uptime Expires DR Bidir- Priority Capable 2.1.1.2 Ethernet2/2 07:53:06 00:01:40 1 yes BFD-Enabled (Up/Down) switch(config)# </pre>

■ **show ip pim neighbor**

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim oif-list

To display information about IPv4 Protocol Independent Multicast (PIM) interfaces for a group, use the **show ip pim oif-list** command.

show ip pim oif-list *group* [*source*] [vrf** {*vrf-name* | **all**}]**

Syntax Description	<i>group</i> Group address. <i>source</i> (Optional) Source address. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs.
--------------------	---

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
----------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.
	4.1(3)	Changed output to include vPC information.

Usage Guidelines	This command requires the Enterprise Services license.
------------------	--

Examples	This example shows how to display PIM interfaces for a group:
	<pre>switch(config)# show ip pim oif-list 225.1.1.1 PIM OIF-List for VRF default (*, 225.1.1.1/32) Incoming interface: Ethernet2/1, RPF nbr 4.1.1.1 Timeout interval: 38 secs left Oif-list (count: 0): (1) 00000010 Timeout-list (count: 0): (0) 00000000 Immediate-list (count: 0): Immediate-timeout-list (count: 0): Assert-lost-list (count: 1): Vlan5 switch(config)# </pre>

■ **show ip pim oif-list**

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim policy statistics auto-rp

To display information about the Auto-RP policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics auto-rp** command.

```
show ip pim policy statistics auto-rp {rp-candidate-policy | mapping-agent-policy} [vrf {vrf-name | all}]
```

Syntax Description	rp-candidate-policy Specifies candidate-RP messages. mapping-agent-policy Specifies mapping agent messages. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM policy statistics:
-----------------	--

```
switch(config)# show ip pim policy statistics auto-rp rp-candidate-policy
C: No. of comparisions, M: No. of matches

route-map rpolicy permit 1
    match ip multicast group 225.1.1.0/24          C: 0      M: 0

Total accept count for policy: 0
Total reject count for policy: 0
switch(config)#

```

```
■ show ip pim policy statistics auto-rp
```

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim policy statistics bsr

To display information about the bootstrap router (BSR) policy statistics for IPv4 Protocol Independent multicast (PIM), use the **show ip pim policy statistics bsr** command.

show ip pim policy statistics bsr {bsr-policy | rp-candidate-policy} [vrf {vrf-name | all}]

Syntax Description	bsr-policy Specifies BSR messages. rp-candidate-policy Specifies candidate-RP messages. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
Defaults	None
Command Modes	Any command mode
Supported User Roles	network-admin network-operator vdc-admin vdc-operator
Command History	Release Modification 4.0(1) This command was introduced.
Usage Guidelines	This command requires the Enterprise Services license.
Examples	<p>This example shows how to display information about PIM policy statistics:</p> <pre>switch(config)# show ip pim policy statistics bsr bsr-policy C: No. of comparisions, M: No. of matches route-map rpolicy permit 1 match ip multicast group 225.1.1.0/24 C: 0 M: 0 Total accept count for policy: 0 Total reject count for policy: 0 switch(config)# </pre>

```
■ show ip pim policy statistics bsr
```

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim policy statistics jp-policy

To display information about the join-prune policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics jp-policy** command.

show ip pim policy statistics jp-policy *if-type if-number*

Syntax Description	<i>if-type</i> Interface type. For more information, use the question mark (?) online help function. <i>if-number</i> Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM policy statistics:
-----------------	--

```
switch(config)# show ip pim policy statistics jp-policy ethernet 2/12
C: No. of comparisions, M: No. of matches

route-map rpolicy permit 1
  match ip multicast group 225.1.1.0/24          C: 0      M: 0
Total accept count for policy: 0
Total reject count for policy: 0
switch(config)#

```

■ **show ip pim policy statistics jp-policy**

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim policy statistics neighbor-policy

To display information about the neighbor policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics neighbor-policy** command.

show ip pim policy statistics neighbor-policy *if-type if-number*

Syntax Description	<i>if-type</i> Interface type. For more information, use the question mark (?) online help function. <i>if-number</i> Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM policy statistics:
-----------------	--

```
switch(config)# show ip pim policy statistics neighbor-policy ethernet 2/12
C: No. of comparisions, M: No. of matches

route-map rpolicy permit 1
  match ip multicast group 225.1.1.0/24          C: 0      M: 0
Total accept count for policy: 0
Total reject count for policy: 0
switch(config)#

```

■ **show ip pim policy statistics neighbor-policy**

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim policy statistics register-policy

To display information about the register policy statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim policy statistics register-policy** command.

show ip pim policy statistics register-policy [vrf {vrf-name | all}]

Syntax Description	vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM policy statistics: <pre>switch(config)# show ip pim policy statistics register-policy vrf all C: No. of comparisions, M: No. of matches route-map rmap1 permit 10 match ip multicast group 225.1.1.0/24 C: 0 M: 0 Total accept count for policy: 0 Total reject count for policy: 0 switch(config)#</pre>
-----------------	---

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

 show ip pim route

show ip pim route

To display information about the routes for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim route** command.

show ip pim route {source group | group [source]} [vrf {vrf-name | all}]

Syntax Description

<i>source</i>	Source address.
<i>group</i>	Group address.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display PIM routes:

```
switch(config)# show ip pim route 224.1.1.1
PIM Routing Table for VRF "default" - 6 entries

(*, 224.0.0.0/4), RP 1.1.1.1*, bidir, expires 00:00:59, RP-bit
  Incoming interface: loopback4, RPF nbr 1.1.1.1
  Oif-list: (0) 00000000, timeout-list: (0) 00000000
  Timeout-interval: 1, JP-holdtime round-up: 3

(*, 225.0.0.1/32), RP 1.1.1.1*, bidir, expires 0.000000 (00:00:06), RP-bit
  Incoming interface: loopback4, RPF nbr 1.1.1.1
  Oif-list: (0) 00000000, timeout-list: (0) 00000000
  Timeout-interval: 1, JP-holdtime round-up: 3

(*, 225.0.1.1/32), RP 1.1.1.1*, bidir, expires 0.000000 (00:00:06), RP-bit
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
Incoming interface: loopback4, RPF nbr 1.1.1.1
Oif-list: (0) 00000000, timeout-list: (0) 00000000
Timeout-interval: 1, JP-holdtime round-up: 3
```

```
switch(config)#
```

Related Commands

Command	Description
clear ip pim event-history	Clears the contents of the PIM event history buffers.
ip pim event-history	Configures the size of PIM event history buffers.

show ip pim rp

show ip pim rp

To display information about the RPs for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim rp** command.

show ip pim rp [group] [vrf {vrf-name | all}]

Syntax Description

group	(Optional) Group address.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about PIM RPs:

```
switch(config)# show ip pim rp
PIM RP Status Information for VRF "default"
BSR: Not Operational
Auto-RP RPA: 192.168.1.222*, next Discovery message in: 00:00:06
BSR RP Candidate policy: my_bsr_rp_candidate_policy
BSR RP policy: my_bsr_policy
Auto-RP Announce policy: my_rp_candidate_policy
Auto-RP Discovery policy: my_mapping_agent_policy

Anycast-RP 192.0.2.3 members:
 192.0.2.31

RP: 192.0.2.33, (0), uptime: 04:08:11, expires: never,
 priority: 0, RP-source: (local), group ranges:
   224.0.0.0/9
switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

show ip pim rp-hash

To display information about the RP-hash values for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim rp-hash** command.

show ip pim rp-hash group [vrf {vrf-name | all}]

Syntax Description	<table border="1"> <tr> <td><i>group</i></td><td>Group address for RP lookup.</td></tr> <tr> <td>vrf</td><td>(Optional) Applies to a virtual routing and forwarding (VRF) instance.</td></tr> <tr> <td><i>vrf-name</i></td><td>VRF name.</td></tr> <tr> <td>all</td><td>Specifies all VRFs.</td></tr> </table>	<i>group</i>	Group address for RP lookup.	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	<i>vrf-name</i>	VRF name.	all	Specifies all VRFs.
<i>group</i>	Group address for RP lookup.								
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.								
<i>vrf-name</i>	VRF name.								
all	Specifies all VRFs.								
Defaults	None								
Command Modes	Any command mode								
Supported User Roles	network-admin network-operator vdc-admin vdc-operator								
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.				
Release	Modification								
4.0(1)	This command was introduced.								
Usage Guidelines	This command requires the Enterprise Services license.								
Examples	<p>This example shows how to display information about PIM RP-hash values:</p> <pre>switch(config)# show ip pim rp-hash 224.1.1.1 PIM Hash Information for VRF "default" PIM RPs for group 224.1.1.1, using hash-length: 0 from BSR: 10.2.0.1 RP 10.2.0.1, hash: 1894762513 (selected) switch(config)#</pre>								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>clear ip pim event-history</td><td>Clears the contents of the PIM event history buffers.</td></tr> <tr> <td>ip pim event-history</td><td>Configures the size of PIM event history buffers.</td></tr> </tbody> </table>	Command	Description	clear ip pim event-history	Clears the contents of the PIM event history buffers.	ip pim event-history	Configures the size of PIM event history buffers.		
Command	Description								
clear ip pim event-history	Clears the contents of the PIM event history buffers.								
ip pim event-history	Configures the size of PIM event history buffers.								

 show ip pim statistics

show ip pim statistics

To display information about the packet counter statistics for IPv4 Protocol Independent Multicast (PIM), use the **show ip pim statistics** command.

show ip pim statistics [vrf {vrf-name | all}]

Syntax Description	vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.
	4.1(3)	Changed output to include vPC information when PIM is in vPC mode.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM statistics (if PIM is not in vPC mode, the vPC statistics are not displayed):
-----------------	---

```
switch(config)# show ip pim statistics
PIM Global Counter Statistics for VRF:default, last reset: never
Register processing (sent/received):
  Registers: 0/0, Null registers: 0/0, Register-Stops: 0/0
  Registers received and not RP: 0
  Registers received for SSM/Bidir groups: 0/0
BSR processing (sent/received):
  Bootstraps: 0/0, Candidate-RPs: 0/0
  BSs from non-neighbors: 0, BSs from border interfaces: 0
  BS length errors: 0, BSs which RPF failed: 0
  BSs received but not listen configured: 0
  Cand-RPs from border interfaces: 0
  Cand-RPs received but not listen configured: 0
Auto-RP processing (sent/received):
  Auto-RP Announces: 0/0, Auto-RP Discoveries: 0/0
```

Send document comments to nexus7k-docfeedback@cisco.com.

```

Auto-RP RPF failed: 0, Auto-RP from border interfaces: 0
Auto-RP invalid type: 0, Auto-RP TTL expired: 0
Auto-RP received but not listen configured: 0
General errors:
  Control-plane RPF failure due to no route found: 0
  Data-plane RPF failure due to no route found: 0
  Data-plane no multicast state found: 0
  Data-plane create route state count: 2
vPC packet stats:
  assert requests sent: 1
  assert requests received: 1
  assert request send error: 0
  assert response sent: 1
  assert response received: 1
  assert response send error: 0
  assert stop sent: 0
  assert stop received: 1
  assert stop send error: 0
switch(config)#

```

Related Commands

Command	Description
clear ip pim event-history	Clears the contents of the PIM event history buffers.
ip pim event-history	Configures the size of PIM event history buffers.

show ip pim vrf

show ip pim vrf

To display information about IPv4 Protocol Independent Multicast (PIM) by virtual routing and forwarding (VRF) instance, use the **show ip pim vrf** command.

show ip pim vrf [vrf-name | all]

Syntax Description	<table border="0"> <tr> <td><i>vrf-name</i></td><td>(Optional) VRF name.</td></tr> <tr> <td>all</td><td>(Optional) Specifies all VRFs.</td></tr> </table>	<i>vrf-name</i>	(Optional) VRF name.	all	(Optional) Specifies all VRFs.
<i>vrf-name</i>	(Optional) VRF name.				
all	(Optional) Specifies all VRFs.				

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.
	5.0(2)	Information on Bidirectional Forwarding Detection (BFD) was added.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM by VRF:
-----------------	---

```
switch(config)# show ip pim vrf
PIM Enabled VRF
VRF Name          VRF      Table     Interface   BFD Enabled
                  ID       ID        Count
default           1        0x00000001  1          Yes
```

Related Commands	Command	Description
	clear ip pim event-history	Clears the contents of the PIM event history buffers.
	ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 mld groups

To display information about the Multicast Listener Discovery (MLD) attached-group membership, use the **show ipv6 mld groups** command.

```
show ipv6 [icmp] mld groups [{source [group]} | {group [source]}] [if-type if-number] [vrf {vrf-name | all}]
```

Syntax Description	icmp (Optional) Specifies ICMPv6 commands.
source	IPv6 source address.
group	(Optional) IPv6 multicast group address.
if-type	(Optional) Interface type. For more information, use the question mark (?) online help function.
if-number	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
vrf-name	VRF name.
all	Specifies all VRFs.

Defaults None

Command Modes Any command mode

Supported User Roles
network-admin
network-operator
vdc-admin
vdc-operator

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines This command requires the Enterprise Services license.

Examples This example shows how to display information about the MLD group membership:

```
switch(config)# show ipv6 mld groups
MLD Connected Group Membership for VRF "default" - 13 total entries (*, ff13::0001)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:25/00:03:54, Last Reporter: fe80::0230:48ff:fe34:0d5b
```

show ipv6 mld groups

```

(*, ff13::0002)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:21/00:03:58, Last Reporter: fe80::0230:48ff:fe34:0d5b

(*, ff13::0003)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:22/00:03:57, Last Reporter: fe80::0230:48ff:fe34:0d5b

(*, ff13::0004)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:23/00:03:56, Last Reporter: fe80::0230:48ff:fe34:0d5b

(*, ff13::0005)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:24/00:03:55, Last Reporter: fe80::0230:48ff:fe34:0d5b

(*, ff13::0006)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:25/00:03:54, Last Reporter: fe80::0230:48ff:fe34:0d5b

(*, ff13::0007)
  Type: Local, Interface: Ethernet2/1
  Uptime/Expires: 00:00:27/00:03:52, Last Reporter: fe80::0230:48ff:fe34:0d5b
switch(config)#

```

Related Commands

Command	Description
clear ip pim event-history	Clears the contents of the PIM event history buffers.
ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 mld local-groups

To display information about the local group membership for Multicast Listener Discovery (MLD), use the **show ipv6 mld local-groups** command.

show ipv6 [icmp] mld local-groups [if-type if-number] [vrf {vrf-name | all}]

Syntax Description	icmp (Optional) Specifies ICMPv6 commands. if-type (Optional) Interface type. For more information, use the question mark (?) online help function. if-number (Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
Defaults	None
Command Modes	Any command mode
Supported User Roles	network-admin network-operator vdc-admin vdc-operator
Command History	Release Modification 4.0(1) This command was introduced.
Usage Guidelines	This command requires the Enterprise Services license.
Examples	This example shows how to display information about MLD local groups: <pre>switch(config)# show ipv6 mld local-groups MLD Locally Joined Group Membership for VRF "default" Group Type Interface Last Reported (*, ff13::0001) Local Eth2/1 00:00:55 (*, ff13::0002) Local Eth2/1 00:00:46 (*, ff13::0003) Local Eth2/1 00:00:54</pre>

show ipv6 mld local-groups

```
(*, ff13::0004)
    Local    Eth2/1      00:00:51
(*, ff13::0005)
    Local    Eth2/1      00:00:49
(*, ff13::0006)
    Local    Eth2/1      00:00:46
(*, ff13::0007)
    Local    Eth2/1      00:00:54
(*, ff13::0008)
    Local    Eth2/1      00:00:52
(*, ff13::0009)
    Local    Eth2/1      00:00:50
(*, ff13::0010)
    Local    Eth2/1      00:00:48
(*, ff14::0001)
    Local    Eth2/1      00:00:46
(*, ff1e::0001)
    Local    Eth2/1      00:00:55
(*, ff1e::0002)
    Static   Lo22       03:47:54
switch(config)#
```

Related Commands

Command	Description
clear ip pim event-history	Clears the contents of the PIM event history buffers.
ip pim event-history	Configures the size of PIM event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 mroute

To display information about IPv6 multicast routes, use the **show ipv6 mroute** command.

```
show ipv6 mroute {group | {source group} | {group [source]} } [summary [software-forwarded]]  
[vrf {vrf-name | all}]
```

Syntax Description

<i>group</i>	Group address for route.
<i>source</i>	Source address for route.
summary	(Optional) Displays route counts and packet rates.
software-forwarded	(Optional) Displays software-switched route counts only.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about multicast routes:

```
switch(config)# show ipv6 mroute  
IPv6 Multicast Routing Table for VRF "default"  
  
(*, ff30::/32), uptime: 1d02h, pim6 ipv6  
  Incoming interface: Null, RPF nbr: 0::  
  Outgoing interface list: (count: 0)  
  
switch(config) #
```

■ **show ipv6 mroute**

Related Commands	Command	Description
	show ipv6 mroute summary	Displays summary information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 mroute summary

To display summary information about IPv6 multicast routes, use the **show ipv6 mroute summary** command.

show ipv6 mroute summary [count | software-forwarded]] [vrf {vrf-name | all}]

show ipv6 mroute {group} summary [software-forwarded] [vrf {vrf-name | all}]

Syntax Description	count (Optional) Displays only route counts. software-forwarded (Optional) Displays software-switched route counts only. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs. group Specifies a group address for a route.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display summary information about multicast routes: <pre>switch(config)# show ipv6 mroute summary IPv6 Multicast Routing Table for VRF "default" Total number of routes: 1 Total number of (*,G) routes: 0 Total number of (S,G) routes: 0 Total number of (*,G-prefix) routes: 1 Group count: 0, rough average sources per group: 0.0</pre>
-----------------	--

show ipv6 mroute summary

```
Group: ff30::/32, Source count: 0
Source          packets      bytes      aps      pps      bit-rate   oifs
(*,G)           0           0           0           0       0 bps       0
switch(config)#
```

Related Commands

Command	Description
show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 pim df

To display information about the designated forwarders (DFs) for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim df** command.

show ipv6 pim df [rp-or-group] [vrf {vrf-name | all}]

Syntax Description	<p>rp-or-group (Optional) RP or group address.</p> <p>vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance.</p> <p>vrf-name VRF name.</p> <p>all Specifies all VRFs.</p>
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6 DFs:
	<pre>switch(config)# show ipv6 pim df Bidir-PIM6 Designated Forwarder Information for VRF "default" RP Address (ordinal) RP Metric Group Range 0001::0001 (7) [0/0] ff00::/8 Interface DF Address DF State DF Metric DF Uptime * Lo1 0:: Lose [0/0] 00:00:02 switch(config)# </pre>

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim event-history

show ipv6 pim event-history

To display information in the IPv6 Protocol Independent Multicast (PIM6) event history buffers, use the **show ipv6 pim event-history** command.

show ipv6 pim event-history {errors | msgs | statistics}

Syntax Description	<table border="1"> <tr> <td>errors</td><td>Displays events of type error.</td></tr> <tr> <td>msgs</td><td>Displays events of type msg.</td></tr> <tr> <td>statistics</td><td>Displays events of type statistics.</td></tr> </table>	errors	Displays events of type error.	msgs	Displays events of type msg.	statistics	Displays events of type statistics.
errors	Displays events of type error.						
msgs	Displays events of type msg.						
statistics	Displays events of type statistics.						
Defaults	None						
Command Modes	Any command mode						
SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.1(2)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.1(2)	This command was introduced.		
Release	Modification						
4.1(2)	This command was introduced.						
Usage Guidelines	This command does not require a license.						
Examples	<p>This example shows how to display information in the PIM6 msgs event history buffer:</p> <pre>switch(config)# show ipv6 pim event-history msgs Note: PIM6 process currently not running switch(config)#+</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>clear ipv6 pim event-history</td> <td>Clears the contents of the PIM6 event history buffers.</td> </tr> <tr> <td>ipv6 pim event-history</td> <td>Configures the size of PIM6 event history buffers.</td> </tr> </tbody> </table>	Command	Description	clear ipv6 pim event-history	Clears the contents of the PIM6 event history buffers.	ipv6 pim event-history	Configures the size of PIM6 event history buffers.
Command	Description						
clear ipv6 pim event-history	Clears the contents of the PIM6 event history buffers.						
ipv6 pim event-history	Configures the size of PIM6 event history buffers.						

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 pim group-range

To display information about IPv6 Protocol Independent Multicast (PIM6) group ranges, use the **show ipv6 pim group-range** command.

show ipv6 pim group-range [group] [vrf {vrf-name | all}]

Syntax Description

group	(Optional) Group address.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
vrf-name	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

Supported User Roles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about PIM6 group ranges:

```
switch(config)# show ipv6 pim group-range
PIM6 Group-Range Configuration for VRF "default"
Group-range          Mode      RP-address      Shared-tree-only range
ff30::/32            SSM       -              -
ff1e:abcd:def1::/96   ASM       2001:0db8:0000:abcd::0001
                                         -
switch(config) #
```

Related Commands

Command	Description
show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim interface

show ipv6 pim interface

To display information about the enabled interfaces for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim interface** command.

show ipv6 pim interface [brief] [vrf {vrf-name | all}]

show ipv6 pim interface if-type if-number

Syntax Description	brief (Optional) Specifies a brief format for display. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs. if-type (Optional) Interface type. For more information, use the question mark (?) online help function. if-number (Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
--------------------	---

Defaults	None
Command Modes	Any command mode

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6-enabled interfaces:
-----------------	--

```
switch(config)# show ipv6 pim interface
PIM6 Interface Status for VRF "default"
Ethernet2/12, Interface status: protocol-down/link-down/admin-down
  IPv6 address: none
  PIM6 DR: 0::, DR's priority: ?
  PIM6 neighbor count: 0
  PIM6 hello interval: 23 secs (configured 22222 ms), next hello sent in: 00:00:08
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
PIM6 neighbor holdtime: 81 secs
PIM6 configured DR priority: 1
PIM6 border interface: no
PIM6 GenID sent in Hellos: 0x144b4667
PIM6 Hello MD5-AH Authentication: disabled
PIM6 Neighbor policy: none configured
PIM6 Join-Prune policy: none configured
PIM6 Interface Statistics, last reset: never
    General (sent/received):
        Hellos: 0/0, JPs: 0/0, Asserts: 0/0
        Grafts: 0/0, Graft-Acks: 0/0
        DF-Offers: 0/0, DF-Winners: 0/0, DF-Backoffs: 0/0, DF-Passes: 0/0
    Errors:
        Checksum errors: 0, Invalid packet types/DF subtypes: 0/0
        Authentication failed: 0
        Packet length errors: 0, Bad version packets: 0, Packets from self: 0
        Packets from non-neighbors: 0
        JPs received on RPF-interface: 0
        (*,G) Joins received with no/wrong RP: 0/0
        (*,G)/(S,G) JPs received for SSM/Bidir groups: 0/0
        JPs policy filtered: 0
switch(config)#
```

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim neighbor

show ipv6 pim neighbor

To display information about IPv6 Protocol Independent Multicast (PIM6) neighbors, use the **show ipv6 pim neighbor** command.

show ipv6 pim neighbor {[if-type if-number] | [neighbor-addr]} [vrf {vrf-name | all}]

Syntax Description	<code>if-type</code> (Optional) Interface type. For more information, use the question mark (?) online help function. <code>if-number</code> (Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function. <code>neighbor-addr</code> (Optional) IPv6 address of a neighbor. <code>vrf</code> (Optional) Applies to a virtual routing and forwarding (VRF) instance. <code>vrf-name</code> VRF name. <code>all</code> Specifies all VRFs.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				

Usage Guidelines This command requires the Enterprise Services license.

Examples This example shows how to display information about PIM6 neighbors:

```
switch(config)# show ipv6 pim neighbor
PIM6 Neighbor Status for VRF "default"
Neighbor Address           Interface      Uptime     Expires   DR      Bidir
                                         Pri
fe80::0230:48ff:fe34:0d67    Eth2/1       00:00:39  00:01:34  1      yes
  Secondary addresses:
    0001::0002
switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim oif-list

show ipv6 pim oif-list

To display information about IPv6 Protocol Independent Multicast (PIM6) interfaces for a group, use the **show ipv6 pim oif-list** command.

show ipv6 pim oif-list *group* [*source*] [vrf** {*vrf-name* | **all**}]**

Syntax Description	<i>group</i> Group address. <i>source</i> (Optional) Source address. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs.
--------------------	---

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
--------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
------------------	--

Examples	This example shows how to display PIM6 interfaces for a group:
	<pre>switch(config)# show ipv6 pim oif-list ff1e::0002 PIM6 OIF-List for VRF default (*, ff1e::0002/128) Incoming interface: Ethernet2/2, RPF nbr 0002::0002 Timeout interval: 45 secs left Oif-list (count: 2): Ethernet8/11, uptime: 00:01:18, pim6 Ethernet8/11, uptime: 00:01:18, pim6 Timeout-list (count: 0): Immediate-list (count: 0): Immediate-timeout-list (count: 0): switch(config)# </pre>

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

■ **show ipv6 pim policy statistics jp-policy**

show ipv6 pim policy statistics jp-policy

To display information about the join-prune policy statistics for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim policy statistics j-policy** command.

show ipv6 pim policy statistics jp-policy *if-type if-number*

Syntax Description	<p><i>if-type</i> Interface type. For more information, use the question mark (?) online help function.</p> <p><i>if-number</i> Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.</p>
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6 policy statistics:	
	switch(config)# show ipv6 pim policy statistics jp-policy ethernet 2/2	C: No. of comparisions, M: No. of matches
	route-map rmap1 permit 10	C: 0 M: 0
	match ipv6 multicast group ff1e::/128	
	Total accept count for policy: 2	
	Total reject count for policy: 0	
	switch(config)#	

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 pim policy statistics neighbor-policy

To display information about the neighbor policy statistics for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim policy statistics neighbor-policy** command.

show ipv6 pim policy statistics neighbor-policy *if-type if-number*

Syntax Description	<i>if-type</i> Interface type. For more information, use the question mark (?) online help function. <i>if-number</i> Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6 policy statistics:
-----------------	---

```
switch(config)# show ipv6 pim policy statistics neighbor-policy ethernet 2/2
C: No. of comparisions, M: No. of matches

route-map rmap2 permit 10
  match ipv6 multicast group ff1e::/128          C: 0      M: 0
                                         Total accept count for policy: 2
                                         Total reject count for policy: 0
switch(config)#

```

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim route

show ipv6 pim route

To display information about IPv6 Protocol Independent Multicast (PIM6) routes, use the **show ipv6 pim route** command.

show ipv6 pim route {*source group* | *group [source]*} [**vrf** {*vrf-name* | **all**}]

Syntax Description	<i>source</i> Source address. <i>group</i> Group address. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs.
--------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display PIM6 routes:
<pre>switch(config)# show ipv6 pim route PIM6 Routing Table for VRF "default" - 1 entries (*, ff30::/32), expires 00:02:33 Incoming interface: Null, RPF nbr 0:: Oif-list: (0) 00000000, timeout-list: (0) 00000000 Immediate-list: (0) 00000000, timeout-list: (0) 00000000 Timeout-interval: 2, JP-holdtime round-up: 3 switch(config)# </pre>	

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 pim rp

To display information about IPv6 Protocol Independent Multicast (PIM) RPs, use the **show ipv6 pim rp** command.

show ipv6 pim rp [group] [vrf {vrf-name | all}]

Syntax Description	<table border="0"> <tr> <td>group</td><td>(Optional) Group address.</td></tr> <tr> <td>vrf</td><td>(Optional) Applies to a virtual routing and forwarding (VRF) instance.</td></tr> <tr> <td>vrf-name</td><td>VRF name.</td></tr> <tr> <td>all</td><td>Specifies all VRFs.</td></tr> </table>	group	(Optional) Group address.	vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	vrf-name	VRF name.	all	Specifies all VRFs.
group	(Optional) Group address.								
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.								
vrf-name	VRF name.								
all	Specifies all VRFs.								

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	<p>This example shows how to display information about PIM6 RPs:</p> <pre>switch(config)# show ipv6 pim rp PIM6 RP Status Information for VRF "default" BSR: 0::, uptime: 1d01h, expires: now, priority: 0, hash-length: 0 Auto-RP disabled BSR RP Candidate policy: None BSR RP policy: None Auto-RP Announce policy: None Auto-RP Discovery policy: None RP: 2001:0db8:0000:abcd::0001, (0), uptime: 1d01h, expires: 0.000000, priority: 0, RP-source: (local), group ranges: ff1e:abcd:def1::/96 switch(config)# </pre>
-----------------	---

■ **show ipv6 pim rp**

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show ipv6 pim rp-hash

To display information about the RP-hash values for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim rp-hash** command.

show ipv6 pim rp-hash *group* [vrf {*vrf-name* | all}]

Syntax Description

group	Group address for the RP lookup.
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.

Defaults

None

Command Modes

Any command mode

Supported User Roles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about PIM6 RP-hash values:

```
switch(config)# show ipv6 pim rp-hash
PIM6 Hash Information for VRF "default"
PIM6 RPs for group ff1e::0001, using hash-length: 126 from BSR: 0001::0001
  RP 0002::0001, hash: 1329585728 (selected)

show ip igmp snooping explicit-tracking
-----
switch# show ip igmp snooping explicit-tracking vlan 33
IGMPv3 Snooping Explicit-tracking information
Source/Group          Intf    Reporter        Uptime   Last-Join Expires
1.1.1.1 232.1.1.1     Eth2/1  3.3.3.3       00:01:33  00:04:27
switch(config)#

```

 show ipv6 pim statistics

show ipv6 pim statistics

To display information about the packet counter statistics for IPv6 Protocol Independent Multicast (PIM6), use the **show ipv6 pim statistics** command.

show ipv6 pim statistics [vrf {vrf-name | all}]

Syntax Description	vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. vrf-name VRF name. all Specifies all VRFs.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6 statistics:
-----------------	--

```
switch(config)# show ipv6 pim statistics
PIM6 Global Counter Statistics for VRF:default, last reset: never
  Register processing (sent/received):
    Registers: 0/0, Null registers: 0/0, Register-Stops: 0/0
    Registers received and not RP: 0
    Registers received for SSM/Bidir groups: 0/0
  BSR processing (sent/received):
    Bootstraps: 0/0, Candidate-RPs: 0/0
    BSs from non-neighbors: 0, BSs from border interfaces: 0
    BS length errors: 0, BSs which RPF failed: 0
    BSs received but not listen configured: 0
    Cand-RPs from border interfaces: 0
    Cand-RPs received but not listen configured: 0
  Auto-RP processing (sent/received):
    Auto-RP Announces: 0/0, Auto-RP Discoveries: 0/0
    Auto-RP RPF failed: 0, Auto-RP from border interfaces: 0
    Auto-RP invalid type: 0, Auto-RP TTL expired: 0
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
Auto-RP received but not listen configured: 0
General errors:
  Control-plane RPF failure due to no route found: 1
  Data-plane RPF failure due to no route found: 0
  Data-plane no multicast state found: 0
  Data-plane create route state count: 0
switch(config)#

```

Related Commands

Command	Description
show ipv6 mroute	Displays information about IPv6 multicast routes.

 show ipv6 pim vrf

show ipv6 pim vrf

To display information about IPv6 Protocol Independent Multicast (PIM6) by virtual routing and forwarding (VRF) instance, use the **show ipv6 pim vrf** command.

show ipv6 pim vrf [vrf-name | all]

Syntax Description	<table border="0"> <tr> <td><i>vrf-name</i></td><td>(Optional) VRF name.</td></tr> <tr> <td>all</td><td>(Optional) Specifies all VRFs.</td></tr> </table>	<i>vrf-name</i>	(Optional) VRF name.	all	(Optional) Specifies all VRFs.
<i>vrf-name</i>	(Optional) VRF name.				
all	(Optional) Specifies all VRFs.				

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about PIM6 by VRF:
	<pre>switch(config)# show ipv6 pim vrf switch(config)#+</pre>

Related Commands	Command	Description
	show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show routing ip multicast event-history

To display information in the IPv4 Multicast Routing Information Base (MRIB) event history buffers, use the **show routing ip multicast event-history** command.

show routing ip multicast event-history {cli | errors | mfdm | mfdm-stats | msgs | rib | statistics | vrf}

Syntax Description	cli Displays the event history buffer of type CLI. errors Displays the event history buffer of type errors. mfdm Displays the event history buffer of type multicast FIB distribution (MFDM). mfdm-stats Displays the event history buffer of type MFDM sum. msgs Displays the event history buffer of type msgs. rib Displays the event history buffer of type RIB. statistics Displays information about the event history buffers. vrf Displays the event history buffer of type virtual routing and forwarding (VRF).
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command does not require a license.
-------------------------	--

Examples	This example shows how to display information in the MRIB msgs event history buffer: <pre>switch(config)# show routing ip multicast event-history msgs</pre> Msg events for MRIB Process 1) Event:E_DEBUG, length:38, at 219263 usecs after Wed Jan 7 17:16:45 2009 [100] : nvdb: transient thread created 2) Event:E_DEBUG, length:38, at 217482 usecs after Wed Jan 7 17:16:45 2009 [100] : nvdb: create transient thread
-----------------	---

■ **show routing ip multicast event-history**

```

3) Event:E_DEBUG, length:76, at 217477 usecs after Wed Jan  7 17:16:45 2009
   [100] : comp-mts-rx opc - from sap 27315 cmd mrib_internal_event_hist_command
4) Event:E_MTS_RX, length:60, at 535173 usecs after Wed Jan  7 17:16:36 2009
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X0021C74B, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1575, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0021C749, Sync:NONE, Payloadsize:120
   Payload:
   0x0000: 01 00 00 00 04 00 01 00 00 04 00 00 00 00 00 00 00
5) Event:E_MTS_RX, length:60, at 675244 usecs after Wed Jan  7 17:15:47 2009
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X0021C283, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1575, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0021C281, Sync:NONE, Payloadsize:148
   Payload:
   0x0000: 02 00 00 00 05 00 01 00 00 04 00 00 00 00 00 00 00
6) Event:E_MTS_RX, length:60, at 525065 usecs after Wed Jan  7 17:15:36 2009
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X0021C1F7, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1575, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0021C1F5, Sync:NONE, Payloadsize:120
   Payload:
   0x0000: 01 00 00 00 04 00 01 00 00 04 00 00 00 00 00 00 00
7) Event:E_MTS_RX, length:60, at 665138 usecs after Wed Jan  7 17:14:47 2009
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X0021BCBB, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1575, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0021BCB9, Sync:NONE, Payloadsize:148
   Payload:
   0x0000: 02 00 00 00 05 00 01 00 00 04 00 00 00 00 00 00 00
8) Event:E_MTS_RX, length:60, at 515080 usecs after Wed Jan  7 17:14:36 2009
   [RSP] Opc:MTS_OPC_MFDM_V4_ROUTE_STATS(75785), Id:0X0021BC34, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1575, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0021BC32, Sync:NONE, Payloadsize:120
   Payload:
   0x0000: 01 00 00 00 04 00 01 00 00 04 00 00 00 00 00 00 00
switch(config)#

```

Related Commands

Command	Description
ip routing multicast event-history	Configures the size of the IPv4 MRIB event history buffers.
clear ip routing multicast event-history	Clears information in the IPv4 MRIB event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show hardware proxy layer-3 detail

To display detail proxy Layer 3 forwarding information, use the **show hardware proxy layer-3 detail** command.

show hardware proxy layer-3 detail

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes EXEC

SupportedUserRoles network-admin
vdc-admin

Command History	Release	Modification
	5.1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

This command applies only to Cisco Nexus 7000 Series chassis that contain an F1 Series module or an M1 Series module. This command applies when you are running either FabricPath or Ethernet interfaces.

Examples This example shows how to display detail proxy Layer 3 forwarding information:

```
switch# show hardware proxy layer-3 detail
switch#
```

Related Commands	Command	Description
	show hardware proxy layer-3 detail	Displays detailed information on the proxy Layer 3 functionality.

 show routing ipv6 multicast

show routing ipv6 multicast

To display information about IPv6 multicast routes, use the **show routing ipv6 multicast** command.

```
show routing ipv6 multicast [vrf {vrf-name | all}] {{source group} | {group [source]}}
```

Syntax Description

vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
<i>vrf-name</i>	VRF name.
all	Specifies all VRFs.
<i>source</i>	Source address for routes.
<i>group</i>	Group address for routes.

Defaults

None

Command Modes

Any command mode

SupportedUserRoles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about IPv6 multicast routes:

```
switch(config)# show routing ipv6 multicast
IPv6 Multicast Routing Table for VRF "default"
switch(config)#+
```

Related Commands

Command	Description
show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show routing ipv6 multicast clients

To display information about IPv6 multicast routing clients, use the **show routing ipv6 multicast clients** command.

show routing ipv6 multicast clients [client-name]

Syntax Description	<i>client-name</i> (Optional) One of the following multicast routing client names: <ul style="list-style-type: none"> • m6rib • icmpv6 • ipv6 • static • pim6 				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command requires the Enterprise Services license.				
Examples	<p>This example shows how to display information about IPv6 multicast routing clients:</p> <pre>switch(config)# show routing ipv6 multicast clients icmpv6 IPv6 Multicast Routing Client information Client: icmpv6, client-id: 2, pid: 3742, mts-sap: 282 Shared-memory: icmpv6, wants notifications Protocol is join-group owner Join notifications: sent 1, fail 0, ack rcvd 1 Prune notifications: sent 0, fail 0, ack rcvd 0 RPF notifications: sent 0, fail 0, ack rcvd 0 Delete notifications: sent 0, fail 0, ack rcvd 0 Clear mroute notifications: sent 0, fail 0 Add route requests: rcvd 0, ack sent 0, ack fail 0</pre>				

```
■ show routing ipv6 multicast clients
```

```
    Delete route requests:      rcvd 0, ack sent 0, ack fail 0
switch(config) #
```

Related Commands

Command	Description
show ipv6 mroute	Displays information about IPv6 multicast routes.

Send document comments to nexus7k-docfeedback@cisco.com.

show routing ipv6 multicast event-history

To display information in the IPv6 Multicast Routing Information Base (M6RIB) event history buffers, use the **show routing ipv6 multicast event-history** command.

```
show routing ipv6 multicast event-history {cli | errors | mfdm | mfdm-stats | msgs | rib | statistics | vrf}
```

Syntax Description	cli Displays the event history buffer of type CLI. errors Displays the event history buffer of type errors. mfdm Displays the event history buffer of type multicast FIB distribution (MFDM). mfdm-stats Displays the event history buffer of type MFDM sum. msgs Displays the event history buffer of type msgs. rib Displays the event history buffer of type RIB. statistics Displays information about the event history buffers. vrf Displays the event history buffer of type virtual routing and forwarding (VRF).
--------------------	---

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
--------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command does not require a license.
------------------	--

Examples	This example shows how to display information in the M6RIB msgs event history buffer: <pre>switch(config)# show routing ipv6 multicast event-history msgs</pre> <pre>Msg events for M6RIB Process 1) Event:E_DEBUG, length:38, at 269000 usecs after Tue Jan 6 18:45:50 2009 [100] : nvdb: transient thread created 2) Event:E_DEBUG, length:38, at 267467 usecs after Tue Jan 6 18:45:50 2009 [100] : nvdb: create transient thread</pre>
----------	--

■ **show routing ipv6 multicast event-history**

```

3) Event:E_DEBUG, length:76, at 267461 usecs after Tue Jan  6 18:45:50 2009
   [100] : comp-mts-rx opc - from sap 3389 cmd m6rib_internal_event_hist_command
4) Event:E_MTS_RX, length:60, at 335251 usecs after Tue Jan  6 18:45:21 2009
   [RSP] Opc:MTS_OPC_MFDM_V6_ROUTE_STATS(75786), Id:0X00049141, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1606, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0004913F, Sync:NONE, Payloadsize:268
   Payload:
   0x0000: 01 00 00 80 05 00 01 00 00 08 00 00 00 00 00 00 00 00 00 00 00
5) Event:E_MTS_RX, length:60, at 325401 usecs after Tue Jan  6 18:44:21 2009
   [RSP] Opc:MTS_OPC_MFDM_V6_ROUTE_STATS(75786), Id:0X000489A2, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1606, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x000489A0, Sync:NONE, Payloadsize:268
   Payload:
   0x0000: 01 00 00 80 05 00 01 00 00 08 00 00 00 00 00 00 00 00 00 00 00
6) Event:E_MTS_RX, length:60, at 315289 usecs after Tue Jan  6 18:43:21 2009
   [RSP] Opc:MTS_OPC_MFDM_V6_ROUTE_STATS(75786), Id:0X00048457, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1606, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00048455, Sync:NONE, Payloadsize:268
   Payload:
   0x0000: 01 00 00 80 05 00 01 00 00 08 00 00 00 00 00 00 00 00 00 00 00
7) Event:E_MTS_RX, length:60, at 305189 usecs after Tue Jan  6 18:42:21 2009
   [RSP] Opc:MTS_OPC_MFDM_V6_ROUTE_STATS(75786), Id:0X00047EFD, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1606, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x00047EFB, Sync:NONE, Payloadsize:268
   Payload:
   0x0000: 01 00 00 80 05 00 01 00 00 08 00 00 00 00 00 00 00 00 00 00 00
8) Event:E_MTS_RX, length:60, at 295210 usecs after Tue Jan  6 18:41:21 2009
   [RSP] Opc:MTS_OPC_MFDM_V6_ROUTE_STATS(75786), Id:0X0004794F, Ret:SUCCESS
   Src:0x00000901/214, Dst:0x00000901/1606, Flags:None
   HA_SEQNO:0X00000000, RRtoken:0x0004794D, Sync:NONE, Payloadsize:268
   Payload:
   0x0000: 01 00 00 80 05 00 01 00 00 08 00 00 00 00 00 00 00 00 00 00 00
switch(config)#

```

Related Commands

Command	Description
ipv6 routing multicast event-history	Configures the size of the IPv6 M6RIB event history buffers.
clear ipv6 routing multicast event-history	Clears information in the IPv6 M6RIB event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show routing multicast

To display information about IPv4 multicast routes, use the **show routing multicast** command.

```
show routing [ip | ipv4] multicast [vrf {vrf-name | all}] {{source group} | {group [source]}}
```

Syntax Description	ip (Optional) Specifies IPv4 routes. ipv4 (Optional) Specifies IPv4 routes. vrf (Optional) Applies to a virtual routing and forwarding (VRF) instance. <i>vrf-name</i> VRF name. all Specifies all VRFs. source Source address for routes. group Group address for routes.
--------------------	--

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
----------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
------------------	--

Examples	<p>This example shows how to display information about IPv4 multicast routes:</p> <pre>switch(config)# show routing multicast IP Multicast Routing Table for VRF "default" (*, 239.128.1.0/24), uptime: 1d01h, pim Incoming interface: Null, RPF nbr: 0.0.0.0 Outgoing interface list: (count: 0) switch(config)# </pre>
----------	---

■ show routing multicast

Related Commands	Command	Description
	ipv6 routing multicast event-history	Configures the size of the IPv6 M6RIB event history buffers.
	clear ipv6 routing multicast event-history	Clears information in the IPv6 M6RIB event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show routing multicast clients

To display information about IPv4 multicast routing clients, use the **show routing multicast clients** command.

show routing [ip | ipv4] multicast clients [client-name]

Syntax Description

ip	(Optional) Specifies IPv4 multicast clients.
ipv4	(Optional) Specifies IPv4 multicast clients.
<i>client-name</i>	(Optional) One of the following multicast routing client names: <ul style="list-style-type: none"> • mrib • igmp • static • msdp • ip • pim

Defaults

None

Command Modes

Any command mode

Supported User Roles

network-admin
network-operator
vdc-admin
vdc-operator

Command History

Release	Modification
4.0(1)	This command was introduced.

Usage Guidelines

This command requires the Enterprise Services license.

Examples

This example shows how to display information about IPv4 multicast clients:

```
switch(config)# show routing multicast clients pim
IP Multicast Routing Client information

Client: pim, client-id: 6, pid: 3982, mts-sap: 1568
Shared-memory: pim, wants notifications
Protocol is ssm owner, bidir owner, shared-only mode owner,
Join notifications:           sent 1, fail 0, ack rcvd 1
```

■ **show routing multicast clients**

```
Prune notifications:      sent 0, fail 0, ack rcvd 0
RPF notifications:      sent 0, fail 0, ack rcvd 0
Delete notifications:   sent 0, fail 0, ack rcvd 0
Clear mroute notifications: sent 0, fail 0
Add route requests:     rcvd 2, ack sent 2, ack fail 0
Delete route requests:  rcvd 1, ack sent 1, ack fail 0
```

```
switch(config)#
```

Related Commands

Command	Description
ipv6 routing multicast event-history	Configures the size of the IPv6 M6RIB event history buffers.
clear ipv6 routing multicast event-history	Clears information in the IPv6 M6RIB event history buffers.

Send document comments to nexus7k-docfeedback@cisco.com.

show running-config igmp

To display information about the running-system configuration for IGMP, use the **show running-config igmp** command.

show running-config igmp [all]

Syntax Description	all (Optional) Displays configured and default information.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

Supported User Roles	network-admin network-operator vdc-admin vdc-operator
-----------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the IGMP running-system configuration: switch(config)# show running-config igmp switch(config)#
-----------------	--

Related Commands	Command	Description
	show running-config msdp	Displays the information about the running-system configuration for Multicast Source Discovery Protocol

 show running-config msdp

show running-config msdp

To display information about the running-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show running-config msdp** command.

show running-config msdp [all]

Syntax Description	all (Optional) Displays configured and default information.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the MSDP running-system configuration:
-----------------	--

```
switch(config)# show running-config msdp
version 4.0(3)
feature msdp
ip msdp originator-id loopback0
ip msdp peer 192.168.1.10 connect-source Ethernet2/11 remote-as 8
ip msdp sa-interval 88
ip msdp reconnect-interval 20
ip msdp group-limit 3 source 172.1.0.0/16
ip msdp group-limit 4000 source 192.168.1.0/24
ip msdp group-limit 4096 source 192.168.1.1/32
ip msdp flush-routes
ip msdp description 192.168.1.10 engineering peer
ip msdp keepalive 192.168.1.10 10 20
ip msdp sa-policy 192.168.1.10 my_sa_policy in
ip msdp mesh-group 192.168.1.10 my_mesh_group

switch(config)#

```

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	show running-config igmp	Displays the information about the running-system configuration for IGMP

 show running-config pim

show running-config pim

To display information about the running-system configuration for IPv4 Protocol Independent Multicast (PIM), use the **show running-config pim** command.

show running-config pim [all]

Syntax Description	all (Optional) Displays configured and default information.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the PIM running-system configuration:
-----------------	---

```
switch(config)# show running-config pim
version 4.0(3)
feature pim
ip pim bsr-candidate Ethernet2/11
ip pim rp-address 192.0.2.33 group-list 224.0.0.0/9
ip pim rp-candidate Ethernet2/11 group-list 239.0.0.0/24 priority 3
ip pim auto-rp rp-candidate Ethernet2/12 group-list 239.0.0.0/24
ip pim send-rp-discovery Ethernet2/11 scope 30
ip pim log-neighbor-changes
ip pim bsr rp-candidate-policy my_bsr_rp_candidate_policy
ip pim bsr bsr-policy my_bsr_policy
ip pim auto-rp rp-candidate-policy my_rp_candidate_policy
ip pim auto-rp mapping-agent-policy my_mapping_agent_policy
ip pim ssm range 239.128.1.0/24
ip pim anycast-rp 192.0.2.3 192.0.2.31
ip pim auto-rp listen forward
ip pim state-limit 100000 reserved my_reserved_policy 40000

interface Ethernet2/11
  ip pim sparse-mode
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
ip pim dr-priority 5
ip pim hello-authentication ah-md5 3 78c3e5487bded5df
ip pim neighbor-policy my_neighbor_policy

interface Ethernet2/12
  ip pim sparse-mode

switch(config) #
```

Related Commands

Command	Description
show startup-config pim6	Displays the information about the startup-system configuration for IPv6 Protocol Independent Multicast.

 show running-config pim6

show running-config pim6

To display information about the running-system configuration for IPv6 Protocol Independent Multicast (PIM6), use the **show running-config pim6** command.

show running-config pim6 [all]

Syntax Description	all (Optional) Displays configured and default information.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the PIM6 running-system configuration:
	<pre>switch(config)# show running-config pim6 version 4.0(3) feature pim6 ipv6 pim bidir-rp-limit 3 ipv6 pim rp-address 2001:0db8::abcd:0000:0000:0001 group-list ff1e:abcd:def1::/96 ipv6 pim rp-candidate Ethernet2/11 group-list ff1e:abcd:def1::/24 ipv6 pim register-policy my_register_policy ipv6 pim ssm range ff30::/32 ipv6 pim flush-routes interface Ethernet2/12 ipv6 pim sparse-mode ipv6 pim hello-interval 22222 switch(config)# </pre>

Send document comments to nexus7k-docfeedback@cisco.com.

Related Commands	Command	Description
	show startup-config pim6	Displays the information about the startup-system configuration for IPv6 Protocol Independent Multicast.

```
■ show startup-config igmp
```

show startup-config igmp

To display information about the startup-system configuration for IGMP, use the **show startup-config igmp** command.

show startup-config igmp [all]

Syntax Description	all (Optional) Displays configured and default information.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any command mode
----------------------	------------------

SupportedUserRoles	network-admin network-operator vdc-admin vdc-operator
---------------------------	--

Command History	Release	Modification
	4.1(2)	This command was introduced.

Usage Guidelines	This command requires the Enterprise Services license.
-------------------------	--

Examples	This example shows how to display information about the IGMP startup-system configuration:
	<pre>switch(config)# show startup-config igmp switch(config)#</pre>

Related Commands	Command	Description
	show startup-config pim6	Displays the information about the startup-system configuration for IPv6 Protocol Independent Multicast.

Send document comments to nexus7k-docfeedback@cisco.com.

show startup-config msdp

To display information about the startup-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show startup-config msdp** command.

show startup-config msdp [all]

Syntax Description	all (Optional) Displays configured and default information.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command requires the Enterprise Services license.				
Examples	<p>This example shows how to display information about the startup-system configuration for MSDP:</p> <pre>switch(config)# show startup-config msdp version 4.0(3) feature msdp ip msdp originator-id loopback0 ip msdp peer 192.168.1.10 connect-source Ethernet2/11 remote-as 8 ip msdp sa-interval 88 ip msdp reconnect-interval 20 ip msdp group-limit 3 source 172.1.0.0/16 ip msdp group-limit 4000 source 192.168.1.0/24 ip msdp group-limit 4096 source 192.168.1.1/32 ip msdp flush-routes ip msdp description 192.168.1.10 engineering peer ip msdp keepalive 192.168.1.10 10 20 ip msdp sa-policy 192.168.1.10 my_incoming_sa_policy in switch(config)# </pre>				

■ **show startup-config msdp**

Related Commands	Command	Description
	show startup-config pim6	Displays the information about the startup-system configuration for IPv6 Protocol Independent Multicast.

Send document comments to nexus7k-docfeedback@cisco.com.

show startup-config pim

To display information about the startup-system configuration for IPv4 Protocol Independent Multicast (PIM), use the **show startup-config pim** command.

show startup-config pim [all]

Syntax Description	all (Optional) Displays configured and default information.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command requires the Enterprise Services license.				
Examples	<p>This example shows how to display information about the startup-system configuration for PIM:</p> <pre>switch(config)# show startup-config pim version 4.0(3) feature pim ip pim bsr-candidate Ethernet2/11 ip pim rp-address 192.0.2.33 group-list 224.0.0.0/9 ip pim rp-candidate Ethernet2/11 group-list 239.0.0.0/24 priority 3 ip pim auto-rp rp-candidate Ethernet2/12 group-list 239.0.0.0/24 ip pim send-rp-discovery Ethernet2/11 scope 30 ip pim log-neighbor-changes ip pim bsr rp-candidate-policy my_bsr_rp_candidate_policy ip pim bsr bsr-policy my_bsr_policy ip pim auto-rp rp-candidate-policy my_rp_candidate_policy ip pim auto-rp mapping-agent-policy my_mapping_agent_policy ip pim ssm range 239.128.1.0/24 ip pim anycast-rp 192.0.2.3 192.0.2.31 ip pim auto-rp listen forward ip pim state-limit 100000 reserved my_reserved_policy 40000 interface Ethernet2/11 ip pim sparse-mode</pre>				

■ **show startup-config pim**

```
ip pim dr-priority 5
ip pim hello-authentication ah-md5 3 78c3e5487bded5df
ip pim neighbor-policy my_neighbor_policy

interface Ethernet2/12
 ip pim sparse-mode

switch(config) #
```

Related Commands

Command	Description
show startup-config pim6	Displays the information about the startup-system configuration for IPv6 Protocol Independent Multicast.

Send document comments to nexus7k-docfeedback@cisco.com.

show startup-config pim6

To display information about the startup-system configuration for IPv6 Protocol Independent Multicast (PIM6), use the **show startup-config pim6** command.

show startup-config pim6 [all]

Syntax Description	all (Optional) Displays configured and default information.				
Defaults	None				
Command Modes	Any command mode				
Supported User Roles	network-admin network-operator vdc-admin vdc-operator				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	This command requires the Enterprise Services license.				
Examples	<p>This example shows how to display information about the startup-system configuration for PIM6:</p> <pre>switch(config)# show startup-config pim6 version 4.0(3) feature pim6 ipv6 pim bidir-rp-limit 3 ipv6 pim rp-address 2001:0db8::abcd:0000:0000:0001 group-list ff1e:abcd:def1::/96 ipv6 pim rp-candidate Ethernet2/11 group-list ff1e:abcd:def1::/24 ipv6 pim register-policy my_register_policy ipv6 pim ssm range ff30::/32 ipv6 pim flush-routes interface Ethernet2/12 ipv6 pim sparse-mode ipv6 pim hello-interval 22222 switch(config)# </pre>				

■ show system internal xbar fabric-flow-control-info

show system internal xbar fabric-flow-control-info

To display the system internal information, use the **show system internal** command.

show system internal xbar fabric-flow-control-info

Syntax Description	xbar Displays the Xbar command. fabric-flow-control-info Displays the flow control information.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC mode
----------------------	-----------

SupportedUserRoles	network-admin vdc-admin
---------------------------	----------------------------

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines	None. This command does not require a license.
-------------------------	---

Examples	This example shows how to display the system internal flow control information:
<pre>switch# show system internal xbar fabric-flow-control-info ----- ----- slot fabric-flow-control (multicast) ----- - ----- 1 enabled 2 disabled 3 enabled 7 enabled 8 disabled switch#</pre>	

Related Commands	Command	Description
	hardware fabric flow-control multicast forced	Configures the fabric flow control on all modules.

Send document comments to nexus7k-docfeedback@cisco.com.

```
■ show system internal xbar fabric-flow-control-info
```