



## **Cisco Plug-in for OpenFlow Configuration Guide 1.1.5**

**First Published:** February 04, 2014

**Last Modified:** July 07, 2016

### **Americas Headquarters**

Cisco Systems, Inc.

170 West Tasman Drive

San Jose, CA 95134-1706

USA

<http://www.cisco.com>

Tel: 408 526-4000

800 553-NETS (6387)

Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2014-2015 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### Preface

#### Preface v

Audience v

Document Conventions v

Related Documentation vii

Documentation Feedback vii

Obtaining Documentation and Submitting a Service Request viii

---

### CHAPTER 1

#### Cisco Plug-in for OpenFlow 1

Cisco Plug-in for OpenFlow 1

Prerequisites for Cisco Plug-in for OpenFlow 1

Restrictions for Cisco Plug-in for OpenFlow 2

Information About Cisco Plug-in for OpenFlow 3

Cisco Plug-in for OpenFlow Feature Support 3

About OpenFlow 8

Cisco Plug-in for OpenFlow Operation 8

OpenFlow Controller Operation 8

Cisco Plug-in for OpenFlow and Virtual Services Container 9

OFA Decommissioning 9

How to Configure Cisco Plug-in for OpenFlow 9

Configuring Physical Device Parameters 9

Enabling Hardware Support for Cisco Plug-in for OpenFlow 9

Adjusting the Number of Flow Entries (Nexus 3000 Series and Nexus 3100 Series) 10

Adjusting the Number of Flow Entries (Nexus 6000 Series) 12

Configuring Global Variables for a Cisco Plug-in for OpenFlow Logical Switch 14

Configuring Control Plane Policing for Packets Sent to a Controller 15

Specifying a Route to a Controller 16

Specifying a Route to a Controller Using a Physical Interface	17
Specifying a Route to a Controller Using a Management Interface	18
Configuring Interfaces for a Cisco Plug-in for OpenFlow Logical Switch	19
Configuring a Physical Interface in Layer 2 mode	19
Configuring a Port-Channel Interface	20
Installing and Activating Cisco Plug-in for OpenFlow	21
Configuring a Cisco Plug-in for OpenFlow Logical Switch	22
Verifying Cisco Plug-in for OpenFlow	25
Configuration Examples for Cisco Plug-in for OpenFlow	31
Additional Information for Cisco Plug-in for OpenFlow	34
Feature Information for Cisco Plug-in for OpenFlow	35

**CHAPTER 2****Virtual Services Container 39**

Virtual Services Container	39
Prerequisites for a Virtual Services Container	39
Information About Virtual Services Container	39
Virtual Services Containers and Applications	39
How to Configure a Virtual Services Container	40
Installing and Activating an Application in a Virtual Services Container	40
Deactivating and Uninstalling an Application from a Virtual Services Container	42
Upgrading an Application in a Virtual Services Container	43
Collecting General Troubleshooting Information	45
Verifying Virtual Services Container Applications	47
Troubleshooting Virtual Services Containers	51
Troubleshooting Installation of Applications in a Virtual Services Container	51
Troubleshooting Activation of Applications in a Virtual Services Container	53
Troubleshooting Uninstallation of Applications in a Virtual Services Container	54
Troubleshooting Deactivation of Applications in a Virtual Services Container	55
Configuration Examples for a Virtual Services Container	55
Additional References for the Virtual Services Container	56
Feature Information for Virtual Services Container	56
Glossary	57



## Preface

---

This preface includes the following sections:

- [Audience, page v](#)
- [Document Conventions, page v](#)
- [Related Documentation, page vii](#)
- [Documentation Feedback, page vii](#)
- [Obtaining Documentation and Submitting a Service Request, page viii](#)

## Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Virtual machine installation and administration
- Server administration
- Switch and network administration

## Document Conventions

Command descriptions use the following conventions:

Convention	Description
<b>bold</b>	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element (keyword or argument).

Convention	Description
[x   y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x   y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.
[x {y   z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
<i>variable</i>	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Examples use the following conventions:

Convention	Description
<code>screen font</code>	Terminal sessions and information the switch displays are in screen font.
<b><code>boldface screen font</code></b>	Information you must enter is in boldface screen font.
<i><code>italic screen font</code></i>	Arguments for which you supply values are in italic screen font.
<>	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

## Related Documentation

**Cisco Application Centric Infrastructure (ACI) Documentation**

The ACI documentation is available at the following URL: <http://www.cisco.com/c/en/us/support/cloud-systems-management/application-policy-infrastructure-controller-apic/tsd-products-support-series-home.html>.

**Cisco Application Centric Infrastructure (ACI) Simulator Documentation**

The Cisco ACI Simulator documentation is available at <http://www.cisco.com/c/en/us/support/cloud-systems-management/application-centric-infrastructure-simulator/tsd-products-support-series-home.html>.

**Cisco Nexus 9000 Series Switches Documentation**

The Cisco Nexus 9000 Series Switches documentation is available at <http://www.cisco.com/c/en/us/support/switches/nexus-9000-series-switches/tsd-products-support-series-home.html>.

**Cisco Application Virtual Switch Documentation**

The Cisco Application Virtual Switch (AVS) documentation is available at <http://www.cisco.com/c/en/us/support/switches/application-virtual-switch/tsd-products-support-series-home.html>.

**Cisco Application Centric Infrastructure (ACI) Integration with OpenStack Documentation**

Cisco ACI integration with OpenStack documentation is available at <http://www.cisco.com/c/en/us/support/cloud-systems-management/application-policy-infrastructure-controller-apic/tsd-products-support-series-home.html>.

## Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to [apic-docfeedback@cisco.com](mailto:apic-docfeedback@cisco.com). We appreciate your feedback.

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation as an RSS feed and delivers content directly to your desktop using a reader application. The RSS feeds are a free service.





# Cisco Plug-in for OpenFlow

---

This chapter contains the following sections:

- [Cisco Plug-in for OpenFlow, page 1](#)

## Cisco Plug-in for OpenFlow

Cisco Plug-in for OpenFlow, Release 2.0.2 provides better control over networks making them more open, programmable, and application-aware and supports the following specifications defined by the Open Networking Foundation (ONF) standards organization:

- OpenFlow Switch Specification Version 1.0.1 (Wire Protocol 0x01) (referred to as OpenFlow 1.0)
- OpenFlow Switch Specification Version 1.3.0 (Wire Protocol 0x04) (referred to as OpenFlow 1.3).

## Prerequisites for Cisco Plug-in for OpenFlow

- A Cisco device and its corresponding operating system that supports the installation of Cisco Plug-in for OpenFlow.



---

**Note** A compatibility matrix is delivered with each Cisco application. Refer to this matrix for information about the operating system releases that support features and infrastructure necessary for a particular application, such as Cisco Plug-in for OpenFlow.

---

- An open virtual application (OVA) package that is compatible with the device operating system and downloaded from an FTP server connected to the device.
- A controller installed on a connected server.

**Table 1: Controller Support**

OpenFlow Version	Supported Controllers
OpenFlow 1.0	Extensible Network Controller (XNC) 1.0, POX, or Ixia controllers
OpenFlow 1.3	Ixia or OpenDaylight

- The required disk storage available on the device for installation and deployment of Cisco Plug-in for OpenFlow. Recommended disk space is 360 MB.

## Restrictions for Cisco Plug-in for OpenFlow

- Cisco Plug-in for OpenFlow supports only a subset of OpenFlow 1.3 and OpenFlow 1.0 functions. For more information, see [Cisco Plug-in for OpenFlow Feature Support, on page 3](#).
- You cannot configure more than one Cisco Plug-in for OpenFlow logical switch. The logical switch ID has a value of 1.
- OpenFlow hybrid model (ships-in-the-night) is supported. VLANs configured for Cisco Plug-in for OpenFlow logical switch ports should not overlap with regular device interfaces.
- Cisco Plug-in for OpenFlow logical switch ports must not be configured in a mode other than trunk port.
- You cannot configure a bridge domain, Virtual LANs and virtual routing and forwarding (VRF) interfaces on an Cisco Plug-in for OpenFlow logical switch. You can configure only Layer 2 physical interfaces or port-channel interfaces.
- Total number of VLANs across all ports cannot exceed 32000. For example, if you have configured 512 VLANs per port, you cannot configure more than 62 ports (32000/512). If you have configured 4000 VLANs per port, you cannot configure more than 8 ports (32000/4000).
- You cannot configure more than 512 VLANs in Per-VLAN Spanning Tree+ (PVST+) mode.
- Matching of flows that use IPv6 address fields and ports is not supported. Connection to controller using IPv6 addresses is not supported. IPv6 Ethertype is supported.
- Cisco IOS In-Service Software Upgrade (ISSU) is not supported for Cisco Plug-in for OpenFlow.
- MIBs and XMLs are not supported
- You cannot configure more than 1400 MAC flows in the ACL table for Cisco Nexus 3000 Series switches. However, you cannot configure more than 700 ACL flows for Cisco Nexus 3000 Series switches with double-wide TCAM carving configuration for a 12-tuple match.  
For Cisco Nexus 3172, you can configure a maximum of 3000 ACL flows normally and a maximum of 1500 ACL flows with double-wide TCAM configuration. For Cisco Nexus 3548, you can configure a maximum of 4095 ACL FIB flows.
- You cannot configure more than 64,000 flows in the MAC forwarding table.
- TCAM carving must be non-zero for the QoS region to ensure that control plane policing for selfIp is effective on the Cisco Nexus 3000 Series switches.

- 
- Reachability to controller via Switched Virtual Interface (SVI) is not supported.
- You must not add or remove an interface as a port of a Cisco Plug-in for OpenFlow if the Cisco Plug-in for OpenFlow is inactive or not running.
- You cannot connect to OpenFlow 1.0 and OpenFlow 1.3 controllers simultaneously. All controllers must support the same version.
- The minimum idle timeout for flows must be 120 seconds.

## Information About Cisco Plug-in for OpenFlow

### Cisco Plug-in for OpenFlow Feature Support

The following is a subset of OpenFlow 1.3 and OpenFlow 1.0 functions that are supported by Cisco Plug-in for OpenFlow.

Supported Feature	Additional Notes
The OpenFlow hybrid (ships-in-night) model is supported using the OpenFlow packet format	<p>OpenFlow-hybrid models where traffic can flow between Cisco Plug-in for OpenFlow ports and regular interfaces (integrated) are not supported. Both types of ports can transmit and receive packets.</p> <p><b>Note</b> VLANs must be configured such that the VLANs on the Cisco Plug-in for OpenFlow do not overlap with those on the regular device interfaces.</p>
Configuration of port-channel and physical interfaces as Cisco Plug-in for OpenFlow logical switch ports	<ul style="list-style-type: none"> <li>• Bridge domain, Virtual LANs and Virtual Routing and Forwarding (VRF) interfaces are not supported.</li> <li>• Only L2 interfaces can be Cisco Plug-in for OpenFlow Logical switch ports.</li> </ul>
Configuration of VLANs for each port of the Cisco Plug-in for OpenFlow logical switch	<p>Total number of VLANs across all ports cannot exceed 32000.</p> <p>Maximum VLAN range supported is 4000. You can configure 8 such ports on the Cisco Plug-in for OpenFlow device.</p> <p>Recommended VLAN range supported is 512. You can configure 62 such ports on the Cisco Plug-in for OpenFlow device.</p> <p>VLAN range greater than 512 is not supported in Per-VLAN Spanning Tree+ (PVST+) mode.</p>

Supported Feature	Additional Notes
Pipelines for Cisco Plug-in for OpenFlow Logical Switch	<ul style="list-style-type: none"><li>• Pipelines are mandatory for the logical switch.</li><li>• The logical switch supports two pipelines: one with an L3 ACL forwarding Table and one with both an L3 ACL forwarding table and L2 MAC forwarding table.<ul style="list-style-type: none"><li>◦ Pipeline 201 supports the L3 ACL forwarding table.</li><li>◦ Pipeline 202 supports an L3 ACL forwarding table and an L2 MAC forwarding table. Mandatory matches and actions in both tables must be specified in all configured flows.</li><li>◦ Pipeline 203, which is supported only on the Nexus 3500 Series switches, supports an L3 ACL forwarding table.</li></ul></li></ul>

Supported Feature	Additional Notes
L3 ACL Forwarding Table (Match Criteria)	<p>The following match criteria are supported:</p> <ul style="list-style-type: none"> <li>• Ethertype <ul style="list-style-type: none"> <li><b>Note</b> For Cisco Nexus 3000 Series switches, you can now use the Ethertype field as a wildcard match criteria when the size of the TCAM is configured for double wide interface ACLs.</li> </ul> </li> <li>• Ethernet MAC destination (Supported on Nexus 3000 and 3500 Series switches only) <ul style="list-style-type: none"> <li><b>Note</b> To keep the field set unique in each table in Pipeline 202, match on destination MAC address is not supported in the ACL table when using Pipeline 202 for Cisco Nexus 3000.</li> </ul> </li> <li>• Ethernet MAC source (Supported on Nexus 3000 and 3500 Series switches only) <ul style="list-style-type: none"> <li><b>Note</b> Cisco Nexus 3000 Series switches support OpenFlow 12-tuple match. To accommodate the additional match criteria of source and destination MAC addresses, the Nexus 3000 switch supports a new TCAM region, <b>ifac1 double-wide</b>, which is a double-wide interface ACL.</li> </ul> </li> <li>• VLAN ID (for IPv4 packets only)</li> <li>• VLAN priority (Supported for the Ethertype value 0x0800 (IP) only) <ul style="list-style-type: none"> <li><b>Note</b> Not supported on Cisco Nexus 3548 and 3548-X.</li> </ul> </li> <li>• Input port</li> <li>• IPv4 source address (Supported for the Ethertype value 0x0800 (IP) only)</li> <li>• IPv4 destination address (Supported for the Ethertype value 0x0800 (IP) only)</li> <li>• IP DSCP (Supported for the Ethertype value 0x0800 (IP) only)</li> <li>• IP protocol (Supported for the Ethertype value 0x0800 (IP) only)</li> <li>• Layer 4 source port (Supported for the Ethertype value 0x0800 (IP) only)</li> <li>• Layer 4 destination port (Supported for the Ethertype value 0x0800 (IP) only)</li> </ul>

Supported Feature	Additional Notes
L3 ACL Forwarding Table (Action Criteria)	<p>The following action criteria are supported:</p> <ul style="list-style-type: none"> <li>• Output to single port</li> <li>• Output to a specified interface</li> <li>• Output to controller (OpenFlow Packet-In message)</li> <li>• Rewrite source MAC address (SMAC) <ul style="list-style-type: none"> <li>◦ Supported for the Ethertype value 0x0800 (IP) only</li> </ul> </li> <li>• Rewrite destination MAC address (DMAC) <ul style="list-style-type: none"> <li>◦ Supported for the Ethertype value 0x0800 (IP) only</li> </ul> </li> <li>• Rewrite VLAN ID <ul style="list-style-type: none"> <li>◦ Supported for the Ethertype value 0x0800 (IP) only</li> </ul> </li> <li>• Strip VLAN (Supported for the Ethertype value 0x0800 (IP) only) <p><b>Note</b> Support for the <b>strip vlan</b> command on the Cisco Nexus 3548 begins with NX-OS software release 6.0(2)A6(4).</p> </li> <li>• Drop</li> </ul> <p><b>Note</b> Rewrite DMAC and Rewrite SMAC actions must be specified together.</p>
L2 MAC Forwarding Table	<p>Match Criteria:</p> <ul style="list-style-type: none"> <li>• Destination MAC address (mandatory)</li> <li>• VLAN ID (mandatory)</li> </ul> <p>Action Criteria:</p> <ul style="list-style-type: none"> <li>• Output to one port</li> <li>• Drop</li> <li>• Punt-to-controller</li> </ul>

Supported Feature	Additional Notes
Default Forwarding Rule	<p>All packets that cannot be matched to flows are dropped by default. You can configure sending unmatched packets to the controller.</p> <p>In Cisco Nexus 3000 Series switches, all unmatched packets will be punted to the controller by default when TCAM carving is set to <b>ifac1 double-wide</b>.</p>
OpenFlow 1.3 message types	The “modify state” and “queue config” message types are not supported. All other message types are supported.
Connection to up to eight controllers	Transport Layer Security (TLS) is supported for the connection to the controller.
Multiple actions	<p>If multiple actions are associated with a flow, they are processed in the order specified. The output action should be the last action in the action list. Any action after the output action is not supported, and can cause the flow to fail and return an error to the controller.</p> <p>Flows defined on the controller must follow the following guidelines :</p> <ul style="list-style-type: none"> <li>• The flow can have only up to 16 output actions.</li> <li>• The flow should have the output action at the end of all actions.</li> <li>• The flow should not have multiple rewrite actions that override one another. For example, strip VLAN after set VLAN or multiple set VLANs.</li> </ul> <p><b>Note</b> Support for the <b>strip vlan</b> and <b>set vlan</b> commands on the Cisco Nexus 3548 begins with NX-OS software release 6.0(2)A6(4).</p> <ul style="list-style-type: none"> <li>• The flow should not have an output-to-controller action in combination with other output-to-port actions or with VLAN-rewrite actions.</li> <li>• Flows with unsupported actions will be rejected.</li> </ul>
Supported counters	<p>Per Table—Active Entries, Packet Lookups, Packet Matches.</p> <p>Per Flow—Received Packets.</p> <p>Per Port—Received or Transmitted packets, bytes, drops and errors.</p>

## About OpenFlow

OpenFlow Switch Specification Version 1.0.1 (Wire Protocol 0x01) (referred to as OpenFlow 1.0) and OpenFlow Switch Specification Version 1.3.0 (Wire Protocol 0x04), referred to as OpenFlow 1.3, is based on the concept of an Ethernet switch, with an internal flow table and standardized interface to allow traffic flows on a device to be added or removed. OpenFlow 1.3 defines the communication channel between Cisco Plug-in for OpenFlow and controllers.


Cisco Plug-in for OpenFlow 1.1.5 refers to Cisco Plug-in for OpenFlow, Release 1.1.5.

A controller can be Extensible Network Controller (XNC) 1.0, or any controller compliant with OpenFlow 1.3.

In an OpenFlow network, Cisco Plug-in for OpenFlow exists on the device and controllers exist on a server, that is external to the device. Flow management and any network management are either part of a controller or accomplished through a controller. Flow management includes the addition, modification, or removal of flows, and the handling of OpenFlow error messages.

The following figure gives an overview of the OpenFlow network.

**Figure 1: OpenFlow Overview**



## Cisco Plug-in for OpenFlow Operation

Cisco Plug-in for OpenFlow creates OpenFlow-based TCP/IP connections to controllers for a Cisco Plug-in for OpenFlow logical switch. Cisco Plug-in for OpenFlow creates databases for a configured logical switch, OpenFlow-enabled interfaces, and flows. The logical switch database contains all the information needed to connect to a controller. The interface database contains the list of OpenFlow-enabled interfaces associated with a logical switch, and the flow database contains the list of flows on a logical switch as well as for interface that is programmed into forwarded traffic.

## OpenFlow Controller Operation

OpenFlow controller (referred to as controller) controls the switch and inserts flows with a subset of OpenFlow 1.3 and 1.0 match and action criteria through Cisco Plug-in for OpenFlow logical switch. Cisco Plug-in for OpenFlow rejects all OpenFlow messages with any other action.



## Cisco Plug-in for OpenFlow and Virtual Services Container

Cisco Plug-in for OpenFlow runs in an operating-system-level virtual service container on the device. The Cisco Plug-in for OpenFlow virtual service container is delivered in an open virtual application (OVA) file package (.ova). The OVA package is installed and enabled on the device through the CLI.

### OFA Decommissioning

OFA must be un-configured before the virtual service is de-activated and uninstalled. If this is not done, part of the OpenFlow configuration on the interfaces will persist even after decommissioning OFA.

## How to Configure Cisco Plug-in for OpenFlow

This section includes the following required and optional tasks. All tasks below require the fulfillment of the prerequisites listed in [Prerequisites for Cisco Plug-in for OpenFlow](#), on page 1:

- [Configuring Physical Device Parameters](#), on page 9
- [Specifying a Route to a Controller](#), on page 16
- [Configuring Interfaces for a Cisco Plug-in for OpenFlow Logical Switch](#), on page 19
- [Installing and Activating Cisco Plug-in for OpenFlow](#), on page 21
- [Configuring a Cisco Plug-in for OpenFlow Logical Switch](#), on page 22 (optional)
- [Verifying Cisco Plug-in for OpenFlow](#), on page 25

### Configuring Physical Device Parameters

- [Enabling Hardware Support for Cisco Plug-in for OpenFlow](#), on page 9
- [Adjusting the Number of Flow Entries \(Nexus 3000 Series and Nexus 3100 Series\)](#), on page 10
- [Configuring Global Variables for a Cisco Plug-in for OpenFlow Logical Switch](#), on page 14
- [Configuring Control Plane Policing for Packets Sent to a Controller](#), on page 15 (optional)

### Enabling Hardware Support for Cisco Plug-in for OpenFlow

#### Procedure

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

	Command or Action	Purpose
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 3</b>	Enter one of the following commands depending on the device: <ul style="list-style-type: none"> <li>• <b>hardware profile openflow</b></li> <li>• <b>hardware profile forwarding-mode openflow-hybrid</b></li> </ul> <b>Example:</b> Device(config)# hardware profile openflow  <b>Example:</b> Device(config)# hardware profile forwarding-mode openflow-hybrid	Allocates resources for Cisco Plug-in for OpenFlow.  The <b>hardware profile forwarding-mode openflow-hybrid</b> command is only for the Cisco Nexus 3548 and 3548-X switches.
<b>Step 4</b>	<b>exit</b>  <b>Example:</b> Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
<b>Step 5</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.
<b>Step 6</b>	<b>reload</b>  <b>Example:</b> Device# reload	Reloads the operating system of a device so that virtual-services container support for the device hardware can start.

### What to Do Next

Configure the number of flow entries.

### Adjusting the Number of Flow Entries (Nexus 3000 Series and Nexus 3100 Series)

You can use this task to adjust the number of L3 flow entries. By default, 384 flow entries are supported. You can adjust the number of flow entries in a Nexus 3000 Series device to the maximum (1400), using the steps listed below. You can use similar steps to adjust the number of flow entries in a Nexus 3100 Series device to the maximum (3000).

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 3</b>	<b>hardware profile tcam region vacl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam region vacl 0	Configures the size of TCAM region for VLAN Access Control Lists (ACLs).
<b>Step 4</b>	<b>hardware profile tcam region e-vacl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam region e-vacl 0	Configures the size of TCAM region for egress VLAN ACLs.
<b>Step 5</b>	<b>hardware profile tcam region racl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam region racl 0	Configures the size of TCAM region for router ACLs.
<b>Step 6</b>	<b>hardware profile tcam region e-racl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam region e-racl 0	Configures the size of TCAM region for egress router ACLs.
<b>Step 7</b>	<b>hardware profile tcam region qos 256</b>  <b>Example:</b> Device(config)# hardware profile tcam region qos 256	Configures the size of TCAM region for egress router ACLs.
<b>Step 8</b>	Enter one of the following commands: <ul style="list-style-type: none"> <li>• <b>hardware profile tcam region ifacl 1408</b></li> <li>• <b>hardware profile tcam region ifacl 704 double-wide</b></li> </ul> <b>Example:</b> Device(config)# hardware profile tcam region ifacl 1408	Configures the size of TCAM region for interface ACLs.  To accommodate the additional match criteria of source and destination MAC addresses, the Cisco Nexus 3000 switch supports a new TCAM region, <b>ifacl double-wide</b> , which is a double-wide interface ACL.  The <b>ifacl</b> and <b>ifacl double-wide</b> sizes for Cisco Nexus 3172 are 3072 and 1536, respectively.

	Command or Action	Purpose
	<b>Example:</b> Device(config)# hardware profile tcam region ifacl 704 double-wide	
<b>Step 9</b>	<b>exit</b>  <b>Example:</b> Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
<b>Step 10</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.
<b>Step 11</b>	<b>reload</b>  <b>Example:</b> Device# reload	Reloads the operating system of a device so that virtual-services container support for the device hardware can start.

### What to Do Next

Configure global variables for Cisco Plug-in for OpenFlow logical switch.

### Adjusting the Number of Flow Entries (Nexus 6000 Series)

You can use this task to adjust the number of L3 flow entries. By default, 384 flow entries are supported. You can adjust the number of flow entries in a Nexus 6000 Series device to the maximum (1500), using the steps listed below.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
<b>Step 3</b>	<b>hardware profile tcam resource template vacl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template vacl 0	Configures the size of TCAM region for VLAN Access Control Lists (ACLs).
<b>Step 4</b>	<b>hardware profile tcam resource template ifacl 3520</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template ifacl 3520	Configures the size of TCAM region for interface ACLs.
<b>Step 5</b>	<b>hardware profile tcam resource template e-vacl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template e-vacl 0	Configures the size of TCAM region for egress VLAN ACLs.
<b>Step 6</b>	<b>hardware profile tcam resource template rbacl 0</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template rbacl 0	Configures the size of TCAM region for role-based ACLs.
<b>Step 7</b>	<b>hardware profile tcam resource template qos 128</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template qos 128	Configures the size of TCAM region for Quality of Service (QoS).
<b>Step 8</b>	<b>hardware profile tcam resource template span 64</b>  <b>Example:</b> Device(config)# hardware profile tcam resource template span 64	Configures the size of span regions.
<b>Step 9</b>	<b>exit</b>  <b>Example:</b> Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
<b>Step 10</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

	Command or Action	Purpose
<b>Step 11</b>	<b>reload</b>  <b>Example:</b> Device# reload	Reloads the operating system of a device so that virtual-services container support for the device hardware can start.

### What to Do Next

Configure global variables for Cisco Plug-in for OpenFlow logical switch.

## Configuring Global Variables for a Cisco Plug-in for OpenFlow Logical Switch

### Before You Begin

Create a non default VDC for Cisco Plug-in for OpenFlow.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>mac-learn disable</b>  <b>Example:</b> Device(config)# mac-learn disable	Disables MAC address learning on all interfaces so that the device can only be used as an Cisco Plug-in for OpenFlow logical switch when an Cisco Plug-in for OpenFlow logical switch is enabled.
<b>Step 3</b>	<b>no cdp enable</b>  <b>Example:</b> Device(config)# no cdp enable	Disables Cisco Discovery Protocol (CDP).
<b>Step 4</b>	<b>vlan {vlan-id   vlan-range}</b>  <b>Example:</b> Device(config)# vlan 1-512	Adds a VLAN or VLAN range for interfaces on the device and enters the VLAN configuration mode.
<b>Step 5</b>	<b>end</b>  <b>Example:</b> Device(config-vlan)# exit	Exits VLAN configuration mode and enters privileged EXEC mode.
<b>Step 6</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

## What to Do Next

Specify a route to the controller.

## Configuring Control Plane Policing for Packets Sent to a Controller

You can use this task to throttle the packet processing rate of Cisco Plug-in for OpenFlow as required for a traffic pattern. In general, a lower rate is helpful when there is a high rate of Link Layer Discovery Protocol (LLDP) and Address Resolution Protocol (ARP) traffic configured to be punted using Cisco Plug-in for OpenFlow flow rules.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode.  • Enter your password if prompted.
<b>Step 2</b>	<b>setup</b>  <b>Example:</b> Device# setup	Enters the basic device setup to configure the device.  • The setup script needs to be run once to add a new control plane policy map policy for Cisco Plug-in for OpenFlow.
<b>Step 3</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 4</b>	<b>policy-map type control-plane</b> <i>policy-map-name</i>  <b>Example:</b> Device(config)# policy-map type control-plane copp-system-policy	Specifies a control plane policy map and enters QoS policy-map configuration mode.  • The policy map name can have a maximum of 64 characters and is case sensitive.
<b>Step 5</b>	<b>class</b> <i>class-map-name</i>  <b>Example:</b> Device(config-pmap)# class copp-s-dpss	Specifies a control plane class map name and enters QoS policy-map class configuration mode.
<b>Step 6</b>	Do one of the following:  • <b>police</b> [pps] <i>pps-value</i>  • <b>police cir</b> <i>committed-information-rate-value</i> <b>bc</b> <i>burst-size-in-bytes</i>	Specifies the rate limit in terms of packets per second (PPS) for the number of packets processed by Cisco Plug-in for OpenFlow and sent to a controller.  • The range is from 0 to 20,000. • The recommended value is 1000.

	Command or Action	Purpose
	<p><b>Example:</b> Device(config-pmap-c)# police pps 1000</p> <p><b>Example:</b> Device(config-pmap-c)# police cir 1000 bc 3200000</p>	
<b>Step 7</b>	<p><b>control-plane</b></p> <p><b>Example:</b> Device(config-pmap-c)# control-plane</p>	(Optional) Associates or modifies attributes (such as a service policy) that are associated with the control plane of the device and enters control plane configuration mode.
<b>Step 8</b>	<p><b>end</b></p> <p><b>Example:</b> Device(config-pmap-c)# end</p> <p><b>Example:</b> Device(config-pmap-c)# end</p>	Enters privileged EXEC mode.

On a Cisco Nexus 3000 Series switch, the following configuration is used for no punt-to-controller packet drop@1000 pps:

```
Device(config)# policy-map type control-plane copp-system-policy
Device(config-pmap)# class copp-s-selfIp
Device(config-pmap-c)# police pps 5000
```

### What to Do Next

Specify a route to a controller.

## Specifying a Route to a Controller

The following tasks are used to specify a route from the device to a controller. This can be done using a physical interface (Front Panel) or a management interface.

- Physical Interface . Refer to [Specifying a Route to a Controller Using a Physical Interface](#), on page 17.
- Management Interface. Refer to [Specifying a Route to a Controller Using a Management Interface](#), on page 18.

The IP address of the controller is configured in the [Configuring a Cisco Plug-in for OpenFlow Logical Switch](#), on page 22 section.



## Specifying a Route to a Controller Using a Physical Interface

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>interface <i>type number</i></b>  <b>Example:</b> Device(config)# interface Ethernet2/2	Configures the physical interface. The interface used here should not be a Cisco Plug-in for OpenFlow ports.
<b>Step 3</b>	<b>no switchport</b>  <b>Example:</b> Device(config-if)# no switchport	Configures a specified interface as a Layer 3 interface and deletes any interface configuration specific to Layer 2.
<b>Step 4</b>	<b>ip address <i>ip-address mask</i></b>  <b>Example:</b> Device(config-if)# ip address 10.0.1.4 255.255.255.0	Configures an IP address for a specified interface.
<b>Step 5</b>	<b>exit</b>  <b>Example:</b> Device(config-if)# exit	Exits interface configuration mode and enters global configuration mode.
<b>Step 6</b>	<b>ip route 0.0.0.0 0.0.0.0 <i>next-hop</i></b>  <b>Example:</b> Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6	Configures a default route for packet addresses not listed in the routing table. Packets are directed toward a controller.
<b>Step 7</b>	<b>exit</b>  <b>Example:</b> Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
<b>Step 8</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the changes persistently by copying the running configuration to the startup configuration.

### What to Do Next

Configure interfaces for the Cisco Plug-in for OpenFlow logical switch.

## Specifying a Route to a Controller Using a Management Interface

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>interface mgmt <i>management-interface-name</i> <i>number</i></b>  <b>Example:</b> Device(config)# interface mgmt0	Enters the management interface.
<b>Step 3</b>	<b>ip address <i>ip-address mask</i></b>  <b>Example:</b> Device(config-if)# ip address 10.0.1.4 255.255.255.0	Configures an IP address for the interface.
<b>Step 4</b>	<b>exit</b>  <b>Example:</b> Device(config-if)# exit	Exits interface configuration mode and enters global configuration mode.
<b>Step 5</b>	<b>vrf context management</b>  <b>Example:</b> Device(config)# vrf context management	Configures the management Virtual routing and forwarding (VRF) instance and enters in VRF configuration mode.
<b>Step 6</b>	<b>ip route 0.0.0.0 0.0.0.0 <i>next-hop</i></b>  <b>Example:</b> Device(config-vrf)# ip route 0.0.0.0 0.0.0.0 10.0.1.6	Configures a default route for packet addresses not listed in the routing table. Packets are directed toward a controller.
<b>Step 7</b>	<b>exit</b>  <b>Example:</b> Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
<b>Step 8</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently by copying the running configuration to the startup configuration.

### What to Do Next

Configure interfaces for the Cisco Plug-in for OpenFlow logical switch.

## Configuring Interfaces for a Cisco Plug-in for OpenFlow Logical Switch

You must configure physical or port-channel interfaces before the interfaces are added as ports of a Cisco Plug-in for OpenFlow logical switch. These interfaces are added as ports of the Cisco Plug-in for OpenFlow logical switch in the [Configuring a Cisco Plug-in for OpenFlow Logical Switch](#), on page 22 section.

### Configuring a Physical Interface in Layer 2 mode

Perform the following task to add a physical interface to a Cisco Plug-in for OpenFlow logical switch in Layer 2 mode.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 2</b>	<b>interface Ethernetslot port</b>  <b>Example:</b> Device(config)# interface Ethernet2/2	Specifies the interface for the logical switch and enters interface configuration mode.
<b>Step 3</b>	<b>channel-group group-number</b>  <b>Example:</b> Device(config-if)# channel-group 2	(Optional) Adds the interface to a port-channel.
<b>Step 4</b>	<b>switchport</b>  <b>Example:</b> Device(config-if)# switchport	Specifies an interface as a Layer 2 port.
<b>Step 5</b>	<b>switchport mode trunk</b>  <b>Example:</b> Device(config-if)# switchport mode trunk	Specifies an interface as a trunk port. <ul style="list-style-type: none"> <li>• A trunk port can carry traffic of one or more VLANs on the same physical link. (VLANs are based on the trunk-allowed VLANs list.) By default, a trunk interface carries traffic for all VLANs.</li> </ul>
<b>Step 6</b>	<b>mac packet-classify</b>  <b>Example:</b> Device(config-if)# mac packet-classify	Enables MAC packet classification on the interface.

	Command or Action	Purpose
<b>Step 7</b>	<b>switchport mode trunk allowed vlan</b> <i>[vlan-list]</i>  <b>Example:</b> Device(config-if)# switchport trunk allowed vlan 1-3	Sets the list of allowed VLANs that transmit traffic from this interface in tagged format when in trunking mode.
<b>Step 8</b>	<b>no shutdown</b>  <b>Example:</b> Device(config-if)# no shutdown	Enables the interface.
<b>Step 9</b>	<b>end</b>  <b>Example:</b> Device(config-if)# end	Exits interface configuration mode and enters privileged EXEC mode.
<b>Step 10</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently by copying the running configuration to the startup configuration.

### What to Do Next

Repeat these steps to configure any additional interfaces for a Cisco Plug-in for OpenFlow logical switch. Once all the interfaces are configured, install and activate Cisco Plug-in for OpenFlow.

### Configuring a Port-Channel Interface

Perform the task below to create a port-channel interface for a Cisco Plug-in for OpenFlow logical switch.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
<b>Step 3</b>	<b>interface port-channel</b> <i>number</i>  <b>Example:</b> Device(config)# interface port-channel 2	Specifies the interface for the logical switch and enters interface configuration mode.
<b>Step 4</b>	<b>switchport mode trunk</b>  <b>Example:</b> Device(config-if)# switchport mode trunk	Specifies the interface as an Ethernet trunk port. A trunk port can carry traffic in one or more VLANs on the same physical link (VLANs are based on the trunk-allowed VLANs list). By default, a trunk interface can carry traffic for all VLANs.  <b>Note</b> If the port-channel is specified as a trunk interface, ensure that member interfaces are also configured as trunk interfaces.
<b>Step 5</b>	<b>switchport mode trunk allowed vlan</b> [ <i>vlan-list</i> ]  <b>Example:</b> Device(config-if)# switchport trunk allowed vlan 1-3	Sets the list of allowed VLANs that transmit traffic from this interface in tagged format when in trunking mode.
<b>Step 6</b>	<b>end</b>  <b>Example:</b> Device(config-if)# end	Ends interface configuration mode and enters privileged EXEC mode.
<b>Step 7</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

### What to Do Next

Install and activate Cisco Plug-in for OpenFlow.

## Installing and Activating Cisco Plug-in for OpenFlow

Cisco Plug-in for OpenFlow is an application that runs at the operating–system-level virtual services container on a device. Cisco Plug-in for OpenFlow is delivered in an open virtual application (OVA) package. The OVA package is installed and activated on the device through the CLI.

Before installing and activating Cisco Plug-in for OpenFlow, ensure that an OVA package compatible with the device exists on a connected FTP server. Refer to the [Prerequisites for a Virtual Services Container](#), on page 39. A reload of the device is not essential after installing, uninstalling, or upgrading Cisco Plug-in for OpenFlow software.

To install and activate Cisco Plug-in for OpenFlow software, refer to the instructions in [Installing and Activating an Application in a Virtual Services Container, on page 40](#), where the virtual services application argument, *virtual-services-name*, can be specified as `openflow_plugin`.

To uninstall and deactivate Cisco Plug-in for OpenFlow software, refer to the instructions in [Deactivating and Uninstalling an Application from a Virtual Services Container, on page 42](#), where the virtual services application argument, *virtual-services-name*, must be the same as that specified during installation.

To upgrade Cisco Plug-in for OpenFlow software, refer to the instructions in [Upgrading an Application in a Virtual Services Container, on page 43](#), where the virtual services application argument, *virtual-services-name*, must be the same as that specified during installation.

Once installed, configure a Cisco Plug-in for OpenFlow logical switch.

## Configuring a Cisco Plug-in for OpenFlow Logical Switch

This task configures a Cisco Plug-in for OpenFlow logical switch and the IP address of a controller.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 2</b>	<b>openflow</b>  <b>Example:</b> Device(config)# <code>openflow</code>	Enters Cisco Plug-in for OpenFlow mode.
<b>Step 3</b>	<b>switch <i>logical-switch-id</i></b>  <b>Example:</b> Device(config-ofa)# <code>switch 1</code>	Specifies an ID for a logical switch that is used for Layer 2 (default) switching operations and enters logical switch configuration mode. <ul style="list-style-type: none"> <li>The only logical switch ID supported is 1.</li> </ul>
<b>Step 4</b>	<b>pipeline <i>pipeline-id</i></b>  <b>Example:</b> Device(config-ofa-switch)# <code>pipeline 201</code>	Configures a pipeline . <ul style="list-style-type: none"> <li>This step is mandatory for a logical switch configuration.</li> <li>You can view the supported pipeline values using the <b>show openflow hardware capabilities</b> command.</li> <li>The valid values are from 321 and 322.</li> </ul>
<b>Step 5</b>	Do one of the following: <ul style="list-style-type: none"> <li><b>of-port interface <i>interface-name</i></b></li> <li><b>of-port interface <i>port-channel-name</i></b></li> </ul>	Configures an Ethernet interface or port-channel interface as a port of a Cisco Plug-in for OpenFlow logical switch. <ul style="list-style-type: none"> <li>Do not abbreviate the interface type. Ensure that the interface type is spelled out completely and is as shown in the examples. If the keyword is abbreviated, the</li> </ul>

	Command or Action	Purpose
	<p><b>Example:</b> For a physical interface: Device(config-ofa-switch) # of-port interface ethernet1/1</p> <p>For a port-channel interface: Device(config-ofa-switch) # of-port interface port-channel2</p>	<p>interface is not configured. The interface type must be in lowercase.</p> <ul style="list-style-type: none"> <li>• The interface must be designated for the Cisco Plug-in for OpenFlow logical switch only.</li> <li>• The <b>mode openflow</b> configuration is added to an interface when an interface is configured as a port of Cisco Plug-in for OpenFlow. To add or remove an interface as a port of Cisco Plug-in for OpenFlow, ensure that the Cisco Plug-in for OpenFlow is activated and running to ensure the proper automatic addition and removal of the <b>mode openflow</b> configuration. To remove an interface as a port of Cisco Plug-in for OpenFlow, use the no form of this command.</li> <li>• An interface configured for a port channel should not be configured as an Cisco Plug-in for OpenFlow logical switch port.</li> <li>• Repeat this step to configure additional interfaces.</li> </ul>
<b>Step 6</b>	<p><b>protocol-version</b> <i>version-info</i></p> <p><b>Example:</b> Device(config-openflow-switch) # protocol-version 1.0</p>	<p>Configures the protocol version.</p> <ul style="list-style-type: none"> <li>• Supported values are: <ul style="list-style-type: none"> <li>◦ <b>1.0</b>—Configures device to connect to 1.0 controllers only</li> <li>◦ <b>1.3</b>—Configures device to connect to 1.3 controllers only</li> <li>◦ <b>negotiate</b>—Negotiates the protocol version with the controller. Device uses 1.3 for negotiation.</li> </ul> </li> </ul> <p><b>Note</b> The default value is <b>negotiate</b>.</p> <ul style="list-style-type: none"> <li>• <b>drop</b> is the default action for both tables or pipeline 1. This can be overridden by this configuration or the controller.</li> </ul>
<b>Step 7</b>	<p><b>controller ipv4</b> <i>ip-address</i> [<b>port</b> <i>tcp-port</i>] [<b>vrf</b> <i>vrf-name</i>] <b>security</b> {<b>none</b>   <b>tls</b>}</p> <p><b>Example:</b> Controller in default VRF: Device(config-openflow-switch) # controller ipv4 10.1.1.2 security none</p>	<p>Specifies the IPv4 address, port number, and VRF of a controller that can manage the logical switch, port number used by the controller to connect to the logical switch and the VRF of the controller.</p> <ul style="list-style-type: none"> <li>• If unspecified, the default VRF is used.</li> <li>• Controllers use TCP port 6653 by default.</li> <li>• You can configure up to eight controllers. Repeat this step if you need to configure additional controllers.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>If TLS is not disabled in this step, configure TLS trustpoints in the next step.</li> <li>You can use the <b>clear openflow switch 1 controller all</b> command to clear controller connections. This command can reset a connection after Transport Layer Security (TLS) certificates and keys are updated. This is not required for TCP connections.</li> </ul> <p>A connection to a controller is initiated for the logical switch.</p>
<b>Step 8</b>	<b>default-miss cascade { drop   controller   normal   }</b>  <b>Example:</b> <pre>Device(config-ofa-switch)# default-miss cascade controller</pre>	<p>Configures the action to be taken for packets that do not match any of the flow defined.</p> <ul style="list-style-type: none"> <li><b>drop</b> is the default action for a pipeline.</li> <li>Configuring this step with the <b>normal</b> keyword is necessary for pipeline 202 (ACL Table) to add a default permit rule instead of the default drop rule.</li> </ul>
<b>Step 9</b>	<b>tls trust-point local local-trust-point remote remote-trust-point</b>  <b>Example:</b> <pre>Device(config-ofa-switch)# tls trust-point local mylocal remote myremote</pre>	<p>(Optional) Specifies the local and remote TLS trustpoints to be used for the controller connection.</p> <ul style="list-style-type: none"> <li>For information on configuring trustpoints, refer to <a href="#">PKI Trustpool Management</a> in the PKI Configuration guide.</li> </ul>
<b>Step 10</b>	<b>logging flow-mod</b>  <b>Example:</b> <pre>Device(config-ofa-switch)# logging flow-mod</pre>	<p>(Optional) Enables logging of flow changes, including addition, deletion, and modification of flows.</p> <ul style="list-style-type: none"> <li>Logging of flow changes is disabled by default.</li> <li>Flow changes are logged in syslog and can be viewed using the <b>show logging</b> command.</li> <li>Logging of flow changes is a CPU intensive activity and should not be enabled for networks greater than 1000 flows.</li> </ul>
<b>Step 11</b>	<b>probe-interval probe-interval</b>  <b>Example:</b> <pre>Device(config-openflow-switch)# probe-interval 5</pre>	<p>(Optional) Configures the interval, in seconds, at which the controller is probed.</p> <ul style="list-style-type: none"> <li>The default value is 5.</li> <li>The range is from 5 to 65535.</li> </ul>



	Command or Action	Purpose
<b>Step 12</b>	<b>rate-limit packet_in</b> <i>controller-packet-rate burst</i> <i>maximum-packets-to-controller</i>  <b>Example:</b> <pre>Device(config-openflow-switch)# rate-limit packet_in 1 burst 4</pre>	(Optional) Configures the maximum packet rate of the connection to the controller and the maximum packets permitted in a burst of packets sent to the controller in a second. <ul style="list-style-type: none"> <li>• The default value is zero, meaning that an indefinite packet rate and packet burst are permitted.</li> <li>• This rate limit is for Cisco Plug-in for OpenFlow. It is not related to the rate limit of the device (data plane) configured by COPP.</li> </ul>
<b>Step 13</b>	<b>max-backoff</b> <i>backoff-timer</i>  <b>Example:</b> <pre>Device(config-openflow-switch)# max-backoff 8</pre>	(Optional) Configures the time, in seconds, for which the device must wait before attempting to initiate a connection with the controller. <ul style="list-style-type: none"> <li>• The default value is eight.</li> <li>• The range is from 1 to 65535.</li> </ul>
<b>Step 14</b>	<b>end</b>  <b>Example:</b> <pre>Device(config-openflow-switch)# end</pre>	Exits logical switch configuration mode and enters privileged EXEC mode.
<b>Step 15</b>	<b>copy running-config startup-config</b>  <b>Example:</b> <pre>Device# copy running-config startup-config</pre>	Saves the change persistently by copying the running configuration to the startup configuration.

### What to Do Next

Verify Cisco Plug-in for OpenFlow.

## Verifying Cisco Plug-in for OpenFlow

### Procedure

#### Step 1 show openflow copyright

Displays copyright information related to Cisco Plug-in for OpenFlow.

#### Example:

```
Device# show openflow copyright
```

```

Cisco Plug-in for OpenFlow
TAC support: http://www.cisco.com/tac
Copyright (c) 2013-2015 by Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0, the GNU
Lesser General Public License (LGPL) Version 2.1, or or the GNU
Library General Public License (LGPL) Version 2. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php and
http://www.gnu.org/licenses/old-licenses/lgpl-2.0.txt

```

## Step 2 **show openflow switch *switch-id***

Displays information related to Cisco Plug-in for OpenFlow logical switch.

### Example:

```

Device# show openflow switch 1

Logical Switch Context
  Id: 1
  Switch type: Forwarding
  Pipeline id: 201
  Signal version: Openflow 1.0
  Data plane: secure
  Table-Miss default: NONE
  Config state: no-shutdown
  Working state: enabled
  Rate limit (packet per second): 0
  Burst limit: 0
  Max backoff (sec): 8
  Probe interval (sec): 5
  TLS local trustpoint name: not configured
  TLS remote trustpoint name: not configured
  Stats coll. period (sec): 5
  Logging flow changes: Disabled
  OFA Description:
    Manufacturer: Cisco Systems, Inc.
    Hardware: N3K-C3064PQ V01
    Software: 6.0(2)U2(1) of_agent 1.1.0_fc1
    Serial Num: SSI15200QD8
    DP Description: n3k-200-141-3:sw1
  OF Features:
    DPID:0001547fee00c2a0
    Number of tables:1
    Number of buffers:256
    Capabilities: FLOW_STATS TABLE_STATS PORT_STATS
    Actions: OUTPUT SET_VLAN_VID STRIP_VLAN SET_DL_SRC SET_DL_DST
  Controllers:
    1.1.1.1:6653, Protocol: TLS, VRF: s
  Interfaces:
    Ethernet1/1
    Ethernet1/7

```

## Step 3 **show openflow switch *switch-id* controllers [stats]**

Displays information related to the connection status between an Cisco Plug-in for OpenFlow logical switch and connected controllers.

### Example:

```

Device# show openflow switch 1 controllers

Logical Switch Id: 1
Total Controllers: 3
Controller: 1
  10.1.1.2:6653
  Protocol: tcp

```

```

VRF: default
Connected: No
Role: Master
Negotiated Protocol Version: disconnected
Last Alive Ping: N/A
last_error:No route to host
state:BACKOFF

Controller: 2
5.30.26.111:6800
Protocol: tcp
VRF: management
Connected: No
Role: Master
Negotiated Protocol Version: disconnected
Last Alive Ping: N/A
last_error:Connection timed out
state:CONNECTING
sec_since_disconnect:14

Controller: 3
10.1.1.2:6653
Protocol: tcp
VRF: management
Connected: No
Role: Master
Negotiated Protocol Version: disconnected
Last Alive Ping: N/A
last_error:Connection timed out
state:CONNECTING
sec_since_disconnect:13

```

The above sample output is displayed when controller is not yet connected.

Device# **show openflow switch 1 controllers stats**

```

Logical Switch Id: 1
Total Controllers: 3
Controller: 1
address                : tcp:10.1.1.2:6653
connection attempts    : 3009
successful connection attempts : 0
flow adds              : 0
flow mods              : 0
flow deletes           : 0
flow removals         : 0
flow errors            : 0
flow unencodable errors : 0
total errors           : 0
echo requests         : rx: 0, tx: 0
echo reply             : rx: 0, tx: 0
flow stats             : rx: 0, tx: 0
barrier                : rx: 0, tx: 0
packet-in/packet-out   : rx: 0, tx: 0

Controller: 2
address                : tcp:5.30.26.111:6800%management
connection attempts    : 1506
successful connection attempts : 0
flow adds              : 0
flow mods              : 0
flow deletes           : 0
flow removals         : 0
flow errors            : 0
flow unencodable errors : 0
total errors           : 0
echo requests         : rx: 0, tx: 0
echo reply             : rx: 0, tx: 0
flow stats             : rx: 0, tx: 0
barrier                : rx: 0, tx: 0
packet-in/packet-out   : rx: 0, tx: 0

Controller: 3

```

```

address                : tcp:10.1.1.2:6653%management
connection attempts   : 1506
successful connection attempts : 0
flow adds              : 0
flow mods              : 0
flow deletes           : 0
flow removals         : 0
flow errors            : 0
flow unencodable errors : 0
total errors           : 0
echo requests         : rx: 0, tx: 0
echo reply             : rx: 0, tx: 0
flow stats             : rx: 0, tx: 0
barrier                : rx: 0, tx: 0
packet-in/packet-out  : rx: 0, tx: 0

```

**Step 4 show openflow switch *switch-id* ports [hidden]**

Displays the mapping between physical device interfaces and ports of an Cisco Plug-in for OpenFlow logical switch.

**Example:**

```
Device# show openflow switch 1 ports
```

```

Logical Switch Id: 1
Port  Interface Name      Config-State  Link-State  Features
  2   Ethernet1/2         PORT_UP      LINK_UP     10MB-FD
  3   Ethernet1/3         PORT_UP      LINK_DOWN   100MB-HD AUTO_NEG
  4   Ethernet1/4         PORT_UP      LINK_UP     10MB-FD

```

**Step 5 show openflow switch *switch-id* flows [table-id *table-id*][configured | controller | default | fixed | pending | pending-del] [brief | summary]**

Displays flows defined for the device by controllers.

**Example:**

```
Device# show openflow switch 1 flows
```

```

Total flows: 2
Flow: 1
  Rule:                ip,d1_vlan=99
  Actions:              strip_svlan,output:1
  Priority:              0x8000
  Table:                0
  Cookie:               0x466c6f7732
  Duration:              96.359s
  Number of packets:    0
  Number of bytes:      0

Flow: 2
  Rule:                ip,in_port=2,d1_vlan=50
  Actions:              output:1
  Priority:              0x8000
  Table:                0
  Cookie:               0x1
  Duration:              95.504s
  Number of packets:    0
  Number of bytes:      0

```

```
Device# show openflow switch 1 flows configured
```

```

Logical Switch Id: 1
Total flows: 1

Flow: 1
  Match:
  Actions:              drop
  Priority:              0

```

```

Table:          0
Cookie:         0x0
Duration:       1937.586s
Number of packets: 0
Number of bytes: 0

```

```
Device# show openflow switch 1 flows fixed
```

```
Logical Switch Id: 1
Total flows: 0
```

### Step 6 show openflow switch *switch-id* stats

Displays send and receive statistics for each port defined for a Cisco Plug-in for OpenFlow logical switch.

#### Example:

```
Device# show openflow switch 1 stats
```

```
Logical Switch Id: 1

Total ports: 1
  Port 31: rx pkts=36688, bytes=7204655, drop=0, errs=0,
           tx pkts=0, bytes=3473880, drop=0, errs=0,
Total tables: 1
  Table 0: classifier
  Wildcards = 0x3ffffff
  Max entries = 1500
  Active entries = 0
  Number of lookups = 0
  Number of matches = 0

```

Flow statistics are available for pipeline 201 and table 0. For pipeline 202, flow statistics are not available for table 1.

### Step 7 show interfaces *type number* counters

Displays send and receive statistics for the specified port defined for an Cisco Plug-in for OpenFlow logical switch.

#### Example:

### Step 8 show logging last *number-of-lines*

Displays logging information of flow changes, including addition, deletion or modification of flows.

#### Example:

```
Device# show logging last 14
```

```

2013 Mar 15 19:13:05 n3k-202-194-4 %VMAN-2-ACTIVATION_STATE: Successfully activa
ted virtual service 'n3k'
2013 Mar 15 19:13:23 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: E
rror: Didn't get initial config when booting up
2013 Mar 15 19:13:50 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flows flushed for sw1, type:cisco-12
2013 Mar 15 19:13:54 n3k-202-194-4 %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configured from
vty by admin on console0
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=3 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=4 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=5 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=6 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O

```

```

VS: Flow created: Rule: ip,d1_vlan=7 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=8 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=9 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=10 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=11 Actions: output:2,output:7
2013 Mar 15 19:14:09 n3k-202-194-4 %VMAN-5-VIRT_INST: VIRTUAL SERVICE n3k LOG: O
VS: Flow created: Rule: ip,d1_vlan=12 Actions: output:2,output:7

```

**Step 9 show running-config | section openflow**

Displays configurations made for Cisco Plug-in for OpenFlow.

**Example:**

```
Device# show running-config | section "openflow"
```

```

openflow
  switch 1
    pipeline 201
      controller ipv4 10.86.201.162 port 8050 vrf management security none
      of-port interface ethernet1/1
      of-port interface ethernet1/2
      of-port interface ethernet1/3
      of-port interface ethernet1/37
      of-port interface ethernet1/4

```

**Step 10 show openflow hardware capabilities**

Displays Cisco Plug-in for OpenFlow configurations.

**Example:**

```
Device# show openflow hardware capabilities
```

```

Pipeline ID: 201

Flow table ID: 0

Match Capabilities
-----
ethernet type
VLAN ID
VLAN priority code point
IP DSCP
IP protocol
IPv4 source address
IPv4 destination address
source port
destination port
in port (virtual or physical)

Match Types
-----
mandatory
optional
optional
optional
optional
lengthmask
lengthmask
optional
optional
optional

Actions:
  output to: specified interface, use normal forwarding, controller
  set: set eth source mac, set eth destination mac, set vlan id
  pop: pop vlan tag
  other actions: drop packet

```

```
Pipeline ID: 202
```

```

Flow table ID: 0

Match Capabilities
-----
ethernet type
VLAN ID

Match Types
-----
mandatory
optional

```

```

VLAN priority code point      optional
IP DSCP                       optional
IP protocol                   optional
IPv4 source address          lengthmask
IPv4 destination address     lengthmask
source port                   optional
destination port             optional
in port (virtual or physical) optional

Actions:
  output to: specified interface, use normal forwarding, controller
  set: set eth source mac, set eth destination mac, set vlan id
  pop: pop vlan tag
  other actions: drop packet

Flow table ID: 1

Match Capabilities           Match Types
-----
ethernet mac destination    mandatory
VLAN ID                     mandatory

Actions:
  output to: specified interface
  other actions: drop packet

```

---

## Configuration Examples for Cisco Plug-in for OpenFlow

### Example: Enabling Hardware Support for Cisco Plug-in for OpenFlow

```

Device> enable
Device# configure terminal
! Enables support for OpenFlow VLAN tagging actions.
Device(config)# hardware profile openflow
Device# copy running-config startup-config
Device# reload

```

### Example: Adjusting the Number of Flow Entries

```

Device> enable
Device# configure terminal
Device(config)# hardware profile tcam region vacl 0
Device(config)# hardware profile tcam region e-racl 0
Device(config)# hardware profile tcam region e-vacl 0
Device(config)# hardware profile tcam region racl 256
Device(config)# hardware profile tcam region ifacl 1664
Device(config)# exit
Device# copy running-config startup-config
Device# reload

```

### Example: Configuring Global Variables for a Cisco Plug-in for OpenFlow Logical Switch

```

Device> enable

Device# configure terminal
Device(config)# mac-learn disable
Device(config)# spanning-tree mode mst
Device(config)# vlan 2
Device(config-vlan)# end

```

**Example: Configuring Control Plane Policing for Packets Sent to a Controller**

```
Device> enable
```

```
Device# configure terminal
```

```
Device# setup
```

```
----- Basic System Configuration Dialog -----
```

This setup utility will guide you through the basic configuration of the system. Setup configures only enough connectivity for management of the system.

\*Note: setup is mainly used for configuring the system initially, when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

```
Would you like to enter the basic configuration dialog (yes/no): yes
```

```
Create another login account (yes/no) [n]:
```

```
Configure read-only SNMP community string (yes/no) [n]:
```

```
Configure read-write SNMP community string (yes/no) [n]:
```

```
Enter the switch name : QI32
```

```
Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: n
```

```
Configure the default gateway? (yes/no) [y]: n
```

```
Enable the telnet service? (yes/no) [n]: y
```

```
Enable the ssh service? (yes/no) [y]: n
```

```
Configure the ntp server? (yes/no) [n]:
```

```
Configure default interface layer (L3/L2) [L2]:
```

```
Configure default switchport interface state (shut/noshut) [noshut]:
```

```
Configure CoPP System Policy Profile ( default / 12 / 13 ) [default]:
```

The following configuration will be applied:

```
switchname QI32
telnet server enable
no ssh server enable
system default switchport
no system default switchport shutdown
policy-map type control-plane copp-system-policy ( default )
```

```
Would you like to edit the configuration? (yes/no) [n]:
```

```
Use this configuration and save it? (yes/no) [y]:
```

```
[#####] 100%
Copy complete, now saving to disk (please wait)...
```

```
Device# configure terminal
```

```
Device(config)# policy-map type control-plane copp-system-policy
```

```
Device(config-pmap)# class copp-s-dpss
```

```
Device(config-pmap-c)# police pps 1000
```

```
Device(config-pmap-c)# end
```

```
Device# show run copp
```



**Example: Specifying a Route to a Controller Using a Physical Interface**

```

Device> enable
Device# switchto vdc openflow
Device# configure terminal
Device(config)# interface GigabitEthernet1/1
Device(config-if)# no switchport
Device(config-if)# ip address 10.0.1.4 255.255.255.255
Device(config-if)# exit
Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6
Device# copy running-config startup-config
Device(config)# exit

```

**Example: Specifying a Route to a Controller Using a Management Interface**

```

Device> enable

Device# configure terminal
Device(config)# interface mgmt0
Device(config-if)# no switchport
Device(config-if)# ip address 10.0.1.4 255.255.255.255
Device(config-if)# exit
Device(config)# vrf context management
Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6
Device(config)# exit
Device# copy running-config startup-config

```

**Example: Installing and Activating Cisco Plug-in for OpenFlow**

Refer to *Installing and Activating an Application in a Virtual Services Container* for an example of installing and activating Cisco Plug-in for OpenFlow in a virtual services container of a device.

**Example: Configuring an Interface for a Cisco Plug-in for OpenFlow Logical Switch in L2 mode**

```

Device> enable

Device# configure terminal

Device(config)# interface ethernet1/1
Device(config-if)# switchport mode trunk
Device(config-if)# no shutdown
Device(config-if)# exit

Device(config)# interface ethernet1/2
! Adding the interface to a port channel.
Device(config-if)# channel-group 2
Device(config-if)# switchport mode trunk
Device(config-if)# no shutdown
Device(config-if)# end
Device# copy running-config startup-config

```

**Example: Configuring a Port-Channel Interface**

```

Device> enable
Device# configure terminal
Device(config)# interface port-channel 2
Device(config-if)# switchport mode trunk
Device(config-if)# mac packet-classify
Device(config-if)# end
Device# copy running-config startup-config

```

**Example: Cisco Plug-in for OpenFlow Logical Switch Configuration (Default VRF)**

```

Device> enable

Device# configure terminal

```

```

Device(config)# openflow
Device(config-ofa)# switch 1
! Specifies the pipeline that enables the IP Forwarding Table.
Device(config-ofa-switch)# pipeline 201

Device(config-ofa-switch)# logging flow-mod
Device(config-ofa-switch)# tls trust-point local local-trustpoint-name remote
remote-trustpoint-name
Device(config-ofa-switch)# max-backoff 5
Device(config-ofa-switch)# probe-interval 5
Device(config-ofa-switch)# rate-limit packet-in 30 burst 50
Device(config-ofa-switch)# controller ipv4 10.0.1.6 security none

! Adding an interface to the Cisco Plug-in for OpenFlow logical switch.

Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface ethernet1/2

! Adding a port channel to the Cisco Plug-in for OpenFlow switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

### Example: Configuring a Cisco Plug-in for OpenFlow Logical Switch (Management VRF)

```

Device> enable

Device# configure terminal

Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# pipeline 201
Device(config-ofa-switch)# pipeline 1
! Specifying a controller that is part of a VRF.

! Adding an interface to the Cisco Plug-in for OpenFlow logical switch.

! Adding a port channel to the Cisco Plug-in for OpenFlow switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

## Additional Information for Cisco Plug-in for OpenFlow

### Related Documents

Related Topic	Document Title
Cisco commands	<a href="#">Cisco Nexus 3000 Series Switches Command References</a>
	<a href="#">Cisco Nexus 5000 Series Switches Command References</a>
	<a href="#">Cisco Nexus 6000 Series Switches Command References</a>

**Standards and RFCs**

Standard/RFC	Title
OpenFlow 1.3	<i>OpenFlow Switch Specification Version 1.3.0 (Wire Protocol 0x04).</i>
OpenFlow 1.0	<i>OpenFlow Switch Specification Version 1.0.1 (Wire Protocol 0x01).</i>

**Technical Assistance**

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation and tools. Use these resources to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>

## Feature Information for Cisco Plug-in for OpenFlow

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

**Table 2: Feature Information for Cisco Plug-in for OpenFlow**

Releases	Supported Platforms	Feature Information
Cisco Plug-in for OpenFlow Release 1.1.5	The supported platforms are Nexus 3000 Series Devices.  The Nexus 3548-X device is supported in NX-OS software release 6.0(2)A6(2) and higher.	Cisco Plug-in for OpenFlow supports OFA decommissioning.

Releases	Supported Platforms	Feature Information
Cisco Plug-in for OpenFlow Release 1.1.1	The supported platforms are: <ul style="list-style-type: none"> <li>• Nexus 3000 Series Devices</li> <li>• Nexus 5000 Series Devices</li> <li>• Nexus 6000 Series Devices</li> </ul>	Cisco Plug-in for OpenFlow now supports Nexus 5000 and 6000 Series.
Cisco Plug-in for OpenFlow Release 1.1	The supported platforms are Nexus 3000 Series Devices.	<ul style="list-style-type: none"> <li>• The OpenFlow hybrid (ships-in-night) model is supported.</li> <li>• L3 ACL and L2 MAC forwarding tables are supported and can be configured using pipelines.</li> <li>• Transport Layer Security (TLS) is supported in Cisco Plug-in for OpenFlow and controller communications.</li> <li>• VLAN priority has been introduced as a flow action.</li> </ul> <p>The following commands have been introduced: <b>clear openflow, max-backoff, probe-interval, rate-limit, tls trust-point</b>.</p> <p>The <b>controller</b> command has been modified to include the <b>no-tls</b> keyword.</p>
Cisco Plug-in for OpenFlow Release 1.0.1	The supported platforms are Nexus 3000 Series Devices.	The following flow actions are supported: <ul style="list-style-type: none"> <li>• Modify source MAC address</li> <li>• Modify destination MAC address</li> </ul>

Releases	Supported Platforms	Feature Information
Cisco Plug-in for OpenFlow Release 1.0	The supported platforms are Nexus 3000 Series Devices.	Cisco Plug-in for OpenFlow supports OpenFlow 1.0, and helps networks become more open, programmable, and application-aware.





## CHAPTER 2

# Virtual Services Container

---

This chapter contains the following sections:

- [Virtual Services Container, page 39](#)

## Virtual Services Container

### Prerequisites for a Virtual Services Container

- You must have a Cisco device installed with an operating system release that supports virtual services and has the needed system infrastructure required for specific applications like Cisco Plug-in for OpenFlow.



---

**Note**

A compatibility matrix is delivered with each Cisco application. Refer to this matrix for information about which operating system release supports the features and infrastructure necessary for a particular application such as Cisco Plug-in for OpenFlow.

---

- You must download an open virtual application (OVA) package that is compatible with the device operating system, and downloaded from an FTP server connected to the device.
- You must have enough memory for installation and deployment of application. Refer to the application configuration guide for specific recommendations.

## Information About Virtual Services Container

### Virtual Services Containers and Applications

A virtual services container is a virtualized environment on a device. It is also referred to as a virtual machine (VM), virtual service, or container.

You can install an application within a virtual services container. The application runs in the virtual services container of the operating system of a device. The application is delivered as an open virtual application (OVA), which is a tar file with a .ova extension. The OVA package is installed and enabled on a device through the device CLI.

Cisco Plug-in for OpenFlow is an example of an application that can be deployed within a virtual services container.

Some of the files that can be found in an OVA file are the following:

- Virtual machine definition file, in libvirt XML format, with Cisco extensions.
- Manifest file, listing the contents of a distribution. It contains the hash information for each file in the OVA package.
- Certificate file containing the signature of a manifest file. This file is used in validating the integrity of an OVA package.
- Version file, used to check compatibility with the virtualization infrastructure.

## How to Configure a Virtual Services Container

This section includes the following required and optional tasks:

- [Installing and Activating an Application in a Virtual Services Container](#), on page 40 (required)
- [Deactivating and Uninstalling an Application from a Virtual Services Container](#), on page 42
- [Upgrading an Application in a Virtual Services Container](#), on page 43
- [Collecting General Troubleshooting Information](#), on page 45
- [Verifying Virtual Services Container Applications](#), on page 47

### Installing and Activating an Application in a Virtual Services Container

This task copies an open virtual application (OVA) package from an FTP file location, installs the application in a virtual services container, provisions the application, and activates it.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>copy</b> <i>from://source-directory-url destination-directory-url</i>  <b>Example:</b> Device# copy tftp://myserver.com/downloads/ofa-1.0.0-n3000-SPA-k9.ova bootflash:/ofa-1.0.0-n3000-SPA-k9.ova	Downloads the new OVA package to the device for upgrade. Possible values are: <ul style="list-style-type: none"> <li>• sftp:</li> <li>• tftp:</li> </ul>



	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• ftp:</li> <li>• http:</li> <li>• bootflash:</li> </ul>
<b>Step 3</b>	<b>virtual-service install name <i>virtual-services-name</i> package file</b>  <b>Example:</b> <pre>Device# virtual-service install name openflow_agent package bootflash:/ofa-1.0.0-n3000-SPA-k9.ova</pre>	Installs an OVA package from the specified location onto a device. Ensure that the ova file is located in the root directory of the storage device <ul style="list-style-type: none"> <li>• The <i>virtual-services-name</i> defined here should be used in all occurrences of this argument in this document.</li> </ul>
<b>Step 4</b>	<b>configure terminal</b>  <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 5</b>	<b>virtual-service <i>virtual-services-name</i></b>  <b>Example:</b> <pre>Device(config)# virtual-service openflow_agent</pre>	Configures a virtual services container and enters virtual services configuration mode. <ul style="list-style-type: none"> <li>• Use the <i>virtual-services-name</i> defined during installation of the application.</li> <li>• Ensure that installation is complete before proceeding to the next step using the <b>show virtual-service list</b> command.</li> </ul>
<b>Step 6</b>	<b>activate</b>  <b>Example:</b> <pre>Device(config-virt-serv)# activate</pre>	Activates the installed virtual services container.
<b>Step 7</b>	<b>end</b>  <b>Example:</b> <pre>Device(config-virt-serv)# end</pre>	Exits virtual services configuration mode and enters privileged EXEC mode.
<b>Step 8</b>	<b>copy running-config startup-config</b>  <b>Example:</b> <pre>Device# copy running-config startup-config</pre>	Saves the change persistently through reboots and restarts by copying the running

	Command or Action	Purpose
		configuration to the startup configuration.

### What to Do Next

You can now begin using your application.

## Deactivating and Uninstalling an Application from a Virtual Services Container

(Optional) Perform this task to uninstall and deactivate an application from within a virtual services container.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode.  • Enter your password if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 3</b>	<b>virtual-service <i>virtual-services-name</i></b>  <b>Example:</b> Device(config)# virtual-service openflow_agent	Enters virtual services configuration mode to configure a specified application.  • Use the <i>virtual-services-name</i> defined during installation of the application.
<b>Step 4</b>	<b>no activate</b>  <b>Example:</b> Device(config-virt-serv)# no activate	Disables the application.
<b>Step 5</b>	<b>no virtual-service <i>virtual-services-name</i></b>  <b>Example:</b> Device(config)# no virtual-service openflow_agent	Unprovisions the application.  • Use the <i>virtual-services-name</i> defined during installation of the application.  • This command is optional for all devices running Cisco IOS-XE.

	Command or Action	Purpose
<b>Step 6</b>	<b>end</b>  <b>Example:</b> Device(config-virt-serv)# end	Exits virtual services configuration mode and enters privileged EXEC mode.
<b>Step 7</b>	<b>virtual-service uninstall name</b> <i>virtual-services-name</i>  <b>Example:</b> Device# virtual-service uninstall name openflow_agent	Uninstalls the application. <ul style="list-style-type: none"> <li>• Use the <i>virtual-services-name</i> defined during installation of the application.</li> <li>• Run this command only after receiving a successful deactivation response from the device.</li> </ul>
<b>Step 8</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

## Upgrading an Application in a Virtual Services Container

(Optional) Perform this task to upgrade a virtual services container application.



### Note

An application upgrade may require an upgrade of the device operating system. Check the compatibility matrix of the respective application software release before upgrading it.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>copy from://source-directory-url destination-directory-url</b>  <b>Example:</b> Device# copy tftp://myserver.com/downloads/ofa-1.0.0-n3000-SPA-k9.ova bootflash:/ofa-1.0.0-n3000-SPA-k9.ova	Downloads the new OVA package to the device for upgrade. Possible values are: <ul style="list-style-type: none"> <li>• sftp:</li> <li>• tftp:</li> <li>• ftp:</li> <li>• http:</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• bootflash:</li> </ul>
<b>Step 3</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 4</b>	<b>virtual-service <i>virtual-services-name</i></b>  <b>Example:</b> Device(config)# virtual-service openflow_agent	Enters virtual services configuration mode for configuring a specified application. <ul style="list-style-type: none"> <li>• Use the <i>virtual-services-name</i> defined during installation of the application.</li> </ul>
<b>Step 5</b>	<b>no activate</b>  <b>Example:</b> Device(config-virt-serv)# no activate	Disables the application.
<b>Step 6</b>	<b>end</b>  <b>Example:</b> Device(config-virt-serv)# end	Exits virtual services configuration mode and enters privileged EXEC mode.
<b>Step 7</b>	<b>virtual-service upgrade name <i>virtual-services-name</i> package file</b>  <b>Example:</b> Device# virtual-service upgrade name openflow_agent package bootflash:/ofa-1.0.0-n3000-SFA-k9.ova	Upgrades the application using the specified OVA file. <ul style="list-style-type: none"> <li>• Use the <i>virtual-services-name</i> defined during installation of the application.</li> <li>• Run this command only after receiving a successful deactivation message from the device.</li> </ul>
<b>Step 8</b>	<b>configure terminal</b>  <b>Example:</b> Device# configure terminal	Enters global configuration mode.
<b>Step 9</b>	<b>virtual-service <i>virtual-services-name</i></b>  <b>Example:</b> Device(config)# virtual-service openflow_agent	Enters virtual services configuration mode for configuration of the specified application.

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>Use the <i>virtual-services-name</i> defined during installation of the application.</li> </ul>
<b>Step 10</b>	<b>activate</b>  <b>Example:</b> Device(config-virt-serv)# activate	Activates the application.
<b>Step 11</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

### What to Do Next

You can now begin using your application.

## Collecting General Troubleshooting Information

Information collected using the commands listed below can be sent to Cisco Technical Support for troubleshooting purposes.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>show system sysmgr service name vman</b>  <b>Example:</b> Device# <b>show system sysmgr service name vman</b>  Service "vman" ("vman", 209): UUID = 0x49B, PID = 3283, SAP = 808 State: SRV_STATE_HANDSHAKED (entered at time Tue Mar 5 01:11:41 2013). Restart count: 1 Time of last restart: Tue Mar 5 01:11:41 2013.  The service never crashed since the last reboot.  Tag = N/A Plugin ID: 0	This command shows the health of the virtualization manager (VMAN) process.
<b>Step 2</b>	<b>show system virtual-service event-history debug</b>	

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre>Device# show system virtual-service event-history debug  1) Event:E_VMAN_MSG, length:42, at 373061 usecs after Thu May 9 20:03:45 2013 (debug): Queueing unprocessed MTS message  2) Event:E_VMAN_MSG, length:42, at 92367 usecs after Thu May 9 19:53:29 2013 (debug): Queueing unprocessed MTS message  3) Event:E_VMAN_MSG, length:42, at 300136 usecs after Thu May 9 19:53:21 2013 (debug): Queueing unprocessed MTS message  4) Event:E_VMAN_MSG, length:42, at 56305 usecs after Thu May 9 19:51:22 2013 (debug): Queueing unprocessed MTS message  5) Event:E_VMAN_MSG, length:91, at 209708 usecs after Thu May 9 09:57:23 2013 (debug): Storage(MB): pools(265) committed(275) quota(600) credit(0), libvirt is connected  6) Event:E_VMAN_MSG, length:70, at 209700 usecs after Thu May 9 09:57:23 2013 (debug): Disk space committed by pool virt_strg_pool_bf_vdc_1 = 275MB</pre>	
<b>Step 3</b>	<p><b>show logging level virtual-service</b></p> <p><b>Example:</b></p> <pre>Device# show logging level virtual-service  Facility          Default Severity      Current Session Severity ----- ----- virtual-service          5                      5  0(emergencies)          1(alerts)              2(critical) 3(errors)                4(warnings)            5(notifications) 6(information)          7(debugging)</pre>	This command contains information related to the VMAN configuration.
<b>Step 4</b>	<p><b>show logging last <i>number-of-lines</i>   include VMAN</b></p> <p><b>Example:</b></p> <pre>Device# show logging last 100   include VMAN  2013 May 8 18:31:26 n3k-202-194-2 %VMAN-2-INSTALL_STATE: Successfully installed virtual service 'openflow agent' 2013 May 8 18:57:15 n3k-202-194-2 %VMAN-2-ACTIVATION_STATE: Successfully activa ted virtual service 'openflow_agent'</pre>	This command shows the VMAN logging configuration and contents of log files.

	Command or Action	Purpose
	<pre>2013 May 8 18:57:15 n3k-202-194-2 %VMAN-5-VIRT_INST: LOG FROM VIRTUAL SERVICE n 3k: OVS: swl&lt;-&gt;tcp:10.86.201.161:6633%management: connected 2013 May 9 14:58:47 n3k-202-194-2 %VMAN-5-VIRT_INST: LOG FROM VIRTUAL SERVICE n 3k: OVS: swl&lt;-&gt;tcp:10.44.94.173:6633%management: connected 2013 May 9 15:00:05 n3k-202-194-2 %VMAN-5-VIRT_INST: LOG FROM VIRTUAL SERVICE n 3k: OVS: swl&lt;-&gt;tcp:10.168.1.31:7777: connected</pre>	
<b>Step 5</b>	<p><b>virtual-service move name <i>virtual-services-name</i> [core   log] to <i>destination-url</i></b></p> <p><b>Example:</b> Device# <b>virtual-service move name openflow_agent core to bootflash:/</b></p>	Moves application log or core files to a specified destination location. This command can be used when the application running in the container has an issue (but the container is running as expected).
<b>Step 6</b>	<p><b>show mgmt-infra trace settings vman_trace</b></p> <p><b>Example:</b> Device# <b>show mgmt-infra trace settings vman_trace</b></p> <p>One shot Trace Settings:</p> <pre>Buffer Name: vman_trace Default Size: 262144 Current Size: 262144 Traces Dropped due to internal error: Yes Total Entries Written: 2513 One shot mode: No One shot and full: No Disabled: False</pre>	This command displays trace settings of a trace buffer.
<b>Step 7</b>	<p><b>set trace control vman_trace buffer-size <i>buffer-size</i></b></p>	This command sets the trace buffer size.
<b>Step 8</b>	<p><b>set trace control vman_trace clear [location active]</b></p>	This command clears the trace buffer.
<b>Step 9</b>	<p><b>set trace vman_trace level {debug   default   err   info   warning} [location active]</b></p>	This command sets the trace level.

## Verifying Virtual Services Container Applications

### Procedure

- Step 1** **show virtual-service [global]**  
This command displays available memory, disk space, and CPU allocated for applications.

**Example:**

```
Device# show virtual-service

Virtual Service Global State and Virtualization Limits:

Infrastructure version : 1.3
Total virtual services installed : 1
Total virtual services activated : 1

Maximum memory for virtualization : 768 MB
Maximum HDD storage for virtualization : 0 MB
Maximum bootflash storage for virtualization : 600 MB
Maximum system CPU : 6%
Maximum VCPUs per virtual service : 1

Committed memory          : 700 MB
Committed disk storage    : 275 MB
Committed system CPU      : 1%

Available memory          : 68 MB
Available disk storage    : 165 MB
Available system CPU      : 5%
Machine types supported   : LXC
Machine types disabled   : KVM
```

**Step 2 show virtual-service detail [name *virtual-services-name*]**

This command displays a list of resources committed to a specified application, including attached devices.

**Example:**

```
Device# show virtual-service detail name openflow_agent

Virtual service openflow_agent detail
State : Activated
Package information
Name : ofa-0.1.0_46-n3000-SSA-k9.ova
Path : bootflash:/ofa-0.1.0_46-n3000-SSA-k9.ova
Application
Name : CiscoPluginForOpenFlow
Installed version : 1.1.0_fc1
Description : Cisco Plug-in for OpenFlow
Signing
Key type : Cisco release key
Method : SHA-1
Licensing
Name : None
Version : None
Resource reservation
Disk : 275 MB
Memory : 700 MB
CPU : 1% system CPU

Attached devices
Type Name Alias
-----
Watchdog watchdog-226.0
Serial/Trace serial3
Serial/Syslog serial2
Serial/aux
Serial/shell
Disk /mnt/core
Disk /mnt/ofa
Disk _rootfs
```

**Step 3 show virtual-service list**

This command displays an overview of resources utilized by the applications.



**Example:**

```
Device# show virtual-service list
Virtual Service List:
```

Name	Status	Package Name
openflow_agent	Activated	ofa-0.1.0_46-n3000-SSA-k9.ova

**Step 4 show virtual-service storage pool list**

This command displays an overview of storage locations (pools) used for virtual service containers.

**Example:**

```
Device# show virtual-service storage pool list
```

```
Virtual-Service storage pool list
```

Name	Pool Type	Path
virt_strg_pool_bf_vdc_1	directory	/bootflash/virt_strg_pool_bf_vdc_1

**Step 5 show virtual-service storage volume list**

This command displays an overview of storage volume information for virtual service containers.

**Example:**

```
Device# show virtual-service storage volume list
```

```
Virtual-Service storage volume list
```

Name	Capacity	In Use	Virtual-Service
_rootfs.ofa	90 MB	Yes	ofa

**Step 6 show virtual-service version name *virtual-services-name* installed**

This command displays the version of an installed application.

**Example:**

```
Device# show virtual-service version name openflow_agent installed
```

```
Virtual service openflow_agent installed version:
```

```
Name : CiscoPluginForOpenFlow
Version : 1.1.0_fc1
```

**Step 7 show virtual-service tech-support**

Displays all relevant container-based information.

**Step 8 show virtual-service redundancy state****Example:**

```
Device# show virtual-service redundancy state
```

```
Device# show virtual-service redundancy state
Virtual Service Redundancy State:
```

Switch No.	Role	Configure sync status	OVA sync status
3	Active	N/A	N/A

Displays state of virtual-services.

**Step 9** show virtual-service utilization name *virtual-services-name*

**Example:**

```
cat4k-openflow1#sh virtual-service utilization name openflow_agent
Virtual-Service Utilization:
```

CPU Utilization:

```
CPU Time: 0 % (30 second average)
CPU State: R : Running
```

Memory Utilization:

```
Memory Allocation: 262144 Kb
Memory Used: 19148 Kb
```

Storage Utilization:

```
Name: _rootfs, Alias: _rootfs
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 89243 Used(1K blocks): 66976
Available(1K blocks): 17659 Usage: 80 %
Name: cisco, Alias: cisco
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 861512 Used(1K blocks): 218216
Available(1K blocks): 643296 Usage: 26 %
Name: /mnt/ofa, Alias: /mnt/ofa
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 4955 Used(1K blocks): 35
Available(1K blocks): 4664 Usage: 1 %
Name: /cisco/core, Alias: /cisco/core
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 138119 Used(1K blocks): 91053
Available(1K blocks): 39935 Usage: 70 %
Name: /tmp1, Alias: /tmp1
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 861512 Used(1K blocks): 218216
Available(1K blocks): 643296 Usage: 26 %
Name: /cisco123, Alias: /cisco123
RD Bytes: 0 WR Bytes: 0
RD Requests: 0 WR Requests: 0
Errors: 0
Capacity(1K blocks): 856308 Used(1K blocks): 19200
Available(1K blocks): 837108 Usage: 3 %
```

Displays virtual-services utilization information.

**Step 10** show virtual-service utilization statistics CPU

Displays virtual service CPU utilization statistics.

## Troubleshooting Virtual Services Containers

### Troubleshooting Installation of Applications in a Virtual Services Container

**Problem** Installation of an application in a virtual services container is not successful.

**Possible Cause** Installation of the application may still be ongoing.

**Solution** Check the status of the installation using the **show virtual-service list** command. The following is sample output when the application has an Installed status.

```
Device# show virtual-service list

Virtual Service List:
Name                Status              Package Name
-----
multiova            Activated           multiova-working.ova
WAAS                Installed           ISR4451X-WAAS-5.2.0-b...
```

**Possible Cause** An application with the same name has already been installed.

**Solution** Ensure that an application of the same name has not been installed using the **show virtual-service list** command. You can verify this by referencing the Name field.

**Possible Cause** The target media has not been installed. Target media for various devices are given below:

- **Possible Cause** Cisco Nexus 3000 Series device—bootflash
- **Possible Cause** Cisco 4500 Series device—bootflash
- **Possible Cause** Cisco 3850 and 3650 device—flash

**Solution** Ensure that the target media is installed using the **show version** command.

```
Device# show version

Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Documents: http://www.cisco.com/en/US/products/ps9372/tsd_products_support_series_home.html
Copyright (c) 2002-2013, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
other third parties and are used and distributed under license.
Some parts of this software are covered under the GNU Public
License. A copy of the license is available at
http://www.gnu.org/licenses/gpl.html.

Software
  BIOS:          version 1.2.0
  loader:        version N/A
  kickstart:     version 6.0(2)U1(1)
  system:        version 6.0(2)U1(1)
  Power Sequencer Firmware:
    Module 1:    version v4.4
  BIOS compile time:      08/25/2011
  kickstart image file is: bootflash:///n3000-uk9-kickstart.6.0.2.U1.0.78.bin
  kickstart compile time: 5/7/2013 12:00:00 [05/07/2013 19:45:30]
  system image file is:   bootflash:///n3000-uk9.6.0.2.U1.0.78.bin
  system compile time:    5/7/2013 12:00:00 [05/07/2013 20:54:48]

Hardware
```

```
cisco Nexus 3048 Chassis ("48x1GE + 4x10G Supervisor")
Intel(R) Celeron(R) CPU P450 with 3980876 kB of memory.
Processor Board ID FOC16434LJ2
```

```
Device name: n3k-202-194-2
bootflash: 2007040 kB
```

```
Kernel uptime is 0 day(s), 19 hour(s), 5 minute(s), 45 second(s)
```

```
Last reset at 132996 usecs after Wed May 8 18:27:54 2013
```

```
Reason: Reset Requested by CLI command reload
System version: 6.0(2)U1(1)
Service:
```

```
plugin
Core Plugin, Ethernet Plugin
```

**Possible Cause** There is insufficient space to install an application.

**Solution** Ensure that sufficient space exists using the **dir** command.

```
Device# dir bootflash:
```

```

407      May 08 21:35:52 2013  admin.rc.cli
1332     Feb 28 16:51:27 2013  bxmnt-n3k
3348     May 08 16:21:57 2013  config-sumana-08-may-13
2826744  Feb 13 15:00:49 2013  dd2
2826744  Jan 30 15:26:15 2013  dplug
10273827 Apr 10 03:09:52 2013  gdb
123496   Apr 10 03:12:46 2013  libexpat.so.0
2016     Feb 28 15:18:33 2013  linux-mount-setup-n3k
2826744  Jan 29 19:51:24 2013  lltor-dplug_md.bin
49152    Nov 29 00:52:45 2012  lost+found/
1903     Jan 11 16:08:49 2013  mts.log
31884800 Apr 01 18:40:52 2013  n3000-uk9-kickstart.6.0.2.U1.0.36.bin
31864320 Apr 08 15:53:00 2013  n3000-uk9-kickstart.6.0.2.U1.0.44.bin
32757760 May 08 16:37:08 2013  n3000-uk9-kickstart.6.0.2.U1.0.78.bin
232540777 Apr 04 18:24:30 2013  n3000-uk9.6.0.2.U1.0.40.bin
232535711 Apr 08 15:51:49 2013  n3000-uk9.6.0.2.U1.0.44.bin
232632475 May 08 16:36:35 2013  n3000-uk9.6.0.2.U1.0.78.bin
53555200 May 08 15:37:44 2013  n3k_ofa.ova
55101440 Feb 28 20:27:39 2013  n3k_ofa.ova-gdb
52613120 Apr 04 18:26:55 2013  n3k_ofa.ova.port-channel2
58675200 Feb 01 14:47:44 2013  n3k_ofa.ova1
58675200 Feb 01 20:40:47 2013  n3k_ofa.ova31-6
2201210  Feb 27 20:30:02 2013  of_agent
56729600 May 08 16:41:33 2013  ofa-0.1.0_46-n3000-SSA-k9.ova
4096     Jan 29 17:52:15 2013  onep/
8552     Apr 04 18:10:50 2013  saveApril3
7536     Feb 28 19:08:06 2013  saveConfigFeb28
4096     Jan 29 00:48:00 2010  vdc_2/
4096     Jan 29 00:48:00 2010  vdc_3/
4096     Jan 29 00:48:00 2010  vdc_4/
4096     May 08 18:56:52 2013  virt_strg_pool_bf_vdc_1/
4096     Apr 09 20:24:06 2013  virtual-instance/
0        May 08 16:51:44 2013  virtual-instance-upgrade.conf
63       May 08 16:51:44 2013  virtual-instance.conf
```

```
Usage for bootflash://sup-local
1558257664 bytes used
90365952 bytes free
1648623616 bytes total
```

**Possible Cause** Disk quota for container is insufficient.

**Solution** Ensure that disk quota available for virtual services is sufficient using the **show virtual-services global** command.

```

Device# show virtual-service global

Virtual Service Global State and Virtualization Limits:

Infrastructure version : 1.5
Total virtual services installed : 1
Total virtual services activated : 1

Machine types supported   : LXC
Machine types disabled   : KVM

Maximum VCPUs per virtual service : 1
Resource virtualization limits:
Name                       Quota      Committed   Available
-----
system CPU (%)             6           1           5
memory (MB)                256        256         0
bootflash (MB)            256        164         92

```

**Possible Cause** An invalid OVA package has been used for installation (Invalid package/Parsing error/Invalid machine specification error).

**Solution** Ensure that the OVA package copied to the device matches in size with the OVA package on the FTP server. Refer to the compatibility matrix for details or Contact Cisco Technical Support to ensure that the OVA file provided is compatible with the device operating system and not corrupted.

**Possible Cause** The virtual services container does not install properly due to unknown reasons.

**Solution** Uninstall the virtual services container. If the problem persists, collect general troubleshooting information and contact Cisco Technical Support. For more information, see [Collecting General Troubleshooting Information](#), on page 45.

## Troubleshooting Activation of Applications in a Virtual Services Container

**Problem** Activation of an application in a virtual services container is not successful.

**Possible Cause** Activation of the application may still be ongoing.

**Solution** Check the status of activation using the **show virtual-service list** command. The following is sample output when the application has an Activated status.

```

Device# show virtual-service list

Virtual Service List:
Name                Status              Package Name
-----
WAAS                 Activated           ISR4451X-WAAS-5.2.0-b...

```

**Possible Cause** The virtual services container does not have sufficient resources for activation of the application.

**Solution** Check if the device has sufficient resources for virtualization, including memory, disk space, and CPU utilization. You can view the resource requirement for virtualization using the **show virtual-service** command.

```

Device# show virtual-service

```

Virtual Service Global State and Virtualization Limits:

```

Infrastructure version : 1.5
Total virtual services installed : 1
Total virtual services activated : 1

Machine types supported   : LXC
Machine types disabled   : KVM

Maximum VCPUs per virtual service : 1
Resource virtualization limits:
Name                      Quota      Committed   Available
-----
system CPU (%)            6          1           5
memory (MB)               256        256         0
bootflash (MB)           256        164         92

```

**Possible Cause** The application does not activate properly due to unknown reasons.

**Solution** Deactivate and uninstall the application. If the problem persists, collect general troubleshooting information and contact Cisco Technical Support. For more information, see [Collecting General Troubleshooting Information, on page 45](#).

## Troubleshooting Uninstallation of Applications in a Virtual Services Container

**Problem** Uninstallation of an application from the virtual services container is not successful.

**Possible Cause** The application being uninstalled has not deactivated completely.

**Solution** Check the activation status of an application using the **show virtual-service list** command. The following is sample output when the application is in the Deactivated status and can be uninstalled.

```

Device# show virtual-service list

Virtual Service List:
Name                      Status      Package Name
-----
WAAS                      Deactivated  ISR4451X-WAAS-5.2.0-b...

```

**Possible Cause** The application does not uninstall gracefully due to unknown reasons.

**Solution** As a last resort, delete the `virtual-instance.conf`, using the **delete** command and then reload the device.

```

Device# delete bootflash:virtual-instance.conf
Device# reload

```

**Solution** If the problem persists, collect general troubleshooting information and contact Cisco Technical Support. For more information, see [Collecting General Troubleshooting Information, on page 45](#).

**Problem** Access control lists (ACLs) are not removed after uninstallation of application.

**Solution** At any given point of time, a device should have only one ACL created with the name `onep-acl-N` (where N is a number). If you see more than one such ACL, you can assume that the device has stale ACLs that need to be removed.

```

Device# configure terminal

!Remove the stale ACL

```

```
Device# no onep-acl-61

!Remove the stale ACL from OpenFlow Interfaces
Device(config)# interface ethernet1/4
Device(config-if)# no ip port access-group onep-acl-61 in
Device(config-if)# exit
Device(config)# no ip access-list onep-acl-61
```

## Troubleshooting Deactivation of Applications in a Virtual Services Container

**Problem** Deactivation of an application is not successful.

**Possible Cause** The application being deactivated is not activated.

**Solution** Check the status of activation of the application using the **show virtual-service list** command. The following is sample output from a **show virtual-service list** when the application is in the Activated state and can be deactivated.

```
Device# show virtual-service list

Virtual Service List:
Name                Status                Package Name
-----
oneFW                Activated             iosxe-cx-9.0.2-hudson...
```

**Possible Cause** Deactivation takes a long time (5 minutes).

**Solution** Check if application directories are in use. Ensure that there are no shells open in the application file system directories on the device.

**Possible Cause** The application does not deactivate gracefully due to unknown reasons.

**Solution** As a last resort, uninstall the application (if you haven't done so yet) and delete the `virtual-instance.conf` configuration file, using the **delete** command and reload the device. This step deletes all applications installed in the virtual services container.

```
Device# delete bootflash:virtual-instance.conf
Device# reload
```

**Solution** If the problem persists, generate general troubleshooting information and contact Cisco Technical support. For more information, see [Collecting General Troubleshooting Information](#), on page 45.

## Configuration Examples for a Virtual Services Container

### Example: Cisco Plug-in for OpenFlow Virtual Services Container Installation Configuration

```
Device# enable
Device# copy scp://myserver.com/downloads/ofa-1.0.0-n3000-SPA-k9.ova
bootflash:/ofa-1.0.0-n3000-SPA-k9.ova
Device# virtual-service install name openflow_agent package
bootflash:/ofa-1.0.0-n3000-SPA-k9.ova
Device# configure terminal
Device(config)# virtual-service openflow_agent
```

```
Device(config-virt-serv) # activate
Device(config-virt-serv) # end
Device# copy running-config startup-config
```

### Example: Verifying Cisco Plug-in for OpenFlow Virtual Services Container Installation Configuration

```
Device# show virtual-service list
Virtual Service List:
```

Name	Status	Package Name
openflow_agent	Installed	ofa-1.0.0-n3000-SPA-k9.ova

## Additional References for the Virtual Services Container

### Related Documents

Related Topic	Document Title
Cisco commands	<a href="#">Cisco Nexus 3000 Series Switches Command References</a> <a href="#">Cisco Nexus 5000 Series Switches Command References</a> <a href="#">Cisco Nexus 6000 Series Switches Command References</a>

### Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation and tools. Use these resources to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>

## Feature Information for Virtual Services Container

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.



**Table 3: Feature Information for the Virtual Services Container**

Feature Name	Releases	Feature Information
Virtual Services Container	<ul style="list-style-type: none"> <li>• <i>Cisco Nexus 3000 Series NX-OS Release 6.0(2)U1(1)</i></li> <li>• <i>Cisco Nexus 5000 Series NX-OS Release NX-OS 6.0(3)</i></li> <li>• <i>Cisco Nexus 6000 Series NX-OS Release NX-OS 6.0(3)</i></li> </ul>	<p>Cisco Plug-in for OpenFlow runs in an operating system-level virtual services container on a device.</p> <p>Cisco Plug-in for OpenFlow is delivered in an open virtual application (OVA). The OVA package is installed and enabled on the device through the CLI.</p>

## Glossary

### application

Application installed within and hosted from a virtual services container on a device.

### container

This is another name for virtual service container.

### guest

Application instance running within a container.

### host

Operating system installed on a device.

### KVM

Kernel Virtual Machine. This is a virtualization infrastructure for the Linux kernel.

### LxC

Linux Container. Operating system virtualization technology that shares the host kernel with the guest, but provides namespace extensions to the kernel.

### logical Switch

An Cisco Plug-in for OpenFlow switch configured on a device and controlled by an external controller using flows defined on the controller.

### OVA

This is an open virtual application. Software package used to install an application and related metafiles within a container. This is a tar file with a .ova extension.

**physical Switch**

A physical device on which Cisco Plug-in for OpenFlow application is installed and deployed.

**virtual machine**

This is another name for virtual service container.

**virtual service**

This is another name for virtual service container.

**virtual services container**

This is a virtualized environment on a device on which an application can be hosted. A virtualized environment on a Cisco device is called a Cisco virtual-services container.

**VMAN**

This is the virtualization manager. A process that manages virtual service containers and runs as a host process.