



Managing Users

This chapter contains the following sections:

- [Information About User Management, on page 1](#)
- [Displaying Current User Access, on page 1](#)
- [Sending a Message to Users, on page 2](#)

Information About User Management

You can identify the users currently connected to the device and send a message to either a single user or all users.

For information about creating user accounts and assigning user roles, see the .

Displaying Current User Access

You can display all users currently accessing the switch.

Before you begin

Log in to the CLI.

Procedure

	Command or Action	Purpose
Step 1	switch# show users	Displays a list of users who are currently accessing the system.

Example

This example shows how to display current user access:

```
switch# Show users
NAME      LINE      TIME      IDLE      PID COMMENT
admin     pts/0     Jul  1 04:40 03:29     2915 (::ffff:64.103.145.136)
admin     pts/2     Jul  1 10:06 03:37     6413 (::ffff:64.103.145.136)
```

```
admin pts/3 Jul 1 13:49 . 8835 (171.71.55.196)*
switch#
```

Sending a Message to Users

You can send a message to all active CLI users who are currently using the system.

Before you begin

Log in to the CLI.

Procedure

	Command or Action	Purpose
Step 1	switch# send <i>{session device} line</i>	<p>Sends a message to users currently logged in to the system.</p> <ul style="list-style-type: none"> • The <i>session</i> argument sends the message to a specified pts/tty device type. • The <i>device</i> argument specifies the device type. • The <i>line</i> argument is a message of up to 80 alphanumeric characters.

Example

This example shows up to send a message to users:

```
switch# send Hello. Shutting down the system in 10 minutes.
```

```
Broadcast Message from admin@switch
(/dev/pts/34) at 8:58 ...
```

```
Hello. Shutting down the system in 10 minutes.
```

```
switch#
```