



Release Notes for Cisco ASR 901 Series Aggregation Services Router for Cisco IOS Release 15.6(2)SP5

First Published Date: September 16, 2018

This release notes is for the Cisco ASR 901 Series Aggregation Services Router for Cisco IOS Release 15.6(2)SP5 and contains the following sections:

- [Introduction, page 1](#)
- [System Specifications and Memory Details, page 2](#)
- [New and Changed Information, page 3](#)
- [Supported Hardware, page 4](#)
- [Caveats, page 7](#)
- [Troubleshooting, page 7](#)
- [Related Documentation, page 8](#)
- [Obtain Documentation and Submit a Service Request, page 8](#)

Introduction

The Cisco ASR 901 Series Aggregation Services Router is a cell-site access platform specifically designed to aggregate and transport mixed-generation radio access network (RAN) traffic. The router is used at the cell site edge as a part of a 2G, 3G, or 4G RAN.

The Cisco ASR 901 router helps enable a variety of RAN solutions by extending IP connectivity to devices using Global System for Mobile Communications (GSM), General Packet Radio Service (GPRS), Node Bs using High Speed Packet Access (HSPA) or Long Term Evolution (LTE), base transceiver stations (BTSs) using Enhanced Data Rates for GSM Evolution (EDGE), Code Division Multiple Access (CDMA), CDMA-2000, EVDO, or WiMAX, and other cell-site equipment.

It transparently and efficiently transports cell-site voice, data, and signaling traffic over IP using traditional T1 and E1 circuits, as well as alternative backhaul networks such as Carrier Ethernet and DSL, Ethernet in the First Mile (EFM), and WiMAX. It also supports standards-based Internet



Engineering Task Force (IETF) Internet protocols over the RAN transport network, including those standardized at the Third-Generation Partnership Project (3GPP) for IP RAN transport. Custom designed for the cell site, the Cisco ASR 901 router features a small form factor, extended operating temperature, and cell-site DC input voltages.

[Table 1](#) lists the Cisco ASR 901 1G Router model versions.

Table 1 Cisco ASR 901 1G Router Models

Power Source	TDM + Ethernet Version	Ethernet Version
DC Power	<ul style="list-style-type: none"> A901-12C-FT-D A901-4C-FT-D 	<ul style="list-style-type: none"> A901-12C-F-D A901-4C-F-D
AC Power	<ul style="list-style-type: none"> none 	<ul style="list-style-type: none"> none

[Table 2](#) lists the Cisco ASR 901 10G Router model versions.

Table 2 Cisco ASR 901 10G Router Models

Power Source	TDM + Ethernet Version	Ethernet Version
DC Power	<ul style="list-style-type: none"> A901-6CZ-FT-D 	<ul style="list-style-type: none"> A901-6CZ-F-D A901-6CZ-FS-D
AC Power	<ul style="list-style-type: none"> A901-6CZ-FT-A 	<ul style="list-style-type: none"> A901-6CZ-F-A A901-6CZ-FS-A



Note

Some of the Cisco ASR 901 models have port based licensing. For more details, see the [Licensing](#) chapter in Cisco ASR 901 Series Aggregation Services Router Software Configuration Guide.

System Specifications and Memory Details

[Table 3](#) lists the supported system configurations and memory details for the Cisco ASR 901 router:

Table 3 Cisco IOS Release 15.6(2)SP5 Memory Details

Platform	Software Image	Flash Memory	DRAM Memory	Runs From
Cisco ASR 901 Series Aggregation Services Router TDM version	asr901-universalk9-mz	128 MB	512 MB	RAM
Cisco ASR 901 Series Aggregation Services Router, Ethernet version	asr901-universalk9-mz	128 MB	512 MB	RAM
Cisco ASR 901 Series Aggregation Services Router, IPsec enabled Ethernet version	asr901sec-universalk9.mz	256 MB	512 MB	RAM

Determining the Software Version

To determine the image and version of Cisco IOS software running on your Cisco ASR 901 router, log in to the router and enter the **show version** command in the EXEC mode:

The following example shows output from Cisco ASR 901 router that supports normal IOS software.

```
ASR901_1> show version
Cisco IOS Software, 901 Software (ASR901-UNIVERSALK9-M), Version 15.6(2)SP3, RELEASE
SOFTWARE (fc3)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2017 by Cisco Systems, Inc.
Compiled Thu 14-Sep-17 16:09 by prod_rel_team
```

```
ROM: System Bootstrap, Version 15.6(3r)SP3, RELEASE SOFTWARE (fc1)
```

The following example shows output from Cisco ASR 901 Series Aggregation Services Router, IPsec enabled Ethernet version.

```
SANR1> show version
Cisco IOS Software, 901 Software (ASR901SEC-UNIVERSALK9-M), Version 15.6(2)SP3, RELEASE
SOFTWARE (fc3)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2017 by Cisco Systems, Inc.
Compiled Thu 14-Sep-17 16:29 by prod_rel_team
```

```
ROM: System Bootstrap, Version 15.6(3r)SP3, RELEASE SOFTWARE (fc1)
```

New and Changed Information

- [New Hardware Features in Release 15.6\(2\)SP5, page 3](#)
- [New Software Features in Release 15.6\(2\)SP5, page 3](#)
- [Modified Software Features in Release 15.6\(2\)SP5, page 3](#)

New Hardware Features in Release 15.6(2)SP5

There are no new hardware features in this release.

New Software Features in Release 15.6(2)SP5

There are no new hardware features in this release.

Modified Software Features in Release 15.6(2)SP5

There are no modified features in this release.

Supported Hardware

Table 4 and Table 5 shows the SFP modules supported on the Cisco ASR 901 routers:

Important Notes

- 10G SFPs inserted into 1GE port provides 1GE speed.
- 10G SFPs inserted into 10GE port without a valid license provides only 1GE speed.
- 100M SFP works only with **no negotiation auto** command.
- If 1G SFP is used to connect a 10G port to a 1G port, you do not have to explicitly configure the **no negotiation auto** command to bring up the link.
- Effective with Cisco IOS Release 15.4(3)S, the auto-select feature is supported on 100M SFPs. However, this feature is not supported on combo ports.
- Remote Fault Indication feature is not applicable for 1G mode in 10GE ports. It applies only to 10G mode in 10GE ports.
- By default dual rate SFP works in 1G mode, to make it work in 100M mode, “no negotiation auto” should be configured.
- Dual rate SFP can be configured in 100M mode when inserted in 1G ports only.
- Dual rate SFP when inserted in 10G ports will work in 1G mode only.

Table 4 SFPs Supported on the Cisco ASR 901 1G and 10G Routers for 1G Mode

• CWDM-SFP-1470	• GLC-SX-MM-RGD
• CWDM-SFP-1490	• GLC-T
• CWDM-SFP-1510	• GLC-ZX-SM
• CWDM-SFP-1530	• GLC-ZX-SMD
• CWDM-SFP-1550	• GLC-ZX-SM-RGD
• CWDM-SFP-1570	• SFP-GE-L
• CWDM-SFP-1590	• SFP-GE-S
• CWDM-SFP-1610	• SFP-GE-T
• CWDM SFP+	• SFP-GE-Z
• DWDM-SFP-XXXX ¹	• GLC-BX40-D-I
• GLC-BX-U and GLC-BX-D ²	• GLC-BX40-DA-I
• GLC-EX-SMD	• GLC-BX40-U-I
• GLC-LH-SMD	• GLC-BX80-D-I
• GLC-LX-SM-RGD	• GLC-BX80-U-I
• GLC-SX-MMD	• GLC-GE-DR-LX

1. 40 wavelengths

2. These SFPs (GLC-BX-U and GLC-BX-D) should be connected back to back to bring the interface link up.

Table 5 SFPs Supported on the Cisco ASR 901 10G Router for 10G Mode

• SFP-10G-ER	• SFP-10G-ZR
• SFP-10G-LR	• SFP-10G-LRM
• SFP-10G-LR-X	• SFP-H10GB-ACU7M
• DWDM-SFP+	• SFP-H10GB-ACU10M
• SFP-H10GB-CU1M	• SFP-10G-BX-D-I
• SFP-H10GB-CU3M	• SFP-10G-BX-U-I
• SFP-H10GB-CU5M	• SFP-10G-BX40-D-I
• SFP-10G-SR	• SFP-10G-BX40-U-I
• SFP-10G-SR-X	

**Note**

For information on how to configure SFPs, see the [Cisco ASR 901 Series Aggregation Services Router Software Configuration Guide](#).

Supported MIBs

The Cisco ASR 901 router supports the following MIBs:

- BGP4-MIB
- BRIDGE-MIB
- CISCO-ACCESSENVMON-MIB
- CISCO-CAR-MIB
- CISCO-CDP-MIB
- CISCO-CEF-MIB
- CISCO-CLASS-BASED-QOS-MIB
- CISCO-CONFIG-COPY-MIB
- CISCO-CONFIG-MAN-MIB
- CISCO-DATA-COLLECTION-MIB
- CISCO-DOT3-OAM-MIB
- CISCO-EIGRP-MIB
- CISCO-ENHANCED-MEMPOOL-MIB
- CISCO-STP-EXTENSIONS-MIB
- CISCO-SYSLOG-MIB
- CISCO-TC
- ENTITY-MIB
- ETHERLIKE-MIB
- HCNUM-TC
- IANAifType-MIB
- IEEE8021-CFM-MIB
- IF-MIB
- IMA-MIB
- INT-SERVE-MIB
- IP-FORWARD-MIB
- IP-MIB

- CISCO-ENTITY-ALARM-MIB
- CISCO-ENTITY-ASSET-MIB
- CISCO-ENTITY-VENDORTYPE-OID-MIB
- CISCO-ENVMON-MIB
- CISCO-FLASH-MIB
- CISCO-IETF-PW-MIB
- CISCO-IETF-PW-TC-MIB
- CISCO-IF-EXTENSION-MIB
- CISCO-IMAGE-MIB
- CISCO-IPSLA-ETHERNETMIB
- CISCO-MEMORY-POOL-MIB
- CISCO-NETSYNC-MIB
- CISCO-NTP-MIB
- CISCO-OSPF-MIB
- CISCO-PING-MIB
- CISCO-PROCESS-MIB
- CISCO-PRODUCTS-MIB
- CISCO-PTP-MIB
- CISCO-QUEUE-MIB
- CISCO-RESILIENT-ETHERNET-PROTOCOL-MIB
- CISCO-RTTMON-MIB
- CISCO-SENSOR-ENTITY-MIB
- CISCO-SMI-MIB
- CISCO-SNAPSHOT-MIB
- CISCO-SNMP-TARGET-EXT-MIB
- MPLS-LDP-MIB
- MPLS-LSR-MIB
- MPLS-VPN-MIB
- NOTIFICATION-LOG-MIB
- OLD-CISCO-CHASSIS-MIB
- OLD-CISCO-FLASH-MIB
- OLD-CISCO-INTERFACES-MIB
- OLD-CISCO-IP-MIB
- OLD-CISCO-SYS-MIB
- OLD-CISCO-TS-MIB
- OSPF-MIB
- OSPFv3-MIB
- PerfHist-TC-MIB
- RFC1213-MIB
- RMON2-MIB
- RMON-MIB
- SNMP-FRAMEWORKMIB
- SNMP-TARGET-MIB
- SNMPv2-MIB
- SNMPv2-SMI
- SNMPV2-TC
- TCP-MIB
- UDP-MIB
- CISCO-IPSEC-FLOW-MONITOR-MIB
- CISCO-IPSEC-MIB

Caveats

Caveats describe unexpected behavior in Cisco IOS software releases. Severity 1 caveats are the most serious caveats, severity 2 caveats are less serious, and severity 3 caveats are the least serious of these three severity levels. Only select severity 3 caveats are listed.

This section contains the following topics:

- [Bug Search Tool](#)
- [Open Caveats](#)
- [Resolved Caveats](#)

Bug Search Tool

The Caveats section only includes the bug ID and a short description of the bug. For details on the symptoms, conditions, and workaround for a particular bug you must use the Bug Search Tool.

Use the following link to access the tool: <https://tools.cisco.com/bugsearch/search>

You will be prompted to log into Cisco.com. After successful login, the Bug Search Tool page opens. Use the Help link in the Bug Search Tool to obtain detailed help.

Open Caveats

There are no open caveats for the Cisco ASR 901 router running Cisco IOS Release 15.6(2)SP5.

Resolved Caveats

This section provides information about the resolved caveats for the Cisco ASR 901 router running Cisco IOS Release 15.6(2)SP5.

Caveat ID Number	Description
CSCvj47305	ASR901: sometime non-mpls packets are matching to exp class map
CSCvj52744	ASR901: TenGigabitEthernet0/1 does not come up when booted with REP enabled on that port
CSCvk23339	qos-config scheduling-mode min BW is lost after default
CSCvk39493	ASR901: interface flapping every 5 hours, due to OAM session down
CSCvk45972	Unable to read from I2C bus cause CPUHOGs and routing protocol drops

Troubleshooting

The following sections describe troubleshooting commands you can use with the router.

Collecting Data for Router Issues

To collect data for reporting router issues, issue the following command:

- **show tech-support**—Displays general information about the router if it reports a problem.

Collecting Data for ROMMON Issues

To collect data for ROMMON issues, issue the following command while in the EXEC mode:

- **show rom-monitor**—Displays currently selected ROM monitor.



Note

If you contact Cisco support for assistance, we recommend that you provide any crashinfo files stored in flash memory. For more information about crashinfo files, see

http://www.cisco.com/en/US/products/hw/routers/ps167/products_tech_note09186a00800a6743.shtml.

Related Documentation

Documents related to the Cisco ASR 901 Series Aggregation Services Router include the following:

- *Cisco ASR 901 Series Aggregation Services Router Hardware Installation Guide*
- *Cisco ASR 901 Series Aggregation Services Router Software Configuration Guide*
- *Regulatory Compliance and Safety Information for Cisco ASR 901 Series Aggregation Services Routers*
- *Cisco ASR 901 Series Aggregation Services Router Series MIB Specifications Guide*

To access the related documentation on Cisco.com, go to:

- Cisco ASR 901 1G Router home page:
http://www.cisco.com/en/US/partner/products/ps12077/tsd_products_support_series_home.html
- Cisco ASR 901 10G Router home page:
<http://www.cisco.com/c/en/us/support/routers/asr-901-10g-series-aggregation-services-routers/tsd-products-support-series-home.html>

Obtain Documentation and Submit a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2018, Cisco Systems, Inc All rights reserved.