



Configure and Verify Roaming Parameters

- [Packet Retries Limitation, on page 1](#)
- [Configure Maximum Retry Limit for Packet Retransmissions using CLI, on page 1](#)
- [Verify Maximum Retry Limit for Packet Retransmissions using CLI, on page 1](#)

Packet Retries Limitation

Starting from UIW Release 17.15.1, you can set the limit for the packet retransmissions of unicast packets. This includes both aggregate and non-aggregate packets.



Note The maximum retry limit for packet retransmission is 32.

Configure Maximum Retry Limit for Packet Retransmissions using CLI

Use this command to configure maximum retry limit for packet retransmissions on the AP.

```
Device#configure dot11Radio <N> packet retries <retry-count>
```

Verify Maximum Retry Limit for Packet Retransmissions using CLI

```
Device#show dot11Radio 1 config
.
.
.
DFS region:           Q
DFS radar role:      auto
Radar detected:      0
Indoor deployment:   disable
```

Verify Maximum Retry Limit for Packet Retransmissions using CLI

```
Rx-SOP Threshold:      0 dBm(AUTO)
Max packet retries:    32
```