



Troubleshooting ISG with Session Monitoring and Distributed Conditional Debugging

Last Updated: August 21, 2011

Intelligent Services Gateway (ISG) is a Cisco IOS XE software feature set that provides a structured framework in which edge devices can deliver flexible and scalable services to subscribers. This document describes ISG session monitoring and distributed conditional debugging. Conditional debugging facilitates debug filtering for ISG and is available as distributed conditional debugging.

- [Finding Feature Information, page 1](#)
- [Prerequisites for ISG Session Monitoring and Distributed Conditional Debugging, page 2](#)
- [Restrictions for Distributed Conditional Debugging, page 2](#)
- [Information About ISG Session Monitoring and Distributed Conditional Debugging, page 2](#)
- [How to Enable ISG Session Monitoring and Distributed Conditional Debugging, page 3](#)
- [Configuration Examples for ISG Distributed Conditional Debugging, page 10](#)
- [Additional References, page 12](#)
- [Feature Information for Distributed Conditional Debugging, page 12](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for ISG Session Monitoring and Distributed Conditional Debugging

Before using the information in this module, it is recommended that you be familiar with the use of Cisco IOS **debug** commands and conditional debugging. See the "Additional References" section to find information about these topics.

Restrictions for Distributed Conditional Debugging

Conditions that are set for an active session take effect only when the session is terminated and reestablished.



Caution

Because debugging output is assigned high priority in the CPU process, it can render the system unusable. For this reason, use the Cisco IOS **debug** commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco technical support staff. Moreover, it is best to use **debug** commands during periods of lower network traffic and fewer users, or on a debug chassis with a single active session. Debugging during these periods decreases the likelihood that increased **debug** command processing overhead will affect system use.

Information About ISG Session Monitoring and Distributed Conditional Debugging

- [ISG Session and Flow Monitoring, page 2](#)
- [ISG Distributed Conditional Debugging, page 2](#)

ISG Session and Flow Monitoring

ISG introduces a mechanism that allows an administrator to monitor ISG sessions and flows continuously. The **show interface monitor** command, which displays interface statistics, and the **show process cpu monitor** command, which displays information about CPU usage, both update the information in their displays at specified intervals. These commands also provide the ability to freeze or clear the information in the display.

ISG Distributed Conditional Debugging

- [Benefits of Enhanced Conditional Debugging for the ISG Platforms, page 2](#)
- [Cisco IOS Software Components Supported by Distributed Conditional Debugging, page 3](#)

Benefits of Enhanced Conditional Debugging for the ISG Platforms

Because thousands of user sessions run on the ISG platforms, it is not practical to troubleshoot a problem with a session by enabling the various component **debug** commands that are available and trace through the

messages for a single session or user. Instead, it is more practical to filter debugging messages for a single session or call across the various Cisco IOS XE components that a session traverses. For this reason, the conditional debugging previously offered in the Cisco IOS XE software has been enhanced to facilitate debug filtering for ISG and is available as distributed conditional debugging.

Cisco IOS Software Components Supported by Distributed Conditional Debugging

The following components are supported for ISG distributed conditional debugging:

- Authentication, authorization, and accounting (AAA) and RADIUS
- ATM components
- Feature Manager
- Policy Manager
- PPP
- PPP over Ethernet (PPPoE)
- Session Manager
- Virtual Private Dialup Network (VPDN)

See Table 1 and Table 2 for specific commands that are supported for distributed conditional debugging.

How to Enable ISG Session Monitoring and Distributed Conditional Debugging

- [Monitoring ISG Sessions and Flows, page 3](#)
- [Configuring Distributed Conditional Debugging, page 4](#)

Monitoring ISG Sessions and Flows

Perform this task to monitor interface and CPU statistics. The **show** commands are not required and may be entered in any order.

SUMMARY STEPS

1. **enable**
2. **show interface *type number* monitor [interval *seconds*]**
3. **show processes cpu monitor [interval *seconds*]**

DETAILED STEPS

Command or Action	Purpose
Step 1 enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.

Command or Action	Purpose
<p>Step 2 <code>show interface <i>type number</i> monitor [<i>interval seconds</i>]</code></p> <p>Example:</p> <pre>Router# show interface ethernet 3/0 monitor interval 10</pre>	Displays interface statistics that are updated at specified intervals.
<p>Step 3 <code>show processes cpu monitor [<i>interval seconds</i>]</code></p> <p>Example:</p> <pre>Router# show processes cpu monitor</pre>	Displays detailed CPU utilization statistics that are updated at specified intervals.

Configuring Distributed Conditional Debugging

Two main tasks are required for configuring distributed conditional debugging: enabling conditional debugging, and issuing one or more supported **debug** commands. These required tasks are described in the following sections:

- [ISG Debug Condition Commands, page 4](#)
- [Debug Commands That Are Supported by ISG Conditional Debug, page 5](#)
- [Restrictions, page 8](#)
- [Enabling Distributed Conditional Debugging, page 8](#)
- [Displaying Debugging Conditions, page 9](#)
- [Troubleshooting Tips, page 9](#)

ISG Debug Condition Commands

The table below lists the **debug condition** commands that you can issue at the EXEC prompt to enable distributed conditional debugging. You can set more than one condition.

Table 1 Supported Conditional Debug Commands

Command	Purpose
<code>debug condition domain <i>domain-name</i></code>	Filters messages on the specified domain name.
<code>debug condition interface atm <i>ATM-interface</i> vc {<i>vci</i> / <i>vpi</i>} <i>vci</i></code>	Filters messages on the specified virtual circuit.
<code>debug condition interface {atm <i>ATM-interface</i> vc {<i>vci</i> / <i>vpi</i> <i>vci</i>} Ethernet Fast Ethernet Gigabit Ethernet} <i>vlan-id</i> <i>ID</i></code>	Filters messages on the specified VLAN identifier.
<code>debug condition mac-address <i>hexadecimal-MAC-address</i></code>	Filters messages on the specified MAC address.

Command	Purpose
debug condition portbundle ip <i>IP-address</i> bundle <i>bundle-number</i>	Filters messages on the specified Port-Bundle Host Key (PBHK).
debug condition session-id <i>session-ID</i>	Filters messages on the specified session identifier. Note The session identifier can be obtained by entering the show subscriber session command.
debug condition username <i>email-address</i>	Filters messages on the specified Internet username.

Debug Commands That Are Supported by ISG Conditional Debug

The table below lists the Cisco IOS debugging commands that are supported for distributed conditional debugging. The commands are listed by component. One or more of these commands can be issued after enabling one of the **debug condition** commands listed in the table above.

Table 2 Debug Commands Supported by ISG Distributed Conditional Debugging

AAA Debug Commands
debug aaa accounting
debug aaa authentication
debug aaa authorization
debug aaa id
ATM Debug Commands
debug atm arp
debug atm error
debug atm event
debug atm oam
debug atm packet
debug atm state
PPP Debug Commands
debug ppp authentication
debug ppp bap error
debug ppp bap events
debug ppp bap negotiation

AAA Debug Commands

debug ppp cbcp

debug ppp error

debug ppp mppe detailed

debug ppp mppe events

debug ppp mppe pack

debug ppp multi data

debug ppp multi events

debug ppp multi frag

debug ppp negotiation

debug ppp pack

debug ppp subscriber

PPPoE Debug Commands

debug pppoe data

debug pppoe error

debug pppoe event

debug pppoe packet

Session Manager Debug Commands

debug subscriber aaa authorization event

debug subscriber aaa authorization fsm

debug subscriber error

debug subscriber event

Feature Manager Debug Commands

debug subscriber feature access-list error

debug subscriber feature access-list event

debug subscriber feature compression detail

debug subscriber feature compression error

debug subscriber feature compression event

debug subscriber feature detail

AAA Debug Commands

debug subscriber feature error

debug subscriber feature event

debug subscriber feature interface-config error

debug subscriber feature interface-config event

debug subscriber feature modem-on-hold detail

debug subscriber feature modem-on-hold error

debug subscriber feature modem-on-hold event

debug subscriber feature portbundle error

debug subscriber feature portbundle event

debug subscriber feature portbundle packet

debug subscriber feature qos-policy error

debug subscriber feature qos-policy event

debug subscriber feature static-routes error

debug subscriber feature static-routes event

debug subscriber feature traffic-classification detail

debug subscriber feature traffic-classification error

debug subscriber feature traffic-classification event

Policy Manager Debug Commands

debug subscriber fsm

debug subscriber policy condition

debug subscriber policy detail

debug subscriber policy error

debug subscriber policy event

debug subscriber policy fsm

debug subscriber policy rule

debug subscriber session error

debug subscriber session event

VPDN Debug Commands

AAA Debug Commands**debug vpdn call event****debug vpdn call fsm****debug vpdn error****debug vpdn event****debug vpdn event disconnect****Restrictions**

The **debug condition session-id** command filters a session only after the session has been established. The session identifier is a unique dynamic number generated internally by the Cisco IOS software and assigned to each session when the session is established.

In VPDN, the **debug** commands and messages associated with tunnels cannot be filtered because they are not associated with a session, but are displayed during the tunnel-establishment phase. The debugging messages will be displayed even if filtering is enabled by one of the conditions.

If multiple conditions are set, the debugging messages corresponding to all the sessions that meet any of the conditions will be displayed. Some conditions, such as domain name, will trigger debugging messages for all the sessions that belong to the particular domain.

Enabling Distributed Conditional Debugging

Perform this task to enable distributed conditional debugging for ISG.

SUMMARY STEPS

1. **enable**
2. **debug condition** *command*
3. **debug** *command*

DETAILED STEPS

Command or Action	Purpose
Step 1 enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.

Command or Action	Purpose
<p>Step 2 <code>debug condition</code> <i>command</i></p> <p>Example:</p> <pre>Router# debug condition username user@cisco.com</pre>	Enter one or more of the debug condition commands listed in Table 1 to enable distributed conditional debugging.
<p>Step 3 <code>debug</code> <i>command</i></p> <p>Example:</p> <pre>Router# debug subscriber aaa authorization fsm</pre>	Enter one or more of the supported debug commands from Table 2.

Displaying Debugging Conditions

To display the debugging conditions that have been set, perform the following task:

SUMMARY STEPS

1. `enable`
2. `show debug condition`

DETAILED STEPS

Command or Action	Purpose
<p>Step 1 <code>enable</code></p> <p>Example:</p> <pre>Router> enable</pre>	<p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> • Enter your password if prompted.
<p>Step 2 <code>show debug condition</code></p> <p>Example:</p> <pre>Router# show debug condition</pre>	Displays conditions that have been set for debugging.

Troubleshooting Tips

The Cisco IOS software displays messages as you set the conditions for filtering the debugging. When a condition is set, it is assigned a number, as follows:

```
Condition 1 set
```

If a condition has already been set, the following message is displayed:

```
% Condition already set
```

The following messages and prompt are displayed when you attempt to disable the last condition using the **no** form of a **debug condition** command:

```
This condition is the last interface condition set.
Removing all conditions may cause a flood of debugging messages
to result, unless specific debugging flags are first removed.
```

```
Proceed with removal? [yes/no]: yes
Condition 1 has been removed
```



Tip

Use the **no** form of the commands to disable all **debug** commands before disabling all of the debugging conditions that have been set.

Configuration Examples for ISG Distributed Conditional Debugging

- [Monitoring Interface Statistics Example, page 10](#)
- [Monitoring CPU Statistics Example, page 11](#)
- [Enabling ISG Distributed Conditional Debugging Example, page 11](#)
- [Displaying Debugging Conditions Example, page 11](#)
- [Filtering Debug Output Example, page 11](#)

Monitoring Interface Statistics Example

The following example shows sample output for the **show interface monitor** command. The display will be updated every 10 seconds.

```
Router> show interface ethernet 0/0 monitor interval 10

Router Name:  Scale3-Router8      Update Secs: 10
Interface Name:  Ethernet 0/0      Interface Status: UP, line is up

Line Statistics:          Total:          Rate(/s)      Delta
Input Bytes:             123456         123           7890
Input Packets:           3456          56            560
Broadcast:                1333          6             60
OutputBytes:              75717         123           1230
Output Packets:           733           44            440

Error Statistics:        Total:          Delta:
Input Errors:            0              0
CRC Errors:              0              0
Frame Errors:            0              0
Ignored:                 0              0
Output Errors:           0              0
Collisions:              0              0

No. Interface Resets:  2
End = e                Clear = c        Freeze = f
Enter Command:
```

Monitoring CPU Statistics Example

The following example shows sample output for the **show processes cpu monitor** command:

```
Router> show processes cpu monitor

CPU utilization for five seconds: 0%/0%; one minute: 0%; five minutes: 0%
  PID Runtime(ms)   Invoked    uSecs   5Sec   1Min   5Min   TTY Process
   3     772         712     1084   0.08%  0.04%  0.02%   0   Exec
   67    276        4151      66    0.08%  0.03%  0.01%   0 L2TP mgmt daemon
  116   604        2263     266    0.16%  0.05%  0.01%   0 IDMGR CORE

End = e      Freeze = f

Enter Command:
```

Enabling ISG Distributed Conditional Debugging Example

The following example shows how to filter PPP, PPPoE, and Session Manager debugs for a PPPoE session with username “user@cisco.com”. Only debugging messages for the defined user are displayed on the console. Any other debugging messages associated with other users will not be displayed.

```
Router# debug condition username user@cisco.com
Condition 1 set

Router# debug ppp negotiation
Router# debug pppoe event
Router# debug subscriber session event
```

Displaying Debugging Conditions Example

The following example shows how to display debugging conditions that have been set.

```
Router# show debug condition

Condition 1: domain cisco.com (0 flags triggered)
Condition 2: username user@cisco.com (0 flags triggered)
Condition 3: ip 172.19.200.10 (0 flags triggered)
```

Filtering Debug Output Example

In the following example, the output of the **debug subscriber packet detail** command is filtered on the basis of the username “cpe6_1@isp.com”:

```
Router# debug condition username cpe6_1@isp.com
Condition 1 set
Router# show debug

Condition 1: username cpe6_1@isp.com (0 flags triggered)

Router# debug subscriber packet detail
SSS packet detail debugging is on

Router# show debug
SSS:
  SSS packet detail debugging is on

Condition 1: username cpe6_1@isp.com (0 flags triggered)
```

Additional References

Related Documents

Related Topic	Document Title
ISG commands	<i>Cisco IOS Intelligent Services Gateway Command Reference</i>
Debug commands	<i>Cisco IOS Debug Command Reference</i>
Conditional debugging	"Conditionally Triggered Debugging" chapter in the <i>Cisco IOS Debug Command Reference</i>

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<p>http://www.cisco.com/cisco/web/support/index.html</p>

Feature Information for Distributed Conditional Debugging

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 3 **Feature Information for ISG Session Monitoring and Distributed Conditional Debugging**

Feature Name	Releases	Feature Configuration Information
ISG: Instrumentation: Session and Flow Monitoring	12.2(28)SB 12.2(33)SRC 15.0(1)S	<p>ISG provides a mechanism for continuously monitoring interface and CPU statistics. This feature introduces the show interface monitor and show processes cpu monitor commands, which display statistics that are updated at specified intervals.</p> <p>In Cisco IOS Release 12.2(28)SB, this feature was introduced.</p> <p>This feature was integrated into Cisco IOS Release 12.2(33)SRC.</p>
ISG: Instrumentation: Advanced Conditional Debugging	12.2(28)SB 12.2(33)SRC	<p>ISG provides the ability to define various conditions for filtering debug output. Conditional debugging generates very specific and relevant information that can be used for session, flow, subscriber, and service diagnostics.</p> <p>In Cisco IOS Release 12.2(28)SB, this feature was introduced.</p> <p>This feature was integrated into Cisco IOS Release 12.2(33)SRC.</p>

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.