



Release Notes for Cisco NCS 540 Series Routers, Cisco IOS XR Release 24.2.11

First Published: 2024-07-05

Network Convergence System 540 Series Routers

What's New in Cisco IOS XR Release 24.2.11

For more details on the Cisco IOS XR release model and associated support, see [Software Lifecycle Support Statement - IOS XR](#).

Software Features Enhanced and Introduced

To learn about features introduced in other Cisco IOS XR releases, select the release from the [Documentation Landing Page](#).

The following features are supported on all the NCS 540 router variants.

Feature	Description
Routing	
Support for NCS 540 routers as Seamless BFD reflector	<p>This feature introduces support for NCS 540 routers as a Seamless BFD (SBFD) reflector.</p> <p>Seamless BFD simplifies the negotiation and state establishment aspects of BFD by predetermining session discriminators and maintaining session state only at the headend. This approach ensures quicker connectivity tests and reduces complexity in session establishment.</p> <p>Previously, support for Seamless BFD reflector was not available.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <p>The <code>sbfd</code> command is extended to support NCS 540 routers.</p>
Segment Routing	

Feature	Description
Data Plane Validation for SR-MPLS IPv6-based Controller Instantiated LSPs	<p>You can now verify the network configuration and paths and policies set up, without interrupting or potentially disrupting live network traffic, for SR-MPLS (Segment Routing over Multiprotocol Label Switching) IPv6-based Label Switched Paths (LSPs). With this feature, you can validate controller instantiated LSPs programmed directly into the forwarding hardware.</p> <p>Previously, SR data plane validation was possible over IPv4-based LSPs.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <p>The dataplane-only keyword is introduced in the tracert sr-mpls and ping sr-mpls commands.</p> <p>YANG Data Models:</p> <ul style="list-style-type: none"> • <code>Cisco-IOS-XR-mpls-tracert-act.yang</code> • <code>Cisco-IOS-XR-mpls-ping-act.yang</code> <p>See (GitHub, Yang Data Models Navigator)</p>
Delay Measurement for IP Endpoint over SRv6 Network	<p>In Segment Routing over an IPv6 network (SRv6), you can measure packet delay from the source to a specific IP endpoint. You can use this information for troubleshooting, network maintenance, and optimizing network performance.</p> <p>Additionally, you can use flow labels to verify the delay of each subsequent hop path towards the IP endpoint of that path. So that, when network traffic is distributed across multiple available paths towards an IP endpoint, delay measurement tracks the delay of each of these paths towards the IP endpoint.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> • The source-address ipv6 keyword is introduced in the performance-measurement endpoint command. • The segment-list name keyword is introduced in the segment-routing traffic-eng explicit command. • The flow-label keyword is introduced in the performance-measurement delay-profile name command. <p>YANG Data Model:</p> <ul style="list-style-type: none"> • <code>Cisco-IOS-XR-um-performance-measurement-cfg</code> • <code>Cisco-IOS-XR-perf-meas-oper.yang</code> <p>(See GitHub, YANG Data Models Navigator)</p>

Feature	Description
Display Neighbor Router Capabilities in OSPF Networks	<p>You can now improve the user experience, understand the features and functionalities supported by neighboring routers, reduce operational work hours and human errors by gaining better visibility into the routing capabilities of directly connected neighboring routers in an OSPF network. These improvements are now possible when you enable Segment Routing on a neighboring connected router.</p> <p>Previously, there was no straightforward method to display the segment routing and other capabilities of neighboring routers in an OSPF network.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The capabilities keyword is introduced in the show ospf neighbor command. <p>YANG Data Models:</p> <ul style="list-style-type: none"> <code>Cisco-IOS-XR-ipv4-ospf-oper.yang</code> <p>See (GitHub, Yang Data Models Navigator)</p>
Liveness Monitoring for IP Endpoint over SRv6 Network	<p>In Segment Routing over an IPv6 network (SRv6), you can keep track of the operational status of both the forward and reverse paths of a particular node or IP endpoint. You can use this information for troubleshooting, network maintenance, and optimizing network performance.</p> <p>Additionally, you can use flow labels to verify the liveness of each subsequent hop path toward the IP endpoint of that path. So that, when network traffic is distributed across multiple available paths towards an IP endpoint, liveness detection tracks the operational status of each of these paths towards the IP endpoint.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The reverse-path and segment-list name keywords are introduced in the segment-routing traffic-eng explicit command. The source-address ipv6 is introduced in the performance-measurement endpoint command. <p>YANG Data Model:</p> <ul style="list-style-type: none"> <code>Cisco-IOS-XR-um-performance-measurement-cfg</code> <code>Cisco-IOS-XR-perf-meas-oper.yang</code> <p>(see GitHub, YANG Data Models Navigator)</p>

Feature	Description
MPLS OAM support for SR-TE Policies using MPLS IPv6-based LSPs	<p>You can now verify the network configuration and paths and SR-TE policies set up, without interrupting or potentially disrupting live network traffic, for SR-MPLS (Segment Routing over Multiprotocol Label Switching) IPv6-based Label Switched Paths (LSPs).</p> <p>Previously, MPLS OAM support was only for IPv4-based LSPs.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <p>The traceroute sr-mpls and ping sr-mpls commands are extended to support IPv6 nexthop addresses.</p> <p>YANG Data Models:</p> <ul style="list-style-type: none"> • <code>Cisco-IOS-XR-mpls-traceroute-act.yang</code> • <code>Cisco-IOS-XR-mpls-ping-act.yang</code> <p>See (GitHub, Yang Data Models Navigator)</p>
Multi-area Loopback Interface Support for OSPF	<p>You can save IP addresses and resources, prevent the use of multiple node SIDs for labels associated with loopback interfaces, and save time configuring multiple loopback interfaces for an Area Border Router (ABR) in a network. These improvements are possible as you can now configure a single loopback interface for multiple areas. With this feature, an ABR can use a single loopback interface for all areas it connects to, eliminating the need for separate loopback interfaces for each area.</p> <p>Previously, each loopback interface was linked to only one area.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <p>The multi-area-interface command is extended to support loopback interfaces.</p>
SRv6 Traffic Class DSCP Marking Enhancement for QoS	<p>This feature enables you to configure the traffic-class DSCP marking to 6-bits using the new policy-map-extend keyword in the</p> <p>hw-module profile segment-routing srv6 mode microsegment f3216 encapsulation traffic-class CLI in both the L2 and L3 traffic configurations for SRv6. This is a mutually inclusive feature for L2 and L3 traffic. Therefore, this feature cannot be used in the individual configuration for L2 and L3 traffic.</p> <p>When you use the policy-map-extend keyword in the hw-module profile segment-routing srv6 mode microsegment f3216 encapsulation traffic-class CLI, the existing 3-bit DSCP marking set by the hw-module profile segment-routing srv6 mode microsegment f3216 encapsulation traffic-class l3-traffic policy-map CLI in the L3 traffic configuration is modified to 6-bits.</p> <p>This feature introduces this change:</p> <p>CLI: The policy-map-extend keyword is introduced in the hw-module profile segment-routing srv6 mode microsegment f3216 encapsulation traffic-class command.</p>

Feature	Description
SR ECMP-FEC Optimization for IPv6 Prefixes	<p>You can now minimize ECMP-FEC resource consumption and duplication of resources during underlay programming for an SR-MPLS network for IPv6 prefixes. The feature supports sharing the same ECMP-FEC, regular FEC, and Egress Encapsulation DB (EEDB) entries for all paths with the same outgoing MPLS label among IPv6 prefixes. This improvement is now possible by using the hw-module fib mpls label lsr-optimized command.</p> <p>In earlier releases, ECMP-FEC optimization for IPv4 prefixes was available.</p>
User-Defined Generic Metric Support for IS-IS Flex Algo	<p>This feature adds support for user-defined generic metric as a metric type for IS-IS Flexible Algorithm.</p> <p>You can now have more control over traffic flows using user-defined generic metrics. You can define a family of user-defined generic metrics that can advertise different types of administrative metrics such as jitter, reliability, and fiscal cost depending on the traffic class for Flexible Algorithms. You can selectively define and assign semantics of these metrics as per the network requirement.</p> <p>The feature introduces the following changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The feature introduces the generic-metric flex-algo and metric-type generic commands. <p>YANG Data Models:</p> <ul style="list-style-type: none"> <code>Cisco-IOS-XR-um-router-isis-cfg.yang</code>
L3VPN	
MPLS Layer 3 VPNs CLI Enhancements	<p>You can now verify that MPLS labels are correctly programmed in the control plane (or software) and the data plane (hardware forwarding tables) using the show mpls forwarding labels command.</p> <p>Previously the command only showed the MPLS label information for software, additional steps were required to verify the label status in the hardware, by checking in the SDK.</p>
Netflow	
Monitor GTP-U Traffic in 5G Network	<p>You can now export GTP-U traffic flow records using NetFlow v9 and IPFIX in 5G network. This enables you to monitor provides you with bidirectional traffic monitoring crucial for analytics and robust DDoS prevention strategies.</p> <p>This feature modifies the output of the show flow monitor command.</p>
Network Synchronization	

Feature	Description
Detect Packet Timing Signal Fail -unusable	<p>This feature allows the exclusion of Foreign Masters (FMs) with unstable timing from Best Master Clock Algorithm (BMCA). It enables the detection of clocks that are unusable due to Packet Timing Signal Fail (PTSF) and keeps them under surveillance for any timing stabilization. Once improvements are observed, these clocks can be reassessed and potentially reinstated as viable sources.</p> <p>The system's reliability is improved by regularly checking all Frequency Managers (FMs) for their Precision Time Protocol (PTP) timing accuracy, including those that are currently not selected. This allows for dynamic selection of time sources, which in turn improves service delivery and strengthens the resilience of the synchronization infrastructure..</p> <p>This feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> • detect-ptsf-unusable • The show ptp foreign-masters command output is enhanced to include phase difference values and servo status.
Delay Request-Response Mechanism for Passive Ports and PTP Phase Difference Alarm Triggering	<p>You can now enable the participation of passive ports in the Delay Request-Response Mechanism (DRRM), thus ensuring that in case the phase difference readings exceed the allowed threshold then syslogs are displayed.</p> <p>This feature enables you to detect potential errors such as fiber asymmetry or a clock failure in the PTP network by measuring the phase difference between passive port and secondary port.</p> <p>This feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> • phase-difference-threshold-breach • The show ptp foreign-masters command output is enhanced to include phase difference values and servo status. <p>YANG Data Models:</p> <p>The following data models are enhanced:</p> <ul style="list-style-type: none"> • <code>Cisco-IOS-XR-ptp-cfg.yang</code> • <code>Cisco-IOS-XR-um-ptp-cfg.yang</code>
<p>System Management</p>	

Feature	Description
Advanced Network Latency Insights through Frame Delay Categorization	<p>By precisely measuring the frame delay range into widths, bins, minimum-delay and range percentile, you can now get a clearer picture of network speeds by sorting delays into groups. This helps make sure data flows smoothly and problems are found and fixed faster. Plus, it allows users to check if most data gets through the network quickly, making the network more reliable for everyone.</p> <p>This feature introduces these changes:</p> <p>CLI:</p> <p>frame delay width bins minimum-delay frame-delay-range percentile</p> <p>Yang Data Models:</p> <ul style="list-style-type: none"> • Cisco-IOS-XR-ethernet-sat-oper.yang • Cisco-IOS-XR-ethernet-sat-cfg.yang
Support For Default mode of Encapsulation	<p>Using the default encapsulation setting for Service Activation Tests (SAT) streamlines the activation process with its ease of configuration and uniform testing standards. It accelerates service rollout by diminishing the need for intricate adjustments and guarantees the consistency of test outcomes. This setting establishes a dependable benchmark for assessing performance, benefits from extensive vendor support, and ensures seamless interaction between diverse network elements, aiding in the efficient deployment and ongoing management of network services.</p>
User-Specified MTU Support for EMIX Traffic in Service Activation Tests	<p>Defining the MTU packet size in Service Activation Tests (SAT) allows for tailored testing that matches the network's maximum frame capacity. This precision testing ensures accurate service performance validation and a reliable network service rollout.</p> <p>This feature introduces the following changes:</p> <p>CLI:</p> <p>packet-size emix Sequence h</p>
System Security	
Support for Layer 2 Untagged Sub-interface configuration in IEEE 802.1X Port-based Authentication	<p>This feature allows you to configure the Layer 2 untagged sub-interfaces in the IEEE 802.1X port-based authentication.</p>
System Monitoring	
Traffic Statistics with Packet Drop Location	<p>We help you save debugging time to locate packet drops by automatically detecting nonzero traffic drops from the commands running in the background and giving you the exact location of the packet drop.</p> <p>In earlier releases, you used multiple show commands with their respective locations to detect packet drops.</p> <p>This feature introduces the show drops all command.</p>

Feature	Description
System Setup	
Installing Owner and Partner RPMs Using IOS XR Install Infrastructure	<p>In previous releases, the Owner and Partner applications could not be installed via the same install infrastructure as the rest of the IOS XR software. Instead, you had to install these applications via the Application Manager interface.</p> <p>Starting this release, you can use the existing IOS XR install infrastructure to install your proprietary Owner and Partner RPMs. This enhancement streamlines the process for integrating third-party software seamlessly into the IOS XR environment, including bundling the owner and partner RPMs into a GISO.</p> <p>This feature introduces the keyword skip-implicit-owner-packages-checks in the following install commands:</p> <ul style="list-style-type: none"> • install package add • install replace • install replace reimage

The following feature is supported only on N540X-6Z18G-SYS-A/D variants.

Feature	Feature
Modular QoS	
Increase in Number of Ingress QoS Policies Supported on Layer 2	<p>Layer 2 Virtual Private Network (L2VPN) now supports increase in number of ingress QoS policies on all the class-map sizes.</p> <p>Now you can attach the additional QoS policies to the interfaces, to manage, prioritize, and control the flow of traffic at ingress.</p> <p>This feature is supported on the following Cisco NCS 540 router variants:</p> <ul style="list-style-type: none"> • N540X-6Z18G-SYS-A • N540X-6Z18G-SYS-D <p>To enable the increased ingress QoS policies on all the class-map sizes in Layer 2, this feature introduces the following new command:</p> <ul style="list-style-type: none"> • hw-module profile qos policer-scale l2-mode

The following feature is supported only on N540-24Q8L2DD-SYS router variant.

Feature	Description
Interface and Hardware Component	

Feature	Description
8x25G Breakout Port Support on N540-24Q8L2DD-SYS	<p>An 8x25G breakout interface allows you to split the 400G high-density ports into multiple lower-density ports.</p> <p>You can now configure 8x25G breakout ports using the optics QDD-2X100-SR4-S.</p> <p>Breakout port is supported on the following Cisco NCS 540 router variant:</p> <ul style="list-style-type: none"> • N540-24Q8L2DD-SYS

YANG Data Models Introduced and Enhanced

This release introduces or enhances the following data models. For detailed information about the supported and unsupported sensor paths of all the data models, see the [Github](#) repository. To get a comprehensive list of the data models supported in a release, navigate to the Available-Content.md file for the release in the Github repository. The unsupported sensor paths are documented as deviations. For example, `openconfig-acl.yang` provides details about the supported sensor paths, whereas `cisco-xr-openconfig-acl-deviations.yang` provides the unsupported sensor paths for `openconfig-acl.yang` on Cisco IOS XR routers.

You can also view the data model definitions using the [YANG Data Models Navigator](#) tool. This GUI-based and easy-to-use tool helps you explore the nuances of the data model and view the dependencies between various containers in the model. You can view the list of models supported across Cisco IOS XR releases and platforms, locate a specific model, view the containers and their respective lists, leaves, and leaf lists presented visually in a tree structure.

To get started with using data models, see the *Programmability Configuration Guide for Cisco NCS 540 Series Routers*.

Feature	Description
Programmability	
<code>openconfig-local-routing.yang</code> Version 2.0.1	<p>The OpenConfig data model, which is part of the <code>openconfig-network-instance.yang</code> data model is revised from version 1.2.0 to 2.0.1. This revision enables you to configure the preference for the order selection when multiple sources, such as protocols and static routes, contribute to the same prefix entry. A lower number signifies a better preference. When the preference value is not specified, default preference value is considered which is one.</p> <p>This data model supports event-driven and Model-driven telemetry.</p>

Feature	Description
openconfig-sflow.yang Version 1.0.0	<p>This OpenConfig data model is enhanced to support:</p> <ul style="list-style-type: none"> stream cadence-driven telemetry data for the total number of flow record packets sent to the collector using packets-sent leaf Stream cadence-driven telemetry data for the total number of packets sampled from the interface using packets-sampled leaf <p>This data model supports event-driven and Model-driven telemetry.</p>
Cisco-IOS-XR-infra-statsd-oper.yang	<p>The native yang data model streams cached counters using a TARGET_DEFINED subscription.</p> <p>It enables you to fetch interface statistics, such as bytes-received, packets-received and other details, from a cache which is periodically updated from hardware using generic-counters container. The hardware-timestamp field indicates the timestamp of the most recent hardware counter readings. If hardware-timestamp field is 0, the last-data-time field indicates the timestamp of the most recent counter readings, which could be either from hardware or software.</p>
openconfig-if-ip.yang Version 3.5.0	<p>The OpenConfig data model has been updated from version 3.0.0 to 3.5.0. This data model helps you specify data structures for managing both configuration and operational state on IP interfaces, supporting IPv4 and IPv6. You can stream telemetry for the operational state of these interfaces using both model-driven and event-driven approaches.</p>
Cisco-IOS-XR-ipv4-ospf-oper.yang	<p>This native data model is enhanced with new leaves <i>sr-capable</i>, <i>ri-capabilities-tlv</i>, <i>te-capable</i>, <i>gr-capable</i>, <i>grh-capable</i>, and <i>host-name</i> in the <i>OSPF-SH-NEIGHBOR-DETAIL</i> and <i>OSPF-SH-NEIGHBOR</i> groupings to display neighbor router capabilities in OSPF networks.</p>
Cisco-IOS-XR-evpn-oper.yang	<p>This native data model is enhanced to stream event-driven telemetry (EDT) data for the operational state of Layer 2 Ethernet VPN (EVPN) MAC routes using mac container. EDT data is streamed when an on-change event on the MAC route is detected such as adding, deleting or modifying a MAC address.</p>
Cisco-IOS-XR-mpls-traceroute-act.yang	<p>This unified data model is enhanced with a new container, <i>ipv6</i>, and leaves such as <i>next-hop</i>, <i>lsp-endpoint</i>, and <i>force-ipv6-explicit-null</i> in the <i>type-ipv6-next-hop</i> interface to extend support to Segment Routing OAM to verify network configuration for SR-MPLS IPv6-based LSPs.</p>
Cisco-IOS-XR-um-router-isis-cfg	<p>This unified data model is enhanced with new containers <i>generic-metric</i>, and <i>generic-metric-level</i> to define a family of user-defined generic metrics that can advertise different types of administrative metrics such as jitter, reliability, and fiscal cost depending on the traffic class for Flexible Algorithms.</p>

Hardware Introduced



Note Before you install the Cisco router, you must prepare your site for the installation, for more details on site planning and environmental requirements, see [Hardware Installation Guide](#).

Hardware	Description
Optics	<p>This release launches the following new optics on selective hardware within the product portfolio. For details and other new supported transceivers, refer to the Transceiver Module Group (TMG) Compatibility Matrix.</p> <ul style="list-style-type: none"> • Cisco 100GBASE QSFP-100G Modules <ul style="list-style-type: none"> • QSFP-100G-B20D4-I • QSFP-100G-B20U4-I • Cisco 10GBASE Dense Wavelength-Division Multiplexing SFP+ Modules <ul style="list-style-type: none"> • DWDM-SFP10G-C-I • Multirate GE, FE pluggable optics <ul style="list-style-type: none"> • ONS-SC-PTP-1510 • ONS-SC-PTP-1514 • Quad Small Form-factor Pluggable Double Density <ul style="list-style-type: none"> • DP04QSDD-ER1 • Cisco 400G QSFP-DD Cable and Transceiver Module <ul style="list-style-type: none"> • QDD-400G-SR8-S

Behavior Changes

- From this release, the default order of authentication methods for SSH clients on Cisco IOS XR routers running Cisco IOS XR SSH is changed to: **public-key**, **keyboard-interactive**, and **password**.
Prior to this release, the default order was: **public-key**, **password**, and **keyboard-interactive**.
- Cisco Secure DDoS Edge Protection is supported from Cisco IOS XR Release 7.10.1 on Cisco NCS 540 series routers. But the smart licensing usage and utilization reporting for the edge protection feature remains disabled. Usage details of the edge protection functionality will be enabled only in the future release. Hence, the **Smart Account In Use** utilization report for edge protection will show as 0 (zero) consumed.

- Prior to Cisco IOS XR Release 7.2.1, a segment of an explicit segment list can be configured as an IPv4 address (representing a Node or a Link) using the **index indexaddress ipv4 address** command.

Starting with Cisco IOS XR Release 7.2.1, an IPv4-based segment (representing a Node or a Link) can also be configured with the new **index index mpls adjacencyaddress** command. The configuration is stored in NVRAM in the same CLI format used to create it. There is no conversion from the old CLI to the new CLI.

Starting with Cisco IOS XR Release 7.9.1, the old CLI has been deprecated. Old configurations stored in NVRAM will be rejected at boot-up.

As a result, explicit segment lists with IPv4-based segments using the old CLI must be re-configured using the new CLI.

There are no CLI changes for segments configured as MPLS labels using the **index index mpls label label** command.

- If you are on a release before Cisco IOS XR Release 7.4.1, you can configure SR-ODN with Flexible Algorithm constraints using the **segment-routing traffic-eng on-demand color color dynamic sid-algorithm algorithm-number** command.

Starting with Cisco IOS XR Release 7.4.1, you can also configure SR-ODN with Flexible Algorithm constraints using the new **segment-routing traffic-eng on-demand color color constraints segments sid-algorithm algorithm-number** command.

From Cisco IOS XR Release 7.9.1, the **segment-routing traffic-eng on-demand color color dynamic sid-algorithm algorithm-number** command is deprecated. Previous configurations stored in NVRAM will be rejected at boot-up.

Hence, for Cisco IOS XR Release 7.9.1, you must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use the **on-demand dynamic sid-algorithm** with the **on-demand constraints** command.

Restrictions and Limitations on the Cisco NCS 540 Series Router

- The statistics collection may time out due to CPU overload during route churn. In such scenarios, statistics collection will resume when the CPU becomes available after the route churn is complete.
- Autonegotiation is disabled by default on the fixed GigE - 0/0/0/0 - 0/0/0/4 copper ports of N540X-16Z4G8Q2C-A/D and N540X-12Z16G-SYS-A/D router variants. To enable autonegotiation, use the **negotiation auto** command.
- If you're migrating from previous XR versions, then you must enable autonegotiation for fixed copper ports using the **negotiation auto** command before performing the software upgrade to avoid any links going down.
- Enabling or disabling frame preemption on the Time Sensitive Networking (TSN) port results in traffic drop for N540-FH-CSR-SYS. The port Twenty Five G0/0/12 is used as the TSN port.
- Fabric multicast queue stats are not supported in N540X-8Z16G-SYS-A/D, N540X-6Z18G-SYS-A/D, N540-6Z14S-SYS-D, N540-6Z18G-SYS-A/D, and N540X-4Z14G2Q-A/D variants.
- Unlabeled BGP PIC EDGE for global prefixes is not supported.

- The interface ports 0/0/0/24 to 0/0/0/31 do not support 1G Copper SFPs on N540-24Z8Q2C-SYS, N540-ACC-SYS, and N540X-ACC-SYS variants. Also, these ports do not support Auto-Negotiation with 1GE optical SFPs and they cannot act as 1GE Synchronous Ethernet sources.
- The interface ports 0/0/0/20 to 0/0/0/27 do not support 1G Copper SFPs on N540X-16Z4G8Q2C-A, N540X-16Z8Q2C-D, and N540X-16Z4G8Q2C-D variants. Also, these ports do not support Auto-Negotiation with 1GE optical SFPs and they cannot act as 1GE Synchronous Ethernet sources.
- Remove the speed settings on the 1G Copper optics when 10M/100M is configured and replaced with 1G SFP optics.
- The **hw-module profile mfib statistics** command is not supported.

Caveats

There are no caveats in this release.

IOS XR Base Images and Optional Packages

For more information on system setup and software installation process, see [System Setup and Software Installation Guide for Cisco NCS 540 Series Routers](#).

For general and ordering information see:

- [Cisco Network Convergence System 540 Fronthaul Routers Data Sheet](#)
- [Cisco Network Convergence System 540 Large Density Router Data Sheet](#)
- [Cisco Network Convergence System 540 Medium Density Routers Data Sheet](#)
- [Cisco Network Convergence System 540 Small Density Router Data Sheet](#)

To install the Cisco NCS 540 Series Routers, see [Cisco NCS 540 Router Hardware Installation Guide](#).

Release 24.2.11 Software

The following tables list the supported base images and optional packages and their corresponding file names.

- The first table lists the supported software for N540-24Q8L2DD-SYS, N540X-16Z4G8Q2C-A/D, N540-28Z4C-SYS-A/D, N540X-12Z16G-SYS-A/D, N540-12Z20G-SYS-A/D, N540-FH-CSR-SYS, N540X-16Z8Q2C-D and N540-FH-AGG-SYS variants.
- The second table lists the supported software for N540X-4Z14G2Q-A/D, N540X-8Z16G-SYS-A/D, N540-6Z14S-SYS-D, N540-6Z18G-SYS-A/D, and N540X-6Z18G-SYS-A/D variants.

Visit the [Cisco Software Download](#) page to download the Cisco IOS XR software images.

Table 1: Release 24.2.11 Software for N540-24Q8L2DD-SYS, N540X-16Z4G8Q2C-A/D, N540-28Z4C-SYS-A/D, N540X-12Z16G-SYS-A/D, N540-12Z20G-SYS-A/D, N540-FH-CSR-SYS, N540X-16Z8Q2C-D and N540-FH-AGG-SYS

Base Image	Filename	Description
------------	----------	-------------

IOS XR Base Image	ncs540l-x64-24.2.11.iso	<p>IOS XR base image with mandatory packages.</p> <p>The base ISO image also includes the following optional packages:</p> <ul style="list-style-type: none"> • xr-bgp • xr-cdp • xr-eigrp • xr-ipsla • xr-is-is • xr-k9sec • xr-lictrl • xr-lldp • xr-mcast • xr-mpls-oam • xr-netflow • xr-ospf • xr-perf-meas • xr-perfmgmt • xr-rip • xr-telnet • xr-track <p>These optional packages are also included in NCS540l-iosxr-24.2.11.tar.</p>
USB Boot Package	ncs540l-usb_boot-24.2.11.zip	<p>Package required to perform USB Boot.</p> <p>Includes the same packages as the base image.</p>
Optional Packages not included in the base image		
Package	Filename	Description
IOS XR Telnet (xr-telnet)	NCS540l-iosxr-24.2.11.tar	Supports Telnet
IOS XR EIGRP (xr-eigrp)	NCS540l-iosxr-24.2.11.tar	Supports EIGRP
IOS XR CDP (xr-cdp)	NCS540l-iosxr-24.2.11.tar	Supports CDP
IOS XR k9sec (xr-k9sec)	NCS540l-k9sec-rpms.24.2.11.tar	Supports 802.1X

IOS XR RIP (xr-rip)	NCS540l-iosxr-24.2.11.tar	Supports RIP
---------------------	---------------------------	--------------

Table 2: Release 24.2.11 Software for N540X-4Z14G2Q-A/D, N540X-8Z16G-SYS-A/D, N540-6Z14S-SYS-D, N540-6Z18G-SYS-A/D, and N540X-6Z18G-SYS-A/D

Base Image	Filename	Description
IOS XR Base Image	ncs540l-aarch64-24.2.11.iso	<p>IOS XR base image with mandatory packages.</p> <p>The ISO image also includes the following optional packages:</p> <ul style="list-style-type: none"> • xr-bgp • xr-cdp • xr-eigrp • xr-ipsla • xr-is-is • xr-k9sec • xr-lictrl • xr-lldp • xr-mcast • xr-mpls-oam • xr-ncs540l-mcast • xr-ncs540l-netflow • xr-netflow • xr-ospf • xr-perf-meas • xr-perfmgmt • xr-rip • xr-telnet • xr-track <p>These optional packages are also included in NCS540l aarch64 iosxr optional rpms-24.2.11.tar.</p>
USB Boot Package	ncs540l-aarch64-usb_boot-24.2.11.zip	<p>Package required to perform USB Boot.</p> <p>Includes the same packages as the base image.</p>

Optional Packages not included in the base image		
Package	Filename	Description
IOS XR Telnet (xr-telnet)	NCS540l-aarch64-iosxr-optional-rpms-24.2.11.tar	Supports Telnet
IOS XR EIGRP (xr-eigrp)	NCS540l-aarch64-iosxr-optional-rpms-24.2.11.tar	Supports EIGRP
IOS XR CDP (xr-cdp)	NCS540l-aarch64-iosxr-optional-rpms-24.2.11.tar	Supports CDP
IOS XR k9sec (xr-k9sec)	NCS540l-aarch64-k9sec-rpms.24.2.11.tar	Supports 802.1X
IOS XR RIP (xr-rip)	NCS540l-aarch64-iosxr-optional-rpms-24.2.11.tar	Supports RIP

Determine Software Version

Log in to the router and enter the **show version** command on the N540X-16Z4G8Q2C-A/D, N540-28Z4C-SYS-A/D, N540X-12Z16G-SYS-A/D, and N540-12Z20G-SYS-A/D variants:

```
RP/0/RP0/CPU0:Router#show version
Fri Jul 5 14:26:39.790 IST
Cisco IOS XR Software, Version 24.2.11 LNT
Copyright (c) 2013-2024 by Cisco Systems, Inc.

Build Information:
  Built By       : sajshah
  Built On       : Tue Jul 02 23:56:31 UTC 2024
  Build Host     : iox-ucs-054
  Workspace      : /auto/srcarchive11/prod/24.2.11/ncs540l/ws/
  Version        : 24.2.11
  Label         : 24.2.11
```

```
cisco NCS540L (C3708 @ 1.70GHz)
cisco N540X-16Z4G8Q2C-A (C3708 @ 1.70GHz) processor with 8GB of memory
EG-PE41 uptime is 1 day, 11 hours, 10 minutes
Cisco NCS 540 System with 16x10G+4x1Gcu+8x25G+2x100G DC
```

Log in to the router and enter the **show version** command on the N540X-4Z14G2Q-A/D, N540-6Z18G-SYS-A/D, N540X-8Z16G-SYS-A/D, N540-6Z14S-SYS-D, and N540X-6Z18G-SYS-A/D variants:

```
RP/0/RP0/CPU0:Router#show version
Cisco IOS XR Software, Version 24.2.11 LNT
Copyright (c) 2013-2024 by Cisco Systems, Inc.

Build Information:
  Built By       : sajshah
  Built On       : Wed Jul 03 00:06:49 UTC 2024
  Build Host     : iox-ucs-055
  Workspace      : /auto/srcarchive11/prod/24.2.11/ncs540l-aarch64/ws/
  Version        : 24.2.11
  Label         : 24.2.11
```

```
cisco NCS540L
cisco N540X-6Z18G-SYS-A processor with 8GB of memory
Darwin-CE48 uptime is 17 hours, 6 minutes
Cisco NCS 540 Series Fixed Router 18x1G, 6x1/10G, AC
```

Log in to the router and enter the **show version** command on the N540-24Q8L2DD-SYS variant:


```
RP/0/RP0/CPU0:Router#show version
Fri Jul 5 14:26:39.790 IST
Cisco IOS XR Software, Version 24.2.11 LNT
Copyright (c) 2013-2024 by Cisco Systems, Inc.
```

Build Information:

```
Built By      : sajshah
Built On     : Tue Jul 02 23:56:31 UTC 2024
Build Host   : iox-ucs-054
Workspace    : /auto/srcarchive11/prod/24.2.11/ncs5401/ws/
Version      : 24.2.11
Label       : 24.2.11
```

```
cisco NCS540L (C3708 @ 1.70GHz)
cisco N540-24Q8L2DD-SYS (C3708 @ 1.70GHz) processor with 8GB of memory
EG-PE41 uptime is 1 day, 11 hours, 10 minutes
Cisco NCS 540 System with 16x10G+4x1GCU+8x25G+2x100G DC
```

Log in to the router and enter the **show version** command on the N540-FH-AGG-SYS variant:

```
RP/0/RP0/CPU0:Router#show version
Fri Jul 5 14:26:39.790 IST
Cisco IOS XR Software, Version 24.2.11 LNT
Copyright (c) 2013-2024 by Cisco Systems, Inc.
```

Build Information:

```
Built By      : sajshah
Built On     : Tue Jul 02 23:56:31 UTC 2024
Build Host   : iox-ucs-054
Workspace    : /auto/srcarchive11/prod/24.2.11/ncs5401/ws/
Version      : 24.2.11
Label       : 24.2.11
```

```
cisco NCS540L (C3708 @ 1.70GHz)
cisco N540-FH-AGG-SYS (C3708 @ 1.70GHz) processor with 8GB of memory
EG-PE41 uptime is 1 day, 11 hours, 10 minutes
Cisco NCS 540 System with 16x10G+4x1GCU+8x25G+2x100G DC
```

Determine Firmware Support

Use the show command in EXEC mode to view the hardware components with their current FPD version and status. The status of the hardware must be “CURRENT”; Running and Programed version must be the same. The Golden FPDs with “NEED UPGD” can be ignored, the Golden FPDs are not upgradable.



Note If the **Req Reload** field is mentioned as **Yes** in the output, then it indicates the need for a router reboot for the FPD's latest version to take effect.

Log in to the router and enter the **show fpd package** and **show hw-module fpd** commands on the Cisco N540-28Z4C-SYS-A/D, N540-12Z20G-SYS-A/D, N540X-12Z16G-SYS-A/D, N540X-16Z8Q2C-D, and N540X-16Z4G8Q2C-A/D variants:

```
RP/0/RP0/CPU0:Router#show fpd package
Fri Jul 5 14:26:49.444 IST
```

```
=====
Field Programmable Device Package
=====
Card Type          FPD Description          Req   SW   Min Req   Min Req
                        Reload Ver               SW Ver   Board Ver
```

Determine Firmware Support

N540-12Z20G-SYS-A	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0
N540-12Z20G-SYS-D	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0
N540-28Z4C-SYS-A	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	JMAC1-Config	YES	3.00	3.00	0.0
	JMAC2-Config	YES	3.00	3.00	0.0
	JMAC3-Config	YES	3.00	3.00	0.0
	JMAC4-Config	YES	3.00	3.00	0.0
	JMAC5-Config	YES	3.00	3.00	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0
N540-28Z4C-SYS-D	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	JMAC1-Config	YES	3.00	3.00	0.0
	JMAC2-Config	YES	3.00	3.00	0.0
	JMAC3-Config	YES	3.00	3.00	0.0
	JMAC4-Config	YES	3.00	3.00	0.0
	JMAC5-Config	YES	3.00	3.00	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0
N540X-12Z16G-SYS-A	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0
N540X-12Z16G-SYS-D	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0

	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0

N540X-16Z4G8Q2C-A	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0

N540X-16Z4G8Q2C-D	ADM_FW	YES	14.03	14.03	0.0
	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0

N540X-16Z8Q2C-A	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0

N540X-16Z8Q2C-D	ADMConfig	NO	1.05	1.05	0.0
	IoFpga	YES	3.08	3.08	0.0
	IoFpgaGolden	YES	2.07	2.03	0.0
	Primary-BIOS	YES	1.49	1.49	0.0
	StdbyFpga	YES	0.50	0.50	0.0
	StdbyFpgaGolden	YES	0.50	0.40	0.0
	TamFw	YES	4.13	4.13	0.0
	TamFwGolden	YES	4.13	4.11	0.0

RP/0/RP0/CPU0:Router#show hw-module fpd
 Fri Jul 5 14:26:57.786 IST

Auto-upgrade:Enabled
 Attribute codes: B golden, P protect, S secure, A Anti Theft aware

Location	Card type	HWver	FPD device	ATR Status	FPD Versions	
					Running	Programd
0/RP0/CPU0	N540X-16Z4G8Q2C-A	0.2	ADM_FW	CURRENT	14.03	14.03
NOT REQ						
0/RP0/CPU0	N540X-16Z4G8Q2C-A	0.2	ADMConfig	CURRENT	1.05	1.05
NOT REQ						
0/RP0/CPU0	N540X-16Z4G8Q2C-A	0.2	IoFpga	CURRENT	3.08	3.08
0/RP0						
0/RP0/CPU0	N540X-16Z4G8Q2C-A	0.2	IoFpgaGolden	B CURRENT	2.0	2.03
0/RP0						
0/RP0/CPU0	N540X-16Z4G8Q2C-A	0.2	Primary-BIOS	SA CURRENT	1.49	1.49

Determine Firmware Support

```

0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2 StdbyFpga S CURRENT 0.50 0.50
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2 StdbyFpgaGolden BS CURRENT 0.50 0.40
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2 TamFw S CURRENT 4.13 4.13
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2 TamFwGolden BS CURRENT 4.13 4.11
0/RP0

```

Log in to the router and enter the **show fpd package** and **show hw-module fpd** commands on the Cisco N540X-4Z14G2Q-A/D, N540-6Z18G-SYS-A/D, N540X-6Z18G-SYS-A/D, N540-6Z14S-SYS-D, and N540X-8Z16G-SYS-A/D variants:

```
RP/0/RP0/CPU0:Router#show fpd package
```

```

=====
Field Programmable Device Package
=====
Card Type          FPD Description          Req  SW   Min Req  Min Req
Reload  Ver   SW Ver   Board Ver
=====
-----
N540-6Z14S-SYS-D   ADMConfig                NO   5.03   5.03     0.0
                  BckUp-BootLoader        YES  20.08  20.08     0.0
                  IoFpga                   YES  0.17   0.17     0.0
                  IoFpgaGolden             YES  0.15   0.15     0.0
                  Prim-BootLoader          YES  20.08  20.08     0.0
                  StdbyFpga                YES  2.05   2.05     0.0
                  StdbyFpgaGolden          YES  0.33   0.33     0.0
                  TamFw                    YES  6.05   6.05     0.0
                  TamFwGolden              YES  6.05   6.05     0.0
-----
N540-6Z18G-SYS-A   ADMConfig                NO   5.03   5.03     0.0
                  BckUp-BootLoader        YES  20.08  20.08     0.0
                  IoFpga                   YES  0.08   0.08     0.0
                  IoFpgaGolden             YES  0.03   0.03     0.0
                  Prim-BootLoader          YES  20.08  20.08     0.0
                  StdbyFpga                YES  2.05   2.05     0.0
                  StdbyFpgaGolden          YES  0.33   0.33     0.0
                  TamFw                    YES  6.05   6.05     0.0
                  TamFwGolden              YES  6.05   6.05     0.0
-----
N540-6Z18G-SYS-D   ADMConfig                NO   5.03   5.03     0.0
                  BckUp-BootLoader        YES  20.08  20.08     0.0
                  IoFpga                   YES  0.08   0.08     0.0
                  IoFpgaGolden             YES  0.03   0.03     0.0
                  Prim-BootLoader          YES  20.08  20.08     0.0
                  StdbyFpga                YES  2.05   2.05     0.0
                  StdbyFpgaGolden          YES  0.33   0.33     0.0
                  TamFw                    YES  6.05   6.05     0.0
                  TamFwGolden              YES  6.05   6.05     0.0
-----
N540X-4Z14G2Q-A   ADMConfig                NO   5.00   5.00     0.0
                  BckUp-BootLoader        YES  20.08  20.08     0.0
                  IoFpga                   YES  0.17   0.17     0.0
                  IoFpgaGolden             YES  0.15   0.15     0.0
                  Prim-BootLoader          YES  20.08  20.08     0.0
                  StdbyFpga                YES  2.05   2.05     0.0
                  StdbyFpgaGolden          YES  0.33   0.33     0.0
                  TamFw                    YES  6.05   6.05     0.0
                  TamFwGolden              YES  6.05   6.05     0.0
-----
N540X-4Z14G2Q-D   ADMConfig                NO   5.00   5.00     0.0
                  BckUp-BootLoader        YES  20.08  20.08     0.0

```

	IoFpga	YES	0.17	0.17	0.0
	IoFpgaGolden	YES	0.15	0.15	0.0
	Prim-BootLoader	YES	20.08	20.08	0.0
	StdbyFpga	YES	2.05	2.05	0.0
	StdbyFpgaGolden	YES	0.33	0.33	0.0
	TamFw	YES	6.05	6.05	0.0
	TamFwGolden	YES	6.05	6.05	0.0

N540X-6Z18G-SYS-A	ADMConfig	NO	5.00	5.00	0.0
	BckUp-BootLoader	YES	20.08	20.08	0.0
	IoFpga	YES	0.17	0.17	0.0
	IoFpgaGolden	YES	0.15	0.15	0.0
	Prim-BootLoader	YES	20.08	20.08	0.0
	StdbyFpga	YES	2.05	2.05	0.0
	StdbyFpgaGolden	YES	0.33	0.33	0.0
	TamFw	YES	6.05	6.05	0.0
	TamFwGolden	YES	6.05	6.05	0.0

N540X-6Z18G-SYS-D	ADMConfig	NO	5.00	5.00	0.0
	BckUp-BootLoader	YES	20.08	20.08	0.0
	IoFpga	YES	0.17	0.17	0.0
	IoFpgaGolden	YES	0.15	0.15	0.0
	Prim-BootLoader	YES	20.08	20.08	0.0
	StdbyFpga	YES	2.05	2.05	0.0
	StdbyFpgaGolden	YES	0.33	0.33	0.0
	TamFw	YES	6.05	6.05	0.0
	TamFwGolden	YES	6.05	6.05	0.0

N540X-8Z16G-SYS-A	ADMConfig	NO	5.00	5.00	0.0
	BckUp-BootLoader	YES	20.08	20.08	0.0
	IoFpga	YES	0.17	0.17	0.0
	IoFpgaGolden	YES	0.15	0.15	0.0
	Prim-BootLoader	YES	20.08	20.08	0.0
	StdbyFpga	YES	2.05	2.05	0.0
	StdbyFpgaGolden	YES	0.33	0.33	0.0
	TamFw	YES	6.05	6.05	0.0
	TamFwGolden	YES	6.05	6.05	0.0

N540X-8Z16G-SYS-D	ADMConfig	NO	5.00	5.00	0.0
	BckUp-BootLoader	YES	20.08	20.08	0.0
	IoFpga	YES	0.17	0.17	0.0
	IoFpgaGolden	YES	0.15	0.15	0.0
	Prim-BootLoader	YES	20.08	20.08	0.0
	StdbyFpga	YES	2.05	2.05	0.0
	StdbyFpgaGolden	YES	0.33	0.33	0.0
	TamFw	YES	6.05	6.05	0.0
	TamFwGolden	YES	6.05	6.05	0.0

RP/0/RP0/CPU0:Router#show hw-module fpd

Auto-upgrade:Enabled

Attribute codes: B golden, P protect, S secure, A Anti Theft aware

Location	Card type	HWver	FPD device	ATR	Status	FPD Versions	
						Running	Programd
0/RP0/CPU0	N540X-6Z18G-SYS-A	0.2	ADMConfig		CURRENT	5.00	5.00
	NOT REQ						
0/RP0/CPU0	N540X-6Z18G-SYS-A	0.2	IoFpga		CURRENT	0.17	0.17
	0/RP0						
0/RP0/CPU0	N540X-6Z18G-SYS-A	0.2	IoFpgaGolden	B	CURRENT	0.15	0.15
	0/RP0						
0/RP0/CPU0	N540X-6Z18G-SYS-A	0.2	Prim-BootLoader	A	CURRENT	20.08	20.08
	0/RP0						
0/RP0/CPU0	N540X-6Z18G-SYS-A	0.2	StdbyFpga	S	CURRENT	2.05	2.05

Determine Firmware Support

```

0/RP0
0/RP0/CPU0 N540X-6Z18G-SYS-A 0.2 StdbyFpgaGolden BS CURRENT 0.33 0.33
0/RP0
0/RP0/CPU0 N540X-6Z18G-SYS-A 0.2 TamFw S CURRENT 6.05 6.05
0/RP0
0/RP0/CPU0 N540X-6Z18G-SYS-A 0.2 TamFwGolden BS CURRENT 6.05 6.05
0/RP0

```

Log in to the router and enter the **show fpd package** and **show hw-module fpd** commands on the Cisco N540-24Q8L2DD-SYS variant:

```
RP/0/RP0/CPU0:Router#show fpd package
```

```

=====
Field Programmable Device Package
=====
Card Type          FPD Description          Req   SW   Min Req  Min Req
=====          =====          =====  =====  =====  =====
N540-24Q8L2DD-SYS  ADM-DBConfig            NO    2.05  2.05     0.0
                   ADM-MBConfig            NO    2.05  2.05     0.0
                   IoFpga                  YES   2.12  2.12     0.0
                   IoFpgaGolden            YES   2.12  2.12     0.0
                   Primary-BIOS            YES   4.07  4.07     0.0
                   SsdSAMS64G3            YES  12.41 12.41     0.0
                   StdbyFpga               YES   2.59  2.59     0.0
                   StdbyFpgaGolden        YES   2.56  2.39     0.0
                   TamFw                   YES   6.05  6.05     0.0
                   TamFwGolden            YES   6.05  6.05     0.0

```

```
RP/0/RP0/CPU0:Router#show hw-module fpd
```

```
Fri Jul 5 14:26:57.786 IST
```

```
Auto-upgrade:Enabled
```

```
Attribute codes: B golden, P protect, S secure, A Anti Theft aware
```

```

Location  Card type          HWver FPD device          ATR Status  FPD Versions
Reload Loc
=====
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  ADM_FW          CURRENT  14.03  14.03
NOT REQ
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  ADMConfig      CURRENT  1.05  1.05
NOT REQ
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  IoFpga         CURRENT  3.08  3.08
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  IoFpgaGolden   B  CURRENT  2.0  2.03
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  Primary-BIOS   SA  CURRENT  1.49  1.49
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  StdbyFpga     S  CURRENT  0.50  0.50
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  StdbyFpgaGolden BS  CURRENT  0.50  0.40
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  TamFw         S  CURRENT  4.13  4.13
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A 0.2  TamFwGolden   BS  CURRENT  4.13  4.11
0/RP0

```

Log in to the router and enter the **show fpd package** and **show hw-module fpd** commands on the Cisco N540-FH-AGG-SYS variant:

```
RP/0/RP0/CPU0:Router#show fpd package
```

```
Fri Jul 5 14:26:49.444 IST
```

```

=====
Field Programmable Device Package
=====
Card Type          FPD Description          Req   SW   Min Req  Min Req
Reload            Ver                      Ver   Ver   SW Ver   Board Ver
=====
N540-FH-AGG-SYS   ADM1_Config              NO    1.02  1.02     1.0
                  ADM2_Config              NO    1.02  1.02     1.0
                  DpFpgaCpri               YES   0.24  0.24     0.0
                  DpFpgaEth                YES   1.22  1.22     0.0
                  IoFpga                   YES   1.30  1.30     0.0
                  IoFpgaGolden             YES   1.30  1.30     0.0
                  Primary-BIOS             YES   1.49  1.49     0.0
                  StdbyFpga                YES   0.46  0.46     0.0
                  StdbyFpgaGolden         YES   0.46  0.46     0.0
                  TamFw                    YES   6.05  6.05     0.0
                  TamFwGolden             YES   6.05  6.05     0.0
=====

```

```

RP0/RP0/CPU0:Router#show hw-module fpd
Fri Jul 5 14:26:57.786 IST

```

```

Auto-upgrade:Enabled
Attribute codes: B golden, P protect, S secure, A Anti Theft aware

```

```

FPD Versions
=====
Location  Card type          HWver FPD device          ATR Status  Running Programd
Reload Loc
=====
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  ADM_FW              CURRENT     14.03     14.03
NOT REQ
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  ADMConfig           CURRENT     1.05      1.05
NOT REQ
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  IoFpga              CURRENT     3.08      3.08
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  IoFpgaGolden       B CURRENT     2.0       2.03
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  Primary-BIOS       SA CURRENT     1.49      1.49
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  StdbyFpga          S CURRENT     0.50      0.50
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  StdbyFpgaGolden   BS CURRENT     0.50      0.40
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  TamFw              S CURRENT     4.13      4.13
0/RP0
0/RP0/CPU0 N540X-16Z4G8Q2C-A  0.2  TamFwGolden       BS CURRENT     4.13      4.11
0/RP0

```

Important Notes

Licensing

Starting with Cisco IOS XR Release 24.1.1, Smart Licensing Using Policy (SLP) is the default Licensing model. When you upgrade to the Cisco IOS XR Release 24.1.1 release or later, the Smart Licensing Using Policy is enabled by default.

You can migrate your devices to Smart Licensing with Policy model, see *Migrating from Smart Licensing to Smart Licensing Using Policy*, [Smart Licensing Using Policy on Cisco IOS XR Routers](#).

We recommend that you update to the latest version of [SSM On-Prem](#) or [Cisco Smart Licensing Utility](#).



Note SSM On-Prem and CSSM both support SLP devices and SL devices. SLP devices and SL devices can coexist in a network. The Smart Licensing (SL) model is available in releases Cisco IOS XR Release 7.11.1 and earlier.

Supported Transceiver Modules

For more information on the supported transceiver modules, see [Transceiver Module Group \(TMG\) Compatibility Matrix](#). In the **Begin your Search** search box, enter the keyword NCS540 and click **Enter**.

Upgrading Cisco IOS XR Software



Note For software installation and upgrades, refer to the respective upgrade/downgrade docs *.tar* files based on your [540 router variant](#).

Cisco IOS XR Software is installed and activated from modular packages, allowing specific features or software patches to be installed, upgraded, or downgraded without affecting unrelated processes.

The upgrade document for N540-28Z4C-SYS-A/D, N540-12Z20G-SYS-A/D, N540X-12Z16G-SYS-A/D, N540X-16Z4G8Q2C-A/D, N540-24Q8L2DD-SYS, N540-FH-AGG-SYS, N540X-16Z8Q2C-D, and N540-FH-CSR-SYS variants is available along with the software image in *NCS540l-docs-24.2.11.tar* file.

The upgrade document for N540X-4Z14G2Q-A/D, N540X-8Z16G-SYS-A/D, N540-6Z14S-SYS-D, N540-6Z18G-SYS-A/D, and N540X-6Z18G-SYS-A/D variants is available along with the software image in *NCS540l-aarch64-docs-24.2.11.tar* file.



Note Quad configurations will be lost when you perform a software downgrade on Cisco NCS 540 Routers that support quad configurations from IOS XR Release 7.5.1 onwards to a release prior to IOS XR Release 7.5.1 due to a non-backward compatibility change. The lost configuration can be applied manually after the downgrade.

Production Software Maintenance Updates (SMUs)

A production SMU is a SMU that is formally requested, developed, tested, and released. Production SMUs are intended for use in a live network environment and are formally supported by the Cisco TAC and the relevant development teams. Software bugs identified through software recommendations or Bug Search Tools are not a basis for production SMU requests.

For information on production SMU types, refer the [Production SMU Types](#) section of the *IOS XR Software Maintenance Updates (SMUs)* guide.

Cisco IOS XR Error messages

To view, search, compare, and download Cisco IOS XR Error Messages, refer to the [Cisco IOS XR Error messages](#) tool.

Cisco IOS XR MIBs

To determine the MIBs supported by platform and release, refer to the [Cisco IOS XR MIBs](#) tool.

Related Documentation

The most current Cisco NCS 540 router documentation is located at the following URL:

<https://www.cisco.com/c/en/us/td/docs/iosxr/ncs-540-series-routers.html>

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2024 Cisco Systems, Inc. All rights reserved.