



RMV Commands

This chapter provides remove (RMV) commands for the Cisco ONS 15454, Cisco ONS 15454 M2, and Cisco ONS 15454 M6.



Note

All commands supported on the Cisco ONS 15454 platform are also supported on Cisco ONS 15454 M2 and Cisco ONS 15454 M6 platforms.

19.1 RMV-<MOD2>

The Remove 10GFC, 10GIGE, 40GIGE, 100GIGE, 1GFC, 1GFICON, 2GFC, 2GFICON, 5GIB, 8GFC, CLNT, D1VIDEO, DS1, DV6000, DVBA5I, E1, E3, E4, EC1, ESCON, ETRCLO, ETH, FSTE, G1000, GFPOS, GIGE, HDTV, ISC1, ILK, ISCCOMPAT, ISC3PEER2R, ISC3PEER1G, ISC3PEER2G, OC12, OC192, OC3, OC48, OC768, OCH, OMS, OTS, OTU3, OTU4, POS, STS1, STS12C, STS18C, STS192C, STS24C, STS36C, STS3C, STS48C, STS96C, STS6C, STS9C, T1, T3, VC12, VC3, VT1, VT2, 3GVIDEO, SDSDI, HDSDI, AUTO, OTU1, ISC3STP1G, or ISC3STP2G (RMV-<MOD2>) command removes a facility from service.

Usage Guidelines

The command supports the modifier 3GVIDEO, SDSDI, HDSDI, AUTO, OTU1, ISC3STP1G, and ISC3STP2G.

See [Table 28-1 on page 28-1](#) for other supported modifiers by platform.

Category

Ports

Security

Maintenance

Input Format

RMV-<MOD2>:[<TID>]:<AID>:<CTAG>[::];

Input Example

RMV-OTU1:ROCCIANERA:VFAC-14-3-1:123;

Input Parameters	<AID>	Access identifier from the “26.1 ALL” section on page 26-1 . The AR-MXP, AR-XP, and AR-XPE cards use the VFAC Access Identifier.
-------------------------	-------	--

19.2 RMV-EQPT

(Cisco ONS 15454, ONS 15454 M2, and ONS 15454 M6) The Remove Equipment (RMV-EQPT) command removes equipment from the In Service (IS) state and places it into the Maintenance (MT) state.

Usage Guidelines This command is only applicable to equipment that is in transition from the IS state to the MT state.



Note

This command can be executed only if the equipment is in IS-NR, OOS-AU,MEA or OOS-AU,UEQ state.

Category Equipment

Security Maintenance

Input Format RMV-EQPT:[<TID>]:<AID>:<CTAG>[::];

Input Example RMV-EQPT:CISCO:SLOT-1:1;

Input Parameters	<AID>	Access identifier from the “26.15 EQPT” section on page 26-39 .
-------------------------	-------	---