

Using Pathtrace

• Pathtrace, on page 1

Pathtrace

The Pathtrace feature builds on the Traceroute feature to provide information about interfaces, such as ingress and egress interface names and the number of transmitted and received frames and errors, at each hop in the path between 2 devices in a fabric. Pathtrace provides an end-to-end view of the shortest path without the need to connect to individual switches and check the Fabric Shortest Path First (FSPF) topology hop by hop.

Pathtrace is used to trace the path from a switch on which the **pathtrace** command is run, to a destination device or all the devices in a destination domain. The Pathtrace feature works with the Fibre Channel, Fibre Channel over Ethernet (FCoE), and Fibre Channel over IP (FCIP) interfaces. Pathtrace collects information about the available paths within the fabric and provides information for devices along the shortest path. Pathtrace displays the source interface, destination interface, cost, speed, and other statistics when used with the **detail** keyword. The **pathtrace** command can also be used to display the reverse path information (from destination back to the source). If the destination cannot be reached, Pathtrace displays the device on which the connectivity terminated.

The statistics displayed for various types of interfaces are:

- Fibre Channel interface—The statistics are displayed for the associated Fibre Channel interfaces.
- Virtual Fibre Channel (VFC) interface—The statistics are displayed for the associated Ethernet interfaces.
- Fibre Channel port channel—The statistics are displayed for port channels.
- VFC port channel—The statistics are displayed for VFC port channels.
- FCIP interface or FCIP port channel—The statistics are displayed for the FCIP interfaces or FCIP port channels.

Guidelines and Limitations for Pathtrace

- Pathtrace is not supported on Cisco MDS switches that are operating in the Cisco NPV mode.
- Pathtrace does not support interop mode.
- Pathtrace is supported only on Cisco MDS switches and not on other vendor switches.

- Pathtrace does not support virtual domains (Inter-VSAN Routing [IVR] for Pathtrace).
- Pathtrace is not manageable via Simple Network Management Protocol (SNMP).
- Pathtrace supports a maximum of 16 hops without the reverse option, and 8 hops with the reverse option.
- Statistics are displayed only for egress interfaces.
- Statistics for FCIP and FCIP port-channel interfaces are not displayed for devices in the path running Cisco MDS NX-OS Release 6.2(5).

Using Pathtrace or Pathtrace Multipath

To display per-hop interface information along the paths between 2 devices, run this command:

```
switch# pathtrace {domain id | fcid id} vsan id [[reverse] [detail] | [multipath]]
```

The following example shows how to trace the path between a switch in which the command is executed and an edge device, using the edge device's FCID:

switch# pathtrace fcid 0xca016c vsan 2000 The final destination port type is F Port

H	op Domair	n In-Port	Out-Port	Speed	Cost	Switchname	
-	111 202	embedded fc1/6	fc1/6 fc1/1		250 -	switch1 switch2	
N	OTE: The	stats are	displayed for the e	gress interf	ace	only	

The following example shows how to trace both the forward path and the return path between a switch in which the command is executed and an edge device, using the edge device's FCID:

switch# pathtrace fcid 0xca016c vsan 2000 reverse

The final destination port type is F_Port

Нор	Domain	In-Port	Out-P	ort	Speed	Cost	Switchname
0	111	embedded	fc1/6		4G	250	switch1
1	202	fc1/6	fc1/1		2G	-	switch2
2	202	embedded	fc1/6		4 G	250	switch2
3	111	fc1/6	embed	ded	-	-	switch1
NOTE	E: The	stats are	displayed for	the egress	interi	face of	nly

The following example shows how to display detailed information about the interfaces (both the forward path and the return path) between a switch in which the command is executed and an edge device, using the edge device's FCID:

switch# pathtrace fcid 0xca016c vsan 2000 reverse detail

The final destination port type is F_Port

Hop 0	Domain	In-Port	Out-Port	Speed	Cost	Switchname
	111	embedded	fc1/6	4G	250	switch1

Stats for egress port: fc1/6

TxRt(B/s): 2944 RxRt(B/s): 3632 TxB B: 32

```
RxB B: 32
     TxFrame: 137467
     RxFrame: 137475
     Errors: 0
     Discard: 0
        CRC: 0
        Domain In-Port Out-Port Speed Cost Switchname 202 fc1/6 fc1/1 2G - switch2
Hop 1
______
Stats for egress port: fc1/1
   TxRt(B/s): 1424
   RxRt(B/s): 1528
      TxB B: 0
      RxB B: 32
     TxFrame: 711
     RxFrame: 649
     Errors: 0
     Discard: 15
        CRC: 0
                                        Speed Cost 5...
4G 250 switch2
                         Out-Port
fc1/6
Нор 2
          Domain In-Port
                                              Speed Cost Switchname
          202 embedded
Stats for egress port: fc1/6
   TxRt(B/s): 3632
   RxRt(B/s): 2952
      TxB B: 32
       RxB B: 32
     TxFrame: 137476
     RxFrame: 137467
     Errors: 0
     Discard: 0
       CRC: 0
Hop 3 Domain In-Port Out-Port Speed Cost Switchname
          111 fc1/6
                              embedded
                                              - - switch1
Stats for egress port: embedded
   TxRt(B/s): -
   RxRt(B/s): -
      TxB B: -
      RxB B: -
     TxFrame: -
     RxFrame: -
     Errors: -
     Discard: -
        CRC: -
NOTE: The stats are displayed for the egress interface only
```

The following example shows how to trace all the links (including equal-cost parallel links) in the paths between all the edge devices in a domain and a switch in which the command is executed:

```
switch# pathtrace domain 238 vsan 1 multipath
***NOTE ***
    I - Ingress
    E - Egress
    M - Member Port-channel
    * - Fport

PATH 1 switch1 switch2
Domain 236 235
```

HOP 1 sw:	itch1(fo	 :1/11)(E)-	(I)	(fc1/12) switch	 2			
Interface TxWait(1s/	-				RxB2B	Errors	Discards	CRC	
(E) fc1/11	8.0	84	44	64	64	0	2	0	0%/0%/0%/0%
(I) fc1/12 -	8.0	- 44 -	84	64	64	0	0	0	0%/0%/0%/0%
HOP 2 sw:	itch2(fo	:1/3)(E)*E	nd Device						
Interface [xWait(1s/1	-				RxB2B	Errors	Discards	CRC	
(E) fc1/3	4.0	0 -	0	16	64	0	0	0	0%/0%/0%/0%
PATH 2 st Domain 23		235						• • • • • • • •	
		:1/12) (E) -		(fc1/11) switch				
Interface [xWait(1s/1	Spd (G)	Tx(B/s)	Rx(B/s)	TxB2B neDrops	 RxB21		s Discards	CRC	
(E) fc1/12	8.0	64	180	64	64	0	0	0	0%/0%/0%/0%
- (I)fc1/11	8.0	180	64	64	64	0	0	0	0%/0%/0%/0%
Interface IxWait(1s/				TxB2B oneDrop		Errors	Discards	CRC	
(E) fc1/3	4.0	0 –	0	16	64	0	0	0	0%/0%/0%/0%
switch# pat ***NOTE *** I - Ingress E - Egress M - Member * - Fport PATH 1 st Domain 18	* s s Port-ch witch1 s	nannel	2 vsan 44						
HOP 1		switch1(port-chan	nel216)	(E)	(I) (p	ort-channel	 216)sw	itch2
Interface OutputFrame							nputFrames(
(E)port-cha									3752399382446
(M) fcip	50	292049		55048	436	3	239		27507
(M) fcip	51	291539		55052	889	3	237		27508

(M)fcip52	291702	55080573	3239	27522
(M)fcip53	278265	52552382	3090	26258
(M) fcip54	278291	52561525	3090	26263
(M)fcip55	278346	52559754	3090	26262
(M)fcip65	291647	55073072	3238	27518
(M)fcip66	278491	52584017	3092	26274
(M)fcip67	278362	52571056	3091	26268
(M)fcip86	278290	52554341	3090	26259
(M)fcip87	278426	52587737	3092	26276
(M)fcip88	278551	52602163	3093	26283
(I)port-channel216	640830213	3394016	1375252823146496 1	61842957647872
(M)fcip50	55058685	292105	27512	3240
(M) fcip51	55080107	291690	27522	3239
(M)fcip52	55097520	291794	27530	3240
(M)fcip53	52559881	278311	26262	3090
(M)fcip54	52570959	278345	26268	3091
(M) fcip55	52571081	278410	26268	3091
(M)fcip65	55051714	291539	27507	3237
(M)fcip66	52564219	278387	26264	3091
(M)fcip67	52562847	278324	26264	3090
(M)fcip86	52564931	278345	26265	3091
(M)fcip87	52571632	278350	26268	3091
(M)fcip88	52576637	278416	26271	3091

switch# pathtrace domain 83 vsan 70 multipath

***NOTE ***

I - Ingress

E - Egress

M - Member Port-channel

* - Fport

.....

PATH 1 switch1 switch2 Domain 144 83

HOP 1 switch1(vfc69)(E)-----(I)(vfc69)switch2

Interface Spd(G) FcoeOut(Oct) FcoeIn(Oct) FcoeOutPkt FcoeInPkt

(E) vfc69	10.0	165604	153648	697	700
(I)vfc69	10.0	153716	166276	701	698



Note

- In the output, *embedded* indicates that the respective port is an HBA interface on an edge device.
- Some of the terminologies used in the multipath outputs are defined in the following table:

Table 1: Multipath Terminologies

Term	Description
FCIP	
InputRate(B/s)	The number of bytes received per second on the in port of an FCIP link.
OutputRate(B/s)	The number of bytes received per second on the out port of an FCIP link.
InputFrames(/sec)	The number of frames received per second on the in port of an FCIP link.
OutputFrames(/sec)	The number of frames received per second on the out port of an FCIP link.
vFC	
FcoeOut(Oct)	The number of egress FCoE octets on a vFC interface.
FcoeIn(Oct)	The number of ingress FCoE octets on a vFC interface.
FcoeOutPkt	The number of egress FCoE packets on a vFC interface.
FcoeInPkt	The number of ingress FCoE packets on a vFC interface.