



CHAPTER

Catalyst 4500 Series IOS Commands

A Commands

aaa accounting dot1x default start-stop group radius
aaa accounting system default start-stop group radiusclear mac-address-table
access-group mode
access-list hardware capture mode
access-list hardware entries
access-list hardware region
action
apply
ancp client server
ancp mode client
apply
arp access-list
attach module
authentication control-direction
authentication critical recovery delay
authentication event
authentication fallback
authentication host-mode
authentication open
authentication order
authentication periodic
authentication port-control
authentication priority
authentication timer
authentication violation
auto qos classify

```
auto qos classify police
auto qos srnd4
auto qos trust
auto qos video
auto qos voip
auto qos voip cisco-softphone
auto-sync
```

C Commands

```
call-home (global configuration)
call-home request
call-home send
call-home send alert-group
call-home test
channel-group
channel-protocol
cisp enable
class-map
clear counters
clear errdisable
clear hw-module slot password
clear interface gigabitethernet
clear interface vlan
clear ip access-template
clear ip arp inspection log
clear ip arp inspection statistics
clear ip dhcp snooping binding
clear ip dhcp snooping database
clear ip dhcp snooping database statistics
clear ip igmp group
clear ip mfib counters
clear ip mfib fastdrop
clear ip wccp
clear lacp counters
clear nmfp statistics
clear mac-address-table dynamic
clear pagp
```

```
clear port-security
clear pppoe intermediate-agent statistics
clear qos
clear vlan counters
clear vmps statistics
control-plane
counter
```

D Commands

```
debug adjacency
debug backup
debug condition interface
debug condition standby
debug condition vlan
debug dot1x
debug etherchnl
debug interface
debug ip dhcp snooping event
debug ip dhcp snooping packet
debug ip verify source packet
debug ipc
debug lacp
debug monitor
debug nmsp
debug nvram
debug pagp
debug platform packet protocol lacp
debug platform packet protocol pagp
debug pm
debug port-security
debug pppoe intermediate-agent
debug redundancy
debug spanning-tree
debug spanning-tree backbonefast
debug spanning-tree switch
debug spanning-tree uplinkfast
debug sw-vlan
```

```
debug sw-vlan ifs
debug sw-vlan notification
debug sw-vlan vtp
debug udld
debug vqpc
define interface-range
deny
diagnostic fpga soft-error recover
diagnostic monitor action
diagnostic start
dot1x auth-fail max-attempts
dot1x auth-fail vlan
dot1x credentials (global configuration)
dot1x critical
dot1x critical eapol
dot1x critical recovery delay
dot1x critical vlan
dot1x control-direction
dot1x guest-vlan
dot1x guest-vlan supplicant
dot1x host-mode
dot1x initialize
dot1x mac-auth-bypass
dot1x max-reauth-req
dot1x max-req
dot1x port-control
dot1x re-authenticate
dot1x re-authentication
dot1x system-auth-control
dot1x timeout
duplex
```

E Commands

```
erase
errdisable detect
errdisable recovery
```

F Commands

[flowcontrol](#)

H Commands

[hardware statistics](#)

[hw-module beacon](#)

[hw-module power](#)

[hw-module system max-queue-limit](#)

I Commands

[instance](#)

[interface](#)

[interface port-channel](#)

[interface range](#)

[interface vlan](#)

[ip admission proxy http refresh-all](#)

[ip arp inspection filter vlan](#)

[ip arp inspection limit \(interface\)](#)

[ip arp inspection log-buffer](#)

[ip arp inspection trust](#)

[ip arp inspection validate](#)

[ip arp inspection vlan](#)

[ip arp inspection vlan logging](#)

[ip cef load-sharing algorithm](#)

[ip dhcp snooping](#)

[ip dhcp snooping binding](#)

[ip dhcp snooping database](#)

[ip dhcp snooping information option](#)

[ip dhcp snooping information option allow-untrusted](#)

[ip dhcp snooping limit rate](#)

[ip dhcp snooping trust](#)

[ip dhcp snooping vlan](#)

[ip device tracking maximum](#)

[ip igmp filter](#)

[ip igmp max-groups](#)

[ip igmp profile](#)

[ip igmp query-interval](#)

```
ip igmp snooping
ip igmp snooping report-suppression
ip igmp snooping vlan
ip igmp snooping vlan explicit-tracking
ip igmp snooping vlan immediate-leave
ip igmp snooping vlan mrouter
ip igmp snooping vlan static
ip local-proxy-arp
ip mfib fastdrop
ip source binding
ip sticky-arp
ip verify header vlan all
ip verify source
ip verify unicast source reachable-viaip wccp
ip wccp check services all
ip wccp group-listen
ip wccp redirect
ip wccp redirect exclude in
ipv6 mld snooping
ipv6 mld snooping last-listener-query-count
ipv6 mld snooping last-listener-query-interval
ipv6 mld snooping listener-message-suppression
ipv6 mld snooping robustness-variable
ipv6 mld snooping tcn
ipv6 mld snooping vlan
issu abortversion
issu acceptversion
issu commitversion
redundancy config-sync mismatched-commands
issu loadversion
issu runversion
issu set rollback-timer
```

L Commands

```
l2protocol-tunnel
l2protocol-tunnel cos
l2protocol-tunnel drop-threshold
```

l2protocol-tunnel shutdown-threshold
lacp port-priority
lacp system-priority
lldp tlv-select power-management
logging event trunk-status global (global configuration)
logging event link-status global (global configuration)
logging event trunk-status global (global configuration)
logging event link-status global (global configuration)
logging event link-status (interface configuration)
logging event trunk-status (interface configuration)

M Commands

match
mac access-list extended
mac-address-table aging-time
mac-address-table dynamic group protocols
mac address-table learning vlan
mac-address-table notification
mac-address-table static
macro apply cisco-desktop
macro apply cisco-phone
macro apply cisco-router
macro apply cisco-switch
macro auto device
macro auto execute (built-in function)
macro auto execute (remotely-defined trigger)
macro auto execute (user-defined function)
macro auto global processing
macro auto mac-address-group
macro auto monitor
macro auto processing
macro auto sticky
macro global apply cisco-global
macro global apply system-cpp
macro global description
main-cpu
match

match flow ip
mdix auto
media-type
mode
monitor capture {access-list | class-map}
monitor capture [clear | export]
monitor capture [interface | vlan | control-plane]
monitor capture file location buffer-size
monitor capture limit
monitor capture mycap match
monitor capture start
monitor session
mtu

O Commands

N Commands

name

P Commands

pagp learn-method
pagp port-priority
passive-interface
permit
policy-map
port-channel load-balance
port-channel standalone-disable
port-security mac-address
port-security mac-address sticky
port-security maximum
power dc input
power efficient-ethernet auto
power inline
power inline consumption
power inline four-pair forced
power redundancy-mode

power inline police
power redundancy-mode
pppoe intermediate-agent (global)
pppoe intermediate-agent (interface)
pppoe intermediate-agent (interface vlan-range)
pppoe intermediate-agent format-type (global)
pppoe intermediate-agent limit rate
pppoe intermediate-agent trust
pppoe intermediate-agent vendor-tag strip
priority
private-vlan
private-vlan mapping
private-vlan synchronize

Q Commands

qos account layer-all encapsulation
qos account layer2 encapsulation
qos trust
queue-limit

R Commands

redundancy
redundancy force-switchover
redundancy reload
remote login module
remote-span
renew ip dhcp snooping database
reset
revision

S Commands

service-policy (interface configuration)
service-policy (policy-map class)
service-policy input (control-plane)
session module
set
set cos

set dscp
set precedence
set qos-group
shape (interface configuration)
shell trigger
show monitor capture
snmp ifindex clear
snmp ifindex persist
snmp-server enable traps
snmp-server ifindex persist
snmp-server ifindex persist compress
snmp trap mac-notification change
spanning-tree backbonefast
spanning-tree bpdufilter
spanning-tree bpduguard
spanning-tree cost
spanning-tree etherchannel guard misconfig
spanning-tree extend system-id
spanning-tree guard
spanning-tree link-type
spanning-tree loopguard default
spanning-tree mode
spanning-tree mst
spanning-tree mst configuration
spanning-tree mst forward-time
spanning-tree mst hello-time
spanning-tree mst max-age
spanning-tree mst max-hops
spanning-tree mst root
spanning-tree pathcost method
spanning-tree portfast (interface configuration mode)
spanning-tree portfast bpdufilter default
spanning-tree portfast bpduguard default
spanning-tree portfast default
spanning-tree port-priority
spanning-tree uplinkfast
spanning-tree vlan
speed

```
storm-control
  storm-control broadcast include multicast
  switchport
    switchport access vlan
    switchport autostate exclude
    switchport block
    switchport mode
    switchport port-security
    switchport private-vlan association trunk
    switchport private-vlan host-association
    switchport private-vlan mapping
    switchport private-vlan trunk allowed vlan
    switchport private-vlan trunk native vlan tag
    switchport trunk
    switchport vlan mapping
system mtu
```

Show Commands

```
show access-group mode interface
show adjacency
show ancp multicast
show arp access-list
show authentication
show auto install status
show auto qos
show bootflash:
show bootvar
show cable-diagnostics tdr
show call-home
show cdp neighbors
show class-map
show diagnostic content
show diagnostic result module
show diagnostic result module test
show diagnostic result module test 2
show diagnostic result module test 3
show dot1x
```

show environment
show errdisable detect
show errdisable recovery
show etherchannel
show flowcontrol
show idprom
show interfaces
show interfaces capabilities
show interfaces counters
show interfaces description
show interfaces link
show interfaces mtu
show interfaces private-vlan mapping
show interfaces status
show interfaces switchport
show interfaces transceiver
show interfaces trunk
show ip arp inspection
show ip arp inspection log
show ip cef vlan
show ip dhcp snooping
show ip dhcp snooping binding
show ip dhcp snooping database
show ip igmp interface
show ip igmp profile
show ip igmp snooping
show ip igmp snooping membership
show ip igmp snooping mrouter
show ip igmp snooping vlan
show ip interface
show ip mfib
show ip mfib fastdrop
show ip mroute
show ip source binding
show ip verify source
show ip wccp
show ipc
show ipv6 mld snooping

show ipv6 mld snooping mrouter
show ipv6 mld snooping querier
show ipv6 snooping counters
show issu capability
show issu clients
show issu comp-matrix
show issu endpoints
show issu entities
show issu fsm
show issu message
show issu negotiated
show issu rollback-timer
show issu sessions
show issu state
show l2protocol-tunnel
show lacp
show mab
show mac access-group interface
show mac-address-table address
show mac-address-table aging-time
show mac-address-table count
show mac-address-table dynamic
show mac-address-table interface
show mac address-table learning
show mac-address-table multicast
show mac-address-table notification
show mac-address-table protocol
show mac-address-table static
show mac-address-table vlan
show macro auto mac-address-group
show macro auto device
show macro auto interface
show macro auto monitor clients
show macro auto monitor device
show macro auto monitor type
show module
show monitor
show nmfp

```
show page
show policy-map
show policy-map control-plane
show policy-map interface
show policy-map interface vlan
show port-security
show power
show power inline police
show qos
show pppoe intermediate-agent interface
show qos
show qos aggregate policer
show qos dbl
show qos interface
show qos maps
show redundancy
show redundancy config-sync
show running-config
show slavebootflash:
show slaveslot0:
show slot0:
show spanning-tree
show spanning-tree mst
show storm-control
show system mtu
show tech-support
show udld
show vlan
show vlan access-map
show vlan counters
show vlan dot1q tag native
show vlan group
show vlan internal usage
show vlan mapping
show vlan mtu
show vlan private-vlan
show vlan remote-span
show vmps
```

show vtp

T Commands

test cable-diagnostics tdr
traceroute mac
traceroute mac ip
trust
tx-queue

U Commands

udld (global configuration mode)
udld (interface configuration mode)
udld reset
unidirectional
username

V Commands

verify
vlan (VLAN Database mode)
vlan access-map
vlan configuration
vlan database
vlan dot1q tag native
vlan filter
vlan group
vlan internal allocation policy
vmps reconfirm (global configuration)
vmps reconfirm (privileged EXEC)
vmps retry
vmps server
vtp (global configuration mode)
vtp client
vtp domain
vtp password
vtp pruning
vtp server
vtp transparent

```
vtp v2-mode
```