UWS – User Levels and Access Privileges

The users of the UWS (AutoDeploy and AutoVNF) platform can be classified into three types based on their role:

- Operator – Read and execute privileges on the UWS platform. A default username oper is created when the UWS is installed.

- USP Administrator – All privileges except to create, edit, and delete user accounts, or upload TLS certificates. A default username admin is created when the UWS is installed.

- Security Administrator – Create, edit, and delete user accounts. A security administrator can also install TLS certificates. A default username security-admin is created when the UWS is installed.

Managing User Accounts

A security administrator can create, edit, and remove user accounts for the UWS platform. Use the following task to manage user accounts for the UWS platform:

Step 1 Log in to the UWS interface as a security administrator.
The User Management screen appears with a list of all the users configured to access the UWS interface.

Step 2 To add a new user account, click **Add** and provide the username, password, and user role in the Add User screen.
To modify an existing user account, select the user, click **Edit**, and modify the user information as necessary in the Modify User screen

To remove an existing user account, select the user, click **Delete**, and confirm deletion of the user account.

Managing Certificates

A security administrator can install TLS certificates for the UWS platform using the following task:

Step 1   Log in to the UWS interface as a security administrator.
The User Management screen appears.

Step 2   Click **Certificate Management**.
The Certificate Management screen appears.

Step 3   Click **Drop File Here** in the Certificate Management screen.

Step 4   Navigate and select the TLS certificate from the local directory.
The certificate name, size and status will be listed in the Certificate Management screen on successful upload.

Step 5   Click **Submit**.