

Dynamic Layer 3 VPNs with Multipoint GRE Tunnels

Last Updated: December 15, 2011

The Dynamic Layer 3 VPNs with Multipoint GRE Tunnels feature provides a Layer 3 (L3) transport mechanism based on an enhanced multipoint generic routing encapsulation (mGRE) tunneling technology for use in IP networks. The dynamic Layer 3 tunneling transport can also be used within IP networks to transport Virtual Private Network (VPN) traffic across service provider and enterprise networks, and to provide interoperability for packet transport between IP and Multiprotocol Label Switching (MPLS) VPNs. This feature provides support for RFC 2547, which defines the outsourcing of IP backbone services for enterprise networks.

- Finding Feature Information, page 1
- Prerequisites for Dynamic L3 VPNs with mGRE Tunnels, page 2
- Restrictions for Dynamic L3 VPNs with mGRE Tunnels, page 2
- Information About Dynamic L3 VPNs with mGRE Tunnels, page 2
- How to Configure L3 VPN mGRE Tunnels, page 4
- Configuration Examples for Dynamic L3 VPNs Support Using mGRE Tunnels, page 19
- Additional References, page 21
- Feature Information for Dynamic L3 VPNs with mGRE Tunnels, page 22

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information for Dynamic L3 VPNs with mGRE Tunnels, page 22.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn. An account on Cisco.com is not required.



Prerequisites for Dynamic L3 VPNs with mGRE Tunnels

Before you configure the Dynamic Layer 3 VPNs with Multipoint GRE Tunnels feature, ensure that your MPLS VPN is configured and working properly. See the "Configuring MPLS Layer 3 VPNs" module for information about setting up MPLS VPNs.

Restrictions for Dynamic L3 VPNs with mGRE Tunnels

- The deployment of a MPLS VPN using both IP/GRE and MPLS encapsulation within a single network is not supported.
- Each provider edge (PE) router supports one tunnel configuration only.

Information About Dynamic L3 VPNs with mGRE Tunnels

You can configure mGRE tunnels to create a multipoint tunnel network that overlays an IP backbone. This overlay connects PE routers to transport VPN traffic. To deploy L3 VPN mGRE tunnels, you create a VRF instance, create the mGRE tunnel, redirect the VPN IP traffic to the tunnel, and set up the BGP VPNv4 exchange so that updates are filtered through a route map and interesting prefixes are resolved in the VRF table.

In addition, when MPLS VPNs are configured over mGRE, you can deploy L3 PE-based VPN services using a standards-based IP core. This allows you to provision the VPN services without using the overlay method. When an MPLS VPN over mGRE is configured, the system uses IPv4-based mGRE tunnels to encapsulate VPN-labeled IPv4 and IPv6 packets between PEs.

• Layer 3 mGRE Tunnels, page 2

Layer 3 mGRE Tunnels

By configuring mGRE tunnels, you create a multipoint tunnel network as an overlay to the IP backbone. This overlay interconnects the PE routers to transport VPN traffic through the backbone. This multipoint tunnel network uses Border Gateway Protocol (BGP) to distribute VPNv4 routing information between PE routers, maintaining the peer relationship between the service provider or enterprise network and customer sites. The advertised next hop in BGP VPNv4 triggers tunnel endpoint discovery. This feature provides the ability for multiple service providers to cooperate and offer a joint VPN service with traffic tunneled directly from the ingress PE router at one service provider directly to the egress PE router at a different service provider site.

In addition to providing the VPN transport capability, the mGRE tunnels create a full-mesh topology and reduce the administrative and operational overhead previously associated with a full mesh of point-to-point tunnels used to interconnect multiple customer sites. The configuration requirements are greatly reduced and enable the network to grow with minimal additional configuration.

Dynamic L3 tunnels provide for better scaling when creating partial-mesh or full-mesh VPNs. Adding new remote VPN peers is simplified because only the new router needs to be configured. The new address is learned dynamically and propagated to the nodes in the network. The dynamic routing capability dramatically reduces the size of configuration needed on all routers in the VPN, such that with the use of multipoint tunnels, only one tunnel interface needs to be configured on a PE that services many VPNs. The L3 mGRE tunnels need to be configured only on the PE router. Features available with GRE are still

available with mGRE, including dynamic IP routing and IP multicast and Cisco Express Forwarding (CEF) switching of mGRE/Next Hop Routing Protocol (NHRP) tunnel traffic.


The following sections describe how the mGRE tunnels are used:

- Interconnecting Provider Edge Routers Within an IP Network, page 3
- Packet Transport Between IP and MPLS Networks, page 3
- BGP Next Hop Verification, page 4

Interconnecting Provider Edge Routers Within an IP Network

The Dynamic Layer 3 VPNs with Multipoint GRE Tunnels feature allows you to create a multiaccess tunnel network to interconnect the PE routers that service your IP network. This tunnel network transports IP VPN traffic to all of the PE routers. The figure below illustrates the tunnel overlay network used in an IP network to transport VPN traffic between the PE routers.

Figure 1 mGRE Tunnel Overlay Connecting PE Routers Within an IP Network




The multiaccess tunnel overlay network provides full connectivity between PE routers. The PE routers exchange VPN routes by using BGP as defined in RFC 2547. IP traffic is redirected through the multipoint tunnel overlay network using distinct IP address spaces for the overlay and transport networks and by changing the address space instead of changing the numerical value of the address.

Packet Transport Between IP and MPLS Networks

Layer 3 mGRE tunnels can be used as a packet transport mechanism between IP and MPLS networks. To enable the packet transport between the two different protocols, one PE router on one side of the

connection between the two networks must run MPLS. The figure below shows how mGRE tunnels can be used to transport VPN traffic between PE routers.

Figure 2 mGRE Used to Transport VPN Traffic Between IP and MPLS Network



For the packet transport to occur between the IP and MPLS network, the MPLS VPN label is mapped to the GRE key. The mapping takes place on the router where both mGRE and MPLS are configured. In the figure above the mapping of the label to the key occurs on Router M, which sits on the MPLS network.

BGP Next Hop Verification

BGP performs the BGP path selection, or next hop verification, at the PE. For a BGP path to a network to be considered in the path selection process, the next hop for the path must be reachable in the Interior Gateway Protocol (IGP). When an IP prefix is received and advertised as the next hop IP address, the IP traffic is tunneled from the source to the destination by switching the address space of the next hop.

How to Configure L3 VPN mGRE Tunnels

- Creating the VRF and mGRE Tunnel, page 5
- Setting Up BGP VPN Exchange, page 7
- Enabling the MPLS VPN over mGRE Tunnels and Configuring an L3VPN Encapsulation Profile, page 9
- Defining the Address Space and Specifying Address Resolution for MPLS VPNs over mGRE, page
 12

Creating the VRF and mGRE Tunnel

The tunnel that transports the VPN traffic across the service provider network resides in its own address space. A special VRF instance must be created called Resolve in VRF (RiV). This section describes how to create the VRF and GRE tunnel.

The IP address on the interface should be the same as that of the source interface specified in the configuration. The source interface specified should match that used by BGP as a source for the VPNv4 update.



Tunnel mode IPSec is not supported on MPLS over GRE Tunnel.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. ip vrf vrf-name
- 4. rd 1:1
- **5. interface tunnel** *tunnel-name*
- 6. ip address ip-address subnet-id
- 7. tunnel source loopback n
- 8. tunnel mode gre multipoint 13vpn
- 9. tunnel key gre-ke y
- 10. end

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	ip vrf vrf-name	Creates the special Resolve in VRF (RiV) VRF instance and table that will be used for the tunnel and redirection of the IP address.
	Example:	
	Router(config)# ip vrf customer a riv	

Command or Action	Purpose
rd 1:1	Enters the VRF configuration mode and specifies a route distinguisher (RD) for a VPN VRF instance.
Example:	
Router(config-vrf)# rd 1:1	
interface tunnel tunnel-name	Enters interface configuration mode to create the tunnel.
Example:	
Router(config-vrf)# interface tunnel 1	
ip address ip-address subnet-id	Specifies the IP address for the tunnel.
Example:	
Router(config-if)# ipaddress 209.165.200.225 255.255.254	
tunnel source loopback n	Creates the loopback interface.
Example:	
Router(config-if)# tunnel source loopback test1	
tunnel mode gre multipoint l3vpn	Sets the mode for the tunnel as "gre multipoint 13vpn".
Framula	
tunnel key gre-ke y	Specifies the GRE key for the tunnel.
Example:	
Router(config-if)# tunnel key 18	
end	Exits the current configuration mode and returns to privileged EXEC mode.
Example:	
Router(config-if)# end	
	Example: Router(config-vrf)# rd 1:1 interface tunnel tunnel-name Example: Router(config-vrf)# interface tunnel 1 ip address ip-address subnet-id Example: Router(config-if)# ipaddress 209.165.200.225 255.255.255.224 tunnel source loopback n Example: Router(config-if)# tunnel source loopback test1 tunnel mode gre multipoint l3vpn Example: Router(config-if)# tunnel mode gre multipoint 13vpn tunnel key gre-ke y Example: Router(config-if)# tunnel key 18 end Example:

Setting Up BGP VPN Exchange

The configuration task described in this section sets up the BGP VPNv4 exchange so that the updates are filtered through a route map and interesting prefixes are resolved in the VRF table.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. interface tunnel** *tunnel-name*
- **4. ip route vrf** riv-vrf-name ip-address subnet-mask **tunnel** n
- **5. router bgp** *as-number*
- 6. network network-id
- 7. **neighbor** {ip-address | peer-group-name} **remote-as** as-number
- **8. neighbor** {*ip-address* | *peer-group-name*} **update-source** *interface-type*
- 9. address-family vpnv4 [unicast]
- **10. neighbor** { *ip-address* | *peer-group-name* } **activate**
- **11. neighbor** {*ip-address* | *peer-group-name*} **route-map** *map-name* {**in** | **out**}
- **12.** set ip next-hop resolve-in-vrf vrf-name
- 13. end

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	interface tunnel tunnel-name	Enters interface configuration mode for the tunnel.
	Example:	
	Router(config)# interface tunnel 1	

Command or Action	Purpose
p route vrf riv-vrf-name ip-address subnet- mask tunnel n	Sets the packet forwarding to the special RiV VRF.
Example:	
Router(config-if)# ip route vrf $vrfI$ 209.165.200.226 255.255.255.224 tunnel 1	
router bgp as-number	Specifies the number of an autonomous system that identifies the router to other BGP routers and tags the
Example:	routing information passed along.
Router(config)# router bgp 100	
network network-id	Specifies the network ID for the networks to be advertised by the BGP and multiprotocol BGP routing processes.
Example:	
Router(config)# network 209.165.200.255	
neighbor {ip-address peer-group-name} remote-as as- number	Adds an entry to the BGP or multiprotocol BGP neighbor table.
Example:	
Router(config)# neighbor 209.165.200.227 remote-as	
neighbor {ip-address peer-group-name} update-source nterface-type	Specifies a specific operational interface that BGP sessions use for TCP connections.
Example:	
Router(config)# neighbor 209.165.200.228 update- source FastEthernet0/1	
nddress-family vpnv4 [unicast]	Specifies address family configuration mode for configuring routing sessions, such as BGP, that use standard VPN4 address prefixes.
Example:	standard VIIV+ address prefixes.
Router(config)# address-family vpnv4	
neighbor {ip-address peer-group-name} activate	Enables the exchange of information with a neighboring router.
Example:	
Router(config)# neighbor 209.165.200.229 activate	
	contervity of the property of

	Command or Action	Purpose
Step 11	neighbor {ip-address peer-group-name} route-map map- name {in out}	Applies a route map to incoming or outgoing routes. • Use once for each inbound route.
	Example:	
	Router(config)# neighbor 209.165.200.230 route-map mpt in	
Step 12	set ip next-hop resolve-in-vrf vrf-name	Specifies that the next hop is to be resolved in the VRF table for the specified VRF.
	Example:	
	Router(config)# set ip next-hop resolve-in-vrf vrft	
Step 13	end	Exits the current configuration mode and returns to privileged EXEC mode.
	Example:	
	Router(config)# end	

Enabling the MPLS VPN over mGRE Tunnels and Configuring an L3VPN Encapsulation Profile

This section describes how to define the VRF, enable MPLS VPN over mGRE, and configure an L3VPN encapsulation profile.



Transport protocols such as IPv6, MPLS, IP, and Layer 2 Tunneling Protocol version 3 (L2TPv3) can also be used in this configuration.

To enable and configure MPLS VPN over mGRE, you must first define the VRF for tunnel encapsulation and enable L3VPN encapsulation in the system.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. vrf definition** *vrf-name*
- 4. rd 1:1
- 5. exit
- 6. ip cef
- 7. ipv6 unicast-routing
- 8. ipv6 cef
- **9. 13vpn encapsulation ip** *profile-name*
- 10. transport ipv4 source interface n
- **11. protocol gre** [**key** *gre-key*]
- **12**. exit
- **13**. **interface** *type number*
- **14.ip address** *ip-address mask*
- 15. ip router isis
- 16. end

	Command or Action	Purpose
	Continuation Action	r ui pose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	vrf definition vrf-name	Configures a VPN VRF routing table instance and enters VRF configuration mode.
	Example:	
	Router(config)# vrf definition tunnel encap	

	Command or Action	Purpose
Step 4	rd 1:1	Specifies an RD for a VPN VRF instance.
	Example:	
	Router(config-vrf)# rd 1:1	
Step 5	exit	Exits VRF configuration mode.
	Example:	
	Router(config-vrf)# exit	
Step 6	ip cef	Enables Cisco Express Forwarding on the router.
	Example:	
	Router(config)# ip cef	
Step 7	ipv6 unicast-routing	Enables the forwarding of IPv6 unicast datagrams.
	Example:	
	Router(config)# ipv6 unicast-routing	
Step 8	ipv6 cef	Enables Cisco Express Forwarding for IPv6 on the router.
	Formula	
	Example:	
	Router(config)# ipv6 cef	
Step 9	13vpn encapsulation ip profile-name	Enters L3 VPN encapsulation configuration mode to create the tunnel.
	Example:	
	Router(config)# 13vpn encapsulation ip tunnel encap	
Step 10	transport ipv4 source interface n	Specifies IPv4 transport source mode and defines the
•	The state of the s	transport source interface.
	Example:	
	Router(config-13vpn-encap-ip)# transport ipv4 source loopback 0	

	Command or Action	Purpose
Step 11	protocol gre [key gre-key]	Specifies GRE as the tunnel mode and sets the GRE key.
	Example:	
	Router(config-13vpn-encap-ip)# protocol gre key 1234	
Step 12	exit	Exits L3 VPN encapsulation configuration mode.
	Example:	
	Router(config-13vpn-encap-ip)# exit	
Step 13	interface type number	Enters interface configuration mode to configure the interface type.
	Example:	
	Router(config)# interface loopback 0	
Step 14	ip address ip-address mask	Specifies the primary IP address and mask for the interface.
	Example:	
	Router(config-if)# ip address 10.10.10.4 255.255.255	
Step 15	ip router isis	Configures an Intermediate System-to-Intermediate System (IS-IS) routing process for IP on the interface and attaches a null area designator to the routing
	Example:	process.
	Router(config-if)# ip router isis	
Step 16	end	Exits the current configuration mode and returns to privileged EXEC mode.
	Example:	
	Router(config-if)#end	

Defining the Address Space and Specifying Address Resolution for MPLS VPNs over mGRE

This section describes how to define the address space and specify the address resolution for MPLS VPNs over mGRE. The following steps also enable you to link the route map to the application template and set up the BGP VPNv4 and VPNv6 exchange so that updates are filtered through the route map.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. router bgp** *as-number*
- 4. bgp log-neighbor-changes
- **5. neighbor** *ip-address* **remote-as** *as-number*
- **6. neighbor** *ip-address* **update-source** *interface-type interface-name*
- 7. address-family vpn4
- 8. no synchronization
- 9. redistribute connected
- 10. neighbor ip-address activate
- 11. no auto-summary
- **12**. exit
- 13. address-family vpnv4
- 14. neighbor ip-address activate
- **15.** neighbor *ip-address* send-community both
- **16. neighbor** *ip-address* **route-map** *map-name* **in**
- 17. exit
- 18. address-family vpnv6
- 19. neighbor ip-address activate
- 20. neighbor ip-address send-community both
- 21. neighbor ip-address route-map ip-address in
- **22**. exit
- 23. route-map map-tag permit position
- 24. set ip next-hop encapsulate l3vpn tunnel encap
- **25. set ipv6 next-hop encapsulate l3vpn** *profile name*
- 26. end
- 27. end

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	

	Command or Action	Purpose
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	router bgp as-number	Specifies the number of an autonomous system that identifies the router to other BGP routers, tags the routing information passed along, and enters router configuration mode.
	Example:	F8,
	Router (config)# router bgp 100	
Step 4	bgp log-neighbor-changes	Enables logging of BGP neighbor resets.
	Example:	
	Router (config-router)# bgp log-neighbor-changes	
Step 5	neighbor ip-address remote-as as-number	Adds an entry to the BGP or multiprotocol BGP neighbor table.
	Example:	
	Router (config-router)# neighbor 10.10.10.6 remote-as 100	
Step 6	neighbor ip-address update-source interface-type interface-name	Allows BGP sessions to use any operational interface for TCP connections.
	Example:	
	Router (config-router)# neighbor 10.10.10.6 update-source loopback 0	
Step 7	address-family vpn4	Enters address family configuration mode to configure routing sessions, that use IPv4 address prefixes.
	Example:	
	Router (config-router)# address-family vpnv4	
Step 8	no synchronization	Enables the Cisco IOS software to advertise a network route without waiting for an IGP.
	Example:	
	Router (config-router-af)# no synchronization	

	Command or Action	Purpose
Step 9	redistribute connected	Redistributes routes from one routing domain into another routing domain and allows the target protocol to redistribute routes learned by the source protocol and connected prefixes
	Example:	on those interfaces over which the source protocol is running.
	Router (config-router-af)# redistribute connected	
Step 10	neighbor ip-address activate	Enables the exchange of information with a BGP neighbor.
	Example:	
	Router (config-router-af)# neighbor 10.10.10.6 activate	
Step 11	no auto-summary	Disables automatic summarization and sends subprefix routing information across classful network boundaries
	Example:	
	Router (config-router-af)# no auto-summary	
Step 12	exit	Exits address family configuration mode.
	Example:	
	Router (config-router-af)# exit	
Step 13	address-family vpnv4	Enters address family configuration mode to configure routing sessions, such as BGP, that use standard VPNv4 address prefixes.
	Example:	prenaes.
	Router (config-router)# address-family vpnv4	
Step 14	neighbor ip-address activate	Enables the exchange of information with a BGP neighbor.
	Example:	
	Router (config-router-af)# neighbor 10.10.10.6 activate	
Step 15	neighbor ip-address send-community both	Specifies that a community attribute, for both standard and extended communities, should be sent to a BGP neighbor.
	Example:	
	Router (config-router-af)# neighbor 10.10.10.6 send-community both	

	Command or Action	Purpose
Step 16	neighbor ip-address route-map map-name in	Applies the named route map to the incoming route.
	Example:	
	Router (config-router-af)# neighbor 10.10.10.6 route-map SELECT UPDATE FOR L3VPN in	
Step 17	exit	Exits address family configuration mode.
	Example:	
	Router (config-router-af)# exit	
Step 18	address-family vpnv6	Enters address family configuration mode to configure routing sessions, such as BGP, that use VPNv6 address prefixes.
	Example:	
	6Router (config-router)# address-family vpnv4	
Step 19	neighbor ip-address activate	Enables the exchange of information with a BGP neighbor.
	Example:	
	Router (config-router-af)# neighbor 209.165.200.252 activate	
Step 20	neighbor ip-address send-community both	Specifies that a communities attribute, for both standard and extended communities, should be sent to a BGP neighbor.
	Example:	
	Router (config-router-af)# neighbor 209.165.200.252 send-community both	
Step 21	neighbor ip-address route-map ip-address in	Applies the named route map to the incoming route.
	Firemole	
	Example:	
	Router (config-router-af)# neighbor 209.165.200.252 route-map SELECT UPDATE FOR L3VPN in	
Step 22	exit	Exits address family configuration mode.
	Example:	
	Router (config-router-af)# exit	

(Command or Action	Purpose
Step 23	route-map map-tag permit position Example: Router (config-router)# route-map 192.168.10.1 permit 10	 Enters route-map configuration mode and defines the conditions for redistributing routes from one routing protocol into another. The redistribute router configuration command uses the specified map tag to reference this route map. Multiple route maps may share the same map tag name. If the match criteria are met for this route map, the route is redistributed as controlled by the set actions. If the match criteria are not met, the next route map with the same map tag is tested. If a route passes none of the match criteria for the set of route maps sharing the same name, it is not redistributed by that set. The position argument indicates the position that new route map will have in the list of route maps already configured with the same name.
Step 24 s	set ip next-hop encapsulate l3vpn tunnel encap	Indicates that output IPv4 packets that pass a match clause of the route map are sent to the VRF for tunnel encapsulation.
I	Example:	
F e	Router (config-route-map)# set ip next-hop encapsulate l3vpn my profile	
Step 25 s	set ipv6 next-hop encapsulate l3vpn profile name	Indicates that output IPv6 packets that pass a match clause of the route map are sent to the VRF for tunnel encapsulation.
I	Example:	
	Router (config-route-map)# set ip next-hop encapsulate l3vpn tunnel encap	
ı	Example:	
Step 26	end	Exits route-map configuration mode and enters global configuration mode.
I	Example:	
I	Router (config-route-map)# exit	
Step 27	end	Exits global configuration mode.
i	Example:	
-	Router (config)# exit	

• What to Do Next, page 18

What to Do Next

You can perform the following to make sure that the configuration is working properly.

Check the VRF Prefix

Verify that the specified VRF prefix has been received by BGP. The BGP table entry should show that the route map has worked and that the next hop is showing in the RiV. Use the **show ip bgp vpnv4** command as shown in this example.

```
Router# show ip bgp vpnv4 vrf customer 209.165.200.250

BGP routing table entry for 100:1:209.165.200.250/24, version 12

Paths: (1 available, best #1)

Not advertised to any peer

Local

209.165.200.251 in "my riv" from 209.165.200.251 (209.165.200.251)

Origin incomplete, metric 0, localpref 100, valid, internal, best Extended Community: RT:100:1
```

Confirm that the same information has been propagated to the routing table:

```
Routing entry for 209.165.200.250

Routing entry for 209.165.200.250

/24

Known via "bgp 100", distance 200, metric 0, type internal Last update from 209.165.200.251 00:23:07 ago
Routing Descriptor Blocks:

* 209.165.200.251 (my riv), from 209.165.200.251, 00:23:07 ago
Route metric is 0, traffic share count is 1

AS Hops 0
```

CEF Switching

You can also verify that CEF switching is working as expected:

```
Router# show ip cef vrf customer 209.165.200.250

209.165.200.250

/24, version 6, epoch 0
0 packets, 0 bytes
tag information set
local tag: VPN-route-head
fast tag rewrite with Tu1, 123.1.1.2, tags imposed: {17}
via 209.165.200.251, 0 dependencies, recursive
next hop 209.165.200.251, Tunnell via 209.165.200.251/32 (my riv)
valid adjacency
tag rewrite with Tu1, 209.165.200.251, tags imposed: {17}
```

Endpoint Creation

Note that in this example display the tunnel endpoint has been created correctly:

```
Router# show tunnel endpoint tunnel 1
Tunnel1 running in multi-GRE/IP mode
  RFC2547/L3VPN Tunnel endpoint discovery is active on Tul
  Transporting l3vpn traffic to all routes recursing through "my riv"
  Endpoint 209.165.200.251 via destination 209.165.200.251
  Endpoint 209.165.200.254 via destination 209.165.200.254
```

Adjacency

Confirm that the corresponding adjacency has been created.

Note that because MPLS is being transported over mGRE, the LINK_TAG adjacency is the relevant adjacency. The MTU reported in the adjacency is the payload length (including the MPLS label) that the packet will accept. The MAC string shown in the adjacency display can be interpreted as follows:

```
45000000 -> Beginning of IP Header (Partially populated, tl & chksum 00000000 are fixed up per packet)
FF2FC3C7
7B010103 -> Source IP Address in transport network 209.165.200.253
7B010102 -> Destination IP address in transport network 209.165.200.252
```

Refer to the Cisco IOS Multiprotocol Label Switching Configuration Guide for information about configuring MPLS Layer 3 VPNs.

You can use the **show l3vpn encapsulation** *profile-name* command to get information on the basic state of the application. The output of this command provides you details on the references to the tunnel and VRF.

Configuration Examples for Dynamic L3 VPNs Support Using mGRE Tunnels

Configuring Layer 3 VPN mGRE Tunnels Example, page 19

Configuring Layer 3 VPN mGRE Tunnels Example

This example shows the configuration sequence for creating mGRE tunnels. It includes the definition of the special VRF instance.

```
ip vrf my riv
  rd 1:1
interface Tunnel1
  ip vrf forwarding my_riv
  ip address 209.165.200.250 255.255.255.224
  tunnel source Loopback0
  tunnel mode gre multipoint 13vpn
  tunnel key 123
end
  ip route vrf my riv ip address subnet mask Tunnel1
router bgp 100
  network 209.165.200.251
  neighbor 209.165.200.250 remote-as 100
```

address-family vpnv4

exit-address-family
!
address-family vpnv6

neighbor 209.165.200.254 activate

neighbor 209.165.200.254 send-community both

neighbor 209.165.200.254 route-map SELECT UPDATE FOR L3VPN in

```
neighbor 209.165.200.250 update-source Loopback0
address-family vpnv4
neighbor 209.165.200.250 activate
neighbor 209.165.200.250 route-map SELECT_UPDATES_FOR_L3VPN_OVER_MGRE in
route-map SELECT UPDATES FOR L3VPN OVER MGRE permit 10
set ip next-hop in-vrf my riv
This example shows the configuration to link a route map to the application:
vrf definition Customer A
rd 100:110
 route-target export 100:1000
 route-target import 100:1000
address-family ipv4
 exit-address-family
 address-family ipv6
 exit-address-family
vrf definition tunnel encap
rd 1:1
address-family ipv4
 exit-address-family
 address-family ipv6
 exit-address-family
ip cef
ipv6 unicast-routing
ipv6 cef
13vpn encapsulation ip profile name
 transport source loopback 0
protocol gre key 1234
 interface Loopback0
  ip address 209.165.200.252 255.255.255.224
  ip router isis
interface Serial2/0
vrf forwarding Customer A
 ip address 209.165.200.253 255.255.255.224
 ipv6 address 3FFE:1001::/64 eui-64
no fair-queue
serial restart-delay 0
router bgp 100
bgp log-neighbor-changes
 neighbor 209.165.200.254 remote-as 100
 neighbor 209.165.200.254 update-source Loopback0
 address-family ipv4
 no synchronization
  redistribute connected
  neighbor 209.165.200.254 activate
 no auto-summary
 exit-address-family
```

```
neighbor 209.165.200.254 activate
neighbor 209.165.200.254 send-community both
neighbor 209.165.200.254 route-map SELECT UPDATE FOR L3VPN in
exit-address-family
!
address-family ipv4 vrf Customer A
no synchronization
redistribute connected
exit-address-family
!
address-family ipv6 vrf Customer A
redistribute connected
no synchronization
exit-address-family
!
route-map SELECT UPDATE FOR L3VPN permit 10
set ip next-hop encapulate <profile_name>
set ipv6 next-hop encapsulate <profile_name>
```

Additional References

For additional information related to dynamic L3 VPN mGRE tunnels, refer to the following references:

Related Documents

Document Title	
Cisco IOS Multiprotocol Label Switching Configuration Guide	
Cisco IOS Interface and Hardware Component Configuration Guide	
Cisco IOS IP Switching Configuration Guide	
Cisco IOS Interface and Hardware Component Configuration Guide	

Standards

Standard	Title
None	

MIBs

MIB	MIBs Link
IETF-PPVPN-MPLS-VPN-MIB	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:
	http://www.cisco.com/go/mibs

RFCs

RFC	Title
RFC 2547	BGP/MPLS VPNs
RFC 2784	Generic Routing Encapsulation (GRE)
RFC 2890	Key Sequence Number Extensions to GRE
RFC 4023	Encapsulating MPLS in IP or Generic Routing Encapsulation
RFC 4364	BGP/MPLS IP Virtual Private Networks (VPNs)

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for Dynamic L3 VPNs with mGRE Tunnels

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1 Feature Information for Dynamic L3 VPNs with mGRE Tunnels

Feature Name	Releases	Feature Information
Dynamic Layer 3 VPNs with Multipoint GRE Tunnels	12.0(23)S	This feature provides an L3 transport mechanism based on an enhanced mGRE tunneling technology for use in IP networks.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.