



Cisco Firepower 1000/2100 FXOS Faults and Error Messages, Firepower Threat Defense 6.6 and ASA 9.14(1)

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)

Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco Firepower 1000/2100 FXOS Faults and Error Messages, Firepower Threat Defense 6.6 and ASA 9.14(1)
© 2020 Cisco Systems, Inc. All rights reserved.



Preface

This preface includes the following sections:

- [Audience, page iii](#)
- [Organization, page iii](#)
- [Related Documentation, page iii](#)

Audience

This troubleshooting guide is designed for users who are responsible for troubleshooting issues that arise in the Cisco Firepower eXtensible Operating System.

Organization

This reference guide is organized into the following chapters:

- Cisco Firepower eXtensible Operating System Faults
 - [Chapter 1, “Introduction to FXOS Faults”](#)
 - [Chapter 2, “FXOS Faults”](#)
 - [Chapter 3, “FSM Faults”](#)
 - [Chapter 4, “Troubleshooting Transient Faults”](#)

Related Documentation

A roadmap that lists all documentation for the Cisco Firepower eXtensible Operating System for Firepower 1000 and Firepower 2100 series devices is available at the following URLs, depending on your deployment:

[Navigating the Cisco Firepower System Documentation](#)

[Navigating the Cisco ASA Series Documentation](#)

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



Preface	iii
Audience	iii
Organization	iii
Related Documentation	iii
Introduction to FXOS Faults	1-1
Overview of Faults	1-1
About Faults in FXOS	1-1
Fault Severities	1-2
Fault Types	1-2
Properties of Faults	1-3
Lifecycle of Faults	1-4
Fault Collection Policy	1-4
Faults in FXOS	1-4
Overview of the Finite State Machine	1-5
About the Finite State Machine in FXOS	1-5
FSM Stage Names	1-6
FSM in FXOS	1-6
FXOS Faults	2-1
FSM Faults	3-1
Troubleshooting Transient Faults	4-1
Initial Setup and Discovery Faults	4-1
Virtual Machine Startup Faults	4-5



Introduction to FXOS Faults

This chapter provides an overview of FXOS faults. This chapter contains the following sections:

- [Overview of Faults, page 1-1](#)
- [Overview of the Finite State Machine, page 1-5](#)

Overview of Faults

This section includes the following topics:

- [About Faults in FXOS, page 1-1](#)
- [Fault Severities, page 1-2](#)
- [Fault Types, page 1-2](#)
- [Properties of Faults, page 1-3](#)
- [Lifecycle of Faults, page 1-4](#)
- [Fault Collection Policy, page 1-4](#)
- [Faults in FXOS, page 1-4](#)

About Faults in FXOS

A fault is a mutable object that is managed by the FXOS. Each fault represents a failure or an alarm threshold that has been raised. During the lifecycle of a fault, it can change from one state or severity to another.

Each fault includes information about the operational state of the affected object at the time the fault was raised. If the fault is transitional and the failure is resolved, then the object transitions to a functional state.

A fault remains in FXOS until the fault is cleared and deleted according to the settings in the fault collection policy.

You can view faults at the FXOS CLI and in Firepower Chassis Manager (ASA Platform Mode only). Also, all FXOS faults are passed to the application, either FTD or ASA, where they are converted into syslog messages. The application syslog configuration determines how you can view the FXOS faults/syslogs. All FXOS faults can also be trapped by SNMP.

Fault Severities

A fault can transition through more than one severity during its lifecycle. [Table 1-1](#) describes the possible fault severities in alphabetical order.

Table 1-1 *Fault Severities in FXOS*

Severity	Description
Cleared	A notification that the condition that caused the fault has been resolved, and the fault has been cleared.
Condition	An informational message about a condition, possibly independently insignificant.
Critical	A service-affecting condition that requires immediate corrective action. For example, this severity could indicate that the managed object is out of service and its capability must be restored.
Info	A basic notification or informational message, possibly independently insignificant.
Major	A service-affecting condition that requires urgent corrective action. For example, this severity could indicate a severe degradation in the capability of the managed object and that its full capability must be restored.
Minor	A non-service-affecting fault condition that requires corrective action to prevent a more serious fault from occurring. For example, this severity could indicate that the detected alarm condition is not currently degrading the capacity of the managed object.
Warning	A potential or impending service-affecting fault that currently has no significant effects in the system. Action should be taken to further diagnose, if necessary, and correct the problem to prevent it from becoming a more serious service-affecting fault.

Fault Types

A fault can be one of the types described in [Table 1-2](#).

Table 1-2 *Types of Faults in FXOS*

Type	Description
fsm	An FSM task has failed to complete successfully, or the FXOS is retrying one of the stages of the FSM.
equipment	FXOS has detected that a physical component is inoperable or has another functional issue.
server	FXOS is unable to complete a server task, such as associating a service profile with a server.
configuration	FXOS is unable to successfully configure a component.
environment	FXOS has detected a power problem, thermal problem, voltage problem, or a loss of CMOS settings.

Table 1-2 *Types of Faults in FXOS*

Type	Description
management	FXOS has detected a serious management issue, such as one of the following: <ul style="list-style-type: none"> • Critical services could not be started. • The primary switch could not be identified. • Components in the instance include incompatible firmware versions.
connectivity	FXOS has detected a connectivity problem, such as an unreachable adapter.
network	FXOS has detected a network issue, such as a link down.
operational	FXOS has detected an operational problem, such as a log capacity issue or a failed server discovery.

Properties of Faults

FXOS provides detailed information about each fault raised on the security appliance. [Table 1-3](#) describes the fault properties that can be viewed in the FXOS CLI or the Firepower Chassis Manager.

Table 1-3 *Fault Properties*

Property Name	Description
Severity	The current severity level of the fault. This can be any of the severities described in Table 1-1 on page 1-2 .
Last Transition	The day and time on which the severity for the fault last changed. If the severity has not changed since the fault was raised, this property displays the original creation date.
Affected Object	The component that is affected by the condition that raised the fault.
Description	The description of the fault.
ID	The unique identifier assigned to the fault.
Status	Additional information about the fault state. This can be any of the states described in Table 1-4 on page 1-4 .
Type	The type of fault that has been raised. This can be any of the types described in Table 1-2 on page 1-2 .
Cause	The unique identifier associated with the condition that caused the fault.
Created at	The day and time when the fault occurred.
Code	The unique identifier assigned to the fault.
Number of Occurrences	The number of times the event that raised the fault occurred.
Original Severity	The severity assigned to the fault on the first time that it occurred.
Previous Severity	If the severity has changed, this is the previous severity.
Highest Severity	The highest severity encountered for this issue.

Lifecycle of Faults

FXOS faults are stateful, and a fault transitions through more than one state during its lifecycle. In addition, only one instance of a given fault can exist on each object. If the same fault occurs a second time, FXOS increases the number of occurrences by one.

A fault has the following lifecycle:

1. A condition occurs in the system and FXOS raises a fault in the active state.
2. If the fault is alleviated within a short period of time known as the flap interval, the fault severity remains at its original active value but the fault enters the soaking state. The soaking state indicates that the condition that raised the fault has cleared, but the system is waiting to see whether the fault condition reoccurs.
3. If the condition reoccurs during the flap interval, the fault enters the flapping state. Flapping occurs when a fault is raised and cleared several times in rapid succession. If the condition does not reoccur during the flap interval, the fault is cleared.
4. Once cleared, the fault enters the retention interval. This interval ensures that the fault reaches the attention of an administrator even if the condition that caused the fault has been alleviated, and that the fault is not deleted prematurely. The retention interval retains the cleared fault for the length of time specified in the fault collection policy.
5. If the condition reoccurs during the retention interval, the fault returns to the active state. If the condition does not reoccur, the fault is deleted.

When a fault is active, the additional lifecycle state information listed in [Table 1-4](#) may be provided in the Status field of the fault notification.

Table 1-4 *Fault Lifecycle States*

State	Description
Soaking	A fault was raised and then cleared within a short time known as the flap interval. Since this may be a flapping condition, the fault severity remains at its original active value, but this state indicates that the condition that raised the fault has cleared. If the fault does not reoccur, the fault moves into the cleared state. Otherwise, the fault moves into the flapping state.
Flapping	A fault was raised, cleared, and then raised again within a short time known as the flap interval.

Fault Collection Policy

The fault collection policy controls the lifecycle of a fault, including the length of time that each fault remains in the flapping and retention intervals.

Faults in FXOS

This section includes the following topics:

- [Faults in Firepower Chassis Manager \(ASA Platform Mode Only\)](#), page 1-5
- [Faults in FXOS CLI](#), page 1-5

Faults in Firepower Chassis Manager (ASA Platform Mode Only)

To view the faults for all objects in the system, navigate to the Overview page in the Firepower Chassis Manager. Each fault severity is represented by a different icon. Above the fault listing you can see how many critical and major faults have occurred in the system. When you double-click a specific fault, Firepower Chassis Manager opens the Faults Properties dialog box and displays details for that fault.

Faults in FXOS CLI

If you want to view the faults for all objects in the system, at the top-level scope, enter the **show fault** command. If you want to view faults for a specific object, scope to that object and then enter the **show fault** command.

If you want to view all of the available details about a fault, enter the **show fault detail** command.

Overview of the Finite State Machine

This section includes the following topics:

- [About the Finite State Machine in FXOS, page 1-5](#)
- [FSM Stage Names, page 1-6](#)
- [FSM in FXOS, page 1-6](#)

About the Finite State Machine in FXOS

A finite state machine (FSM) is a workflow model, similar to a flow chart, that is composed of the following:

- Finite number of stages (states)
- Transitions between those stages
- Operations

The current stage in the FSM is determined by past stages and the operations performed to transition between the stages. A transition from one stage to another stage is dependent on the success or failure of an operation.

FXOS uses FSM tasks that run in the Data Management Engine (DME) to manage end points in the Firepower object model, including the following:

- Physical components (chassis, I/O module, servers)
- Logical components (LAN cloud, policies)
- Workflows (server discovery, service profile management, downloads, upgrades, backups)

The DME manages the FSM stages and transition, and instructs the Application Gateway (AG) to perform operations on the managed end points. Therefore, each stage can be considered to be an interaction between the DME, the AG, and the managed end point. The AGs do the real work of interacting with managed end points.

When all of the FSM stages have run successfully, the FXOS considers that the FSM operation is successful.

If the FSM encounters an error or a timeout at a stage, the FSM retries that stage at scheduled intervals. When the retry count has been reached for that stage, the FSM stops and the FXOS declares that the change has failed. If an FSM task fails, the FXOS raises the appropriate faults and alarms.

Multiple FSM tasks can be associated to an end point. However, only one FSM task at a time can run. Additional FSM tasks for the same end point are placed in a queue and are scheduled to be run when the previous FSM task is either successfully completed or the task fails.

You can view the FSM details for a particular end point to determine if a task succeeded or failed. You can also use the FSM to troubleshoot any failures.

FSM Stage Names

The FSM stage names are constructed using the following notation

FsmObjectWorkflowOperationWhere-is-it-executed

where:

- *Object* is the object that the FSM is running, such as the Blade or Chassis.
- *Workflow* is the overall task being performed by the FSM, such as Discover or Association.
- *Operation* is the task being performed at a particular stage, such as Pnuos-Config.
- *Where-is-it-executed* is generally "", or "A" or "B" or "Local" or "Peer". If this is not specified, it is executed on the managingInst node.

Each FSM stage name has a prefix that identifies the FSM and a suffix that identifies a stage within the FSM. The prefix notation is **FsmObjectWorkflow** and the suffix notation is **OperationWhere-is-it-executed**. For example, if the FSM name is

FsmComputeBladeDiscoverBmcInventory:

- The prefix is **FsmComputeBladeDiscover**
- The suffix is **BmcInventory**

FSM in FXOS

The FXOS CLI can display the FSM information for an end point when you are in the command mode for that end point.

Enter the **show fsm status** command in the appropriate mode to view the current FSM task for an end point. The information displayed about a current FSM task in the CLI is static. You must re-enter the command to see the progress updates. The following example displays the information about the current FSM task for the server in chassis 1, slot 6:

```
Firepower# scope server 1/1
Firepower /chassis/server # show fsm status
Slot: 1
Server: sys/chassis-1/blade-1
  FSM 1:
    Remote Result: Not Applicable
    Remote Error Code: None
    Remote Error Description:
    Status: Discover Blade Boot Wait
    Previous Status: Discover Blade Boot Wait
    Timestamp: 2006-01-26T23:31:36
    Try: 0
    Flags: 0
```

```
Progress (%): 33
Current Task: Waiting for system reset on server 1/1
(FSM-STAGE:sam:dme:ComputeBladeDiscover:BladeBootWait)
```

Enter the **show fsm task** command in the appropriate mode to view all of the pending tasks in the FSM queue. The following example displays the FSM task queue for chassis 1, slot 1:

```
Firepower# scope server 1/1
Firepower /chassis/server # show fsm task

FSM Task:
  Item           ID           Completion  FSM Flags
-----
  Powercycle     1154858    Scheduled
  BiosRecovery   1154860    Scheduled
```




FXOS Faults

This chapter provides information about the faults that may be raised in FXOS.

fltFabricVlanReqVlanPermitUnresolved

Fault Code: F0019

Message

The VLAN permit does not reference any existing vlans.

Explanation

This fault occurs when a VLAN permit exists but there are no vnics by the name.

Recommended Action

Delete the VLAN permit, create the referenced VLAN (or ignore).

Fault Details

```
Severity: warning
Cause: vlan-permit-unresolved
mibFaultCode: 19
mibFaultName: fltFabricVlanReqVlanPermitUnresolved
moClass: fabric:VlanReq
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/vlan-req- [name]
```

fltFabricVlanGroupReqVlanGroupPermitUnresolved

Fault Code: F0021

Message

The VLAN permit does not reference any existing net groups.

Explanation

This fault occurs when a VLAN group permit exists but there are no referenced network groups.

Recommended Action

Delete the VLAN permit, create the referenced VLAN (or ignore).

Fault Details

```
Severity: warning
Cause: group-permit-unresolved
mibFaultCode: 21
mibFaultName: fltFabricVlanGroupReqVlanGroupPermitUnresolved
moClass: fabric:VlanGroupReq
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /vlan-group-req- [name]
```

fltDcxNsFailed**Fault Code: F0056****Message**

Server [chassisId]/[slotId] (service profile: [assignedToDn]) virtual network interface allocation failed. Server [id] (service profile: [assignedToDn]) virtual network interface allocation failed.

Explanation

The adapter's vif-namespace activation failed due to insufficient resources. Cisco FPR Manager raises this fault when the number of deployed VIF resources exceeds the maximum VIF resources available on the adapter connected to the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the NS "size" and "used" resources to determine by how many vNICs the adapter exceeded the maximum.
 - Step 2** Unconfigure or delete all vNICs on the adapter above the maximum number.
 - Step 3** Add additional fabric uplinks from the IOM to the corresponding fabric interconnect and reacknowledge the chassis. This increases the "NS size" on the adapter.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: insufficient-resources
mibFaultCode: 56
mibFaultName: fltDcxNsFailed
moClass: dcx:Ns
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /adaptor- [id] /dcxns- [switchId]
Affected MO: sys/rack-unit- [id] /adaptor- [id] /dcxns- [switchId]
```


fltComputePhysicalInsufficientlyEquipped

Fault Code: F0057

Message

Server [id] (service profile: [assignedToDn]) has insufficient number of DIMMs, CPUs and/or adapters
Server [chassisId]/[slotId] (service profile: [assignedToDn]) has insufficient number of DIMMs, CPUs and/or adapters

Explanation

This fault typically occurs because Cisco FPR Manager has detected that the server has an insufficient number of DIMMs, CPUs, and/or adapters.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the DIMMs are installed in a supported configuration.
 - Step 2** Verify that an adapter and CPU are installed.
 - Step 3** Reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: insufficiently-equipped
mibFaultCode: 57
mibFaultName: fltComputePhysicalInsufficientlyEquipped
moClass: compute:Physical
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalIdentityUnestablishable

Fault Code: F0058

Message

Server [id] (service profile: [assignedToDn]) has an invalid FRU
Server [chassisId]/[slotId] (service profile: [assignedToDn]) has an invalid FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported server or CPU.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that a supported server and/or CPU is installed.

- Step 2** Verify that the Cisco FPR Manager capability catalog is up to date.
- Step 3** Reacknowledge the server.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: identity-unestablishable
mibFaultCode: 58
mibFaultName: fltComputePhysicalIdentityUnestablishable
moClass: compute:Physical
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]
```

fltComputeBoardPowerError

Fault Code: F0059

Message

Motherboard of server [chassisId]/[slotId] (service profile: [assignedToDn]) power: [operPower]Motherboard of server [id] (service profile: [assignedToDn]) power: [operPower]

Explanation

This fault typically occurs when the server power sensors have detected a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Make sure that the server is correctly installed in the chassis and that all cables are secure.
 - Step 2** If you reinstalled the server, reacknowledge it.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: power-problem
mibFaultCode: 59
mibFaultName: fltComputeBoardPowerError
moClass: compute:Board
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board
Affected MO: sys/rack-unit- [id]/board
```

fltComputeBoardPowerFail

Fault Code: F0060

Message

Motherboard of server [chassisId]/[slotId] (service profile: [assignedToDn]) power: [power]Motherboard of server [id] (service profile: [assignedToDn]) power: [power]

Explanation

This fault typically occurs when the power sensors on a blade server detect a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove the blade server from the chassis.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: power-problem
mibFaultCode: 60
mibFaultName: fltComputeBoardPowerFail
moClass: compute:Board
Type: environmental
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/rack-unit-[id]/board
```

fltComputeABoardThermalProblem

Fault Code: F0061

Message

Motherboard [faultQualifier] of server [chassisId]/[slotId] (service profile: [assignedToDn]) thermal: [thermal]Motherboard of server [id] (service profile: [assignedToDn]) thermal: [thermal]

Explanation

This fault typically occurs when the motherboard thermal sensors on a server detect a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the server fans are working properly.
 - Step 2** Wait for 24 hours to see if the problem resolves itself.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: thermal-problem
mibFaultCode: 61
mibFaultName: fltComputeABoardThermalProblem
moClass: compute:ABoard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /board
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id]
Affected MO: sys/rack-unit- [id] /board
Affected MO: sys/rack-unit- [id] /ext-board- [id]

```

fltComputeABoardPowerUsageProblem**Fault Code: F0062****Message**

Motherboard [faultQualifier] of server [chassisId]/[slotId] (service profile: [assignedToDn]) powerUsage: [powerUsage] Motherboard of server [id] (service profile: [assignedToDn]) powerUsage: [powerUsage]

Explanation

This fault typically occurs when the motherboard power consumption exceeds certain threshold limits. At that time the power usage sensors on a server detect a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: power-problem
mibFaultCode: 62
mibFaultName: fltComputeABoardPowerUsageProblem
moClass: compute:ABoard
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /board
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id]
Affected MO: sys/rack-unit- [id] /board
Affected MO: sys/rack-unit- [id] /ext-board- [id]

```

fltComputePhysicalPowerProblem

Fault Code: F0063

Message

Server [id] (service profile: [assignedToDn]) oper state: [operState]Server [chassisId]/[slotId] (service profile: [assignedToDn]) oper state: [operState]

Explanation

This fault typically occurs when the server power sensors have detected a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Make sure that the server is correctly installed in the chassis and that all cables are secure.
 - Step 2** If you reinstalled the server, reacknowledge it.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: power-problem
mibFaultCode: 63
mibFaultName: fltComputePhysicalPowerProblem
moClass: compute:Physical
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalBiosPostTimeout

Fault Code: F0065

Message

Server [id] (service profile: [assignedToDn]) BIOS failed power-on self testServer [chassisId]/[slotId] (service profile: [assignedToDn]) BIOS failed power-on self test

Explanation

This fault typically occurs when the server has encountered a diagnostic failure.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the server. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the server. In Cisco FPR Manager CLI, you can access the POST results through the show post command under the scope for the server.
 - Step 2** Reacknowledge the server.

Step 3 If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: 65
mibFaultName: fltComputePhysicalBiosPostTimeout
moClass: compute:Physical
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalDiscoveryFailed

Fault Code: F0066

Message

Server [id] (service profile: [assignedToDn]) discovery: [discovery]Server [chassisId]/[slotId] (service profile: [assignedToDn]) discovery: [discovery]

Explanation

This fault typically occurs for one of the following reasons:

- The shallow discovery that occurs when the server associated with service profile failed.
- The server is down.
- The data path is not working.
- Cisco FPR Manager cannot communicate with the CIMC on the server.
- The server cannot communicate with the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FSM tab and the current state of the server and any FSM operations.
- Step 2** Check the error descriptions and see if any server components indicate a failure.
- Step 3** If the server or a server component has failed, do the following:
- a. Check the operational state of the server.
 - b. If the server is not operable, re-acknowledge the server.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: discovery-failed
mibFaultCode: 66
mibFaultName: fltComputePhysicalDiscoveryFailed
moClass: compute:Physical
Type: operational
Callhome: diagnostic
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAssociationFailed

Fault Code: F0067

Message

Service profile [assignedToDn] failed to associate with server [id]Service profile [assignedToDn] failed to associate with server [chassisId]/[slotId]

Explanation

This fault typically occurs for one of the following reasons:

- The service profile could not be associated with the server.
- The server is down.
- The data path is not working.
- Cisco FPR Manager cannot communicate with one or more of the fabric interconnect, the server, or a component on the server.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FSM tab and the current state of the server and any FSM operations.
- Step 2** If the server is stuck in an inappropriate state, such as booting, power cycle the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: association-failed
mibFaultCode: 67
mibFaultName: fltComputePhysicalAssociationFailed
moClass: compute:Physical
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalDisassociationFailed

Fault Code: F0068

Message

Failed to disassociate server [id]Failed to disassociate server [chassisId]/[slotId]

Explanation

This fault typically occurs for one of the following reasons:

- The server is down.
- The data path is not working.
- Cisco FPR Manager cannot communicate with one or more of the fabric interconnect, the server, or a component on the server.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the communication path to the server including fabric interconnect server ports, IOM link and the current state of the server
- Step 2** If the server is stuck in an inappropriate state, such as booting, power cycle the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: disassociation-failed
mibFaultCode: 68
mibFaultName: fltComputePhysicalDisassociationFailed
moClass: compute:Physical
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]
```

fltComputePhysicalInoperable**Fault Code: F0069****Message**

Server [id] (service profile: [assignedToDn]) health: [operability] Server [chassisId]/[slotId] (service profile: [assignedToDn]) health: [operability]

Explanation

This fault typically occurs when the server has encountered a diagnostic failure.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the server. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the server. In Cisco FPR Manager CLI, you can access the POST results through the show post command under the scope for the server.
- Step 2** Reacknowledge the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: 69
mibFaultName: fltComputePhysicalInoperable
moClass: compute:Physical
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalUnassignedMissing**Fault Code: F0070****Message**

Server [id] (no profile) missingServer [chassisId]/[slotId] (no profile) missing

Explanation

This fault typically occurs when the server, which is not associated with a service profile, was previously physically inserted in the slot, but cannot be detected by Cisco FPR Manager.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the server is physically present in the slot, remove and then reinsert it.
 - Step 2** If the server is not physically present in the slot, insert it.
 - Step 3** Reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: equipment-missing
mibFaultCode: 70
mibFaultName: fltComputePhysicalUnassignedMissing
moClass: compute:Physical
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAssignedMissing**Fault Code: F0071****Message**

Server [id] (service profile: [assignedToDn]) missingServer [chassisId]/[slotId] (service profile: [assignedToDn]) missing

Explanation

This fault typically occurs when the server, which is associated with a service profile, was previously physically inserted in the slot, but cannot be detected by Cisco FPR Manager.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the server is physically present in the slot, remove and then reinsert it.
 - Step 2** If the server is not physically present in the slot, reinsert it.
 - Step 3** Reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: equipment-missing
mibFaultCode: 71
mibFaultName: fltComputePhysicalAssignedMissing
moClass: compute:Physical
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]
```

fltComputePhysicalUnidentified**Fault Code: F0072****Message**

Server [id] (service profile: [assignedToDn]) has an invalid FRU: [presence]Server [chassisId]/[slotId] (service profile: [assignedToDn]) has an invalid FRU: [presence]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported server or CPU.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that a supported server and/or CPU is installed.
 - Step 2** Verify that the Cisco FPR Manager capability catalog is up to date.
 - Step 3** Reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: identity-unestablishable
mibFaultCode: 72
mibFaultName: fltComputePhysicalUnidentified
```

```

moClass: compute:Physical
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalNetworkMisconfigured

Fault Code: F0075

Message

Server [id] (service profile: [assignedToDn]) has mis-configured network vif resourcesServer [chassisId]/[slotId] (service profile: [assignedToDn]) has mis-configured network vif resources

Explanation

This fault would occur when FPRM VIF-id Map is not the same as the VIF-id map deployed on the adaptor upon Full Backup-Restore etc.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Re-acknowledge the server. This will trigger Deep Discovery-Deep Association & will resolve the issue
 - Step 2** If the above actions did not resolve the issue, execute the **show tech-support** command and contact Cisco Technical Support.

Fault Details

```

Severity: minor
Cause: vif-ids-mismatch
mibFaultCode: 75
mibFaultName: fltComputePhysicalNetworkMisconfigured
moClass: compute:Physical
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAdapterMismatch

Fault Code: F0076

Message

Server [id] (service profile: [assignedToDn]) has invalid adapter combinatonServer [chassisId]/[slotId] (service profile: [assignedToDn]) has invalid adapter combination

Explanation

This fault typically occurs because Cisco FPR Manager has detected that the server has an invalid combination of Cisco VICs.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the valid adapter combinations are installed configuration.
 - Step 2** Reacknowledge the server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: adaptor-mismatch
mibFaultCode: 76
mibFaultName: fltComputePhysicalAdapterMismatch
moClass: compute:Physical
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]

```

fltComputeBoardCmosVoltageThresholdCritical**Fault Code: F0077****Message**

Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [id] is [cmosVoltage]

Explanation

This fault is raised when the CMOS battery voltage has dropped to lower than the normal operating range. This could impact the clock and other CMOS settings.

Recommended Action

If you see this fault, replace the battery.

Fault Details

```

Severity: major
Cause: voltage-problem
mibFaultCode: 77
mibFaultName: fltComputeBoardCmosVoltageThresholdCritical
moClass: compute:Board
Type: environmental
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board
Affected MO: sys/rack-unit- [id]/board

```

fltComputeBoardCmosVoltageThresholdNonRecoverable

Fault Code: F0078

Message

Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [id] is [cmosVoltage]

Explanation

This fault is raised when the CMOS battery voltage has dropped quite low and is unlikely to recover. This impacts the clock and other CMOS settings.

Recommended Action

If you see this fault, replace the battery.

Fault Details

```
Severity: major
Cause: voltage-problem
mibFaultCode: 78
mibFaultName: fltComputeBoardCmosVoltageThresholdNonRecoverable
moClass: compute:Board
Type: environmental
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/rack-unit-[id]/board
```

fltComputeABoardMotherBoardVoltageThresholdUpperNonRecoverable

Fault Code: F0079

Message

Motherboard input voltage(12V/5V/3V) in server [id] is [voltage]Motherboard [faultQualifier] input voltage(12V/5V/3V) in server [chassisId]/[slotId] is [voltage]

Explanation

This fault is raised when one or more motherboard input voltages has become too high and is unlikely to recover.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: voltage-problem
mibFaultCode: 79
mibFaultName: fltComputeABoardMotherBoardVoltageThresholdUpperNonRecoverable
moClass: compute:ABoard
Type: environmental
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]

```

fltComputeABoardMotherBoardVoltageThresholdLowerNonRecoverable

Fault Code: F0080

Message

Motherboard input voltage(12V/5V/3V) in server [id] is [voltage]Motherboard [faultQualifier] input voltage(12V/5V/3V) in server [chassisId]/[slotId] is [voltage]

Explanation

This fault is raised when one or more motherboard input voltages has dropped too low and is unlikely to recover.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: voltage-problem
mibFaultCode: 80
mibFaultName: fltComputeABoardMotherBoardVoltageThresholdLowerNonRecoverable
moClass: compute:ABoard
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]

```

fltComputeABoardMotherBoardVoltageUpperThresholdCritical

Fault Code: F0081

Message

Motherboard input voltage(12V/5V/3V) in server [id] is [voltage]Motherboard [faultQualifier] input voltage(12V/5V/3V) in server [chassisId]/[slotId] is [voltage]

Explanation

This fault is raised when one or more motherboard input voltages has crossed upper critical thresholds.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: minor
Cause: voltage-problem
mibFaultCode: 81
mibFaultName: fltComputeABoardMotherBoardVoltageUpperThresholdCritical
moClass: compute:ABoard
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /board
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id]
Affected MO: sys/rack-unit- [id] /board
Affected MO: sys/rack-unit- [id] /ext-board- [id]
```

fltComputeABoardMotherBoardVoltageLowerThresholdCritical**Fault Code: F0082****Message**

Motherboard input voltage(12V/5V/3V) in server [id] is [voltage]Motherboard [faultQualifier] input voltage(12V/5V/3V) in server [chassisId]/[slotId] is [voltage]

Explanation

This fault is raised when one or more motherboard input voltages has crossed lower critical thresholds.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: minor
Cause: voltage-problem
mibFaultCode: 82
mibFaultName: fltComputeABoardMotherBoardVoltageLowerThresholdCritical
moClass: compute:ABoard
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /board
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id]
Affected MO: sys/rack-unit- [id] /board
Affected MO: sys/rack-unit- [id] /ext-board- [id]
```

fltComputePoolEmpty

Fault Code: F0083

Message

server pool [name] is empty

Explanation

This fault typically occurs when the selected server pool does not contain any servers.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify the qualifier settings in the server pool policy qualifications. If the policy was modified after the server was discovered, reacknowledge the server.
 - Step 2** Manually associate the service profile with a server.
 - Step 3** If the server pool is not used, ignore the fault.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: empty-pool
mibFaultCode: 83
mibFaultName: fltComputePoolEmpty
moClass: compute:Pool
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/compute-pool-[name]
```

fltComputePhysicalPost-failure

Fault Code: F0084

Message

Server [id] POST or diagnostic failureServer [chassisId]/[slotId] POST or diagnostic failure

Explanation

This fault typically occurs when the server has encountered a diagnostic failure or an error during POST.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the server. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the server. In Cisco FPR Manager CLI, you can access the POST results through the show post command under the scope for the server.
 - Step 2** Reboot the server.

- Step 3** If the above actions did not resolve the issue, execute the **show tech-support** command and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: equipment-problem
mibFaultCode: 84
mibFaultName: fltComputePhysicalPostFailure
moClass: compute:Physical
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fltComputeRtcBatteryInoperable

Fault Code: F0085

Message

RTC Battery on server [chassisId]/[slotId] operability: [operability]

Explanation

This fault is raised when the CMOS battery voltage is below the normal operating range. This impacts the system clock.

Recommended Action

If you see this fault, replace the CMOS battery.

Fault Details

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: 85
mibFaultName: fltComputeRtcBatteryInoperable
moClass: compute:RtcBattery
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/rtc-battery
Affected MO: sys/rack-unit-[id]/board/rtc-battery

```

fltComputeIOHubThermalNonCritical

Fault Code: F0086

Message

IO Hub on server [chassisId]/[slotId] temperature: [thermal]

Explanation

This fault is raised when the IO controller temperature is outside the upper or lower non-critical threshold.

Recommended Action

If you see this fault, monitor other environmental events related to this server and ensure the temperature ranges are within recommended ranges.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 86
mibFaultName: fltComputeIOHubThermalNonCritical
moClass: compute:IOHub
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/iohub
Affected MO: sys/rack-unit- [id]/board/iohub
```

fltComputeIOHubThermalThresholdCritical**Fault Code: F0087****Message**

IO Hub on server [chassisId]/[slotId] temperature: [thermal]

Explanation

This fault is raised when the IO controller temperature is outside the upper or lower critical threshold.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor other environmental events related to the server and ensure the temperature ranges are within recommended ranges.
 - Step 2** Consider turning off the server for a while if possible.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 87
mibFaultName: fltComputeIOHubThermalThresholdCritical
moClass: compute:IOHub
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/iohub
Affected MO: sys/rack-unit- [id]/board/iohub
```

fltComputeIOHubThermalThresholdNonRecoverable

Fault Code: F0088

Message

IO Hub on server [chassisId]/[slotId] temperature: [thermal]

Explanation

This fault is raised when the IO controller temperature is outside the recoverable range of operation.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Shutdown the server immediately.
 - Step 2** Create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 88
mibFaultName: fltComputeIOHubThermalThresholdNonRecoverable
moClass: compute:IOHub
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub
Affected MO: sys/rack-unit-[id]/board/iohub
```

fltFirmwareBootUnitPowerCycleRequired

Fault Code: F0089

Message

Board controller upgraded, manual a/c power cycle required on server [serverId]

Explanation

None set.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Power cycle the board controller.

Fault Details

```
Severity: critical
Cause: board-ctrl-upgraded
mibFaultCode: 89
mibFaultName: fltFirmwareBootUnitPowerCycleRequired
moClass: firmware:BootUnit
Type: generic
```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit- [type]
Affected MO: capabilities/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/graphics-card- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/fpga/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/rommon/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fex- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fw-system/fw-boot-def/bootunit- [type]
Affected MO: sys/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/board/graphics-card- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/switch- [id]/mgmt/fw-boot-def/bootunit- [type]

fltCimcvmediaActualMountEntryVmediaMountFailed

Fault Code: F0090

Message

Server [chassisId]/[slotId] (service profile: [assignedToDn]) vmedia mapping [mappingName] has failed. Server [id] (service profile: [assignedToDn]) vmedia mapping [mappingName] has failed.

Explanation

None set.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the mount related details(remote server ip, port, path & file is reachable) and reack the server .

Fault Details

Severity: major
Cause: vmedia-mount-inaccessible
mibFaultCode: 90
mibFaultName: fltCimcvmediaActualMountEntryVmediaMountFailed
moClass: cimcvmedia:ActualMountEntry
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/boardController/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/slot-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO: sys/fex-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/fex-[id]/slot-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO: sys/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]

Affected MO:
 sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt/actual-mount-list/actual-mount-entry- [virtualDiskId]
Affected MO:
 sys/rack-unit- [id] /ext-board- [id] /mgmt/actual-mount-list/actual-mount-entry- [virtualDiskId]
Affected MO:
 sys/rack-unit- [id] /mgmt/actual-mount-list/actual-mount-entry- [virtualDiskId]
Affected MO: sys/switch- [id] /mgmt/actual-mount-list/actual-mount-entry- [virtualDiskId]

fltFirmwarePackItemImageMissing

Fault Code: F0095

Message

[type] image with vendor [hwVendor], model [hwModel] and version [version] is deleted

Explanation

This fault typically occurs when the image to which a firmware package item refers is missing.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In Cisco FPR Manager GUI, navigate to the Firmware Management Images tab and determine whether the missing image is available or not.
 - Step 2** If the image is present, click on it to verify the model and vendor.
 - Step 3** If the image for the required model and vendor is not present, download that image or bundle from the Cisco.com website.
 - Step 4** If the image is present and the fault persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: image-deleted
mibFaultCode: 95
mibFaultName: fltFirmwarePackItemImageMissing
moClass: firmware:PackItem
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /fw-catalog-pack- [name] /pack-image- [hwVendor] | [hwModel] | [type]
Affected MO: org- [name] /fw-host-pack- [name] /pack-image- [hwVendor] | [hwModel] | [type]
Affected MO: org- [name] /fw-infra-pack- [name] /pack-image- [hwVendor] | [hwModel] | [type]
Affected MO: org- [name] /fw-mgmt-pack- [name] /pack-image- [hwVendor] | [hwModel] | [type]
Affected MO: org- [name] /fw-platform-pack- [name] /pack-image- [hwVendor] | [hwModel] | [type]
Affected MO: org- [name] /pack-image- [hwVendor] | [hwModel] | [type]

fltFirmwareUpdatableImageUnusable

Fault Code: F0096

Message

backup image is unusable. reason: [operStateQual]

Explanation

This fault typically occurs when the backup firmware image on an endpoint is unusable.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the fault and the error message on the FSM tab for the endpoint to determine why the firmware image is unusable.
 - Step 2** If the firmware image is bad or corrupted, download another copy from the Cisco website and update the backup version on the endpoint with the new image.
 - Step 3** If the image is present and the fault persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: image-unusable
mibFaultCode: 96
mibFaultName: fltFirmwareUpdatableImageUnusable
moClass: firmware:Updatable
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/os-ctrl/fw-updatable
Affected MO: sys/chassis-[id]/fpga/fw-updatable
Affected MO: sys/chassis-[id]/rommon/fw-updatable
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-updatable
Affected MO: sys/fex-[id]/mgmt/fw-updatable
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-updatable
Affected MO: sys/mgmt/fw-updatable
Affected MO: sys/os-ctrl/fw-updatable
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/bios/fw-updatable
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/os-ctrl/fw-updatable
Affected MO: sys/switch-[id]/mgmt/fw-updatable

```

fltFirmwareBootUnitCantBoot

Fault Code: F0097

Message

unable to boot the startup image. End point booted with backup image

Explanation

This fault typically occurs when the startup firmware image on an endpoint is corrupted or invalid, and the endpoint cannot boot from that image.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the fault and the error message on the FSM tab for the endpoint to determine why the firmware image is unusable. The error message usually includes an explanation for why the endpoint could not boot from the startup image, such as Bad-Image or Checksum Failed.
 - Step 2** If the firmware image is bad or corrupted, download another copy from the Cisco website and update the startup version on the endpoint with the new image.
 - Step 3** If the fault persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: image-cannot-boot
mibFaultCode: 97
mibFaultName: fltFirmwareBootUnitCantBoot
moClass: firmware:BootUnit
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit- [type]
Affected MO: capabilities/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/graphics-card- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/fw-boot-def/bootunit- [type]

```



```

Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/os-ctrl/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/fpga/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/rommon/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fw-system/fw-boot-def/bootunit-[type]
Affected MO: sys/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/os-ctrl/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/os-ctrl/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/mgmt/fw-boot-def/bootunit-[type]

```

fltFirmwareBootUnitActivateStatusFailed

Fault Code: F0098

Message

Activation failed and Activate Status set to failed.

Explanation

This fault typically occurs for the following reasons: when firmware activation fails, or if the after activation running image is not the corresponding startup image.

- Firmware activation failed.
- The version of firmware running on the server after activation is not the version listed in Cisco FPR Manager as the startup image.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Go to FSM tab for the endpoint on which the fault is raised and review the error description for the reason that the activation failed.
- Step 2** If the FSM failed, review the error message in the FSM.
- Step 3** If possible, correct the problem described in the error message.
- Step 4** If the problem persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major

```

Cause: activation-failed
mibFaultCode: 98
mibFaultName:fltFirmwareBootUnitActivateStatusFailed
moClass: firmware:BootUnit
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit- [type]
Affected MO: capabilities/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/graphics-card- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/fpga/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/rommon/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fex- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/fw-system/fw-boot-def/bootunit- [type]
Affected MO: sys/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/board/graphics-card- [id]/fw-boot-def/bootunit- [type]
Affected MO:
sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/bios/fw-boot-def/bootunit- [type]
Affected MO:
sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/mgmt/fw-boot-def/bootunit- [type]
Affected MO: sys/rack-unit- [id]/os-ctrl/fw-boot-def/bootunit- [type]
Affected MO: sys/switch- [id]/mgmt/fw-boot-def/bootunit- [type]

```

fltFirmwareStatusCimcFirmwareMismatch

Fault Code: F0099

Message

Aggregate blade CIMC firmware mismatch. Firmware: [cimcVersion]

Explanation

This fault typically occurs when the CIMC firmware image on master and slave node in an aggregate blade does not match.

Recommended Action

Update and activate master and slave CIMC to same firmware version.

Fault Details

```
Severity: critical
Cause: cimc-firmware-mismatch
mibFaultCode: 99
mibFaultName: fltFirmwareStatusCimcFirmwareMismatch
moClass: firmware:Status
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/fw-status
Affected MO: sys/chassis-[id]/slot-[id]/fw-status
Affected MO: sys/fex-[id]/slot-[id]/fw-status
Affected MO: sys/fw-status
Affected MO: sys/fw-system/fw-status
Affected MO: sys/rack-unit-[id]/fw-status
Affected MO: sys/switch-[id]/fw-status
```

fltFirmwareStatusPldFirmwareMismatch

Fault Code: F0100

Message

Aggregate blade board controller firmware mismatch. Firmware: [pldVersion]

Explanation

This fault typically occurs when the board controller firmware image on master and slave node in an aggregate blade does not match.

Recommended Action

Update master and slave board controller to same firmware version.

Fault Details

```
Severity: critical
Cause: pld-firmware-mismatch
mibFaultCode: 100
mibFaultName: fltFirmwareStatusPldFirmwareMismatch
moClass: firmware:Status
Type: management
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/fw-status
Affected MO: sys/chassis-[id]/slot-[id]/fw-status
Affected MO: sys/fex-[id]/slot-[id]/fw-status
Affected MO: sys/fw-status
Affected MO: sys/fw-system/fw-status
Affected MO: sys/rack-unit-[id]/fw-status
Affected MO: sys/switch-[id]/fw-status

```

fltFirmwareAutoSyncPolicyDefaultHostPackageMissing

Fault Code: F0101

Message

Default host firmware package is missing or deleted.

Explanation

This fault typically occurs for the following reasons: when Auto Firmware Sync Policy is set Auto-acknowledge or User-acknowledge and default host firmware pack is not available.

- Auto Firmware Sync is not happening.
- Default host firmware package is missing or deleted.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Go to Servers tab and expand policies node. Select Host Firmware Packages under policies node.
- Step 2** If the FSM failed, review the error message in the FSM.
- Step 3** Create a host firmware package with name 'default'. If the problem persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: default-hostpack-missing
mibFaultCode: 101
mibFaultName: fltFirmwareAutoSyncPolicyDefaultHostPackageMissing
moClass: firmware:AutoSyncPolicy
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-auto-sync

```

fltPowerChassisMemberPowerGroupCapInsufficient

Fault Code: F0149

Message

Chassis [id] cannot be capped as group cap is low. Please consider raising the cap.

Explanation

This fault typically occurs when an updated group cap is insufficient to meet the minimum hardware requirements and a chassis that has just been added to the power group cannot be capped as a result.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Consider increasing the group cap.
 - Step 2** Reduce the number of blade servers or chassis in the Cisco FPR instance.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: group-cap-insufficient
mibFaultCode: 149
mibFaultName: fltPowerChassisMemberPowerGroupCapInsufficient
moClass: power:ChassisMember
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group- [name] /ch-member- [id]
```

fltPowerChassisMemberChassisFirmwareProblem

Fault Code: F0150

Message

Chassis [id] cannot be capped as at least one of the CMC or CIMC or BIOS firmware version is less than 1.4. Please upgrade the firmware for cap to be applied.

Explanation

This fault typically occurs when the CIMC firmware on a server is an earlier release than Cisco FPR, Release 1.4.

Recommended Action

If you see this fault, consider upgrading the CIMC firmware, and the entire Cisco FPR instance if necessary, to Cisco FPR, Release 1.4 or later.

Fault Details

```
Severity: major
Cause: old-chassis-component-firmware
mibFaultCode: 150
mibFaultName: fltPowerChassisMemberChassisFirmwareProblem
moClass: power:ChassisMember
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group- [name] /ch-member- [id]
```

fltPowerBudgetFirmwareMismatch

Fault Code: F0151

Message

Firmware on blade [chassisId]/[slotId] does not allow chassis level power capping. Please consider upgrading to at least 1.4 version

Explanation

This fault typically occurs when the CIMC or BIOS firmware on a server is an earlier release than Cisco FPR, Release 1.4.

Recommended Action

If you see this fault, consider upgrading the CIMC firmware, and the entire Cisco FPR instance if necessary, to Cisco FPR, Release 1.4 or later.

Fault Details

```
Severity: major
Cause: old-firmware
mibFaultCode: 151
mibFaultName: fltPowerBudgetFirmwareMismatch
moClass: power:Budget
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/budget
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/budget
Affected MO: sys/chassis- [id]/budget
Affected MO: sys/rack-unit- [id]/budget
Affected MO: sys/rack-unit- [id]/ext-board- [id]/budget
```

fltPowerChassisMemberChassisPsuInsufficient

Fault Code: F0152

Message

Chassis [id] cannot be capped as at least two PSU need to be powered

Explanation

This fault typically occurs when at least two PSUs are not powered on.

Recommended Action

If you see this fault, insert at least two PSUs and power them on.

Fault Details

```
Severity: major
Cause: psu-insufficient
mibFaultCode: 152
mibFaultName: fltPowerChassisMemberChassisPsuInsufficient
moClass: power:ChassisMember
Type: environmental
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group- [name] /ch-member- [id]

```

fltPowerBudgetChassisPsuInsufficient

Fault Code: F0153

Message

Chassis [id] cannot be capped as the available PSU power is not enough for the chassis and the blades. Please correct the problem by checking input power or replace the PSU

Explanation

This fault typically occurs when the available PSU power is not enough to deploy the power budget of chassis and blades.

Recommended Action

If you see this fault, check the PSU input power or replace the PSU.

Fault Details

```

Severity: major
Cause: psu-insufficient
mibFaultCode: 153
mibFaultName: fltPowerBudgetChassisPsuInsufficient
moClass: power:Budget
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /budget
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /budget
Affected MO: sys/chassis- [id] /budget
Affected MO: sys/rack-unit- [id] /budget
Affected MO: sys/rack-unit- [id] /ext-board- [id] /budget

```

fltPowerChassisMemberChassisPsuRedundanceFailure

Fault Code: F0154

Message

Chassis [id] was configured for redundancy, but running in a non-redundant configuration.

Explanation

This fault typically occurs when chassis power redundancy has failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Consider adding more PSUs to the chassis.
 - Step 2** Replace any non-functional PSUs.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: psu-redundancy-fail
mibFaultCode: 154
mibFaultName: fltPowerChassisMemberChassisPsuRedundanceFailure
moClass: power:ChassisMember
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group-[name]/ch-member-[id]

fltPowerBudgetPowerBudgetCmcProblem**Fault Code:** F0155**Message**

Power cap application failed for chassis [id]

Explanation

This fault typically occurs when the server CIMC has failed to enforce the configured power cap.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the power consumption of the chassis. If the chassis is consuming significantly more power than configured in the power cap, consider reducing the group cap so that the power consumption of other chassis consumption can be reduced to make up for the increase.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file for Cisco FPR Manager and the chassis and then contact Cisco TAC.

Fault Details

Severity: major
Cause: power-cap-fail
mibFaultCode: 155
mibFaultName: fltPowerBudgetPowerBudgetCmcProblem
moClass: power:Budget
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget

fltPowerBudgetPowerBudgetBmcProblem**Fault Code:** F0156**Message**

Power cap application failed for server [chassisId]/[slotId]Power cap application failed for server [id]

Explanation

This fault typically occurs when the server CIMC or BIOS has failed to enforce the configured power cap.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the power consumption of the blade server. If the server is consuming significantly more power than configured in the power cap, switch to a manual per blade cap configuration. If the power consumption is still too high, consider reducing the group cap so that the power consumption of other chassis consumption can be reduced to make up for the increase.
 - Step 2** If the power consumption is still too high, the CIMC or BIOS software is likely faulty.
 - Step 3** Create a **show tech-support** file for Cisco FPR Manager and the chassis and then contact Cisco TAC.

Fault Details

```
Severity: major
Cause: power-cap-fail
mibFaultCode: 156
mibFaultName: fltPowerBudgetPowerBudgetBmcProblem
moClass: power:Budget
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
```

fltPowerBudgetPowerCapReachedCommit**Fault Code: F0157****Message**

P-State lowered as consumption hit power cap for server [chassisId]/[slotId]P-State lowered as consumption hit power cap for server [id]

Explanation

This fault typically occurs when Cisco FPR Manager is actively capping the power for a blade server.

Recommended Action

If you see this fault, no action is needed.

Fault Details

```
Severity: info
Cause: power-consumption-hit-limit
mibFaultCode: 157
mibFaultName: fltPowerBudgetPowerCapReachedCommit
moClass: power:Budget
Type: environmental
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/budget
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/budget
Affected MO: sys/chassis- [id]/budget
Affected MO: sys/rack-unit- [id]/budget
Affected MO: sys/rack-unit- [id]/ext-board- [id]/budget

```

fltPowerBudgetTStateTransition

Fault Code: F0158

Message

Blade [chassisId]/[slotId] has been severely throttled. CIMC can recover if budget is redeployed to the blade or by rebooting the blade. If problem persists, please ensure that OS is ACPI compliantRack server [id] has been severely throttled. CIMC can recover if budget is redeployed to the blade or by rebooting the blade. If problem persists, please ensure that OS is ACPI compliant

Explanation

This fault typically occurs when the processor T-state is used to severely throttle the CPU.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Redeploy the power budget for the affected power group, blade server, or chassis.
 - Step 2** If the problem persists, reboot the blade server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: no-ack-from-bios
mibFaultCode: 158
mibFaultName: fltPowerBudgetTStateTransition
moClass: power:Budget
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/budget
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/budget
Affected MO: sys/chassis- [id]/budget
Affected MO: sys/rack-unit- [id]/budget
Affected MO: sys/rack-unit- [id]/ext-board- [id]/budget

```

fltPowerBudgetPowerBudgetDiscFail

Fault Code: F0159

Message

Insufficient power available to discover server [chassisId]/[slotId]Insufficient power available to discover server [id]

Explanation

This fault typically occurs when discovery fails due to unavailable power in the group.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Consider increasing the group cap.
 - Step 2** Reduce the number of blade servers or chassis in the Cisco FPR instance.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: power-cap-fail
mibFaultCode: 159
mibFaultName: fltPowerBudgetPowerBudgetDiscFail
moClass: power:Budget
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
```

fltPowerPolicyPowerPolicyApplicationFail

Fault Code: F0160

Message

Insufficient budget to apply no-cap priority through policy [name]. Blades will continue to be capped

Explanation

This fault occurs when a power policy cannot be applied to one or more blade servers. The affected blade servers cannot operate normally without power capping due to the limited power budget for those servers.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Increase the power budget for the blade servers in the power policy.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: no-cap-fail
mibFaultCode: 160
mibFaultName: fltPowerPolicyPowerPolicyApplicationFail
moClass: power:Policy
Type: environmental
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/power-policy- [name]

```

fltPowerGroupPowerGroupInsufficientBudget

Fault Code: F0161

Message

insufficient budget for power group [name]

Explanation

This fault typically occurs when the group cap is insufficient to meet the minimum hardware requirements.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Consider increasing the group cap.
 - Step 2** Reduce the number of blade servers or chassis in the Cisco FPR instance.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: power-cap-fail
mibFaultCode: 161
mibFaultName: fltPowerGroupPowerGroupInsufficientBudget
moClass: power:Group
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group- [name]

```

fltPowerGroupPowerGroupBudgetIncorrect

Fault Code: F0162

Message

admin committed insufficient for power group [name], using previous value [operCommitted]

Explanation

This fault typically occurs when the group cap is insufficient to meet the minimum hardware requirements. Under these circumstances, Cisco FPR Manager uses the previously entered group cap for provisioning.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Consider increasing the group cap.
- Step 2** Reduce the number of blade servers or chassis in the Cisco FPR instance.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: power-cap-fail
mibFaultCode: 162
mibFaultName: fltPowerGroupPowerGroupBudgetIncorrect
moClass: power:Group
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/power-ep/group- [name]

```

fltPowerBudgetChassisPsuMixedMode

Fault Code: F0163

Message

Chassis [id] has a mix of high-line and low-line PSU input power sources.

Explanation

This fault occurs when there is a mix of high-line and low-line PSU input power source.

Recommended Action

If you see this fault, change all the PSU input power sources to have same mode

Fault Details

```

Severity: critical
Cause: psu-mixed-mode
mibFaultCode: 163
mibFaultName: fltPowerBudgetChassisPsuMixedMode
moClass: power:Budget
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/budget
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/budget
Affected MO: sys/chassis- [id]/budget
Affected MO: sys/rack-unit- [id]/budget
Affected MO: sys/rack-unit- [id]/ext-board- [id]/budget

```

fltSmSlotSmaHeartbeat

Fault Code: F0185

Message

Slot [slotId], is not operationally up

Explanation

This fault occurs when a slot is not operationally up.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reboot the Blade associated with the Slot

Fault Details

```
Severity: major
Cause: slot-not-responding
mibFaultCode: 185
mibFaultName: fltSmSlotSmaHeartbeat
moClass: sm:Slot
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]
```

fltSmSlotBladeNotWorking**Fault Code: F0186****Message**

Slot [slotId] has a fault, either blade discovery is failed or service profile association is failed

Explanation

This fault occurs when a blade discovery is failed or service profile association is failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reboot the blade associated with the slot

Fault Details

```
Severity: major
Cause: blade-not-working
mibFaultCode: 186
mibFaultName: fltSmSlotBladeNotWorking
moClass: sm:Slot
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]
```

fltSmSlotDiskFormatFailed

Fault Code: F0187

Message

Disk format is failed on slot [slotId]

Explanation

This fault occurs when a blade disk formatting is failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reformat disk or need disk replacement

Fault Details

```
Severity: major
Cause: disk-format-failed
mibFaultCode: 187
mibFaultName: fltSmSlotDiskFormatFailed
moClass: sm:Slot
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]
```

fltSmSlotBladeSwap

Fault Code: F0188

Message

Blade swap detected on slot [slotId]

Explanation

This fault occurs during the blade swap.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** 1. Insert the correct blade
Step 2 2. Reformat the disk

Fault Details

```
Severity: critical
Cause: blade-swap
mibFaultCode: 188
mibFaultName: fltSmSlotBladeSwap
moClass: sm:Slot
Type: server
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]

```

fltSmSecSvcSwitchConfigFail

Fault Code: F0189

Message

Switch configuration failed for Logical Device. Error: [switchErrorMsg]

Explanation

This fault occurs when switch configuration fails for a LogicalDevice.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: switch-config-failed
mibFaultCode: 189
mibFaultName: fltSmSecSvcSwitchConfigFail
moClass: sm:SecSvc
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

```

fltSmAppInstanceAppNotResponding

Fault Code: F0190

Message

App Instance [appName] on slot [slotId], is not responding

Explanation

This fault occurs when an app instance is not responding.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: appinstance-not-responding
mibFaultCode: 190
mibFaultName: fltSmAppInstanceAppNotResponding
moClass: sm:AppInstance

```



```

Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fltSmAppInstanceAppInstallFailed

Fault Code: F0191

Message

Failed to install App Instance [appName] on slot [slotId]. Error: [errorMsg]

Explanation

This fault occurs when an app instance installation fails.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: appinstance-install-failed
mibFaultCode: 191
mibFaultName: fltSmAppInstanceAppInstallFailed
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fltSmAppInstanceAppStartFailed

Fault Code: F0192

Message

Failed to start App Instance [appName] on slot [slotId]. Error: [errorMsg]

Explanation

This fault occurs when an app instance start fails.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: appinstance-start-failed
mibFaultCode: 192

```

```

mibFaultName: fltSmAppInstanceAppStartFailed
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fltSmAppInstanceAppUpdateFailed

Fault Code: F0193

Message

Failed to update App Instance [appName] on slot [slotId]. Error: [errorMsg]

Explanation

This fault occurs when an app instance updation fails.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: appinstance-update-failed
mibFaultCode: 193
mibFaultName: fltSmAppInstanceAppUpdateFailed
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fltSmAppInstanceAppStopFailed

Fault Code: F0194

Message

Failed to stop App Instance [appName] on slot [slotId]. Error: [errorMsg]

Explanation

This fault occurs when an app instance stop fails.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major

```

```

Cause: appinstance-stop-failed
mibFaultCode: 194
mibFaultName: fltSmAppInstanceAppStopFailed
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]

```

fltSmAppInstanceAppInstanceError

Fault Code: F0195

Message

Error in App Instance [appName]. [errorMsg]

Explanation

This fault occurs when an app instance is in a non-terminal error state.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: minor
Cause: appinstance-error
mibFaultCode: 195
mibFaultName: fltSmAppInstanceAppInstanceError
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]

```

fltSmLogicalDeviceIncompleteConfig

Fault Code: F0196

Message

Logical Device [name] is not configured correctly. Error [errorMsg]

Explanation

This fault occurs when a logical device is not configured correctly.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: major
Cause: logical-device-incomplete-configuration
mibFaultCode: 196
mibFaultName: fltSmLogicalDeviceIncompleteConfig
moClass: sm:LogicalDevice
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/ld- [name]

fltSmLogicalDeviceLogicalDeviceError**Fault Code: F0197****Message**

Error in Logical Device [name]. [errorMsg]

Explanation

This fault occurs when a logical device is in a non-terminal error state.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: minor
Cause: logical-device-error
mibFaultCode: 197
mibFaultName: fltSmLogicalDeviceLogicalDeviceError
moClass: sm:LogicalDevice
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/ld- [name]

fltSmAppLicenseAgreementNotAccepted**Fault Code: F0198****Message**

End User License Agreement not accepted for Application [name].[version]

Explanation

This fault occurs when an application requiring End User License Agreement(EULA) is downloaded but EULA is yet to be accepted.

Recommended Action

If you see this fault, take the following actions:

Step 1 Accept the license agreement for this application

Fault Details

```

Severity: major
Cause: license-agreement-not-accepted
mibFaultCode: 198
mibFaultName:fltSmAppLicenseAgreementNotAccepted
moClass: sm:App
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]

```

fltSmAppInstanceAppInstanceUnsupported

Fault Code: F0199

Message

App Instance [appName] on slot [slotId] is not supported in the current bundle. Error: [errorMsg]

Explanation

This fault occurs when an app instance is not supported in the current platform bundle

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: appinstance-unsupported
mibFaultCode: 199
mibFaultName:fltSmAppInstanceAppInstanceUnsupported
moClass: sm:AppInstance
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId] /app-inst- [appName]

```

fltSmAppAppMetaCorrupted

Fault Code: F0200

Message

The application [appId] cannot be reloaded.

Explanation

This fault occurs when an application meta data cannot be reloaded.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Re-download the application from a trusted source

Fault Details

```

Severity: major
Cause: app-meta-corrupted
mibFaultCode: 200
mibFaultName: fltSmAppAppMetaCorrupted
moClass: sm:App
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]

```

fltSwVlanPortNsVLANCompNotSupport

Fault Code: F0299

Message

VLAN Port Count Optimization is not supported

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: no-vlan-optimization
mibFaultCode: 299
mibFaultName: fltSwVlanPortNsVLANCompNotSupport
moClass: sw:VlanPortNs
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /vlan-port-ns

```

fltDcxVifLinkState

Fault Code: F0300

Message

Virtual interface [id] link state is down

Explanation

This fault occurs when Cisco FPR cannot send or receive data through an uplink port.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reenable the uplink port that failed.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: vif-down
mibFaultCode: 300
mibFaultName: fltDcxVifLinkState
moClass: dcx:Vif
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fcoe/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fcoe/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fcoe/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fcoe/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vif-[id]

```

fltVnicEtherConfig-failed

Fault Code: F0314

Message

Eth vNIC [name], service profile [name] failed to apply configuration

Explanation

This fault typically occurs when Cisco FPR Manager could not place the vNIC on the vCon.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the server was successfully discovered.
 - Step 2** Verify that the correct type of adapters are installed on the server.
 - Step 3** Confirm that the vCon assignment is correct.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: configuration-failed
mibFaultCode: 314
mibFaultName: fltVnicEtherConfigFailed
moClass: vnic:Ether
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name]
Affected MO: org- [name] /ls- [name] /ether- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name]

```

fltVnicEtherPinningMismatch**Fault Code: F0315****Message**

Hard pinning target for eth vNIC [name], service profile [name] does not have all the required vlans configured

Explanation

This fault occurs when one or more VLANs required by vNIC in a service profile are not configured on the target uplink port or port channel for a hard-pinned LAN pin group.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In the LAN Uplinks Manager of the Cisco FPR Manager GUI, configure all of the VLANs in the vNIC in the target uplink port or port channel for the LAN pin group. If you prefer to use the Cisco FPR Manager CLI, navigate to scope **/eth-uplink/vlan** and create the required member ports for the LAN pin group.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: pinning-mismatch
mibFaultCode: 315
mibFaultName: fltVnicEtherPinningMismatch
moClass: vnic:Ether
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name]
Affected MO: org- [name] /ls- [name] /ether- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name]

```


fltVnicEtherPinningMisconfig

Fault Code: F0316

Message

Hard pinning target for eth vNIC [name], service profile [name] is missing or misconfigured

Explanation

This fault occurs when one or more vNIC target uplink ports or port channels for a hard-pinned LAN pin group are either missing or misconfigured as the wrong port type.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the LAN pin group configuration.
 - Step 2** Correct the configuration of the port and port channels in the pin group.
 - Step 3** Ensure that all required vLANs are allowed on the target ports or port channels.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: pinning-misconfig
mibFaultCode: 316
mibFaultName: fltVnicEtherPinningMisconfig
moClass: vnic:Ether
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name]
Affected MO: org- [name] /ls- [name] /ether- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name]
```

fltVnicEtherIfVlanAccessFault

Fault Code: F0317

Message

The named vlan [name] for vNIC [name] cannot be accessed from org [name]

Explanation

This fault typically occurs when a Service Profile's vnic interface (LAN) is resolvable but the service profile does not have access to the vlan. In this case, the default vlan will be used.

Recommended Action

This fault will be removed if you perform one of the following actions:

-
- Step 1** Change the vnic's interface name to a VLAN that you have access to.
 - Step 2** If you wish to use the default vlan, change the vnic's interface name to default.

- Step 3** Configure access to the named vlan by creating a vlan permit or vlan group permit in the service profile's org (or a parent org).

Fault Details

```

Severity: major
Cause: inaccessible-vlan-referenced
mibFaultCode: 317
mibFaultName: fltVnicEtherIfVlanAccessFault
moClass: vnic:EtherIf
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/lan/network-sets/fabric-network- [name] /fabric-network-def- [name] /vm-network-def-
- [name] /if- [name]
Affected MO: fabric/lan/profiles/vnic- [name] /if- [name]
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /lan-conn-templ- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ipc- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ipc- [name] /if- [name]

```

fltVnicEtherIfVlanUnresolvable

Fault Code: F0318

Message

The named vlan [name] for vNIC [name] cannot be resolved

Explanation

This fault (warning) occurs when a Service Profile's vnic interface (LAN) is unresolvable. In this case, the default vlan will be used as the operational vlan.

Recommended Action

This fault will be removed if you perform one of the following actions:

-
- Step 1** Change the vnic interface name to an existing VLAN.

- Step 2** Create the named vlan .

Fault Details

```

Severity: warning
Cause: referenced-vlan-unresolvable
mibFaultCode: 318
mibFaultName: fltVnicEtherIfVlanUnresolvable
moClass: vnic:EtherIf
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true

```

```

Affected MO:
fabric/lan/network-sets/fabric-network- [name] /fabric-network-def- [name] /vm-network-def
- [name] /if- [name]
Affected MO: fabric/lan/profiles/vnic- [name] /if- [name]
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /lan-conn-templ- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ipc- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ipc- [name] /if- [name]

```

fltVnicEtherIfRemoteVlanUnresolvable

Fault Code: F0319

Message

The named vlan [name] for vNIC [name] cannot be resolved remotely

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: referenced-remote-vlan-unresolvable
mibFaultCode: 319
mibFaultName: fltVnicEtherIfRemoteVlanUnresolvable
moClass: vnic:EtherIf
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/lan/network-sets/fabric-network- [name] /fabric-network-def- [name] /vm-network-def
- [name] /if- [name]
Affected MO: fabric/lan/profiles/vnic- [name] /if- [name]
Affected MO: org- [name] /lan-conn-pol- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /lan-conn-templ- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /ls- [name] /ipc- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ether- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /if- [name]
Affected MO: org- [name] /tier- [name] /ls- [name] /ipc- [name] /if- [name]

```

fltVnicEtherIfInvalidVlan

Fault Code: F0320

Message

Invalid Vlan in the allowed vlan list

Explanation

This fault typically occurs when a vnic of a service profile or a port profile contains an invalid vlan. an invalid vlan can be any one of the following:

-
- Step 1** an isolated vlan or a community vlan that is not associated to a valid primary vlan
 - Step 2** a primary vlan without any of its associated secondary vlans allowed on the vnic
 - Step 3** a vlan which has sharing-type or primary vlan name not matching to that of vlan in lan-side/appliance-side

Recommended Action

This fault will be removed if you perform one of the following actions:

-
- Step 1** if invalid vlan is an isolated or community vlan then make sure it is mapped to a valid primary vlan.
 - Step 2** if invalid vlan is a primary vlan then either allow any of its secondary vlans or delete it from vnic or port profile.
 - Step 3** if invalid vlan is a vlan that does not match the sharing properties with the vlan of same vlan id in the lan-side/appliance-side, change the properties of this vlan to be the same as the other.

Fault Details

```

Severity: major
Cause: invalid-vlan-in-the-allowed-vlan-list
mibFaultCode: 320
mibFaultName: fltVnicEtherIfInvalidVlan
moClass: vnic:EtherIf
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/lan/network-sets/fabric-network-[name]/fabric-network-def-[name]/vm-network-def-
-[name]/if-[name]
Affected MO: fabric/lan/profiles/vnic-[name]/if-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ipc-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ipc-[name]/if-[name]

```

fltFabricVlanVlanConflictPermit

Fault Code: F0321

Message

There are multiple vlans with id [id] have different accessibility configured.

Explanation

This fault occurs when multipl global vlans with the same id have different access configurations.

Recommended Action

Change the access configuration by configuring VLAN/VLAN Group Permits.

Fault Details

```
Severity: warning
Cause: vlan-conflict-permit
mibFaultCode: 321
mibFaultName: fltFabricVlanVlanConflictPermit
moClass: fabric:Vlan
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltVnicProfileProfileConfigIncorrect

Fault Code: F0322

Message

The Port Profile [name] has an invalid configuration.

Explanation

This fault occurs there is an invalid entry for a port profile configuration.

Recommended Action

Check documentation and correct the offending entry in the port profile configuration.

Fault Details

```
Severity: warning
Cause: profile-config-incorrect
mibFaultCode: 322
mibFaultName: fltVnicProfileProfileConfigIncorrect
moClass: vnic:Profile
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/profiles/vnic-[name]
```

fltVnicIScsiConfig-failed

Fault Code: F0323

Message

iSCSI vNIC [name], service profile [name] has duplicate iqname [initiatorName]

Explanation

This fault typically occurs when iSCSI vNICs refer the same iqname.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Make sure that iqname is unique per iSCSI vNIC.
 - Step 2** Using show identity iqname check if the iSCSI vNIC is registered in the universe.
 - Step 3** Try non disruptive actions such as changing description on the Service Profile to register the iqname in the universe.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: configuration-failed
mibFaultCode: 323
mibFaultName: fltVnicIScsiConfigFailed
moClass: vnic:IScsi
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]/iscsi-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/iscsi-[name]
```

fltVnicEtherVirtualization-conflict

Fault Code: F0324

Message

Multiple connection policies cannot be assigned to the same Eth vNIC

Explanation

This fault occurs when multiple connection policies are assigned to the same vNIC.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check on the vNIC if different types of connection policies (dynamic/VMQ) are assigned. Keep only one type.
 - Step 2** Check on the vNIC through CLI if more than one connection policy of the same type is assigned. Keep only one connection policy.

Fault Details

Severity: major
Cause: multiple-connection-policies
mibFaultCode: 324
mibFaultName: fltVnicEtherVirtualizationConflict
moClass: vnic:Ether
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/lan-conn-pol- [name]/ether- [name]
Affected MO: org- [name]/ls- [name]/ether- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]/ether- [name]

fltVnicEtherVirtualization-netflow-conflict**Fault Code:** F0325**Message**

Netflow and VMQ/SRIOV-USNIC policies cannot be assigned to the same Eth vNIC

Explanation

This fault typically occurs when a netflow src vnic is made a USNIC or VMQ vnic

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove the vnic from a netflow session or remove the usnic/vmq policy
 - Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: multiple-connection-policies
mibFaultCode: 325
mibFaultName: fltVnicEtherVirtualizationNetflowConflict
moClass: vnic:Ether
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/lan-conn-pol- [name]/ether- [name]
Affected MO: org- [name]/ls- [name]/ether- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]/ether- [name]

fltLsIssuesIscsi-config-failed**Fault Code:** F0326**Message**

Service Profile [name] configuration failed due to iSCSI issue [iscsiConfigIssues]

Explanation

This fault typically occurs when Cisco FPR Manager Service Profile configuration failed due to iSCSI Config Issues.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Correct the Service Profile iSCSI Configuration as per the issue reported.
 - Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: configuration-failed
mibFaultCode: 326
mibFaultName: fltLsIssuesIscsiConfigFailed
moClass: ls:Issues
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]/config-issue
Affected MO: org- [name]/tier- [name]/ls- [name]/config-issue
```

fltMacpoolPoolEmpty

Fault Code: F0332

Message

MAC pool [name] is empty

Explanation

This fault typically occurs when a MAC address pool does not contain any MAC addresses.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the pool is in use, add a block of MAC addresses to the pool.
 - Step 2** If the pool is not in use, ignore the fault.

Fault Details

```
Severity: minor
Cause: empty-pool
mibFaultCode: 332
mibFaultName: fltMacpoolPoolEmpty
moClass: macpool:Pool
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/mac-pool- [name]
```


fltCallhomeEpNoSnmpPolicyForCallhome

Fault Code: F0335

Message

FPR Manager cannot apply Callhome policy if SNMP Policy is not configured or if SNMP Syscontact has an empty value. The Callhome policy from FPR Central has not been applied.

Explanation

This fault typically occurs when FPR Manager receives an invalid configuration from FPR Central wherein Callhome is configured on FPR Central but there is no SNMP Syscontact defined locally.

Recommended Action

If you see this fault, please ensure that the SNMP Policy is configured on FPRM Manager, either locally or via FPR Central.

Fault Details

```
Severity: minor
Cause: callhome-config-error
mibFaultCode: 335
mibFaultName: fltCallhomeEpNoSnmpPolicyForCallhome
moClass: callhome:Ep
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: call-home
```

fltAdaptorUnitUnidentifiable-fru

Fault Code: F0349

Message

Adapter [id] in server [id] has unidentified FRUAdapter [id] in server [chassisId]/[slotId] has unidentified FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported adapter. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that a supported adapter is installed.
 - Step 2** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: unidentifiable-fru
```

```

mibFaultCode: 349
mibFaultName: fltAdaptorUnitUnidentifiableFru
moClass: adaptor:Unit
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]

```

fltAdaptorUnitExtnUnidentifiable-fru

Fault Code: F0350

Message

Adapter extension [id] in server [chassisId]/[slotId] has unidentified FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported adapter unit extension, such as a pass-through adaptor. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that a supported adapter unit extension is installed.
 - Step 2** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: unidentifiable-fru
mibFaultCode: 350
mibFaultName: fltAdaptorUnitExtnUnidentifiableFru
moClass: adaptor:UnitExtn
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/adaptor-extn- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/adaptor-extn- [id]

```

fltAdaptorUnitMissing

Fault Code: F0351

Message

Adapter [id] in server [id] presence: [presence]Adapter [id] in server [chassisId]/[slotId] presence: [presence]

Explanation

The adaptor is missing. Cisco FPR Manager raises this fault when any of the following scenarios occur:

- The endpoint reports there is no adapter in the adaptor slot.
- The endpoint cannot detect or communicate with the adapter in the adaptor slot.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Make sure an adapter is inserted in the adaptor slot in the server.
- Step 2** Check whether the adaptor is connected and configured properly and is running the recommended firmware version.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: equipment-missing
mibFaultCode: 351
mibFaultName: fltAdaptorUnitMissing
moClass: adaptor:Unit
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltAdaptorUnitExtnMissing

Fault Code: F0352

Message

Adapter extension [id] in server [chassisId]/[slotId] presence: [presence]

Explanation

This fault typically occurs when an I/O adapter unit extension, such as a pass-through adapter, is missing. Cisco FPR Manager raises this fault when any of the following scenario occur:

- The endpoint reports there is no adapter unit extension, such as a pass-through adapter, plugged into the adapter slot.
- The endpoint cannot detect or communicate with the adapter unit extension plugged into the adapter slot.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Ensure the adapter unit extension is properly plugged into an adapter slot in the server.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: equipment-missing
mibFaultCode: 352
```

```

mibFaultName: fltAdaptorUnitExtnMissing
moClass: adaptor:UnitExtn
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/adaptor-extn- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/adaptor-extn- [id]

```

fltAdaptorUnitAdaptorReachability

Fault Code: F0353

Message

Adapter [id]/[id] is unreachableAdapter [chassisId]/[slotId]/[id] is unreachable

Explanation

Cisco FPR Manager cannot access the adaptor. This fault typically occurs as a result of one of the following issues:

- The server does not have sufficient power.
- The I/O module is not functional.
- The adaptor firmware has failed.
- The adaptor is not functional

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the server. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the server. In Cisco FPR Manager CLI, you can access the POST results through the **show post** command under the scope for the server.
- Step 2** In Cisco FPR Manager, check the power state of the server.
- Step 3** Verify that the physical server has the same power state.
- Step 4** If the server is off, turn the server on.
- Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: connectivity-problem
mibFaultCode: 353
mibFaultName: fltAdaptorUnitAdaptorReachability
moClass: adaptor:Unit
Type: connectivity
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]

```

fltAdaptorHostIfLink-down

Fault Code: F0354

Message

Adapter [transport] host interface [id]/[id]/[id] link state: [linkState]Adapter [transport] host interface [chassisId]/[slotId]/[id]/[id] link state: [linkState]

Explanation

This fault typically occurs as a result of one of the following issues:

- The fabric interconnect is in End-Host mode, and all uplink ports failed.
- The server port to which the adapter is pinned failed.
- A transient error caused the link to fail.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If an associated port is disabled, enable the port.
- Step 2** Reacknowledge the server with the adapter that has the failed link.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: link-down
mibFaultCode: 354
mibFaultName: fltAdaptorHostIfLinkDown
moClass: adaptor:HostIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]
```

fltAdaptorExtIfLink-down

Fault Code: F0355

Message

Adapter uplink interface [id]/[id]/[id] link state: [linkState]. Please verify connectivity to Fabric Interconnect. Acknowledging FEX might be required. Adapter uplink interface [chassisId]/[slotId]/[id]/[id] on security module [slotId] link state: [linkState]. Please check switch blade-facing port status. Resetting security module might be required.

Explanation

The link for a network facing adapter interface is down. Cisco FPR Manager raises this fault when any of the following scenarios occur:

- Cisco FPR Manager cannot establish and/or validate the adapter's connectivity to any of the fabric interconnects.
- The endpoint reports a link down or vNIC down event on the adapter link.
- The endpoint reports an errored link state or errored vNIC state event on the adapter link.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the adapter is connected, configured properly, and is running the recommended firmware version.
- Step 2** If the server is stuck at discovery, decommission the server and reacknowledge the server slot.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: link-down
mibFaultCode: 355
mibFaultName: fltAdaptorExtIfLinkDown
moClass: adaptor:ExtIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/ext-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/ext-eth- [id]
```

fltAdaptorHostEthIfMisConnect

Fault Code: F0356

Message

Adapter [id] eth interface [id] in server [id] mis-connected

Explanation

The link for a network-facing host interface is misconnected. Cisco FPR Manager raises this fault when any of the following scenarios occur:

- Cisco FPR Manager detects a new connectivity between a previously configured switch port and the host Ethernet interface.
- Cisco FPR Manager detects a misconnected link between the host interface and its non-peer fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check whether the host Ethernet interface is connected to a port belonging to its peer fabric interconnect.

- Step 2** If connectivity seems correct, reacknowledge the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: link-misconnected
mibFaultCode: 356
mibFaultName: fltAdaptorHostEthIfMisConnect
moClass: adaptor:HostEthIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fltAdaptorHostEthIfMissing

Fault Code: F0357

Message

Connection to Adapter [id] eth interface [id] in server [id] missing

Explanation

The link for a network-facing host interface is missing. Cisco FPR Manager raises this fault when it detects missing connectivity between a previously configured switch port and its previous peer host interface.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check whether the adapter link is connected to a port that belongs to its non-peer fabric interconnect.
- Step 2** If that connectivity seems correct, reacknowledge the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: link-missing
mibFaultCode: 357
mibFaultName: fltAdaptorHostEthIfMissing
moClass: adaptor:HostEthIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fltAdaptorExtEthIfMisConnect

Fault Code: F0358

Message

Adapter [id] eth interface [id] in server [id] mis-connected

Explanation

The link for a network-facing adapter interface is misconnected. Cisco FPR Manager raises this fault when any of the following scenarios occur:

- Cisco FPR Manager detects a new connectivity between a previously configured switch port or FEX port and the adapter's external interface.
- Cisco FPR Manager detects a misconnected link between a fabric interconnect or FEX and its non-peer adapter's interface.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check whether the adapter link is connected to a port that belongs to its peer fabric interconnect or FEX.
- Step 2** If that connectivity seems correct, reacknowledge the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: link-misconnected
mibFaultCode: 358
mibFaultName: fltAdaptorExtEthIfMisConnect
moClass: adaptor:ExtEthIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]
```

fltAdaptorExtEthIfMissing

Fault Code: F0359

Message

Connection to Adapter [id] eth interface [id] in server [id] missing

Explanation

The link for a network-facing adapter interface is misconnected. Cisco FPR Manager raises this fault when it detects that the connectivity between a previously configured port on a fabric interconnect or FEX and its prior peer network-facing adapter interface is misconnected or missing.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check whether the adapter interface is connected to a port belonging to its peer fabric interconnect or FEX.
- Step 2** If the connectivity seems correct, reacknowledge the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: link-missing
mibFaultCode: 359
mibFaultName: fltAdaptorExtEthIfMissing
moClass: adaptor:ExtEthIf
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]

```

fltMemoryUnitDegraded

Fault Code: F0369

Message

DIMM [location] on server [chassisId]/[slotId] operability: [operability]DIMM [location] on server [id] operability: [operability]

Explanation

This fault occurs when a DIMM is in a degraded operability state. This state typically occurs when an excessive number of correctable ECC errors are reported on the DIMM by the server BIOS.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the error statistics on the degraded DIMM through Cisco FPR Manager. If the high number of errors persists, there is a high possibility of the DIMM becoming inoperable.
- Step 2** If the DIMM becomes inoperable, replace the DIMM.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: equipment-degraded
mibFaultCode: 369
mibFaultName: fltMemoryUnitDegraded
moClass: memory:Unit
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]

```

fltMemoryUnitIdentity-unestablishable

Fault Code: F0370

Message

DIMM [location] on server [chassisId]/[slotId] has an invalid FRUDIMM [location] on server [id] has an invalid FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected unsupported DIMM in the server. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 2** If the above action did not resolve the issue, you may have unsupported DIMMs or DIMM configuration in the server. Create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: identity-unestablishable
mibFaultCode: 370
mibFaultName: fltMemoryUnitIdentityUnestablishable
moClass: memory:Unit
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/memarray- [id]/mem- [id]
Affected MO: sys/rack-unit- [id]/board/memarray- [id]/mem- [id]
```

fltMemoryUnitInoperable

Fault Code: F0371

Message

DIMM [location] on server [chassisId]/[slotId] operability: [operability]DIMM [location] on server [id] operability: [operability]

Explanation

This fault typically occurs because an above threshold number of correctable or uncorrectable errors has occurred on a DIMM. The DIMM may be inoperable.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the SEL is enabled, review the SEL statistics on the DIMM to determine which threshold was crossed.
- Step 2** If necessary, replace the DIMM.

Step 3 If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: 371
mibFaultName: fltMemoryUnitInoperable
moClass: memory:Unit
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryUnitDisabled

Fault Code: F0372

Message

DIMM [location] on server [chassisId]/[slotId] operState: [operState]DIMM [location] on server [id] operaState: [operState]

Explanation

This fault is raised when the server BIOS disables a DIMM. The BIOS could disable a DIMM for several reasons, including incorrect location of the DIMM or incompatible speed.

Recommended Action

If you see this fault, refer to the Cisco FPR B-Series Troubleshooting Guide for information on how to resolve the DIMM issues.

Fault Details

```
Severity: major
Cause: equipment-disabled
mibFaultCode: 372
mibFaultName: fltMemoryUnitDisabled
moClass: memory:Unit
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryUnitThermalThresholdNonCritical

Fault Code: F0373

Message

DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory unit on a blade or rack server exceeds a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: info
Cause: thermal-problem
mibFaultCode: 373
mibFaultName: fltMemoryUnitThermalThresholdNonCritical
moClass: memory:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/memarray- [id]/mem- [id]
Affected MO: sys/rack-unit- [id]/board/memarray- [id]/mem- [id]
```

fltMemoryBufferUnitThermalThresholdNonCritical

Fault Code: F0374

Message

Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal]Buffer Unit [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory buffer unit on a blade or rack server exceeds a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: info
Cause: thermal-problem
mibFaultCode: 374
mibFaultName:fltMemoryBufferUnitThermalThresholdNonCritical
moClass: memory:BufferUnit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltMemoryUnitThermalThresholdCritical

Fault Code: F0375

Message

DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory unit on a blade or rack server exceeds a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 375
mibFaultName: fltMemoryUnitThermalThresholdCritical
moClass: memory:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryBufferUnitThermalThresholdCritical

Fault Code: F0376

Message

Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal]Buffer Unit [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory buffer unit on a blade or rack server exceeds a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 376
mibFaultName: fltMemoryBufferUnitThermalThresholdCritical
moClass: memory:BufferUnit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltMemoryUnitThermalThresholdNonRecoverable

Fault Code: F0377

Message

DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory unit on a blade or rack server has been out of the operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 377
mibFaultName: fltMemoryUnitThermalThresholdNonRecoverable
moClass: memory:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/memarray- [id]/mem- [id]
Affected MO: sys/rack-unit- [id]/board/memarray- [id]/mem- [id]
```

fltMemoryBufferUnitThermalThresholdNonRecoverable

Fault Code: F0378

Message

Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal]Buffer Unit [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a memory buffer unit on a blade or rack server has been out of the operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 378
mibFaultName: fltMemoryBufferUnitThermalThresholdNonRecoverable
moClass: memory:BufferUnit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltMemoryArrayVoltageThresholdNonCritical

Fault Code: F0379

Message

Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id] voltage: [voltage]

Explanation

This fault occurs when the memory array voltage is out of normal operating range, but hasn't yet reached a critical stage. Typically the memory array recovers itself from this situation.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the SEL is enabled, look at the SEL statistics on the DIMM to determine which threshold was crossed.
 - Step 2** Monitor the memory array for further degradation.
 - Step 3** If the fault occurs on a blade server memory array, remove the blade and re-insert into the chassis.
 - Step 4** In Cisco FPR Manager, decommission and recommission the server.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: voltage-problem
mibFaultCode: 379
mibFaultName: fltMemoryArrayVoltageThresholdNonCritical
mcClass: memory:Array
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/memarray- [id]
Affected MO: sys/rack-unit- [id]/board/memarray- [id]
```

fltMemoryArrayVoltageThresholdCritical**Fault Code: F0380****Message**

Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id]
voltage: [voltage]

Explanation

This fault occurs when the memory array voltage exceeds the specified hardware voltage rating

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the SEL is enabled, look at the SEL statistics on the DIMM to determine which threshold was crossed.
 - Step 2** Monitor the memory array for further degradation.
 - Step 3** If the fault occurs on a blade server memory array, remove the blade and re-insert into the chassis.
 - Step 4** In Cisco FPR Manager, decommission and recommission the server.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
```

```

Cause: voltage-problem
mibFaultCode: 380
mibFaultName: fltMemoryArrayVoltageThresholdCritical
moClass: memory:Array
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]

```

fltMemoryArrayVoltageThresholdNonRecoverable

Fault Code: F0381

Message

Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id] voltage: [voltage]

Explanation

This fault occurs when the memory array voltage exceeded the specified hardware voltage rating and potentially memory hardware may be in damage or jeopardy

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the SEL is enabled, review the SEL statistics on the DIMM to determine which threshold was crossed.
 - Step 2** Monitor the memory array for further degradation.
 - Step 3** If the fault occurs on a blade server memory array, remove the server from the chassis and re-insert it.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: voltage-problem
mibFaultCode: 381
mibFaultName: fltMemoryArrayVoltageThresholdNonRecoverable
moClass: memory:Array
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]

```

fltLsServerFailed

Fault Code: F0657

Message

Service profile [name] failed

Explanation

Server has failed. This fault typically occurs if the adapter power on self-test results in major and critical errors.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the server. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the server. In Cisco FPR Manager CLI, you can access the POST results through the **show post** command under the scope for the server.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: server-failed
mibFaultCode: 657
mibFaultName: fltLsServerFailed
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fltLsServerDiscoveryFailed

Fault Code: F0658

Message

Service profile [name] discovery failed

Explanation

The shallow discovery that occurs when the server associated with service profile fails. If the server is up and the data path is working, this fault typically occurs as a result of one of the following issues:

- Cisco FPR Manager cannot communicate with the CIMC on the server.
- The server cannot communicate with the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FSM tab and view the current state of the server and any FSM operations.
- Step 2** Check the error descriptions and see if any server components indicate a failure.
- Step 3** If the server or a server component has failed, do the following:
- a. Check the operational state of the server.
 - b. If the server is not operable, reacknowledge the server.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: discovery-failed
mibFaultCode: 658
mibFaultName: fltLsServerDiscoveryFailed
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fltLsServerConfigFailure**Fault Code: F0659****Message**

Service profile [name] configuration failed due to [configQualifier]

Explanation

The named configuration qualifier is not available. This fault typically occurs because Cisco FPR Manager cannot successfully deploy the service profile due to a lack of resources that meet the named qualifier. For example, this fault can occur if the following occurs:

- The service profile is configured for a server adapter with vHBAs, and the adapter on the server does not support vHBAs.
- The service profile is created from a template which includes a server pool, and the server pool is empty.
- The local disk configuration policy in the service profile specifies the No Local Storage mode, but the server contains local disks.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the status of the server pool associated with the service profile. If the pool is empty, add more blade servers to it.
- Step 2** Check the state of the server and ensure that it is in either the discovered or unassociated state.
- Step 3** If the server is associated or undiscovered, do one of the following:
- Discover the server.
 - Disassociate the server from the current service profile.
 - Select another server to associate with the service profile.
- Step 4** Review each policy in the service profile and verify that the selected server meets the requirements in the policy.
- Step 5** If the server does not meet the requirements of the service profile, do one of the following:
- Modify the service profile to match the server.
 - Select another server that does meet the requirements to associate with the service profile.

- Step 6** If you can verify that the server meets the requirements of the service profile, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: configuration-failure
mibFaultCode: 659
mibFaultName: fltLsServerConfigFailure
moClass: ls:Server
Type: server
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsServerMaintenanceFailed

Fault Code: F0660

Message

Service profile [name] maintenance failed

Explanation

Cisco FPR Manager currently does not use this fault.

Recommended Action

If you see this fault, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: maintenance-failed
mibFaultCode: 660
mibFaultName: fltLsServerMaintenanceFailed
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsServerRemoved

Fault Code: F0661

Message

Service profile [name] underlying resource removed

Explanation

Cisco FPR Manager cannot access the server associated with the service profile. This fault typically occurs as a result of one of the following issues:

- The server has been physically removed from the slot.
- The server is not available.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the server was removed from the slot, reinsert the server in the slot.
- Step 2** If the server was not removed, remove and reinsert the server. **NOTE:** If the server is operable, this action can be disruptive to current operations.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: equipment-removed
mibFaultCode: 661
mibFaultName:fltLsServerRemoved
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsServerInaccessible

Fault Code: F0662

Message

Service profile [name] cannot be accessed

Explanation

Cisco FPR Manager cannot communicate with the CIMC on the server. This fault typically occurs as a result of one of the following issues:

- The server port or ports have failed.
- The I/O module is offline.
- The BMC has failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If Cisco FPR Manager shows that the CIMC is down, physically reseal the server.
- Step 2** If Cisco FPR Manager shows that the server ports have failed, attempt to enable them.
- Step 3** If the I/O module is offline, check for faults on that component.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
```

```

Cause: server-inaccessible
mibFaultCode: 662
mibFaultName: fltLsServerInaccessible
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fltLsServerAssociationFailed

Fault Code: F0663

Message

Service profile [name] association failed for [pnDn]

Explanation

The service profile could not be associated with the server. This fault typically occurs because Cisco FPR Manager cannot communicate with one or more of the following:

- Fabric interconnect
- CIMC on the server
- SAS controller driver
- Server

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FSM tab for the server and service profile to determine why the association failed.
 - Step 2** If the server is stuck in an inappropriate state, such as booting, power cycle the server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: association-failed
mibFaultCode: 663
mibFaultName: fltLsServerAssociationFailed
moClass: ls:Server
Type: server
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```


fltLsComputeBindingAssignmentRequirementsNotMet

Fault Code: F0664

Message

Assignment of service profile [name] to server [pnDn] failed

Explanation

The server could not be assigned to the selected service profile. This fault typically occurs as a result of one of the following issues:

- The selected server does not meet the requirements of the service profile.
- If the service profile was configured for restricted migration, the selected server does not match the currently or previously assigned server.

Recommended Action

If you see this fault, select a different server that meets the requirements of the service profile or matches the currently or previously assigned server.

Fault Details

```
Severity: minor
Cause: assignment-failed
mibFaultCode: 664
mibFaultName: fltLsComputeBindingAssignmentRequirementsNotMet
moClass: ls:ComputeBinding
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name] /pn
Affected MO: org- [name] /ls- [name] /pn-req
Affected MO: org- [name] /tier- [name] /ls- [name] /pn
Affected MO: org- [name] /tier- [name] /ls- [name] /pn-req
```

fltLsServerUnassociated

Fault Code: F0665

Message

Service profile [name] is not associated

Explanation

The service profile has not yet been associated with a server or a server pool. This fault typically occurs as a result of one of the following issues:

- There is no acceptable server in the server pool.
- The association failed.

Recommended Action

If you see this fault, take the following actions:

Step 1 If you did not intend to associate the service profile, ignore the fault.

- Step 2** If you did intend to associate the service profile, check the association failure fault.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: unassociated
mibFaultCode: 665
mibFaultName: fltLsServerUnassociated
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsServerSvnicNotPresent

Fault Code: F0666

Message

Service profile [name] does not contain service vnics for netflow.

Explanation

The service profile does not have service vnics, hence netflow will not function on this server. This fault typically occurs as a result of one of the following issues:

- Service profile has maximum number of vnics already created, hence cannot accommodate service vnics required for netflow.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If you have already enabled netflow, please reduce the number of vnics on the SP to accommodate service vnics.
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: svnic-not-present
mibFaultCode: 666
mibFaultName: fltLsServerSvnicNotPresent
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsServerServer-unfulfilled

Fault Code: F0667

Message

Server [pnDn] does not fulfill Service profile [name] due to [configQualifier]

Explanation

The server no longer meets the qualification requirements of the service profile. This fault typically occurs as a result of one of the following issues:

- The server has been physically changed.
- A required component of the server has failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the server inventory compare to the service profile qualifications.
- Step 2** If the server inventory does not match the service profile qualifications, do one of the following:
- Associate the server with a different service profile.
 - Ensure the server has sufficient resources to qualify for the current service profile.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: server-failed
mibFaultCode: 667
mibFaultName: fltLsServerServerUnfulfilled
moClass: ls:Server
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fltLsmaintMaintPolicyUnresolvableScheduler

Fault Code: F0668

Message

Schedule [schedName] referenced by maintenance policy [name] does not exist

Explanation

The schedule that is referenced by the maintenance policy does not exist. This fault typically occurs as a result of one of the following issues:

- The schedule does not exist.
- The schedule was deleted.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check if the named schedule exists. If it is deleted or missing, try to create it.
 - Step 2** If the named schedule is deleted or missing, recreate it.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: non-existent-scheduler
mibFaultCode: 668
mibFaultName: fltLsmaintMaintPolicyUnresolvableScheduler
moClass: lsmaint:MaintPolicy
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/maint- [name]

```

fltLsIssuesKvmPolicyUnsupported

Fault Code: F0669

Message

Kvm mgmt policy not supported by current CIMC version

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: minor
Cause: unsupported-cimc-firmware
mibFaultCode: 669
mibFaultName: fltLsIssuesKvmPolicyUnsupported
moClass: ls:Issues
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]/config-issue
Affected MO: org- [name]/tier- [name]/ls- [name]/config-issue

```

fltIqnpoolPoolEmpty

Fault Code: F0675

Message

iqn pool [name] is empty

Explanation

This fault typically occurs when an IQN pool does not contain any IQNs.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the pool is in use, add a block of IQNs to the pool.
 - Step 2** If the pool is not in use, ignore the fault.

Fault Details

```
Severity: minor
Cause: empty-pool
mibFaultCode: 675
mibFaultName: fltIqnpoolPoolEmpty
moClass: iqnpool:Pool
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/iqn-pool- [name]
```

fltEtherSwitchIntFloSatellite-connection-absent

Fault Code: F0687

Message

No link between IOM port [chassisId]/[slotId]/[portId] and fabric interconnect [switchId]:[peerSlotId]/[peerPortId]

Explanation

This fault is raised when an I/O module fabric port, which links the I/O module port and the fabric interconnect, is not functional

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify the fabric interconnect-chassis topology. Make sure each I/O module is connected to only one fabric interconnect.
 - Step 2** Ensure that the fabric interconnect server port is configured and enabled.
 - Step 3** Ensure that the links are plugged in properly and reacknowledge the chassis.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: satellite-connection-absent
mibFaultCode: 687
mibFaultName: fltEtherSwitchIntFioSatelliteConnectionAbsent
moClass: ether:SwitchIntFio
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]

```

fltEtherSwitchIntFioSatellite-wiring-problem**Fault Code: F0688****Message**

Invalid connection between IOM port [chassisId]/[slotId]/[portId] and fabric interconnect [switchId]:[peerSlotId]/[peerPortId]

Explanation

This fault typically occurs as a result of a satellite wiring problem on the network-facing interface of an I/O module and Cisco FPR Manager detects that at least one IOM uplink is misconnected to one of the fabric interconnect ports.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify the fabric interconnect-chassis topology. Make sure each I/O module is connected to only one fabric interconnect.
 - Step 2** Ensure that the links are plugged in properly and re-acknowledge the chassis.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: satellite-mis-connected
mibFaultCode: 688
mibFaultName: fltEtherSwitchIntFioSatelliteWiringProblem
moClass: ether:SwitchIntFio
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]

```

fltEtherSwitchIntFloSatellite-wiring-numbers-unexpected

Fault Code: F0689

Message

Chassis discovery policy conflict: Link IOM [chassisId]/[slotId]/[portId] to fabric interconnect [switchId]:[peerSlotId]/[peerPortId] not configured

Explanation

The configuration of the chassis discovery policy conflicts with the physical IOM uplinks. Cisco FPR Manager raises this fault when the chassis discovery policy is configured for more links than are physically cabled between the IOM uplinks on the chassis and the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Ensure that you cable at least the same number of IOM uplinks as are configured in the chassis discovery policy, and that you configure the corresponding server ports on the fabric interconnect.
 - Step 2** Reacknowledge the chassis.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: info
Cause: unexpected-number-of-links
mibFaultCode: 689
mibFaultName: fltEtherSwitchIntFloSatelliteWiringNumbersUnexpected
moClass: ether:SwitchIntFio
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltEquipmentPsuPowerSupplyProblem

Fault Code: F0690

Message

Power supply [id] in chassis [id] power: [power]Power supply [id] in fabric interconnect [id] power: [power]Power supply [id] in fex [id] power: [power]Power supply [id] in server [id] power: [power]

Explanation

This fault typically occurs when Cisco FPR Manager detects a problem with a power supply unit in a chassis, fabric interconnect or a FEX. For example, the PSU is not functional.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the power cord is properly connected to the PSU and the power source.
 - Step 2** Verify that the power source is 220 volts.
 - Step 3** Verify that the PSU is properly installed in the chassis or fabric interconnect.
 - Step 4** Remove the PSU and reinstall it.
 - Step 5** Replace the PSU.
 - Step 6** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: power-problem
mibFaultCode: 690
mibFaultName: fltEquipmentPsuPowerSupplyProblem
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuOffline

Fault Code: F0691

Message

Power supply [id] in chassis [id] power: [power]Power supply [id] in fabric interconnect [id] power: [power]Power supply [id] in fex [id] power: [power]Power supply [id] in server [id] power: [power]

Explanation

This fault typically occurs when Cisco FPR Manager detects that a power supply unit in a chassis, fabric interconnect, or FEX is offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the power cord is properly connected to the PSU and the power source.
 - Step 2** Verify that the power source is 220 volts.
 - Step 3** Verify that the PSU is properly installed in the chassis or fabric interconnect.
 - Step 4** Remove the PSU and reinstall it.
 - Step 5** Replace the PSU.
 - Step 6** If the above actions did not resolve the issue, note down the type of PSU, execute the **show tech-support** command, and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: equipment-offline

```



```

mibFaultCode: 691
mibFaultName: fltEquipmentPsuOffline
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuPowerSupplyShutdown

Fault Code: F0692

Message

Power supply [id] in chassis [id] shutdown reason:[powerStateQualifier]

Explanation

This fault typically occurs when a power supply unit in a chassis, fabric interconnect, or a FEX is shut down, either due to higher than expected power current, higher than expected temperatures, or the failure of a fan.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Verify that the power cord is properly connected to the PSU and the power source.
 - Step 7** Verify that the power source is 220 volts.
 - Step 8** Verify that the PSU is properly installed in the chassis or fabric interconnect.
 - Step 9** Remove the PSU and reinstall it.
 - Step 10** Replace the PSU.
 - Step 11** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-offline
mibFaultCode: 692
mibFaultName: fltEquipmentPsuPowerSupplyShutdown
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true

```

Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

fltEquipmentChassisIdentity-unestablishable

Fault Code: F0693

Message

Chassis [id] has an invalid FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported chassis. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 2** If the above action did not resolve the issue, execute the **show tech-support** command and contact Cisco technical support.

Fault Details

Severity: major
Cause: identity-unestablishable
mibFaultCode: 693
mibFaultName: fltEquipmentChassisIdentityUnestablishable
moClass: equipment:Chassis
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

fltEquipmentFexIdentity-unestablishable

Fault Code: F0694

Message

Fex [id] has an invalid FRU

Explanation

This fault typically occurs because Cisco FPR Manager detected an unsupported chassis. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.

- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: identity-unestablishable
mibFaultCode: 694
mibFaultName: fltEquipmentFexIdentityUnestablishable
moClass: equipment:Fex
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fex-[id]
```

fltEquipmentFexFex-unsupported

Fault Code: F0695

Message

Fex [id] with model [model] is unsupported

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported FEX. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that a supported FEX is installed.
- Step 2** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: fex-unsupported
mibFaultCode: 695
mibFaultName: fltEquipmentFexFexUnsupported
moClass: equipment:Fex
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fex-[id]
```

fltEquipmentFanModuleDegraded

Fault Code: F0696

Message

Fan module [tray]-[id] in chassis [id] operability: [operability]Fan module [tray]-[id] in server [id] operability: [operability]Fan module [tray]-[id] in fabric interconnect [id] operability: [operability]

Explanation

This fault occurs when a fan module is not operational.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the fan module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the fan module has adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows for the fan module are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: equipment-degraded
mibFaultCode: 696
mibFaultName: fltEquipmentFanModuleDegraded
moClass: equipment:FanModule
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]

```

fltEquipmentFanDegraded

Fault Code: F0697

Message

Fan [id] in Fan Module [tray]-[id] under chassis [id] operability: [operability]Fan [id] in fabric interconnect [id] operability: [operability]Fan [id] in fex [id] operability: [operability]Fan [id] in Fan Module [tray]-[id] under server [id] operability: [operability]

Explanation

This fault occurs when one or more fans in a fan module are not operational, but at least one fan is operational.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the fan module.
- Step 2** Review the Cisco FPR Site Preparation Guide and ensure the fan module has adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace the faulty fan modules.
- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: 697
mibFaultName: fltEquipmentFanDegraded
moClass: equipment:Fan
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentChassisInoperable

Fault Code: F0698

Message

Chassis [id] operability: [operability]

Explanation

This fault typically occurs for one of the following reasons:

- The fabric interconnect cannot communicate with a chassis. For a cluster configuration, this fault means that neither fabric interconnect can communicate with the chassis.
- The chassis has an invalid FRU.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In Cisco FPR Manager, reacknowledge the chassis that raised the fault.
 - Step 2** Physically unplug and replug the power cord into the chassis.
 - Step 3** Verify that the I/O modules are functional.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-inoperable
mibFaultCode: 698
mibFaultName: fltEquipmentChassisInoperable
moClass: equipment:Chassis
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]

```

fltEquipmentFanModuleInoperable

Fault Code: F0700

Message

Fan module [tray]-[id] in chassis [id] operability: [operability]Fan module [tray]-[id] in server [id] operability: [operability]Fan module [tray]-[id] in fabric interconnect [id] operability: [operability]

Explanation

This fault occurs if a fan module is not operational.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove and reinstall the fan module. If multiple fans are affected by this fault, remove and reinstall one fan module at a time.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-inoperable
mibFaultCode: 700
mibFaultName: fltEquipmentFanModuleInoperable
moClass: equipment:FanModule
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/fan-module- [tray]- [id]
Affected MO: sys/rack-unit- [id]/fan-module- [tray]- [id]
Affected MO: sys/switch- [id]/fan-module- [tray]- [id]

```

fltEquipmentFanInoperable

Fault Code: F0701

Message

Fan [id] under chassis [id] operability: [operability]Fan [id] in fabric interconnect [id] operability: [operability]Fan [id] in fex [id] operability: [operability]Fan [id] in Fan Module [tray]-[id] under server [id] operability: [operability]

Explanation

This fault occurs if a fan is not operational.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove fan module and re-install the fan module again. Remove only one fan module at a time.
 - Step 2** Replace fan module with a different fan module
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: 701
mibFaultName: fltEquipmentFanInoperable
moClass: equipment:Fan
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentPsuInoperable

Fault Code: F0702

Message

Power supply [id] in chassis [id] operability: [operability]Power supply [id] in fabric interconnect [id] operability: [operability]Power supply [id] in fex [id] operability: [operability]Power supply [id] in server [id] operability: [operability]

Explanation

This fault typically occurs when Cisco FPR Manager detects a problem with a power supply unit in a chassis, fabric interconnect or a FEX. For example, the PSU is not functional.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the power cord is properly connected to the PSU and the power source.
 - Step 2** Verify that the power source is 220 volts.
 - Step 3** Verify that the PSU is properly installed in the chassis or fabric interconnect.
 - Step 4** Remove the PSU and reinstall it.
 - Step 5** Replace the PSU.
 - Step 6** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-inoperable
mibFaultCode: 702
mibFaultName: fltEquipmentPsuInoperable
moClass: equipment:Psu
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentIOCardRemoved

Fault Code: F0703

Message

[side] IOM [chassisId]/[id] ([switchId]) is removed

Explanation

This fault typically occurs because an I/O module is removed from the chassis. In a cluster configuration, the chassis fails over to the other I/O module. For a standalone configuration, the chassis associated with the I/O module loses network connectivity. This is a critical fault because it can result in the loss of network connectivity and disrupt data traffic through the I/O module.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reinsert the I/O module and configure the fabric-interconnect ports connected to it as server ports and wait a few minutes to see if the fault clears.
 - Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-removed
mibFaultCode: 703
mibFaultName: fltEquipmentIOCardRemoved
moClass: equipment:IOCard
Type: equipment
Callhome: none

```



```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fltEquipmentIOCardInaccessible

Fault Code: F0704

Message

[side] IOM [chassisId]/[id] ([switchId]) is inaccessible

Explanation

This fault typically occurs because an I/O module has lost its connection to the fabric interconnects. In a cluster configuration, the chassis fails over to the other I/O module. For a standalone configuration, the chassis associated with the I/O module loses network connectivity. This is a critical fault because it can result in the loss of network connectivity and disrupt data traffic through the I/O module.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Wait a few minutes to see if the fault clears. This is typically a temporary issue, and can occur after a firmware upgrade.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-inaccessible
mibFaultCode: 704
mibFaultName: fltEquipmentIOCardInaccessible
moClass: equipment:IOCard
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fltEquipmentIOCardPost-failure

Fault Code: F0705

Message

[side] IOM [chassisId]/[id] ([switchId]) POST failure

Explanation

This fault typically occurs when an I/O module encounters errors during the Power On Self Test (POST). The impact of this fault varies according to the errors that were encountered during POST.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the I/O module. In Cisco FPR Manager GUI, you can access the POST results from the General tab for the I/O module. In Cisco FPR Manager CLI, you can access the POST results through the show post command under the scope for the I/O module.
 - Step 2** If the POST results indicate FRU error, check if FPR manager has raised fault for the FRU and follow recommended action for the fault.
 - Step 3** Otherwise, reboot the I/O module.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-problem
mibFaultCode: 705
mibFaultName: fltEquipmentIOCardPostFailure
moClass: equipment:IOCard
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id]
Affected MO: sys/fex- [id] /slot- [id]

```

fltEquipmentFexPost-failure

Fault Code: F0706

Message

fex [id] POST failure

Explanation

This fault typically occurs when a FEX encounters errors during the Power On Self Test (POST). The impact of this fault varies depending on which errors were encountered during POST.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the POST results for the FEX. In the Cisco FPR Manager GUI, you can access the POST results from the General tab for the FEX. In the Cisco FPR Manager CLI, you can access the POST results by entering the **show post** command under the scope for the FEX.
 - Step 2** Reboot the FEX.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-problem
mibFaultCode: 706
mibFaultName: fltEquipmentFexPostFailure
moClass: equipment:Fex
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true

```

Affected MO: sys/fex-[id]

fltEquipmentFanModuleMissing

Fault Code: F0707

Message

Fan module [tray]-[id] in chassis [id] presence: [presence]Fan module [tray]-[id] in server [id] presence: [presence]Fan module [tray]-[id] in fabric interconnect [id] presence: [presence]

Explanation

This fault occurs if a fan Module slot is not equipped or removed from its slot

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the reported slot is empty, insert a fan module into the slot.
 - Step 2** If the reported slot contains a fan module, remove and reinsert the fan module.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: critical
Cause: equipment-missing
mibFaultCode: 707
mibFaultName: fltEquipmentFanModuleMissing
moClass: equipment:FanModule
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]

fltEquipmentFanMissing

Fault Code: F0708

Message

Fan [id] in fabric interconnect [id] presence: [presence]Fan [id] in fex [id] presence: [presence]Fan [id] in Fan Module [tray]-[id] under server [id] presence: [presence]

Explanation

This fault occurs in the unlikely event that a fan in a fan module cannot be detected.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Insert/reinsert the fan module in the slot that is reporting the issue.

- Step 2** Replace the fan module with a different fan module, if available.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-missing
mibFaultCode: 708
mibFaultName: fltEquipmentFanMissing
moClass: equipment:Fan
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /fan- [id]
Affected MO: sys/chassis- [id] /fan-module- [tray] - [id] /fan- [id]
Affected MO: sys/fex- [id] /fan- [id]
Affected MO: sys/rack-unit- [id] /fan-module- [tray] - [id] /fan- [id]
Affected MO: sys/switch- [id] /fan- [id]
Affected MO: sys/switch- [id] /fan-module- [tray] - [id] /fan- [id]

```

fltEquipmentPsuMissing

Fault Code: F0709

Message

Power supply [id] in chassis [id] presence: [presence]Power supply [id] in fabric interconnect [id] presence: [presence]Power supply [id] in fex [id] presence: [presence]Power supply [id] in server [id] presence: [presence]

Explanation

This fault typically occurs when Cisco FPR Manager detects a problem with a power supply unit in a chassis, fabric interconnect, or a FEX. For example, the PSU is missing.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the PSU is physically present in the slot, remove and then reinsert it.
- Step 2** If the PSU is not physically present in the slot, insert a new PSU.
- Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-missing
mibFaultCode: 709
mibFaultName: fltEquipmentPsuMissing
moClass: equipment:Psu
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

```

fltEquipmentIOCardThermalProblem

Fault Code: F0710

Message

[side] IOM [chassisId]/[id] ([switchId]) operState: [operState]

Explanation

This fault occurs when there is a thermal problem on an I/O module. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the I/O module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the I/O modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace faulty I/O modules.
- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 710
mibFaultName: fltEquipmentIOCardThermalProblem
moClass: equipment:IOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardThermalThresholdNonCritical

Fault Code: F0711

Message

[side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an I/O module has exceeded a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the I/O module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and I/O modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows on the Cisco FPR chassis and I/O module are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 711
mibFaultName: fltEquipmentIOCardThermalThresholdNonCritical
moClass: equipment:IOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardThermalThresholdCritical

Fault Code: F0712

Message

[side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an I/O module has exceeded a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the I/O module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and I/O modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows on the Cisco FPR chassis and I/O module are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace the faulty I/O modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 712
mibFaultName: fltEquipmentIOCardThermalThresholdCritical
moClass: equipment:IOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardThermalThresholdNonRecoverable

Fault Code: F0713

Message

[side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an I/O module has been out of the operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the I/O module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and I/O modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows on the Cisco FPR chassis and I/O module are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace the faulty I/O modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 713
mibFaultName: fltEquipmentIOCardThermalThresholdNonRecoverable
moClass: equipment:IOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```


fltEquipmentFanModuleThermalThresholdNonCritical

Fault Code: F0714

Message

Fan module [tray]-[id] in chassis [id] temperature: [thermal]Fan module [tray]-[id] in server [id] temperature: [thermal]Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a fan module has exceeded a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the fan module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the fan modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace faulty fan modules.
- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 714
mibFaultName: fltEquipmentFanModuleThermalThresholdNonCritical
moClass: equipment:FanModule
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuThermalThresholdNonCritical

Fault Code: F0715

Message

Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a PSU module has exceeded a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the PSU module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the PSU modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace faulty PSU modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 715
mibFaultName: fltEquipmentPsuThermalThresholdNonCritical
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentFanModuleThermalThresholdCritical

Fault Code: F0716

Message

Fan module [tray]-[id] in chassis [id] temperature: [thermal]Fan module [tray]-[id] in server [id] temperature: [thermal]Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a fan module has exceeded a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the fan module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the fan modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace faulty fan modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 716
mibFaultName: fltEquipmentFanModuleThermalThresholdCritical
moClass: equipment:FanModule
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuThermalThresholdCritical

Fault Code: F0717

Message

Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a PSU module has exceeded a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the PSU module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the PSU modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace faulty PSU modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 717
mibFaultName: fltEquipmentPsuThermalThresholdCritical
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentFanModuleThermalThresholdNonRecoverable

Fault Code: F0718

Message

Fan module [tray]-[id] in chassis [id] temperature: [thermal]Fan module [tray]-[id] in server [id] temperature: [thermal]Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a fan module has been out of operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the fan module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the fan modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace faulty fan modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 718
mibFaultName: fltEquipmentFanModuleThermalThresholdNonRecoverable
moClass: equipment:FanModule
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuThermalThresholdNonRecoverable

Fault Code: F0719

Message

Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a PSU module has been out of operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the PSU module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the PSU modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace faulty PSU modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 719
mibFaultName: fltEquipmentPsuThermalThresholdNonRecoverable
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentPsuVoltageThresholdNonCritical

Fault Code: F0720

Message

Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]

Explanation

This fault occurs when the PSU voltage is out of normal operating range, but hasn't reached to a critical stage yet. Normally the PSU will recover itself from this situation.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the PSU for further degradation.
 - Step 2** Remove and reseal the PSU.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: voltage-problem
mibFaultCode: 720
mibFaultName: fltEquipmentPsuVoltageThresholdNonCritical
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentPsuVoltageThresholdCritical

Fault Code: F0721

Message

Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]

Explanation

This fault occurs when the PSU voltage has exceeded the specified hardware voltage rating.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove and reseal the PSU.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: voltage-problem
mibFaultCode: 721
mibFaultName: fltEquipmentPsuVoltageThresholdCritical
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

```

fltEquipmentPsuVoltageThresholdNonRecoverable

Fault Code: F0722

Message

Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]

Explanation

This fault occurs when the PSU voltage has exceeded the specified hardware voltage rating and PSU hardware may have been damaged as a result or may be at risk of being damaged.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove and reseal the PSU.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: voltage-problem
mibFaultCode: 722
mibFaultName: fltEquipmentPsuVoltageThresholdNonRecoverable
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

```


fltEquipmentPsuPerfThresholdNonCritical

Fault Code: F0723

Message

Power supply [id] in chassis [id] output power: [perf]Power supply [id] in fabric interconnect [id] output power: [perf]Power supply [id] in server [id] output power: [perf]

Explanation

This fault is raised as a warning if the current output of the PSU in a chassis, fabric interconnect, or rack server does not match the desired output value.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the PSU status.
 - Step 2** If possible, remove and reseal the PSU.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file for the chassis and Cisco FPR Manager, and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: performance-problem
mibFaultCode: 723
mibFaultName: fltEquipmentPsuPerfThresholdNonCritical
moClass: equipment:Psu
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentPsuPerfThresholdCritical

Fault Code: F0724

Message

Power supply [id] in chassis [id] output power: [perf]Power supply [id] in fabric interconnect [id] output power: [perf]Power supply [id] in server [id] output power: [perf]

Explanation

This fault occurs if the current output of the PSU in a chassis, fabric interconnect, or rack server is far below or above the desired output value.

Recommended Action

If you see this fault, take the following actions:

- Step 1** Monitor the PSU status.
- Step 2** Plan to replace the PSU as soon as possible.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file for the chassis and Cisco FPR Manager, and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: performance-problem
mibFaultCode: 724
mibFaultName: fltEquipmentPsuPerfThresholdCritical
moClass: equipment:Psu
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

```

fltEquipmentPsuPerfThresholdNonRecoverable

Fault Code: F0725

Message

Power supply [id] in chassis [id] output power: [perf]Power supply [id] in fabric interconnect [id] output power: [perf]Power supply [id] in server [id] output power: [perf]

Explanation

This fault occurs if the current output of the PSU in a chassis, fabric interconnect, or rack server is far above or below the non-recoverable threshold value.

Recommended Action

If you see this fault, plan to replace the PSU as soon as possible.

Fault Details

```

Severity: critical
Cause: performance-problem
mibFaultCode: 725
mibFaultName: fltEquipmentPsuPerfThresholdNonRecoverable
moClass: equipment:Psu
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

```

fltEquipmentFanPerfThresholdNonCritical

Fault Code: F0726

Message

Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]

Explanation

This fault occurs when the fan speed reading from the fan controller does not match the desired fan speed and is outside of the normal operating range. This can indicate a problem with a fan or with the reading from the fan controller.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the fan status.
 - Step 2** If the problem persists for a long period of time or if other fans do not show the same problem, reseal the fan.
 - Step 3** Replace the fan module.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: info
Cause: performance-problem
mibFaultCode: 726
mibFaultName: fltEquipmentFanPerfThresholdNonCritical
moClass: equipment:Fan
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentFanPerfThresholdCritical

Fault Code: F0727

Message

Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]

Explanation

This fault occurs when the fan speed read from the fan controller does not match the desired fan speed and has exceeded the critical threshold and is in risk of failure. This can indicate a problem with a fan or with the reading from the fan controller.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the fan status.
- Step 2** If the problem persists for a long period of time or if other fans do not show the same problem, reseal the fan.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file for the chassis and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: performance-problem
mibFaultCode: 727
mibFaultName: fltEquipmentFanPerfThresholdCritical
moClass: equipment:Fan
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

```

fltEquipmentFanPerfThresholdNonRecoverable

Fault Code: F0728

Message

Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]

Explanation

This fault occurs when the fan speed read from the fan controller has far exceeded the desired fan speed. It frequently indicates that the fan has failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Replace the fan.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: performance-problem
mibFaultCode: 728
mibFaultName: fltEquipmentFanPerfThresholdNonRecoverable
moClass: equipment:Fan
Type: equipment
Callhome: diagnostic

```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

```

fltEquipmentFanPerfThresholdLowerNonRecoverable

Fault Code: F0729

Message

Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]

Explanation

This fault occurs when the fan speed reading from the fan controller is far below the desired fan speed, and the fan has likely failed.

Recommended Action

If you see this fault, create a detailed **show tech-support** file for the chassis and replace the fan module. If necessary, contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: performance-problem
mibFaultCode: 729
mibFaultName: fltEquipmentFanPerfThresholdLowerNonRecoverable
moClass: equipment:Fan
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-[id]
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

```

fltEquipmentIOCardFirmwareUpgrade

Fault Code: F0730

Message

Chassis controller in IOM [chassisId]/[id] ([switchId]) firmware upgrade problem: [upgradeStatus]

Explanation

This fault typically occurs when an IOM upgrade fails.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** On the FSM tab for the IOM, verify whether FSM for the upgrade completed successfully or failed.
 - Step 2** If the FSM failed, review the error message in the FSM.
 - Step 3** If the error message is self explanatory, verify the physical connectivity. For example, an error message could be No Connection to Endpoint or Link Down.
 - Step 4** If the above action did not resolve the issue and the fault persists, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: firmware-upgrade-problem
mibFaultCode: 730
mibFaultName: fltEquipmentIOCardFirmwareUpgrade
moClass: equipment:IOCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentChassisUnsupportedConnectivity

Fault Code: F0731

Message

Current connectivity for chassis [id] does not match discovery policy: [configState]

Explanation

This fault typically occurs when the current connectivity for a chassis does not match the configuration in the chassis discovery policy.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the correct number of links are configured in the chassis discovery policy.
 - Step 2** Check the state of the I/O module links.
 - Step 3** Reacknowledge the chassis.
 - Step 4** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: unsupported-connectivity-configuration
mibFaultCode: 731
mibFaultName: fltEquipmentChassisUnsupportedConnectivity
moClass: equipment:Chassis
Type: connectivity
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fltEquipmentChassisUnacknowledged

Fault Code: F0732

Message

Chassis [id] connectivity configuration: [configState]

Explanation

This fault typically occurs when or more of the I/O module links from the chassis are unacknowledged.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the state of the I/O module links.
 - Step 2** Reacknowledge the chassis.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: equipment-unacknowledged
mibFaultCode: 732
mibFaultName: fltEquipmentChassisUnacknowledged
moClass: equipment:Chassis
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fltEquipmentIOCardUnsupportedConnectivity

Fault Code: F0733

Message

IOM [chassisId]/[id] ([switchId]) current connectivity does not match discovery policy or connectivity is unsupported: [configState]

Explanation

This fault typically occurs when the current connectivity for an I/O module does not match the configuration in the chassis discovery policy.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the correct number of links are configured in the chassis discovery policy.

- Step 2** Check the state of the I/O module links.
- Step 3** Note that atleast 2 links are required to be connected between FEX and 61xx Fabric Interconnect
- Step 4** Reacknowledge the chassis.
- Step 5** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: unsupported-connectivity-configuration
mibFaultCode: 733
mibFaultName: fltEquipmentIOCardUnsupportedConnectivity
moClass: equipment:IOCard
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fltEquipmentIOCardAutoUpgradingFirmware

Fault Code: F0734

Message

IOM [chassisId]/[id] ([switchId]) is auto upgrading firmware

Explanation

This fault typically occurs when an I/O module is auto upgrading. Auto-upgrade occurs when the firmware version on the IOM is incompatible with the firmware version on the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the IOM and fabric interconnects are not running the same firmware version, wait for the auto-upgrade to complete.
 - Step 2** When the IOM upgrade is completed, verify that Cisco FPR Manager has cleared this fault.
 - Step 3** If you see this fault after the IOM overall status changes to operable, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: auto-firmware-upgrade
mibFaultCode: 734
mibFaultName: fltEquipmentIOCardAutoUpgradingFirmware
moClass: equipment:IOCard
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```


fltEquipmentIOCardUnacknowledged

Fault Code: F0735

Message

IOM [chassisId]/[id] ([switchId]) connectivity configuration: [configState]

Explanation

This fault typically occurs when an I/O module is unacknowledged.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the state of the I/O module links.
 - Step 2** Reacknowledge the chassis.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: equipment-unacknowledged
mibFaultCode: 735
mibFaultName: fltEquipmentIOCardUnacknowledged
moClass: equipment:IOCard
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardPeerDisconnected

Fault Code: F0736

Message

IOM [chassisId]/[id] ([switchId]) peer connectivity: [peerCommStatus]

Explanation

This fault typically occurs when an I/O module is unable to communicate with its peer I/O module.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Wait a few minutes to see if the fault clears. This is typically a temporary issue, and can occur after a firmware upgrade.
 - Step 2** If the fault does not clear after a few minutes, remove and reinsert the I/O module.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: warning
Cause: equipment-disconnected
mibFaultCode: 736
mibFaultName:fltEquipmentIOCardPeerDisconnected
moClass: equipment:IOCard
Type: connectivity
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id]
Affected MO: sys/fex- [id] /slot- [id]

fltEquipmentChassisIdentity**Fault Code: F0737****Message**

Chassis [id] has a mismatch between FRU identity reported by Fabric/IOM vs. FRU identity reported by CMC

Explanation

This fault typically occurs when the FRU information for an I/O module is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: critical
Cause: fru-problem
mibFaultCode: 737
mibFaultName:fltEquipmentChassisIdentity
moClass: equipment:Chassis
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]

fltEquipmentChassisInvalid-fru**Fault Code: F0738****Message**

Chassis [id] has a empty value for FRU identity reported by CMC.

Explanation

This fault typically occurs when the FRU information for a chassis has empty value.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: fru-problem
mibFaultCode: 738
mibFaultName: fltEquipmentChassisInvalidFru
moClass: equipment:Chassis
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisPowerProblem

Fault Code: F0739

Message

Power state on chassis [id] is [power]

Explanation

This fault typically occurs when the chassis fails to meet the minimal power requirements defined in the power policy or when one or more power supplies have failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In Cisco FPR Manager, verify that all PSUs for the chassis are functional.
 - Step 2** Verify that all PSUs are seated properly within the chassis and are powered on.
 - Step 3** Physically unplug and replug the power cord into the chassis.
 - Step 4** If all PSUs are operating at maximum capacity, either add more PSUs to the chassis or redefine the power policy in Cisco FPR Manager.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: power-problem
mibFaultCode: 739
mibFaultName: fltEquipmentChassisPowerProblem
moClass: equipment:Chassis
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdCritical

Fault Code: F0740

Message

Chassis thermal state is [thermal]. [faultMsg]

Explanation

This fault occurs under the following conditions:

-
- Step 1** If a component within a chassis is operating outside the safe thermal operating range.
 - Step 2** If the chassis controller in the IOM is unable to determine the thermal condition of a blade server, the **show tech-support** file for the chassis provides a more detailed report of the most severe thermal conditions currently applicable for that chassis.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the temperature readings for the blade servers and IOM and ensure they are within the recommended thermal safe operating range.
 - Step 2** If the fault reports a "Thermal Sensor threshold crossing in blade" error for one or more blade servers, check if DIMM or processor temperature related faults have been raised against that blade.
 - Step 3** If the fault reports a "Thermal Sensor threshold crossing in IOM" error for one or both the IOMs, check if thermal faults have been raised against that IOM. Those faults include details of the thermal condition.
 - Step 4** If the fault reports a "Missing or Faulty Fan" error, check on the status of that fan. If it needs replacement, create a **show tech-support** file for the chassis and contact Cisco TAC.
 - Step 5** If the fault reports a "No connectivity between IOM and blade" or "Thermal Sensor readings unavailable from blade" error, check if that blade server is operational and whether any faults have been raised against that blade server. In this situation, the chassis controller may go into a fail-safe operating mode and the fan speeds may increase as a precautionary measure.
 - Step 6** If the above actions did not resolve the issue and the condition persists, create a **show tech-support** file for Cisco FPR Manager and the chassis and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 740
mibFaultName: fltEquipmentChassisThermalThresholdCritical
moClass: equipment:Chassis
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdNonCritical

Fault Code: F0741

Message

Thermal condition on chassis [id]. [thermalStateQualifier]

Explanation

FPRM raises this fault under the following conditions:

-
- Step 1** If a component within a chassis is operating outside the safe thermal operating range.
 - Step 2** If the chassis controller in the IOM is unable to determine the thermal condition of a blade server, the **show tech-support** file for the chassis provides a more detailed report of the most severe thermal conditions currently applicable for that chassis.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the temperature readings for the blade servers and IOM and ensure they are within the recommended thermal safe operating range.
 - Step 2** If the fault reports a "Thermal Sensor threshold crossing in blade" error for one or more blade servers, check if DIMM or processor temperature related faults have been raised against that blade.
 - Step 3** If the fault reports a "Thermal Sensor threshold crossing in IOM" error for one or both the IOMs, check if thermal faults have been raised against that IOM. Those faults include details of the thermal condition.
 - Step 4** If the fault reports a "Missing or Faulty Fan" error, check on the status of that fan. If it needs replacement, create a **show tech-support** file for the chassis and contact Cisco TAC.
 - Step 5** If the fault reports a "No connectivity between IOM and blade" or "Thermal Sensor readings unavailable from blade" error, check if that blade server is operational and whether any faults have been raised against that blade server. In this situation, the chassis controller may go into a fail-safe operating mode and the fan speeds may increase as a precautionary measure.
 - Step 6** If the above actions did not resolve the issue and the condition persists, create a **show tech-support** file for Cisco FPR Manager and the chassis and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 741
mibFaultName: fltEquipmentChassisThermalThresholdNonCritical
moClass: equipment:Chassis
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdNonRecoverable

Fault Code: F0742

Message

Thermal condition on chassis [id]. [thermalStateQualifier]

Explanation

FPRM raises this fault under the following conditions:

-
- Step 1** If a component within a chassis is operating outside the safe thermal operating range.
 - Step 2** If the chassis controller in the IOM is unable to determine the thermal condition of a blade server, the **show tech-support** file for the chassis provides a more detailed report of the most severe thermal conditions currently applicable for that chassis.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the temperature readings for the blade servers and IOM and ensure they are within the recommended thermal safe operating range.
 - Step 2** If the fault reports a "Thermal Sensor threshold crossing in blade" error for one or more blade servers, check if DIMM or processor temperature related faults have been raised against that blade.
 - Step 3** If the fault reports a "Thermal Sensor threshold crossing in IOM" error for one or both the IOMs, check if thermal faults have been raised against that IOM. Those faults include details of the thermal condition.
 - Step 4** If the fault reports a "Missing or Faulty Fan" error, check on the status of that fan. If it needs replacement, create a **show tech-support** file for the chassis and contact Cisco TAC.
 - Step 5** If the fault reports a "No connectivity between IOM and blade" or "Thermal Sensor readings unavailable from blade" error, check if that blade server is operational and whether any faults have been raised against that blade server. In this situation, the chassis controller may go into a fail-safe operating mode and the fan speeds may increase as a precautionary measure.
 - Step 6** If the above actions did not resolve the issue and the condition persists, create a **show tech-support** file for Cisco FPR Manager and the chassis and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 742
mibFaultName: fltEquipmentChassisThermalThresholdNonRecoverable
moClass: equipment:Chassis
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fltEquipmentIOCardIdentity

Fault Code: F0743

Message

[side] IOM [chassisId]/[id] ([switchId]) has a malformed FRU

Explanation

This fault typically occurs when the FRU information for an I/O module is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: fru-problem
mibFaultCode: 743
mibFaultName: fltEquipmentIOCardIdentity
moClass: equipment:IOCard
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentFexIdentity

Fault Code: F0744

Message

Fex [id] has a malformed FRU

Explanation

This fault typically occurs when the FRU information for a FEX is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: fru-problem
mibFaultCode: 744
mibFaultName: fltEquipmentFexIdentity
```

```

moClass: equipment:Fex
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fex- [id]

```

fltEquipmentFanModuleIdentity

Fault Code: F0745

Message

Fan Module [tray]-[id] in chassis [id] has a malformed FRUFan Module [tray]-[id] in server [id] has a malformed FRUFan Module [tray]-[id] in fabric interconnect [id] has a malformed FRU

Explanation

This fault typically occurs when the FRU information for a fan module is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: fru-problem
mibFaultCode: 745
mibFaultName: fltEquipmentFanModuleIdentity
moClass: equipment:FanModule
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/fan-module- [tray]- [id]
Affected MO: sys/rack-unit- [id]/fan-module- [tray]- [id]
Affected MO: sys/switch- [id]/fan-module- [tray]- [id]

```

fltEquipmentPsIdentity

Fault Code: F0746

Message

Power supply [id] on chassis [id] has a malformed FRUPower supply [id] on server [id] has a malformed FRU

Explanation

This fault typically occurs when the FRU information for a power supply unit is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: fru-problem
mibFaultCode: 746
mibFaultName: fltEquipmentPsuIdentity
moClass: equipment:Psu
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuPowerThreshold

Fault Code: F0747

Message

Power supply [id] on chassis [id] has exceeded its power thresholdPower supply [id] on server [id] has exceeded its power threshold

Explanation

This fault occurs when a power supply unit is drawing too much current.

Recommended Action

If you see this fault, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: power-problem
mibFaultCode: 747
mibFaultName: fltEquipmentPsuPowerThreshold
moClass: equipment:Psu
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuInputError

Fault Code: F0748

Message

Power supply [id] on chassis [id] has disconnected cable or bad input voltagePower supply [id] on server [id] has disconnected cable or bad input voltage

Explanation

This fault occurs when a power cable is disconnected or input voltage is incorrect.

Recommended Action

If you see this fault, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: power-problem
mibFaultCode: 748
mibFaultName: fltEquipmentPsuInputError
moClass: equipment:Psu
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]
```

fltEquipmentSwitchCardPowerOff

Fault Code: F0749

Message

Switch card is powered down.

Explanation

This fault occurs when the switch card is powered down.

Recommended Action

If you see this fault, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: power-down
mibFaultCode: 749
mibFaultName: fltEquipmentSwitchCardPowerOff
moClass: equipment:SwitchCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /slot- [id]
```

fltEquipmentSwitchCardAct2LiteFail

Fault Code: F0750

Message

Failed Identification Test in slot - [id] ([descr]). The module in this slot may not be a genuine product. warranties and support programs only apply to genuine products. If its determined that your insertion of non genuine modules into a product is the cause of a support issue, support under your warranty may be denied or under a support program such as SmartNet.

Explanation

This fault occurs when the ACT2 chip fails.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: act2-fail
mibFaultCode: 750
mibFaultName: fltEquipmentSwitchCardAct2LiteFail
moClass: equipment:SwitchCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/slot-[id]
```

fltEquipmentHealthLedCriticalError

Fault Code: F0751

Message

Health LED of server [chassisId]/[slotId] shows error. Reason: [healthLedStateQualifier]Health LED of server [id] shows error. Reason: [healthLedStateQualifier]

Explanation

This fault is raised Blade LED changes to amber blinking

Recommended Action

If you see this fault, take the following actions:

Step 1 Read fault summary and determine course of action.

Fault Details

```
Severity: critical
Cause: health-led-amber-blinking
mibFaultCode: 751
mibFaultName: fltEquipmentHealthLedCriticalError
```

```

moClass: equipment:HealthLed
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/blade-[slotId]/health-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/chassis-[id]/health-led
Affected MO: sys/chassis-[id]/psu-[id]/health-led
Affected MO: sys/chassis-[id]/slot-[id]/health-led
Affected MO: sys/fex-[id]/health-led
Affected MO: sys/fex-[id]/psu-[id]/health-led
Affected MO: sys/fex-[id]/slot-[id]/health-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/health-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-unit-[id]/health-led
Affected MO: sys/rack-unit-[id]/psu-[id]/health-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/switch-[id]/psu-[id]/health-led

```

fltEquipmentTpmSlaveTpm

Fault Code: F0752

Message

Server [chassisId]/[slotId], has a Tpm present on the Slave Board.

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: info
Cause: tpm-on-slave-board
mibFaultCode: 752
mibFaultName: fltEquipmentTpmSlaveTpm
moClass: equipment:Tpm
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/Tpm-[id]
Affected MO: sys/rack-unit-[id]/board/Tpm-[id]

```

fltEquipmentHealthLedMinorError

Fault Code: F0753

Message

Health LED of server [chassisId]/[slotId] shows error. Reason: [healthLedStateQualifier]Health LED of server [id] shows error. Reason: [healthLedStateQualifier]

Explanation

This fault is raised Blade LED changes to amber

Recommended Action

If you see this fault, take the following actions:

Step 1 Read fault summary and determine course of action.

Fault Details

```

Severity: minor
Cause: health-led-amber
mibFaultCode: 753
mibFaultName: fltEquipmentHealthLedMinorError
moClass: equipment:HealthLed
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/blade-[slotId]/health-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/chassis-[id]/health-led
Affected MO: sys/chassis-[id]/psu-[id]/health-led
Affected MO: sys/chassis-[id]/slot-[id]/health-led
Affected MO: sys/fex-[id]/health-led
Affected MO: sys/fex-[id]/psu-[id]/health-led
Affected MO: sys/fex-[id]/slot-[id]/health-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/health-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-unit-[id]/health-led
Affected MO: sys/rack-unit-[id]/psu-[id]/health-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/switch-[id]/psu-[id]/health-led

```

fltEquipmentSwitchIOCardRemoved

Fault Code: F0754

Message

[side] FI IOM [chassisId]/[id] ([switchId]) is removed

Explanation

This fault typically occurs because an FI I/O module is removed from the chassis. In a cluster configuration, the chassis fails over to the other FI I/O module. For a standalone configuration, the chassis associated with the FI I/O module loses network connectivity. This is a critical fault because it can result in the loss of network connectivity and disrupt data traffic through the FI I/O module.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reinsert the FI I/O module and configure the fabric-interconnect ports connected to it as server ports and wait a few minutes to see if the fault clears.
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: equipment-removed
mibFaultCode: 754
mibFaultName: fltEquipmentSwitchIOCardRemoved
moClass: equipment:SwitchIOCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalProblem

Fault Code: F0755

Message

[side] FI IOM [chassisId]/[id] ([switchId]) operState: [operState]

Explanation

This fault occurs when there is a thermal problem on an FI I/O module. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the FI I/O module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the FI I/O modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace faulty FI I/O modules.

- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 755
mibFaultName: fltEquipmentSwitchIOCardThermalProblem
moClass: equipment:SwitchIOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdNonCritical

Fault Code: F0756

Message

[side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an FI I/O module has exceeded a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the FI I/O module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and FI I/O modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis and FI I/O module are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.

- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 756
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdNonCritical
moClass: equipment:SwitchIOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdCritical

Fault Code: F0757

Message

[side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an FI I/O module has exceeded a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the FI I/O module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and FI I/O modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis and FI I/O module are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace the faulty FI I/O modules.

- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 757
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdCritical
moClass: equipment:SwitchIOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdNonRecoverable

Fault Code: F0758

Message

[side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

Explanation

This fault occurs when the temperature of an FI I/O module has been out of the operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the FI I/O module.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and FI I/O modules have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis and FI I/O module are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 7** Replace the faulty FI I/O modules.

- Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 758
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdNonRecoverable
moClass: equipment:SwitchIOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardIdentity

Fault Code: F0759

Message

[side] FI IOM [chassisId]/[id] ([switchId]) has a malformed FRU

Explanation

This fault typically occurs when the FRU information for an FI I/O module is corrupted or malformed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: fru-problem
mibFaultCode: 759
mibFaultName: fltEquipmentSwitchIOCardIdentity
moClass: equipment:SwitchIOCard
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardCpuThermalThresholdCritical

Fault Code: F0760

Message

[side] FI IOM [chassisId]/[id] ([switchId]) processor temperature exceeded the limit

Explanation

This fault typically occurs when the processor temperature in FI-IOM exceeds the limit.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the FI I/O module.
 - Step 2** Review the Cisco FPR Site Preparation Guide to ensure the chassis and FI I/O modules have adequate airflow, including front and back clearance.
 - Step 3** Verify that the air flows on the Cisco FPR chassis and FI I/O module are not obstructed.
 - Step 4** Verify that the site cooling system is operating properly.
 - Step 5** Power off unused blade servers and rack servers.
 - Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
 - Step 7** Replace the faulty FI I/O modules.
 - Step 8** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
 - Step 9** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: thermal-problem
mibFaultCode: 760
mibFaultName: fltEquipmentSwitchIOCardCpuThermalThresholdCritical
moClass: equipment:SwitchIOCard
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltExtpolClientClientLostConnectivity

Fault Code: F0792

Message

FPRM has lost connectivity with Firepower Central

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: major
Cause: client-lost-connectivity
mibFaultCode: 792
mibFaultName: fltExtpolClientClientLostConnectivity
moClass: extpol:Client
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

fltExtpolClientGracePeriodWarning**Fault Code: F0793****Message**

FPR domain [name] registered with FPR Central has entered into the grace period.

Explanation

A FPR domain is registered with FPR Central without having a license. This fault typically occurs if this FPR domain is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for the FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under license scope from **service-reg** session.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: warning
Cause: license-graceperiod-entered
mibFaultCode: 793
mibFaultName: fltExtpolClientGracePeriodWarning
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

fltExtpolClientGracePeriodWarning2**Fault Code: F0794****Message**

FPR Domain [name] registered with FPR Central is running in the grace period for more than 10 days

Explanation

This FPR domain is registered with FPR Central without having a license. This fault typically occurs if this FPR domain is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for the FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: license-graceperiod-10days
mibFaultCode: 794
mibFaultName: fltExtpolClientGracePeriodWarning2
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning3**Fault Code: F0795****Message**

FPR Domain [name] registered with FPR Central is running in the grace period for more than 30 days

Explanation

This FPR Domain registered with FPR Central has been running in the grace period for more than 30 days. This fault typically occurs if this FPR domain is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains and the unlicensed FPR Domains have been running for more than 120 days.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Manager GUI, you can access the licensing information from the Operations Management tab for the FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
```

```

Cause: license-graceperiod-30days
mibFaultCode: 795
mibFaultName: fltExtpolClientGracePeriodWarning3
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

```

fltExtpolClientGracePeriodWarning4

Fault Code: F0796

Message

FPR Domain [name] registered with FPR Central is running in the grace period for more than 60 days

Explanation

This FPR Domain registered with FPR Central has been running in the grace period for more than 60 days. This fault typically occurs if this FPR domain is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains and the unlicensed FPR Domains have been running for more than 60 days.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for the FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: license-graceperiod-60days
mibFaultCode: 796
mibFaultName: fltExtpolClientGracePeriodWarning4
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

```

fltExtpolClientGracePeriodWarning5

Fault Code: F0797

Message

FPR Domain [name] registered with FPR Central is running in the grace period for more than 90 days

Explanation

This FPR Domain registered with FPR Central has been running in the grace period for more than 90 days. This fault typically occurs if this FPR domains is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains and the unlicensed FPR Domains have been running for more than 90 days.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed by FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for the FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: license-graceperiod-90days
mibFaultCode: 797
mibFaultName: fltExtpolClientGracePeriodWarning5
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning6**Fault Code: F0798****Message**

FPR Domain [name] registered with FPR Central is running in the grace period for more than 119 days

Explanation

This FPR Domain registered with FPR Central has been running in the grace period for more than 119 days. This fault typically occurs if this FPR domain is registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains and the unlicensed FPR Domains have been running for more than 119 days.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: critical
Cause: license-graceperiod-119days
mibFaultCode: 798
mibFaultName: fltExtpolClientGracePeriodWarning6
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

fltExtpolClientGracePeriodWarning7**Fault Code: F0799****Message**

Grace period for FPR Domain [name] registered with FPR Central has expired. Please acquire a license for the same.

Explanation

This FPR Domain registered with FPR Central has been running in the grace period for more than 120 days. FPR domains are registered with FPR Central after all default (and procured) licenses are assigned to other FPR domains and the unlicensed FPR Domains have been running for more than 120 days. At this stage, the system licensing state is set to expired.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the number of licenses installed and consumed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
 - Step 2** Disable the unlicensed FPR Domains to bring the number of enabled Domains down to the number of total licenses.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC immediately to procure more licenses.

Fault Details

Severity: critical
Cause: license-graceperiod-expired
mibFaultCode: 799
mibFaultName: fltExtpolClientGracePeriodWarning7
moClass: extpol:Client
Type: management
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]

fltExtpolClientGracePeriodWarning1

Fault Code: F0800

Message

FPR Domain [name] is registered with FPR Central without a valid license.

Explanation

This FPR domain is registered with FPR Central without having a license. This fault typically occurs if this FPR domain is registered with FPR Central without the initial activation license and after all default licenses are assigned to other FPR domains.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check if the initial activation license is installed on FPR Central. In the Cisco FPR Central GUI, you can access the licensing information from the Operations Management tab for FPR Central. In the Cisco FPR Central CLI, you can access the licensing information by entering the **show usage detail** command under the license scope.
 - Step 2** Disable the unlicensed FPR Domains to bring the number of enabled Domains down to the number of total licenses.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC immediately to procure more licenses.

Fault Details

```
Severity: critical
Cause: license-insufficient
mibFaultCode: 800
mibFaultName: fltExtpolClientGracePeriodWarning1
moClass: extpol:Client
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]
```

fltStorageLocalDiskInoperable

Fault Code: F0809

Message

Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the local disk has become inoperable.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Insert the disk in a supported slot.
 - Step 2** Remove and reinsert the local disk.
 - Step 3** Replace the disk, if an additional disk is available.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: 809
mibFaultName: fltStorageLocalDiskInoperable
moClass: storage:LocalDisk
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]

```

fltStorageLocalDiskDegraded

Fault Code: F0810

Message

Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the local disk has become degraded. The fault description will contain the physical drive state, which indicates the reason for the degradation.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the drive state is "rebuild" or "copyback", wait for the rebuild or copyback operation to complete.
 - Step 2** If the drive state is "predictive-failure", replace the disk.

Fault Details

```

Severity: warning
Cause: equipment-degraded
mibFaultCode: 810
mibFaultName: fltStorageLocalDiskDegraded
moClass: storage:LocalDisk
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]

```

fltStorageLocalDiskSlotEpUnusable

Fault Code: F0811

Message

Local disk [id] on server [serverId] is not usable by the operating system

Explanation

This fault occurs when the server disk drive is in a slot that is not supported by the storage controller.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Insert the server disk drive in a supported slot.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: equipment-inoperable
mibFaultCode: 811
mibFaultName: fltStorageLocalDiskSlotEpUnusable
moClass: storage:LocalDiskSlotEp
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/disk-[id]
Affected MO: sys/rack-unit-[id]/board/disk-[id]
```

fltStorageItemCapacityExceeded

Fault Code: F0812

Message

Disk usage for partition [name] on fabric interconnect [id] exceeded 70%

Explanation

This fault occurs when the partition disk usage exceeds 70% but is less than 90%.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reduce the partition disk usage to less than 70% by deleting unused and unnecessary files.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: capacity-exceeded
mibFaultCode: 812
mibFaultName: fltStorageItemCapacityExceeded
```

```

moClass: storage:Item
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/stor-part-[name]

```

fltStorageItemCapacityWarning

Fault Code: F0813

Message

Disk usage for partition [name] on fabric interconnect [id] exceeded 90%

Explanation

This fault occurs when the partition disk usage exceeds 90%.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reduce the partition disk usage to less than 90% by deleting unused and unnecessary files.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: capacity-exceeded
mibFaultCode: 813
mibFaultName: fltStorageItemCapacityWarning
moClass: storage:Item
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/stor-part-[name]

```

fltStorageItemFilesystemIssues

Fault Code: F0814

Message

Partition [name] on fabric interconnect [id] has file system errors

Explanation

This fault occurs when the partition develops faults

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-degraded
mibFaultCode: 814
mibFaultName: fltStorageItemFilesystemIssues
moClass: storage:Item
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id]/stor-part- [name]

```

fltStorageRaidBatteryInoperable**Fault Code: F0815****Message**

RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the RAID backup unit is not operational.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the backup unit is a battery, replace the battery.
 - Step 2** If the backup unit is a supercapacitor type and the supercapacitor is missing, verify its presence and supply if missing.
 - Step 3** If the backup unit is a supercapacitor type and the TFM is missing, verify its presence and supply if missing.
 - Step 4** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: 815
mibFaultName: fltStorageRaidBatteryInoperable
moClass: storage:RaidBattery
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type]- [id]/raid-battery
Affected MO: sys/rack-unit- [id]/board/storage- [type]- [id]/raid-battery

```

fltStorageMezzFlashLifeConfiguration-error

Fault Code: F0816

Message

Flash Life on server [chassisId]/[slotId] flashStatus: [flashStatus]

Explanation

This fault occurs when FPRM is not able to retrieve the Fusion-io life left due to an error.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Upgrade Fusion-io Firmware.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: info
Cause: configuration-error
mibFaultCode: 816
mibFaultName: fltStorageMezzFlashLifeConfigurationError
moClass: storage:MezzFlashLife
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/flash-life-
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/flash-life-
```

fltStorageMezzFlashLifeDegraded

Fault Code: F0817

Message

Flash Life on server [chassisId]/[slotId] flashStatus: [flashStatus]

Explanation

This fault occurs when the Fusion-io life left is 10 percent or less.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Continue to monitor the the Fusion-io life left and if it reaches 0 percent, the adapter might revert to read-only.

Fault Details

```
Severity: warning
Cause: equipment-degraded
mibFaultCode: 817
mibFaultName: fltStorageMezzFlashLifeDegraded
moClass: storage:MezzFlashLife
```

```

Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/flash-life-
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/flash-life-

```

fltStorageRaidBatteryDegraded

Fault Code: F0818

Message

RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the RAID backup unit is degraded.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the fault reason indicates the backup unit is in a relearning cycle, wait for relearning to complete.
 - Step 2** If the fault reason indicates the backup unit is about to fail, replace the backup unit.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: equipment-degraded
mibFaultCode: 818
mibFaultName: fltStorageRaidBatteryDegraded
moClass: storage:RaidBattery
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery

```

fltStorageRaidBatteryRelearnAborted

Fault Code: F0819

Message

RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower Manager. This fault is present only as a placeholder, possibly for another release, such as stand-alone rack servers. --- This fault occurs when the backup unit's relearning cycle was aborted.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Retry the learn cycle.
 - Step 2** Replace the backup unit.

Fault Details

```

Severity: minor
Cause: equipment-degraded
mibFaultCode: 819
mibFaultName:fltStorageRaidBatteryRelearnAborted
moClass: storage:RaidBattery
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery

```

fltStorageRaidBatteryRelearnFailed**Fault Code: F0820****Message**

RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower Manager. This fault is present only as a placeholder, possibly for another release, such as stand-alone rack servers. --- This fault occurs when the backup unit's relearning cycle has failed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Retry the learn cycle.
 - Step 2** Replace the backup unit.

Fault Details

```

Severity: major
Cause: equipment-degraded
mibFaultCode: 820
mibFaultName:fltStorageRaidBatteryRelearnFailed
moClass: storage:RaidBattery
Type: equipment

```



```

Callhome: diagnostic
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery

```

fltStorageInitiatorConfiguration-error

Fault Code: F0821

Message

Initiator [name] either cannot be resolved or does not match with one of the storage targets. No zones are deployed for this initiator and the target.

Explanation

Initiator either cannot be resolved or does not match with one of the targets.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check if vhba interface referenced by this Initiator exists.
 - Step 2** Check if switch id or vsan name of the vhba interface referenced by this Initiator matches one of the targets.

Fault Details

```

Severity: warning
Cause: configuration-error
mibFaultCode: 821
mibFaultName: fltStorageInitiatorConfigurationError
moClass: storage:Initiator
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/san-conn-pol-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/grp-[name]/ini-[name]

```

fltStorageControllerPatrolReadFailed

Fault Code: F0822

Message

Controller [id] on server [chassisId]/[slotId] had a patrol read failure. Reason: [operQualifierReason]Controller [id] on server [id] had a patrol read failure. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower ManagerThis fault is present only as a placeholder, possibly for another release,such as stand-alone rack servers.---This fault occurs when a Patrol Read operation has failed.

Recommended Action

Re-run the patrol read operation.

Fault Details

Severity: warning
Cause: operation-failed
mibFaultCode: 822
mibFaultName: fltStorageControllerPatrolReadFailed
moClass: storage:Controller
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]

fltStorageControllerInoperable**Fault Code: F0823****Message**

Controller [id] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason]Controller [id] on server [id] is inoperable. Reason: [operQualifierReason]

Explanation

This fault occurs when the storage controller is inaccessible.

Recommended Action

For PCI and mezz-based storage controllers, check the seating of the storage controller. If the problem persists, replace the controller.

Fault Details

Severity: critical
Cause: equipment-inoperable
mibFaultCode: 823
mibFaultName: fltStorageControllerInoperable
moClass: storage:Controller
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]

fltStorageLocalDiskRebuildFailed**Fault Code: F0824****Message**

Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower Manager. This fault is present only as a placeholder, possibly for another release, such as stand-alone rack servers. This fault occurs when a rebuild operation has failed. This may cause a degradation in performance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Retry the rebuild operation.
Step 2 Replace the disk.

Fault Details

```
Severity: major
Cause: equipment-offline
mibFaultCode: 824
mibFaultName: fltStorageLocalDiskRebuildFailed
moClass: storage:LocalDisk
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
```

fltStorageLocalDiskCopybackFailed

Fault Code: F0825

Message

Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower Manager. This fault is present only as a placeholder, possibly for another release, such as stand-alone rack servers. This fault occurs when a copyback operation has failed. This may cause a degradation in performance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Retry the copyback operation.
Step 2 Replace the disk.

Fault Details

```
Severity: major
Cause: equipment-offline
mibFaultCode: 825
mibFaultName: fltStorageLocalDiskCopybackFailed
moClass: storage:LocalDisk
Type: equipment
```

```

Callhome: diagnostic
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]

```

fltStorageLocalDiskMissing

Fault Code: F0826

Message

Local disk [id] missing on server [chassisId]/[slotId]Local disk [id] missing on server [id]

Explanation

This fault occurs when a disk is missing.

Recommended Action

If you see this fault, take the following action:

Step 1 Insert the disk.

Fault Details

```

Severity: info
Cause: equipment-missing
mibFaultCode: 826
mibFaultName: fltStorageLocalDiskMissing
moClass: storage:LocalDisk
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/disk- [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/disk- [id]

```

fltStorageVirtualDriveInoperable

Fault Code: F0827

Message

Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the virtual drive has become inoperable.

Recommended Action

If you see this fault, take the following actions:

Step 1 Verify the presence and health of disks that are used by the virtual drive.

- Step 2** If applicable, reseal or replace used disks.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-inoperable
mibFaultCode: 827
mibFaultName: fltStorageVirtualDriveInoperable
moClass: storage:VirtualDrive
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]

```

fltStorageVirtualDriveDegraded

Fault Code: F0828

Message

Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

This fault occurs when the virtual drive has become degraded. The fault description will contain the physical drive state, which indicates the reason for the degradation.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the drive is performing a consistency check operation, wait for the operation to complete.
- Step 2** Verify the presence and health of disks that are used by the virtual drive.
- Step 3** If applicable, reseal or replace used disks.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: equipment-degraded
mibFaultCode: 828
mibFaultName: fltStorageVirtualDriveDegraded
moClass: storage:VirtualDrive
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]

```

fltStorageVirtualDriveReconstructionFailed

Fault Code: F0829

Message

Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower ManagerThis fault is present only as a placeholder, possibly for another release,such as stand-alone rack servers.---This fault occurs when a drive reconstruction operation has failed. This may cause a degradation in performance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Retry the reconstruction operation.
 - Step 2** Delete and recreate the virtual drive.

Fault Details

```
Severity: major
Cause: equipment-degraded
mibFaultCode: 829
mibFaultName: fltStorageVirtualDriveReconstructionFailed
moClass: storage:VirtualDrive
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage- [type] - [id]/vd- [id]
Affected MO: sys/rack-unit- [id]/board/storage- [type] - [id]/vd- [id]
```

fltStorageVirtualDriveConsistencyCheckFailed

Fault Code: F0830

Message

Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason]

Explanation

NOTE: This fault is not currently implemented by Firepower ManagerThis fault is present only as a placeholder, possibly for another release,such as stand-alone rack servers.---This fault occurs when a drive consistency check operation has failed. This may cause a degradation in performance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Retry the consistency check operation.
- Step 2** Delete and recreate the virtual drive.

Fault Details

Severity: major
Cause: equipment-degraded
mibFaultCode: 830
mibFaultName: fltStorageVirtualDriveConsistencyCheckFailed
moClass: storage:VirtualDrive
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: false
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]

fltStorageFlexFlashControllerInoperable

Fault Code: F0831

Message

FlexFlash Controller [id] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason]
 Status: [controllerHealth]FlexFlash Controller [id] on server [id] is inoperable. Reason:
 [operQualifierReason] Status: [controllerHealth]

Explanation

This fault occurs when the flexflash controller is inaccessible.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** If reported as Firmware Mismatch, update the CIMC and Board Controller firmware
- Step 2** If reported as Fatal Error, reset the CIMC and update Board Controller firmware
- Step 3** For PCI and mezz-based controllers, check the seating of the storage controller. If the problem persists, replace the controller

Fault Details

Severity: major
Cause: equipment-inoperable
mibFaultCode: 831
mibFaultName: fltStorageFlexFlashControllerInoperable
moClass: storage:FlexFlashController
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]

fltStorageFlexFlashCardInoperable

Fault Code: F0832

Message

FlexFlash Card [slotNumber] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason]FlexFlash Card [slotNumber] on server [id] is inoperable. Reason: [operQualifierReason]

Explanation

This fault occurs when the flexflash card is inaccessible.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** If reported as Write Protected, then remove write protection from the card
 - Step 2** If reported as Invalid Capacity, use an OS disk utility to delete/recreate the partitions
 - Step 3** If the above action did not resolve the issue, replace the card

Fault Details

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: 832
mibFaultName: fltStorageFlexFlashCardInoperable
moClass: storage:FlexFlashCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/card- [slotNumber]
Affected MO: sys/rack-unit- [id]/board/storage-flexflash- [id]/card- [slotNumber]

```

fltStorageFlexFlashCardMissing

Fault Code: F0833

Message

FlexFlash Card [slotNumber] missing on server [chassisId]/[slotId]FlexFlash Card [slotNumber] missing on server [id]

Explanation

This fault occurs when a FlexFlash Card is missing.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Insert the Card.

Fault Details

Severity: info
Cause: equipment-missing
mibFaultCode: 833
mibFaultName: fltStorageFlexFlashCardMissing
moClass: storage:FlexFlashCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/card- [slotNumber]
Affected MO: sys/rack-unit- [id]/board/storage-flexflash- [id]/card- [slotNumber]

fltStorageFlexFlashVirtualDriveDegraded**Fault Code:** F0834**Message**

FlexFlash Virtual Drive RAID degraded on server [chassisId]/[slotId]. Reason: [raidState]FlexFlash Virtual Drive RAID degraded on server [id]. Reason: [raidState]

Explanation

This fault occurs when the flexflash raid is degraded.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Re-acknowledge the server by setting the flexflash scrub policy to yes. Please note that this action will erase all data in the card(s)
- Step 2** Verify the health of the controller/card(s). If the above action did not resolve the issue, replace the card(s)

Fault Details

Severity: minor
Cause: equipment-degraded
mibFaultCode: 834
mibFaultName: fltStorageFlexFlashVirtualDriveDegraded
moClass: storage:FlexFlashVirtualDrive
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/vd- [id]
Affected MO: sys/rack-unit- [id]/board/storage-flexflash- [id]/vd- [id]

fltStorageFlexFlashVirtualDriveInoperable**Fault Code:** F0835**Message**

FlexFlash Virtual Drive on server [chassisId]/[slotId] is inoperable. Reason: [raidState]FlexFlash Virtual Drive on server [id] is inoperable. Reason: [raidState]

Explanation

This fault occurs when the flexflash virtual drive is inoperable.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Re-acknowledge the server by setting the flexflash scrub policy to yes. Please note that this action will erase all data in the card(s)
- Step 2** Verify the health of the controller/card(s). If the above action did not resolve the issue, replace the card(s)

Fault Details

Severity: major
Cause: equipment-inoperable
mibFaultCode: 835
mibFaultName: fltStorageFlexFlashVirtualDriveInoperable
moClass: storage:FlexFlashVirtualDrive
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/vd- [id]
Affected MO: sys/rack-unit- [id]/board/storage-flexflash- [id]/vd- [id]

fltStorageFlexFlashControllerUnhealthy

Fault Code: F0836**Message**

FlexFlash Controller [id] on server [chassisId]/[slotId] is unhealthy. Reason: [operQualifierReason]
 Status: [controllerHealth]FlexFlash Controller [id] on server [id] is unhealthy. Reason:
 [operQualifierReason] Status: [controllerHealth]

Explanation

This fault occurs when the flexflash controller is unhealthy.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** If reported as Old Firmware/Firmware Mismatch, update the CIMC and Board Controller firmware, reboot the server
- Step 2** Re-acknowledge the server by setting the flexflash scrub policy to yes. Please note that this action will erase all data in the card(s)
- Step 3** Verify the health of the controller. If the above action did not resolve the issue, replace the card(s)

Fault Details

Severity: minor
Cause: equipment-unhealthy
mibFaultCode: 836
mibFaultName: fltStorageFlexFlashControllerUnhealthy
moClass: storage:FlexFlashController
Type: equipment

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]

```

fltStorageFlexFlashControllerMismatch

Fault Code: F0837

Message

FlexFlash Controller [id] on server [chassisId]/[slotId] has SD cards with different sizes.FlexFlash Controller [id] on server [id] has SD cards with different sizes.

Explanation

This fault occurs when the flexflash SD Cards dont match in size.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Remove one of the existing cards and replace it with another card that has the same size as the unremoved one.

Fault Details

```

Severity: major
Cause: equipment-unhealthy
mibFaultCode: 837
mibFaultName: fltStorageFlexFlashControllerMismatch
moClass: storage:FlexFlashController
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]

```

fltStorageFlexFlashDriveUnhealthy

Fault Code: F0838

Message

FlexFlash Drive [id] on server [chassisId]/[slotId] is unhealthy. Reason: [operQualifierReason] Status: [operationState]FlexFlash Drive [id] on server [id] is unhealthy. Reason: [operQualifierReason] Status: [operationState]

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: major
Cause: equipment-unhealthy
mibFaultCode: 838
mibFaultName: fltStorageFlexFlashDriveUnhealthy
moClass: storage:FlexFlashDrive
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/card- [slotNumber]/drive- [
name]
Affected MO:
sys/rack-unit- [id]/board/storage-flexflash- [id]/card- [slotNumber]/drive- [name]

```

fltStorageFlexFlashCardUnhealthy**Fault Code: F0839****Message**

FlexFlash Card [slotNumber] on server [chassisId]/[slotId] is unhealthy. Reason: [cardHealth]FlexFlash Card [slotNumber] on server [id] is unhealthy. Reason: [cardHealth]

Explanation

This fault occurs when the flexflash card is unhealthy.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Re-acknowledge the server by setting the flexflash scrub policy to yes. Please note that this action will erase all data in the card(s)
 - Step 2** Verify the health of the card. If the above action did not resolve the issue, replace the card

Fault Details

```

Severity: minor
Cause: equipment-unhealthy
mibFaultCode: 839
mibFaultName: fltStorageFlexFlashCardUnhealthy
moClass: storage:FlexFlashCard
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis- [id]/blade- [slotId]/board/storage-flexflash- [id]/card- [slotNumber]
Affected MO: sys/rack-unit- [id]/board/storage-flexflash- [id]/card- [slotNumber]

```

fltIppoolPoolEmpty

Fault Code: F0844

Message

IP pool [name] is empty

Explanation

This fault typically occurs when an IP address pool does not contain any IP addresses.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the pool is in use, add a block of IP addresses to the pool.
 - Step 2** If the pool is not in use, ignore the fault.

Fault Details

```
Severity: minor
Cause: empty-pool
mibFaultCode: 844
mibFaultName: fltIppoolPoolEmpty
moClass: ippool:Pool
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/network-sets/ip-pool- [name]
Affected MO: org- [name]/ip-pool- [name]
```

fltAaaProviderGroupProvidergroup

Fault Code: F0850

Message

For [dn]: Server Group with name [name] already exist, You need to specify a unique name for this object.

Explanation

This fault typically occurs because Cisco FPR Manager has detected multiple provider-groups with same name.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Need to delete the duplicate provider group configured causing this problem.

Fault Details

```
Severity: major
Cause: provider-group-already-exists
mibFaultCode: 850
mibFaultName: fltAaaProviderGroupProvidergroup
```

```

moClass: aaa:ProviderGroup
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext/providergroup- [name]
Affected MO: sys/radius-ext/providergroup- [name]
Affected MO: sys/tacacs-ext/providergroup- [name]

```

fltAaaProviderGroupProvidergroupsize

Fault Code: F0851

Message

For [dn]: Server Group [name] has [size] provider references. Authentication might fail, if this provider group is used with auth-domain.

Explanation

This fault typically occurs because Cisco FPR Manager has detected provider-group with 0 provider references..

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Need to delete the provider group which does not have any provider references.
 - Step 2** Or Add provider references to provider group.

Fault Details

```

Severity: warning
Cause: provider-group-size-empty
mibFaultCode: 851
mibFaultName: fltAaaProviderGroupProvidergroupsize
moClass: aaa:ProviderGroup
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext/providergroup- [name]
Affected MO: sys/radius-ext/providergroup- [name]
Affected MO: sys/tacacs-ext/providergroup- [name]

```

fltAaaConfigServergroup

Fault Code: F0852

Message

For [dn]: [realm] Server Group with name [providerGroup] doesn't exist or is not deployed.

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported authentication method.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that server group configured for authentication is present.
- Step 2** If the server group is not configured, create the server group to use for authentication.

Fault Details

```
Severity: critical
Cause: invalid-server-group
mibFaultCode: 852
mibFaultName: fltAaaConfigServergroup
moClass: aaa:Config
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/auth-realm/console-auth
Affected MO: sys/auth-realm/default-auth
Affected MO: sys/auth-realm/domain-[name]/domain-auth
```

fltPkiKeyRingStatus

Fault Code: F0853

Message

[name] Keyring's certificate is invalid, reason: [certStatus].

Explanation

This fault occurs when certificate status of Keyring has become invalid.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: invalid-keyring-certificate
mibFaultCode: 853
mibFaultName: fltPkiKeyRingStatus
moClass: pki:KeyRing
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltPkiKeyRingModulus

Fault Code: F0854

Message

[name] Keyring's RSA modulus is invalid.

Explanation

This fault occurs when RSA keyring is created without modulus set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: invalid-keyring-modulus
mibFaultCode: 854
mibFaultName: fltPkiKeyRingModulus
moClass: pki:KeyRing
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltPkiTPStatus

Fault Code: F0855

Message

[name] Trustpoint's cert-chain is invalid, reason: [certStatus].

Explanation

This fault occurs when certificate status of TrustPoint has become invalid.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: invalid-trustpoint-cert-chain
mibFaultCode: 855
mibFaultName: fltPkiTPStatus
moClass: pki:TP
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext/tp-[name]
```


fltAaaRoleRoleNotDeployed

Fault Code: F0856

Message

Role [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported role.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that total number of roles is less than maximum supported roles.
 - Step 2** Verify that sum of privileges across all roles is less than maximum privileges sum.

Fault Details

```
Severity: critical
Cause: role-config-error
mibFaultCode: 856
mibFaultName: fltAaaRoleRoleNotDeployed
moClass: aaa:Role
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext/role-[name]
```

fltAaaLocaleLocaleNotDeployed

Fault Code: F0857

Message

Locale [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported locale.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that total number of locale is less than maximum supported roles.

Fault Details

```
Severity: critical
Cause: locale-config-error
mibFaultCode: 857
mibFaultName: fltAaaLocaleLocaleNotDeployed
moClass: aaa:Locale
Type: security
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext/locale-[name]

fltAaaOrgLocaleOrgNotPresent

Fault Code: F0858

Message

Locale Org [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unidentified org reference.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the org dn referenced in this Org is exists, if not create the same.

Fault Details

Severity: warning
Cause: locale-org-config-error
mibFaultCode: 858
mibFaultName: fltAaaOrgLocaleOrgNotPresent
moClass: aaa:Org
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext/locale-[name]/org-[name]

fltAaaUserRoleUserRoleNotDeployed

Fault Code: F0859

Message

For user: [name] role [name] can't be assigned. Error: [configStatusMessage].For Ldap Group: [name] role [name] can't be assigned. Error: [configStatusMessage].

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported user role for ldap groups or local users.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the role is present .
Step 2 Verify that the role is applied .
Step 3 Verify that the role is compatible with locales assigned to ldap group or local user .

Fault Details

Severity: critical
Cause: user-role-config-error
mibFaultCode: 859
mibFaultName: fltAaaUserRoleUserRoleNotDeployed
moClass: aaa:UserRole
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext/ldapgroup-[name]/role-[name]
Affected MO: sys/user-ext/remoteuser-[name]/role-[name]
Affected MO: sys/user-ext/user-[name]/role-[name]

fltAaaUserLocaleUserLocaleNotDeployed**Fault Code:** F0860**Message**

For user: [name] locale [name] can't be assigned. Error: [configStatusMessage].For Ldap Group: [name] locale [name] can't be assigned. Error: [configStatusMessage].

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported user locale for ldap groups or local users.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the locale is present .
 - Step 2** Verify that the locale is applied .
 - Step 3** Verify that the locale is compatible with roles assigned to ldap group or local user .

Fault Details

Severity: critical
Cause: user-locale-config-error
mibFaultCode: 860
mibFaultName: fltAaaUserLocaleUserLocaleNotDeployed
moClass: aaa:UserLocale
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext/ldapgroup-[name]/locale-[name]
Affected MO: sys/user-ext/remoteuser-[name]/locale-[name]
Affected MO: sys/user-ext/user-[name]/locale-[name]

fltPkiKeyRingKeyRingNotDeployed

Fault Code: F0861

Message

Keyring [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an invalid Keyring.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the trust point configured for this keyring is present .
- Step 2** Verify that the trust point found above is applied .

Fault Details

```
Severity: critical
Cause: keyring-config-error
mibFaultCode: 861
mibFaultName: fltPkiKeyRingKeyRingNotDeployed
moClass: pki:KeyRing
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltCommSnmpSyscontactEmpty

Fault Code: F0862

Message

Manager cannot deploy an empty value of SNMP Syscontact when Callhome is enabled. The previous value [sysContact] for SNMP Syscontact has been retained.

Explanation

This fault typically occurs when FPR Manager receives an invalid configuration from FPR Central wherein SNMP Syscontact is set to empty when Callhome is enabled.

Recommended Action

If you see this fault, please ensure that the SNMP Syscontact field on FPR Central is configured correctly for the domain group corresponding to this FPRM.

Fault Details

```
Severity: warning
Cause: snmp-config-error
mibFaultCode: 862
mibFaultName: fltCommSnmpSyscontactEmpty
moClass: comm:Snmp
Type: configuration
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext/snmp-svc

```

fltCommDateTimeCommTimeZoneInvalid

Fault Code: F0863

Message

Timezone:[timezone] is invalid

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported role.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that total number of roles is less than maximum supported roles.
 - Step 2** Verify that sum of privileges across all roles is less than maximum privileges sum.

Fault Details

```

Severity: minor
Cause: timezone-file-not-exists
mibFaultCode: 863
mibFaultName: fltCommDateTimeCommTimeZoneInvalid
moClass: comm:DateTime
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext/datetime-svc

```

fltAaaUserLocalUserNotDeployed

Fault Code: F0864

Message

Local User [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an invalid system user.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that local user name is not used by snmp users.

Fault Details

```

Severity: major

```

```

Cause: user-config-error
mibFaultCode: 864
mibFaultName: fltAaaUserLocalUserNotDeployed
moClass: aaa:User
Type: security
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext/user- [name]

```

fltCommSnmpUserSnmpUserNotDeployed

Fault Code: F0865

Message

SNMP User [name] can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an invalid snmp user.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that snmp user name is not used by system users.

Fault Details

```

Severity: major
Cause: snmp-user-config-error
mibFaultCode: 865
mibFaultName: fltCommSnmpUserSnmpUserNotDeployed
moClass: comm:SnmpUser
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext/snmp-svc/snmpv3-user- [name]

```

fltCommSvcEpCommSvcNotDeployed

Fault Code: F0866

Message

Communication Service configuration can't be deployed. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an invalid communication policy configuration.

Recommended Action

If you see this fault, take the following actions:

Step 1 Verify that ports configured across all communication services is unique.

Fault Details

Severity: major
Cause: comm-svc-config-error
mibFaultCode: 866
mibFaultName: fltCommSvcEpCommSvcNotDeployed
moClass: comm:SvcEp
Type: configuration
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

fltSysdebugLogExportStatusLogExportFailure

Fault Code: F0871

Message

Log export to remote server failed from [switchId]:[exportFailureReason]

Explanation

This fault occurs when Cisco Firepower Manager cannot transfer a log file to a remote server. This is typically the result of one of the following issues:

- The remote server is not accessible.
- One or more of the parameters for the remote server that are specified for the log export target, such as path, username, password, ssh-key and server name, are incorrect.

Recommended Action

If you see this fault, take the following actions:

Step 1 Verify the connectivity to the remote server.

Step 2 Verify the path information of the remote server.

Step 3 If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: server-error
mibFaultCode: 871
mibFaultName: fltSysdebugLogExportStatusLogExportFailure
moClass: sysdebug:LogExportStatus
Type: sysdebug
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy/log-export-status- [switchId]

fltSysdebugAutoCoreFileExportTargetAutoCoreTransferFailure

Fault Code: F0872

Message

Auto core transfer failure at remote server [hostname]:[path] [exportFailureReason]

Explanation

This fault occurs when Cisco Firepower Manager cannot transfer a core file to a remote TFTP server. This is typically the result of one of the following issues:

- The remote TFTP server is not accessible.
- One or more of the parameters for the TFTP server that are specified for the core export target, such as path, port, and server name, are incorrect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify the connectivity to the remote server.
- Step 2** Verify the path information of the remote server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: tftp-server-error
mibFaultCode: 872
mibFaultName: fltSysdebugAutoCoreFileExportTargetAutoCoreTransferFailure
moClass: sysdebug:AutoCoreFileExportTarget
Type: sysdebug
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fltProcessorUnitInoperable

Fault Code: F0899

Message

Processor [id] on server [chassisId]/[slotId] operability: [operability]

Explanation

This fault occurs in the unlikely event that processor is inoperable.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the fault occurs on a blade server processor, remove the server from the chassis and then reinsert it.
- Step 2** In Cisco FPR Manager, decommission and then recommission the server.

Step 3 If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: 899
mibFaultName: fltProcessorUnitInoperable
moClass: processor:Unit
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npu/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitThermalNonCritical

Fault Code: F0900

Message

Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the processor temperature on a blade or rack server exceeds a non-critical threshold value, but is still below the critical threshold. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.

- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: thermal-problem
mibFaultCode: 900
mibFaultName:fltProcessorUnitThermalNonCritical
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npu/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]

```

fltProcessorUnitThermalThresholdCritical

Fault Code: F0901

Message

Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the processor temperature on a blade or rack server exceeds a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.

- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: thermal-problem
mibFaultCode: 901
mibFaultName: fltProcessorUnitThermalThresholdCritical
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npu/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitThermalThresholdNonRecoverable

Fault Code: F0902

Message

Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]

Explanation

This fault occurs when the processor temperature on a blade or rack server has been out of the operating range, and the issue is not recoverable. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment. In addition, extreme temperature fluctuations can cause CPUs to become loose in their sockets.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).
- If sensors on a CPU reach 179.6F (82C), the system will take that CPU offline.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the server.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the servers have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows on the Cisco FPR chassis or rack server are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Power off unused blade servers and rack servers.
- Step 6** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.

- Step 7** Use the Cisco FPR power capping capability to limit power usage. Power capping can limit the power consumption of the system, including blade and rack servers, to a threshold that is less than or equal to the system's maximum rated power. Power-capping can have an impact on heat dissipation and help to lower the installation site temperature.
- Step 8** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: thermal-problem
mibFaultCode: 902
mibFaultName:fltProcessorUnitThermalThresholdNonRecoverable
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npucpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitVoltageThresholdNonCritical

Fault Code: F0903

Message

Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id] voltage: [voltage]

Explanation

This fault occurs when the processor voltage is out of normal operating range, but hasn't yet reached a critical stage. Normally the processor recovers itself from this situation

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Monitor the processor for further degradation.
- Step 2** If the fault occurs on a blade server processor, remove the server from the chassis and then reinsert it.
- Step 3** In Cisco FPR Manager, decommission and then recommission the server.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: voltage-problem
mibFaultCode: 903
mibFaultName:fltProcessorUnitVoltageThresholdNonCritical
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npucpu-[id]
```

Affected MO: sys/rack-unit-[id]/board/cpu-[id]

fltProcessorUnitVoltageThresholdCritical

Fault Code: F0904

Message

Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id] voltage: [voltage]

Explanation

This fault occurs when the processor voltage has exceeded the specified hardware voltage rating.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the fault occurs on a blade server processor, remove the server from the chassis and then reinsert it.
 - Step 2** In Cisco FPR Manager, decommission and then recommission the server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: voltage-problem
mibFaultCode: 904
mibFaultName: fltProcessorUnitVoltageThresholdCritical
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npu/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]

fltProcessorUnitVoltageThresholdNonRecoverable

Fault Code: F0905

Message

Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id] voltage: [voltage]

Explanation

This fault occurs when the processor voltage has exceeded the specified hardware voltage rating and may cause processor hardware damage or jeopardy.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the fault occurs on a blade server processor, remove the server from the chassis and then reinsert it.

- Step 2** In Cisco FPR Manager, decommission and then recommission the server.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: voltage-problem
mibFaultCode: 905
mibFaultName: fltProcessorUnitVoltageThresholdNonRecoverable
moClass: processor:Unit
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/cpu- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/npu/cpu- [id]
Affected MO: sys/rack-unit- [id]/board/cpu- [id]

```

fltProcessorUnitIdentity-unestablishable

Fault Code: F0906

Message

Processor [id] on server [chassisId]/[slotId] has an invalid FRUProcessor [id] on server [id] has an invalid FRU

Explanation

This fault typically occurs because Cisco FPR Manager has detected an unsupported CPU in the server. For example, the model, vendor, or revision is not recognized.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the capability catalog in Cisco FPR Manager is up to date. If necessary, update the catalog.
- Step 2** If the above action did not resolve the issue, you may have an unsupported CPU configuration in the server. Create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: identity-unestablishable
mibFaultCode: 906
mibFaultName: fltProcessorUnitIdentityUnestablishable
moClass: processor:Unit
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/cpu- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/npu/cpu- [id]
Affected MO: sys/rack-unit- [id]/board/cpu- [id]

```

fltProcessorUnitDisabled

Fault Code: F0907

Message

Processor [id] on server [chassisId]/[slotId] operState: [operState]Processor [id] on server [id] operState: [operState]

Explanation

This fault occurs in the unlikely event that a processor is disabled.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If this fault occurs on a blade server, remove and reinsert the server into the chassis.
 - Step 2** In Cisco FPR Manager, decommission and recommission the blade server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: equipment-disabled
mibFaultCode: 907
mibFaultName: fltProcessorUnitDisabled
moClass: processor:Unit
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/npv/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltExtmgmtIfMgmtifdown

Fault Code: F0964

Message

Management interface on Fabric Interconnect [id] is [operState]

Explanation

This fault occurs when a fabric interconnect reports that the operational state of an external management interface is down.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the state transitions of the external management interface on the fabric interconnect.
 - Step 2** Check the link connectivity for the external management interface.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: mgmtif-down
mibFaultCode: 964
mibFaultName: fltExtmgmtIfMgmtifdown
moClass: extmgmt:If
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/extmgmt-intf

fltExtmgmtArpTargetsArpTargetsNotValid**Fault Code:** F0965**Message**

Invalid ARP Targets configured for Management Interface Polling. Error: [configStatusMessage]

Explanation

This fault typically occurs because Cisco FPR Manager has detected an invalid ArpTargets Configuration.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that Arp target ip address and external management ip address are in the same subnet.
 - Step 2** Verify that Arp target ip address is not the same as ip address of this system's fabric-interconnects.
 - Step 3** Verify that Arp target ip address is not the same as virtual IP Address.

Fault Details

Severity: major
Cause: arp-targets-config-error
mibFaultCode: 965
mibFaultName: fltExtmgmtArpTargetsArpTargetsNotValid
moClass: extmgmt:ArpTargets
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/extmgmt-intf-monitor-policy/arp-target-policy

fltExtmgmtNdiscTargetsNdiscTargetsNotValid**Fault Code:** F0966**Message**

Invalid NDISC Targets configured for Management Interface Polling. Error: [configStatusMessage]

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: ndisc-targets-config-error
mibFaultCode: 966
mibFaultName: fltExtmgmtNdiscTargetsNdiscTargetsNotValid
moClass: extmgmt:NdiscTargets
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/extmgmt-intf-monitor-policy/ndisc-target-policy
```

fltPoolElementDuplicatedAssigned**Fault Code: F0967****Message**

Duplicated ID is assigned for multiple blades

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: major
Cause: duplicated-assigned
mibFaultCode: 967
mibFaultName: fltPoolElementDuplicatedAssigned
moClass: pool:Element
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: ip/[id]
Affected MO: iqn/[name]
Affected MO: mac/[id]
Affected MO: uuid/[id]
Affected MO: wwn/[id]
```

fltNetworkElementInoperable

Fault Code: F0977

Message

Fabric Interconnect [id] operability: [operability]

Explanation

This fault typically occurs when the fabric interconnect cluster controller reports that the membership state of the fabric interconnect is down, indicating that the fabric interconnect is inoperable.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that both fabric interconnects in the cluster are running the same Kernel and System software versions.
 - Step 2** Verify that the fabric interconnects software version and the Cisco FPR Manager software versions are the same.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: 977
mibFaultName: fltNetworkElementInoperable
moClass: network:Element
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]
```

fltNetworkElementRemoved

Fault Code: F0978

Message

Fabric Interconnect [id] operability: [operability]

Explanation

This fault occurs when the fabric interconnect is removed in a clustering setup.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Reinsert the removed fabric interconnect back into the chassis (applicable to FPR-Mini only).
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: equipment-removed
mibFaultCode: 978
mibFaultName: fltNetworkElementRemoved
moClass: network:Element
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]

```

fltSwVlanPortNsResourceStatus**Fault Code: F0979****Message**

Vlan-Port Resource exceeded

Explanation

This fault occurs when the total number of configured VLANs in the Cisco FPR instance has exceeded the allowed maximum number of configured VLANs on the fabric interconnect.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In the Cisco FPR Manager CLI or Cisco FPR Manager GUI, check the port VLAN count to determine by how many VLANs the system is over the maximum.
- Step 2** Reduce the VLAN port count in one of the following ways:
- Delete VLANs configured on the LAN cloud.
 - Delete VLANs configured on vNICs.
 - Unconfigure one or more vNICs.
 - Unconfigure one or more uplink Ethernet ports on the fabric interconnect.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: limit-reached
mibFaultCode: 979
mibFaultName: fltSwVlanPortNsResourceStatus
moClass: sw:VlanPortNs
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/vlan-port-ns

```

fltSwVlanPortNsResourceStatusWarning

Fault Code: F0980

Message

Total Available Vlan-Port Count on switch [switchId] is below 10%

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: near-max-limit
mibFaultCode: 980
mibFaultName: fltSwVlanPortNsResourceStatusWarning
moClass: sw:VlanPortNs
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/vlan-port-ns
```

fltNetworkElementInventoryFailed

Fault Code: F0981

Message

Fabric Interconnect [id] inventory is not complete [inventoryStatus]

Explanation

Cisco FPR Manager raises this fault when the management subsystem is unable to perform an inventory of the physical components, such as I/O cards or physical ports.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Ensure that both fabric interconnects in an HA cluster are running the same software versions.
 - Step 2** Ensure that the fabric interconnect software is a version that is compatible with the Cisco FPR Manager software.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: inventory-failed
mibFaultCode: 981
```

```

mibFaultName: fltNetworkElementInventoryFailed
moClass: network:Element
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]

```

fltNetworkElementThermalThresholdCritical

Fault Code: F0982

Message

Fabric Interconnect [id] temperature: [thermal]

Explanation

This fault occurs when the temperature of a Fabric Interconnect exceeds a critical threshold value. Be aware of the following possible contributing factors:

- Temperature extremes can cause Cisco FPR equipment to operate at reduced efficiency and cause a variety of problems, including early degradation, failure of chips, and failure of equipment.
- Cisco FPR equipment should operate in an environment that provides an inlet air temperature not colder than 50F (10C) nor hotter than 95F (35C).

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Review the product specifications to determine the temperature operating range of the Fabric Interconnect.
- Step 2** Review the Cisco FPR Site Preparation Guide to ensure the Fabric Interconnects have adequate airflow, including front and back clearance.
- Step 3** Verify that the air flows are not obstructed.
- Step 4** Verify that the site cooling system is operating properly.
- Step 5** Clean the installation site at regular intervals to avoid buildup of dust and debris, which can cause a system to overheat.
- Step 6** Replace faulty Fabric Interconnects.
- Step 7** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: thermal-problem
mibFaultCode: 982
mibFaultName: fltNetworkElementThermalThresholdCritical
moClass: network:Element
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]

```

fltNetworkElementMemoryerror

Fault Code: F0983

Message

Fabric Interconnect [id] memory less than expected! Total Memory: [totalMemory] and Expected Memory: [expectedMemory]

Explanation

This fault occurs when the total memory on FI is less than expected.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** You will need to do a manual physical inspection of the DIMMs on the FI. Try removing and reinserting the DIMMs, and verify the Total Memory. If this does not resolve the issue, one of the DIMMs has gone bad and needs to be replaced.
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: memory-error
mibFaultCode: 983
mibFaultName: fltNetworkElementMemoryerror
moClass: network:Element
Type: equipment
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]
```

fltNetworkOperLevelExtraprimaryvlans

Fault Code: F0984

Message

Fabric Interconnect [id]: Number of primary vlans exceeds the max limit on the FI: Number of Primary Vlans: [primaryVlanCount] and Max primary vlans allowed: [maxPrimaryVlanCount]

Explanation

This fault occurs when the fabric interconnect has more number of primary vlans than what is supported.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** It is recommended that operator should delete the extra primary vlans than are there in the FI. System may appear to be normally functioning even with these extra primary vlans in place. However there may be performance issues observed as the system is operating above the recommended scale limits..
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: extra-primary-vlans
mibFaultCode: 984
mibFaultName: fltNetworkOperLevelExtraprimaryvlans
moClass: network:OperLevel
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/oper-level

```

fltNetworkOperLevelExtrasecondaryvlans**Fault Code: F0985****Message**

Fabric Interconnect [id]: Number of secondary vlans exceeds the max limit on the FI: Number of secondary vlans: [secondaryVlanCount] and Max secondary vlans allowed: [maxSecondaryVlanCount]

Explanation

This fault occurs when the fabric interconnect has more number of secondary vlans than what is supported.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** It is recommended that operator should delete the extra secondary vlans that are there in the FI. System may appear to be normally functioning even with these extra secondary vlans in place. However there may be performance issues observed as the system is operating above the recommended scale limits..
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: extra-secondary-vlans
mibFaultCode: 985
mibFaultName: fltNetworkOperLevelExtrasecondaryvlans
moClass: network:OperLevel
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/oper-level

```

fltSwVlanExtrasecondaryvlansperprimary**Fault Code: F0986****Message**

Number of secondary vlans associated with the primary vlan [id] in Fabric Interconnect [switchId] exceeds the max limit: Number of secondary vlans: [secVlanPerPrimaryVlanCount] and Max secondary vlans allowed in a primary vlan: 30

Explanation

This fault occurs when the fabric interconnect has more number of secondary vlans per primary vlan than what is supported.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** It is recommended that operator should delete the extra secondary vlans on this primary vlan that are there in the FI. System may appear to be normally functioning even with these extra secondary vlans on this primary vlan in place. However there may be performance issues observed as the system is operating above the recommended scale limits..
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: extra-secondary-vlans-per-primary
mibFaultCode: 986
mibFaultName: fltSwVlanExtrasecondaryvlansperprimary
moClass: sw:Vlan
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/profiles/vnic-[name]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/
vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[i
d]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[i
d]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/
path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/
vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id
]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id
]
Affected MO:
sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]

```


Affected MO:
 sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-eth/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/pc-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/fcoesan-pc-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]

Affected MO:
 sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/pc-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vlan-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
 sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]

fltFcpoolInitiatorsEmpty

Fault Code: F0987

Message

FC pool [purpose] [name] is empty

Explanation

This fault typically occurs when a WWN pool does not contain any WWNs.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the pool is in use, add a block of WWNs to the pool.
Step 2 If the pool is not in use, ignore the fault.

Fault Details

Severity: minor
Cause: empty-pool
mibFaultCode: 987

```

mibFaultName: fltFcpoolInitiatorsEmpty
moClass: fcpool:Initiators
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /wwn-pool- [name]

```

fltOsControllerFailedBladeBootstrap

Fault Code: F0996

Message

Slot [slotId], boot up failed - recovery in progress

Explanation

This fault occurs when blade failed to boot up.

Recommended Action

If you see this fault, do nothing because the blade will try to recover

Step 1 Reboot the Blade associated with the Slot

Fault Details

```

Severity: major
Cause: bootup-failure
mibFaultCode: 996
mibFaultName: fltOsControllerFailedBladeBootstrap
moClass: os:Controller
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /os-ctrl
Affected MO: sys/os-ctrl
Affected MO: sys/rack-unit- [id] /os-ctrl

```

fltOsControllerFailedBootupRecovery

Fault Code: F0997

Message

Slot [slotId], boot up failed - exceeded max number of retries

Explanation

This fault occurs when blade failed to boot up.

Recommended Action

If you see this fault, do the following:

Step 1 Reboot the Blade associated with the Slot

Fault Details

Severity: major
Cause: bootup-failure
mibFaultCode: 997
mibFaultName: fltOsControllerFailedBootupRecovery
moClass: os:Controller
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/os-ctrl
Affected MO: sys/os-ctrl
Affected MO: sys/rack-unit-[id]/os-ctrl

fltUuidpoolPoolEmpty**Fault Code:** F1014**Message**

UUID suffix pool [name] is empty

Explanation

This fault typically occurs when a UUID suffix pool does not contain any UUID suffixes.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the pool is in use, add a block of UUID suffixes to the pool.
- Step 2** If the pool is not in use, ignore the fault.

Fault Details

Severity: minor
Cause: empty-pool
mibFaultCode: 1014
mibFaultName: fltUuidpoolPoolEmpty
moClass: uuidpool:Pool
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/uuid-pool-[name]

fltCapabilityCatalogueLoadErrors**Fault Code:** F1020**Message**

Load errors: File parse errors: [fileParseFailures], provider load failures: [providerLoadFailures], XML element load errors: [loadErrors].

Explanation

The capability catalog failed to load fully. This may be caused by either a faulty FPRM image or a faulty catalog image.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the version of the capability catalog.
 - Step 2** Contact Cisco TAC to see if there are known issues with the catalog and if there is a catalog image that will fix the known issues.

Fault Details

```
Severity: major
Cause: load-catalog-failed
mibFaultCode: 1020
mibFaultName: fltCapabilityCatalogueLoadErrors
moClass: capability:Catalogue
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fltFabricComputeSlotEpMisplacedInChassisSlot**Fault Code: F1038****Message**

Server, vendor([vendor]), model([model]), serial([serial]) in slot [chassisId]/[slotId] presence: [presence]

Explanation

This fault typically occurs when Cisco FPR Manager detects a server in a chassis slot that does not match what was previously equipped in the slot.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the previous server was intentionally removed and a new one was inserted, reacknowledge the server.
 - Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: server-moved
mibFaultCode: 1038
mibFaultName: fltFabricComputeSlotEpMisplacedInChassisSlot
moClass: fabric:ComputeSlotEp
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]
```

fltFabricComputeSlotEpServerIdentificationProblem

Fault Code: F1039

Message

Problem identifying server in slot [chassisId]/[slotId]

Explanation

This fault typically occurs when Cisco FPR Manager encountered a problem identifying the server in a chassis slot.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Remove and reinsert the server.
 - Step 2** Reacknowledge the server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: server-identification-problem
mibFaultCode: 1039
mibFaultName: fltFabricComputeSlotEpServerIdentificationProblem
moClass: fabric:ComputeSlotEp
Type: equipment
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]
```

fltFabricVlanPrimaryVlanMissingForIsolated

Fault Code: F1040

Message

Primary Vlan can not be resolved for isolated vlan [name]

Explanation

This fault typically occurs when Cisco FPR Manager encounters a problem resolving the primary VLAN ID corresponding to a particular isolated VLAN.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Associate the isolated VLAN with a valid primary VLAN.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
```

```

Cause: primary-vlan-missing-for-isolated
mibFaultCode: 1040
mibFaultName: fltFabricVlanPrimaryVlanMissingForIsolated
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricVlanPrimaryVlanMissingForCommunity

Fault Code: F1041

Message

Primary Vlan can not be resolved for community vlan [name]

Explanation

This fault typically occurs when Cisco FPR Manager encounters a problem resolving the primary VLAN ID corresponding to a particular community VLAN.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Associate the community VLAN with a valid primary VLAN.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: primary-vlan-missing-for-community
mibFaultCode: 1041
mibFaultName: fltFabricVlanPrimaryVlanMissingForCommunity
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricLanPinGroupEmpty

Fault Code: F1042

Message

LAN Pin Group [name] is empty

Explanation

This fault typically occurs when a LAN pin group does not contain any targets.

Recommended Action

If you see this fault, add a target to the LAN pin group.

Fault Details

```
Severity: minor
Cause: empty-pin-group
mibFaultCode: 1042
mibFaultName: fltFabricLanPinGroupEmpty
moClass: fabric:LanPinGroup
Type: server
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/lan-pin-group-[name]
```

fltFabricEthLanPcEpDown**Fault Code: F1043****Message**

[type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

Explanation

This fault typically occurs when a member port in an Ethernet port channel is down.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the link connectivity on the upstream Ethernet switch.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: membership-down
mibFaultCode: 1043
mibFaultName: fltFabricEthLanPcEpDown
moClass: fabric:EthLanPcEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-
-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portI
d]
Affected MO: fabric/lan/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
```


Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

fltFabricEthEstcPcEpDown

Fault Code: F1044

Message

[type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

Explanation

This fault typically occurs when a member port in an Ethernet port channel is down.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the link connectivity on the upstream Ethernet switch.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: membership-down
mibFaultCode: 1044
mibFaultName: fltFabricEthEstcPcEpDown
moClass: fabric:EthEstcPcEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

fltFabricPinTargetDown

Fault Code: F1045

Message

Pin target is a non-existent interface

Explanation

This fault typically occurs when a PinGroup has an unresolvable target.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check whether the PinGroup target is correctly provisioned.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: warning
Cause: invalid-target
mibFaultCode: 1045
mibFaultName: fltFabricPinTargetDown
moClass: fabric:PinTarget
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/lan-pin-group-[name]/target-[fabricId]
Affected MO: fabric/san/san-pin-group-[name]/target-[fabricId]

fltFabricDceSwSrvPcEpDown

Fault Code: F1046

Message

[type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

Explanation

This fault typically occurs when a member port in a fabric port channel is down.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the link connectivity between the FEX or IOM and the fabric interconnect.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: membership-down
mibFaultCode: 1046
mibFaultName: fltFabricDceSwSrvPcEpDown
moClass: fabric:DceSwSrvPcEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-
-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portI
d]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-
[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId
]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotI
d]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/server/sw-[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId
]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[port
Id]

```

fltFabricMonSpanConfigFail

Fault Code: F1047

Message

Configuration for traffic monitor [name] failed, reason: [configFailReason]

Explanation

This fault typically occurs when the configuration of a traffic monitoring session is incorrect.

Recommended Action

If you see this fault, correct the configuration problem provided in the fault description.

Fault Details

```
Severity: major
Cause: config-error
mibFaultCode: 1047
mibFaultName: fltFabricMonSpanConfigFail
moClass: fabric:Mon
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lanmon/[id]/eth-mon-[name]
```

fltFabricEpMgrEpTransModeFail

Fault Code: F1048

Message

Port constraint violation on switch [id]: [confQual]

Explanation

This fault occurs when at least one logical interface is misconfigured. This can happen when upgrading to a different type or series of fabric interconnect or when importing a configuration. The configuration must meet the following constraints:

- There must be at most one logical port per fabric interconnect ID/module ID/port ID.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Create a list of all logical interfaces that are misconfigured and have caused an 'error-misconfigured' fault.
 - Step 2** For each logical interface, note the reason listed in the fault for the misconfiguration.
 - Step 3** Log into Cisco FPR Manager and correct each misconfigured logical interface. If you used the Cisco FPR Manager CLI, commit all changes.
 - Step 4** Review any faults or error messages that describe additional misconfigurations and correct those errors.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: config-error
mibFaultCode: 1048
mibFaultName: fltFabricEpMgrEpTransModeFail
moClass: fabric:EpMgr
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

```

fltFabricVlanMismatch-a**Fault Code: F1049****Message**

VLAN [name] has [overlapStateForA] with another vlan under lan-cloud/appliance-cloud for the fabric interconnect A

Explanation

This fault typically occurs when private vlan properties of VLAN under one cloud conflicts with the private vlan properties of VLAN under another cloud for the fabric interconnect A. The cloud here means either a LAN cloud or an appliance cloud. This issue can stop the usage of this vlan.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the sharing property of the VLAN under both clouds and fabric A referred by its VLAN ID.
 - Step 2** If the sharing property of the VLAN does not match with the VLAN on the other cloud, then change the sharing property of either of the VLANs, so that it matches with each other.
 - Step 3** If the VLAN is a isolated/community vlan, check the pubnwnname property of the VLAN under both clouds referred by its VLAN ID.
 - Step 4** If the pubnwnname property of the isolated/community VLAN does not match with the isolated/community VLAN on the other cloud, then change the pubnwnname property of either of the VLANs, so that it matches with each other.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: vlan-mismatch
mibFaultCode: 1049
mibFaultName: fltFabricVlanMismatchA
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricVlanMismatch-b

Fault Code: F1050

Message

VLAN [name] has [overlapStateForB] with another vlan under lan-cloud/appliance-cloud for the fabric interconnect B

Explanation

This fault typically occurs when private vlan properties of VLAN under one cloud conflicts with the private vlan properties of VLAN under another cloud for the fabric interconnect B. The cloud here means either a LAN cloud or an appliance cloud. This issue can stop the usage of this vlan.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the sharing property of the VLAN under both clouds and fabric B referred by its VLAN ID.
 - Step 2** If the sharing property of the VLAN does not match with the VLAN on the other cloud, then change the sharing property of either of the VLANs, so that it matches with each other.
 - Step 3** If the VLAN is a isolated/community vlan, check the pubnwnname property of the VLAN under both clouds referred by its VLAN ID.
 - Step 4** If the pubnwnname property of the isolated/community VLAN does not match with the isolated/community VLAN on the other cloud, then change the pubnwnname property of either of the VLANs, so that it matches with each other.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: vlan-mismatch
mibFaultCode: 1050
mibFaultName: fltFabricVlanMismatchB
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricVlanErrorAssocPrimary

Fault Code: F1051

Message

VLAN [name] is in error state because the associated primary vlan [assocPrimaryVlanState]

Explanation

This fault typically occurs when there is an error in associated primary vlan of a secondary VLAN. This issue can stop the usage of this vlan.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the pubnwnme property of the VLAN.
 - Step 2** If the pubnwnme is not given or refers to a non-existing primary vlan, give a name of a primary vlan which is in good state.
 - Step 3** If the pubnwnme refers to a vlan which is not a primary vlan, then either change the referred vlan to be a primary vlan or give a different primary vlan.
 - Step 4** If the pubnwnme refers to a valid primary vlan, then check the state of the primary VLAN.
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: vlan-error-assoc-primary
mibFaultCode: 1051
mibFaultName: fltFabricVlanErrorAssocPrimary
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricPloEpErrorMisconfigured**Fault Code: F1052****Message**

Interface [name] is [operState]. Reason: [operStateReason]

Explanation

This fault occurs when a logical interface is misconfigured. This can happen when upgrading to a different type or series of fabric interconnect or when importing a configuration.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Create a list of all logical interfaces that are misconfigured and have caused an 'error-misconfigured' fault.
 - Step 2** For each logical interface, note the reason listed in the fault for the misconfiguration.
 - Step 3** Log into Cisco FPR Manager and correct each misconfigured logical interface. If you used the Cisco FPR Manager CLI, commit all changes.

- Step 4** Review any faults or error messages that describe additional misconfigurations and correct those errors.
- Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: interface-misconfigured
mibFaultCode: 1052
mibFaultName: fltFabricPIoEpErrorMisconfigured
moClass: fabric:PIoEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/eth-estc/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

```


Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO:
fabric/eth-estc/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/eth-estc/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/eth-estc/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-group-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/lan/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO: fabric/lan/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/net-group-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/lan/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/lanmon/[id]/eth-mon-[name]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/net-[name]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO:
fabric/san/net-[name]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/san/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/server/chassis-[chassisId]

Affected MO: fabric/server/chassis- [chassisId] /slot- [slotId]
Affected MO: fabric/server/chassis-ep-ven- [vendor] -mod[model] -ser- [serial]
Affected MO: fabric/server/compute-ep-ven- [vendor] -mod- [model] -ser- [serial]
Affected MO: fabric/server/sw- [id] /pc- [portId] /ep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /dest-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /ep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /fcoesanpcep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /phys-eth-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /phys-eth-slot- [slotId] -port- [portId] /eth-target-ep- [name]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /phys-fcoesanep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /phys-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /pc- [portId] /slot- [slotId] -aggr-port- [aggrPortId] /slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /dest-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /ep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /fcoesanpcep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /phys-eth-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /phys-eth-slot- [slotId] -port- [portId] /eth-target-ep- [name]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /phys-fcoesanep-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /phys-slot- [slotId] -port- [portId]
Affected MO:
fabric/server/sw- [id] /slot- [slotId] -aggr-port- [aggrPortId] /slot- [slotId] -port- [portId]
Affected MO: fabric/server/sw- [id] /slot- [slotId] -port- [portId]
Affected MO:
sys/switch- [id] /access-eth/slot- [slotId] -aggr-port- [aggrPortId] /ethestc-ep-slot- [slotId] -port- [portId] /eth-target- [name]
Affected MO:
sys/switch- [id] /border-eth/ethestc-ep-slot- [slotId] -port- [portId] /eth-target- [name]
Affected MO: sys/switch- [id] /border-eth/pc- [portId] /eth-target- [name]
Affected MO:
sys/switch- [id] /border-eth/slot- [slotId] -aggr-port- [aggrPortId] /ethestc-ep-slot- [slotId] -port- [portId] /eth-target- [name]
Affected MO:
sys/switch- [id] /border-fc/slot- [slotId] -aggr-port- [aggrPortId] /ethestc-ep-slot- [slotId] -port- [portId] /eth-target- [name]

Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/pc-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO: sys/switch-[id]/mgmt-port-[portId]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]

fltFabricEthLanEpMissingPrimaryVlan

Fault Code: F1053

Message

Primary vlan missing from fabric: [switchId], port: [slotId]/[aggrPortId]/[portId]. Primary vlan missing from fabric: [switchId], port: [slotId]/[portId].

Explanation

This fault occurs when an uplink port or port channel is configured with a primary VLAN that does not exist in the Cisco FPR instance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Update the configuration of the port or port channel to include a primary VLAN.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: missing-primary-vlan
mibFaultCode: 1053
mibFaultName: fltFabricEthLanEpMissingPrimaryVlan
moClass: fabric:EthLanEp
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]port-[portId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]port-[portId]
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]port-[portId]
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]port-[portId]
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]port-[portId]

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

fltFabricEthLanEpUdldLinkDown

Fault Code: F1054

Message

UDLD state for ether port [slotId]/[aggrPortId]/[portId] on fabric interconnect [switchId] is: [udldOperState].UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

Explanation

This fault occurs when an ethernet uplink port is unidirectional connected.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the tx and rx connection of the uplink port.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: warning
Cause: udld-link-down
mibFaultCode: 1054
mibFaultName: fltFabricEthLanEpUdldLinkDown
moClass: fabric:EthLanEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

fltFabricEthLanPcEpUdldLinkDown

Fault Code: F1055

Message

UDLD state for ether port [slotId]/[aggrPortId]/[portId] on fabric interconnect [switchId] is: [udldOperState].UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

Explanation

This fault occurs when an ethernet uplink port-channel member is unidirectional connected.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Check the tx and rx connection of the uplink port.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: warning
Cause: udld-link-down
mibFaultCode: 1055
mibFaultName: fltFabricEthLanPcEpUdldLinkDown
moClass: fabric:EthLanPcEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

```

Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

```

fltFabricEthLanPcMissingPrimaryVlan

Fault Code: F1056

Message

Primary vlan missing from fabric: [switchId], port-channel: [portId].

Explanation

This fault occurs when an uplink port or port channel is configured with a primary VLAN that does not exist in the Cisco FPR instance.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Update the configuration of the port or port channel to include a primary VLAN.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: missing-primary-vlan
mibFaultCode: 1056
mibFaultName: fltFabricEthLanPcMissingPrimaryVlan
moClass: fabric:EthLanPc
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/[id]/pc-[portId]

```

fltFabricEthLanEpOverlapping-vlan

Fault Code: F1057

Message

On Fabric: [switchId], Port: [slotId]/[aggrPortId]/[portId] following overlapping VLANs detected: [overlappingVlans] On Fabric: [switchId], Port: [slotId]/[portId] following overlapping VLANs detected: [overlappingVlans]

Explanation

This fault occurs when Overlapping Vlans occur due to mis configuration.

Recommended Action

Ports configured on Vlans belonging to a group should not intersect with other ports of different network group belonging to Vlans which overlap .

Fault Details

```

Severity: info
Cause: configuration-error
mibFaultCode: 1057
mibFaultName: fltFabricEthLanEpOverlappingVlan
moClass: fabric:EthLanEp
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

```

fltFabricEthLanPcOverlapping-vlan

Fault Code: F1058

Message

Overlapping VLANs detected on Fabric: [switchId], Port: [portId] in configured VLANs: [overlappingVlans]

Explanation

This fault occurs when Overlapping Vlans occur due to mis configuration.

Recommended Action

Ports configured on Vlans belonging to a group should not intersect with other ports of different network group belonging to Vlans which overlap .

Fault Details

```

Severity: info
Cause: configuration-error
mibFaultCode: 1058
mibFaultName: fltFabricEthLanPcOverlappingVlan
moClass: fabric:EthLanPc
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/[id]/pc-[portId]

```

fltFabricVlanMisconfigured-mcast-policy**Fault Code: F1059****Message**

VLAN [name] multicast policy [mcastPolicyName] is non-default.

Explanation

This fault is raised when VLAN belonging to a Springfield fabric has a non-default multicast policy assigned to it.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Un-assign multicast policy for the this vlan or change the multicast policy to default.
 - Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: vlan-mcast-policy-misconfigured
mibFaultCode: 1059
mibFaultName: fltFabricVlanMisconfiguredMcastPolicy
moClass: fabric:Vlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricPooledVlanNamedVlanUnresolved**Fault Code: F1062****Message**

VLAN [name] for VLAN group [name] cannot be resolved to any existing vlans.

Explanation

This fault typically occurs when a named VLAN in VLAN group cannot be resolved to any existing vlans.

Recommended Action

If you see this fault, take the following action:

-
- Step 1** Create VLAN.
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: named-vlan-unresolved
mibFaultCode: 1062
mibFaultName: fltFabricPooledVlanNamedVlanUnresolved
moClass: fabric:PooledVlan
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/[id]/net-group-[name]/net-[name]
Affected MO: fabric/lan/net-group-[name]/net-[name]
```

fltMgmtEntityDegraded**Fault Code: F1115****Message**

Fabric Interconnect [id], HA Cluster interconnect link failure

Explanation

This fault occurs when one of the cluster links (either L1 or L2) of a fabric interconnect is not operationally up. This issue impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that both L1 and L2 links are properly connected between the fabric interconnects.
- Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: link-down
mibFaultCode: 1115
mibFaultName: fltMgmtEntityDegraded
moClass: mgmt:Entity
Type: network
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDown

Fault Code: F1116

Message

Fabric Interconnect [id], HA Cluster interconnect total link failure

Explanation

This fault occurs when both cluster links (L1 and L2) of the fabric interconnects are in a link-down state. This issue impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that both L1 and L2 links are properly connected between the fabric interconnects.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: link-down
mibFaultCode: 1116
mibFaultName: fltMgmtEntityDown
moClass: mgmt:Entity
Type: network
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity- [id]
```

fltMgmtEntityElection-failure

Fault Code: F1117

Message

Fabric Interconnect [id], election of primary management instance has failed

Explanation

This fault occurs in an unlikely event that the fabric interconnects in a cluster configuration could not reach an agreement for selecting the primary fabric interconnect. This impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the initial setup configuration is correct on both fabric interconnects.
 - Step 2** Verify that the L1 and L2 links are properly connected between the fabric interconnects.
 - Step 3** In the Cisco FPR Manager CLI, run the **cluster force primary local-mgmt** command on one fabric interconnect.
 - Step 4** Reboot the fabric interconnects.

Step 5 If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: election-failure
mibFaultCode: 1117
mibFaultName: fltMgmtEntityElectionFailure
moClass: mgmt:Entity
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity- [id]
```

fltMgmtEntityManagement-services-failure

Fault Code: F1118

Message

Fabric Interconnect [id], management services have failed

Explanation

This fault occurs in an unlikely event that management services fail on a fabric interconnect. This impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the initial setup configuration is correct on both fabric interconnects.
 - Step 2** Verify that the L1 and L2 links are properly connected between the fabric interconnects.
 - Step 3** Reboot the fabric interconnects.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: management-services-failure
mibFaultCode: 1118
mibFaultName: fltMgmtEntityManagementServicesFailure
moClass: mgmt:Entity
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity- [id]
```

fltMgmtEntityManagement-services-unresponsive

Fault Code: F1119

Message

Fabric Interconnect [id], management services are unresponsive

Explanation

This fault occurs when management services on a fabric interconnect are unresponsive. This impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the initial setup configuration is correct on both fabric interconnects.
 - Step 2** Verify that the L1 and L2 links are properly connected between the fabric interconnects.
 - Step 3** Reboot the fabric interconnects.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: management-services-unresponsive
mibFaultCode: 1119
mibFaultName: fltMgmtEntityManagementServicesUnresponsive
moClass: mgmt:Entity
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity- [id]
```

fltMgmtEntityHa-not-ready**Fault Code: F1120****Message**

Fabric Interconnect [id], HA functionality not ready

Explanation

This fault occurs if Cisco FPR Manager cannot discover or communicate with one or more chassis or rack servers to write the HA Cluster state. This impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the initial setup configuration is correct on both fabric interconnects.
 - Step 2** Verify that the L1 and L2 links are properly connected between the fabric interconnects.
 - Step 3** Verify that the IOMs and/or FEXes are reachable and the server ports are enabled and operationally up.
 - Step 4** Verify that the chassis and/or rack servers are powered up and reachable
 - Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: ha-not-ready
```

```

mibFaultCode: 1120
mibFaultName: fltMgmtEntityHaNotReady
moClass: mgmt:Entity
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]

```

fltMgmtEntityVersion-incompatible

Fault Code: F1121

Message

Fabric Interconnect [id], management services, incompatible versions

Explanation

This fault occurs if the Cisco FPR Manager software on the subordinate fabric interconnect is not the same release as that of the primary fabric interconnect. This impacts the full HA functionality of the fabric interconnect cluster.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Upgrade the Cisco FPR Manager software on the subordinate fabric interconnect to the same release as the primary fabric interconnect and verify that both fabric interconnects are running the same release of Cisco FPR Manager.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: critical
Cause: version-incompatible
mibFaultCode: 1121
mibFaultName: fltMgmtEntityVersionIncompatible
moClass: mgmt:Entity
Type: management
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]

```

fltMgmtEntityDevice-1-shared-storage-error

Fault Code: F1122

Message

device [chassis1], error accessing shared-storage

Explanation

This fault occurs in an unlikely event that the shared storage selected for writing the cluster state is not accessible. This fault is typically a transient fault. You might see this fault when one of the following occurs: (a) the Fabric Interconnect boots, (b) the IO Module is reset, (c) the rack server is reboot, or (d)

system is upgraded/downgraded. If this fault is not cleared after the system returns to normal operation following the reboot/reset/upgrade/downgrade, then it may affect the full HA functionality of the Fabric Interconnect cluster.

Recommended Action

If this fault is not cleared even after the system returns to normal operation, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: 1122
mibFaultName: fltMgmtEntityDevice1SharedStorageError
moClass: mgmt:Entity
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDevice-2-shared-storage error

Fault Code: F1123

Message

device [chassis2], error accessing shared-storage

Explanation

This fault occurs in an unlikely event that the shared storage selected for writing the cluster state is not accessible. This fault is typically a transient fault. You might see this fault when one of the following occurs: (a) the Fabric Interconnect boots, (b) the IO Module is reset, (c) the rack server is reboot, or (d) system is upgraded/downgraded. If this fault is not cleared after the system returns to normal operation following the reboot/reset/upgrade/downgrade, then it may affect the full HA functionality of the Fabric Interconnect cluster.

Recommended Action

If this fault is not cleared even after the system returns to normal operation, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: 1123
mibFaultName: fltMgmtEntityDevice2SharedStorageError
moClass: mgmt:Entity
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]
```


fltMgmtEntityDevice-3-shared-storage error

Fault Code: F1124

Message

device [chassis3], error accessing shared-storage

Explanation

This fault occurs in an unlikely event that the shared storage selected for writing the cluster state is not accessible. This fault is typically a transient fault. You might see this fault when one of the following occurs: (a) the Fabric Interconnect boots, (b) the IO Module is reset, (c) the rack server is reboot, or (d) system is upgraded/downgraded. If this fault is not cleared after the system returns to normal operation following the reboot/reset/upgrade/downgrade, then it may affect the full HA functionality of the Fabric Interconnect cluster.

Recommended Action

If this fault is not cleared even after the system returns to normal operation, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: 1124
mibFaultName: fltMgmtEntityDevice3SharedStorageError
moClass: mgmt:Entity
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityHa-ssh-keys-mismatched

Fault Code: F1125

Message

Fabric Interconnect [id], management services, mismatched SSH keys

Explanation

This fault indicates that one of the following scenarios has occurred:

- The internal SSH keys used for HA in the cluster configuration are mismatched. This causes certain operations to fail.
- Another fabric interconnect is connected to the primary fabric interconnect in the cluster without first erasing the existing configuration in the primary.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Log into the Cisco FPR Manager CLI on the subordinate fabric interconnect.
- Step 2** Enter **connect local-mgmt**

- Step 3** Enter **erase configuration** to erase the configuration on the subordinate fabric interconnect and reboot it.
- Step 4** When the secondary fabric interconnect has rebooted, reconfigure it for the cluster.
- Step 5** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: ha-ssh-keys-mismatched
mibFaultCode: 1125
mibFaultName: fltMgmtEntityHaSshKeysMismatched
moClass: mgmt:Entity
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtPmonEntryFPRM process failure

Fault Code: F1126

Message

FPRM process [name] failed on FI [switchId]

Explanation

This fault occurs in an unlikely event of a Cisco FPR Manager process crash. Typically, the failed process restarts and recovers from the problem. Any pending operations are restarted after the process successfully restarts.

Recommended Action

If you see this fault and the process does not restart successfully, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: critical
Cause: fprm-process-failure
mibFaultCode: 1126
mibFaultName: fltMgmtPmonEntryFPRMProcessFailure
moClass: mgmt:PmonEntry
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/mgmt-entity-[id]/[name]
```

fltSysdebugMEpLogMEpLogLog

Fault Code: F1127

Message

Log capacity on [side] IOM [chassisId]/[id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity]Log capacity on Management Controller on server [id] is [capacity]

Explanation

This fault typically occurs because Cisco FPR Manager has detected that the system event log (SEL) on the server is approaching full capacity. The available capacity in the log is low. This is an info-level fault and can be ignored if you do not want to clear the SEL at this time.

Recommended Action

If you see this fault, you can clear the SEL in Cisco FPR Manager if desired.

Fault Details

```

Severity: info
Cause: log-capacity
mibFaultCode: 1127
mibFaultName: fltSysdebugMEpLogMEpLogLog
moClass: sysdebug:MEpLog
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

```

fltSysdebugMEpLogMEpLogVeryLow

Fault Code: F1128

Message

Log capacity on [side] IOM [chassisId]/[id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity]Log capacity on Management Controller on server [id] is [capacity]

Explanation

This fault typically occurs because Cisco FPR Manager has detected that the system event log (SEL) on the server is almost full. The available capacity in the log is very low. This is an info-level fault and can be ignored if you do not want to clear the SEL at this time.

Recommended Action

If you see this fault, you can clear the SEL in Cisco FPR Manager if desired.

Fault Details

```
Severity: info
```

```

Cause: log-capacity
mibFaultCode: 1128
mibFaultName: fltSysdebugMEpLogMEpLogVeryLow
moClass: sysdebug:MEpLog
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

```

fltSysdebugMEpLogMEpLogFull

Fault Code: F1129

Message

Log capacity on [side] IOM [chassisId]/[id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity]Log capacity on Management Controller on server [id] is [capacity]

Explanation

This fault typically occurs because Cisco FPR Manager could not transfer the SEL file to the location specified in the SEL policy. This is an info-level fault and can be ignored if you do not want to clear the SEL at this time.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify the configuration of the SEL policy to ensure that the location, user, and password provided are correct.
 - Step 2** If you do want to transfer and clear the SEL and the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: log-capacity
mibFaultCode: 1129
mibFaultName: fltSysdebugMEpLogMEpLogFull
moClass: sysdebug:MEpLog
Type: operational

```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

```

fltSysdebugMEpLogTransferError

Fault Code: F1130

Message

Server [chassisId]/[slotId] [type] transfer failed: [operState]Server [id] [type] transfer failed: [operState]

Explanation

This fault occurs when the transfer of a managed endpoint log file, such as the SEL, fails.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** If the fault is related to the SEL, verify the connectivity to the CIMC on the server.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: info
Cause: file-transfer-failed
mibFaultCode: 1130
mibFaultName: fltSysdebugMEpLogTransferError
moClass: sysdebug:MEpLog
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]

```

```

Affected MO: sys/mgmt/log- [type] - [id]
Affected MO: sys/rack-unit- [id] /adaptor- [id] /mgmt/log- [type] - [id]
Affected MO: sys/rack-unit- [id] /boardController/mgmt/log- [type] - [id]
Affected MO: sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt/log- [type] - [id]
Affected MO: sys/rack-unit- [id] /ext-board- [id] /mgmt/log- [type] - [id]
Affected MO: sys/rack-unit- [id] /mgmt/log- [type] - [id]
Affected MO: sys/switch- [id] /mgmt/log- [type] - [id]

```

fltMgmtIfMisConnect

Fault Code: F1131

Message

Management Port [id] in server [id] is mis connected

Explanation

This fault occurs when the server and FEX connectivity changes.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the connectivity between the server and FEX.
 - Step 2** If the connectivity was changed by mistake, restore it to its previous configuration.
 - Step 3** If the connectivity change was intentional, reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: link-misconnected
mibFaultCode: 1131
mibFaultName: fltMgmtIfMisConnect
moClass: mgmt:If
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /adaptor- [id] /host-eth- [id] /if- [id]
Affected MO: sys/chassis- [id] /blade- [slotId] /adaptor- [id] /mgmt/if- [id]
Affected MO: sys/chassis- [id] /blade- [slotId] /boardController/mgmt/if- [id]
Affected MO:
sys/chassis- [id] /blade- [slotId] /ext-board- [id] /boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /mgmt/if- [id]
Affected MO: sys/chassis- [id] /blade- [slotId] /mgmt/if- [id]
Affected MO: sys/chassis- [id] /slot- [id] /mgmt/if- [id]
Affected MO: sys/chassis- [id] /sw-slot- [id] /mgmt/if- [id]
Affected MO: sys/fex- [id] /mgmt/if- [id]
Affected MO: sys/fex- [id] /slot- [id] /mgmt/if- [id]
Affected MO: sys/mgmt/if- [id]
Affected MO: sys/rack-unit- [id] /adaptor- [id] /host-eth- [id] /if- [id]
Affected MO: sys/rack-unit- [id] /adaptor- [id] /mgmt/if- [id]
Affected MO: sys/rack-unit- [id] /boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id] /ext-board- [id] /mgmt/if- [id]
Affected MO: sys/rack-unit- [id] /mgmt/if- [id]
Affected MO: sys/switch- [id] /mgmt/if- [id]

```

fltMgmtIfMissing

Fault Code: F1132

Message

Connection to Management Port [id] in server [id] is missing

Explanation

This fault occurs when the connectivity between a server and FEX is removed or unconfigured.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the connectivity between the server and FEX.
 - Step 2** If the connectivity was changed by mistake, restore it to its previous configuration.
 - Step 3** If the connectivity change was intentional, reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: link-missing
mibFaultCode: 1132
mibFaultName: fltMgmtIfMissing
moClass: mgmt:If
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fltMgmtIfNew

Fault Code: F1133

Message

New connection discovered on Management Port [id] in server [id]

Explanation

This fault occurs when the connectivity between a server and a FEX is added or changed.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the connectivity between the server and FEX.
 - Step 2** If the connectivity was changed by mistake, restore it to its previous configuration.
 - Step 3** If the connectivity change was intentional, reacknowledge the server.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: new-link
mibFaultCode: 1133
mibFaultName: fltMgmtIfNew
moClass: mgmt:If
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```


fltMgmtConnectionDisabled

Fault Code: F1134

Message

Management Connection [type] in server [id] is not operational

Explanation

This fault occurs when multiple management connections are acknowledged.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Disable the management connection which is unused.
 - Step 2** If new management connection needs to be used, decommission and recommission server.
 - Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: another-connection-already-enabled
mibFaultCode: 1134
mibFaultName: fltMgmtConnectionDisabled
moClass: mgmt:Connection
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[t
ype]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/switch-[id]/mgmt/mgmt-connection-[type]

```

fltMgmtConnectionUnused

Fault Code: F1135

Message

Management Connection [type] in server [id] is unused

Explanation

This fault occurs when a management connection is not enabel

Recommended Action

If you see this fault, you can enable the connection if none of the management connections are enabled. Else this can be ignored

Fault Details

```

Severity: info
Cause: connection-unused
mibFaultCode: 1135
mibFaultName: fltMgmtConnectionUnused
moClass: mgmt:Connection
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/mgmt-connection- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/boardController/mgmt/mgmt-connection- [type]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/mgmt-connection- [t
ype]
Affected MO:
sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/mgmt-connection- [type]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/fex- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/mgmt/mgmt-connection- [type]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/mgmt-connection- [type]
Affected MO:
sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/mgmt-connection- [type]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/rack-unit- [id]/mgmt/mgmt-connection- [type]
Affected MO: sys/switch- [id]/mgmt/mgmt-connection- [type]

```

fltMgmtConnectionUnsupportedConnectivity

Fault Code: F1136

Message

Unsupported connectivity for management connection [type] in server [id]

Explanation

This fault typically occurs because Cisco FPR Manager has detected that the physical connectivity of the management port of the server is unsupported.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Connect the management port/s of the rack mount server to the Fabric Extender/s
- Step 2** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: minor
Cause: unsupported-connectivity
mibFaultCode: 1136
mibFaultName: fltMgmtConnectionUnsupportedConnectivity
moClass: mgmt:Connection
Type: operational
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/switch-[id]/mgmt/mgmt-connection-[type]

```

fltMgmtControllerUnsupportedDimmBlacklisting

Fault Code: F1137

Message

Dimm blacklisting is not supported on server [chassisId]/[slotId]Dimm blacklisting is not supported on server [id]

Explanation

This fault typically occurs when the CIMC firmware on a server is an earlier release than Cisco FPR, Release 2.2.

Recommended Action

If you see this fault, consider upgrading the CIMC firmware, and the entire Cisco FPR instance if necessary, to Cisco FPR, Release 2.2 or later.

Fault Details

```

Severity: info
Cause: incompatible-server-firmware
mibFaultCode: 1137
mibFaultName: fltMgmtControllerUnsupportedDimmBlacklisting
moClass: mgmt:Controller
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fltMgmtInterfaceNamedInbandVlanUnresolved

Fault Code: F1138

Message

[configMessage]

Explanation

This fault occurs if there is an issue in Inband interface configuration.

Recommended Action

If you see this fault check if the VLAN configured on Inband IP is created and the VLAN is present in the Inband Profile or IP address is configured

Fault Details

```

Severity: minor
Cause: named-inband-vlan-unresolved
mibFaultCode: 1138
mibFaultName: fltMgmtInterfaceNamedInbandVlanUnresolved
moClass: mgmt:Interface
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]/iface-[mode]

```

```

Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

```

fltMgmtInterfaceInbandUnsupportedServer

Fault Code: F1139

Message

[configMessage]

Explanation

This fault occurs if there is an issue in Inband interface configuration.

Recommended Action

If you see this fault check if the VLAN configured on Inband IP is created and the VLAN is present in the Inband Profile or IP address is configured

Fault Details

```

Severity: minor
Cause: inband-unsupported-server
mibFaultCode: 1139
mibFaultName: fltMgmtInterfaceInbandUnsupportedServer
moClass: mgmt:Interface
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]

```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

fltMgmtInterfaceInbandUnsupportedFirmware

Fault Code: F1140

Message

[configMessage]

Explanation

This fault occurs if there is an issue in Inband interface configuration.

Recommended Action

If you see this fault check if the VLAN configured on Inband IP is created and the VLAN is present in the Inband Profile or IP address is configured

Fault Details

Severity: minor
Cause: unsupported-cimc-firmware
mibFaultCode: 1140
mibFaultName: fltMgmtInterfaceInbandUnsupportedFirmware
moClass: mgmt:Interface
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

fltPortPloLink-down

Fault Code: F1150

Message

[transport] port [portId] on chassis [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

Explanation

This fault occurs when a fabric interconnect port is in link-down state. This state impacts the traffic destined for the port.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the physical link is properly connected between the fabric interconnect and the peer component.
 - Step 2** Verify that the configuration on the peer entity is properly configured and matches the fabric interconnect port configuration.
 - Step 3** Unconfigure and re-configure the port.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: link-down
mibFaultCode: 1150
mibFaultName: fltPortPloLinkDown
moClass: port:PIo
Type: network
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltPortPIoFailed

Fault Code: F1151

Message

[transport] port [portId] on chassis [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

Explanation

This fault is raised on fabric interconnect ports and on server-facing ports on an IOM or a FEX module when FPRM detects that the port is not up and in failed state while it is expected to be up since it has been enabled by user and there is no known hardware failure or missing SFP issue and port license is valid. Additional reason is displayed by the fault description string.

Recommended Action

If you see this fault, Corrective action maybe taken based on reason information in the fault description whenever such a reason is displayed. If the fault description displays reason as "ENM source pinning failed" then it means that the fabric interconnect is operating in End-host Node Mode and the uplink port that this server facing port is pinned to is down or does not have appropriate VLAN configured. In case of such an error for an appliance port check the VLAN configuration on uplink port. A VLAN with same id as the one on the appliance port will also need to be configured on the uplink port. After setting the configuration right if you still see the fault then create a **show tech-support** file for Cisco FPR Manager and the chassis or FEX module, and then contact Cisco TAC.

Fault Details

```
Severity: minor
Cause: port-failed
mibFaultCode: 1151
mibFaultName: fltPortPIoFailed
moClass: port:PIo
Type: network
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```


fltPortPloHardware-failure

Fault Code: F1152

Message

[transport] port [portId] on chassis [id] oper state: [operState], reason: hardware-failure[transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: hardware-failure[transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: hardware-failure

Explanation

This fault is raised on fabric interconnect ports and server-facing ports on an IOM or a FEX module when the system detects a hardware failure.

Recommended Action

If you see this fault, create a **show tech-support** file for Cisco FPR Manager and the chassis or FEX module, and then contact Cisco TAC.

Fault Details

```
Severity: major
Cause: port-failed
mibFaultCode: 1152
mibFaultName: fltPortPloHardwareFailure
moClass: port:Plo
Type: network
Callhome: diagnostic
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltPortPloSfp-not-present

Fault Code: F1153

Message

[transport] port [portId] on chassis [id] oper state: [operState][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState]

Explanation

When a fabric interconnect port is not in an unconfigured state, an SFP is required for its operation. This fault is raised to indicate that the SFP is missing from a configured port.

Recommended Action

If you see this fault, insert a supported SFP into the port on the fabric interconnect. A list of supported SFPs can be found on www.Cisco.com.

Fault Details

```

Severity: info
Cause: port-failed
mibFaultCode: 1153
mibFaultName: fltPortPIoSfpNotPresent
moClass: port:PIo
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]

```

fltPortPIoInvalid-sfp**Fault Code: F1154****Message**

```

[transport] port [portId] on chassis [id] role : [ifRole] transceiver type:[xcvrType][transport] port
[slotId]/[aggrPortId]/[portId] on fabric interconnect [id] role : [ifRole] transceiver
type:[xcvrType][transport] port [slotId]/[portId] on fabric interconnect [id] role : [ifRole] transceiver
type:[xcvrType]

```

Explanation

This fault is raised against a fabric interconnect port, network-facing IOM port, or FEX module port if an unsupported transceiver type is inserted. The port cannot be used if it has an unsupported transceiver.

Recommended Action

If you see this fault, replace the transceiver with a supported SFP type. Refer to the documentation on the Cisco website for a list of supported SFPs.

Fault Details

```

Severity: major
Cause: unsupported-transceiver
mibFaultCode: 1154
mibFaultName: fltPortPIoInvalidSfp
moClass: port:PIo
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]

```

fltEtherServerIntFioHardware-failure

Fault Code: F1155

Message

IOM [transport] interface [portId] on chassis [id] oper state: [operState], reason: [stateQual]Fabric Interconnect [transport] interface [portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]IOM [transport] interface [portId] on fex [id] oper state: [operState], reason: [stateQual]

Explanation

This fault is raised on the IOM/FEX backplane ports when Cisco FPR Manager detects a hardware failure.

Recommended Action

If you see this fault, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: interface-failed
mibFaultCode: 1155
mibFaultName: fltEtherServerIntFioHardwareFailure
moClass: ether:ServerIntFio
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/rack-unit-[id]/diag/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltFabricExternalPcDown

Fault Code: F1156

Message

[type] port-channel [portId] on fabric interconnect [switchId] oper state: [operState], reason: [stateQual][type] port-channel [portId] on fabric interconnect [switchId] oper state: [operState], reason: [stateQual]

Explanation

This fault typically occurs when a fabric interconnect reports that a fabric port channel is operationally down.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the member ports in the fabric port channel are administratively up and operational. Check the link connectivity for each port.

- Step 2** If connectivity seems correct, check the operational states on the peer switch ports of the port channel members.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: operational-state-down
mibFaultCode: 1156
mibFaultName: fltFabricExternalPcDown
moClass: fabric:ExternalPc
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/eth-estc/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]
Affected MO: fabric/eth-estc/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/net-group-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]
Affected MO: fabric/lan/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/net-group-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/san/[id]/fcoepc-switch-[switchId]-fcoepc-[portId]
Affected MO: fabric/san/[id]/net-[name]/fcoepc-switch-[switchId]-fcoepc-[portId]
Affected MO: fabric/san/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/san/[id]/pc-[portId]
Affected MO: fabric/san/net-[name]/fcoepc-switch-[switchId]-fcoepc-[portId]
Affected MO: fabric/san/net-[name]/pc-switch-[switchId]-pc-[portId]

```

fltFabricInternalPcDown

Fault Code: F1157

Message

[type] port-channel [portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

Explanation

This fault occurs when the transport VIF for a server is down. Cisco FPR Manager raises this fault when a fabric interconnect reports the connectivity state on virtual interface as one of the following:

- Down
- Errored
- Unavailable

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the blade server discovery was successful.
- Step 2** Check the states on all communicating ports from end to end.
- Step 3** If connectivity seems correct, decommission and recommission the server.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: operational-state-down
mibFaultCode: 1157
mibFaultName: fltFabricInternalPcDown
moClass: fabric:InternalPc
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/server/sw-[id]/pc-[portId]

fltDcxVcDown**Fault Code: F1158****Message**

[transport] VIF [id] on server [chassisId] / [slotId] of switch [switchId] down, reason: [stateQual][transport] VIF [id] on server [id] of switch [switchId] down, reason: [stateQual]

Explanation

This fault typically occurs when a fabric interconnect reports one of the following connectivity states for a virtual interface:

- Down
- Errored
- Unavailable

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the uplink physical interface is up.
- Step 2** If the vNIC/vHBA is configured for a pin group, verify that the pin group targets are configured correctly.
- Step 3** In the Network Control Policy for the vNIC, verify that the 'Action on Uplink Fail' field is set to 'warning'.
- Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

Severity: major
Cause: link-down
mibFaultCode: 1158
mibFaultName: fltDcxVcDown
moClass: dcx:Vc
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/fex-[id]/fabric-[switchId]/vc-[id]

Affected MO:
 sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/fabric-[switchId]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]

Affected MO:
 sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

Affected MO:
 sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]

fltDcxVcMgmt-vif-down

Fault Code: F1159

Message

IOM [chassisId] / [slotId] ([switchId]) management VIF [id] down, reason [stateQual]

Explanation

This fault occurs when the transport VIF for an I/O module is down. Cisco FPR Manager raises this fault when a fabric interconnect reports the connectivity state on virtual interface as one of the following:

- Down
- Errored
- Unavailable

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the chassis discovery has gone through successfully. Check the states on all communicating ports from end to end.
- Step 2** If connectivity seems correct, decommission and recommission the chassis.
- Step 3** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: cmc-vif-down
mibFaultCode: 1159
mibFaultName: fltDcxVcMgmtVifDown
moClass: dcx:Vc
Type: network
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]

```

```

Affected MO: sys/fex-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]

```

fltPolicyControlEpSuspendModeActive

Fault Code: F1174

Message

FPRM is suspended from receiving updates from FPR Central.

Explanation

This fault occurs when FPRM enters into suspend state from receiving updates from FPR Central that it is registered with.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Please check if FPR Central is restored to a previous version or a policy roll-back has occurred. You may have brought FPR in to manual suspension mode by using **set suspendstate on** command under the system-control-ep policy scope.
 - Step 2** Please confirm the suspend state by using **show control-ep policy detail** under system scope. If you still want to receive the updates from FPR Central, you need to restore it back to a version compatible with FPRM or set the suspend state to off by acknowledging it by using **set ackstate acked** under policy-control scope.
 - Step 3** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: warning
Cause: suspend-mode-entered
mibFaultCode: 1174

```



```

mibFaultName: fltPolicyControlEpSuspendModeActive
moClass: policy:ControlEp
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]

```

fltProcessorUnitThermalProblem

Fault Code: F1308

Message

[typeInKp] thermal state is upper-critical. [faultMsg]

Explanation

This fault typically occurs when the processor unit thermal sensors have detected a problem.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Make sure that the fans are working properly.
 - Step 2** If the above action did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```

Severity: major
Cause: thermal-problem
mibFaultCode: 1308
mibFaultName: fltProcessorUnitThermalProblem
moClass: processor:Unit
Type: environmental
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/board/cpu- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/npu/cpu- [id]
Affected MO: sys/rack-unit- [id]/board/cpu- [id]

```

fltFirmwareInfraPackInfraBundleVersionMissing

Fault Code: F1309

Message

Bundle version in firmware package is empty, need to re-install

Explanation

This fault typically occurs when the bundle version in a firmware infrastructure package is not set.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In the CLI, under scope `org/fw-infra-pack`, set the `infra-bundle-version` to a desired or expected running version.

Fault Details

```

Severity: critical
Cause: default-infra-version-missing
mibFaultCode: 1309
mibFaultName:fltFirmwareInfraPackInfraBundleVersionMissing
moClass: firmware:InfraPack
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/fw-infra-pack- [name]

```

fltFirmwareSystemInfraBundleValidationFailure

Fault Code: F1310

Message

Software Pack upgrade failed validation

Explanation

This fault typically occurs when the bundle upgrade failed the image signature validation

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** In the CLI, under scope `firmware`, delete the software pack and redownload again. If problem still persists, please contact customer support

Fault Details

```

Severity: major
Cause: default-infra-bundle-validation-failed
mibFaultCode: 1310
mibFaultName:fltFirmwareSystemInfraBundleValidationFailure
moClass: firmware:System
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fltFirmwareSystemInfraBundleUpgradeFailure

Fault Code: F1311

Message

Software Pack upgrade failure: [upgradeStatus]

Explanation

This fault typically occurs when the bundle upgrade failed to upgrade one or more platform image(s)

Recommended Action

If you see this fault, please contact customer support

Fault Details

```
Severity: critical
Cause: default-infra-bundle-upgrade-failure
mibFaultCode: 1311
mibFaultName: fltFirmwareSystemInfraBundleUpgradeFailure
moClass: firmware:System
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fltFirmwareSystemFirmwareUpgradeFailure**Fault Code: F1312****Message**

Failed to upgrade Firmware Image

Explanation

This fault typically occurs when firmware image is failed to upgrade

Recommended Action

If you see this fault, please contact customer support

Fault Details

```
Severity: critical
Cause: default-firmware-upgrade-failure
mibFaultCode: 1312
mibFaultName: fltFirmwareSystemFirmwareUpgradeFailure
moClass: firmware:System
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fltFirmwareSystemTooManyKeysInstalled**Fault Code: F1314****Message**

Too many keys on the system Primary/Backup Release Keys([numPrimaryReleaseKeys], [numBackupReleaseKeys])

Explanation

This fault typically occurs when the firmware was not properly install on the system

Recommended Action

If you see this fault, please contact customer support

Fault Details

```
Severity: info
Cause: too-many-keys-on-system
mibFaultCode: 1314
mibFaultName: fltFirmwareSystemTooManyKeysInstalled
moClass: firmware:System
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fltFirmwareSystemDevkeysInstalled**Fault Code: F1315****Message**

System is installed with development keys

Explanation

This fault typically occurs when the development keys are installed on the system

Recommended Action

If you see this fault, please contact customer support

Fault Details

```
Severity: info
Cause: devkeys-installed-on-system
mibFaultCode: 1315
mibFaultName: fltFirmwareSystemDevkeysInstalled
moClass: firmware:System
Type: management
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fltEquipmentFanModuleFanModuleUnidentified**Fault Code: F1322****Message**

Fan module inserted unidentified

Explanation

This fault typically occurs when Cisco FPR Manager can not identify a Fan Tray

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the fan tray is properly installed in the chassis.
 - Step 2** Remove the fan tray and reinstall it.
 - Step 3** Make sure that a Cisco Firepower fan tray is inserted.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: fan-module-unidentified
mibFaultCode: 1322
mibFaultName: fltEquipmentFanModuleFanModuleUnidentified
moClass: equipment:FanModule
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuPsuUnidentified**Fault Code: F1323****Message**

Power supply inserted into slot [id] unidentified

Explanation

This fault typically occurs when Cisco FPR Manager can not identify a PSU

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Verify that the PSU is properly installed in the chassis.
 - Step 2** Remove the PSU and reinstall it.
 - Step 3** Make sure that a Cisco Firepower Psu is inserted.
 - Step 4** If the above actions did not resolve the issue, create a **show tech-support** file and contact Cisco TAC.

Fault Details

```
Severity: major
Cause: psu-unidentified
mibFaultCode: 1323
mibFaultName: fltEquipmentPsuPsuUnidentified
moClass: equipment:Psu
Type: equipment
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/psu-[id]
```

Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

fltEquipmentPsuPsuFanProblem

Fault Code: F1324

Message

Power supply [id] in chassis [id] Fan Status: [psuFanStatus]Power supply [id] in fabric interconnect [id] Fan Status: [psuFanStatus]Power supply [id] in fex [id] Fan Status: [psuFanStatus]Power supply [id] in server [id] Fan Status: [psuFanStatus]

Explanation

This fault typically occurs when Cisco FPR Manager detects a problem with PSU Fan

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: major
Cause: psu-fan-problem
mibFaultCode: 1324
mibFaultName: fltEquipmentPsuPsuFanProblem
moClass: equipment:Psu
Type: environmental
Callhome: environmental
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /psu- [id]
Affected MO: sys/fex- [id] /psu- [id]
Affected MO: sys/rack-unit- [id] /psu- [id]
Affected MO: sys/switch- [id] /psu- [id]

fltEquipmentChassisBoot-problem

Fault Code: F1325

Message

Device [id] Boot Status: [bootStatus]

Explanation

This fault occurs in the event that the Chassis Boot Status is not normal

Recommended Action



FSM Faults

This chapter provides information about the faults that may be raised during one or more stages of an FSM task.



Note

Unless an FSM fault appears on the Overview page, you do not need to take any action to resolve the fault. FSM stages fail and retry for many reasons. These faults do not always indicate an issue with a component or the FSM.

fsmStFailComputeServerDiscPolicyResolveScrubPolicy:Resolve

Fault Code: F16476

Message

[FSM:STAGE:FAILEDIRETRY]: Resolving scrub
policy(FSM-STAGE:sam:dme:ComputeServerDiscPolicyResolveScrubPolicy:Resolve)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-failed
mibFaultCode: 16476
mibFaultName: fsmStFailComputeServerDiscPolicyResolveScrubPolicyResolve
moClass: compute:ServerDiscPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/server-discovery
```

fsmStFailGmetaHolderInventory:CheckInventoryStatus

Fault Code: F16477

Message

[FSM:STAGE:FAILED|RETRY]: Throttle
inventory(FSM-STAGE:sam:dme:GmetaHolderInventory:CheckInventoryStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: check-inventory-status-failed
mibFaultCode: 16477
mibFaultName: fsmStFailGmetaHolderInventoryCheckInventoryStatus
moClass: gmeta:Holder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: gmeta/category-[category]-provider-[provider]

fsmStFailGmetaHolderInventory:ReportFullInventory

Fault Code: F16477

Message

[FSM:STAGE:FAILED|RETRY]: Report
inventory(FSM-STAGE:sam:dme:GmetaHolderInventory:ReportFullInventory)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: report-full-inventory-failed
mibFaultCode: 16477
mibFaultName: fsmStFailGmetaHolderInventoryReportFullInventory
moClass: gmeta:Holder
Type: fsm
Callhome: none


```

Auto Cleared: true
Is Implemented: true
Affected MO: gmeta/category- [category] -provider- [provider]

```

fsmStFailFirmwareDownloaderDownload:CheckPendingNetworkConfig

Fault Code: F16517

Message

[FSM:STAGE:FAILED|RETRY]: checking pending management network config(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:CheckPendingNetworkConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: check-pending-network-config-failed
mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadCheckPendingNetworkConfig
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

```

fsmStFailFirmwareDownloaderDownload:CopyRemote

Fault Code: F16517

Message

[FSM:STAGE:FAILED|RETRY]: sync images to subordinate(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-remote-failed

```

```

mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadCopyRemote
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

```

fsmStFailFirmwareDownloaderDownload:DeleteExtraImages

Fault Code: F16517

Message

[FSM:STAGE:FAILED|RETRY]: deleting extra distributable images(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteExtraImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: delete-extra-images-failed
mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadDeleteExtraImages
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

```

fsmStFailFirmwareDownloaderDownload:DeleteLocal

Fault Code: F16517

Message

[FSM:STAGE:FAILED|RETRY]: deleting downloadable [fileName] on local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-local-failed
mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadDeleteLocal
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmStFailFirmwareDownloaderDownload:Local**Fault Code: F16517****Message**

```
[FSM:STAGE:FAILED|RETRY]: downloading image [fileName] from
[server](FSM-STAGE:sam:dme:FirmwareDownloaderDownload:Local)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadLocal
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmStFailFirmwareDownloaderDownload:UnpackLocal

Fault Code: F16517

Message

[FSM:STAGE:FAILED|RETRY]: unpacking image [fileName] on primary(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 16517
mibFaultName: fsmStFailFirmwareDownloaderDownloadUnpackLocal
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmStFailFirmwareImageDelete:Local

Fault Code: F16518

Message

[FSM:STAGE:FAILED|RETRY]: deleting image file [name] ([invTag]) from primary(FSM-STAGE:sam:dme:FirmwareImageDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16518
mibFaultName: fsmStFailFirmwareImageDeleteLocal
moClass: firmware:Image
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/image-[name]

```

fsmStFailFirmwareImageDelete:Remote

Fault Code: F16518

Message

[FSM:STAGE:FAILED|RETRY]: deleting image file [name] ([invTag]) from secondary(FSM-STAGE:sam:dme:FirmwareImageDelete:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remote-failed
mibFaultCode: 16518
mibFaultName: fsmStFailFirmwareImageDeleteRemote
moClass: firmware:Image
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/image-[name]

```

fsmStFailFirmwareDistributableDelete:Local

Fault Code: F16519

Message

[FSM:STAGE:FAILED|RETRY]: deleting package [name] from primary(FSM-STAGE:sam:dme:FirmwareDistributableDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed

```

```

mibFaultCode: 16519
mibFaultName: fsmStFailFirmwareDistributableDeleteLocal
moClass: firmware:Distributable
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]

```

fsmStFailFirmwareDistributableDelete:Remote

Fault Code: F16519

Message

[FSM:STAGE:FAILED|RETRY]: deleting package [name] from secondary(FSM-STAGE:sam:dme:FirmwareDistributableDelete:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remote-failed
mibFaultCode: 16519
mibFaultName: fsmStFailFirmwareDistributableDeleteRemote
moClass: firmware:Distributable
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]

```

fsmStFailMgmtControllerUpdateUCSManager:copyExtToLocal

Fault Code: F16520

Message

[FSM:STAGE:FAILED|RETRY]: copying image from external repository to local repository(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:copyExtToLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-ext-to-local-failed
mibFaultCode: 16520
mibFaultName: fsmStFailMgmtControllerUpdateUCSManagerCopyExtToLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateUCSManager:copyExtToPeer**Fault Code: F16520****Message**

[FSM:STAGE:FAILEDIRETRY]: copying image from external repository to local repository of peer(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:copyExtToPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-ext-to-peer-failed
mibFaultCode: 16520
mibFaultName: fsmStFailMgmtControllerUpdateUCSManagerCopyExtToPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt

```

```

Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateUCSManager:execute

Fault Code: F16520

Message

[FSM:STAGE:FAILED|RETRY]: Updating firmware
image(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 16520
mibFaultName: fsmStFailMgmtControllerUpdateUCSManagerExecute
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```


fsmStFailMgmtControllerUpdateUCSManager:start

Fault Code: F16520

Message

[FSM:STAGE:FAILED|RETRY]: Scheduling firmware image update(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:start)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: start-failed
mibFaultCode: 16520
mibFaultName: fsmStFailMgmtControllerUpdateUCSManagerStart
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:copyToLocal

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: copying image from external repository to local repository(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:copyToLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-to-local-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchCopyToLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:copyToPeer

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: copying image from external repository to local repository of peer(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:copyToPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-to-peer-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchCopyToPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none

```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:resetLocal

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: rebooting local fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:resetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: reset-local-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchResetLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt

```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmStFailMgmtControllerUpdateSwitch:resetRemote

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: rebooting remote fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:resetRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: reset-remote-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchResetRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmStFailMgmtControllerUpdateSwitch:updateLocal

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: updating local fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:updateLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-local-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchUpdateLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:updateRemote

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: updating peer fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:updateRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-remote-failed
mibFaultCode: 16521

```

```

mibFaultName: fsmStFailMgmtControllerUpdateSwitchUpdateRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:verifyLocal

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: verifying boot variables for local fabric interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:verifyLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: verify-local-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchVerifyLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt

```

```

Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateSwitch:verifyRemote

Fault Code: F16521

Message

[FSM:STAGE:FAILED|RETRY]: verifying boot variables for remote fabric interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:verifyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: verify-remote-failed
mibFaultCode: 16521
mibFaultName: fsmStFailMgmtControllerUpdateSwitchVerifyRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerUpdateIOM:CopyIOMImgToSub

Fault Code: F16522

Message

[FSM:STAGE:FAILED|RETRY]: Copying IOM Image to subordinate
FI(FSM-STAGE:sam:dme:MgmtControllerUpdateIOM:CopyIOMImgToSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copyiomimg-to-sub-failed
mibFaultCode: 16522
mibFaultName: fsmStFailMgmtControllerUpdateIOMCopyIOMImgToSub
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmStFailMgmtControllerUpdateIOM:CopyImgFromRep

Fault Code: F16522

Message

[FSM:STAGE:FAILED|RETRY]: Copying IOM Image from repository to
FI(FSM-STAGE:sam:dme:MgmtControllerUpdateIOM:CopyImgFromRep)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-img-from-rep-failed
mibFaultCode: 16522
mibFaultName: fsmStFailMgmtControllerUpdateIOMCopyImgFromRep
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailFirmwarePlatformPackPlatformVersion:Restore**Fault Code: F16523****Message**

[FSM:STAGE:FAILED|RETRY]: Check and Restore the Platform Version(FSM-STAGE:sam:dme:FirmwarePlatformPackPlatformVersion:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: restore-failed
mibFaultCode: 16523
mibFaultName: fsmStFailFirmwarePlatformPackPlatformVersionRestore
moClass: firmware:PlatformPack
Type: fsm
Callhome: none

```

```

Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /fw-platform-pack- [name]

```

fsmStFailFirmwarePlatformPackPlatformVersion:WaitForReady

Fault Code: F16523

Message

[FSM:STAGE:FAILED|RETRY]: Wait for system to be ready(FSM-STAGE:sam:dme:FirmwarePlatformPackPlatformVersion:WaitForReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-ready-failed
mibFaultCode: 16523
mibFaultName: fsmStFailFirmwarePlatformPackPlatformVersionWaitForReady
moClass: firmware:PlatformPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /fw-platform-pack- [name]

```

fsmStFailFirmwareSystemDeploy:ActivateApplicationImage

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating Application(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateApplicationImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: activate-application-image-failed
mibFaultCode: 16524

```

```

mibFaultName: fsmStFailFirmwareSystemDeployActivateApplicationImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmStFailFirmwareSystemDeploy:ActivateFirmwareImage

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating System
Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateFirmwareImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: activate-firmware-image-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployActivateFirmwareImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmStFailFirmwareSystemDeploy:ActivateManagerImage

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating Service
Manager(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateManagerImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: activate-manager-image-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployActivateManagerImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:ActivateNpuImage

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating NPU Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateNpuImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: activate-npu-image-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployActivateNpuImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:ActivateSystemImage

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating System Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateSystemImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-system-image-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployActivateSystemImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:CheckFirmwareUpgradeStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Check Firmware Upgrade
Status(FSM-STAGE:sam:dme:FirmwareSystemDeploy:CheckFirmwareUpgradeStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-firmware-upgrade-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployCheckFirmwareUpgradeStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:CompleteFirmwareUpgrade

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Complete Firmware Pack
Upgrade(FSM-STAGE:sam:dme:FirmwareSystemDeploy:CompleteFirmwareUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: complete-firmware-upgrade-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployCompleteFirmwareUpgrade
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:DeleteCurrentApplication

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Delete Current Application(FSM-STAGE:sam:dme:FirmwareSystemDeploy:DeleteCurrentApplication)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-current-application-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployDeleteCurrentApplication
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:PollApplicationActivationStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Application Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollApplicationActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-application-activation-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployPollApplicationActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:PollDeleteCurrentApplicationStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Wait for Current Application Deletion to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollDeleteCurrentApplicationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-delete-current-application-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployPollDeleteCurrentApplicationStatus
moClass: firmware:System
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:PollManagerActivationStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Service Manager Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollManagerActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: poll-manager-activation-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployPollManagerActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:PollNpuActivationStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for NPU Image Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollNpuActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: poll-npu-activation-status-failed
mibFaultCode: 16524


```

mibFaultName: fsmStFailFirmwareSystemDeployPollNpuActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmStFailFirmwareSystemDeploy:PollStartupServiceManagerStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Setting Service Manager Startup Version to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollStartupServiceManagerStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: poll-startup-service-manager-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployPollStartupServiceManagerStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmStFailFirmwareSystemDeploy:PollSystemActivationStatus

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for System Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollSystemActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: poll-system-activation-status-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployPollSystemActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:RebootSystemForImageUpgrade

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Activating System
Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:RebootSystemForImageUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: reboot-system-for-image-upgrade-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployRebootSystemForImageUpgrade
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemDeploy:SetStartupServiceManagerVersion

Fault Code: F16524

Message

[FSM:STAGE:FAILED|RETRY]: Setting Service Manager Startup
Version(FSM-STAGE:sam:dme:FirmwareSystemDeploy:SetStartupServiceManagerVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-startup-service-manager-version-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeploySetStartupServiceManagerVersion
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:ValidateApplicationPack**Fault Code: F16524****Message**

```
[FSM:STAGE:FAILED|RETRY]: Validating the application
pack(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ValidateApplicationPack)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-application-pack-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployValidateApplicationPack
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:WaitForDeploy**Fault Code: F16524****Message**

```
[FSM:STAGE:FAILED|RETRY]: Waiting for Deploy to
begin(FSM-STAGE:sam:dme:FirmwareSystemDeploy:WaitForDeploy)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-deploy-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployWaitForDeploy
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemDeploy:WaitForSystemReady

Fault Code: F16524

Message

```
[FSM:STAGE:FAILED|RETRY]: Waiting for System
Ready(FSM-STAGE:sam:dme:FirmwareSystemDeploy:WaitForSystemReady)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-system-ready-failed
mibFaultCode: 16524
mibFaultName: fsmStFailFirmwareSystemDeployWaitForSystemReady
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSupFirmwareDeploy:ActivateFirmwarePack

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Activating SUP
Firmware(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:ActivateFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-firmware-pack-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployActivateFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmStFailFirmwareSupFirmwareDeploy:CompleteFirmwareUpgrade

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Complete Firmware Pack
Upgrade(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:CompleteFirmwareUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: complete-firmware-upgrade-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployCompleteFirmwareUpgrade
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmStFailFirmwareSupFirmwareDeploy:DebundlePort

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Debundle the ports(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:DebundlePort)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: debundle-port-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployDebundlePort
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmStFailFirmwareSupFirmwareDeploy:PollActivateOfFirmwarePack

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Firmware Activation to complete(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:PollActivateOfFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: poll-activate-of-firmware-pack-failed
mibFaultCode: 16525

```

mibFaultName: fsmStFailFirmwareSupFirmwareDeployPollActivateOfFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

```

fsmStFailFirmwareSupFirmwareDeploy:PollDebundlePort

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Ports debundle complete(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:PollDebundlePort)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: poll-debundle-port-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployPollDebundlePort
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

```

fsmStFailFirmwareSupFirmwareDeploy:UpdateImageVersion

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Updating Image Version(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:UpdateImageVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-image-version-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployUpdateImageVersion
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmStFailFirmwareSupFirmwareDeploy:UpdatePackageVersion

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Updating Package Version(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:UpdatePackageVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-package-version-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployUpdatePackageVersion
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmStFailFirmwareSupFirmwareDeploy:ValidateFirmwarePack

Fault Code: F16525

Message

[FSM:STAGE:FAILED|RETRY]: Validate the firmware pack(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:ValidateFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-firmware-pack-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployValidateFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmStFailFirmwareSupFirmwareDeploy:WaitForDeploy**Fault Code: F16525****Message**

```
[FSM:STAGE:FAILED|RETRY]: Waiting for Deploy to
begin(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:WaitForDeploy)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-deploy-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployWaitForDeploy
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmStFailFirmwareSupFirmwareDeploy:WaitForFirmwareVersionUpdate**Fault Code: F16525****Message**

```
[FSM:STAGE:FAILED|RETRY]: Waiting for Firmware Version to
update(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:WaitForFirmwareVersionUpdate)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-firmware-version-update-failed
mibFaultCode: 16525
mibFaultName: fsmStFailFirmwareSupFirmwareDeployWaitForFirmwareVersionUpdate
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmStFailFirmwareSystemApplyCatalogPack:ActivateCatalog

Fault Code: F16526

Message

[FSM:STAGE:FAILED|RETRY]: Activating
Catalog(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ActivateCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-catalog-failed
mibFaultCode: 16526
mibFaultName: fsmStFailFirmwareSystemApplyCatalogPackActivateCatalog
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemApplyCatalogPack:ResolveDistributable

Fault Code: F16526

Message

[FSM:STAGE:FAILED|RETRY]: Resolve distributable from operations manager(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveDistributable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-failed
mibFaultCode: 16526
mibFaultName: fsmStFailFirmwareSystemApplyCatalogPackResolveDistributable
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmStFailFirmwareSystemApplyCatalogPack:ResolveDistributableNames

Fault Code: F16526

Message

[FSM:STAGE:FAILED|RETRY]: Resolving distributable name(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveDistributableNames)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-names-failed
mibFaultCode: 16526
mibFaultName: fsmStFailFirmwareSystemApplyCatalogPackResolveDistributableNames
moClass: firmware:System
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailFirmwareSystemApplyCatalogPack:ResolveImages

Fault Code: F16526

Message

[FSM:STAGE:FAILED|RETRY]: Resolve images from operations manager(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-images-failed
mibFaultCode: 16526
mibFaultName: fsmStFailFirmwareSystemApplyCatalogPackResolveImages
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmStFailIdentIdentRequestUpdateIdent:Execute

Fault Code: F16528

Message

[FSM:STAGE:FAILED|RETRY]: Update identities to external identifier manager(FSM-STAGE:sam:dme:IdentIdentRequestUpdateIdent:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 16528

```

mibFaultName: fsmStFailIdentIdentRequestUpdateIdentExecute
moClass: ident:IdentRequest
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys/IdentQ-[id]

```

fsmStFailIdentMetaSystemSync:Execute

Fault Code: F16529

Message

[FSM:STAGE:FAILED|RETRY]: Synchronise ID universe to external identifier manager(FSM-STAGE:sam:dme:IdentMetaSystemSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 16529
mibFaultName: fsmStFailIdentMetaSystemSyncExecute
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

```

fsmStFailIdentMetaSystemSync:Ping

Fault Code: F16529

Message

[FSM:STAGE:FAILED|RETRY]: Check identifier manager availability(FSM-STAGE:sam:dme:IdentMetaSystemSync:Ping)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: ping-failed
mibFaultCode: 16529
mibFaultName: fsmStFailIdentMetaSystemSyncPing
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

fsmStFailIdentMetaSystemUcscUnivSync:Execute

Fault Code: F16530

Message

[FSM:STAGE:FAILED|RETRY]: Synchronise ID universe to external identifier manager(FSM-STAGE:sam:dme:IdentMetaSystemUcscUnivSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 16530
mibFaultName: fsmStFailIdentMetaSystemUcscUnivSyncExecute
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

fsmStFailSmAppDelete:Local

Fault Code: F16585

Message

[FSM:STAGE:FAILED|RETRY]: deleting the Application [name]-[version](FSM-STAGE:sam:dme:SmAppDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16585
mibFaultName: fsmStFailSmAppDeleteLocal
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst - [appInstId] /app- [name] - [version]
```

fsmStFailSmSecSvcRestoreApplication:Restore

Fault Code: F16586

Message

[FSM:STAGE:FAILED|RETRY]: Restoring Apps in progress(FSM-STAGE:sam:dme:SmSecSvcRestoreApplication:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: restore-failed
mibFaultCode: 16586
mibFaultName: fsmStFailSmSecSvcRestoreApplicationRestore
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc
```

fsmStFailSmAppUpdateApplication:Update

Fault Code: F16587

Message

[FSM:STAGE:FAILED|RETRY]: Updating Apps in progress(FSM-STAGE:sam:dme:SmAppUpdateApplication:Update)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-failed
mibFaultCode: 16587
mibFaultName: fsmStFailSmAppUpdateApplicationUpdate
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]
```

fsmStFailSmAppInstanceResetApplication:StartApps

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Start main and decorator applications(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StartApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: start-apps-failed
mibFaultCode: 16588
mibFaultName: fsmStFailSmAppInstanceResetApplicationStartApps
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId] /app-inst- [appName]
```


fsmStFailSmAppInstanceResetApplication:StopDecoratorApps

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Stop decorator applications(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StopDecoratorApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-decorator-apps-failed
mibFaultCode: 16588
mibFaultName: fsmStFailSmAppInstanceResetApplicationStopDecoratorApps
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmStFailSmAppInstanceResetApplication:StopMainApp

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Stop main application(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StopMainApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-main-app-failed
mibFaultCode: 16588
mibFaultName: fsmStFailSmAppInstanceResetApplicationStopMainApp
moClass: sm:AppInstance
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fsmStFailSmAppInstanceResetApplication:WairForStopDecorators

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Wait for stopping decorator applications to complete(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WairForStopDecorators)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wair-for-stop-decorators-failed
mibFaultCode: 16588
mibFaultName: fsmStFailSmAppInstanceResetApplicationWairForStopDecorators
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId]/app-inst- [appName]

```

fsmStFailSmAppInstanceResetApplication:WaitForBladeReboot

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Wait for blade reboot(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WaitForBladeReboot)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-blade-reboot-failed
mibFaultCode: 16588

```

```

mibFaultName: fsmStFailSmAppInstanceResetApplicationWaitForBladeReboot
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]

```

fsmStFailSmAppInstanceResetApplication:WaitForStopMainApp

Fault Code: F16588

Message

[FSM:STAGE:FAILED|RETRY]: Wait for stopping main application to complete.(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WaitForStopMainApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-stop-main-app-failed
mibFaultCode: 16588
mibFaultName: fsmStFailSmAppInstanceResetApplicationWaitForStopMainApp
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]

```

fsmStFailSmSecSvcAutoDeployCSP:CreateLogicalDevice

Fault Code: F16589

Message

[FSM:STAGE:FAILED|RETRY]: Creating a default logical device(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:CreateLogicalDevice)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: create-logical-device-failed
mibFaultCode: 16589
mibFaultName: fsmStFailSmSecSvcAutoDeployCSPCreateLogicalDevice
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

fsmStFailSmSecSvcAutoDeployCSP:WaitForChassisMoReady

Fault Code: F16589

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for chassis object ready(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForChassisMoReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-chassis-mo-ready-failed
mibFaultCode: 16589
mibFaultName: fsmStFailSmSecSvcAutoDeployCSPWaitForChassisMoReady
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

fsmStFailSmSecSvcAutoDeployCSP:WaitForPortReady

Fault Code: F16589

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for physical interfaces ready(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForPortReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-port-ready-failed
mibFaultCode: 16589
mibFaultName: fsmStFailSmSecSvcAutoDeployCSPWaitForPortReady
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc
```

fsmStFailSwAccessDomainDeploy:UpdateConnectivity

Fault Code: F16667

Message

[FSM:STAGE:FAILED|RETRY]: internal network configuration on [switchId](FSM-STAGE:sam:dme:SwAccessDomainDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 16667
mibFaultName: fsmStFailSwAccessDomainDeployUpdateConnectivity
moClass: sw:AccessDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/access-eth
```

fsmStFailSwEthLanBorderDeploy:UpdateConnectivity

Fault Code: F16668

Message

[FSM:STAGE:FAILED|RETRY]: Uplink eth port configuration on [switchId](FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 16668
mibFaultName: fsmStFailSwEthLanBorderDeployUpdateConnectivity
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmStFailSwEthLanBorderDeploy:UpdateSwitchConfigToAppAG

Fault Code: F16668

Message

[FSM:STAGE:FAILED|RETRY]: Update switch config info to appAG(FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateSwitchConfigToAppAG)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-switch-config-to-appag-failed
mibFaultCode: 16668
mibFaultName: fsmStFailSwEthLanBorderDeployUpdateSwitchConfigToAppAG
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmStFailSwEthLanBorderDeploy:UpdateSwitchPortConfigToAppAG

Fault Code: F16668

Message

[FSM:STAGE:FAILED|RETRY]: Update switch port config to appAG(FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateSwitchPortConfigToAppAG)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-switch-port-config-to-appag-failed
mibFaultCode: 16668
mibFaultName: fsmStFailSwEthLanBorderDeployUpdateSwitchPortConfigToAppAG
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmStFailSwEthLanBorderDeploy:UpdateVlanGroups

Fault Code: F16668

Message

[FSM:STAGE:FAILED|RETRY]: VLAN group configuration on [switchId](FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateVlanGroups)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-vlan-groups-failed
mibFaultCode: 16668
mibFaultName: fsmStFailSwEthLanBorderDeployUpdateVlanGroups
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth

fsmStFailSwFcSanBorderDeploy:UpdateConnectivity

Fault Code: F16669

Message

[FSM:STAGE:FAILED|RETRY]: Uplink fc port configuration on [switchId](FSM-STAGE:sam:dme:SwFcSanBorderDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 16669
mibFaultName: fsmStFailSwFcSanBorderDeployUpdateConnectivity
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc

fsmStFailSwUtilityDomainDeploy:UpdateConnectivity

Fault Code: F16670

Message

[FSM:STAGE:FAILED|RETRY]: Utility network configuration on [switchId](FSM-STAGE:sam:dme:SwUtilityDomainDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 16670


```

mibFaultName: fsmStFailSwUtilityDomainDeployUpdateConnectivity
moClass: sw:UtilityDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/utility-eth

```

fsmStFailSwPhysConfPhysical:ConfigSwA

Fault Code: F16676

Message

[FSM:STAGE:FAILED|RETRY]: Configure physical port mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:ConfigSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: config-sw-afailed
mibFaultCode: 16676
mibFaultName: fsmStFailSwPhysConfPhysicalConfigSwA
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

```

fsmStFailSwPhysConfPhysical:ConfigSwB

Fault Code: F16676

Message

[FSM:STAGE:FAILED|RETRY]: Configure physical port mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:ConfigSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: config-sw-bfailed
mibFaultCode: 16676
mibFaultName: fsmStFailSwPhysConfPhysicalConfigSwB
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

fsmStFailSwPhysConfPhysical:PortInventorySwA**Fault Code:** F16676**Message**

[FSM:STAGE:FAILED|RETRY]: Performing local port inventory of switch [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:PortInventorySwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: port-inventory-sw-afailed
mibFaultCode: 16676
mibFaultName: fsmStFailSwPhysConfPhysicalPortInventorySwA
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

fsmStFailSwPhysConfPhysical:PortInventorySwB**Fault Code:** F16676**Message**

[FSM:STAGE:FAILED|RETRY]: Performing peer port inventory of switch [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:PortInventorySwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: port-inventory-sw-bfailed
mibFaultCode: 16676
mibFaultName: fsmStFailSwPhysConfPhysicalPortInventorySwB
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys
```

fsmStFailSwPhysConfPhysical:VerifyPhysConfig**Fault Code: F16676****Message**

[FSM:STAGE:FAILED|RETRY]: Verifying physical transition on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:VerifyPhysConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-phys-config-failed
mibFaultCode: 16676
mibFaultName: fsmStFailSwPhysConfPhysicalVerifyPhysConfig
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys
```

fsmStFailSwExtUtilityConfPortBreakout:ConfigSwA**Fault Code: F16681****Message**

[FSM:STAGE:FAILED|RETRY]: Configure port breakout mode mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:ConfigSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-sw-afailed
mibFaultCode: 16681
mibFaultName: fsmStFailSwExtUtilityConfPortBreakoutConfigSwA
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmStFailSwExtUtilityConfPortBreakout:ConfigSwB

Fault Code: F16681

Message

[FSM:STAGE:FAILED|RETRY]: Configure port breakout mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:ConfigSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-sw-bfailed
mibFaultCode: 16681
mibFaultName: fsmStFailSwExtUtilityConfPortBreakoutConfigSwB
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmStFailSwExtUtilityConfPortBreakout:PortInventorySwA

Fault Code: F16681

Message

[FSM:STAGE:FAILED|RETRY]: Performing local port inventory of switch [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:PortInventorySwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: port-inventory-sw-afailed
mibFaultCode: 16681
mibFaultName: fsmStFailSwExtUtilityConfPortBreakoutPortInventorySwA
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmStFailSwExtUtilityConfPortBreakout:PortInventorySwB

Fault Code: F16681

Message

[FSM:STAGE:FAILED|RETRY]: Performing peer port inventory of switch [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:PortInventorySwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: port-inventory-sw-bfailed
mibFaultCode: 16681
mibFaultName: fsmStFailSwExtUtilityConfPortBreakoutPortInventorySwB
moClass: sw:ExtUtility
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext

fsmStFailSwExtUtilityConfPortBreakout:VerifyBreakoutConfig

Fault Code: F16681

Message

[FSM:STAGE:FAILED|RETRY]: Verifying physical port breakout config on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:VerifyBreakoutConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: verify-breakout-config-failed
mibFaultCode: 16681
mibFaultName: fsmStFailSwExtUtilityConfPortBreakoutVerifyBreakoutConfig
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext

fsmStFailSwFcSanBorderActivateZoneSet:UpdateZones

Fault Code: F16682

Message

[FSM:STAGE:FAILED|RETRY]: fc zone configuration on [switchId](FSM-STAGE:sam:dme:SwFcSanBorderActivateZoneSet:UpdateZones)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-zones-failed
mibFaultCode: 16682

```

mibFaultName: fsmStFailSwFcSanBorderActivateZoneSetUpdateZones
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc

```

fsmStFailCallhomeEpConfigCallhome:SetLocal

Fault Code: F16718

Message

[FSM:STAGE:FAILED|RETRY]: call-home configuration on primary(FSM-STAGE:sam:dme:CallhomeEpConfigCallhome:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-local-failed
mibFaultCode: 16718
mibFaultName: fsmStFailCallhomeEpConfigCallhomeSetLocal
moClass: callhome:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: call-home

```

fsmStFailCallhomeEpConfigCallhome:SetPeer

Fault Code: F16718

Message

[FSM:STAGE:FAILED|RETRY]: call-home configuration on secondary(FSM-STAGE:sam:dme:CallhomeEpConfigCallhome:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-peer-failed
mibFaultCode: 16718
mibFaultName: fsmStFailCallhomeEpConfigCallhomeSetPeer
moClass: callhome:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: call-home

fsmStFailAdaptorExtEthIfPathReset:Disable**Fault Code:** F16727**Message**

[FSM:STAGE:FAILED|RETRY]: Disable path [side]([switchId]) on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorExtEthIfPathReset:Disable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: disable-failed
mibFaultCode: 16727
mibFaultName: fsmStFailAdaptorExtEthIfPathResetDisable
moClass: adaptor:ExtEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/ext-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/ext-eth- [id]

fsmStFailAdaptorExtEthIfPathReset:Enable**Fault Code:** F16727**Message**

[FSM:STAGE:FAILED|RETRY]: Enabe path [side]([switchId]) on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorExtEthIfPathReset:Enable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-failed
mibFaultCode: 16727
mibFaultName: fsmStFailAdaptorExtEthIfPathResetEnable
moClass: adaptor:ExtEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]
```

fsmStFailAdaptorHostEthIfCircuitReset:DisableA**Fault Code: F16730****Message**

[FSM:STAGE:FAILED|RETRY]: Disable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:DisableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-afailed
mibFaultCode: 16730
mibFaultName: fsmStFailAdaptorHostEthIfCircuitResetDisableA
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]
```

fsmStFailAdaptorHostEthIfCircuitReset:DisableB

Fault Code: F16730

Message

[FSM:STAGE:FAILED|RETRY]: Disable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:DisableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-bfailed
mibFaultCode: 16730
mibFaultName: fsmStFailAdaptorHostEthIfCircuitResetDisableB
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]
```

fsmStFailAdaptorHostEthIfCircuitReset:EnableA

Fault Code: F16730

Message

[FSM:STAGE:FAILED|RETRY]: Enable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:EnableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-afailed
mibFaultCode: 16730
mibFaultName: fsmStFailAdaptorHostEthIfCircuitResetEnableA
moClass: adaptor:HostEthIf
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fsmStFailAdaptorHostEthIfCircuitReset:EnableB

Fault Code: F16730

Message

[FSM:STAGE:FAILED|RETRY]: Enable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:EnableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: enable-bfailed
mibFaultCode: 16730
mibFaultName: fsmStFailAdaptorHostEthIfCircuitResetEnableB
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fsmStFailAdaptorHostFcIfCircuitReset:DisableA

Fault Code: F16731

Message

[FSM:STAGE:FAILED|RETRY]: Disable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:DisableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: disable-afailed
mibFaultCode: 16731
mibFaultName: fsmStFailAdaptorHostFcIfCircuitResetDisableA
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]

fsmStFailAdaptorHostFcIfCircuitReset:DisableB**Fault Code:** F16731**Message**

[FSM:STAGE:FAILED|RETRY]: Disable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:DisableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: disable-bfailed
mibFaultCode: 16731
mibFaultName: fsmStFailAdaptorHostFcIfCircuitResetDisableB
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]

fsmStFailAdaptorHostFcIfCircuitReset:EnableA**Fault Code:** F16731**Message**

[FSM:STAGE:FAILED|RETRY]: Enable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:EnableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-afailed
mibFaultCode: 16731
mibFaultName: fsmStFailAdaptorHostFcIfCircuitResetEnableA
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]
```

fsmStFailAdaptorHostFcIfCircuitReset:EnableB**Fault Code: F16731****Message**

[FSM:STAGE:FAILED|RETRY]: Enable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:EnableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-bfailed
mibFaultCode: 16731
mibFaultName: fsmStFailAdaptorHostFcIfCircuitResetEnableB
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]
```

fsmStFailLicenseDownloaderDownload:CopyRemote

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: Copy the license file to subordinate for inventory(FSM-STAGE:sam:dme:LicenseDownloaderDownload:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-remote-failed
mibFaultCode: 16748
mibFaultName: fsmStFailLicenseDownloaderDownloadCopyRemote
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]
```

fsmStFailLicenseDownloaderDownload>DeleteLocal

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: deleting temporary files for [fileName] on local(FSM-STAGE:sam:dme:LicenseDownloaderDownload>DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-local-failed
mibFaultCode: 16748
mibFaultName: fsmStFailLicenseDownloaderDownloadDeleteLocal
moClass: license:Downloader
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]

```

fsmStFailLicenseDownloaderDownload>DeleteRemote

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: deleting temporary files for [fileName] on subordinate(FSM-STAGE:sam:dme:LicenseDownloaderDownload>DeleteRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: delete-remote-failed
mibFaultCode: 16748
mibFaultName: fsmStFailLicenseDownloaderDownload>DeleteRemote
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]

```

fsmStFailLicenseDownloaderDownload:Local

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: downloading license file [fileName] from [server](FSM-STAGE:sam:dme:LicenseDownloaderDownload:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 16748

```

```

mibFaultName: fsmStFailLicenseDownloaderDownloadLocal
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]

```

fsmStFailLicenseDownloaderDownload:ValidateLocal

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: validation for license file [fileName] on primary(FSM-STAGE:sam:dme:LicenseDownloaderDownload:ValidateLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: validate-local-failed
mibFaultCode: 16748
mibFaultName: fsmStFailLicenseDownloaderDownloadValidateLocal
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]

```

fsmStFailLicenseDownloaderDownload:ValidateRemote

Fault Code: F16748

Message

[FSM:STAGE:FAILED|RETRY]: validation for license file [fileName] on subordinate(FSM-STAGE:sam:dme:LicenseDownloaderDownload:ValidateRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-remote-failed
mibFaultCode: 16748
mibFaultName: fsmStFailLicenseDownloaderDownloadValidateRemote
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld- [fileName]

fsmStFailLicenseFileInstall:Local**Fault Code: F16749****Message**

[FSM:STAGE:FAILED|RETRY]: Installing license on primary(FSM-STAGE:sam:dme:LicenseFileInstall:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 16749
mibFaultName: fsmStFailLicenseFileInstallLocal
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file- [scope] : [id]

fsmStFailLicenseFileInstall:Remote**Fault Code: F16749****Message**

[FSM:STAGE:FAILED|RETRY]: Installing license on subordinate(FSM-STAGE:sam:dme:LicenseFileInstall:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 16749
mibFaultName: fsmStFailLicenseFileInstallRemote
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]
```

fsmStFailLicenseFileClear:Local**Fault Code: F16750****Message**

[FSM:STAGE:FAILED|RETRY]: Clearing license on primary(FSM-STAGE:sam:dme:LicenseFileClear:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16750
mibFaultName: fsmStFailLicenseFileClearLocal
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]
```

fsmStFailLicenseFileClear:Remote**Fault Code: F16750****Message**

[FSM:STAGE:FAILED|RETRY]: Clearing license on subordinate(FSM-STAGE:sam:dme:LicenseFileClear:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 16750
mibFaultName: fsmStFailLicenseFileClearRemote
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]
```

fsmStFailLicenseInstanceUpdateFlexlm:Local**Fault Code: F16751****Message**

[FSM:STAGE:FAILED|RETRY]: Updating on
primary(FSM-STAGE:sam:dme:LicenseInstanceUpdateFlexlm:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16751
mibFaultName: fsmStFailLicenseInstanceUpdateFlexlmLocal
moClass: license:Instance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fsmStFailLicenseInstanceUpdateFlexlm:Remote

Fault Code: F16751

Message

[FSM:STAGE:FAILED|RETRY]: Updating on subordinate(FSM-STAGE:sam:dme:LicenseInstanceUpdateFlexlm:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 16751
mibFaultName: fsmStFailLicenseInstanceUpdateFlexlmRemote
moClass: license:Instance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fsmStFailLicenseSmartConfigSetConfig:Local

Fault Code: F16752

Message

[FSM:STAGE:FAILED|RETRY]: Smart config change(FSM-STAGE:sam:dme:LicenseSmartConfigSetConfig:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 16752
mibFaultName: fsmStFailLicenseSmartConfigSetConfigLocal
moClass: license:SmartConfig
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/license-config-[operation]

```

fsmStFailLsServerConfigure:AnalyzeImpact

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Analyzing changes
 impact(FSM-STAGE:sam:dme:LsServerConfigure:AnalyzeImpact)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: analyze-impact-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureAnalyzeImpact
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]

```

fsmStFailLsServerConfigure:ApplyConfig

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Applying config to server
 [pnDn](FSM-STAGE:sam:dme:LsServerConfigure:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-config-failed

```

```

mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureApplyConfig
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmStFailLsServerConfigure:ApplyDefaultIdentifiers

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving and applying default identifiers locally(FSM-STAGE:sam:dme:LsServerConfigure:ApplyDefaultIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-default-identifiers-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureApplyDefaultIdentifiers
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmStFailLsServerConfigure:ApplyIdentifiers

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving and applying identifiers locally(FSM-STAGE:sam:dme:LsServerConfigure:ApplyIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-identifiers-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureApplyIdentifiers
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ApplyPolicies**Fault Code: F16770****Message**

[FSM:STAGE:FAILED|RETRY]: Resolving and applying policies(FSM-STAGE:sam:dme:LsServerConfigure:ApplyPolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-policies-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureApplyPolicies
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ApplyTemplate

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Applying configuration template
[srcTemplName](FSM-STAGE:sam:dme:LsServerConfigure:ApplyTemplate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-template-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureApplyTemplate
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmStFailLsServerConfigure:CommitStorage

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: committing storage for service
profile(FSM-STAGE:sam:dme:LsServerConfigure:CommitStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: commit-storage-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureCommitStorage
moClass: ls:Server
Type: fsm
```



```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmStFailLsServerConfigure:EvaluateAssociation

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Evaluate association with server
[pnDn](FSM-STAGE:sam:dme:LsServerConfigure:EvaluateAssociation)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: evaluate-association-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureEvaluateAssociation
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmStFailLsServerConfigure:ProvisionStorage

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving storage
policy(FSM-STAGE:sam:dme:LsServerConfigure:ProvisionStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: provision-storage-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureProvisionStorage
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:ResolveBootConfig**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: Computing binding changes(FSM-STAGE:sam:dme:LsServerConfigure:ResolveBootConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-boot-config-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveBootConfig
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:ResolveDefaultIdentifiers**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: Resolving default identifiers(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDefaultIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-default-identifiers-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveDefaultIdentifiers
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ResolveDistributable**Fault Code: F16770****Message**

[FSM:STAGE:FAILED|RETRY]: Resolve distributable from operations manager(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDistributable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveDistributable
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ResolveDistributableNames

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving distributable names from host pack(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDistributableNames)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-names-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveDistributableNames
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ResolveIdentifiers

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving identifiers(FSM-STAGE:sam:dme:LsServerConfigure:ResolveIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-identifiers-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveIdentifiers
moClass: ls:Server
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmStFailLsServerConfigure:ResolveImages

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolve images from operations manager(FSM-STAGE:sam:dme:LsServerConfigure:ResolveImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-images-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveImages
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmStFailLsServerConfigure:ResolveNetworkPolicies

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Resolving various dependent policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolveNetworkPolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-network-policies-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveNetworkPolicies
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:ResolveNetworkTemplates**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: Resolving various template policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolveNetworkTemplates)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-network-templates-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveNetworkTemplates
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:ResolvePolicies**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: Resolving various policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolvePolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-policies-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolvePolicies
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ResolveSchedule**Fault Code: F16770****Message**

[FSM:STAGE:FAILED|RETRY]: Resolving schedule policy(FSM-STAGE:sam:dme:LsServerConfigure:ResolveSchedule)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-schedule-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureResolveSchedule
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:ValidatePolicyOwnership

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Validating policy integrity from ownership perspective(FSM-STAGE:sam:dme:LsServerConfigure:ValidatePolicyOwnership)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-policy-ownership-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureValidatePolicyOwnership
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailLsServerConfigure:WaitForAssocCompletion

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for Association completion on server [pnDn](FSM-STAGE:sam:dme:LsServerConfigure:WaitForAssocCompletion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-assoc-completion-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureWaitForAssocCompletion
moClass: ls:Server
Type: fsm
```



```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmStFailLsServerConfigure:WaitForCommitStorage

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for storage commit to complete(FSM-STAGE:sam:dme:LsServerConfigure:WaitForCommitStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-commit-storage-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureWaitForCommitStorage
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmStFailLsServerConfigure:WaitForMaintPermission

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: Waiting for ack or maint window(FSM-STAGE:sam:dme:LsServerConfigure:WaitForMaintPermission)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-maint-permission-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureWaitForMaintPermission
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:WaitForMaintWindow**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: Waiting for maintenance window(FSM-STAGE:sam:dme:LsServerConfigure:WaitForMaintWindow)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-maint-window-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureWaitForMaintWindow
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmStFailLsServerConfigure:WaitForStorageProvision**Fault Code:** F16770**Message**

[FSM:STAGE:FAILED|RETRY]: waiting for storage provisioning to complete(FSM-STAGE:sam:dme:LsServerConfigure:WaitForStorageProvision)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-storage-provision-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureWaitForStorageProvision
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmStFailLsServerConfigure:checkAssignedDefaultIdentifiersForDup**Fault Code: F16770****Message**

[FSM:STAGE:FAILED|RETRY]: checking assigned identifiers(from default pool) for dup(FSM-STAGE:sam:dme:LsServerConfigure:checkAssignedDefaultIdentifiersForDup)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-assigned-default-identifiers-for-dup-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureCheckAssignedDefaultIdentifiersForDup
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmStFailLsServerConfigure:checkAssignedIdentifiersForDup

Fault Code: F16770

Message

[FSM:STAGE:FAILED|RETRY]: checking assigned identifiers for dup(FSM-STAGE:sam:dme:LsServerConfigure:checkAssignedIdentifiersForDup)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-assigned-identifiers-for-dup-failed
mibFaultCode: 16770
mibFaultName: fsmStFailLsServerConfigureCheckAssignedIdentifiersForDup
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmStFailComputeBladeDiag:CleanupServerConnSwA

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Cleaning up server [chassisId]/[slotId] interface on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:CleanupServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: cleanup-server-conn-sw-afailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagCleanupServerConnSwA
moClass: compute:Blade
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:CleanupServerConnSwB

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Cleaning up server [chassisId]/[slotId] interface on fabric B(FSM-STAGE:sam:dme:ComputeBladeDiag:CleanupServerConnSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: cleanup-server-conn-sw-bfailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagCleanupServerConnSwB
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:ConfigFeLocal

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Configuring primary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:ConfigFeLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: config-fe-local-failed

```

```

mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagConfigFeLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:ConfigFePeer

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Configuring secondary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:ConfigFePeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: config-fe-peer-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagConfigFePeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:DisableServerConnSwA

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Disable server [chassisId]/[slotId] interface on fabric A after completion of network traffic tests on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:DisableServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-server-conn-sw-afailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagDisableServerConnSwA
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmStFailComputeBladeDiag:DisableServerConnSwB**Fault Code: F16780****Message**

```
[FSM:STAGE:FAILEDIRETRY]: Disable server [chassisId]/[slotId] connectivity on fabric B in
preparation for network traffic tests on fabric
A(FSM-STAGE:sam:dme:ComputeBladeDiag:DisableServerConnSwB)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-server-conn-sw-bfailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagDisableServerConnSwB
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmStFailComputeBladeDiag:EnableServerConnSwA

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Enable server [chassisId]/[slotId] connectivity on fabric A in preparation for network traffic tests on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:EnableServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: enable-server-conn-sw-afailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagEnableServerConnSwA
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmStFailComputeBladeDiag:EnableServerConnSwB

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Enable server [chassisId]/[slotId] connectivity on fabric B in preparation for network traffic tests on fabric B(FSM-STAGE:sam:dme:ComputeBladeDiag:EnableServerConnSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: enable-server-conn-sw-bfailed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagEnableServerConnSwB
moClass: compute:Blade


```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:EvaluateStatus

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Evaluating status; diagnostics completed(FSM-STAGE:sam:dme:ComputeBladeDiag:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagEvaluateStatus
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:RemoveConfig

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Derive diag config for server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RemoveConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning

```

```

Cause: remove-config-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagRemoveConfig
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:RestoreConfigFeLocal

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Reconfiguring primary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RestoreConfigFeLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: restore-config-fe-local-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagRestoreConfigFeLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

```

fsmStFailComputeBladeDiag:RestoreConfigFePeer

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Reconfiguring secondary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RestoreConfigFePeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: restore-config-fe-peer-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagRestoreConfigFePeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmStFailComputeBladeDiag:SwConfigLocal**Fault Code: F16780****Message**

[FSM:STAGE:FAILED|RETRY]: Configure primary fabric interconnect in server [chassisId]/[slotId] for diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagSwConfigLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmStFailComputeBladeDiag:SwConfigPeer**Fault Code: F16780****Message**

[FSM:STAGE:FAILED|RETRY]: Configure secondary fabric interconnect in server [chassisId]/[slotId] for diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagSwConfigPeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
```

fsmStFailComputeBladeDiag:SwUnconfigLocal**Fault Code: F16780****Message**

[FSM:STAGE:FAILED|RETRY]: Unconfigure primary fabric interconnect for server [chassisId]/[slotId] in diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwUnconfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-unconfig-local-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagSwUnconfigLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
```

fsmStFailComputeBladeDiag:SwUnconfigPeer

Fault Code: F16780

Message

[FSM:STAGE:FAILED|RETRY]: Unconfigure secondary fabric interconnect for server [chassisId]/[slotId] in diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwUnconfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-unconfig-peer-failed
mibFaultCode: 16780
mibFaultName: fsmStFailComputeBladeDiagSwUnconfigPeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmStFailMgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgLocal

Fault Code: F16803

Message

[FSM:STAGE:FAILED|RETRY]: in-band vlan configuration on Local CIMC(FSM-STAGE:sam:dme:MgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: cimcvlan-cfg-local-failed
mibFaultCode: 16803
mibFaultName: fsmStFailMgmtControllerExtMgmtInterfaceConfigCIMCVlanCfgLocal
moClass: mgmt:Controller
Type: fsm

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmStFailMgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgPeer

Fault Code: F16803

Message

[FSM:STAGE:FAILED|RETRY]: in-band vlan configuration on Peer
 CIMC(FSM-STAGE:sam:dme:MgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: cimcvlan-cfg-peer-failed
mibFaultCode: 16803
mibFaultName: fsmStFailMgmtControllerExtMgmtInterfaceConfigCIMCVlanCfgPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt

```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmStFailComputePhysicalSwConnUpd:A

Fault Code: F16804

Message

[FSM:STAGE:FAILED|RETRY]: Updating fabric A for server [dn](FSM-STAGE:sam:dme:ComputePhysicalSwConnUpd:A)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: a-failed
mibFaultCode: 16804
mibFaultName: fsmStFailComputePhysicalSwConnUpdA
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

fsmStFailComputePhysicalSwConnUpd:B

Fault Code: F16804

Message

[FSM:STAGE:FAILED|RETRY]: Updating fabric B for server [dn](FSM-STAGE:sam:dme:ComputePhysicalSwConnUpd:B)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning

```

Cause: b-failed
mibFaultCode: 16804
mibFaultName: fsmStFailComputePhysicalSwConnUpdB
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]

```

fsmStFailEquipmentIOCardResetIom:Execute

Fault Code: F16805

Message

```
[FSM:STAGE:FAILED|RETRY]: Reset IOM [id] on Fex
[chassisId](FSM-STAGE:sam:dme:EquipmentIOCardResetIom:Execute)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 16805
mibFaultName: fsmStFailEquipmentIOCardResetIomExecute
moClass: equipment:IOCard
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/slot- [id]
Affected MO: sys/fex- [id]/slot- [id]

```

fsmStFailComputePhysicalServiceInfraDeploy:SwConfigLocal

Fault Code: F16806

Message

```
[FSM:STAGE:FAILED|RETRY]: Configure service infrastructure on primary fabric
Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraDeploy:SwConfigLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 16806
mibFaultName: fsmStFailComputePhysicalServiceInfraDeploySwConfigLocal
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fsmStFailComputePhysicalServiceInfraDeploy:SwConfigPeer

Fault Code: F16806

Message

[FSM:STAGE:FAILED|RETRY]: Configure service infrastructure on secondary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraDeploy:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 16806
mibFaultName: fsmStFailComputePhysicalServiceInfraDeploySwConfigPeer
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fsmStFailComputePhysicalServiceInfraWithdraw:SwUnConfigLocal

Fault Code: F16807

Message

[FSM:STAGE:FAILED|RETRY]: Unconfigure service infrastructure on primary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraWithdraw:SwUnConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-un-config-local-failed
mibFaultCode: 16807
mibFaultName: fsmStFailComputePhysicalServiceInfraWithdrawSwUnConfigLocal
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]
```

fsmStFailComputePhysicalServiceInfraWithdraw:SwUnConfigPeer

Fault Code: F16807

Message

[FSM:STAGE:FAILED|RETRY]: Unconfigure service infrastructure on secondary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraWithdraw:SwUnConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-un-config-peer-failed
mibFaultCode: 16807
mibFaultName: fsmStFailComputePhysicalServiceInfraWithdrawSwUnConfigPeer
moClass: compute:Physical
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fsmStFailEquipmentIOCardBaseFePresence:CheckLicense

Fault Code: F16815

Message

[FSM:STAGE:FAILED|RETRY]: Checking license for chassis [chassisId] (iom [id])(FSM-STAGE:sam:dme:EquipmentIOCardBaseFePresence:CheckLicense)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: check-license-failed
mibFaultCode: 16815
mibFaultName: fsmStFailEquipmentIOCardBaseFePresenceCheckLicense
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fsmStFailEquipmentIOCardBaseFePresence:Identify

Fault Code: F16815

Message

[FSM:STAGE:FAILED|RETRY]: identifying IOM [chassisId]/[id](FSM-STAGE:sam:dme:EquipmentIOCardBaseFePresence:Identify)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: identify-failed
mibFaultCode: 16815
mibFaultName: fsmStFailEquipmentIOCardBaseFePresenceIdentify
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmStFailEquipmentIOCardBaseFeConn:ConfigureSwMgmtEndPoint**Fault Code: F16816****Message**

[FSM:STAGE:FAILED|RETRY]: configuring fabric interconnect [switchId] mgmt connectivity to IOM [chassisId]/[id]([side])(FSM-STAGE:sam:dme:EquipmentIOCardBaseFeConn:ConfigureSwMgmtEndPoint)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-sw-mgmt-end-point-failed
mibFaultCode: 16816
mibFaultName: fsmStFailEquipmentIOCardBaseFeConnConfigureSwMgmtEndPoint
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmStFailEquipmentIOCardBaseFeConn:ConfigureVifNs**Fault Code: F16816****Message**

[FSM:STAGE:FAILED|RETRY]: configuring IOM [chassisId]/[id]([side]) virtual name space(FSM-STAGE:sam:dme:EquipmentIOCardBaseFeConn:ConfigureVifNs)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: configure-vif-ns-failed
mibFaultCode: 16816
mibFaultName: fsmStFailEquipmentIOCardBaseFeConnConfigureVifNs
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fsmStFailEquipmentChassisRemoveChassis:DisableEndPoint**Fault Code: F16817****Message**

```
[FSM:STAGE:FAILED|RETRY]: unconfiguring access to chassis
[id](FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:DisableEndPoint)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-end-point-failed
mibFaultCode: 16817
mibFaultName: fsmStFailEquipmentChassisRemoveChassisDisableEndPoint
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmStFailEquipmentChassisRemoveChassis:UnIdentifyLocal

Fault Code: F16817

Message

[FSM:STAGE:FAILED|RETRY]: erasing chassis identity [id] from primary(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:UnIdentifyLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: un-identify-local-failed
mibFaultCode: 16817
mibFaultName: fsmStFailEquipmentChassisRemoveChassisUnIdentifyLocal
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

fsmStFailEquipmentChassisRemoveChassis:UnIdentifyPeer

Fault Code: F16817

Message

[FSM:STAGE:FAILED|RETRY]: erasing chassis identity [id] from secondary(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:UnIdentifyPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: un-identify-peer-failed
mibFaultCode: 16817
mibFaultName: fsmStFailEquipmentChassisRemoveChassisUnIdentifyPeer
moClass: equipment:Chassis
Type: fsm
Callhome: none

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmStFailEquipmentChassisRemoveChassis:Wait

Fault Code: F16817

Message

[FSM:STAGE:FAILED|RETRY]: waiting for clean up of resources for chassis [id] (approx. 2 min)(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:Wait)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-failed
mibFaultCode: 16817
mibFaultName: fsmStFailEquipmentChassisRemoveChassisWait
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmStFailEquipmentChassisRemoveChassis:decomission

Fault Code: F16817

Message

[FSM:STAGE:FAILED|RETRY]: decomissioning chassis [id](FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:decomission)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: decomission-failed
mibFaultCode: 16817

```

```

mibFaultName: fsmStFailEquipmentChassisRemoveChassisDecomission
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmStFailEquipmentLocatorLedSetFeLocatorLed:Execute

Fault Code: F16818

Message

```

[FSM:STAGE:FAILED|RETRY]: setting locator led to
[adminState](FSM-STAGE:sam:dme:EquipmentLocatorLedSetFeLocatorLed:Execute)

```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 16818
mibFaultName: fsmStFailEquipmentLocatorLedSetFeLocatorLedExecute
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led

```


fsmStFailEquipmentLocatorLedSetFiLocatorLed:Execute

Fault Code: F16819

Message

[FSM:STAGE:FAILED|RETRY]: setting FI locator led to
[adminState](FSM-STAGE:sam:dme:EquipmentLocatorLedSetFiLocatorLed:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 16819
mibFaultName: fsmStFailEquipmentLocatorLedSetFiLocatorLedExecute
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led
```

fsmStFailPortPloInCompatSfpPresence:Shutdown

Fault Code: F16822

Message

[FSM:STAGE:FAILED|RETRY]: Shutting down
port(FSM-STAGE:sam:dme:PortPloInCompatSfpPresence:Shutdown)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: shutdown-failed
mibFaultCode: 16822
mibFaultName: fsmStFailPortPioInCompatSfpPresenceShutdown
moClass: port:PIO
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fsmStFailPortPioInCompatSfpReplaced:EnablePort**Fault Code: F16823****Message**

```
[FSM:STAGE:FAILED|RETRY]: Enabling
port(FSM-STAGE:sam:dme:PortPioInCompatSfpReplaced:EnablePort)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-port-failed
mibFaultCode: 16823
mibFaultName: fsmStFailPortPioInCompatSfpReplacedEnablePort
moClass: port:PIO
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
```

Affected MO: sys/switch- [id]/slot- [id]/ [type]/aggr-port- [aggrPortId]/port- [portId]
Affected MO: sys/switch- [id]/slot- [id]/ [type]/port- [portId]

fsmStFailObserveObservedResolvePolicyFsm:Execute

Fault Code: F17063

Message

[FSM:STAGE:FAILED|RETRY]: Resolve Policy FSM
 Execute(FSM-STAGE:sam:dme:ObserveObservedResolvePolicyFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 17063
mibFaultName: fsmStFailObserveObservedResolvePolicyFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client- [id]/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/controllers/contro- [id]/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/providers/prov- [type]/observed- [dataSrcSysId] - [id]
Affected MO: observe/observed- [dataSrcSysId] - [id]

fsmStFailObserveObservedResolveResourceFsm:Execute

Fault Code: F17064

Message

[FSM:STAGE:FAILED|RETRY]: Resolve Resource FSM
 Execute(FSM-STAGE:sam:dme:ObserveObservedResolveResourceFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 17064
mibFaultName: fsmStFailObserveObservedResolveResourceFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmStFailObserveObservedResolveVMFsm:Execute**Fault Code:** F17065**Message**

```
[FSM:STAGE:FAILED|RETRY]: Resolve VM FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolveVMFsm:Execute)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 17065
mibFaultName: fsmStFailObserveObservedResolveVMFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmStFailObserveObservedResolveControllerFsm:Execute

Fault Code: F17066

Message

[FSM:STAGE:FAILED|RETRY]: Resolve Mgmt Controller FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolveControllerFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 17066
mibFaultName: fsmStFailObserveObservedResolveControllerFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/controllers/contro- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/providers/prov- [type] /observed- [dataSrcSysId] - [id]
Affected MO: observe/observed- [dataSrcSysId] - [id]
```

fsmStFailEquipmentBeaconLedIlluminate:ExecuteA

Fault Code: F17149

Message

[FSM:STAGE:FAILED|RETRY]: Turn beacon lights on/off for [dn] on fabric interconnect
[id](FSM-STAGE:sam:dme:EquipmentBeaconLedIlluminate:ExecuteA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-afailed
mibFaultCode: 17149
```

```

mibFaultName: fsmStFailEquipmentBeaconLedIlluminateExecuteA
moClass: equipment:BeaconLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/beacon
Affected MO: sys/chassis-[id]/blade-[slotId]/beacon
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/chassis-[id]/psu-[id]/beacon
Affected MO: sys/chassis-[id]/slot-[id]/beacon
Affected MO: sys/fex-[id]/beacon
Affected MO: sys/fex-[id]/psu-[id]/beacon
Affected MO: sys/fex-[id]/slot-[id]/beacon
Affected MO: sys/rack-unit-[id]/beacon
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/rack-unit-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/switch-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/slot-[id]/beacon

```

fsmStFailEquipmentBeaconLedIlluminate:ExecuteB

Fault Code: F17149

Message

[FSM:STAGE:FAILED|RETRY]: Turn beacon lights on/off for [dn] on fabric interconnect [id](FSM-STAGE:sam:dme:EquipmentBeaconLedIlluminate:ExecuteB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-bfailed
mibFaultCode: 17149
mibFaultName: fsmStFailEquipmentBeaconLedIlluminateExecuteB
moClass: equipment:BeaconLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/beacon
Affected MO: sys/chassis-[id]/blade-[slotId]/beacon
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/chassis-[id]/psu-[id]/beacon
Affected MO: sys/chassis-[id]/slot-[id]/beacon
Affected MO: sys/fex-[id]/beacon
Affected MO: sys/fex-[id]/psu-[id]/beacon
Affected MO: sys/fex-[id]/slot-[id]/beacon
Affected MO: sys/rack-unit-[id]/beacon
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/rack-unit-[id]/psu-[id]/beacon

```

Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/switch-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/slot-[id]/beacon

fsmStFailSdAppInstanceInstallApplication:SendCommand

Fault Code: F17151

Message

[FSM:STAGE:FAILED|RETRY]: Send command to install application(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 17151
mibFaultName: fsmStFailSdAppInstanceInstallApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

fsmStFailSdAppInstanceInstallApplication:UpdateAppInstance

Fault Code: F17151

Message

[FSM:STAGE:FAILED|RETRY]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 17151

```

mibFaultName: fsmStFailSdAppInstanceInstallApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceInstallApplication:WaitStage

Fault Code: F17151

Message

[FSM:STAGE:FAILED|RETRY]: Wait for confirmation from SMA that the application is installed(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-stage-failed
mibFaultCode: 17151
mibFaultName: fsmStFailSdAppInstanceInstallApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceStartApplication:SendCommand

Fault Code: F17152

Message

[FSM:STAGE:FAILED|RETRY]: Send command to start application(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 17152
mibFaultName: fsmStFailSdAppInstanceStartApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmStFailSdAppInstanceStartApplication:UpdateAppInstance**Fault Code: F17152****Message**

[FSM:STAGE:FAILED|RETRY]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 17152
mibFaultName: fsmStFailSdAppInstanceStartApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmStFailSdAppInstanceStartApplication:WaitStage**Fault Code: F17152****Message**

[FSM:STAGE:FAILED|RETRY]: Wait for confirmation from SMA that the application has started(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 17152
mibFaultName: fsmStFailSdAppInstanceStartApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmStFailSdLduProvisionLDU:CheckBladeReadiness**Fault Code: F17153****Message**

[FSM:STAGE:FAILED|RETRY]: Check if the blade is available to provision logical device.(FSM-STAGE:sam:dme:SdLduProvisionLDU:CheckBladeReadiness)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-blade-readiness-failed
mibFaultCode: 17153
mibFaultName: fsmStFailSdLduProvisionLDUCheckBladeReadiness
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]
```

fsmStFailSdLduProvisionLDU:StartApps**Fault Code: F17153****Message**

[FSM:STAGE:FAILED|RETRY]: Start the Apps(FSM-STAGE:sam:dme:SdLduProvisionLDU:StartApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: start-apps-failed
mibFaultCode: 17153
mibFaultName: fsmStFailSdLduProvisionLDUStartApps
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name] /ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /ldu- [slotId]
```

fsmStFailSdLduProvisionLDU:WaitForAppsInstallation**Fault Code: F17153****Message**

[FSM:STAGE:FAILED|RETRY]: Wait for all the apps in the LDU to get installed.(FSM-STAGE:sam:dme:SdLduProvisionLDU:WaitForAppsInstallation)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-apps-installation-failed
mibFaultCode: 17153
mibFaultName: fsmStFailSdLduProvisionLDUWaitForAppsInstallation
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name] /ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /ldu- [slotId]
```

fsmStFailSdLduProvisionLDU:WaitForLinkConfiguration

Fault Code: F17153

Message

[FSM:STAGE:FAILED|RETRY]: Wait for CCL and MGMT Links configuration(FSM-STAGE:sam:dme:SdLduProvisionLDU:WaitForLinkConfiguration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-link-configuration-failed
mibFaultCode: 17153
mibFaultName: fsmStFailSdLduProvisionLDUWaitForLinkConfiguration
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]
```

fsmStFailSdAppInstanceUpgradeApplication:SendCommand

Fault Code: F17154

Message

[FSM:STAGE:FAILED|RETRY]: Send command to upgrade application(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-command-failed
mibFaultCode: 17154
mibFaultName: fsmStFailSdAppInstanceUpgradeApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

```

fsmStFailSdAppInstanceUpgradeApplication:UpdateAppInstance

Fault Code: F17154

Message

[FSM:STAGE:FAILED|RETRY]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 17154
mibFaultName: fsmStFailSdAppInstanceUpgradeApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

```

fsmStFailSdAppInstanceUpgradeApplication:WaitStage

Fault Code: F17154

Message

[FSM:STAGE:FAILED|RETRY]: Wait for confirmation from SMA that the application is upgraded(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-stage-failed

```

```

mibFaultCode: 17154
mibFaultName: fsmStFailSdAppInstanceUpgradeApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceStopApplication:ReleaseAppLicense

Fault Code: F17155

Message

[FSM:STAGE:FAILED|RETRY]: Release license of application instance(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:ReleaseAppLicense)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-app-license-failed
mibFaultCode: 17155
mibFaultName: fsmStFailSdAppInstanceStopApplicationReleaseAppLicense
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceStopApplication:SendCommand

Fault Code: F17155

Message

[FSM:STAGE:FAILED|RETRY]: Send command to stop application(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 17155
mibFaultName: fsmStFailSdAppInstanceStopApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmStFailSdAppInstanceStopApplication:UpdateAppInstance**Fault Code: F17155****Message**

[FSM:STAGE:FAILED|RETRY]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 17155
mibFaultName: fsmStFailSdAppInstanceStopApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmStFailSdAppInstanceStopApplication:WaitStage**Fault Code: F17155****Message**

[FSM:STAGE:FAILED|RETRY]: Wait for confirmation from SMA that the application has stopped(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 17155
mibFaultName: fsmStFailSdAppInstanceStopApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmStFailSdAppInstanceUninstallApplication:ReleaseAppLicense

Fault Code: F17156

Message

```
[FSM:STAGE:FAILED|RETRY]: Release license of application
instance(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:ReleaseAppLicense)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: release-app-license-failed
mibFaultCode: 17156
mibFaultName: fsmStFailSdAppInstanceUninstallApplicationReleaseAppLicense
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmStFailSdAppInstanceUninstallApplication:SendCommand

Fault Code: F17156

Message

```
[FSM:STAGE:FAILED|RETRY]: Send command to uninstall
application(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:SendCommand)
```


Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-command-failed
mibFaultCode: 17156
mibFaultName: fsmStFailSdAppInstanceUninstallApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmStFailSdAppInstanceUninstallApplication:WaitStage**Fault Code: F17156****Message**

[FSM:STAGE:FAILED|RETRY]: Wait for confirmation from SMA that the application has been uninstalled.(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 17156
mibFaultName: fsmStFailSdAppInstanceUninstallApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmStFailSdSlotChangePlatformLogLevel:SendCommand

Fault Code: F17157

Message

[FSM:STAGE:FAILED|RETRY]: Send command to change the log level(FSM-STAGE:sam:dme:SdSlotChangePlatformLogLevel:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 17157
mibFaultName: fsmStFailSdSlotChangePlatformLogLevelSendCommand
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

fsmStFailSdAppInstanceBundleDataPorts:ConfigureLinks

Fault Code: F17158

Message

[FSM:STAGE:FAILED|RETRY]: Trigger ConfigureLinks
 FSM(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:ConfigureLinks)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-links-failed
mibFaultCode: 17158
mibFaultName: fsmStFailSdAppInstanceBundleDataPortsConfigureLinks
moClass: sd:AppInstance
Type: fsm
Callhome: none

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceBundleDataPorts:SendBundleStatus

Fault Code: F17158

Message

[FSM:STAGE:FAILED|RETRY]: Notify Application about Port Bundle Status(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:SendBundleStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-bundle-status-failed
mibFaultCode: 17158
mibFaultName: fsmStFailSdAppInstanceBundleDataPortsSendBundleStatus
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceBundleDataPorts:UpdateBundleStatus

Fault Code: F17158

Message

[FSM:STAGE:FAILED|RETRY]: Update the bundle status(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:UpdateBundleStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-bundle-status-failed
mibFaultCode: 17158

```

```

mibFaultName: fsmStFailSdAppInstanceBundleDataPortsUpdateBundleStatus
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdAppInstanceBundleDataPorts:WaitForConfigCompletion

Fault Code: F17158

Message

[FSM:STAGE:FAILED|RETRY]: Wait for links configuration completion(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:WaitForConfigCompletion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-config-completion-failed
mibFaultCode: 17158
mibFaultName: fsmStFailSdAppInstanceBundleDataPortsWaitForConfigCompletion
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmStFailSdLogicalDeviceConfigureLinks:ConfigureSwitch

Fault Code: F17159

Message

[FSM:STAGE:FAILED|RETRY]: Invoke Port API to configure the switch(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:ConfigureSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-switch-failed
mibFaultCode: 17159
mibFaultName: fsmStFailSdLogicalDeviceConfigureLinksConfigureSwitch
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmStFailSdLogicalDeviceConfigureLinks:SendInterfaces**Fault Code: F17159****Message**

[FSM:STAGE:FAILED|RETRY]: Send Updated Interface Mapping(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:SendInterfaces)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-interfaces-failed
mibFaultCode: 17159
mibFaultName: fsmStFailSdLogicalDeviceConfigureLinksSendInterfaces
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmStFailSdLogicalDeviceConfigureLinks:UnconfigureLinks**Fault Code: F17159****Message**

[FSM:STAGE:FAILED|RETRY]: Unconfigure Links in the LogicalDevice(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:UnconfigureLinks)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unconfigure-links-failed
mibFaultCode: 17159
mibFaultName: fsmStFailSdLogicalDeviceConfigureLinksUnconfigureLinks
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]
```

fsmStFailSdLogicalDeviceConfigureLinks:UnconfigureLogicalDevice

Fault Code: F17159

Message

[FSM:STAGE:FAILED|RETRY]: Unconfigure logical device(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:UnconfigureLogicalDevice)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unconfigure-logical-device-failed
mibFaultCode: 17159
mibFaultName: fsmStFailSdLogicalDeviceConfigureLinksUnconfigureLogicalDevice
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]
```

fsmStFailSdLogicalDeviceConfigureLinks:WaitForSwitchConfig

Fault Code: F17159

Message

[FSM:STAGE:FAILED|RETRY]: Wait for Switch configuration to complete(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:WaitForSwitchConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-switch-config-failed
mibFaultCode: 17159
mibFaultName: fsmStFailSdLogicalDeviceConfigureLinksWaitForSwitchConfig
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]
```

fsmStFailSdLinkUpdateInterfaceStatus:SendStatus**Fault Code: F17160****Message**

[FSM:STAGE:FAILED|RETRY]: Send Interface Operational
State(FSM-STAGE:sam:dme:SdLinkUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-status-failed
mibFaultCode: 17160
mibFaultName: fsmStFailSdLinkUpdateInterfaceStatusSendStatus
moClass: sd:Link
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys-secsvc/ld- [name]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]/ext-ldulink- [name] - [appInstId]
Affected MO:
sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
```

Affected MO:

```
sys-secsvc/slot- [slotId] /app-inst- [appInstId] /ldu- [slotId] /ext-ldulink- [name] - [appInstId]
```

fsmStFailSdClusterBootstrapUpdateClusterConfiguration:SendConfig

Fault Code: F17161

Message

[FSM:STAGE:FAILED|RETRY]: Send Updated Cluster Configuration(FSM-STAGE:sam:dme:SdClusterBootstrapUpdateClusterConfiguration:SendConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-config-failed
mibFaultCode: 17161
mibFaultName: fsmStFailSdClusterBootstrapUpdateClusterConfigurationSendConfig
moClass: sd:ClusterBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name] /cluster-bootstrap
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /cluster-bootstrap
```

fsmStFailSdSlotFormatDisk:CheckBladeReadiness

Fault Code: F17162

Message

[FSM:STAGE:FAILED|RETRY]: Check blade readiness(FSM-STAGE:sam:dme:SdSlotFormatDisk:CheckBladeReadiness)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-blade-readiness-failed
```



```

mibFaultCode: 17162
mibFaultName: fsmStFailSdSlotFormatDiskCheckBladeReadiness
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]

```

fsmStFailSdSlotFormatDisk:ResetBladePower

Fault Code: F17162

Message

[FSM:STAGE:FAILED|RETRY]: Blade power
reset(FSM-STAGE:sam:dme:SdSlotFormatDisk:ResetBladePower)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: reset-blade-power-failed
mibFaultCode: 17162
mibFaultName: fsmStFailSdSlotFormatDiskResetBladePower
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]

```

fsmStFailSdSlotFormatDisk:StartDiskFormat

Fault Code: F17162

Message

[FSM:STAGE:FAILED|RETRY]: Start formatting
disk(FSM-STAGE:sam:dme:SdSlotFormatDisk:StartDiskFormat)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: start-disk-format-failed
mibFaultCode: 17162
mibFaultName: fsmStFailSdSlotFormatDiskStartDiskFormat
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

fsmStFailSdSlotFormatDisk:WaitForDiskFormatComplete**Fault Code:** F17162**Message**

[FSM:STAGE:FAILED|RETRY]: Wait for disk format complete(FSM-STAGE:sam:dme:SdSlotFormatDisk:WaitForDiskFormatComplete)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-disk-format-complete-failed
mibFaultCode: 17162
mibFaultName: fsmStFailSdSlotFormatDiskWaitForDiskFormatComplete
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

fsmStFailSdSlotSynchTimeZone:UpdateTimeZone**Fault Code:** F17163**Message**

[FSM:STAGE:FAILED|RETRY]: Update time zone(FSM-STAGE:sam:dme:SdSlotSynchTimeZone:UpdateTimeZone)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-time-zone-failed
mibFaultCode: 17163
mibFaultName: fsmStFailSdSlotSynchTimeZoneUpdateTimeZone
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]
```

fsmStFailSdAppAttributeCtrlGetAppAttributes:GetAttributes**Fault Code: F17164****Message**

[FSM:STAGE:FAILED|RETRY]: Retrive application attributes(FSM-STAGE:sam:dme:SdAppAttributeCtrlGetAppAttributes:GetAttributes)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: get-attributes-failed
mibFaultCode: 17164
mibFaultName: fsmStFailSdAppAttributeCtrlGetAppAttributesGetAttributes
moClass: sd:AppAttributeCtrl
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app-attribute-ctrl
```

fsmStFailSdMgmtInfoUpdateMgmtInfo:SendUpdate**Fault Code: F17165****Message**

[FSM:STAGE:FAILED|RETRY]: Update management information(FSM-STAGE:sam:dme:SdMgmtInfoUpdateMgmtInfo:SendUpdate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-update-failed
mibFaultCode: 17165
mibFaultName: fsmStFailSdMgmtInfoUpdateMgmtInfoSendUpdate
moClass: sd:MgmtInfo
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/mgmt-info
```

fsmStFailSdNetMgmtBootstrapUpdateNetMgmtBootstrap:SendUpdate

Fault Code: F17166

Message

[FSM:STAGE:FAILED|RETRY]: Send message to
AppAgent(FSM-STAGE:sam:dme:SdNetMgmtBootstrapUpdateNetMgmtBootstrap:SendUpdate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-update-failed
mibFaultCode: 17166
mibFaultName: fsmStFailSdNetMgmtBootstrapUpdateNetMgmtBootstrapSendUpdate
moClass: sd:NetMgmtBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/net-mgmt-bootstrap
```

fsmStFailSdUpgradeTaskStopUpgradeStartApp:StartApp

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Trigger FSM to start application(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:StartApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: start-app-failed
mibFaultCode: 17167
mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppStartApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/upgrade-task
```

fsmStFailSdUpgradeTaskStopUpgradeStartApp:StopApp

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Stop application before upgrade(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:StopApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-app-failed
mibFaultCode: 17167
mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppStopApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/upgrade-task

fsmStFailSdUpgradeTaskStopUpgradeStartApp:UpgradeApp

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Trigger FSM to upgrade application(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:UpgradeApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: upgrade-app-failed
mibFaultCode: 17167
mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppUpgradeApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/upgrade-task

fsmStFailSdUpgradeTaskStopUpgradeStartApp:WaitForBladeReboot

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Wait for blade reboot(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForBladeReboot)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-blade-reboot-failed
mibFaultCode: 17167

```

mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppWaitForBladeReboot
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task

```

fsmStFailSdUpgradeTaskStopUpgradeStartApp:WaitForStopApp

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Wait for application stop to complete.(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForStopApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-stop-app-failed
mibFaultCode: 17167
mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppWaitForStopApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task

```

fsmStFailSdUpgradeTaskStopUpgradeStartApp:WaitForUpgradeApp

Fault Code: F17167

Message

[FSM:STAGE:FAILED|RETRY]: Wait for application upgrade to complete.(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForUpgradeApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-upgrade-app-failed
mibFaultCode: 17167
mibFaultName: fsmStFailSdUpgradeTaskStopUpgradeStartAppWaitForUpgradeApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task

fsmStFailEtherServerIntFioConfigSpeed:Configure**Fault Code: F17169****Message**

[FSM:STAGE:FAILED|RETRY]: Configure admin speed for [dn](FSM-STAGE:sam:dme:EtherServerIntFioConfigSpeed:Configure)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-failed
mibFaultCode: 17169
mibFaultName: fsmStFailEtherServerIntFioConfigSpeedConfigure
moClass: ether:ServerIntFio
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /diag/port- [portId]
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/rack-unit- [id] /diag/port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]

fsmStFailEtherFtwPortPairConfigFtw:Configure**Fault Code: F17170****Message**

[FSM:STAGE:FAILED|RETRY]: Configure fail-to-wire for [dn](FSM-STAGE:sam:dme:EtherFtwPortPairConfigFtw:Configure)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: configure-failed
mibFaultCode: 17170
mibFaultName: fsmStFailEtherFtwPortPairConfigFtwConfigure
moClass: ether:FtwPortPair
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/switch-[id]/fail-to-wire/ftw-port-[slotId]-[aggrPortId]-[portId]-port-[peerSlotId]
-[peerAggrPortId]-[peerPortId]
```

fsmStFailExtpolEpRegisterFsm:Execute**Fault Code: F17185****Message**

```
[FSM:STAGE:FAILED|RETRY]: Register FSM
Execute(FSM-STAGE:sam:dme:ExtpolEpRegisterFsm:Execute)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 17185
mibFaultName: fsmStFailExtpolEpRegisterFsmExecute
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol
```

fsmStFailExtpolRegistryCrossDomainConfig:SetLocal

Fault Code: F17186

Message

[FSM:STAGE:FAILED|RETRY]: Configure cross-domain XML for FLEX client on local fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainConfig:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-local-failed
mibFaultCode: 17186
mibFaultName: fsmStFailExtpolRegistryCrossDomainConfigSetLocal
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg
```

fsmStFailExtpolRegistryCrossDomainConfig:SetPeer

Fault Code: F17186

Message

[FSM:STAGE:FAILED|RETRY]: Configure cross-domain XML for FLEX client on peer fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainConfig:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-peer-failed
mibFaultCode: 17186
mibFaultName: fsmStFailExtpolRegistryCrossDomainConfigSetPeer
moClass: extpol:Registry
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmStFailExtpolRegistryCrossDomainDelete:SetLocal

Fault Code: F17187

Message

[FSM:STAGE:FAILED|RETRY]: Remove cross-domain XML for FLEX client on local fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainDelete:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-local-failed
mibFaultCode: 17187
mibFaultName: fsmStFailExtpolRegistryCrossDomainDeleteSetLocal
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmStFailExtpolRegistryCrossDomainDelete:SetPeer

Fault Code: F17187

Message

[FSM:STAGE:FAILED|RETRY]: Remove cross-domain XML for FLEX client on peer fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainDelete:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-peer-failed
mibFaultCode: 17187

```

```

mibFaultName: fsmStFailExtpolRegistryCrossDomainDeleteSetPeer
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmStFailStorageSystemSync:Execute

Fault Code: F17224

Message

[FSM:STAGE:FAILED|RETRY]: Synchronise requestors with storage broker(FSM-STAGE:sam:dme:StorageSystemSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 17224
mibFaultName: fsmStFailStorageSystemSyncExecute
moClass: storage:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: storage-ep/system

```

fsmStFailSysfileMutationSingle:Execute

Fault Code: F17226

Message

[FSM:STAGE:FAILED|RETRY]: [action] file [name](FSM-STAGE:sam:dme:SysfileMutationSingle:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 17226
mibFaultName: fsmStFailSysfileMutationSingleExecute
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation

```

fsmStFailSysfileMutationGlobal:Local**Fault Code: F17227****Message**

[FSM:STAGE:FAILED|RETRY]: remove files from local(FSM-STAGE:sam:dme:SysfileMutationGlobal:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17227
mibFaultName: fsmStFailSysfileMutationGlobalLocal
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation

```

fsmStFailSysfileMutationGlobal:Peer**Fault Code: F17227****Message**

[FSM:STAGE:FAILED|RETRY]: remove files from peer(FSM-STAGE:sam:dme:SysfileMutationGlobal:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 17227
mibFaultName: fsmStFailSysfileMutationGlobalPeer
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation
```

fsmStFailApplicationDownloaderDownload:Local

Fault Code: F17231

Message

[FSM:STAGE:FAILED|RETRY]: downloading image [fileName] from [server](FSM-STAGE:sam:dme:ApplicationDownloaderDownload:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17231
mibFaultName: fsmStFailApplicationDownloaderDownloadLocal
moClass: application:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/app-catalogue/dnld- [fileName]
```

fsmStFailApplicationDownloaderDownload:UnpackLocal

Fault Code: F17231

Message

[FSM:STAGE:FAILED|RETRY]: unpacking image [fileName] on primary(FSM-STAGE:sam:dme:ApplicationDownloaderDownload:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 17231
mibFaultName: fsmStFailApplicationDownloaderDownloadUnpackLocal
moClass: application:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/app-catalogue/dnld- [fileName]
```

fsmStFailCommSvcEpUpdateSvcEp:PropogateEpSettings**Fault Code: F17232****Message**

[FSM:STAGE:FAILED|RETRY]: propogate updated settings (eg. timezone)(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpSettings)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: propogate-ep-settings-failed
mibFaultCode: 17232
mibFaultName: fsmStFailCommSvcEpUpdateSvcEpPropogateEpSettings
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmStFailCommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomLocal

Fault Code: F17232

Message

[FSM:STAGE:FAILED|RETRY]: propogate updated timezone settings to FEXs and IOMs.(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: propogate-ep-time-zone-settings-to-fex-iom-local-failed
mibFaultCode: 17232
mibFaultName: fsmStFailCommSvcEpUpdateSvcEpPropogateEpTimeZoneSettingsToFexIomLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

fsmStFailCommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomPeer

Fault Code: F17232

Message

[FSM:STAGE:FAILED|RETRY]: propogate updated timezone settings to FEXs and IOMs.(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: propogate-ep-time-zone-settings-to-fex-iom-peer-failed
mibFaultCode: 17232
mibFaultName: fsmStFailCommSvcEpUpdateSvcEpPropogateEpTimeZoneSettingsToFexIomPeer
moClass: comm:SvcEp


```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmStFailCommSvcEpUpdateSvcEp:SetEpLocal

Fault Code: F17232

Message

[FSM:STAGE:FAILED|RETRY]: communication service [name] configuration to primary(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:SetEpLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-ep-local-failed
mibFaultCode: 17232
mibFaultName: fsmStFailCommSvcEpUpdateSvcEpSetEpLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmStFailCommSvcEpUpdateSvcEp:SetEpPeer

Fault Code: F17232

Message

[FSM:STAGE:FAILED|RETRY]: communication service [name] configuration to secondary(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:SetEpPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning

```

```

Cause: set-ep-peer-failed
mibFaultCode: 17232
mibFaultName: fsmStFailCommSvcEpUpdateSvcEpSetEpPeer
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmStFailCommSvcEpRestartWebSvc:local

Fault Code: F17233

Message

[FSM:STAGE:FAILED|RETRY]: restart web services in primary(FSM-STAGE:sam:dme:CommSvcEpRestartWebSvc:local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17233
mibFaultName: fsmStFailCommSvcEpRestartWebSvcLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmStFailCommSvcEpRestartWebSvc:peer

Fault Code: F17233

Message

[FSM:STAGE:FAILED|RETRY]: restart web services in secondary(FSM-STAGE:sam:dme:CommSvcEpRestartWebSvc:peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 17233
mibFaultName: fsmStFailCommSvcEpRestartWebSvcPeer
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmStFailPkiEpUpdateEp:PostSetKeyRingLocal

Fault Code: F17251

Message

[FSM:STAGE:FAILED|RETRY]: post processing after keyring configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: post-set-key-ring-local-failed
mibFaultCode: 17251
mibFaultName: fsmStFailPkiEpUpdateEpPostSetKeyRingLocal
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmStFailPkiEpUpdateEp:PostSetKeyRingPeer

Fault Code: F17251

Message

[FSM:STAGE:FAILED|RETRY]: post processing after keyring configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: post-set-key-ring-peer-failed
mibFaultCode: 17251
mibFaultName: fsmStFailPkiEpUpdateEpPostSetKeyRingPeer
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmStFailPkiEpUpdateEp:SetKeyRingLocal**Fault Code: F17251****Message**

[FSM:STAGE:FAILED|RETRY]: keyring configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-key-ring-local-failed
mibFaultCode: 17251
mibFaultName: fsmStFailPkiEpUpdateEpSetKeyRingLocal
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmStFailPkiEpUpdateEp:SetKeyRingPeer

Fault Code: F17251

Message

[FSM:STAGE:FAILED|RETRY]: keyring configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-key-ring-peer-failed
mibFaultCode: 17251
mibFaultName: fsmStFailPkiEpUpdateEpSetKeyRingPeer
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext

fsmStFailPkiEpUpdateEp:ValidateKeyRingAndTP

Fault Code: F17251

Message

[FSM:STAGE:FAILED|RETRY]: validate keyring and trust point(FSM-STAGE:sam:dme:PkiEpUpdateEp:ValidateKeyRingAndTP)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-key-ring-andtp-failed
mibFaultCode: 17251
mibFaultName: fsmStFailPkiEpUpdateEpValidateKeyRingAndTP
moClass: pki:Ep
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext

fsmStFailAaaEpUpdateEp:SetEpLocal

Fault Code: F17252

Message

[FSM:STAGE:FAILED|RETRY]: external aaa server configuration to primary(FSM-STAGE:sam:dme:AaaEpUpdateEp:SetEpLocal)

Explanation

Cisco FPR Manager could not set the configurations in the primary Fabric Interconnect for AAA servers while re-ordering/deleting providers.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** 1. Identify the auth-domain(s) that are using the auth-realm modification causing this fault.
 - Step 2** 2. Modify the auth-domain(s) realm identified in step 1, to local realm and commit the changes.
 - Step 3** 3. Re-order/Delete the AAA providers user wish to modify and commit the changes.
 - Step 4** 4. Change the auth-domain(s) realm back to previous realm modified in step2 and commit the changes.

Fault Details

Severity: warning
Cause: set-ep-local-failed
mibFaultCode: 17252
mibFaultName: fsmStFailAaaEpUpdateEpSetEpLocal
moClass: aaa:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext
Affected MO: sys/radius-ext
Affected MO: sys/tacacs-ext

fsmStFailAaaEpUpdateEp:SetEpPeer

Fault Code: F17252

Message

[FSM:STAGE:FAILED|RETRY]: external aaa server configuration to secondary(FSM-STAGE:sam:dme:AaaEpUpdateEp:SetEpPeer)

Explanation

Cisco FPR Manager could not set the configurations in the secondary Fabric Interconnect for AAA servers while re-ordering/deleting providers.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** 0. Make sure secondary FI is up and running.
- Step 2** 1. Identify the auth-domain(s) that are using the auth-realm modification causing this fault.
- Step 3** 2. Modify the auth-domain(s) realm identified in step 1, to local realm and commit the changes.
- Step 4** 3. Re-order/Delete the AAA providers user wish to modify and commit the changes.
- Step 5** 4. Change the auth-domain(s) realm back to previous realm modified in step2 and commit the changes.

Fault Details

```

Severity: warning
Cause: set-ep-peer-failed
mibFaultCode: 17252
mibFaultName: fsmStFailAaaEpUpdateEpSetEpPeer
moClass: aaa:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext
Affected MO: sys/radius-ext
Affected MO: sys/tacacs-ext

```

fsmStFailAaaRealmUpdateRealm:SetRealmLocal

Fault Code: F17253

Message

[FSM:STAGE:FAILED|RETRY]: realm configuration to primary(FSM-STAGE:sam:dme:AaaRealmUpdateRealm:SetRealmLocal)

Explanation

Cisco FPR Manager could not set the configurations in the primary Fabric Interconnect for Authentication realms.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** 1. Make sure the auth-server-group used in the auth-domain is exist and is deployed on to switch.
- Step 2** 2. If auth-server-group doesn't exist, either create auth-server-group in appropriate realm (RADIUS/TACACS+/LDAP) or unset the auth-server-group in auth-domain.

Fault Details

```

Severity: warning
Cause: set-realm-local-failed
mibFaultCode: 17253
mibFaultName: fsmStFailAaaRealmUpdateRealmSetRealmLocal
moClass: aaa:Realm
Type: fsm
Callhome: none
Auto Cleared: true

```

Is Implemented: true
Affected MO: sys/auth-realm

fsmStFailAaaRealmUpdateRealm:SetRealmPeer

Fault Code: F17253

Message

[FSM:STAGE:FAILED|RETRY]: realm configuration to secondary(FSM-STAGE:sam:dme:AaaRealmUpdateRealm:SetRealmPeer)

Explanation

Cisco FPR Manager could not set the configurations in the secondary Fabric Interconnect for Authentication realms.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** 0. Make sure secondary FI is up and running.
- Step 2** 1. Make sure the auth-server-group used in the auth-domain is exist and is deployed on to switch.
- Step 3** 2. If auth-server-group doesn't exist, either create auth-server-group in appropriate realm (RADIUS/TACACS+/LDAP) or unset the auth-server-group in auth-domain.

Fault Details

Severity: warning
Cause: set-realm-peer-failed
mibFaultCode: 17253
mibFaultName: fsmStFailAaaRealmUpdateRealmSetRealmPeer
moClass: aaa:Realm
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/auth-realm

fsmStFailAaaUserEpUpdateUserEp:SetUserLocal

Fault Code: F17254

Message

[FSM:STAGE:FAILED|RETRY]: user configuration to primary(FSM-STAGE:sam:dme:AaaUserEpUpdateUserEp:SetUserLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-user-local-failed
mibFaultCode: 17254
mibFaultName: fsmStFailAaaUserEpUpdateUserEpSetUserLocal
moClass: aaa:UserEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext

fsmStFailAaaUserEpUpdateUserEp:SetUserPeer**Fault Code:** F17254**Message**

[FSM:STAGE:FAILED|RETRY]: user configuration to secondary(FSM-STAGE:sam:dme:AaaUserEpUpdateUserEp:SetUserPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-user-peer-failed
mibFaultCode: 17254
mibFaultName: fsmStFailAaaUserEpUpdateUserEpSetUserPeer
moClass: aaa:UserEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext

fsmStFailSysdebugManualCoreFileExportTargetExport:Execute**Fault Code:** F17265**Message**

[FSM:STAGE:FAILED|RETRY]: export core file [name] to [hostname](FSM-STAGE:sam:dme:SysdebugManualCoreFileExportTargetExport:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 17265
mibFaultName: fsmStFailSysdebugManualCoreFileExportTargetExportExecute
moClass: sysdebug:ManualCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/export-to- [hostname]
```

fsmStFailSysdebugLogExportPolicyConfigure:Local

Fault Code: F17266

Message

[FSM:STAGE:FAILED|RETRY]: configuring log file export service on local(FSM-STAGE:sam:dme:SysdebugLogExportPolicyConfigure:Local)

Explanation

Cisco Firepower Manager could not set the configurations in the primary Fabric Interconnect for log file transfer to remote server.

Recommended Action

If you see this fault, take the following actions:

Step 1 Execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17266
mibFaultName: fsmStFailSysdebugLogExportPolicyConfigureLocal
moClass: sysdebug:LogExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy
```

fsmStFailSysdebugLogExportPolicyConfigure:Peer

Fault Code: F17266

Message

[FSM:STAGE:FAILEDIRETRY]: configuring log file export service on peer(FSM-STAGE:sam:dme:SysdebugLogExportPolicyConfigure:Peer)

Explanation

Cisco Firepower Manager could not set the configurations in the subordinate Fabric Interconnect (FI) for log file transfer to remote server. This fault typically appears for one of the following reasons:

- The subordinate FI is not reachable.
- The subordinate FI is experiencing an internal system error on applying the configuration.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FI cluster state to ensure that the subordinate FI is reachable and functioning correctly. If the subordinate FI is down, take appropriate corrective actions so that the Firepower cluster goes into HA ready state.
- Step 2** If the HA state of the primary and subordinate FIs are good, execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 17266
mibFaultName: fsmStFailSysdebugLogExportPolicyConfigurePeer
moClass: sysdebug:LogExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy
```

fsmStFailSysdebugAutoCoreFileExportTargetConfigure:Local

Fault Code: F17267

Message

[FSM:STAGE:FAILEDIRETRY]: configuring automatic core file export service on local(FSM-STAGE:sam:dme:SysdebugAutoCoreFileExportTargetConfigure:Local)

Explanation

Cisco Firepower Manager could not set the configurations in the primary Fabric Interconnect for auto core transfer to remote TFTP server.

Recommended Action

If you see this fault, take the following actions:

Step 1 Execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17267
mibFaultName: fsmStFailSysdebugAutoCoreFileExportTargetConfigureLocal
moClass: sysdebug:AutoCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fsmStFailSysdebugAutoCoreFileExportTargetConfigure:Peer

Fault Code: F17267

Message

[FSM:STAGE:FAILED|RETRY]: configuring automatic core file export service on peer(FSM-STAGE:sam:dme:SysdebugAutoCoreFileExportTargetConfigure:Peer)

Explanation

Cisco Firepower Manager could not set the configurations in the subordinate Fabric Interconnect (FI) for auto core transfer to remote TFTP server. This fault typically appears for one of the following reasons:

- The subordinate FI is not reachable.
- The subordinate FI is experiencing an internal system error on applying the configuration.

Recommended Action

If you see this fault, take the following actions:

Step 1 Check the FI cluster state to ensure that the subordinate FI is reachable and functioning correctly. If the subordinate FI is down, take appropriate corrective actions so that the Firepower cluster goes into HA ready state.

Step 2 If the HA state of the primary and subordinate FIs are good, execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 17267
mibFaultName: fsmStFailSysdebugAutoCoreFileExportTargetConfigurePeer
moClass: sysdebug:AutoCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fsmStFailSysdebugTechSupportInitiate:Local

Fault Code: F17268

Message

[FSM:STAGE:FAILED|RETRY]: create tech-support file from GUI on local(FSM-STAGE:sam:dme:SysdebugTechSupportInitiate:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17268
mibFaultName: fsmStFailSysdebugTechSupportInitiateLocal
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]
```

fsmStFailSysdebugTechSupportDeleteTechSupFile:Local

Fault Code: F17269

Message

[FSM:STAGE:FAILED|RETRY]: delete tech-support file from GUI on local(FSM-STAGE:sam:dme:SysdebugTechSupportDeleteTechSupFile:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17269
mibFaultName: fsmStFailSysdebugTechSupportDeleteTechSupFileLocal
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmStFailSysdebugTechSupportDeleteTechSupFile:peer

Fault Code: F17269

Message

[FSM:STAGE:FAILED|RETRY]: delete tech-support file from GUI on peer(FSM-STAGE:sam:dme:SysdebugTechSupportDeleteTechSupFile:peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed
mibFaultCode: 17269
mibFaultName: fsmStFailSysdebugTechSupportDeleteTechSupFilePeer
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmStFailSysdebugTechSupportDownload:CopyPrimary

Fault Code: F17270

Message

[FSM:STAGE:FAILED|RETRY]: Copy the tech-support file to primary for download(FSM-STAGE:sam:dme:SysdebugTechSupportDownload:CopyPrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-primary-failed
mibFaultCode: 17270

```

```

mibFaultName: fsmStFailSysdebugTechSupportDownloadCopyPrimary
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmStFailSysdebugTechSupportDownload:CopySub

Fault Code: F17270

Message

[FSM:STAGE:FAILED|RETRY]: copy tech-support file on subordinate switch to tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload:CopySub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-sub-failed
mibFaultCode: 17270
mibFaultName: fsmStFailSysdebugTechSupportDownloadCopySub
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmStFailSysdebugTechSupportDownload>DeletePrimary

Fault Code: F17270

Message

[FSM:STAGE:FAILED|RETRY]: Delete the tech-support file from primary switch under tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload>DeletePrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-primary-failed
mibFaultCode: 17270
mibFaultName: fsmStFailSysdebugTechSupportDownloadDeletePrimary
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

fsmStFailSysdebugTechSupportDownload>DeleteSub**Fault Code:** F17270**Message**

[FSM:STAGE:FAILED|RETRY]: Delete the tech-support file from subordinate under tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload>DeleteSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-sub-failed
mibFaultCode: 17270
mibFaultName: fsmStFailSysdebugTechSupportDownloadDeleteSub
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

fsmStFailSysdebugCoreDownload:CopyPrimary**Fault Code:** F17271**Message**

[FSM:STAGE:FAILED|RETRY]: Copy the Core file to primary for download(FSM-STAGE:sam:dme:SysdebugCoreDownload:CopyPrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-primary-failed
mibFaultCode: 17271
mibFaultName: fsmStFailSysdebugCoreDownloadCopyPrimary
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file-[name] |[switchId]
```

fsmStFailSysdebugCoreDownload:CopySub**Fault Code: F17271****Message**

[FSM:STAGE:FAILED|RETRY]: copy Core file on subordinate switch to tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload:CopySub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-sub-failed
mibFaultCode: 17271
mibFaultName: fsmStFailSysdebugCoreDownloadCopySub
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file-[name] |[switchId]
```

fsmStFailSysdebugCoreDownload>DeletePrimary**Fault Code: F17271****Message**

[FSM:STAGE:FAILED|RETRY]: Delete the Core file from primary switch under tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload>DeletePrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-primary-failed
mibFaultCode: 17271
mibFaultName: fsmStFailSysdebugCoreDownloadDeletePrimary
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmStFailSysdebugCoreDownload:DeleteSub**Fault Code: F17271****Message**

[FSM:STAGE:FAILED|RETRY]: Delete the Core file from subordinate under tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload:DeleteSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-sub-failed
mibFaultCode: 17271
mibFaultName: fsmStFailSysdebugCoreDownloadDeleteSub
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmStFailSysdebugLogControlEpLogControlPersist:Local

Fault Code: F17272

Message

[FSM:STAGE:FAILED|RETRY]: persisting LogControl on local(FSM-STAGE:sam:dme:SysdebugLogControlEpLogControlPersist:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17272
mibFaultName: fsmStFailSysdebugLogControlEpLogControlPersistLocal
moClass: sysdebug:LogControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/logcontrol
```

fsmStFailSysdebugLogControlEpLogControlPersist:Peer

Fault Code: F17272

Message

[FSM:STAGE:FAILED|RETRY]: persisting LogControl on peer(FSM-STAGE:sam:dme:SysdebugLogControlEpLogControlPersist:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 17272
mibFaultName: fsmStFailSysdebugLogControlEpLogControlPersistPeer
moClass: sysdebug:LogControlEp
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/logcontrol

fsmStFailEpqosDefinitionDeploy:Local

Fault Code: F17336

Message

[FSM:STAGE:FAILED|RETRY]: vnic qos policy [name] configuration to primary(FSM-STAGE:sam:dme:EpqosDefinitionDeploy:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 17336
mibFaultName: fsmStFailEpqosDefinitionDeployLocal
moClass: epqos:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ep-qos-[name]

fsmStFailEpqosDefinitionDeploy:Peer

Fault Code: F17336

Message

[FSM:STAGE:FAILED|RETRY]: vnic qos policy [name] configuration to secondary(FSM-STAGE:sam:dme:EpqosDefinitionDeploy:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: peer-failed
mibFaultCode: 17336

```

mibFaultName: fsmStFailEpgosDefinitionDeployPeer
moClass: epqos:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos- [name]

```

fsmStFailEpgosDefinitionDelTaskRemove:Local

Fault Code: F17337

Message

[FSM:STAGE:FAILED|RETRY]: vnic qos policy [name] removal from primary(FSM-STAGE:sam:dme:EpgosDefinitionDelTaskRemove:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17337
mibFaultName: fsmStFailEpgosDefinitionDelTaskRemoveLocal
moClass: epqos:DefinitionDelTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos-deletion- [defIntId]

```

fsmStFailEpgosDefinitionDelTaskRemove:Peer

Fault Code: F17337

Message

[FSM:STAGE:FAILED|RETRY]: vnic qos policy [name] removal from secondary(FSM-STAGE:sam:dme:EpgosDefinitionDelTaskRemove:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: peer-failed
mibFaultCode: 17337
mibFaultName: fsmStFailEpgosDefinitionDelTaskRemovePeer
moClass: epgos:DefinitionDelTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/ep-qos-deletion-[defIntId]

fsmStFailQosclassDefinitionConfigGlobalQoS:SetLocal**Fault Code:** F17340**Message**

[FSM:STAGE:FAILED|RETRY]: QoS Classification Definition [name] configuration on primary(FSM-STAGE:sam:dme:QosclassDefinitionConfigGlobalQoS:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-local-failed
mibFaultCode: 17340
mibFaultName: fsmStFailQosclassDefinitionConfigGlobalQoSSetLocal
moClass: qosclass:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/classes

fsmStFailQosclassDefinitionConfigGlobalQoS:SetPeer**Fault Code:** F17340**Message**

[FSM:STAGE:FAILED|RETRY]: QoS Classification Definition [name] configuration on secondary(FSM-STAGE:sam:dme:QosclassDefinitionConfigGlobalQoS:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-peer-failed
mibFaultCode: 17340
mibFaultName: fsmStFailQosclassDefinitionConfigGlobalQoSSetPeer
moClass: qosclass:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/classes
```

fsmStFailMgmtControllerRegistryConfig:Remove**Fault Code: F17347****Message**

[FSM:STAGE:FAILED|RETRY]: Deleting registry information from config file(FSM-STAGE:sam:dme:MgmtControllerRegistryConfig:Remove)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remove-failed
mibFaultCode: 17347
mibFaultName: fsmStFailMgmtControllerRegistryConfigRemove
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmStFailMgmtIfSwMgmtOobIfConfig:Switch

Fault Code: F17358

Message

[FSM:STAGE:FAILED|RETRY]: configuring the out-of-band interface(FSM-STAGE:sam:dme:MgmtIfSwMgmtOobIfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: switch-failed
mibFaultCode: 17358
mibFaultName: fsmStFailMgmtIfSwMgmtOobIfConfigSwitch
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmStFailMgmtIfSwMgmtInbandIfConfig:Switch

Fault Code: F17359

Message

[FSM:STAGE:FAILED|RETRY]: configuring the inband interface(FSM-STAGE:sam:dme:MgmtIfSwMgmtInbandIfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: switch-failed
mibFaultCode: 17359
mibFaultName: fsmStFailMgmtIfSwMgmtInbandIfConfigSwitch
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmStFailMgmtIPv6IfAddrSwMgmtOobIpv6IfConfig:Switch

Fault Code: F17360

Message

[FSM:STAGE:FAILED|RETRY]: configuring the out-of-band IPv6 interface(FSM-STAGE:sam:dme:MgmtIPv6IfAddrSwMgmtOobIpv6IfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: switch-failed
mibFaultCode: 17360
mibFaultName: fsmStFailMgmtIPv6IfAddrSwMgmtOobIPv6IfConfigSwitch
moClass: mgmt:IPv6IfAddr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6

```

fsmStFailNhTableHolderConfigureLinks:ApplyConfig

Fault Code: F17373

Message

```
[FSM:STAGE:FAILED|RETRY]: Apply
Configuration(FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:ApplyConfig)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-config-failed
mibFaultCode: 17373
mibFaultName: fsmStFailNhTableHolderConfigureLinksApplyConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmStFailNhTableHolderConfigureLinks:ConfigInterface

Fault Code: F17373

Message

[FSM:STAGE:FAILED|RETRY]: Configure Interface(FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:ConfigInterface)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-interface-failed
mibFaultCode: 17373
mibFaultName: fsmStFailNhTableHolderConfigureLinksConfigInterface
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmStFailNhTableHolderConfigureLinks:VerifyLinkConfig

Fault Code: F17373

Message

[FSM:STAGE:FAILED|RETRY]: (FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:VerifyLinkConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-link-config-failed
mibFaultCode: 17373
mibFaultName: fsmStFailNhTableHolderConfigureLinksVerifyLinkConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmStFailNhTableHolderBootstrapLinks:ApplyConfig**Fault Code: F17374****Message**

```
[FSM:STAGE:FAILED|RETRY]: Apply
Configuration(FSM-STAGE:sam:dme:NhTableHolderBootstrapLinks:ApplyConfig)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-config-failed
mibFaultCode: 17374
mibFaultName: fsmStFailNhTableHolderBootstrapLinksApplyConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmStFailStatsCollectionPolicyUpdateEp:SetEpA

Fault Code: F17378

Message

[FSM:STAGE:FAILED|RETRY]: Update endpoint on fabric interconnect
A(FSM-STAGE:sam:dme:StatsCollectionPolicyUpdateEp:SetEpA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-ep-afailed
mibFaultCode: 17378
mibFaultName: fsmStFailStatsCollectionPolicyUpdateEpSetEpA
moClass: stats:CollectionPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: stats/coll-policy-[name]
```

fsmStFailStatsCollectionPolicyUpdateEp:SetEpB

Fault Code: F17378

Message

[FSM:STAGE:FAILED|RETRY]: Update endpoint on fabric interconnect
B(FSM-STAGE:sam:dme:StatsCollectionPolicyUpdateEp:SetEpB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-ep-bfailed
mibFaultCode: 17378
mibFaultName: fsmStFailStatsCollectionPolicyUpdateEpSetEpB
moClass: stats:CollectionPolicy
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: stats/coll-policy- [name]

```

fsmStFailSyntheticFsObjCreate:createLocal

Fault Code: F17403

Message

[FSM:STAGE:FAILED|RETRY]: create on primary(FSM-STAGE:sam:dme:SyntheticFsObjCreate:createLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: create-local-failed
mibFaultCode: 17403
mibFaultName: fsmStFailSyntheticFsObjCreateCreateLocal
moClass: synthetic:Fsobj
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/file- [name]

```

fsmStFailSyntheticFsObjCreate:createRemote

Fault Code: F17403

Message

[FSM:STAGE:FAILED|RETRY]: create on secondary(FSM-STAGE:sam:dme:SyntheticFsObjCreate:createRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: create-remote-failed
mibFaultCode: 17403

```

```

mibFaultName: fsmStFailSyntheticFsObjCreateCreateRemote
moClass: synthetic:FsObj
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/file-[name]

```

fsmStFailCapabilityUpdaterUpdater:Apply

Fault Code: F17408

Message

[FSM:STAGE:FAILED|RETRY]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:Apply)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterApply
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]

```

fsmStFailCapabilityUpdaterUpdater:CopyRemote

Fault Code: F17408

Message

[FSM:STAGE:FAILED|RETRY]: syncing catalog files to subordinate(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-remote-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterCopyRemote
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater- [fileName]

fsmStFailCapabilityUpdaterUpdater>DeleteLocal**Fault Code:** F17408**Message**

[FSM:STAGE:FAILED|RETRY]: deleting temp image [fileName] on local(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater>DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-local-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdater>DeleteLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater- [fileName]

fsmStFailCapabilityUpdaterUpdater>EvaluateStatus**Fault Code:** F17408**Message**

[FSM:STAGE:FAILED|RETRY]: evaluating status of update(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater>EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterEvaluateStatus
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmStFailCapabilityUpdaterUpdater:Local

Fault Code: F17408

Message

[FSM:STAGE:FAILED|RETRY]: downloading catalog file [fileName] from [server](FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmStFailCapabilityUpdaterUpdater:RescanImages

Fault Code: F17408

Message

[FSM:STAGE:FAILED|RETRY]: rescanning image files(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:RescanImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: rescan-images-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterRescanImages
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmStFailCapabilityUpdaterUpdater:UnpackLocal**Fault Code: F17408****Message**

[FSM:STAGE:FAILED|RETRY]: unpacking catalog file [fileName] on primary(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 17408
mibFaultName: fsmStFailCapabilityUpdaterUpdaterUnpackLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmStFailCapabilityCatalogueActivateCatalog:ApplyCatalog

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:ApplyCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-catalog-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogApplyCatalog
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fsmStFailCapabilityCatalogueActivateCatalog:CopyCatFromRep

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: Copying Catalogue from repository to FI(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyCatFromRep)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-cat-from-rep-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogCopyCatFromRep
moClass: capability:Catalogue
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityCatalogueActivateCatalog:CopyExternalRepToRemote

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: syncing external repository to subordinate(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyExternalRepToRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-external-rep-to-remote-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogCopyExternalRepToRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityCatalogueActivateCatalog:CopyRemote

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: syncing catalog changes to subordinate(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-remote-failed
mibFaultCode: 17409

```

mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogCopyRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

```

fsmStFailCapabilityCatalogueActivateCatalog:EvaluateStatus

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: evaluating status of activation(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogEvaluateStatus
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

```

fsmStFailCapabilityCatalogueActivateCatalog:RescanImages

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: rescanning image files(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:RescanImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: rescan-images-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogRescanImages
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityCatalogueActivateCatalog:UnpackLocal

Fault Code: F17409

Message

[FSM:STAGE:FAILED|RETRY]: activating catalog changes(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unpack-local-failed
mibFaultCode: 17409
mibFaultName: fsmStFailCapabilityCatalogueActivateCatalogUnpackLocal
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityMgmtExtensionActivateMgmtExt:ApplyCatalog

Fault Code: F17410

Message

[FSM:STAGE:FAILED|RETRY]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:ApplyCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-catalog-failed
mibFaultCode: 17410
mibFaultName: fsmStFailCapabilityMgmtExtensionActivateMgmtExtApplyCatalog
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmStFailCapabilityMgmtExtensionActivateMgmtExt:CopyRemote

Fault Code: F17410

Message

[FSM:STAGE:FAILED|RETRY]: syncing management extension changes to subordinate(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-remote-failed
mibFaultCode: 17410
mibFaultName: fsmStFailCapabilityMgmtExtensionActivateMgmtExtCopyRemote
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmStFailCapabilityMgmtExtensionActivateMgmtExt:EvaluateStatus

Fault Code: F17410

Message

[FSM:STAGE:FAILED|RETRY]: evaluating status of activation(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 17410
mibFaultName: fsmStFailCapabilityMgmtExtensionActivateMgmtExtEvaluateStatus
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmStFailCapabilityMgmtExtensionActivateMgmtExt:RescanImages**Fault Code: F17410****Message**

```
[FSM:STAGE:FAILED|RETRY]: rescanning image
files(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:RescanImages)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: rescan-images-failed
mibFaultCode: 17410
mibFaultName: fsmStFailCapabilityMgmtExtensionActivateMgmtExtRescanImages
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```


fsmStFailCapabilityMgmtExtensionActivateMgmtExt:UnpackLocal

Fault Code: F17410

Message

[FSM:STAGE:FAILED|RETRY]: activating management extension changes(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 17410
mibFaultName: fsmStFailCapabilityMgmtExtensionActivateMgmtExtUnpackLocal
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmStFailCapabilityCatalogueDeployCatalogue:SyncPortAGLocal

Fault Code: F17411

Message

[FSM:STAGE:FAILED|RETRY]: Sending capability catalogue [version] to local portAG(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:SyncPortAGLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sync-portaglocal-failed
mibFaultCode: 17411
mibFaultName: fsmStFailCapabilityCatalogueDeployCatalogueSyncPortAGLocal
moClass: capability:Catalogue
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityCatalogueDeployCatalogue:SyncPortAGRemote

Fault Code: F17411

Message

[FSM:STAGE:FAILED|RETRY]: Sending capability catalogue [version] to remote portAG(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:SyncPortAGRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sync-portagremote-failed
mibFaultCode: 17411
mibFaultName: fsmStFailCapabilityCatalogueDeployCatalogueSyncPortAGRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmStFailCapabilityCatalogueDeployCatalogue:finalize

Fault Code: F17411

Message

[FSM:STAGE:FAILED|RETRY]: Finalizing capability catalogue [version] deployment(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:finalize)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: finalize-failed
mibFaultCode: 17411

```

mibFaultName: fsmStFailCapabilityCatalogueDeployCatalogueFinalize
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

```

fsmStFailSwEthMonDeploy:UpdateEthMon

Fault Code: F17420

Message

[FSM:STAGE:FAILED|RETRY]: Ethernet traffic monitor (SPAN)configuration on [switchId](FSM-STAGE:sam:dme:SwEthMonDeploy:UpdateEthMon)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-eth-mon-failed
mibFaultCode: 17420
mibFaultName: fsmStFailSwEthMonDeployUpdateEthMon
moClass: sw:EthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id]/lanmon-eth/mon- [name]

```

fsmStFailSwSspEthMonDeploy:UpdateSspEthMon

Fault Code: F17469

Message

[FSM:STAGE:FAILED|RETRY]: SSP Packet Capture configuration on [switchId](FSM-STAGE:sam:dme:SwSspEthMonDeploy:UpdateSspEthMon)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-ssp-eth-mon-failed
mibFaultCode: 17469
mibFaultName: fsmStFailSwSspEthMonDeployUpdateSspEthMon
moClass: sw:SspEthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /ssp-lanmon-eth/ssp-mon-session[name]

fsmStFailSwSspEthMonSrcPhyEpDelete>DeletePcapFile**Fault Code:** F17470**Message**

[FSM:STAGE:FAILED|RETRY]: Delete Pcap file whenever there is a delete interface trigger(FSM-STAGE:sam:dme:SwSspEthMonSrcPhyEpDelete>DeletePcapFile)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-pcap-file-failed
mibFaultCode: 17470
mibFaultName: fsmStFailSwSspEthMonSrcPhyEpDelete>DeletePcapFile
moClass: sw:SspEthMonSrcPhyEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /ssp-lanmon-eth/ssp-mon-session[name] /ssp-mon-src-phy- [chassisId] -slot- [slotId] -port- [portId] -aggr- [aggrPortId]

fsmStFailFabricVnetEpSyncEpPushVnetEpDeletion:Sync**Fault Code:** F17476**Message**

[FSM:STAGE:FAILED|RETRY]: Update resource-mgr with VnetEp deletion(FSM-STAGE:sam:dme:FabricVnetEpSyncEpPushVnetEpDeletion:Sync)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sync-failed
mibFaultCode: 17476
mibFaultName: fsmStFailFabricVnetEpSyncEpPushVnetEpDeletionSync
moClass: fabric:VnetEpSyncEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/providers/prov-[type]/syncEp
```

fsmStFailFabricLanCloudSwitchMode:SwConfigLocal

Fault Code: F17477

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:FabricLanCloudSwitchMode:SwConfigLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 17477
mibFaultName: fsmStFailFabricLanCloudSwitchModeSwConfigLocal
moClass: fabric:LanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan
```

fsmStFailFabricLanCloudSwitchMode:SwConfigPeer

Fault Code: F17477

Message

```
[FSM:STAGE:FAILED|RETRY]: Fabric interconnect mode configuration to
primary(FSM-STAGE:sam:dme:FabricLanCloudSwitchMode:SwConfigPeer)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 17477
mibFaultName: fsmStFailFabricLanCloudSwitchModeSwConfigPeer
moClass: fabric:LanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan
```

fsmStFailFabricSanCloudSwitchMode:SwConfigLocal**Fault Code: F17478****Message**

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:FabricSanCloudSwitchMode:SwConfigLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 17478
mibFaultName: fsmStFailFabricSanCloudSwitchModeSwConfigLocal
moClass: fabric:SanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/san
```

fsmStFailFabricSanCloudSwitchMode:SwConfigPeer

Fault Code: F17478

Message

[FSM:STAGE:FAILED|RETRY]: Fabric interconnect FC mode configuration to primary(FSM-STAGE:sam:dme:FabricSanCloudSwitchMode:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 17478
mibFaultName: fsmStFailFabricSanCloudSwitchModeSwConfigPeer
moClass: fabric:SanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/san

fsmStFailFabricEpMgrConfigure:ApplyConfig

Fault Code: F17484

Message

[FSM:STAGE:FAILED|RETRY]: Apply switch configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-config-failed
mibFaultCode: 17484
mibFaultName: fsmStFailFabricEpMgrConfigureApplyConfig
moClass: fabric:EpMgr
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

fsmStFailFabricEpMgrConfigure:ApplyPhysical

Fault Code: F17484

Message

[FSM:STAGE:FAILED|RETRY]: Applying physical configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ApplyPhysical)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-physical-failed
mibFaultCode: 17484
mibFaultName: fsmStFailFabricEpMgrConfigureApplyPhysical
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

fsmStFailFabricEpMgrConfigure:ValidateConfiguration

Fault Code: F17484

Message

[FSM:STAGE:FAILED|RETRY]: Validating logical configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ValidateConfiguration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-configuration-failed
mibFaultCode: 17484


```

mibFaultName: fsmStFailFabricEpMgrConfigureValidateConfiguration
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

```

fsmStFailFabricEpMgrConfigure:WaitOnPhys

Fault Code: F17484

Message

[FSM:STAGE:FAILED|RETRY]: Waiting on physical change application(FSM-STAGE:sam:dme:FabricEpMgrConfigure:WaitOnPhys)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-on-phys-failed
mibFaultCode: 17484
mibFaultName: fsmStFailFabricEpMgrConfigureWaitOnPhys
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

```

fsmStFailMgmtExportPolicyReportConfigCopy:Report

Fault Code: F17490

Message

[FSM:STAGE:FAILED|RETRY]: Report config copy to Ops Mgr(FSM-STAGE:sam:dme:MgmtExportPolicyReportConfigCopy:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: report-failed
mibFaultCode: 17490
mibFaultName: fsmStFailMgmtExportPolicyReportConfigCopyReport
moClass: mgmt:ExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /cfg-exp-policy- [name]
Affected MO: org- [name] /db-backup-policy- [name]

fsmStFailExtpolProviderReportConfigImport:Report

Fault Code: F17491

Message

[FSM:STAGE:FAILED|RETRY]: Report config import to Ops Mgr(FSM-STAGE:sam:dme:ExtpolProviderReportConfigImport:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: report-failed
mibFaultCode: 17491
mibFaultName: fsmStFailExtpolProviderReportConfigImportReport
moClass: extpol:Provider
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/providers/prov- [type]

fsmStFailMgmtIfVirtualIfConfig:Local

Fault Code: F17492

Message

[FSM:STAGE:FAILED|RETRY]: Updating virtual interface on local fabric interconnect(FSM-STAGE:sam:dme:MgmtIfVirtualIfConfig:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17492
mibFaultName: fsmStFailMgmtIfVirtualIfConfigLocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmStFailMgmtIfVirtualIfConfig:Remote

Fault Code: F17492

Message

[FSM:STAGE:FAILED|RETRY]: Updating virtual interface on peer fabric interconnect(FSM-STAGE:sam:dme:MgmtIfVirtualIfConfig:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remote-failed
mibFaultCode: 17492
mibFaultName: fsmStFailMgmtIfVirtualIfConfigRemote

```

```

moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmStFailMgmtIfEnableVip:Local

Fault Code: F17493

Message

[FSM:STAGE:FAILED|RETRY]: Enable virtual interface on local fabric interconnect(FSM-STAGE:sam:dme:MgmtIfEnableVip:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17493
mibFaultName: fsmStFailMgmtIfEnableVipLocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]

```

```

Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmStFailMgmtIfDisableVip:Peer

Fault Code: F17494

Message

[FSM:STAGE:FAILEDIRETRY]: Disable virtual interface on peer fabric interconnect(FSM-STAGE:sam:dme:MgmtIfDisableVip:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed
mibFaultCode: 17494
mibFaultName: fsmStFailMgmtIfDisableVipPeer
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmStFailMgmtIfEnableHA:Local

Fault Code: F17495

Message

[FSM:STAGE:FAILED|RETRY]: Transition from single to cluster mode(FSM-STAGE:sam:dme:MgmtIfEnableHA:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 17495
mibFaultName: fsmStFailMgmtIfEnableHALocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/mgmt/if- [id]
Affected MO: sys/switch- [id]/mgmt/if- [id]

```

fsmStFailMgmtBackupBackup:backupLocal

Fault Code: F17496

Message

[FSM:STAGE:FAILED|RETRY]: internal database backup(FSM-STAGE:sam:dme:MgmtBackupBackup:backupLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: backup-local-failed
mibFaultCode: 17496
mibFaultName: fsmStFailMgmtBackupBackupBackupLocal
moClass: mgmt:Backup
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/backup- [hostname]
```

fsmStFailMgmtBackupBackup:upload**Fault Code: F17496****Message**

[FSM:STAGE:FAILED|RETRY]: internal system
backup(FSM-STAGE:sam:dme:MgmtBackupBackup:upload)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: upload-failed
mibFaultCode: 17496
mibFaultName: fsmStFailMgmtBackupBackupUpload
moClass: mgmt:Backup
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/backup- [hostname]
```

fsmStFailMgmtImporterImport:cleanUp

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: cleaning up old Security Service configuration(FSM-STAGE:sam:dme:MgmtImporterImport:cleanUp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: clean-up-failed
mibFaultCode: 17497
mibFaultName: fsmStFailMgmtImporterImportCleanUp
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]
```

fsmStFailMgmtImporterImport:config

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: importing the configuration file(FSM-STAGE:sam:dme:MgmtImporterImport:config)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-failed
mibFaultCode: 17497
mibFaultName: fsmStFailMgmtImporterImportConfig
moClass: mgmt:Importer
Type: fsm
Callhome: none
```



```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmStFailMgmtImporterImport:configBreakout

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: updating breakout port configuration(FSM-STAGE:sam:dme:MgmtImporterImport:configBreakout)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: config-breakout-failed
mibFaultCode: 17497
mibFaultName: fsmStFailMgmtImporterImportConfigBreakout
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmStFailMgmtImporterImport:downloadLocal

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: downloading the configuration file(FSM-STAGE:sam:dme:MgmtImporterImport:downloadLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: download-local-failed
mibFaultCode: 17497

```

```

mibFaultName: fsmStFailMgmtImporterImportDownloadLocal
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmStFailMgmtImporterImport:reportResults

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: Reporting results of import configuration(FSM-STAGE:sam:dme:MgmtImporterImport:reportResults)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: report-results-failed
mibFaultCode: 17497
mibFaultName: fsmStFailMgmtImporterImportReportResults
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmStFailMgmtImporterImport:waitForSwitch

Fault Code: F17497

Message

[FSM:STAGE:FAILED|RETRY]: waiting for completion of switch configuration(FSM-STAGE:sam:dme:MgmtImporterImport:waitForSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-switch-failed
mibFaultCode: 17497
mibFaultName: fsmStFailMgmtImporterImportWaitForSwitch
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

fsmStFailMgmtControllerSysConfig:Primary**Fault Code: F17498****Message**

[FSM:STAGE:FAILEDIRETRY]: system configuration on primary(FSM-STAGE:sam:dme:MgmtControllerSysConfig:Primary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: primary-failed
mibFaultCode: 17498
mibFaultName: fsmStFailMgmtControllerSysConfigPrimary
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt
Affected MO: sys/chassis- [id]/slot- [id]/mgmt
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt
Affected MO: sys/fex- [id]/mgmt
Affected MO: sys/fex- [id]/slot- [id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt
Affected MO: sys/rack-unit- [id]/boardController/mgmt
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt
Affected MO: sys/rack-unit- [id]/mgmt
Affected MO: sys/switch- [id]/mgmt

fsmStFailMgmtControllerSysConfig:Secondary

Fault Code: F17498

Message

[FSM:STAGE:FAILED|RETRY]: system configuration on secondary(FSM-STAGE:sam:dme:MgmtControllerSysConfig:Secondary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: secondary-failed
mibFaultCode: 17498
mibFaultName: fsmStFailMgmtControllerSysConfigSecondary
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt
Affected MO: sys/chassis- [id]/slot- [id]/mgmt
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt
Affected MO: sys/fex- [id]/mgmt
Affected MO: sys/fex- [id]/slot- [id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt
Affected MO: sys/rack-unit- [id]/boardController/mgmt
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt
Affected MO: sys/rack-unit- [id]/mgmt
Affected MO: sys/switch- [id]/mgmt

fsmStFailNfsMountInstMount:MountLocal

Fault Code: F17531

Message

[FSM:STAGE:FAILED|RETRY]: Mount nfs [remoteDir] from server [server] on local switch(FSM-STAGE:sam:dme:NfsMountInstMount:MountLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: mount-local-failed
mibFaultCode: 17531
mibFaultName: fsmStFailNfsMountInstMountMountLocal
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmStFailNfsMountInstMount:MountPeer**Fault Code: F17531****Message**

[FSM:STAGE:FAILED|RETRY]: Mount nfs [remoteDir] from NFS server [server] on peer switch(FSM-STAGE:sam:dme:NfsMountInstMount:MountPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: mount-peer-failed
mibFaultCode: 17531
mibFaultName: fsmStFailNfsMountInstMountMountPeer
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmStFailNfsMountInstMount:RegisterClient**Fault Code: F17531****Message**

[FSM:STAGE:FAILED|RETRY]: Register client with Ops Mgr(FSM-STAGE:sam:dme:NfsMountInstMount:RegisterClient)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: register-client-failed
mibFaultCode: 17531
mibFaultName: fsmStFailNfsMountInstMountRegisterClient
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmStFailNfsMountInstMount:VerifyRegistration**Fault Code: F17531****Message**

[FSM:STAGE:FAILED|RETRY]: Verify client registration with Ops Mgr(FSM-STAGE:sam:dme:NfsMountInstMount:VerifyRegistration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-registration-failed
mibFaultCode: 17531
mibFaultName: fsmStFailNfsMountInstMountVerifyRegistration
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmStFailNfsMountInstUnmount:UnmountLocal

Fault Code: F17532

Message

[FSM:STAGE:FAILED|RETRY]: Unmount nfs [remoteDir] from server [server](FSM-STAGE:sam:dme:NfsMountInstUnmount:UnmountLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unmount-local-failed
mibFaultCode: 17532
mibFaultName: fsmStFailNfsMountInstUnmountUnmountLocal
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]

fsmStFailNfsMountInstUnmount:UnmountPeer

Fault Code: F17532

Message

[FSM:STAGE:FAILED|RETRY]: Unmount nfs [remoteDir] from server [server](FSM-STAGE:sam:dme:NfsMountInstUnmount:UnmountPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unmount-peer-failed
mibFaultCode: 17532
mibFaultName: fsmStFailNfsMountInstUnmountUnmountPeer
moClass: nfs:MountInst
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]

fsmStFailNfsMountDefReportNfsMountSuspend:Report

Fault Code: F17533

Message

[FSM:STAGE:FAILED|RETRY]: Report mount suspend success to operations manager(FSM-STAGE:sam:dme:NfsMountDefReportNfsMountSuspend:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: report-failed
mibFaultCode: 17533
mibFaultName: fsmStFailNfsMountDefReportNfsMountSuspendReport
moClass: nfs:MountDef
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: nfs-ep/nfs-mount-def-[name]

fsmStFailExtpolEpRepairCert:cleanOldData

Fault Code: F17554

Message

[FSM:STAGE:FAILED|RETRY]: Cleaning certificates, channels and policy meta data(FSM-STAGE:sam:dme:ExtpolEpRepairCert:cleanOldData)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: clean-old-data-failed
mibFaultCode: 17554


```

mibFaultName: fsmStFailExtpolEpRepairCertCleanOldData
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmStFailExtpolEpRepairCert:request

Fault Code: F17554

Message

[FSM:STAGE:FAILED|RETRY]: Provisioning latest certificates(FSM-STAGE:sam:dme:ExtpolEpRepairCert:request)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: request-failed
mibFaultCode: 17554
mibFaultName: fsmStFailExtpolEpRepairCertRequest
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmStFailExtpolEpRepairCert:unregister

Fault Code: F17554

Message

[FSM:STAGE:FAILED|RETRY]: unregister from old FPR Central, if needed(FSM-STAGE:sam:dme:ExtpolEpRepairCert:unregister)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unregister-failed
mibFaultCode: 17554
mibFaultName: fsmStFailExtpolEpRepairCertUnregister
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

fsmStFailExtpolEpRepairCert:verify

Fault Code: F17554

Message

[FSM:STAGE:FAILED|RETRY]: checking that cert was provisioned(FSM-STAGE:sam:dme:ExtpolEpRepairCert:verify)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: verify-failed
mibFaultCode: 17554
mibFaultName: fsmStFailExtpolEpRepairCertVerify
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

fsmStFailExtpolEpRepairCert:verifyGuid

Fault Code: F17554

Message

[FSM:STAGE:FAILED|RETRY]: verifying GUID of FPR Central(FSM-STAGE:sam:dme:ExtpolEpRepairCert:verifyGuid)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-guid-failed
mibFaultCode: 17554
mibFaultName: fsmStFailExtpolEpRepairCertVerifyGuid
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol
```

fsmStFailPolicyControlEpOperate:Resolve**Fault Code: F17555****Message**

[FSM:STAGE:FAILED|RETRY]: (FSM-STAGE:sam:dme:PolicyControlEpOperate:Resolve)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-failed
mibFaultCode: 17555
mibFaultName: fsmStFailPolicyControlEpOperateResolve
moClass: policy:ControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]
```

fsmStFailPolicyControlledTypeOperate:ResolveAll**Fault Code: F17556****Message**

[FSM:STAGE:FAILED|RETRY]: Resolving controlled type global policies(FSM-STAGE:sam:dme:PolicyControlledTypeOperate:ResolveAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 17556
mibFaultName: fsmStFailPolicyControlledTypeOperateResolveAll
moClass: policy:ControlledType
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep-[type]/cfg-backup-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/comm-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/datetime-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/discovery-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/dns-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/fabric-fw-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/fault-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/mep-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/monitoring-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/powermgmt-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/psu-ctrl/ctrlled-type-[type]
Affected MO: sys/control-ep-[type]/security-ctrl/ctrlled-type-[type]

```

fsmStFailPolicyPolicyScopeReleasePolicyFsm:Release

Fault Code: F17559

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleasePolicyFsm:Release)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-failed
mibFaultCode: 17559
mibFaultName: fsmStFailPolicyPolicyScopeReleasePolicyFsmRelease
moClass: policy:PolicyScope
Type: fsm

```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeReleaseOperationFsm:Release

Fault Code: F17560

Message

```
[FSM:STAGE:FAILEDIRETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseOperationFsm:Release)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-failed
mibFaultCode: 17560
mibFaultName: fsmStFailPolicyPolicyScopeReleaseOperationFsmRelease
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]

```

Affected MO:

policy-ep/scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policy Name]

fsmStFailPolicyPolicyScopeReleaseStorageFsm:Release

Fault Code: F17561**Message**

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseStorageFsm:Release)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-failed
mibFaultCode: 17561
mibFaultName: fsmStFailPolicyPolicyScopeReleaseStorageFsmRelease
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client- [id] /scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policyName]
Affected MO:
 extpol/reg/controllers/contro- [id] /scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policyName]
Affected MO:
 extpol/reg/providers/prov- [type] /scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policyName]
Affected MO:
 extpol/reg/scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policyName]
Affected MO:
 policy-ep/scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policy Name]

fsmStFailPolicyPolicyScopeResolveManyPolicyFsm:ResolveMany

Fault Code: F17562**Message**

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyPolicyFsm:ResolveMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 17562
mibFaultName: fsmStFailPolicyPolicyScopeResolveManyPolicyFsmResolveMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
  extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
  [resolveType]-[policyName]
Affected MO:
  extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
  [resolveType]-[policyName]
Affected MO:
  extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-
  [resolveType]-[policyName]
Affected MO:
  extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
  policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

```

fsmStFailPolicyPolicyScopeResolveManyOperationFsm:ResolveMany

Fault Code: F17563

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyOperationFsm:ResolveMany)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 17563
mibFaultName: fsmStFailPolicyPolicyScopeResolveManyOperationFsmResolveMany

```

```

moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client- [id] /scope-cont- [appType] /context- [name] /scope- [policyType] -
[resolveType] - [policyName]
Affected MO:
extpol/reg/controllers/contro- [id] /scope-cont- [appType] /context- [name] /scope- [policyTy
pe] - [resolveType] - [policyName]
Affected MO:
extpol/reg/providers/prov- [type] /scope-cont- [appType] /context- [name] /scope- [policyType
] - [resolveType] - [policyName]
Affected MO:
extpol/reg/scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [polic
yName]
Affected MO:
policy-ep/scope-cont- [appType] /context- [name] /scope- [policyType] - [resolveType] - [policy
Name]

```

fsmStFailPolicyPolicyScopeResolveManyStorageFsm:ResolveMany

Fault Code: F17564

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyStorageFsm:ResolveMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 17564
mibFaultName: fsmStFailPolicyPolicyScopeResolveManyStorageFsmResolveMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client- [id] /scope-cont- [appType] /context- [name] /scope- [policyType] -
[resolveType] - [policyName]
Affected MO:
extpol/reg/controllers/contro- [id] /scope-cont- [appType] /context- [name] /scope- [policyTy
pe] - [resolveType] - [policyName]
Affected MO:
extpol/reg/providers/prov- [type] /scope-cont- [appType] /context- [name] /scope- [policyType
] - [resolveType] - [policyName]

```


Affected MO:

extpol/reg/scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

Affected MO:

policy-ep/scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

fsmStFailPolicyPolicyScopeReleaseManyPolicyFsm:ReleaseMany

Fault Code: F17565

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyPolicyFsm:ReleaseMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning

Cause: release-many-failed

mibFaultCode: 17565

mibFaultName: fsmStFailPolicyPolicyScopeReleaseManyPolicyFsmReleaseMany

moClass: policy:PolicyScope

Type: fsm

Callhome: none

Auto Cleared: true

Is Implemented: true

Affected MO:

extpol/reg/clients/client - [id] /scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

Affected MO:

extpol/reg/controllers/contro - [id] /scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

Affected MO:

extpol/reg/providers/prov - [type] /scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

Affected MO:

extpol/reg/scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

Affected MO:

policy-ep/scope-cont - [appType] /context - [name] /scope - [policyType] - [resolveType] - [policyName]

fsmStFailPolicyPolicyScopeReleaseManyOperationFsm:ReleaseMany

Fault Code: F17566

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyOperationFsm:ReleaseMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-many-failed
mibFaultCode: 17566
mibFaultName: fsmStFailPolicyPolicyScopeReleaseManyOperationFsmReleaseMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmStFailPolicyPolicyScopeReleaseManyStorageFsm:ReleaseMany

Fault Code: F17567

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyStorageFsm:ReleaseMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-many-failed
mibFaultCode: 17567
mibFaultName: fsmStFailPolicyPolicyScopeReleaseManyStorageFsmReleaseMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeResolveAllPolicyFsm:ResolveAll

Fault Code: F17568

Message

```
[FSM:STAGE:FAILEDIRETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllPolicyFsm:ResolveAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 17568
mibFaultName: fsmStFailPolicyPolicyScopeResolveAllPolicyFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```

```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeResolveAllOperationFsm:ResolveAll

Fault Code: F17569

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllOperationFsm:ResolveAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 17569
mibFaultName: fsmStFailPolicyPolicyScopeResolveAllOperationFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeResolveAllStorageFsm:ResolveAll

Fault Code: F17570

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllStorageFsm:ResolveAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-all-failed
mibFaultCode: 17570
mibFaultName: fsmStFailPolicyPolicyScopeResolveAllStorageFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
  extpol/reg/clients/client- [id]/scope-cont- [appType]/context- [name]/scope- [policyType] -
  [resolveType] - [policyName]
Affected MO:
  extpol/reg/controllers/contro- [id]/scope-cont- [appType]/context- [name]/scope- [policyTy
  pe] - [resolveType] - [policyName]
Affected MO:
  extpol/reg/providers/prov- [type]/scope-cont- [appType]/context- [name]/scope- [policyType
  ] - [resolveType] - [policyName]
Affected MO:
  extpol/reg/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [polic
  yName]
Affected MO:
  policy-ep/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [policy
  Name]
```

fsmStFailPolicyPolicyScopeReleaseAllPolicyFsm:ReleaseAll

Fault Code: F17571

Message

[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllPolicyFsm:ReleaseAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-all-failed
mibFaultCode: 17571
mibFaultName: fsmStFailPolicyPolicyScopeReleaseAllPolicyFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeReleaseAllOperationFsm:ReleaseAll

Fault Code: F17572

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllOperationFsm:ReleaseAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-all-failed
mibFaultCode: 17572
mibFaultName: fsmStFailPolicyPolicyScopeReleaseAllOperationFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```

```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailPolicyPolicyScopeReleaseAllStorageFsm:ReleaseAll

Fault Code: F17573

Message

```
[FSM:STAGE:FAILED|RETRY]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllStorageFsm:ReleaseAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-all-failed
mibFaultCode: 17573
mibFaultName: fsmStFailPolicyPolicyScopeReleaseAllStorageFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmStFailFirmwareInfraPackInfraVersion:Restore

Fault Code: F17690

Message

[FSM:STAGE:FAILED|RETRY]: Check and Restore the Platform Version(FSM-STAGE:sam:dme:FirmwareInfraPackInfraVersion:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: restore-failed
mibFaultCode: 17690
mibFaultName: fsmStFailFirmwareInfraPackInfraVersionRestore
moClass: firmware:InfraPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /fw-infra-pack- [name]
```

fsmStFailFirmwareInfraPackInfraVersion:WaitForReady

Fault Code: F17690

Message

[FSM:STAGE:FAILED|RETRY]: Wait for system to be ready(FSM-STAGE:sam:dme:FirmwareInfraPackInfraVersion:WaitForReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-ready-failed
mibFaultCode: 17690
mibFaultName: fsmStFailFirmwareInfraPackInfraVersionWaitForReady
moClass: firmware:InfraPack
Type: fsm
Callhome: none
```



```

Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/fw-infra-pack- [name]

```

fsmStFailFirmwareValidationStatusValidate:ApplicationPack

Fault Code: F17700

Message

[FSM:STAGE:FAILED|RETRY]: Validating the application pack(FSM-STAGE:sam:dme:FirmwareValidationStatusValidate:ApplicationPack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: application-pack-failed
mibFaultCode: 17700
mibFaultName: fsmStFailFirmwareValidationStatusValidateApplicationPack
moClass: firmware:ValidationStatus
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib- [name]/validation

```

fsmStFailFirmwareValidationStatusValidate:Complete

Fault Code: F17700

Message

[FSM:STAGE:FAILED|RETRY]: Complete Validation(FSM-STAGE:sam:dme:FirmwareValidationStatusValidate:Complete)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: complete-failed
mibFaultCode: 17700

```

```

mibFaultName: fsmStFailFirmwareValidationStatusValidateComplete
moClass: firmware:ValidationStatus
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]/validation

```

fsmStFailSdLogicalDeviceConfigureUserMacs:ConfigureSwitch

Fault Code: F17711

Message

[FSM:STAGE:FAILED|RETRY]: Invoke Port API to configure the switch(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureUserMacs:ConfigureSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: configure-switch-failed
mibFaultCode: 17711
mibFaultName: fsmStFailSdLogicalDeviceConfigureUserMacsConfigureSwitch
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld-[name]

```

fsmStFailSdLogicalDeviceConfigureUserMacs:WaitForSwitchConfig

Fault Code: F17711

Message

[FSM:STAGE:FAILED|RETRY]: Wait for Switch configuration to complete(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureUserMacs:WaitForSwitchConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-switch-config-failed
mibFaultCode: 17711
mibFaultName: fsmStFailSdLogicalDeviceConfigureUserMacsWaitForSwitchConfig
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmStFailMgmtIfSwMgmtOobIfDhcpConfig:StopDhcpSvc**Fault Code: F17715****Message**

[FSM:STAGE:FAILEDIRETRY]: disabling the out-of-band interface dhcp service(FSM-STAGE:sam:dme:MgmtIfSwMgmtOobIfDhcpConfig:StopDhcpSvc)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: stop-dhcp-svc-failed
mibFaultCode: 17715
mibFaultName: fsmStFailMgmtIfSwMgmtOobIfDhcpConfigStopDhcpSvc
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/mgmt/if- [id]
Affected MO: sys/switch- [id]/mgmt/if- [id]

fsmStFailSdLduUpdateInterfaceStatus:SendStatus

Fault Code: F17718

Message

[FSM:STAGE:FAILED|RETRY]: Send Interface Operational State(FSM-STAGE:sam:dme:SdLduUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-status-failed
mibFaultCode: 17718
mibFaultName: fsmStFailSdLduUpdateInterfaceStatusSendStatus
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]
```

fsmStFailEquipmentChassisShutdownChassis:ApplyShutdown

Fault Code: F17724

Message

[FSM:STAGE:FAILED|RETRY]: Shutdown Chassis(FSM-STAGE:sam:dme:EquipmentChassisShutdownChassis:ApplyShutdown)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-shutdown-failed
mibFaultCode: 17724
mibFaultName: fsmStFailEquipmentChassisShutdownChassisApplyShutdown
moClass: equipment:Chassis
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmStFailEquipmentChassisRebootChassis:ApplyReboot

Fault Code: F17725

Message

```

[FSM:STAGE:FAILED|RETRY]: Reboot
Chassis(FSM-STAGE:sam:dme:EquipmentChassisRebootChassis:ApplyReboot)

```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-reboot-failed
mibFaultCode: 17725
mibFaultName: fsmStFailEquipmentChassisRebootChassisApplyReboot
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmStFailIpsecEpUpdateEp:ApplyConfig

Fault Code: F17730

Message

```

[FSM:STAGE:FAILED|RETRY]: configure IPsec
connections(FSM-STAGE:sam:dme:IpsecEpUpdateEp:ApplyConfig)

```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-config-failed

```

```

mibFaultCode: 17730
mibFaultName: fsmStFailIpsecEpUpdateEpApplyConfig
moClass: ipsec:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ipsec-ext

```

fsmStFailNetworkEthLanMgmtUpdateInterfaceStatus:SendStatus

Fault Code: F17743

Message

[FSM:STAGE:FAILED|RETRY]: Send Management Interface Operational State(FSM-STAGE:sam:dme:NetworkEthLanMgmtUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-status-failed
mibFaultCode: 17743
mibFaultName: fsmStFailNetworkEthLanMgmtUpdateInterfaceStatusSendStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/mgmt-port-[portId]

```

fsmStFailNetworkEthLanMgmtUpdateMgmtInterfaceStatus:SendStatus

Fault Code: F17744

Message

[FSM:STAGE:FAILED|RETRY]: Send Management Interface Operational State(FSM-STAGE:sam:dme:NetworkEthLanMgmtUpdateMgmtInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-status-failed
mibFaultCode: 17744
mibFaultName: fsmStFailNetworkEthLanMgmtUpdateMgmtInterfaceStatusSendStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /mgmt-port- [portId]

fsmRmtErrComputeServerDiscPolicyResolveScrubPolicy:Resolve**Fault Code:** F77916**Message**

[FSM:STAGE:REMOTE-ERROR]: Resolving scrub policy(FSM-STAGE:sam:dme:ComputeServerDiscPolicyResolveScrubPolicy:Resolve)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-failed
mibFaultCode: 77916
mibFaultName: fsmRmtErrComputeServerDiscPolicyResolveScrubPolicyResolve
moClass: compute:ServerDiscPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /server-discovery

fsmRmtErrGmetaHolderInventory:CheckInventoryStatus**Fault Code:** F77917**Message**

[FSM:STAGE:REMOTE-ERROR]: Throttle inventory(FSM-STAGE:sam:dme:GmetaHolderInventory:CheckInventoryStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-inventory-status-failed
mibFaultCode: 77917
mibFaultName: fsmRmtErrGmetaHolderInventoryCheckInventoryStatus
moClass: gmeta:Holder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: gmeta/category-[category]-provider-[provider]
```

fsmRmtErrGmetaHolderInventory:ReportFullInventory

Fault Code: F77917

Message

[FSM:STAGE:REMOTE-ERROR]: Report
inventory(FSM-STAGE:sam:dme:GmetaHolderInventory:ReportFullInventory)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: report-full-inventory-failed
mibFaultCode: 77917
mibFaultName: fsmRmtErrGmetaHolderInventoryReportFullInventory
moClass: gmeta:Holder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: gmeta/category-[category]-provider-[provider]
```

fsmRmtErrFirmwareDownloaderDownload:CheckPendingNetworkConfig

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: checking pending management network
config(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:CheckPendingNetworkConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-pending-network-config-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadCheckPendingNetworkConfig
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmRmtErrFirmwareDownloaderDownload:CopyRemote

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: sync images to subordinate(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-remote-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadCopyRemote
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmRmtErrFirmwareDownloaderDownload:DeleteExtraImages

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: deleting extra distributable images(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteExtraImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-extra-images-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadDeleteExtraImages
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmRmtErrFirmwareDownloaderDownload:DeleteLocal

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: deleting downloadable [fileName] on local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-local-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadDeleteLocal
moClass: firmware:Downloader
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

```

fsmRmtErrFirmwareDownloaderDownload:Local

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: downloading image [fileName] from [server](FSM-STAGE:sam:dme:FirmwareDownloaderDownload:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadLocal
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

```

fsmRmtErrFirmwareDownloaderDownload:UnpackLocal

Fault Code: F77957

Message

[FSM:STAGE:REMOTE-ERROR]: unpacking image [fileName] on primary(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unpack-local-failed
mibFaultCode: 77957
mibFaultName: fsmRmtErrFirmwareDownloaderDownloadUnpackLocal
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]

fsmRmtErrFirmwareImageDelete:Local

Fault Code: F77958

Message

[FSM:STAGE:REMOTE-ERROR]: deleting image file [name] ([invTag]) from primary(FSM-STAGE:sam:dme:FirmwareImageDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 77958
mibFaultName: fsmRmtErrFirmwareImageDeleteLocal
moClass: firmware:Image
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/image- [name]

fsmRmtErrFirmwareImageDelete:Remote

Fault Code: F77958

Message

[FSM:STAGE:REMOTE-ERROR]: deleting image file [name] ([invTag]) from secondary(FSM-STAGE:sam:dme:FirmwareImageDelete:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 77958
mibFaultName: fsmRmtErrFirmwareImageDeleteRemote
moClass: firmware:Image
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/image-[name]
```

fsmRmtErrFirmwareDistributableDelete:Local

Fault Code: F77959

Message

[FSM:STAGE:REMOTE-ERROR]: deleting package [name] from primary(FSM-STAGE:sam:dme:FirmwareDistributableDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 77959
mibFaultName: fsmRmtErrFirmwareDistributableDeleteLocal
moClass: firmware:Distributable
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]
```

fsmRmtErrFirmwareDistributableDelete:Remote

Fault Code: F77959

Message

[FSM:STAGE:REMOTE-ERROR]: deleting package [name] from secondary(FSM-STAGE:sam:dme:FirmwareDistributableDelete:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 77959
mibFaultName: fsmRmtErrFirmwareDistributableDeleteRemote
moClass: firmware:Distributable
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]
```

fsmRmtErrMgmtControllerUpdateUCSManager:copyExtToLocal**Fault Code: F77960****Message**

[FSM:STAGE:REMOTE-ERROR]: copying image from external repository to local repository(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:copyExtToLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-ext-to-local-failed
mibFaultCode: 77960
mibFaultName: fsmRmtErrMgmtControllerUpdateUCSManagerCopyExtToLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
```

```

Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateUCSManager:copyExtToPeer

Fault Code: F77960

Message

[FSM:STAGE:REMOTE-ERROR]: copying image from external repository to local repository of peer(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:copyExtToPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-ext-to-peer-failed
mibFaultCode: 77960
mibFaultName: fsmRmtErrMgmtControllerUpdateUCSManagerCopyExtToPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateUCSManager:execute

Fault Code: F77960

Message

[FSM:STAGE:REMOTE-ERROR]: Updating firmware image(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 77960
mibFaultName: fsmRmtErrMgmtControllerUpdateUCSManagerExecute
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrMgmtControllerUpdateUCSManager:start

Fault Code: F77960

Message

[FSM:STAGE:REMOTE-ERROR]: Scheduling firmware image update(FSM-STAGE:sam:dme:MgmtControllerUpdateUCSManager:start)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: start-failed
mibFaultCode: 77960
mibFaultName: fsmRmtErrMgmtControllerUpdateUCSManagerStart
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateSwitch:copyToLocal

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: copying image from external repository to local repository(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:copyToLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-to-local-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchCopyToLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none

```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateSwitch:copyToPeer

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: copying image from external repository to local repository of peer(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:copyToPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-to-peer-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchCopyToPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt

```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrMgmtControllerUpdateSwitch:resetLocal

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: rebooting local fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:resetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: reset-local-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchResetLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrMgmtControllerUpdateSwitch:resetRemote

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: rebooting remote fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:resetRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: reset-remote-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchResetRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateSwitch:updateLocal

Fault Code: F77961

Message

```
[FSM:STAGE:REMOTE-ERROR]: updating local fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:updateLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-local-failed
mibFaultCode: 77961

```

```

mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchUpdateLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateSwitch:updateRemote

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: updating peer fabric
interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:updateRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-remote-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchUpdateRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt

```

Affected MO: sys/mgmt
Affected MO: sys/rack-unit- [id] /adaptor- [id] /mgmt
Affected MO: sys/rack-unit- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /mgmt
Affected MO: sys/rack-unit- [id] /mgmt
Affected MO: sys/switch- [id] /mgmt

fsmRmtErrMgmtControllerUpdateSwitch:verifyLocal

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: verifying boot variables for local fabric interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:verifyLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: verify-local-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchVerifyLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /adaptor- [id] /mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /boardController/mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /boardController/mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /mgmt
Affected MO: sys/chassis- [id] /slot- [id] /mgmt
Affected MO: sys/chassis- [id] /sw-slot- [id] /mgmt
Affected MO: sys/fex- [id] /mgmt
Affected MO: sys/fex- [id] /slot- [id] /mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit- [id] /adaptor- [id] /mgmt
Affected MO: sys/rack-unit- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /mgmt
Affected MO: sys/rack-unit- [id] /mgmt
Affected MO: sys/switch- [id] /mgmt

fsmRmtErrMgmtControllerUpdateSwitch:verifyRemote

Fault Code: F77961

Message

[FSM:STAGE:REMOTE-ERROR]: verifying boot variables for remote fabric interconnect(FSM-STAGE:sam:dme:MgmtControllerUpdateSwitch:verifyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-remote-failed
mibFaultCode: 77961
mibFaultName: fsmRmtErrMgmtControllerUpdateSwitchVerifyRemote
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt
```

fsmRmtErrMgmtControllerUpdateIOM:CopyIOMImgToSub

Fault Code: F77962

Message

[FSM:STAGE:REMOTE-ERROR]: Copying IOM Image to subordinate FI(FSM-STAGE:sam:dme:MgmtControllerUpdateIOM:CopyIOMImgToSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copyiomimg-to-sub-failed
mibFaultCode: 77962
mibFaultName: fsmRmtErrMgmtControllerUpdateIOMCopyIOMImgToSub
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerUpdateIOM:CopyImgFromRep

Fault Code: F77962

Message

[FSM:STAGE:REMOTE-ERROR]: Copying IOM Image from repository to FI(FSM-STAGE:sam:dme:MgmtControllerUpdateIOM:CopyImgFromRep)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-img-from-rep-failed
mibFaultCode: 77962
mibFaultName: fsmRmtErrMgmtControllerUpdateIOMCopyImgFromRep
moClass: mgmt:Controller
Type: fsm
Callhome: none

```



```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrFirmwarePlatformPackPlatformVersion:Restore

Fault Code: F77963

Message

[FSM:STAGE:REMOTE-ERROR]: Check and Restore the Platform Version(FSM-STAGE:sam:dme:FirmwarePlatformPackPlatformVersion:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: restore-failed
mibFaultCode: 77963
mibFaultName: fsmRmtErrFirmwarePlatformPackPlatformVersionRestore
moClass: firmware:PlatformPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-platform-pack-[name]

```

fsmRmtErrFirmwarePlatformPackPlatformVersion:WaitForReady

Fault Code: F77963

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for system to be ready(FSM-STAGE:sam:dme:FirmwarePlatformPackPlatformVersion:WaitForReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-ready-failed
mibFaultCode: 77963
mibFaultName: fsmRmtErrFirmwarePlatformPackPlatformVersionWaitForReady
moClass: firmware:PlatformPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-platform-pack-[name]
```

fsmRmtErrFirmwareSystemDeploy:ActivateApplicationImage

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating
Application(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateApplicationImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-application-image-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployActivateApplicationImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:ActivateFirmwareImage

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating System Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateFirmwareImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-firmware-image-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployActivateFirmwareImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:ActivateManagerImage

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating Service Manager(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateManagerImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-manager-image-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployActivateManagerImage
moClass: firmware:System
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy:ActivateNpuImage

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating NPU Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateNpuImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: activate-npu-image-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployActivateNpuImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy:ActivateSystemImage

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating System Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ActivateSystemImage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: activate-system-image-failed
mibFaultCode: 77964

```

mibFaultName: fsmRmtErrFirmwareSystemDeployActivateSystemImage
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmRmtErrFirmwareSystemDeploy:CheckFirmwareUpgradeStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Check Firmware Upgrade Status(FSM-STAGE:sam:dme:FirmwareSystemDeploy:CheckFirmwareUpgradeStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: check-firmware-upgrade-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployCheckFirmwareUpgradeStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmRmtErrFirmwareSystemDeploy:CompleteFirmwareUpgrade

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Complete Firmware Pack Upgrade(FSM-STAGE:sam:dme:FirmwareSystemDeploy:CompleteFirmwareUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: complete-firmware-upgrade-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployCompleteFirmwareUpgrade
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy>DeleteCurrentApplication

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Delete Current Application(FSM-STAGE:sam:dme:FirmwareSystemDeploy>DeleteCurrentApplication)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-current-application-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployDeleteCurrentApplication
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy>PollApplicationActivationStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Application Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy>PollApplicationActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-application-activation-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollApplicationActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:PollDeleteCurrentApplicationStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for Current Application Deletion to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollDeleteCurrentApplicationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-delete-current-application-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollDeleteCurrentApplicationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:PollManagerActivationStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Service Manager Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollManagerActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-manager-activation-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollManagerActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:PollNpuActivationStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for NPU Image Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollNpuActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-npu-activation-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollNpuActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```


fsmRmtErrFirmwareSystemDeploy:PollStartupServiceManagerStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Setting Service Manager Startup Version to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollStartupServiceManagerStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-startup-service-manager-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollStartupServiceManagerStatus
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemDeploy:PollSystemActivationStatus

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for System Activation to complete(FSM-STAGE:sam:dme:FirmwareSystemDeploy:PollSystemActivationStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-system-activation-status-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployPollSystemActivationStatus
moClass: firmware:System
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy:RebootSystemForImageUpgrade

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Activating System Image(FSM-STAGE:sam:dme:FirmwareSystemDeploy:RebootSystemForImageUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: reboot-system-for-image-upgrade-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployRebootSystemForImageUpgrade
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy:SetStartupServiceManagerVersion

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Setting Service Manager Startup Version(FSM-STAGE:sam:dme:FirmwareSystemDeploy:SetStartupServiceManagerVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-startup-service-manager-version-failed
mibFaultCode: 77964

```

mibFaultName: fsmRmtErrFirmwareSystemDeploySetStartupServiceManagerVersion
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmRmtErrFirmwareSystemDeploy:ValidateApplicationPack

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Validating the application pack(FSM-STAGE:sam:dme:FirmwareSystemDeploy:ValidateApplicationPack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: validate-application-pack-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployValidateApplicationPack
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmRmtErrFirmwareSystemDeploy:WaitForDeploy

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Deploy to begin(FSM-STAGE:sam:dme:FirmwareSystemDeploy:WaitForDeploy)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-deploy-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployWaitForDeploy
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemDeploy:WaitForSystemReady

Fault Code: F77964

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for System Ready(FSM-STAGE:sam:dme:FirmwareSystemDeploy:WaitForSystemReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-system-ready-failed
mibFaultCode: 77964
mibFaultName: fsmRmtErrFirmwareSystemDeployWaitForSystemReady
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSupFirmwareDeploy:ActivateFirmwarePack

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Activating SUP Firmware(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:ActivateFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: activate-firmware-pack-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployActivateFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmRmtErrFirmwareSupFirmwareDeploy:CompleteFirmwareUpgrade

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Complete Firmware Pack Upgrade(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:CompleteFirmwareUpgrade)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: complete-firmware-upgrade-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployCompleteFirmwareUpgrade
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmRmtErrFirmwareSupFirmwareDeploy:DebundlePort

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Debundle the ports(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:DebundlePort)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: debundle-port-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployDebundlePort
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmRmtErrFirmwareSupFirmwareDeploy:PollActivateOfFirmwarePack

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Firmware Activation to complete(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:PollActivateOfFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-activate-of-firmware-pack-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployPollActivateOfFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmRmtErrFirmwareSupFirmwareDeploy:PollDebundlePort

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Ports debundle complete(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:PollDebundlePort)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: poll-debundle-port-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployPollDebundlePort
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware
```

fsmRmtErrFirmwareSupFirmwareDeploy:UpdateImageVersion

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Updating Image Version(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:UpdateImageVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-image-version-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployUpdateImageVersion
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmRmtErrFirmwareSupFirmwareDeploy:UpdatePackageVersion

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Updating Package
 Version(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:UpdatePackageVersion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-package-version-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployUpdatePackageVersion
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmRmtErrFirmwareSupFirmwareDeploy:ValidateFirmwarePack

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Validate the firmware
 pack(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:ValidateFirmwarePack)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-firmware-pack-failed
mibFaultCode: 77965


```

mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployValidateFirmwarePack
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

```

fsmRmtErrFirmwareSupFirmwareDeploy:WaitForDeploy

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Deploy to begin(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:WaitForDeploy)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-deploy-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployWaitForDeploy
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

```

fsmRmtErrFirmwareSupFirmwareDeploy:WaitForFirmwareVersionUpdate

Fault Code: F77965

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Firmware Version to update(FSM-STAGE:sam:dme:FirmwareSupFirmwareDeploy:WaitForFirmwareVersionUpdate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-firmware-version-update-failed
mibFaultCode: 77965
mibFaultName: fsmRmtErrFirmwareSupFirmwareDeployWaitForFirmwareVersionUpdate
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

fsmRmtErrFirmwareSystemApplyCatalogPack:ActivateCatalog

Fault Code: F77966

Message

[FSM:STAGE:REMOTE-ERROR]: Activating Catalog(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ActivateCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: activate-catalog-failed
mibFaultCode: 77966
mibFaultName: fsmRmtErrFirmwareSystemApplyCatalogPackActivateCatalog
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

fsmRmtErrFirmwareSystemApplyCatalogPack:ResolveDistributable

Fault Code: F77966

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve distributable from operations manager(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveDistributable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-failed
mibFaultCode: 77966
mibFaultName: fsmRmtErrFirmwareSystemApplyCatalogPackResolveDistributable
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemApplyCatalogPack:ResolveDistributableNames

Fault Code: F77966

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving distributable name(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveDistributableNames)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-distributable-names-failed
mibFaultCode: 77966
mibFaultName: fsmRmtErrFirmwareSystemApplyCatalogPackResolveDistributableNames
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrFirmwareSystemApplyCatalogPack:ResolveImages

Fault Code: F77966

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve images from operations manager(FSM-STAGE:sam:dme:FirmwareSystemApplyCatalogPack:ResolveImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-images-failed
mibFaultCode: 77966
mibFaultName: fsmRmtErrFirmwareSystemApplyCatalogPackResolveImages
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system
```

fsmRmtErrIdentIdentRequestUpdateIdent:Execute

Fault Code: F77968

Message

[FSM:STAGE:REMOTE-ERROR]: Update identities to external identifier manager(FSM-STAGE:sam:dme:IdentIdentRequestUpdateIdent:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 77968
mibFaultName: fsmRmtErrIdentIdentRequestUpdateIdentExecute
moClass: ident:IdentRequest
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys/IdentQ-[id]
```

fsmRmtErrIdentMetaSystemSync:Execute

Fault Code: F77969

Message

[FSM:STAGE:REMOTE-ERROR]: Synchronise ID universe to external identifier manager(FSM-STAGE:sam:dme:IdentMetaSystemSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 77969
mibFaultName: fsmRmtErrIdentMetaSystemSyncExecute
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys
```

fsmRmtErrIdentMetaSystemSync:Ping

Fault Code: F77969

Message

[FSM:STAGE:REMOTE-ERROR]: Check identifier manager availability(FSM-STAGE:sam:dme:IdentMetaSystemSync:Ping)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: ping-failed
mibFaultCode: 77969
mibFaultName: fsmRmtErrIdentMetaSystemSyncPing
moClass: ident:MetaSystem
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

fsmRmtErrIdentMetaSystemUcscUnivSync:Execute

Fault Code: F77970

Message

[FSM:STAGE:REMOTE-ERROR]: Synchronise ID universe to external identifier manager(FSM-STAGE:sam:dme:IdentMetaSystemUcscUnivSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 77970
mibFaultName: fsmRmtErrIdentMetaSystemUcscUnivSyncExecute
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

fsmRmtErrSmAppDelete:Local

Fault Code: F78025

Message

[FSM:STAGE:REMOTE-ERROR]: deleting the Application [name]-[version](FSM-STAGE:sam:dme:SmAppDelete:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 78025

```

mibFaultName: fsmRmtErrSmAppDeleteLocal
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app-[name]-[version]
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/app-[name]-[version]

```

fsmRmtErrSmSecSvcRestoreApplication:Restore

Fault Code: F78026

Message

[FSM:STAGE:REMOTE-ERROR]: Restoring Apps in progress(FSM-STAGE:sam:dme:SmSecSvcRestoreApplication:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: restore-failed
mibFaultCode: 78026
mibFaultName: fsmRmtErrSmSecSvcRestoreApplicationRestore
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

```

fsmRmtErrSmAppUpdateApplication:Update

Fault Code: F78027

Message

[FSM:STAGE:REMOTE-ERROR]: Updating Apps in progress(FSM-STAGE:sam:dme:SmAppUpdateApplication:Update)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-failed
mibFaultCode: 78027
mibFaultName: fsmRmtErrSmAppUpdateApplicationUpdate
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]

fsmRmtErrSmAppInstanceResetApplication:StartApps

Fault Code: F78028

Message

[FSM:STAGE:REMOTE-ERROR]: Start main and decorator applications(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StartApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: start-apps-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationStartApps
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot- [slotId] /app-inst- [appName]

fsmRmtErrSmAppInstanceResetApplication:StopDecoratorApps

Fault Code: F78028

Message

[FSM:STAGE:REMOTE-ERROR]: Stop decorator applications(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StopDecoratorApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-decorator-apps-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationStopDecoratorApps
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmRmtErrSmAppInstanceResetApplication:StopMainApp

Fault Code: F78028

Message

```
[FSM:STAGE:REMOTE-ERROR]: Stop main
application(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:StopMainApp)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-main-app-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationStopMainApp
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmRmtErrSmAppInstanceResetApplication:WairForStopDecorators

Fault Code: F78028

Message

```
[FSM:STAGE:REMOTE-ERROR]: Wait for stopping decorator applications to
complete(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WairForStopDecorators)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wair-for-stop-decorators-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationWairForStopDecorators
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmRmtErrSmAppInstanceResetApplication:WaitForBladeReboot

Fault Code: F78028

Message

```
[FSM:STAGE:REMOTE-ERROR]: Wait for blade
reboot(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WaitForBladeReboot)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-blade-reboot-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationWaitForBladeReboot
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmRmtErrSmAppInstanceResetApplication:WaitForStopMainApp

Fault Code: F78028

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for stopping main application to complete.(FSM-STAGE:sam:dme:SmAppInstanceResetApplication:WaitForStopMainApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-stop-main-app-failed
mibFaultCode: 78028
mibFaultName: fsmRmtErrSmAppInstanceResetApplicationWaitForStopMainApp
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmRmtErrSmSecSvcAutoDeployCSP:CreateLogicalDevice

Fault Code: F78029

Message

[FSM:STAGE:REMOTE-ERROR]: Creating a default logical device(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:CreateLogicalDevice)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: create-logical-device-failed
mibFaultCode: 78029
mibFaultName: fsmRmtErrSmSecSvcAutoDeployCSPCreateLogicalDevice
moClass: sm:SecSvc
Type: fsm
Callhome: none
```

Auto Cleared: true
 Is Implemented: true
 Affected MO: sec-svc

fsmRmtErrSmSecSvcAutoDeployCSP:WaitForChassisMoReady

Fault Code: F78029

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for chassis object ready(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForChassisMoReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-chassis-mo-ready-failed
mibFaultCode: 78029
mibFaultName: fsmRmtErrSmSecSvcAutoDeployCSPWaitForChassisMoReady
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

fsmRmtErrSmSecSvcAutoDeployCSP:WaitForPortReady

Fault Code: F78029

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for physical interfaces ready(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForPortReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-port-ready-failed
mibFaultCode: 78029

```

mibFaultName: fsmRmtErrSmSecSvcAutoDeployCSPWaitForPortReady
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc

```

fsmRmtErrSwAccessDomainDeploy:UpdateConnectivity

Fault Code: F78107

Message

[FSM:STAGE:REMOTE-ERROR]: internal network configuration on [switchId](FSM-STAGE:sam:dme:SwAccessDomainDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 78107
mibFaultName: fsmRmtErrSwAccessDomainDeployUpdateConnectivity
moClass: sw:AccessDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/access-eth

```

fsmRmtErrSwEthLanBorderDeploy:UpdateConnectivity

Fault Code: F78108

Message

[FSM:STAGE:REMOTE-ERROR]: Uplink eth port configuration on [switchId](FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 78108
mibFaultName: fsmRmtErrSwEthLanBorderDeployUpdateConnectivity
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth

fsmRmtErrSwEthLanBorderDeploy:UpdateSwitchConfigToAppAG**Fault Code:** F78108**Message**

[FSM:STAGE:REMOTE-ERROR]: Update switch config info to appAG(FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateSwitchConfigToAppAG)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-switch-config-to-appag-failed
mibFaultCode: 78108
mibFaultName: fsmRmtErrSwEthLanBorderDeployUpdateSwitchConfigToAppAG
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth

fsmRmtErrSwEthLanBorderDeploy:UpdateSwitchPortConfigToAppAG**Fault Code:** F78108**Message**

[FSM:STAGE:REMOTE-ERROR]: Update switch port config to appAG(FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateSwitchPortConfigToAppAG)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-switch-port-config-to-appag-failed
mibFaultCode: 78108
mibFaultName: fsmRmtErrSwEthLanBorderDeployUpdateSwitchPortConfigToAppAG
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmRmtErrSwEthLanBorderDeploy:UpdateVlanGroups

Fault Code: F78108

Message

[FSM:STAGE:REMOTE-ERROR]: VLAN group configuration on [switchId](FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateVlanGroups)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-vlan-groups-failed
mibFaultCode: 78108
mibFaultName: fsmRmtErrSwEthLanBorderDeployUpdateVlanGroups
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmRmtErrSwFcSanBorderDeploy:UpdateConnectivity

Fault Code: F78109

Message

[FSM:STAGE:REMOTE-ERROR]: Uplink fc port configuration on [switchId](FSM-STAGE:sam:dme:SwFcSanBorderDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 78109
mibFaultName: fsmRmtErrSwFcSanBorderDeployUpdateConnectivity
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc
```

fsmRmtErrSwUtilityDomainDeploy:UpdateConnectivity

Fault Code: F78110

Message

[FSM:STAGE:REMOTE-ERROR]: Utility network configuration on [switchId](FSM-STAGE:sam:dme:SwUtilityDomainDeploy:UpdateConnectivity)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-connectivity-failed
mibFaultCode: 78110
mibFaultName: fsmRmtErrSwUtilityDomainDeployUpdateConnectivity
moClass: sw:UtilityDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/utility-eth
```


fsmRmtErrSwPhysConfPhysical:ConfigSwA

Fault Code: F78116

Message

[FSM:STAGE:REMOTE-ERROR]: Configure physical port mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:ConfigSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-sw-afailed
mibFaultCode: 78116
mibFaultName: fsmRmtErrSwPhysConfPhysicalConfigSwA
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys
```

fsmRmtErrSwPhysConfPhysical:ConfigSwB

Fault Code: F78116

Message

[FSM:STAGE:REMOTE-ERROR]: Configure physical port mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:ConfigSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-sw-bfailed
mibFaultCode: 78116
mibFaultName: fsmRmtErrSwPhysConfPhysicalConfigSwB
moClass: sw:Phys
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

fsmRmtErrSwPhysConfPhysical:PortInventorySwA

Fault Code: F78116

Message

[FSM:STAGE:REMOTE-ERROR]: Performing local port inventory of switch [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:PortInventorySwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: port-inventory-sw-afailed
mibFaultCode: 78116
mibFaultName: fsmRmtErrSwPhysConfPhysicalPortInventorySwA
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

fsmRmtErrSwPhysConfPhysical:PortInventorySwB

Fault Code: F78116

Message

[FSM:STAGE:REMOTE-ERROR]: Performing peer port inventory of switch [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:PortInventorySwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: port-inventory-sw-bfailed
mibFaultCode: 78116

```

mibFaultName: fsmRmtErrSwPhysConfPhysicalPortInventorySwB
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

```

fsmRmtErrSwPhysConfPhysical:VerifyPhysConfig

Fault Code: F78116

Message

[FSM:STAGE:REMOTE-ERROR]: Verifying physical transition on fabric interconnect [id](FSM-STAGE:sam:dme:SwPhysConfPhysical:VerifyPhysConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: verify-phys-config-failed
mibFaultCode: 78116
mibFaultName: fsmRmtErrSwPhysConfPhysicalVerifyPhysConfig
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys

```

fsmRmtErrSwExtUtilityConfPortBreakout:ConfigSwA

Fault Code: F78121

Message

[FSM:STAGE:REMOTE-ERROR]: Configure port breakout mode mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:ConfigSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: config-sw-afailed
mibFaultCode: 78121
mibFaultName: fsmRmtErrSwExtUtilityConfPortBreakoutConfigSwA
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext

fsmRmtErrSwExtUtilityConfPortBreakout:ConfigSwB

Fault Code: F78121

Message

[FSM:STAGE:REMOTE-ERROR]: Configure port breakout mode on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:ConfigSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: config-sw-bfailed
mibFaultCode: 78121
mibFaultName: fsmRmtErrSwExtUtilityConfPortBreakoutConfigSwB
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext

fsmRmtErrSwExtUtilityConfPortBreakout:PortInventorySwA

Fault Code: F78121

Message

[FSM:STAGE:REMOTE-ERROR]: Performing local port inventory of switch [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:PortInventorySwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: port-inventory-sw-afailed
mibFaultCode: 78121
mibFaultName: fsmRmtErrSwExtUtilityConfPortBreakoutPortInventorySwA
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmRmtErrSwExtUtilityConfPortBreakout:PortInventorySwB

Fault Code: F78121

Message

[FSM:STAGE:REMOTE-ERROR]: Performing peer port inventory of switch [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:PortInventorySwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: port-inventory-sw-bfailed
mibFaultCode: 78121
mibFaultName: fsmRmtErrSwExtUtilityConfPortBreakoutPortInventorySwB
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmRmtErrSwExtUtilityConfPortBreakout:VerifyBreakoutConfig

Fault Code: F78121

Message

[FSM:STAGE:REMOTE-ERROR]: Verifying physical port breakout config on fabric interconnect [id](FSM-STAGE:sam:dme:SwExtUtilityConfPortBreakout:VerifyBreakoutConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-breakout-config-failed
mibFaultCode: 78121
mibFaultName: fsmRmtErrSwExtUtilityConfPortBreakoutVerifyBreakoutConfig
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmRmtErrSwFcSanBorderActivateZoneSet:UpdateZones

Fault Code: F78122

Message

```
[FSM:STAGE:REMOTE-ERROR]: fc zone configuration on
[switchId](FSM-STAGE:sam:dme:SwFcSanBorderActivateZoneSet:UpdateZones)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-zones-failed
mibFaultCode: 78122
mibFaultName: fsmRmtErrSwFcSanBorderActivateZoneSetUpdateZones
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc
```

fsmRmtErrCallhomeEpConfigCallhome:SetLocal

Fault Code: F78158

Message

[FSM:STAGE:REMOTE-ERROR]: call-home configuration on primary(FSM-STAGE:sam:dme:CallhomeEpConfigCallhome:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-local-failed
mibFaultCode: 78158
mibFaultName: fsmRmtErrCallhomeEpConfigCallhomeSetLocal
moClass: callhome:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: call-home
```

fsmRmtErrCallhomeEpConfigCallhome:SetPeer

Fault Code: F78158

Message

[FSM:STAGE:REMOTE-ERROR]: call-home configuration on secondary(FSM-STAGE:sam:dme:CallhomeEpConfigCallhome:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-peer-failed
mibFaultCode: 78158
mibFaultName: fsmRmtErrCallhomeEpConfigCallhomeSetPeer
moClass: callhome:Ep
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: call-home

fsmRmtErrAdaptorExtEthIfPathReset:Disable

Fault Code: F78167

Message

[FSM:STAGE:REMOTE-ERROR]: Disable path [side]([switchId]) on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorExtEthIfPathReset:Disable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: disable-failed
mibFaultCode: 78167
mibFaultName: fsmRmtErrAdaptorExtEthIfPathResetDisable
moClass: adaptor:ExtEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/ext-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/ext-eth- [id]

fsmRmtErrAdaptorExtEthIfPathReset:Enable

Fault Code: F78167

Message

[FSM:STAGE:REMOTE-ERROR]: Enabe path [side]([switchId]) on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorExtEthIfPathReset:Enable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: enable-failed


```

mibFaultCode: 78167
mibFaultName: fsmRmtErrAdaptorExtEthIfPathResetEnable
moClass: adaptor:ExtEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]

```

fsmRmtErrAdaptorHostEthIfCircuitReset:DisableA

Fault Code: F78170

Message

[FSM:STAGE:REMOTE-ERROR]: Disable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:DisableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: disable-afailed
mibFaultCode: 78170
mibFaultName: fsmRmtErrAdaptorHostEthIfCircuitResetDisableA
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fsmRmtErrAdaptorHostEthIfCircuitReset:DisableB

Fault Code: F78170

Message

[FSM:STAGE:REMOTE-ERROR]: Disable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:DisableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-bfailed
mibFaultCode: 78170
mibFaultName: fsmRmtErrAdaptorHostEthIfCircuitResetDisableB
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]
```

fsmRmtErrAdaptorHostEthIfCircuitReset:EnableA**Fault Code: F78170****Message**

```
[FSM:STAGE:REMOTE-ERROR]: Enable circuit A for host adaptor [id] on server
[chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:EnableA)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-afailed
mibFaultCode: 78170
mibFaultName: fsmRmtErrAdaptorHostEthIfCircuitResetEnableA
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]
```

fsmRmtErrAdaptorHostEthIfCircuitReset:EnableB

Fault Code: F78170

Message

[FSM:STAGE:REMOTE-ERROR]: Enable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostEthIfCircuitReset:EnableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-bfailed
mibFaultCode: 78170
mibFaultName: fsmRmtErrAdaptorHostEthIfCircuitResetEnableB
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]
```

fsmRmtErrAdaptorHostFcIfCircuitReset:DisableA

Fault Code: F78171

Message

[FSM:STAGE:REMOTE-ERROR]: Disable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:DisableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-afailed
mibFaultCode: 78171
mibFaultName: fsmRmtErrAdaptorHostFcIfCircuitResetDisableA
moClass: adaptor:HostFcIf
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]

```

fsmRmtErrAdaptorHostFcIfCircuitReset:DisableB

Fault Code: F78171

Message

[FSM:STAGE:REMOTE-ERROR]: Disable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:DisableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: disable-bfailed
mibFaultCode: 78171
mibFaultName: fsmRmtErrAdaptorHostFcIfCircuitResetDisableB
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-fc- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-fc- [id]

```

fsmRmtErrAdaptorHostFcIfCircuitReset:EnableA

Fault Code: F78171

Message

[FSM:STAGE:REMOTE-ERROR]: Enable circuit A for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:EnableA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: enable-afailed
mibFaultCode: 78171
mibFaultName: fsmRmtErrAdaptorHostFcIfCircuitResetEnableA
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]

```

fsmRmtErrAdaptorHostFcIfCircuitReset:EnableB**Fault Code: F78171****Message**

[FSM:STAGE:REMOTE-ERROR]: Enable circuit B for host adaptor [id] on server [chassisId]/[slotId](FSM-STAGE:sam:dme:AdaptorHostFcIfCircuitReset:EnableB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: enable-bfailed
mibFaultCode: 78171
mibFaultName: fsmRmtErrAdaptorHostFcIfCircuitResetEnableB
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]

```

fsmRmtErrLicenseDownloaderDownload:CopyRemote**Fault Code: F78188****Message**

[FSM:STAGE:REMOTE-ERROR]: Copy the license file to subordinate for inventory(FSM-STAGE:sam:dme:LicenseDownloaderDownload:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-remote-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadCopyRemote
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld- [fileName]
```

fsmRmtErrLicenseDownloaderDownload:DeleteLocal

Fault Code: F78188

Message

[FSM:STAGE:REMOTE-ERROR]: deleting temporary files for [fileName] on local(FSM-STAGE:sam:dme:LicenseDownloaderDownload:DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-local-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadDeleteLocal
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld- [fileName]
```

fsmRmtErrLicenseDownloaderDownload:DeleteRemote

Fault Code: F78188

Message

[FSM:STAGE:REMOTE-ERROR]: deleting temporary files for [fileName] on subordinate(FSM-STAGE:sam:dme:LicenseDownloaderDownload:DeleteRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-remote-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadDeleteRemote
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]
```

fsmRmtErrLicenseDownloaderDownload:Local**Fault Code: F78188****Message**

[FSM:STAGE:REMOTE-ERROR]: downloading license file [fileName] from [server](FSM-STAGE:sam:dme:LicenseDownloaderDownload:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadLocal
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]
```

fsmRmtErrLicenseDownloaderDownload:ValidateLocal

Fault Code: F78188

Message

[FSM:STAGE:REMOTE-ERROR]: validation for license file [fileName] on primary(FSM-STAGE:sam:dme:LicenseDownloaderDownload:ValidateLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-local-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadValidateLocal
moClass: license:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld- [fileName]
```

fsmRmtErrLicenseDownloaderDownload:ValidateRemote

Fault Code: F78188

Message

[FSM:STAGE:REMOTE-ERROR]: validation for license file [fileName] on subordinate(FSM-STAGE:sam:dme:LicenseDownloaderDownload:ValidateRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-remote-failed
mibFaultCode: 78188
mibFaultName: fsmRmtErrLicenseDownloaderDownloadValidateRemote
moClass: license:Downloader
Type: fsm
Callhome: none
```



```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld-[fileName]

```

fsmRmtErrLicenseFileInstall:Local

Fault Code: F78189

Message

[FSM:STAGE:REMOTE-ERROR]: Installing license on primary(FSM-STAGE:sam:dme:LicenseFileInstall:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78189
mibFaultName: fsmRmtErrLicenseFileInstallLocal
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]

```

fsmRmtErrLicenseFileInstall:Remote

Fault Code: F78189

Message

[FSM:STAGE:REMOTE-ERROR]: Installing license on subordinate(FSM-STAGE:sam:dme:LicenseFileInstall:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remote-failed
mibFaultCode: 78189

```

```

mibFaultName: fsmRmtErrLicenseFileInstallRemote
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]

```

fsmRmtErrLicenseFileClear:Local

Fault Code: F78190

Message

[FSM:STAGE:REMOTE-ERROR]: Clearing license on primary(FSM-STAGE:sam:dme:LicenseFileClear:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78190
mibFaultName: fsmRmtErrLicenseFileClearLocal
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]

```

fsmRmtErrLicenseFileClear:Remote

Fault Code: F78190

Message

[FSM:STAGE:REMOTE-ERROR]: Clearing license on subordinate(FSM-STAGE:sam:dme:LicenseFileClear:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: remote-failed
mibFaultCode: 78190
mibFaultName: fsmRmtErrLicenseFileClearRemote
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]

fsmRmtErrLicenseInstanceUpdateFlexlm:Local**Fault Code: F78191****Message**

[FSM:STAGE:REMOTE-ERROR]: Updating on primary(FSM-STAGE:sam:dme:LicenseInstanceUpdateFlexlm:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 78191
mibFaultName: fsmRmtErrLicenseInstanceUpdateFlexlmLocal
moClass: license:Instance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

fsmRmtErrLicenseInstanceUpdateFlexlm:Remote**Fault Code: F78191****Message**

[FSM:STAGE:REMOTE-ERROR]: Updating on subordinate(FSM-STAGE:sam:dme:LicenseInstanceUpdateFlexlm:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: remote-failed
mibFaultCode: 78191
mibFaultName: fsmRmtErrLicenseInstanceUpdateFlexlmRemote
moClass: license:Instance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fsmRmtErrLicenseSmartConfigSetConfig:Local

Fault Code: F78192

Message

```
[FSM:STAGE:REMOTE-ERROR]: Smart config
change(FSM-STAGE:sam:dme:LicenseSmartConfigSetConfig:Local)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78192
mibFaultName: fsmRmtErrLicenseSmartConfigSetConfigLocal
moClass: license:SmartConfig
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/license-config-[operation]
```

fsmRmtErrLsServerConfigure:AnalyzeImpact

Fault Code: F78210

Message

```
[FSM:STAGE:REMOTE-ERROR]: Analyzing changes
impact(FSM-STAGE:sam:dme:LsServerConfigure:AnalyzeImpact)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: analyze-impact-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureAnalyzeImpact
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:ApplyConfig**Fault Code: F78210****Message**

[FSM:STAGE:REMOTE-ERROR]: Applying config to server
[pnDn](FSM-STAGE:sam:dme:LsServerConfigure:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-config-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureApplyConfig
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:ApplyDefaultIdentifiers

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving and applying default identifiers locally(FSM-STAGE:sam:dme:LsServerConfigure:ApplyDefaultIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-default-identifiers-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureApplyDefaultIdentifiers
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:ApplyIdentifiers

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving and applying identifiers locally(FSM-STAGE:sam:dme:LsServerConfigure:ApplyIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-identifiers-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureApplyIdentifiers
moClass: ls:Server
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:ApplyPolicies

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving and applying policies(FSM-STAGE:sam:dme:LsServerConfigure:ApplyPolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-policies-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureApplyPolicies
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:ApplyTemplate

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Applying configuration template [srcTemplName](FSM-STAGE:sam:dme:LsServerConfigure:ApplyTemplate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-template-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureApplyTemplate
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:CommitStorage

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: committing storage for service profile(FSM-STAGE:sam:dme:LsServerConfigure:CommitStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: commit-storage-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureCommitStorage
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:EvaluateAssociation

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Evaluate association with server [pnDn](FSM-STAGE:sam:dme:LsServerConfigure:EvaluateAssociation)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: evaluate-association-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureEvaluateAssociation
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:ProvisionStorage**Fault Code: F78210****Message**

[FSM:STAGE:REMOTE-ERROR]: Resolving storage policy(FSM-STAGE:sam:dme:LsServerConfigure:ProvisionStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: provision-storage-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureProvisionStorage
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:ResolveBootConfig

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Computing binding changes(FSM-STAGE:sam:dme:LsServerConfigure:ResolveBootConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-boot-config-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveBootConfig
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:ResolveDefaultIdentifiers

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving default identifiers(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDefaultIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-default-identifiers-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveDefaultIdentifiers
moClass: ls:Server
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:ResolveDistributable

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve distributable from operations manager(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDistributable)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-distributable-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveDistributable
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:ResolveDistributableNames

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving distributable names from host pack(FSM-STAGE:sam:dme:LsServerConfigure:ResolveDistributableNames)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-distributable-names-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveDistributableNames
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:ResolveIdentifiers**Fault Code:** F78210**Message**

[FSM:STAGE:REMOTE-ERROR]: Resolving identifiers(FSM-STAGE:sam:dme:LsServerConfigure:ResolveIdentifiers)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-identifiers-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveIdentifiers
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:ResolveImages**Fault Code:** F78210**Message**

[FSM:STAGE:REMOTE-ERROR]: Resolve images from operations manager(FSM-STAGE:sam:dme:LsServerConfigure:ResolveImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-images-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveImages
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:ResolveNetworkPolicies**Fault Code: F78210****Message**

[FSM:STAGE:REMOTE-ERROR]: Resolving various dependent policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolveNetworkPolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-network-policies-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveNetworkPolicies
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:ResolveNetworkTemplates

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving various template policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolveNetworkTemplates)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-network-templates-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveNetworkTemplates
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:ResolvePolicies

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving various policies(FSM-STAGE:sam:dme:LsServerConfigure:ResolvePolicies)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-policies-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolvePolicies
moClass: ls:Server
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmRmtErrLsServerConfigure:ResolveSchedule

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Resolving schedule policy(FSM-STAGE:sam:dme:LsServerConfigure:ResolveSchedule)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-schedule-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureResolveSchedule
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmRmtErrLsServerConfigure:ValidatePolicyOwnership

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Validating policy integrity from ownership perspective(FSM-STAGE:sam:dme:LsServerConfigure:ValidatePolicyOwnership)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-policy-ownership-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureValidatePolicyOwnership
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:WaitForAssocCompletion

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for Association completion on server [pnDn](FSM-STAGE:sam:dme:LsServerConfigure:WaitForAssocCompletion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-assoc-completion-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureWaitForAssocCompletion
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrLsServerConfigure:WaitForCommitStorage

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for storage commit to complete(FSM-STAGE:sam:dme:LsServerConfigure:WaitForCommitStorage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-commit-storage-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureWaitForCommitStorage
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:WaitForMaintPermission**Fault Code: F78210****Message**

```
[FSM:STAGE:REMOTE-ERROR]: Waiting for ack or maint
window(FSM-STAGE:sam:dme:LsServerConfigure:WaitForMaintPermission)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-maint-permission-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureWaitForMaintPermission
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]
```

fsmRmtErrLsServerConfigure:WaitForMaintWindow

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting for maintenance window(FSM-STAGE:sam:dme:LsServerConfigure:WaitForMaintWindow)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-maint-window-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureWaitForMaintWindow
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]
```

fsmRmtErrLsServerConfigure:WaitForStorageProvision

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: waiting for storage provisioning to complete(FSM-STAGE:sam:dme:LsServerConfigure:WaitForStorageProvision)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-storage-provision-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureWaitForStorageProvision
moClass: ls:Server
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:checkAssignedDefaultIdentifiersForDup

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: checking assigned identifiers(from default pool) for dup(FSM-STAGE:sam:dme:LsServerConfigure:checkAssignedDefaultIdentifiersForDup)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: check-assigned-default-identifiers-for-dup-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureCheckAssignedDefaultIdentifiersForDup
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

```

fsmRmtErrLsServerConfigure:checkAssignedIdentifiersForDup

Fault Code: F78210

Message

[FSM:STAGE:REMOTE-ERROR]: checking assigned identifiers for dup(FSM-STAGE:sam:dme:LsServerConfigure:checkAssignedIdentifiersForDup)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: check-assigned-identifiers-for-dup-failed
mibFaultCode: 78210
mibFaultName: fsmRmtErrLsServerConfigureCheckAssignedIdentifiersForDup
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ls- [name]
Affected MO: org- [name] /tier- [name] /ls- [name]

fsmRmtErrComputeBladeDiag:CleanupServerConnSwA

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Cleaning up server [chassisId]/[slotId] interface on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:CleanupServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: cleanup-server-conn-sw-afailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagCleanupServerConnSwA
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId]

fsmRmtErrComputeBladeDiag:CleanupServerConnSwB

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Cleaning up server [chassisId]/[slotId] interface on fabric B(FSM-STAGE:sam:dme:ComputeBladeDiag:CleanupServerConnSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: cleanup-server-conn-sw-bfailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagCleanupServerConnSwB
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:ConfigFeLocal

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Configuring primary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:ConfigFeLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-fe-local-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagConfigFeLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:ConfigFePeer

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Configuring secondary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:ConfigFePeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-fe-peer-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagConfigFePeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
```

fsmRmtErrComputeBladeDiag:DisableServerConnSwA**Fault Code: F78220****Message**

[FSM:STAGE:REMOTE-ERROR]: Disable server [chassisId]/[slotId] interface on fabric A after completion of network traffic tests on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:DisableServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-server-conn-sw-afailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagDisableServerConnSwA
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
```

fsmRmtErrComputeBladeDiag:DisableServerConnSwB

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Disable server [chassisId]/[slotId] connectivity on fabric B in preparation for network traffic tests on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:DisableServerConnSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: disable-server-conn-sw-bfailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagDisableServerConnSwB
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:EnableServerConnSwA

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Enable server [chassisId]/[slotId] connectivity on fabric A in preparation for network traffic tests on fabric A(FSM-STAGE:sam:dme:ComputeBladeDiag:EnableServerConnSwA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: enable-server-conn-sw-afailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagEnableServerConnSwA
moClass: compute:Blade
```

```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]

```

fsmRmtErrComputeBladeDiag:EnableServerConnSwB

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Enable server [chassisId]/[slotId] connectivity on fabric B in preparation for network traffic tests on fabric B(FSM-STAGE:sam:dme:ComputeBladeDiag:EnableServerConnSwB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: enable-server-conn-sw-bfailed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagEnableServerConnSwB
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]

```

fsmRmtErrComputeBladeDiag:EvaluateStatus

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Evaluating status; diagnostics completed(FSM-STAGE:sam:dme:ComputeBladeDiag:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagEvaluateStatus
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmRmtErrComputeBladeDiag:RemoveConfig**Fault Code:** F78220**Message**

[FSM:STAGE:REMOTE-ERROR]: Derive diag config for server
 [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RemoveConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: remove-config-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagRemoveConfig
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmRmtErrComputeBladeDiag:RestoreConfigFeLocal**Fault Code:** F78220**Message**

[FSM:STAGE:REMOTE-ERROR]: Reconfiguring primary fabric interconnect access to server
 [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RestoreConfigFeLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: restore-config-fe-local-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagRestoreConfigFeLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:RestoreConfigFePeer

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Reconfiguring secondary fabric interconnect access to server [chassisId]/[slotId](FSM-STAGE:sam:dme:ComputeBladeDiag:RestoreConfigFePeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: restore-config-fe-peer-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagRestoreConfigFePeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:SwConfigLocal

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Configure primary fabric interconnect in server [chassisId]/[slotId] for diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagSwConfigLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:SwConfigPeer

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Configure secondary fabric interconnect in server [chassisId]/[slotId] for diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagSwConfigPeer
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

fsmRmtErrComputeBladeDiag:SwUnconfigLocal

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure primary fabric interconnect for server [chassisId]/[slotId] in diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwUnconfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-unconfig-local-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagSwUnconfigLocal
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmRmtErrComputeBladeDiag:SwUnconfigPeer

Fault Code: F78220

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure secondary fabric interconnect for server [chassisId]/[slotId] in diagnostics environment(FSM-STAGE:sam:dme:ComputeBladeDiag:SwUnconfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-unconfig-peer-failed
mibFaultCode: 78220
mibFaultName: fsmRmtErrComputeBladeDiagSwUnconfigPeer
moClass: compute:Blade

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]

fsmRmtErrMgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgLocal

Fault Code: F78243

Message

[FSM:STAGE:REMOTE-ERROR]: in-band vlan configuration on Local CIMC(FSM-STAGE:sam:dme:MgmtControllerExtMgmtInterfaceConfig:CIMCVlanCfgLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: cimcvlan-cfg-local-failed
mibFaultCode: 78243
mibFaultName: fsmRmtErrMgmtControllerExtMgmtInterfaceConfigCIMCVlanCfgLocal
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrMgmtControllerExtMgmtInterfaceConfig: CIMCVlanCfgPeer

Fault Code: F78243

Message

[FSM:STAGE:REMOTE-ERROR]: in-band vlan configuration on Peer
CIMC(FSM-STAGE:sam:dme:MgmtControllerExtMgmtInterfaceConfig: CIMCVlanCfgPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: cimcvlan-cfg-peer-failed
mibFaultCode: 78243
mibFaultName: fsmRmtErrMgmtControllerExtMgmtInterfaceConfigCIMCVlanCfgPeer
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrComputePhysicalSwConnUpd:A

Fault Code: F78244

Message

[FSM:STAGE:REMOTE-ERROR]: Updating fabric A for server
[dn](FSM-STAGE:sam:dme:ComputePhysicalSwConnUpd:A)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: a-failed
mibFaultCode: 78244
mibFaultName: fsmRmtErrComputePhysicalSwConnUpdA
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fsmRmtErrComputePhysicalSwConnUpd:B**Fault Code: F78244****Message**

```
[FSM:STAGE:REMOTE-ERROR]: Updating fabric B for server
[dn](FSM-STAGE:sam:dme:ComputePhysicalSwConnUpd:B)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: b-failed
mibFaultCode: 78244
mibFaultName: fsmRmtErrComputePhysicalSwConnUpdB
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]
```

fsmRmtErrEquipmentIOCardResetIom:Execute

Fault Code: F78245

Message

[FSM:STAGE:REMOTE-ERROR]: Reset IOM [id] on Fex
[chassisId](FSM-STAGE:sam:dme:EquipmentIOCardResetIom:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 78245
mibFaultName: fsmRmtErrEquipmentIOCardResetIomExecute
moClass: equipment:IOCard
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmRmtErrComputePhysicalServiceInfraDeploy:SwConfigLocal

Fault Code: F78246

Message

[FSM:STAGE:REMOTE-ERROR]: Configure service infrastructure on primary fabric
Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraDeploy:SwConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 78246
mibFaultName: fsmRmtErrComputePhysicalServiceInfraDeploySwConfigLocal
moClass: compute:Physical
Type: fsm


```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fsmRmtErrComputePhysicalServiceInfraDeploy:SwConfigPeer

Fault Code: F78246

Message

[FSM:STAGE:REMOTE-ERROR]: Configure service infrastructure on secondary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraDeploy:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 78246
mibFaultName: fsmRmtErrComputePhysicalServiceInfraDeploySwConfigPeer
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

```

fsmRmtErrComputePhysicalServiceInfraWithdraw:SwUnConfigLocal

Fault Code: F78247

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure service infrastructure on primary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraWithdraw:SwUnConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-un-config-local-failed
mibFaultCode: 78247
mibFaultName: fsmRmtErrComputePhysicalServiceInfraWithdrawSwUnConfigLocal
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]

fsmRmtErrComputePhysicalServiceInfraWithdraw:SwUnConfigPeer

Fault Code: F78247

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure service infrastructure on secondary fabric Interconnect(FSM-STAGE:sam:dme:ComputePhysicalServiceInfraWithdraw:SwUnConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: sw-un-config-peer-failed
mibFaultCode: 78247
mibFaultName: fsmRmtErrComputePhysicalServiceInfraWithdrawSwUnConfigPeer
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]

fsmRmtErrEquipmentIOCardBaseFePresence:CheckLicense

Fault Code: F78255

Message

[FSM:STAGE:REMOTE-ERROR]: Checking license for chassis [chassisId] (iom [id])(FSM-STAGE:sam:dme:EquipmentIOCardBaseFePresence:CheckLicense)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-license-failed
mibFaultCode: 78255
mibFaultName: fsmRmtErrEquipmentIOCardBaseFePresenceCheckLicense
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fsmRmtErrEquipmentIOCardBaseFePresence:Identify

Fault Code: F78255

Message

```
[FSM:STAGE:REMOTE-ERROR]: identifying IOM
[chassisId]/[id](FSM-STAGE:sam:dme:EquipmentIOCardBaseFePresence:Identify)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: identify-failed
mibFaultCode: 78255
mibFaultName: fsmRmtErrEquipmentIOCardBaseFePresenceIdentify
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fsmRmtErrEquipmentIOCardBaseFeConn:ConfigureSwMgmtEndPoint

Fault Code: F78256

Message

[FSM:STAGE:REMOTE-ERROR]: configuring fabric interconnect [switchId] mgmt connectivity to IOM
[chassisId]/[id]([side])(FSM-STAGE:sam:dme:EquipmentIOCardBaseFeConn:ConfigureSwMgmtEndPoint)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-sw-mgmt-end-point-failed
mibFaultCode: 78256
mibFaultName: fsmRmtErrEquipmentIOCardBaseFeConnConfigureSwMgmtEndPoint
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmRmtErrEquipmentIOCardBaseFeConn:ConfigureVifNs

Fault Code: F78256

Message

[FSM:STAGE:REMOTE-ERROR]: configuring IOM [chassisId]/[id]([side]) virtual name space(FSM-STAGE:sam:dme:EquipmentIOCardBaseFeConn:ConfigureVifNs)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-vif-ns-failed
mibFaultCode: 78256

```

mibFaultName: fsmRmtErrEquipmentIOCardBaseFeConnConfigureVifNs
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fsmRmtErrEquipmentChassisRemoveChassis:DisableEndPoint

Fault Code: F78257

Message

[FSM:STAGE:REMOTE-ERROR]: unconfiguring access to chassis
[id](FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:DisableEndPoint)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: disable-end-point-failed
mibFaultCode: 78257
mibFaultName: fsmRmtErrEquipmentChassisRemoveChassisDisableEndPoint
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmRmtErrEquipmentChassisRemoveChassis:UnIdentifyLocal

Fault Code: F78257

Message

[FSM:STAGE:REMOTE-ERROR]: erasing chassis identity [id] from
primary(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:UnIdentifyLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: un-identify-local-failed
mibFaultCode: 78257
mibFaultName: fsmRmtErrEquipmentChassisRemoveChassisUnIdentifyLocal
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmRmtErrEquipmentChassisRemoveChassis:UnIdentifyPeer

Fault Code: F78257

Message

[FSM:STAGE:REMOTE-ERROR]: erasing chassis identity [id] from secondary(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:UnIdentifyPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: un-identify-peer-failed
mibFaultCode: 78257
mibFaultName: fsmRmtErrEquipmentChassisRemoveChassisUnIdentifyPeer
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmRmtErrEquipmentChassisRemoveChassis:Wait

Fault Code: F78257

Message

[FSM:STAGE:REMOTE-ERROR]: waiting for clean up of resources for chassis [id] (approx. 2 min)(FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:Wait)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-failed
mibFaultCode: 78257
mibFaultName: fsmRmtErrEquipmentChassisRemoveChassisWait
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmRmtErrEquipmentChassisRemoveChassis:decomission**Fault Code: F78257****Message**

```
[FSM:STAGE:REMOTE-ERROR]: decomissioning chassis
[id](FSM-STAGE:sam:dme:EquipmentChassisRemoveChassis:decomission)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: decomission-failed
mibFaultCode: 78257
mibFaultName: fsmRmtErrEquipmentChassisRemoveChassisDecomission
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmRmtErrEquipmentLocatorLedSetFeLocatorLed:Execute

Fault Code: F78258

Message

[FSM:STAGE:REMOTE-ERROR]: setting locator led to
[adminState](FSM-STAGE:sam:dme:EquipmentLocatorLedSetFeLocatorLed:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 78258
mibFaultName: fsmRmtErrEquipmentLocatorLedSetFeLocatorLedExecute
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led

fsmRmtErrEquipmentLocatorLedSetFiLocatorLed:Execute

Fault Code: F78259

Message

[FSM:STAGE:REMOTE-ERROR]: setting FI locator led to
[adminState](FSM-STAGE:sam:dme:EquipmentLocatorLedSetFiLocatorLed:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 78259
mibFaultName: fsmRmtErrEquipmentLocatorLedSetFiLocatorLedExecute
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led
```

fsmRmtErrPortPIoInCompatSfpPresence:Shutdown

Fault Code: F78262

Message

```
[FSM:STAGE:REMOTE-ERROR]: Shutting down
port(FSM-STAGE:sam:dme:PortPIoInCompatSfpPresence:Shutdown)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: shutdown-failed
mibFaultCode: 78262
mibFaultName: fsmRmtErrPortPIoInCompatSfpPresenceShutdown
moClass: port:PIo
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

```

fsmRmtErrPortPloInCompatSfpReplaced:EnablePort

Fault Code: F78263

Message

[FSM:STAGE:REMOTE-ERROR]: Enabling
port(FSM-STAGE:sam:dme:PortPloInCompatSfpReplaced:EnablePort)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: enable-port-failed
mibFaultCode: 78263
mibFaultName: fsmRmtErrPortPloInCompatSfpReplacedEnablePort
moClass: port:PIO
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

```

fsmRmtErrObserveObservedResolvePolicyFsm:Execute

Fault Code: F78503

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve Policy FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolvePolicyFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 78503
mibFaultName: fsmRmtErrObserveObservedResolvePolicyFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/controllers/contro- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/providers/prov- [type] /observed- [dataSrcSysId] - [id]
Affected MO: observe/observed- [dataSrcSysId] - [id]
```

fsmRmtErrObserveObservedResolveResourceFsm:Execute

Fault Code: F78504

Message

```
[FSM:STAGE:REMOTE-ERROR]: Resolve Resource FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolveResourceFsm:Execute)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 78504
mibFaultName: fsmRmtErrObserveObservedResolveResourceFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/controllers/contro- [id] /observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/observed- [dataSrcSysId] - [id]
Affected MO: extpol/reg/providers/prov- [type] /observed- [dataSrcSysId] - [id]
Affected MO: observe/observed- [dataSrcSysId] - [id]
```

fsmRmtErrObserveObservedResolveVMFsm:Execute

Fault Code: F78505

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve VM FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolveVMFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 78505
mibFaultName: fsmRmtErrObserveObservedResolveVMFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

fsmRmtErrObserveObservedResolveControllerFsm:Execute

Fault Code: F78506

Message

[FSM:STAGE:REMOTE-ERROR]: Resolve Mgmt Controller FSM
Execute(FSM-STAGE:sam:dme:ObserveObservedResolveControllerFsm:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-failed
mibFaultCode: 78506

```

mibFaultName: fsmRmtErrObserveObservedResolveControllerFsmExecute
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmRmtErrEquipmentBeaconLedIlluminate:ExecuteA

Fault Code: F78589

Message

[FSM:STAGE:REMOTE-ERROR]: Turn beacon lights on/off for [dn] on fabric interconnect [id](FSM-STAGE:sam:dme:EquipmentBeaconLedIlluminate:ExecuteA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-afailed
mibFaultCode: 78589
mibFaultName: fsmRmtErrEquipmentBeaconLedIlluminateExecuteA
moClass: equipment:BeaconLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/beacon
Affected MO: sys/chassis-[id]/blade-[slotId]/beacon
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/chassis-[id]/psu-[id]/beacon
Affected MO: sys/chassis-[id]/slot-[id]/beacon
Affected MO: sys/fex-[id]/beacon
Affected MO: sys/fex-[id]/psu-[id]/beacon
Affected MO: sys/fex-[id]/slot-[id]/beacon
Affected MO: sys/rack-unit-[id]/beacon
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/rack-unit-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/switch-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/slot-[id]/beacon

```

fsmRmtErrEquipmentBeaconLedIlluminate:ExecuteB

Fault Code: F78589

Message

[FSM:STAGE:REMOTE-ERROR]: Turn beacon lights on/off for [dn] on fabric interconnect [id](FSM-STAGE:sam:dme:EquipmentBeaconLedIlluminate:ExecuteB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: execute-bfailed
mibFaultCode: 78589
mibFaultName: fsmRmtErrEquipmentBeaconLedIlluminateExecuteB
moClass: equipment:BeaconLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/beacon
Affected MO: sys/chassis-[id]/blade-[slotId]/beacon
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/chassis-[id]/psu-[id]/beacon
Affected MO: sys/chassis-[id]/slot-[id]/beacon
Affected MO: sys/fex-[id]/beacon
Affected MO: sys/fex-[id]/psu-[id]/beacon
Affected MO: sys/fex-[id]/slot-[id]/beacon
Affected MO: sys/rack-unit-[id]/beacon
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/rack-unit-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/switch-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/slot-[id]/beacon

fsmRmtErrSdAppInstanceInstallApplication:SendCommand

Fault Code: F78591

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to install application(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-command-failed
mibFaultCode: 78591
mibFaultName: fsmRmtErrSdAppInstanceInstallApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceInstallApplication:UpdateAppInstance

Fault Code: F78591

Message

[FSM:STAGE:REMOTE-ERROR]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 78591
mibFaultName: fsmRmtErrSdAppInstanceInstallApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceInstallApplication:WaitStage

Fault Code: F78591

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for confirmation from SMA that the application is installed(FSM-STAGE:sam:dme:SdAppInstanceInstallApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 78591
mibFaultName: fsmRmtErrSdAppInstanceInstallApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmRmtErrSdAppInstanceStartApplication:SendCommand

Fault Code: F78592

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to start application(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-command-failed
mibFaultCode: 78592
mibFaultName: fsmRmtErrSdAppInstanceStartApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```


fsmRmtErrSdAppInstanceStartApplication:UpdateAppInstance

Fault Code: F78592

Message

[FSM:STAGE:REMOTE-ERROR]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 78592
mibFaultName: fsmRmtErrSdAppInstanceStartApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceStartApplication:WaitStage

Fault Code: F78592

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for confirmation from SMA that the application has started(FSM-STAGE:sam:dme:SdAppInstanceStartApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 78592
mibFaultName: fsmRmtErrSdAppInstanceStartApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmRmtErrSdLduProvisionLDU:CheckBladeReadiness

Fault Code: F78593

Message

[FSM:STAGE:REMOTE-ERROR]: Check if the blade is available to provision logical device.(FSM-STAGE:sam:dme:SdLduProvisionLDU:CheckBladeReadiness)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: check-blade-readiness-failed
mibFaultCode: 78593
mibFaultName: fsmRmtErrSdLduProvisionLDUCheckBladeReadiness
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]

fsmRmtErrSdLduProvisionLDU:StartApps

Fault Code: F78593

Message

[FSM:STAGE:REMOTE-ERROR]: Start the Apps(FSM-STAGE:sam:dme:SdLduProvisionLDU:StartApps)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: start-apps-failed

```

mibFaultCode: 78593
mibFaultName: fsmRmtErrSdLduProvisionLDUStartApps
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]

```

fsmRmtErrSdLduProvisionLDU:WaitForAppsInstallation

Fault Code: F78593

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for all the apps in the LDU to get installed.(FSM-STAGE:sam:dme:SdLduProvisionLDU:WaitForAppsInstallation)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-apps-installation-failed
mibFaultCode: 78593
mibFaultName: fsmRmtErrSdLduProvisionLDUWaitForAppsInstallation
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]

```

fsmRmtErrSdLduProvisionLDU:WaitForLinkConfiguration

Fault Code: F78593

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for CCL and MGMT Links configuration(FSM-STAGE:sam:dme:SdLduProvisionLDU:WaitForLinkConfiguration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-link-configuration-failed
mibFaultCode: 78593
mibFaultName: fsmRmtErrSdLduProvisionLDUWaitForLinkConfiguration
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]

fsmRmtErrSdAppInstanceUpgradeApplication:SendCommand

Fault Code: F78594

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to upgrade application(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 78594
mibFaultName: fsmRmtErrSdAppInstanceUpgradeApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmRmtErrSdAppInstanceUpgradeApplication:UpdateAppInstance

Fault Code: F78594

Message

[FSM:STAGE:REMOTE-ERROR]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 78594
mibFaultName: fsmRmtErrSdAppInstanceUpgradeApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmRmtErrSdAppInstanceUpgradeApplication:WaitStage

Fault Code: F78594

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for confirmation from SMA that the application is upgraded(FSM-STAGE:sam:dme:SdAppInstanceUpgradeApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-stage-failed
mibFaultCode: 78594
mibFaultName: fsmRmtErrSdAppInstanceUpgradeApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmRmtErrSdAppInstanceStopApplication:ReleaseAppLicense

Fault Code: F78595

Message

[FSM:STAGE:REMOTE-ERROR]: Release license of application instance(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:ReleaseAppLicense)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-app-license-failed
mibFaultCode: 78595
mibFaultName: fsmRmtErrSdAppInstanceStopApplicationReleaseAppLicense
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

fsmRmtErrSdAppInstanceStopApplication:SendCommand

Fault Code: F78595

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to stop application(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 78595
mibFaultName: fsmRmtErrSdAppInstanceStopApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmRmtErrSdAppInstanceStopApplication:UpdateAppInstance

Fault Code: F78595

Message

[FSM:STAGE:REMOTE-ERROR]: Updates the operational state of application instance(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:UpdateAppInstance)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-app-instance-failed
mibFaultCode: 78595
mibFaultName: fsmRmtErrSdAppInstanceStopApplicationUpdateAppInstance
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmRmtErrSdAppInstanceStopApplication:WaitStage

Fault Code: F78595

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for confirmation from SMA that the application has stopped(FSM-STAGE:sam:dme:SdAppInstanceStopApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-stage-failed
mibFaultCode: 78595

```

```

mibFaultName: fsmRmtErrSdAppInstanceStopApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmRmtErrSdAppInstanceUninstallApplication:ReleaseAppLicense

Fault Code: F78596

Message

[FSM:STAGE:REMOTE-ERROR]: Release license of application
instance(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:ReleaseAppLicense)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-app-license-failed
mibFaultCode: 78596
mibFaultName: fsmRmtErrSdAppInstanceUninstallApplicationReleaseAppLicense
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

```

fsmRmtErrSdAppInstanceUninstallApplication:SendCommand

Fault Code: F78596

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to uninstall
application(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-command-failed
mibFaultCode: 78596
mibFaultName: fsmRmtErrSdAppInstanceUninstallApplicationSendCommand
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmRmtErrSdAppInstanceUninstallApplication:WaitStage

Fault Code: F78596

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for confirmation from SMA that the application has been uninstalled.(FSM-STAGE:sam:dme:SdAppInstanceUninstallApplication:WaitStage)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-stage-failed
mibFaultCode: 78596
mibFaultName: fsmRmtErrSdAppInstanceUninstallApplicationWaitStage
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]

fsmRmtErrSdSlotChangePlatformLogLevel:SendCommand

Fault Code: F78597

Message

[FSM:STAGE:REMOTE-ERROR]: Send command to change the log level(FSM-STAGE:sam:dme:SdSlotChangePlatformLogLevel:SendCommand)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-command-failed
mibFaultCode: 78597
mibFaultName: fsmRmtErrSdSlotChangePlatformLogLevelSendCommand
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]
```

fsmRmtErrSdAppInstanceBundleDataPorts:ConfigureLinks

Fault Code: F78598

Message

```
[FSM:STAGE:REMOTE-ERROR]: Trigger ConfigureLinks
FSM(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:ConfigureLinks)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: configure-links-failed
mibFaultCode: 78598
mibFaultName: fsmRmtErrSdAppInstanceBundleDataPortsConfigureLinks
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceBundleDataPorts:SendBundleStatus

Fault Code: F78598

Message

```
[FSM:STAGE:REMOTE-ERROR]: Notify Application about Port Bundle
Status(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:SendBundleStatus)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-bundle-status-failed
mibFaultCode: 78598
mibFaultName: fsmRmtErrSdAppInstanceBundleDataPortsSendBundleStatus
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceBundleDataPorts:UpdateBundleStatus

Fault Code: F78598

Message

[FSM:STAGE:REMOTE-ERROR]: Update the bundle status(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:UpdateBundleStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: update-bundle-status-failed
mibFaultCode: 78598
mibFaultName: fsmRmtErrSdAppInstanceBundleDataPortsUpdateBundleStatus
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmRmtErrSdAppInstanceBundleDataPorts:WaitForConfigCompletion

Fault Code: F78598

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for links configuration completion(FSM-STAGE:sam:dme:SdAppInstanceBundleDataPorts:WaitForConfigCompletion)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-config-completion-failed
mibFaultCode: 78598
mibFaultName: fsmRmtErrSdAppInstanceBundleDataPortsWaitForConfigCompletion
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

fsmRmtErrSdLogicalDeviceConfigureLinks:ConfigureSwitch

Fault Code: F78599

Message

[FSM:STAGE:REMOTE-ERROR]: Invoke Port API to configure the switch(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:ConfigureSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: configure-switch-failed
mibFaultCode: 78599
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureLinksConfigureSwitch
moClass: sd:LogicalDevice
Type: fsm
Callhome: none

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

```

fsmRmtErrSdLogicalDeviceConfigureLinks:SendInterfaces

Fault Code: F78599

Message

[FSM:STAGE:REMOTE-ERROR]: Send Updated Interface Mapping(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:SendInterfaces)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-interfaces-failed
mibFaultCode: 78599
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureLinksSendInterfaces
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

```

fsmRmtErrSdLogicalDeviceConfigureLinks:UnconfigureLinks

Fault Code: F78599

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure Links in the LogicalDevice(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:UnconfigureLinks)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: unconfigure-links-failed
mibFaultCode: 78599

```

```

mibFaultName: fsmRmtErrSdLogicalDeviceConfigureLinksUnconfigureLinks
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

```

fsmRmtErrSdLogicalDeviceConfigureLinks:UnconfigureLogicalDevice

Fault Code: F78599

Message

[FSM:STAGE:REMOTE-ERROR]: Unconfigure logical device(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:UnconfigureLogicalDevice)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: unconfigure-logical-device-failed
mibFaultCode: 78599
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureLinksUnconfigureLogicalDevice
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

```

fsmRmtErrSdLogicalDeviceConfigureLinks:WaitForSwitchConfig

Fault Code: F78599

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for Switch configuration to complete(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureLinks:WaitForSwitchConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-switch-config-failed
mibFaultCode: 78599
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureLinksWaitForSwitchConfig
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmRmtErrSdLinkUpdateInterfaceStatus:SendStatus

Fault Code: F78600

Message

[FSM:STAGE:REMOTE-ERROR]: Send Interface Operational State(FSM-STAGE:sam:dme:SdLinkUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: send-status-failed
mibFaultCode: 78600
mibFaultName: fsmRmtErrSdLinkUpdateInterfaceStatusSendStatus
moClass: sd:Link
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 sys-secsvc/ld- [name]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]/ext-ldulink- [name] - [appInstId]
Affected MO:
 sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
Affected MO:
 sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]/ext-ldulink- [name] - [appInstId]

fsmRmtErrSdClusterBootstrapUpdateClusterConfiguration:SendConfig

Fault Code: F78601

Message

[FSM:STAGE:REMOTE-ERROR]: Send Updated Cluster Configuration(FSM-STAGE:sam:dme:SdClusterBootstrapUpdateClusterConfiguration:SendConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-config-failed
mibFaultCode: 78601
mibFaultName: fsmRmtErrSdClusterBootstrapUpdateClusterConfigurationSendConfig
moClass: sd:ClusterBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/cluster-bootstrap
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/cluster-bootstrap
```

fsmRmtErrSdSlotFormatDisk:CheckBladeReadiness

Fault Code: F78602

Message

[FSM:STAGE:REMOTE-ERROR]: Check blade readiness(FSM-STAGE:sam:dme:SdSlotFormatDisk:CheckBladeReadiness)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: check-blade-readiness-failed
mibFaultCode: 78602
mibFaultName: fsmRmtErrSdSlotFormatDiskCheckBladeReadiness
moClass: sd:Slot
Type: fsm
```



```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]

```

fsmRmtErrSdSlotFormatDisk:ResetBladePower

Fault Code: F78602

Message

```
[FSM:STAGE:REMOTE-ERROR]: Blade power
reset(FSM-STAGE:sam:dme:SdSlotFormatDisk:ResetBladePower)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: reset-blade-power-failed
mibFaultCode: 78602
mibFaultName: fsmRmtErrSdSlotFormatDiskResetBladePower
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]

```

fsmRmtErrSdSlotFormatDisk:StartDiskFormat

Fault Code: F78602

Message

```
[FSM:STAGE:REMOTE-ERROR]: Start formatting
disk(FSM-STAGE:sam:dme:SdSlotFormatDisk:StartDiskFormat)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: start-disk-format-failed

```

```

mibFaultCode: 78602
mibFaultName: fsmRmtErrSdSlotFormatDiskStartDiskFormat
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

```

fsmRmtErrSdSlotFormatDisk:WaitForDiskFormatComplete

Fault Code: F78602

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for disk format complete(FSM-STAGE:sam:dme:SdSlotFormatDisk:WaitForDiskFormatComplete)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-disk-format-complete-failed
mibFaultCode: 78602
mibFaultName: fsmRmtErrSdSlotFormatDiskWaitForDiskFormatComplete
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

```

fsmRmtErrSdSlotSynchTimeZone:UpdateTimeZone

Fault Code: F78603

Message

[FSM:STAGE:REMOTE-ERROR]: Update time zone(FSM-STAGE:sam:dme:SdSlotSynchTimeZone:UpdateTimeZone)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-time-zone-failed
mibFaultCode: 78603
mibFaultName: fsmRmtErrSdSlotSynchTimeZoneUpdateTimeZone
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]

fsmRmtErrSdAppAttributeCtrlGetAppAttributes:GetAttributes**Fault Code: F78604****Message**

[FSM:STAGE:REMOTE-ERROR]: Retrive application attributes(FSM-STAGE:sam:dme:SdAppAttributeCtrlGetAppAttributes:GetAttributes)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: get-attributes-failed
mibFaultCode: 78604
mibFaultName: fsmRmtErrSdAppAttributeCtrlGetAppAttributesGetAttributes
moClass: sd:AppAttributeCtrl
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/app-attribute-ctrl

fsmRmtErrSdMgmtInfoUpdateMgmtInfo:SendUpdate**Fault Code: F78605****Message**

[FSM:STAGE:REMOTE-ERROR]: Update management information(FSM-STAGE:sam:dme:SdMgmtInfoUpdateMgmtInfo:SendUpdate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-update-failed
mibFaultCode: 78605
mibFaultName: fsmRmtErrSdMgmtInfoUpdateMgmtInfoSendUpdate
moClass: sd:MgmtInfo
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/mgmt-info
```

fsmRmtErrSdNetMgmtBootstrapUpdateNetMgmtBootstrap:SendUpdate

Fault Code: F78606

Message

[FSM:STAGE:REMOTE-ERROR]: Send message to
AppAgent(FSM-STAGE:sam:dme:SdNetMgmtBootstrapUpdateNetMgmtBootstrap:SendUpdate)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: send-update-failed
mibFaultCode: 78606
mibFaultName: fsmRmtErrSdNetMgmtBootstrapUpdateNetMgmtBootstrapSendUpdate
moClass: sd:NetMgmtBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/net-mgmt-bootstrap
```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:StartApp

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Trigger FSM to start
application(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:StartApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: start-app-failed
mibFaultCode: 78607
mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppStartApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task
```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:StopApp

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Stop application before
upgrade(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:StopApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: stop-app-failed
mibFaultCode: 78607
mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppStopApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task
```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:UpgradeApp

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Trigger FSM to upgrade application(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:UpgradeApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: upgrade-app-failed
mibFaultCode: 78607
mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppUpgradeApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/upgrade-task
```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:WaitForBladeReboot

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for blade reboot(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForBladeReboot)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-blade-reboot-failed
mibFaultCode: 78607
mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppWaitForBladeReboot
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task

```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:WaitForStopApp

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for application stop to complete.(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForStopApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-stop-app-failed
mibFaultCode: 78607
mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppWaitForStopApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /upgrade-task

```

fsmRmtErrSdUpgradeTaskStopUpgradeStartApp:WaitForUpgradeApp

Fault Code: F78607

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for application upgrade to complete.(FSM-STAGE:sam:dme:SdUpgradeTaskStopUpgradeStartApp:WaitForUpgradeApp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-upgrade-app-failed
mibFaultCode: 78607

```

```

mibFaultName: fsmRmtErrSdUpgradeTaskStopUpgradeStartAppWaitForUpgradeApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/upgrade-task

```

fsmRmtErrEtherServerIntFloConfigSpeed:Configure

Fault Code: F78609

Message

[FSM:STAGE:REMOTE-ERROR]: Configure admin speed for
[dn](FSM-STAGE:sam:dme:EtherServerIntFioConfigSpeed:Configure)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: configure-failed
mibFaultCode: 78609
mibFaultName: fsmRmtErrEtherServerIntFioConfigSpeedConfigure
moClass: ether:ServerIntFio
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/diag/port- [portId]
Affected MO: sys/chassis- [id]/slot- [id]/ [type]/port- [portId]
Affected MO: sys/chassis- [id]/sw-slot- [id]/ [type]/port- [portId]
Affected MO: sys/fex- [id]/slot- [id]/ [type]/port- [portId]
Affected MO: sys/rack-unit- [id]/diag/port- [portId]
Affected MO: sys/switch- [id]/slot- [id]/ [type]/port- [portId]

```

fsmRmtErrEtherFtwPortPairConfigFtw:Configure

Fault Code: F78610

Message

[FSM:STAGE:REMOTE-ERROR]: Configure fail-to-wire for
[dn](FSM-STAGE:sam:dme:EtherFtwPortPairConfigFtw:Configure)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: configure-failed
mibFaultCode: 78610
mibFaultName: fsmRmtErrEtherFtwPortPairConfigFtwConfigure
moClass: ether:FtwPortPair
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/switch-[id]/fail-to-wire/ftw-port-[slotId] - [aggrPortId] - [portId] -port- [peerSlotId]
-[peerAggrPortId] - [peerPortId]
```

fsmRmtErrExtpolEpRegisterFsm:Execute**Fault Code: F78625****Message**

```
[FSM:STAGE:REMOTE-ERROR]: Register FSM
Execute(FSM-STAGE:sam:dme:ExtpolEpRegisterFsm:Execute)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 78625
mibFaultName: fsmRmtErrExtpolepRegisterFsmExecute
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol
```

fsmRmtErrExtpolRegistryCrossDomainConfig:SetLocal

Fault Code: F78626

Message

[FSM:STAGE:REMOTE-ERROR]: Configure cross-domain XML for FLEX client on local fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainConfig:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-local-failed
mibFaultCode: 78626
mibFaultName: fsmRmtErrExtpolRegistryCrossDomainConfigSetLocal
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg
```

fsmRmtErrExtpolRegistryCrossDomainConfig:SetPeer

Fault Code: F78626

Message

[FSM:STAGE:REMOTE-ERROR]: Configure cross-domain XML for FLEX client on peer fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainConfig:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-peer-failed
mibFaultCode: 78626
mibFaultName: fsmRmtErrExtpolRegistryCrossDomainConfigSetPeer
moClass: extpol:Registry
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmRmtErrExtpolRegistryCrossDomainDelete:SetLocal

Fault Code: F78627

Message

[FSM:STAGE:REMOTE-ERROR]: Remove cross-domain XML for FLEX client on local fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainDelete:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-local-failed
mibFaultCode: 78627
mibFaultName: fsmRmtErrExtpolRegistryCrossDomainDeleteSetLocal
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmRmtErrExtpolRegistryCrossDomainDelete:SetPeer

Fault Code: F78627

Message

[FSM:STAGE:REMOTE-ERROR]: Remove cross-domain XML for FLEX client on peer fabric-interconnect(FSM-STAGE:sam:dme:ExtpolRegistryCrossDomainDelete:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-peer-failed
mibFaultCode: 78627

```

```

mibFaultName: fsmRmtErrExtpolRegistryCrossDomainDeleteSetPeer
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmRmtErrStorageSystemSync:Execute

Fault Code: F78664

Message

[FSM:STAGE:REMOTE-ERROR]: Synchronise requestors with storage broker(FSM-STAGE:sam:dme:StorageSystemSync:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 78664
mibFaultName: fsmRmtErrStorageSystemSyncExecute
moClass: storage:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: storage-ep/system

```

fsmRmtErrSysfileMutationSingle:Execute

Fault Code: F78666

Message

[FSM:STAGE:REMOTE-ERROR]: [action] file [name](FSM-STAGE:sam:dme:SysfileMutationSingle:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: execute-failed
mibFaultCode: 78666
mibFaultName: fsmRmtErrSysfileMutationSingleExecute
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation

```

fsmRmtErrSysfileMutationGlobal:Local**Fault Code: F78667****Message**

[FSM:STAGE:REMOTE-ERROR]: remove files from local(FSM-STAGE:sam:dme:SysfileMutationGlobal:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78667
mibFaultName: fsmRmtErrSysfileMutationGlobalLocal
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation

```

fsmRmtErrSysfileMutationGlobal:Peer**Fault Code: F78667****Message**

[FSM:STAGE:REMOTE-ERROR]: remove files from peer(FSM-STAGE:sam:dme:SysfileMutationGlobal:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 78667
mibFaultName: fsmRmtErrSysfileMutationGlobalPeer
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation
```

fsmRmtErrApplicationDownloaderDownload:Local

Fault Code: F78671

Message

[FSM:STAGE:REMOTE-ERROR]: downloading image [fileName] from [server](FSM-STAGE:sam:dme:ApplicationDownloaderDownload:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78671
mibFaultName: fsmRmtErrApplicationDownloaderDownloadLocal
moClass: application:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/app-catalogue/dnld- [fileName]
```

fsmRmtErrApplicationDownloaderDownload:UnpackLocal

Fault Code: F78671

Message

[FSM:STAGE:REMOTE-ERROR]: unpacking image [fileName] on primary(FSM-STAGE:sam:dme:ApplicationDownloaderDownload:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 78671
mibFaultName: fsmRmtErrApplicationDownloaderDownloadUnpackLocal
moClass: application:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/app-catalogue/dnld- [fileName]
```

fsmRmtErrCommSvcEpUpdateSvcEp:PropogateEpSettings

Fault Code: F78672

Message

[FSM:STAGE:REMOTE-ERROR]: propogate updated settings (eg. timezone)(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpSettings)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: propogate-ep-settings-failed
mibFaultCode: 78672
mibFaultName: fsmRmtErrCommSvcEpUpdateSvcEpPropogateEpSettings
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmRmtErrCommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomLocal

Fault Code: F78672

Message

[FSM:STAGE:REMOTE-ERROR]: propogate updated timezone settings to FEXs and IOMs.(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: propogate-ep-time-zone-settings-to-fex-iom-local-failed
mibFaultCode: 78672
mibFaultName: fsmRmtErrCommSvcEpUpdateSvcEpPropogateEpTimeZoneSettingsToFexIomLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

fsmRmtErrCommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomPeer

Fault Code: F78672

Message

[FSM:STAGE:REMOTE-ERROR]: propogate updated timezone settings to FEXs and IOMs.(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:PropogateEpTimeZoneSettingsToFexIomPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: propogate-ep-time-zone-settings-to-fex-iom-peer-failed
mibFaultCode: 78672
mibFaultName: fsmRmtErrCommSvcEpUpdateSvcEpPropogateEpTimeZoneSettingsToFexIomPeer
moClass: comm:SvcEp


```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmRmtErrCommSvcEpUpdateSvcEp:SetEpLocal

Fault Code: F78672

Message

[FSM:STAGE:REMOTE-ERROR]: communication service [name] configuration to primary(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:SetEpLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-ep-local-failed
mibFaultCode: 78672
mibFaultName: fsmRmtErrCommSvcEpUpdateSvcEpSetEpLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmRmtErrCommSvcEpUpdateSvcEp:SetEpPeer

Fault Code: F78672

Message

[FSM:STAGE:REMOTE-ERROR]: communication service [name] configuration to secondary(FSM-STAGE:sam:dme:CommSvcEpUpdateSvcEp:SetEpPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning

```

```

Cause: set-ep-peer-failed
mibFaultCode: 78672
mibFaultName: fsmRmtErrCommSvcEpUpdateSvcEpSetEpPeer
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmRmtErrCommSvcEpRestartWebSvc:local

Fault Code: F78673

Message

[FSM:STAGE:REMOTE-ERROR]: restart web services in primary(FSM-STAGE:sam:dme:CommSvcEpRestartWebSvc:local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78673
mibFaultName: fsmRmtErrCommSvcEpRestartWebSvcLocal
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext

```

fsmRmtErrCommSvcEpRestartWebSvc:peer

Fault Code: F78673

Message

[FSM:STAGE:REMOTE-ERROR]: restart web services in secondary(FSM-STAGE:sam:dme:CommSvcEpRestartWebSvc:peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 78673
mibFaultName: fsmRmtErrCommSvcEpRestartWebSvcPeer
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmRmtErrPkiEpUpdateEp:PostSetKeyRingLocal

Fault Code: F78691

Message

[FSM:STAGE:REMOTE-ERROR]: post processing after keyring configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: post-set-key-ring-local-failed
mibFaultCode: 78691
mibFaultName: fsmRmtErrPkiEpUpdateEpPostSetKeyRingLocal
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmRmtErrPkiEpUpdateEp:PostSetKeyRingPeer

Fault Code: F78691

Message

[FSM:STAGE:REMOTE-ERROR]: post processing after keyring configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:PostSetKeyRingPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: post-set-key-ring-peer-failed
mibFaultCode: 78691
mibFaultName: fsmRmtErrPkiEpUpdateEpPostSetKeyRingPeer
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmRmtErrPkiEpUpdateEp:SetKeyRingLocal

Fault Code: F78691

Message

[FSM:STAGE:REMOTE-ERROR]: keyring configuration on primary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-key-ring-local-failed
mibFaultCode: 78691
mibFaultName: fsmRmtErrPkiEpUpdateEpSetKeyRingLocal
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmRmtErrPkiEpUpdateEp:SetKeyRingPeer

Fault Code: F78691

Message

[FSM:STAGE:REMOTE-ERROR]: keyring configuration on secondary(FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-key-ring-peer-failed
mibFaultCode: 78691
mibFaultName: fsmRmtErrPkiEpUpdateEpSetKeyRingPeer
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmRmtErrPkiEpUpdateEp:ValidateKeyRingAndTP

Fault Code: F78691

Message

[FSM:STAGE:REMOTE-ERROR]: validate keyring and trust point(FSM-STAGE:sam:dme:PkiEpUpdateEp:ValidateKeyRingAndTP)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: validate-key-ring-andtp-failed
mibFaultCode: 78691
mibFaultName: fsmRmtErrPkiEpUpdateEpValidateKeyRingAndTP
moClass: pki:Ep
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext

fsmRmtErrAaaEpUpdateEp:SetEpLocal

Fault Code: F78692

Message

[FSM:STAGE:REMOTE-ERROR]: external aaa server configuration to primary(FSM-STAGE:sam:dme:AaaEpUpdateEp:SetEpLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: set-ep-local-failed
mibFaultCode: 78692
mibFaultName: fsmRmtErrAaaEpUpdateEpSetEpLocal
moClass: aaa:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext
Affected MO: sys/radius-ext
Affected MO: sys/tacacs-ext

fsmRmtErrAaaEpUpdateEp:SetEpPeer

Fault Code: F78692

Message

[FSM:STAGE:REMOTE-ERROR]: external aaa server configuration to secondary(FSM-STAGE:sam:dme:AaaEpUpdateEp:SetEpPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning

```

Cause: set-ep-peer-failed
mibFaultCode: 78692
mibFaultName: fsmRmtErrAaaEpUpdateEpSetEpPeer
moClass: aaa:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext
Affected MO: sys/radius-ext
Affected MO: sys/tacacs-ext

```

fsmRmtErrAaaRealmUpdateRealm:SetRealmLocal

Fault Code: F78693

Message

[FSM:STAGE:REMOTE-ERROR]: realm configuration to primary(FSM-STAGE:sam:dme:AaaRealmUpdateRealm:SetRealmLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: set-realm-local-failed
mibFaultCode: 78693
mibFaultName: fsmRmtErrAaaRealmUpdateRealmSetRealmLocal
moClass: aaa:Realm
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/auth-realm

```

fsmRmtErrAaaRealmUpdateRealm:SetRealmPeer

Fault Code: F78693

Message

[FSM:STAGE:REMOTE-ERROR]: realm configuration to secondary(FSM-STAGE:sam:dme:AaaRealmUpdateRealm:SetRealmPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-realm-peer-failed
mibFaultCode: 78693
mibFaultName: fsmRmtErrAaaRealmUpdateRealmSetRealmPeer
moClass: aaa:Realm
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/auth-realm
```

fsmRmtErrAaaUserEpUpdateUserEp:SetUserLocal

Fault Code: F78694

Message

[FSM:STAGE:REMOTE-ERROR]: user configuration to primary(FSM-STAGE:sam:dme:AaaUserEpUpdateUserEp:SetUserLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-user-local-failed
mibFaultCode: 78694
mibFaultName: fsmRmtErrAaaUserEpUpdateUserEpSetUserLocal
moClass: aaa:UserEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext
```

fsmRmtErrAaaUserEpUpdateUserEp:SetUserPeer

Fault Code: F78694

Message

[FSM:STAGE:REMOTE-ERROR]: user configuration to secondary(FSM-STAGE:sam:dme:AaaUserEpUpdateUserEp:SetUserPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-user-peer-failed
mibFaultCode: 78694
mibFaultName: fsmRmtErrAaaUserEpUpdateUserEpSetUserPeer
moClass: aaa:UserEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext
```

fsmRmtErrSysdebugManualCoreFileExportTargetExport:Execute

Fault Code: F78705

Message

[FSM:STAGE:REMOTE-ERROR]: export core file [name] to [hostname](FSM-STAGE:sam:dme:SysdebugManualCoreFileExportTargetExport:Execute)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: execute-failed
mibFaultCode: 78705
mibFaultName: fsmRmtErrSysdebugManualCoreFileExportTargetExportExecute
moClass: sysdebug:ManualCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/export-to- [hostname]
```

fsmRmtErrSysdebugLogExportPolicyConfigure:Local

Fault Code: F78706

Message

[FSM:STAGE:REMOTE-ERROR]: configuring log file export service on local(FSM-STAGE:sam:dme:SysdebugLogExportPolicyConfigure:Local)

Explanation

Cisco Firepower Manager could not set the configurations in the primary Fabric Interconnect for log file transfer to remote server.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78706
mibFaultName: fsmRmtErrSysdebugLogExportPolicyConfigureLocal
moClass: sysdebug:LogExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy
```

fsmRmtErrSysdebugLogExportPolicyConfigure:Peer

Fault Code: F78706

Message

[FSM:STAGE:REMOTE-ERROR]: configuring log file export service on peer(FSM-STAGE:sam:dme:SysdebugLogExportPolicyConfigure:Peer)

Explanation

Cisco Firepower Manager could not set the configurations in the subordinate Fabric Interconnect (FI) for log file transfer to remote server. This fault typically appears for one of the following reasons:

- The subordinate FI is not reachable.
- The subordinate FI is experiencing an internal system error on applying the configuration.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FI cluster state to ensure that the subordinate FI is reachable and functioning correctly. If the subordinate FI is down, take appropriate corrective actions so that the Firepower cluster goes into HA ready state.

- Step 2** If the HA state of the primary and subordinate FIs are good, execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 78706
mibFaultName: fsmRmtErrSysdebugLogExportPolicyConfigurePeer
moClass: sysdebug:LogExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy
```

fsmRmtErrSysdebugAutoCoreFileExportTargetConfigure:Local

Fault Code: F78707

Message

[FSM:STAGE:REMOTE-ERROR]: configuring automatic core file export service on local(FSM-STAGE:sam:dme:SysdebugAutoCoreFileExportTargetConfigure:Local)

Explanation

Cisco Firepower Manager could not set the configurations in the primary Fabric Interconnect for auto core transfer to remote TFTP server.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78707
mibFaultName: fsmRmtErrSysdebugAutoCoreFileExportTargetConfigureLocal
moClass: sysdebug:AutoCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fsmRmtErrSysdebugAutoCoreFileExportTargetConfigure:Peer

Fault Code: F78707

Message

[FSM:STAGE:REMOTE-ERROR]: configuring automatic core file export service on peer(FSM-STAGE:sam:dme:SysdebugAutoCoreFileExportTargetConfigure:Peer)

Explanation

Cisco Firepower Manager could not set the configurations in the subordinate Fabric Interconnect (FI) for auto core transfer to remote TFTP server. This fault typically appears for one of the following reasons:

- The subordinate FI is not reachable.
- The subordinate FI is experiencing an internal system error on applying the configuration.

Recommended Action

If you see this fault, take the following actions:

-
- Step 1** Check the FI cluster state to ensure that the subordinate FI is reachable and functioning correctly. If the subordinate FI is down, take appropriate corrective actions so that the Firepower cluster goes into HA ready state.
- Step 2** If the HA state of the primary and subordinate FIs are good, execute the show tech-support command and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: peer-failed
mibFaultCode: 78707
mibFaultName: fsmRmtErrSysdebugAutoCoreFileExportTargetConfigurePeer
moClass: sysdebug:AutoCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fsmRmtErrSysdebugTechSupportInitiate:Local

Fault Code: F78708

Message

```
[FSM:STAGE:REMOTE-ERROR]: create tech-support file from GUI on
local(FSM-STAGE:sam:dme:SysdebugTechSupportInitiate:Local)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78708
mibFaultName: fsmRmtErrSysdebugTechSupportInitiateLocal
moClass: sysdebug:TechSupport
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support- [creationTS]

```

fsmRmtErrSysdebugTechSupportDeleteTechSupFile:Local

Fault Code: F78709

Message

[FSM:STAGE:REMOTE-ERROR]: delete tech-support file from GUI on local(FSM-STAGE:sam:dme:SysdebugTechSupportDeleteTechSupFile:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78709
mibFaultName: fsmRmtErrSysdebugTechSupportDeleteTechSupFileLocal
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support- [creationTS]

```

fsmRmtErrSysdebugTechSupportDeleteTechSupFile:peer

Fault Code: F78709

Message

[FSM:STAGE:REMOTE-ERROR]: delete tech-support file from GUI on peer(FSM-STAGE:sam:dme:SysdebugTechSupportDeleteTechSupFile:peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed

```

```

mibFaultCode: 78709
mibFaultName: fsmRmtErrSysdebugTechSupportDeleteTechSupFilePeer
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmRmtErrSysdebugTechSupportDownload:CopyPrimary

Fault Code: F78710

Message

[FSM:STAGE:REMOTE-ERROR]: Copy the tech-support file to primary for download(FSM-STAGE:sam:dme:SysdebugTechSupportDownload:CopyPrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-primary-failed
mibFaultCode: 78710
mibFaultName: fsmRmtErrSysdebugTechSupportDownloadCopyPrimary
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

```

fsmRmtErrSysdebugTechSupportDownload:CopySub

Fault Code: F78710

Message

[FSM:STAGE:REMOTE-ERROR]: copy tech-support file on subordinate switch to tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload:CopySub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-sub-failed
mibFaultCode: 78710
mibFaultName: fsmRmtErrSysdebugTechSupportDownloadCopySub
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

fsmRmtErrSysdebugTechSupportDownload>DeletePrimary**Fault Code: F78710****Message**

[FSM:STAGE:REMOTE-ERROR]: Delete the tech-support file from primary switch under tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload>DeletePrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-primary-failed
mibFaultCode: 78710
mibFaultName: fsmRmtErrSysdebugTechSupportDownload>DeletePrimary
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]

fsmRmtErrSysdebugTechSupportDownload>DeleteSub**Fault Code: F78710****Message**

[FSM:STAGE:REMOTE-ERROR]: Delete the tech-support file from subordinate under tmp directory(FSM-STAGE:sam:dme:SysdebugTechSupportDownload>DeleteSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-sub-failed
mibFaultCode: 78710
mibFaultName: fsmRmtErrSysdebugTechSupportDownloadDeleteSub
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]
```

fsmRmtErrSysdebugCoreDownload:CopyPrimary

Fault Code: F78711

Message

[FSM:STAGE:REMOTE-ERROR]: Copy the Core file to primary for download(FSM-STAGE:sam:dme:SysdebugCoreDownload:CopyPrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-primary-failed
mibFaultCode: 78711
mibFaultName: fsmRmtErrSysdebugCoreDownloadCopyPrimary
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file-[name] | [switchId]
```

fsmRmtErrSysdebugCoreDownload:CopySub

Fault Code: F78711

Message

[FSM:STAGE:REMOTE-ERROR]: copy Core file on subordinate switch to tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload:CopySub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-sub-failed
mibFaultCode: 78711
mibFaultName: fsmRmtErrSysdebugCoreDownloadCopySub
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmRmtErrSysdebugCoreDownload>DeletePrimary**Fault Code: F78711****Message**

[FSM:STAGE:REMOTE-ERROR]: Delete the Core file from primary switch under tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload>DeletePrimary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-primary-failed
mibFaultCode: 78711
mibFaultName: fsmRmtErrSysdebugCoreDownloadDeletePrimary
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmRmtErrSysdebugCoreDownload>DeleteSub

Fault Code: F78711

Message

[FSM:STAGE:REMOTE-ERROR]: Delete the Core file from subordinate under tmp directory(FSM-STAGE:sam:dme:SysdebugCoreDownload>DeleteSub)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: delete-sub-failed
mibFaultCode: 78711
mibFaultName: fsmRmtErrSysdebugCoreDownload>DeleteSub
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmRmtErrSysdebugLogControlEpLogControlPersist:Local

Fault Code: F78712

Message

[FSM:STAGE:REMOTE-ERROR]: persisting LogControl on local(FSM-STAGE:sam:dme:SysdebugLogControlEpLogControlPersist:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78712
mibFaultName: fsmRmtErrSysdebugLogControlEpLogControlPersistLocal
moClass: sysdebug:LogControlEp
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/logcontrol

```

fsmRmtErrSysdebugLogControlEpLogControlPersist:Peer

Fault Code: F78712

Message

[FSM:STAGE:REMOTE-ERROR]: persisting LogControl on peer(FSM-STAGE:sam:dme:SysdebugLogControlEpLogControlPersist:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed
mibFaultCode: 78712
mibFaultName: fsmRmtErrSysdebugLogControlEpLogControlPersistPeer
moClass: sysdebug:LogControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/logcontrol

```

fsmRmtErrEpqosDefinitionDeploy:Local

Fault Code: F78776

Message

[FSM:STAGE:REMOTE-ERROR]: vnic qos policy [name] configuration to primary(FSM-STAGE:sam:dme:EpqosDefinitionDeploy:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78776

```

```

mibFaultName: fsmRmtErrEpqosDefinitionDeployLocal
moClass: epqos:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos- [name]

```

fsmRmtErrEpqosDefinitionDeploy:Peer

Fault Code: F78776

Message

[FSM:STAGE:REMOTE-ERROR]: vnic qos policy [name] configuration to secondary(FSM-STAGE:sam:dme:EpqosDefinitionDeploy:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed
mibFaultCode: 78776
mibFaultName: fsmRmtErrEpqosDefinitionDeployPeer
moClass: epqos:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos- [name]

```

fsmRmtErrEpqosDefinitionDelTaskRemove:Local

Fault Code: F78777

Message

[FSM:STAGE:REMOTE-ERROR]: vnic qos policy [name] removal from primary(FSM-STAGE:sam:dme:EpqosDefinitionDelTaskRemove:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 78777
mibFaultName: fsmRmtErrEpqosDefinitionDelTaskRemoveLocal
moClass: epqos:DefinitionDelTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos-deletion- [defIntId]

fsmRmtErrEpqosDefinitionDelTaskRemove:Peer**Fault Code:** F78777**Message**

[FSM:STAGE:REMOTE-ERROR]: vnic qos policy [name] removal from secondary(FSM-STAGE:sam:dme:EpqosDefinitionDelTaskRemove:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: peer-failed
mibFaultCode: 78777
mibFaultName: fsmRmtErrEpqosDefinitionDelTaskRemovePeer
moClass: epqos:DefinitionDelTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos-deletion- [defIntId]

fsmRmtErrQosclassDefinitionConfigGlobalQoS:SetLocal**Fault Code:** F78780**Message**

[FSM:STAGE:REMOTE-ERROR]: QoS Classification Definition [name] configuration on primary(FSM-STAGE:sam:dme:QosclassDefinitionConfigGlobalQoS:SetLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-local-failed
mibFaultCode: 78780
mibFaultName: fsmRmtErrQosclassDefinitionConfigGlobalQoSSetLocal
moClass: qosclass:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/classes
```

fsmRmtErrQosclassDefinitionConfigGlobalQoS:SetPeer

Fault Code: F78780

Message

[FSM:STAGE:REMOTE-ERROR]: QoS Classification Definition [name] configuration on secondary(FSM-STAGE:sam:dme:QosclassDefinitionConfigGlobalQoS:SetPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-peer-failed
mibFaultCode: 78780
mibFaultName: fsmRmtErrQosclassDefinitionConfigGlobalQoSSetPeer
moClass: qosclass:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/classes
```

fsmRmtErrMgmtControllerRegistryConfig:Remove

Fault Code: F78787

Message

[FSM:STAGE:REMOTE-ERROR]: Deleting registry information from config file(FSM-STAGE:sam:dme:MgmtControllerRegistryConfig:Remove)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remove-failed
mibFaultCode: 78787
mibFaultName: fsmRmtErrMgmtControllerRegistryConfigRemove
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtIfSwMgmtOobIfConfig:Switch

Fault Code: F78798

Message

[FSM:STAGE:REMOTE-ERROR]: configuring the out-of-band interface(FSM-STAGE:sam:dme:MgmtIfSwMgmtOobIfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: switch-failed
mibFaultCode: 78798

```

```

mibFaultName: fsmRmtErrMgmtIfSwMgmtOobIfConfigSwitch
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmRmtErrMgmtIfSwMgmtInbandIfConfig:Switch

Fault Code: F78799

Message

[FSM:STAGE:REMOTE-ERROR]: configuring the inband interface(FSM-STAGE:sam:dme:MgmtIfSwMgmtInbandIfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: switch-failed
mibFaultCode: 78799
mibFaultName: fsmRmtErrMgmtIfSwMgmtInbandIfConfigSwitch
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]

```


Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmRmtErrMgmtIPv6IfAddrSwMgmtOobIpv6IfConfig:Switch

Fault Code: F78800

Message

[FSM:STAGE:REMOTE-ERROR]: configuring the out-of-band IPv6 interface(FSM-STAGE:sam:dme:MgmtIPv6IfAddrSwMgmtOobIpv6IfConfig:Switch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: switch-failed
mibFaultCode: 78800
mibFaultName: fsmRmtErrMgmtIPv6IfAddrSwMgmtOobIpv6IfConfigSwitch
moClass: mgmt:IPv6IfAddr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
 sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/mgmt/if-[id]/ifConfig-ipv6/if-ipv6

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6

fsmRmtErrNhTableHolderConfigureLinks:ApplyConfig

Fault Code: F78813

Message

[FSM:STAGE:REMOTE-ERROR]: Apply
 Configuration(FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-config-failed
mibFaultCode: 78813
mibFaultName: fsmRmtErrNhTableHolderConfigureLinksApplyConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh

fsmRmtErrNhTableHolderConfigureLinks:ConfigInterface

Fault Code: F78813

Message

[FSM:STAGE:REMOTE-ERROR]: Configure
 Interface(FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:ConfigInterface)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: config-interface-failed
mibFaultCode: 78813
mibFaultName: fsmRmtErrNhTableHolderConfigureLinksConfigInterface
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmRmtErrNhTableHolderConfigureLinks:VerifyLinkConfig

Fault Code: F78813

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:NhTableHolderConfigureLinks:VerifyLinkConfig)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-link-config-failed
mibFaultCode: 78813
mibFaultName: fsmRmtErrNhTableHolderConfigureLinksVerifyLinkConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmRmtErrNhTableHolderBootstrapLinks:ApplyConfig

Fault Code: F78814

Message

```
[FSM:STAGE:REMOTE-ERROR]: Apply
Configuration(FSM-STAGE:sam:dme:NhTableHolderBootstrapLinks:ApplyConfig)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-config-failed
mibFaultCode: 78814
mibFaultName: fsmRmtErrNhTableHolderBootstrapLinksApplyConfig
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmRmtErrStatsCollectionPolicyUpdateEp:SetEpA

Fault Code: F78818

Message

[FSM:STAGE:REMOTE-ERROR]: Update endpoint on fabric interconnect A(FSM-STAGE:sam:dme:StatsCollectionPolicyUpdateEp:SetEpA)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-ep-afailed
mibFaultCode: 78818
mibFaultName: fsmRmtErrStatsCollectionPolicyUpdateEpSetEpA
moClass: stats:CollectionPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: stats/coll-policy-[name]
```

fsmRmtErrStatsCollectionPolicyUpdateEp:SetEpB

Fault Code: F78818

Message

[FSM:STAGE:REMOTE-ERROR]: Update endpoint on fabric interconnect
B(FSM-STAGE:sam:dme:StatsCollectionPolicyUpdateEp:SetEpB)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: set-ep-bfailed
mibFaultCode: 78818
mibFaultName: fsmRmtErrStatsCollectionPolicyUpdateEpSetEpB
moClass: stats:CollectionPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: stats/coll-policy-[name]
```

fsmRmtErrSyntheticFsObjCreate:createLocal

Fault Code: F78843

Message

[FSM:STAGE:REMOTE-ERROR]: create on
primary(FSM-STAGE:sam:dme:SyntheticFsObjCreate:createLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: create-local-failed
mibFaultCode: 78843
mibFaultName: fsmRmtErrSyntheticFsObjCreateCreateLocal
moClass: synthetic:FsoObj
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/file-[name]

```

fsmRmtErrSyntheticFsObjCreate:createRemote

Fault Code: F78843

Message

[FSM:STAGE:REMOTE-ERROR]: create on secondary(FSM-STAGE:sam:dme:SyntheticFsObjCreate:createRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: create-remote-failed
mibFaultCode: 78843
mibFaultName: fsmRmtErrSyntheticFsObjCreateCreateRemote
moClass: synthetic:Fsobj
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/file-[name]

```

fsmRmtErrCapabilityUpdaterUpdater:Apply

Fault Code: F78848

Message

[FSM:STAGE:REMOTE-ERROR]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:Apply)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-failed
mibFaultCode: 78848

```

```

mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterApply
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]

```

fsmRmtErrCapabilityUpdaterUpdater:CopyRemote

Fault Code: F78848

Message

[FSM:STAGE:REMOTE-ERROR]: syncing catalog files to subordinate(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: copy-remote-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterCopyRemote
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]

```

fsmRmtErrCapabilityUpdaterUpdater>DeleteLocal

Fault Code: F78848

Message

[FSM:STAGE:REMOTE-ERROR]: deleting temp image [fileName] on local(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater>DeleteLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: delete-local-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterDeleteLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater- [fileName]

fsmRmtErrCapabilityUpdaterUpdater:EvaluateStatus**Fault Code:** F78848**Message**

[FSM:STAGE:REMOTE-ERROR]: evaluating status of
update(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterEvaluateStatus
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater- [fileName]

fsmRmtErrCapabilityUpdaterUpdater:Local**Fault Code:** F78848**Message**

[FSM:STAGE:REMOTE-ERROR]: downloading catalog file [fileName] from
[server](FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: local-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmRmtErrCapabilityUpdaterUpdater:RescanImages

Fault Code: F78848

Message

```
[FSM:STAGE:REMOTE-ERROR]: rescanning image
files(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:RescanImages)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: rescan-images-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterRescanImages
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmRmtErrCapabilityUpdaterUpdater:UnpackLocal

Fault Code: F78848

Message

```
[FSM:STAGE:REMOTE-ERROR]: unpacking catalog file [fileName] on
primary(FSM-STAGE:sam:dme:CapabilityUpdaterUpdater:UnpackLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 78848
mibFaultName: fsmRmtErrCapabilityUpdaterUpdaterUnpackLocal
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmRmtErrCapabilityCatalogueActivateCatalog:ApplyCatalog

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:ApplyCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: apply-catalog-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogApplyCatalog
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fsmRmtErrCapabilityCatalogueActivateCatalog:CopyCatFromRep

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: Copying Catalogue from repository to
FI(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyCatFromRep)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-cat-from-rep-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogCopyCatFromRep
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrCapabilityCatalogueActivateCatalog:CopyExternalRepToRemote

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: syncing external repository to
subordinate(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyExternalRepToRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-external-rep-to-remote-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogCopyExternalRepToRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrCapabilityCatalogueActivateCatalog:CopyRemote

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: syncing catalog changes to subordinate(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: copy-remote-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogCopyRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrCapabilityCatalogueActivateCatalog:EvaluateStatus

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: evaluating status of activation(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 78849

```

mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogEvaluateStatus
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

```

fsmRmtErrCapabilityCatalogueActivateCatalog:RescanImages

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: rescanning image
files(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:RescanImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: rescan-images-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogRescanImages
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

```

fsmRmtErrCapabilityCatalogueActivateCatalog:UnpackLocal

Fault Code: F78849

Message

[FSM:STAGE:REMOTE-ERROR]: activating catalog
changes(FSM-STAGE:sam:dme:CapabilityCatalogueActivateCatalog:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: unpack-local-failed
mibFaultCode: 78849
mibFaultName: fsmRmtErrCapabilityCatalogueActivateCatalogUnpackLocal
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrCapabilityMgmtExtensionActivateMgmtExt:ApplyCatalog

Fault Code: F78850

Message

[FSM:STAGE:REMOTE-ERROR]: applying changes to catalog(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:ApplyCatalog)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-catalog-failed
mibFaultCode: 78850
mibFaultName: fsmRmtErrCapabilityMgmtExtensionActivateMgmtExtApplyCatalog
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext

fsmRmtErrCapabilityMgmtExtensionActivateMgmtExt:CopyRemote

Fault Code: F78850

Message

[FSM:STAGE:REMOTE-ERROR]: syncing management extension changes to subordinate(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:CopyRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: copy-remote-failed
mibFaultCode: 78850
mibFaultName: fsmRmtErrCapabilityMgmtExtensionActivateMgmtExtCopyRemote
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmRmtErrCapabilityMgmtExtensionActivateMgmtExt:EvaluateStatus

Fault Code: F78850

Message

[FSM:STAGE:REMOTE-ERROR]: evaluating status of activation(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:EvaluateStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: evaluate-status-failed
mibFaultCode: 78850
mibFaultName: fsmRmtErrCapabilityMgmtExtensionActivateMgmtExtEvaluateStatus
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmRmtErrCapabilityMgmtExtensionActivateMgmtExt:RescanImages

Fault Code: F78850

Message

[FSM:STAGE:REMOTE-ERROR]: rescanning image files(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:RescanImages)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: rescan-images-failed
mibFaultCode: 78850
mibFaultName: fsmRmtErrCapabilityMgmtExtensionActivateMgmtExtRescanImages
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmRmtErrCapabilityMgmtExtensionActivateMgmtExt:UnpackLocal

Fault Code: F78850

Message

[FSM:STAGE:REMOTE-ERROR]: activating management extension changes(FSM-STAGE:sam:dme:CapabilityMgmtExtensionActivateMgmtExt:UnpackLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unpack-local-failed
mibFaultCode: 78850
mibFaultName: fsmRmtErrCapabilityMgmtExtensionActivateMgmtExtUnpackLocal
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```


fsmRmtErrCapabilityCatalogueDeployCatalogue:SyncPortAGLocal

Fault Code: F78851

Message

[FSM:STAGE:REMOTE-ERROR]: Sending capability catalogue [version] to local portAG(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:SyncPortAGLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sync-portaglocal-failed
mibFaultCode: 78851
mibFaultName: fsmRmtErrCapabilityCatalogueDeployCatalogueSyncPortAGLocal
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fsmRmtErrCapabilityCatalogueDeployCatalogue:SyncPortAGRemote

Fault Code: F78851

Message

[FSM:STAGE:REMOTE-ERROR]: Sending capability catalogue [version] to remote portAG(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:SyncPortAGRemote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sync-portagremote-failed
mibFaultCode: 78851
mibFaultName: fsmRmtErrCapabilityCatalogueDeployCatalogueSyncPortAGRemote
moClass: capability:Catalogue
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrCapabilityCatalogueDeployCatalogue:finalize

Fault Code: F78851

Message

[FSM:STAGE:REMOTE-ERROR]: Finalizing capability catalogue [version] deployment(FSM-STAGE:sam:dme:CapabilityCatalogueDeployCatalogue:finalize)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: finalize-failed
mibFaultCode: 78851
mibFaultName: fsmRmtErrCapabilityCatalogueDeployCatalogueFinalize
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities

fsmRmtErrSwEthMonDeploy:UpdateEthMon

Fault Code: F78860

Message

[FSM:STAGE:REMOTE-ERROR]: Ethernet traffic monitor (SPAN)configuration on [switchId](FSM-STAGE:sam:dme:SwEthMonDeploy:UpdateEthMon)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: update-eth-mon-failed
mibFaultCode: 78860

```

mibFaultName: fsmRmtErrSwEthMonDeployUpdateEthMon
moClass: sw:EthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]

```

fsmRmtErrSwSspEthMonDeploy:UpdateSspEthMon

Fault Code: F78909

Message

[FSM:STAGE:REMOTE-ERROR]: SSP Packet Capture configuration on [switchId](FSM-STAGE:sam:dme:SwSspEthMonDeploy:UpdateSspEthMon)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: update-ssp-eth-mon-failed
mibFaultCode: 78909
mibFaultName: fsmRmtErrSwSspEthMonDeployUpdateSspEthMon
moClass: sw:SspEthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]

```

fsmRmtErrSwSspEthMonSrcPhyEpDelete:DeletePcapFile

Fault Code: F78910

Message

[FSM:STAGE:REMOTE-ERROR]: Delete Pcap file whenever there is a delete interface trigger(FSM-STAGE:sam:dme:SwSspEthMonSrcPhyEpDelete:DeletePcapFile)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: delete-pcap-file-failed
mibFaultCode: 78910
mibFaultName: fsmRmtErrSwSspEthMonSrcPhyEpDeleteDeletePcapFile
moClass: sw:SspEthMonSrcPhyEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/switch- [id] /ssp-lanmon-eth/ssp-mon-session [name] /ssp-mon-src-phy- [chassisId] -slot-
[slotId] -port- [portId] -aggr- [aggrPortId]

```

fsmRmtErrFabricVnetEpSyncEpPushVnetEpDeletion:Sync**Fault Code: F78916****Message**

[FSM:STAGE:REMOTE-ERROR]: Update resource-mgr with VnetEp deletion(FSM-STAGE:sam:dme:FabricVnetEpSyncEpPushVnetEpDeletion:Sync)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: sync-failed
mibFaultCode: 78916
mibFaultName: fsmRmtErrFabricVnetEpSyncEpPushVnetEpDeletionSync
moClass: fabric:VnetEpSyncEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/providers/prov- [type] /syncEp

```

fsmRmtErrFabricLanCloudSwitchMode:SwConfigLocal**Fault Code: F78917****Message**

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:FabricLanCloudSwitchMode:SwConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 78917
mibFaultName: fsmRmtErrFabricLanCloudSwitchModeSwConfigLocal
moClass: fabric:LanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan
```

fsmRmtErrFabricLanCloudSwitchMode:SwConfigPeer

Fault Code: F78917

Message

[FSM:STAGE:REMOTE-ERROR]: Fabric interconnect mode configuration to primary(FSM-STAGE:sam:dme:FabricLanCloudSwitchMode:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 78917
mibFaultName: fsmRmtErrFabricLanCloudSwitchModeSwConfigPeer
moClass: fabric:LanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan
```

fsmRmtErrFabricSanCloudSwitchMode:SwConfigLocal

Fault Code: F78918

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:FabricSanCloudSwitchMode:SwConfigLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-local-failed
mibFaultCode: 78918
mibFaultName: fsmRmtErrFabricSanCloudSwitchModeSwConfigLocal
moClass: fabric:SanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/san
```

fsmRmtErrFabricSanCloudSwitchMode:SwConfigPeer

Fault Code: F78918

Message

[FSM:STAGE:REMOTE-ERROR]: Fabric interconnect FC mode configuration to primary(FSM-STAGE:sam:dme:FabricSanCloudSwitchMode:SwConfigPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: sw-config-peer-failed
mibFaultCode: 78918
mibFaultName: fsmRmtErrFabricSanCloudSwitchModeSwConfigPeer
moClass: fabric:SanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/san
```

fsmRmtErrFabricEpMgrConfigure:ApplyConfig

Fault Code: F78924

Message

[FSM:STAGE:REMOTE-ERROR]: Apply switch configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-config-failed
mibFaultCode: 78924
mibFaultName: fsmRmtErrFabricEpMgrConfigureApplyConfig
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

fsmRmtErrFabricEpMgrConfigure:ApplyPhysical

Fault Code: F78924

Message

[FSM:STAGE:REMOTE-ERROR]: Applying physical configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ApplyPhysical)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-physical-failed
mibFaultCode: 78924
mibFaultName: fsmRmtErrFabricEpMgrConfigureApplyPhysical
moClass: fabric:EpMgr
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

fsmRmtErrFabricEpMgrConfigure:ValidateConfiguration

Fault Code: F78924

Message

[FSM:STAGE:REMOTE-ERROR]: Validating logical configuration(FSM-STAGE:sam:dme:FabricEpMgrConfigure:ValidateConfiguration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: validate-configuration-failed
mibFaultCode: 78924
mibFaultName: fsmRmtErrFabricEpMgrConfigureValidateConfiguration
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

fsmRmtErrFabricEpMgrConfigure:WaitOnPhys

Fault Code: F78924

Message

[FSM:STAGE:REMOTE-ERROR]: Waiting on physical change application(FSM-STAGE:sam:dme:FabricEpMgrConfigure:WaitOnPhys)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-on-phys-failed
mibFaultCode: 78924


```

mibFaultName: fsmRmtErrFabricEpMgrConfigureWaitOnPhys
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

```

fsmRmtErrMgmtExportPolicyReportConfigCopy:Report

Fault Code: F78930

Message

[FSM:STAGE:REMOTE-ERROR]: Report config copy to Ops
Mgr(FSM-STAGE:sam:dme:MgmtExportPolicyReportConfigCopy:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: report-failed
mibFaultCode: 78930
mibFaultName: fsmRmtErrMgmtExportPolicyReportConfigCopyReport
moClass: mgmt:ExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/cfg-exp-policy- [name]
Affected MO: org- [name]/db-backup-policy- [name]

```

fsmRmtErrExtpolProviderReportConfigImport:Report

Fault Code: F78931

Message

[FSM:STAGE:REMOTE-ERROR]: Report config import to Ops
Mgr(FSM-STAGE:sam:dme:ExtpolProviderReportConfigImport:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: report-failed
mibFaultCode: 78931
mibFaultName: fsmRmtErrExtpolProviderReportConfigImportReport
moClass: extpol:Provider
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/providers/prov- [type]

fsmRmtErrMgmtIfVirtualIfConfig:Local**Fault Code: F78932****Message**

[FSM:STAGE:REMOTE-ERROR]: Updating virtual interface on local fabric interconnect(FSM-STAGE:sam:dme:MgmtIfVirtualIfConfig:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: local-failed
mibFaultCode: 78932
mibFaultName: fsmRmtErrMgmtIfVirtualIfConfigLocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/mgmt/if- [id]
Affected MO: sys/switch- [id]/mgmt/if- [id]

fsmRmtErrMgmtIfVirtualIfConfig:Remote

Fault Code: F78932

Message

[FSM:STAGE:REMOTE-ERROR]: Updating virtual interface on peer fabric interconnect(FSM-STAGE:sam:dme:MgmtIfVirtualIfConfig:Remote)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: remote-failed
mibFaultCode: 78932
mibFaultName: fsmRmtErrMgmtIfVirtualIfConfigRemote
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmRmtErrMgmtIfEnableVip:Local

Fault Code: F78933

Message

[FSM:STAGE:REMOTE-ERROR]: Enable virtual interface on local fabric interconnect(FSM-STAGE:sam:dme:MgmtIfEnableVip:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78933
mibFaultName: fsmRmtErrMgmtIfEnableVipLocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmRmtErrMgmtIfDisableVip:Peer

Fault Code: F78934

Message

[FSM:STAGE:REMOTE-ERROR]: Disable virtual interface on peer fabric interconnect(FSM-STAGE:sam:dme:MgmtIfDisableVip:Peer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: peer-failed
mibFaultCode: 78934
mibFaultName: fsmRmtErrMgmtIfDisableVipPeer
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmRmtErrMgmtIfEnableHA:Local**Fault Code: F78935****Message**

[FSM:STAGE:REMOTE-ERROR]: Transition from single to cluster mode(FSM-STAGE:sam:dme:MgmtIfEnableHA:Local)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: local-failed
mibFaultCode: 78935
mibFaultName: fsmRmtErrMgmtIfEnableHALocal
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]

```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmRmtErrMgmtBackupBackup:backupLocal

Fault Code: F78936

Message

[FSM:STAGE:REMOTE-ERROR]: internal database
 backup(FSM-STAGE:sam:dme:MgmtBackupBackup:backupLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: backup-local-failed
mibFaultCode: 78936
mibFaultName: fsmRmtErrMgmtBackupBackupBackupLocal
moClass: mgmt:Backup
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/backup-[hostname]

fsmRmtErrMgmtBackupBackup:upload

Fault Code: F78936

Message

[FSM:STAGE:REMOTE-ERROR]: internal system
 backup(FSM-STAGE:sam:dme:MgmtBackupBackup:upload)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: upload-failed
mibFaultCode: 78936
mibFaultName: fsmRmtErrMgmtBackupBackupUpload
moClass: mgmt:Backup
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/backup- [hostname]
```

fsmRmtErrMgmtImporterImport:cleanUp

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: cleaning up old Security Service configuration(FSM-STAGE:sam:dme:MgmtImporterImport:cleanUp)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: clean-up-failed
mibFaultCode: 78937
mibFaultName: fsmRmtErrMgmtImporterImportCleanUp
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]
```

fsmRmtErrMgmtImporterImport:config

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: importing the configuration file(FSM-STAGE:sam:dme:MgmtImporterImport:config)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: config-failed
mibFaultCode: 78937
mibFaultName: fsmRmtErrMgmtImporterImportConfig
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

fsmRmtErrMgmtImporterImport:configBreakout

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: updating breakout port configuration(FSM-STAGE:sam:dme:MgmtImporterImport:configBreakout)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: config-breakout-failed
mibFaultCode: 78937
mibFaultName: fsmRmtErrMgmtImporterImportConfigBreakout
moClass: mgmt:Importer
Type: fsm
Callhome: none


```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmRmtErrMgmtImporterImport:downloadLocal

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: downloading the configuration file(FSM-STAGE:sam:dme:MgmtImporterImport:downloadLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: download-local-failed
mibFaultCode: 78937
mibFaultName: fsmRmtErrMgmtImporterImportDownloadLocal
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmRmtErrMgmtImporterImport:reportResults

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: Reporting results of import configuration(FSM-STAGE:sam:dme:MgmtImporterImport:reportResults)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: report-results-failed
mibFaultCode: 78937

```

```

mibFaultName: fsmRmtErrMgmtImporterImportReportResults
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmRmtErrMgmtImporterImport:waitForSwitch

Fault Code: F78937

Message

[FSM:STAGE:REMOTE-ERROR]: waiting for completion of switch configuration(FSM-STAGE:sam:dme:MgmtImporterImport:waitForSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: wait-for-switch-failed
mibFaultCode: 78937
mibFaultName: fsmRmtErrMgmtImporterImportWaitForSwitch
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]

```

fsmRmtErrMgmtControllerSysConfig:Primary

Fault Code: F78938

Message

[FSM:STAGE:REMOTE-ERROR]: system configuration on primary(FSM-STAGE:sam:dme:MgmtControllerSysConfig:Primary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: primary-failed
mibFaultCode: 78938
mibFaultName: fsmRmtErrMgmtControllerSysConfigPrimary
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmRmtErrMgmtControllerSysConfig:Secondary**Fault Code: F78938****Message**

[FSM:STAGE:REMOTE-ERROR]: system configuration on secondary(FSM-STAGE:sam:dme:MgmtControllerSysConfig:Secondary)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: secondary-failed
mibFaultCode: 78938
mibFaultName: fsmRmtErrMgmtControllerSysConfigSecondary
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt

```

Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmRmtErrNfsMountInstMount:MountLocal

Fault Code: F78971

Message

[FSM:STAGE:REMOTE-ERROR]: Mount nfs [remoteDir] from server [server] on local switch(FSM-STAGE:sam:dme:NfsMountInstMount:MountLocal)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: mount-local-failed
mibFaultCode: 78971
mibFaultName: fsmRmtErrNfsMountInstMountMountLocal
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]

fsmRmtErrNfsMountInstMount:MountPeer

Fault Code: F78971

Message

[FSM:STAGE:REMOTE-ERROR]: Mount nfs [remoteDir] from NFS server [server] on peer switch(FSM-STAGE:sam:dme:NfsMountInstMount:MountPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: mount-peer-failed
mibFaultCode: 78971
mibFaultName: fsmRmtErrNfsMountInstMountMountPeer
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id]/nfs-mount-inst- [name]
```

fsmRmtErrNfsMountInstMount:RegisterClient

Fault Code: F78971

Message

[FSM:STAGE:REMOTE-ERROR]: Register client with Ops
Mgr(FSM-STAGE:sam:dme:NfsMountInstMount:RegisterClient)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: register-client-failed
mibFaultCode: 78971
mibFaultName: fsmRmtErrNfsMountInstMountRegisterClient
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id]/nfs-mount-inst- [name]
```

fsmRmtErrNfsMountInstMount:VerifyRegistration

Fault Code: F78971

Message

[FSM:STAGE:REMOTE-ERROR]: Verify client registration with Ops
Mgr(FSM-STAGE:sam:dme:NfsMountInstMount:VerifyRegistration)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: verify-registration-failed
mibFaultCode: 78971
mibFaultName: fsmRmtErrNfsMountInstMountVerifyRegistration
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmRmtErrNfsMountInstUnmount:UnmountLocal

Fault Code: F78972

Message

```
[FSM:STAGE:REMOTE-ERROR]: Unmount nfs [remoteDir] from server
[server](FSM-STAGE:sam:dme:NfsMountInstUnmount:UnmountLocal)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unmount-local-failed
mibFaultCode: 78972
mibFaultName: fsmRmtErrNfsMountInstUnmountUnmountLocal
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmRmtErrNfsMountInstUnmount:UnmountPeer

Fault Code: F78972

Message

[FSM:STAGE:REMOTE-ERROR]: Unmount nfs [remoteDir] from server [server](FSM-STAGE:sam:dme:NfsMountInstUnmount:UnmountPeer)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: unmount-peer-failed
mibFaultCode: 78972
mibFaultName: fsmRmtErrNfsMountInstUnmountUnmountPeer
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmRmtErrNfsMountDefReportNfsMountSuspend:Report

Fault Code: F78973

Message

[FSM:STAGE:REMOTE-ERROR]: Report mount suspend success to operations manager(FSM-STAGE:sam:dme:NfsMountDefReportNfsMountSuspend:Report)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: report-failed
mibFaultCode: 78973
mibFaultName: fsmRmtErrNfsMountDefReportNfsMountSuspendReport
moClass: nfs:MountDef
Type: fsm
Callhome: none
```

```

Auto Cleared: true
Is Implemented: true
Affected MO: nfs-ep/nfs-mount-def- [name]

```

fsmRmtErrExtpolEpRepairCert:cleanOldData

Fault Code: F78994

Message

[FSM:STAGE:REMOTE-ERROR]: Cleaning certificates, channels and policy meta data(FSM-STAGE:sam:dme:ExtpolEpRepairCert:cleanOldData)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: clean-old-data-failed
mibFaultCode: 78994
mibFaultName: fsmRmtErrExtpolEpRepairCertCleanOldData
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmRmtErrExtpolEpRepairCert:request

Fault Code: F78994

Message

[FSM:STAGE:REMOTE-ERROR]: Provisioning latest certificates(FSM-STAGE:sam:dme:ExtpolEpRepairCert:request)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: request-failed
mibFaultCode: 78994

```



```

mibFaultName: fsmRmtErrExtpolEpRepairCertRequest
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmRmtErrExtpolEpRepairCert:unregister

Fault Code: F78994

Message

[FSM:STAGE:REMOTE-ERROR]: unregister from old FPR Central, if needed(FSM-STAGE:sam:dme:ExtpolEpRepairCert:unregister)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: unregister-failed
mibFaultCode: 78994
mibFaultName: fsmRmtErrExtpolEpRepairCertUnregister
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmRmtErrExtpolEpRepairCert:verify

Fault Code: F78994

Message

[FSM:STAGE:REMOTE-ERROR]: checking that cert was provisioned(FSM-STAGE:sam:dme:ExtpolEpRepairCert:verify)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: verify-failed
mibFaultCode: 78994
mibFaultName: fsmRmtErrExtpolEpRepairCertVerify
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

fsmRmtErrExtpolEpRepairCert:verifyGuid

Fault Code: F78994

Message

[FSM:STAGE:REMOTE-ERROR]: verifying GUID of FPR
 Central(FSM-STAGE:sam:dme:ExtpolEpRepairCert:verifyGuid)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: verify-guid-failed
mibFaultCode: 78994
mibFaultName: fsmRmtErrExtpolEpRepairCertVerifyGuid
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

fsmRmtErrPolicyControlEpOperate:Resolve

Fault Code: F78995

Message

[FSM:STAGE:REMOTE-ERROR]: (FSM-STAGE:sam:dme:PolicyControlEpOperate:Resolve)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-failed
mibFaultCode: 78995
mibFaultName: fsmRmtErrPolicyControlEpOperateResolve
moClass: policy:ControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]
```

fsmRmtErrPolicyControlledTypeOperate:ResolveAll**Fault Code: F78996****Message**

[FSM:STAGE:REMOTE-ERROR]: Resolving controlled type global policies(FSM-STAGE:sam:dme:PolicyControlledTypeOperate:ResolveAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: resolve-all-failed
mibFaultCode: 78996
mibFaultName: fsmRmtErrPolicyControlledTypeOperateResolveAll
moClass: policy:ControlledType
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]/cfg-backup-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/comm-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/datetime-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/discovery-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/dns-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/fabric-fw-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/fault-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/mep-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/monitoring-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/powermgmt-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/psu-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/security-ctrl/ctrlled-type- [type]
```

fsmRmtErrPolicyPolicyScopeReleasePolicyFsm:Release

Fault Code: F78999

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleasePolicyFsm:Release)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-failed
mibFaultCode: 78999
mibFaultName: fsmRmtErrPolicyPolicyScopeReleasePolicyFsmRelease
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmRmtErrPolicyPolicyScopeReleaseOperationFsm:Release

Fault Code: F79000

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseOperationFsm:Release)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-failed
mibFaultCode: 79000
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseOperationFsmRelease
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseStorageFsm:Release

Fault Code: F79001

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseStorageFsm:Release)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-failed
mibFaultCode: 79001
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseStorageFsmRelease
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```

```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeResolveManyPolicyFsm:ResolveMany

Fault Code: F79002

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyPolicyFsm:ResolveMany)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 79002
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveManyPolicyFsmResolveMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeResolveManyOperationFsm:ResolveMany

Fault Code: F79003

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyOperationFsm:ResolveMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 79003
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveManyOperationFsmResolveMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmRmtErrPolicyPolicyScopeResolveManyStorageFsm:ResolveMany

Fault Code: F79004

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveManyStorageFsm:ResolveMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-many-failed
mibFaultCode: 79004
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveManyStorageFsmResolveMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseManyPolicyFsm:ReleaseMany

Fault Code: F79005

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyPolicyFsm:ReleaseMany)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-many-failed
mibFaultCode: 79005
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseManyPolicyFsmReleaseMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```



```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseManyOperationFsm:ReleaseMany

Fault Code: F79006

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyOperationFsm:ReleaseMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-many-failed
mibFaultCode: 79006
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseManyOperationFsmReleaseMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseManyStorageFsm:ReleaseMany

Fault Code: F79007

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseManyStorageFsm:ReleaseMany)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-many-failed
mibFaultCode: 79007
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseManyStorageFsmReleaseMany
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmRmtErrPolicyPolicyScopeResolveAllPolicyFsm:ResolveAll

Fault Code: F79008

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllPolicyFsm:ResolveAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 79008
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveAllPolicyFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeResolveAllOperationFsm:ResolveAll

Fault Code: F79009

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllOperationFsm:ResolveAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 79009
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveAllOperationFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```

```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeResolveAllStorageFsm:ResolveAll

Fault Code: F79010

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeResolveAllStorageFsm:ResolveAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: resolve-all-failed
mibFaultCode: 79010
mibFaultName: fsmRmtErrPolicyPolicyScopeResolveAllStorageFsmResolveAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseAllPolicyFsm:ReleaseAll

Fault Code: F79011

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllPolicyFsm:ReleaseAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: release-all-failed
mibFaultCode: 79011
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseAllPolicyFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmRmtErrPolicyPolicyScopeReleaseAllOperationFsm:ReleaseAll

Fault Code: F79012

Message

[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllOperationFsm:ReleaseAll)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-all-failed
mibFaultCode: 79012
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseAllOperationFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrPolicyPolicyScopeReleaseAllStorageFsm:ReleaseAll

Fault Code: F79013

Message

```
[FSM:STAGE:REMOTE-ERROR]:
(FSM-STAGE:sam:dme:PolicyPolicyScopeReleaseAllStorageFsm:ReleaseAll)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: release-all-failed
mibFaultCode: 79013
mibFaultName: fsmRmtErrPolicyPolicyScopeReleaseAllStorageFsmReleaseAll
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true

```

```

Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmRmtErrFirmwareInfraPackInfraVersion:Restore

Fault Code: F79130

Message

[FSM:STAGE:REMOTE-ERROR]: Check and Restore the Platform Version(FSM-STAGE:sam:dme:FirmwareInfraPackInfraVersion:Restore)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: restore-failed
mibFaultCode: 79130
mibFaultName: fsmRmtErrFirmwareInfraPackInfraVersionRestore
moClass: firmware:InfraPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-infra-pack-[name]

```

fsmRmtErrFirmwareInfraPackInfraVersion:WaitForReady

Fault Code: F79130

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for system to be ready(FSM-STAGE:sam:dme:FirmwareInfraPackInfraVersion:WaitForReady)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: wait-for-ready-failed
mibFaultCode: 79130
mibFaultName: fsmRmtErrFirmwareInfraPackInfraVersionWaitForReady
moClass: firmware:InfraPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-infra-pack-[name]
```

fsmRmtErrFirmwareValidationStatusValidate:ApplicationPack

Fault Code: F79140

Message

```
[FSM:STAGE:REMOTE-ERROR]: Validating the application
pack(FSM-STAGE:sam:dme:FirmwareValidationStatusValidate:ApplicationPack)
```

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: application-pack-failed
mibFaultCode: 79140
mibFaultName: fsmRmtErrFirmwareValidationStatusValidateApplicationPack
moClass: firmware:ValidationStatus
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]/validation
```


fsmRmtErrFirmwareValidationStatusValidate:Complete

Fault Code: F79140

Message

[FSM:STAGE:REMOTE-ERROR]: Complete
Validation(FSM-STAGE:sam:dme:FirmwareValidationStatusValidate:Complete)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: complete-failed
mibFaultCode: 79140
mibFaultName: fsmRmtErrFirmwareValidationStatusValidateComplete
moClass: firmware:ValidationStatus
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]/validation
```

fsmRmtErrSdLogicalDeviceConfigureUserMacs:ConfigureSwitch

Fault Code: F79151

Message

[FSM:STAGE:REMOTE-ERROR]: Invoke Port API to configure the
switch(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureUserMacs:ConfigureSwitch)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: warning
Cause: configure-switch-failed
mibFaultCode: 79151
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureUserMacsConfigureSwitch
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
```

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmRmtErrSdLogicalDeviceConfigureUserMacs:WaitForSwitchConfig

Fault Code: F79151

Message

[FSM:STAGE:REMOTE-ERROR]: Wait for Switch configuration to complete(FSM-STAGE:sam:dme:SdLogicalDeviceConfigureUserMacs:WaitForSwitchConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: wait-for-switch-config-failed
mibFaultCode: 79151
mibFaultName: fsmRmtErrSdLogicalDeviceConfigureUserMacsWaitForSwitchConfig
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmRmtErrMgmtIfSwMgmtOobIfDhcpConfig:StopDhcpSvc

Fault Code: F79155

Message

[FSM:STAGE:REMOTE-ERROR]: disabling the out-of-band interface dhcp service(FSM-STAGE:sam:dme:MgmtIfSwMgmtOobIfDhcpConfig:StopDhcpSvc)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: stop-dhcp-svc-failed
mibFaultCode: 79155

```

mibFaultName: fsmRmtErrMgmtIfSwMgmtOobIfDhcpConfigStopDhcpSvc
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmRmtErrSdLduUpdateInterfaceStatus:SendStatus

Fault Code: F79158

Message

[FSM:STAGE:REMOTE-ERROR]: Send Interface Operational
State(FSM-STAGE:sam:dme:SdLduUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-status-failed
mibFaultCode: 79158
mibFaultName: fsmRmtErrSdLduUpdateInterfaceStatusSendStatus
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld-[name]/ldu-[slotId]
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/ldu-[slotId]

```

fsmRmtErrEquipmentChassisShutdownChassis:ApplyShutdown

Fault Code: F79164

Message

[FSM:STAGE:REMOTE-ERROR]: Shutdown
Chassis(FSM-STAGE:sam:dme:EquipmentChassisShutdownChassis:ApplyShutdown)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-shutdown-failed
mibFaultCode: 79164
mibFaultName: fsmRmtErrEquipmentChassisShutdownChassisApplyShutdown
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

fsmRmtErrEquipmentChassisRebootChassis:ApplyReboot

Fault Code: F79165

Message

[FSM:STAGE:REMOTE-ERROR]: Reboot
Chassis(FSM-STAGE:sam:dme:EquipmentChassisRebootChassis:ApplyReboot)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: warning
Cause: apply-reboot-failed
mibFaultCode: 79165
mibFaultName: fsmRmtErrEquipmentChassisRebootChassisApplyReboot
moClass: equipment:Chassis
Type: fsm
Callhome: none

```

Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

```

fsmRmtErrIpsecEpUpdateEp:ApplyConfig

Fault Code: F79170

Message

[FSM:STAGE:REMOTE-ERROR]: configure IPsec connections(FSM-STAGE:sam:dme:IpsecEpUpdateEp:ApplyConfig)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: apply-config-failed
mibFaultCode: 79170
mibFaultName: fsmRmtErrIpsecEpUpdateEpApplyConfig
moClass: ipsec:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ipsec-ext

```

fsmRmtErrNetworkEthLanMgmtUpdateInterfaceStatus:SendStatus

Fault Code: F79183

Message

[FSM:STAGE:REMOTE-ERROR]: Send Management Interface Operational State(FSM-STAGE:sam:dme:NetworkEthLanMgmtUpdateInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-status-failed
mibFaultCode: 79183

```

```

mibFaultName: fsmRmtErrNetworkEthLanMgmtUpdateInterfaceStatusSendStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/mgmt-port-[portId]

```

fsmRmtErrNetworkEthLanMgmtUpdateMgmtInterfaceStatus:SendStatus

Fault Code: F79184

Message

[FSM:STAGE:REMOTE-ERROR]: Send Management Interface Operational State(FSM-STAGE:sam:dme:NetworkEthLanMgmtUpdateMgmtInterfaceStatus:SendStatus)

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: warning
Cause: send-status-failed
mibFaultCode: 79184
mibFaultName: fsmRmtErrNetworkEthLanMgmtUpdateMgmtInterfaceStatusSendStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/mgmt-port-[portId]

```

fsmFailComputeServerDiscPolicyResolveScrubPolicy

Fault Code: F999516

Message

[FSM:FAILED]: sam:dme:ComputeServerDiscPolicyResolveScrubPolicy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999516
mibFaultName: fsmFailComputeServerDiscPolicyResolveScrubPolicy
moClass: compute:ServerDiscPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /server-discovery

fsmFailGmetaHolderInventory

Fault Code: F999517

Message

[FSM:FAILED]: sam:dme:GmetaHolderInventory

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999517
mibFaultName: fsmFailGmetaHolderInventory
moClass: gmeta:Holder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: gmeta/category- [category] -provider- [provider]

fsmFailFirmwareDownloaderDownload

Fault Code: F999557

Message

[FSM:FAILED]: sam:dme:FirmwareDownloaderDownload

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999557
mibFaultName: fsmFailFirmwareDownloaderDownload
moClass: firmware:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/dnld- [fileName]
Affected MO: sys/pki-ext/tp- [name]/certrevoke/dnld- [fileName]
```

fsmFailFirmwareImageDelete

Fault Code: F999558

Message

[FSM:FAILED]: sam:dme:FirmwareImageDelete

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999558
mibFaultName: fsmFailFirmwareImageDelete
moClass: firmware:Image
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/image- [name]
```

fsmFailFirmwareDistributableDelete

Fault Code: F999559

Message

[FSM:FAILED]: sam:dme:FirmwareDistributableDelete

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999559
mibFaultName: fsmFailFirmwareDistributableDelete
moClass: firmware:Distributable
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]
```

fsmFailMgmtControllerUpdateUCSManager

Fault Code: F999560

Message

[FSM:FAILED]: sam:dme:MgmtControllerUpdateUCSManager

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999560
mibFaultName: fsmFailMgmtControllerUpdateUCSManager
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmFailMgmtControllerUpdateSwitch

Fault Code: F999561

Message

[FSM:FAILED]: sam:dme:MgmtControllerUpdateSwitch

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999561
mibFaultName: fsmFailMgmtControllerUpdateSwitch
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fsmFailMgmtControllerUpdateIOM

Fault Code: F999562

Message

[FSM:FAILED]: sam:dme:MgmtControllerUpdateIOM

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999562
mibFaultName: fsmFailMgmtControllerUpdateIOM
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmFailFirmwarePlatformPackPlatformVersion

Fault Code: F999563

Message

[FSM:FAILED]: sam:dme:FirmwarePlatformPackPlatformVersion

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999563
mibFaultName: fsmFailFirmwarePlatformPackPlatformVersion

```

```

moClass: firmware:PlatformPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org-[name]/fw-platform-pack-[name]

```

fsmFailFirmwareSystemDeploy

Fault Code: F999564

Message

[FSM:FAILED]: sam:dme:FirmwareSystemDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999564
mibFaultName: fsmFailFirmwareSystemDeploy
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmFailFirmwareSupFirmwareDeploy

Fault Code: F999565

Message

[FSM:FAILED]: sam:dme:FirmwareSupFirmwareDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed

```

```

mibFaultCode: 999565
mibFaultName: fsmFailFirmwareSupFirmwareDeploy
moClass: firmware:SupFirmware
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-supfirmware

```

fsmFailFirmwareSystemApplyCatalogPack

Fault Code: F999566

Message

[FSM:FAILED]: sam:dme:FirmwareSystemApplyCatalogPack

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999566
mibFaultName: fsmFailFirmwareSystemApplyCatalogPack
moClass: firmware:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-system

```

fsmFailIdentIdentRequestUpdateIdent

Fault Code: F999568

Message

[FSM:FAILED]: sam:dme:IdentIdentRequestUpdateIdent

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999568
mibFaultName: fsmFailIdentIdentRequestUpdateIdent
moClass: ident:IdentRequest
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys/IdentQ-[id]

fsmFailIdentMetaSystemSync

Fault Code: F999569

Message

[FSM:FAILED]: sam:dme:IdentMetaSystemSync

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999569
mibFaultName: fsmFailIdentMetaSystemSync
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys

fsmFailIdentMetaSystemUcscUnivSync

Fault Code: F999570

Message

[FSM:FAILED]: sam:dme:IdentMetaSystemUcscUnivSync

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999570
mibFaultName: fsmFailIdentMetaSystemUcscUnivSync
moClass: ident:MetaSystem
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: metaverse/metasys
```

fsmFailSmAppDelete

Fault Code: F999625

Message

[FSM:FAILED]: sam:dme:SmAppDelete

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999625
mibFaultName: fsmFailSmAppDelete
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]
```

fsmFailSmSecSvcRestoreApplication

Fault Code: F999626

Message

[FSM:FAILED]: sam:dme:SmSecSvcRestoreApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999626
mibFaultName: fsmFailSmSecSvcRestoreApplication
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc
```

fsmFailSmAppUpdateApplication

Fault Code: F999627

Message

[FSM:FAILED]: sam:dme:SmAppUpdateApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999627
mibFaultName: fsmFailSmAppUpdateApplication
moClass: sm:App
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/app- [name] - [version]
Affected MO: sys-secsvc/slot- [slotId] /app-inst- [appInstId] /app- [name] - [version]
```


fsmFailSmAppInstanceResetApplication

Fault Code: F999628

Message

[FSM:FAILED]: sam:dme:SmAppInstanceResetApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999628
mibFaultName: fsmFailSmAppInstanceResetApplication
moClass: sm:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc/slot-[slotId]/app-inst-[appName]
```

fsmFailSmSecSvcAutoDeployCSP

Fault Code: F999629

Message

[FSM:FAILED]: sam:dme:SmSecSvcAutoDeployCSP

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999629
mibFaultName: fsmFailSmSecSvcAutoDeployCSP
moClass: sm:SecSvc
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sec-svc
```

fsmFailSwAccessDomainDeploy

Fault Code: F999707

Message

[FSM:FAILED]: sam:dme:SwAccessDomainDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999707
mibFaultName: fsmFailSwAccessDomainDeploy
moClass: sw:AccessDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/access-eth
```

fsmFailSwEthLanBorderDeploy

Fault Code: F999708

Message

[FSM:FAILED]: sam:dme:SwEthLanBorderDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999708
mibFaultName: fsmFailSwEthLanBorderDeploy
moClass: sw:EthLanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-eth
```

fsmFailSwFcSanBorderDeploy

Fault Code: F999709

Message

[FSM:FAILED]: sam:dme:SwFcSanBorderDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999709
mibFaultName: fsmFailSwFcSanBorderDeploy
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc
```

fsmFailSwUtilityDomainDeploy

Fault Code: F999710

Message

[FSM:FAILED]: sam:dme:SwUtilityDomainDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999710
mibFaultName: fsmFailSwUtilityDomainDeploy
moClass: sw:UtilityDomain
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/utility-eth
```

fsmFailSwPhysConfPhysical

Fault Code: F999716

Message

[FSM:FAILED]: sam:dme:SwPhysConfPhysical

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999716
mibFaultName: fsmFailSwPhysConfPhysical
moClass: sw:Phys
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/phys
```

fsmFailSwExtUtilityConfPortBreakout

Fault Code: F999721

Message

[FSM:FAILED]: sam:dme:SwExtUtilityConfPortBreakout

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999721
mibFaultName: fsmFailSwExtUtilityConfPortBreakout
moClass: sw:ExtUtility
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ext
```

fsmFailSwFcSanBorderActivateZoneSet

Fault Code: F999722

Message

[FSM:FAILED]: sam:dme:SwFcSanBorderActivateZoneSet

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999722
mibFaultName: fsmFailSwFcSanBorderActivateZoneSet
moClass: sw:FcSanBorder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/border-fc
```

fsmFailCallhomeEpConfigCallhome

Fault Code: F999758

Message

[FSM:FAILED]: sam:dme:CallhomeEpConfigCallhome

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999758
mibFaultName: fsmFailCallhomeEpConfigCallhome
moClass: callhome:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: call-home
```

fsmFailAdaptorExtEthIfPathReset

Fault Code: F999767

Message

[FSM:FAILED]: sam:dme:AdaptorExtEthIfPathReset

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999767
mibFaultName: fsmFailAdaptorExtEthIfPathReset
moClass: adaptor:ExtEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/ext-eth- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/ext-eth- [id]
```

fsmFailAdaptorHostEthIfCircuitReset

Fault Code: F999770

Message

[FSM:FAILED]: sam:dme:AdaptorHostEthIfCircuitReset

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999770
mibFaultName: fsmFailAdaptorHostEthIfCircuitReset
moClass: adaptor:HostEthIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

fsmFailAdaptorHostFcIfCircuitReset

Fault Code: F99771

Message

[FSM:FAILED]: sam:dme:AdaptorHostFcIfCircuitReset

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999771
mibFaultName: fsmFailAdaptorHostFcIfCircuitReset
moClass: adaptor:HostFcIf
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]

fsmFailLicenseDownloaderDownload

Fault Code: F99788

Message

[FSM:FAILED]: sam:dme:LicenseDownloaderDownload

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999788
mibFaultName: fsmFailLicenseDownloaderDownload
moClass: license:Downloader

```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/dnld- [fileName]

```

fsmFailLicenseFileInstall

Fault Code: F999789

Message

[FSM:FAILED]: sam:dme:LicenseFileInstall

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999789
mibFaultName: fsmFailLicenseFileInstall
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file- [scope]: [id]

```

fsmFailLicenseFileClear

Fault Code: F999790

Message

[FSM:FAILED]: sam:dme:LicenseFileClear

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999790

```



```

mibFaultName: fsmFailLicenseFileClear
moClass: license:File
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/file-[scope]:[id]

```

fsmFailLicenseInstanceUpdateFlexIm

Fault Code: F999791

Message

[FSM:FAILED]: sam:dme:LicenseInstanceUpdateFlexIm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999791
mibFaultName: fsmFailLicenseInstanceUpdateFlexIm
moClass: license:Instance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

```

fsmFailLicenseSmartConfigSetConfig

Fault Code: F999792

Message

[FSM:FAILED]: sam:dme:LicenseSmartConfigSetConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical

```

```

Cause: fsm-failed
mibFaultCode: 999792
mibFaultName: fsmFailLicenseSmartConfigSetConfig
moClass: license:SmartConfig
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/license/license-config- [operation]

```

fsmFailLsServerConfigure

Fault Code: F999810

Message

[FSM:FAILED]: sam:dme:LsServerConfigure

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999810
mibFaultName: fsmFailLsServerConfigure
moClass: ls:Server
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name]/ls- [name]
Affected MO: org- [name]/tier- [name]/ls- [name]

```

fsmFailComputeBladeDiag

Fault Code: F999820

Message

[FSM:FAILED]: sam:dme:ComputeBladeDiag

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999820
mibFaultName: fsmFailComputeBladeDiag
moClass: compute:Blade
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId]

fsmFailMgmtControllerExtMgmtInterfaceConfig**Fault Code: F999843****Message**

[FSM:FAILED]: sam:dme:MgmtControllerExtMgmtInterfaceConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999843
mibFaultName: fsmFailMgmtControllerExtMgmtInterfaceConfig
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /blade- [slotId] /adaptor- [id] /mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /boardController/mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /boardController/mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /ext-board- [id] /mgmt
Affected MO: sys/chassis- [id] /blade- [slotId] /mgmt
Affected MO: sys/chassis- [id] /slot- [id] /mgmt
Affected MO: sys/chassis- [id] /sw-slot- [id] /mgmt
Affected MO: sys/fex- [id] /mgmt
Affected MO: sys/fex- [id] /slot- [id] /mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit- [id] /adaptor- [id] /mgmt
Affected MO: sys/rack-unit- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /boardController/mgmt
Affected MO: sys/rack-unit- [id] /ext-board- [id] /mgmt
Affected MO: sys/rack-unit- [id] /mgmt
Affected MO: sys/switch- [id] /mgmt

fsmFailComputePhysicalSwConnUpd

Fault Code: F999844

Message

[FSM:FAILED]: sam:dme:ComputePhysicalSwConnUpd

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999844
mibFaultName: fsmFailComputePhysicalSwConnUpd
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]
```

fsmFailEquipmentIOCardResetIom

Fault Code: F999845

Message

[FSM:FAILED]: sam:dme:EquipmentIOCardResetIom

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999845
mibFaultName: fsmFailEquipmentIOCardResetIom
moClass: equipment:IOCard
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
```

Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmFailComputePhysicalServiceInfraDeploy

Fault Code: F999846

Message

[FSM:FAILED]: sam:dme:ComputePhysicalServiceInfraDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999846
mibFaultName: fsmFailComputePhysicalServiceInfraDeploy
moClass: compute:Physical
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/rack-unit-[id]

fsmFailComputePhysicalServiceInfraWithdraw

Fault Code: F999847

Message

[FSM:FAILED]: sam:dme:ComputePhysicalServiceInfraWithdraw

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999847
mibFaultName: fsmFailComputePhysicalServiceInfraWithdraw
moClass: compute:Physical

```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]
Affected MO: sys/rack-unit- [id]

```

fsmFailEquipmentIOCardBaseFePresence

Fault Code: F999855

Message

[FSM:FAILED]: sam:dme:EquipmentIOCardBaseFePresence

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999855
mibFaultName: fsmFailEquipmentIOCardBaseFePresence
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/slot- [id]
Affected MO: sys/chassis- [id]/sw-slot- [id]
Affected MO: sys/fex- [id]/slot- [id]

```

fsmFailEquipmentIOCardBaseFeConn

Fault Code: F999856

Message

[FSM:FAILED]: sam:dme:EquipmentIOCardBaseFeConn

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999856
mibFaultName: fsmFailEquipmentIOCardBaseFeConn
moClass: equipment:IOCardBase
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fsmFailEquipmentChassisRemoveChassis

Fault Code: F999857

Message

[FSM:FAILED]: sam:dme:EquipmentChassisRemoveChassis

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 999857
mibFaultName: fsmFailEquipmentChassisRemoveChassis
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]

fsmFailEquipmentLocatorLedSetFeLocatorLed

Fault Code: F999858

Message

[FSM:FAILED]: sam:dme:EquipmentLocatorLedSetFeLocatorLed

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999858
mibFaultName: fsmFailEquipmentLocatorLedSetFeLocatorLed
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led

```

fsmFailEquipmentLocatorLedSetFiLocatorLed

Fault Code: F999859

Message

[FSM:FAILED]: sam:dme:EquipmentLocatorLedSetFiLocatorLed

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999859
mibFaultName: fsmFailEquipmentLocatorLedSetFiLocatorLed
moClass: equipment:LocatorLed
Type: fsm
Callhome: none
Auto Cleared: true

```



```

Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/locator-led
Affected MO: sys/chassis-[id]/blade-[slotId]/locator-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/chassis-[id]/locator-led
Affected MO: sys/chassis-[id]/psu-[id]/locator-led
Affected MO: sys/chassis-[id]/slot-[id]/locator-led
Affected MO: sys/fex-[id]/locator-led
Affected MO: sys/fex-[id]/psu-[id]/locator-led
Affected MO: sys/fex-[id]/slot-[id]/locator-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/locator-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/rack-unit-[id]/locator-led
Affected MO: sys/rack-unit-[id]/psu-[id]/locator-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/locator-led
Affected MO: sys/switch-[id]/locator-led
Affected MO: sys/switch-[id]/psu-[id]/locator-led

```

fsmFailPortPIoInCompatSfpPresence

Fault Code: F999862

Message

[FSM:FAILED]: sam:dme:PortPIoInCompatSfpPresence

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 999862
mibFaultName: fsmFailPortPIoInCompatSfpPresence
moClass: port:PIo
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

```

fsmFailPortPloInCompatSfpReplaced

Fault Code: F999863

Message

[FSM:FAILED]: sam:dme:PortPloInCompatSfpReplaced

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 999863
mibFaultName: fsmFailPortPloInCompatSfpReplaced
moClass: port:Plo
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/chassis- [id] /sw-slot- [id] / [type] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/fex- [id] /slot- [id] / [type] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /aggr-port- [aggrPortId] /port- [portId]
Affected MO: sys/switch- [id] /slot- [id] / [type] /port- [portId]
```

fsmFailObserveObservedResolvePolicyFsm

Fault Code: F1000103

Message

[FSM:FAILED]: sam:dme:ObserveObservedResolvePolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000103
```

```

mibFaultName: fsmFailObserveObservedResolvePolicyFsm
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmFailObserveObservedResolveResourceFsm

Fault Code: F1000104

Message

[FSM:FAILED]: sam:dme:ObserveObservedResolveResourceFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000104
mibFaultName: fsmFailObserveObservedResolveResourceFsm
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmFailObserveObservedResolveVMFsm

Fault Code: F1000105

Message

[FSM:FAILED]: sam:dme:ObserveObservedResolveVMFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000105
mibFaultName: fsmFailObserveObservedResolveVMFsm
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmFailObserveObservedResolveControllerFsm

Fault Code: F1000106

Message

[FSM:FAILED]: sam:dme:ObserveObservedResolveControllerFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000106
mibFaultName: fsmFailObserveObservedResolveControllerFsm
moClass: observe:Observed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/clients/client-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/controllers/contro-[id]/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/observed-[dataSrcSysId]-[id]
Affected MO: extpol/reg/providers/prov-[type]/observed-[dataSrcSysId]-[id]
Affected MO: observe/observed-[dataSrcSysId]-[id]

```

fsmFailEquipmentBeaconLedIlluminate

Fault Code: F1000189

Message

[FSM:FAILED]: sam:dme:EquipmentBeaconLedIlluminate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000189
mibFaultName: fsmFailEquipmentBeaconLedIlluminate
moClass: equipment:BeaconLed
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/beacon
Affected MO: sys/chassis-[id]/blade-[slotId]/beacon
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/chassis-[id]/psu-[id]/beacon
Affected MO: sys/chassis-[id]/slot-[id]/beacon
Affected MO: sys/fex-[id]/beacon
Affected MO: sys/fex-[id]/psu-[id]/beacon
Affected MO: sys/fex-[id]/slot-[id]/beacon
Affected MO: sys/rack-unit-[id]/beacon
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/rack-unit-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/beacon
Affected MO: sys/switch-[id]/psu-[id]/beacon
Affected MO: sys/switch-[id]/slot-[id]/beacon
```

fsmFailSdAppInstanceInstallApplication

Fault Code: F1000191

Message

[FSM:FAILED]: sam:dme:SdAppInstanceInstallApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000191
mibFaultName: fsmFailSdAppInstanceInstallApplication
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

fsmFailSdAppInstanceStartApplication

Fault Code: F1000192

Message

[FSM:FAILED]: sam:dme:SdAppInstanceStartApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000192
mibFaultName: fsmFailSdAppInstanceStartApplication
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]

fsmFailSdLduProvisionLDU

Fault Code: F1000193

Message

[FSM:FAILED]: sam:dme:SdLduProvisionLDU

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000193
mibFaultName: fsmFailSdLduProvisionLDU
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]
```

fsmFailSdAppInstanceUpgradeApplication

Fault Code: F1000194

Message

[FSM:FAILED]: sam:dme:SdAppInstanceUpgradeApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000194
mibFaultName: fsmFailSdAppInstanceUpgradeApplication
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmFailSdAppInstanceStopApplication

Fault Code: F1000195

Message

[FSM:FAILED]: sam:dme:SdAppInstanceStopApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000195
mibFaultName: fsmFailSdAppInstanceStopApplication
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```

fsmFailSdAppInstanceUninstallApplication

Fault Code: F1000196

Message

[FSM:FAILED]: sam:dme:SdAppInstanceUninstallApplication

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000196
mibFaultName: fsmFailSdAppInstanceUninstallApplication
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]
```


fsmFailSdSlotChangePlatformLogLevel

Fault Code: F1000197

Message

[FSM:FAILED]: sam:dme:SdSlotChangePlatformLogLevel

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000197
mibFaultName: fsmFailSdSlotChangePlatformLogLevel
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]
```

fsmFailSdAppInstanceBundleDataPorts

Fault Code: F1000198

Message

[FSM:FAILED]: sam:dme:SdAppInstanceBundleDataPorts

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000198
mibFaultName: fsmFailSdAppInstanceBundleDataPorts
moClass: sd:AppInstance
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]
```

fsmFailSdLogicalDeviceConfigureLinks

Fault Code: F1000199

Message

[FSM:FAILED]: sam:dme:SdLogicalDeviceConfigureLinks

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000199
mibFaultName: fsmFailSdLogicalDeviceConfigureLinks
moClass: sd:LogicalDevice
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]
```

fsmFailSdLinkUpdateInterfaceStatus

Fault Code: F1000200

Message

[FSM:FAILED]: sam:dme:SdLinkUpdateInterfaceStatus

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000200
mibFaultName: fsmFailSdLinkUpdateInterfaceStatus
moClass: sd:Link
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
```

Affected MO:
 sys-secsvc/ld- [name]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]/ext-ldulink- [name] - [appInstId]
Affected MO:
 sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]/app-ldulink- [name] - [endpoint1AppInstId] - [endpoint2AppInstId]
Affected MO:
 sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]/ext-ldulink- [name] - [appInstId]

fsmFailSdClusterBootstrapUpdateClusterConfiguration

Fault Code: F1000201

Message

[FSM:FAILED]: sam:dme:SdClusterBootstrapUpdateClusterConfiguration

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000201
mibFaultName: fsmFailSdClusterBootstrapUpdateClusterConfiguration
moClass: sd:ClusterBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/cluster-bootstrap
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/cluster-bootstrap

fsmFailSdSlotFormatDisk

Fault Code: F1000202

Message

[FSM:FAILED]: sam:dme:SdSlotFormatDisk

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000202
mibFaultName: fsmFailSdSlotFormatDisk
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

fsmFailSdSlotSynchTimeZone

Fault Code: F1000203

Message

[FSM:FAILED]: sam:dme:SdSlotSynchTimeZone

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000203
mibFaultName: fsmFailSdSlotSynchTimeZone
moClass: sd:Slot
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]

fsmFailSdAppAttributeCtrlGetAppAttributes

Fault Code: F1000204

Message

[FSM:FAILED]: sam:dme:SdAppAttributeCtrlGetAppAttributes

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000204
mibFaultName: fsmFailSdAppAttributeCtrlGetAppAttributes
moClass: sd:AppAttributeCtrl
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/app-attribute-ctrl
```

fsmFailSdMgmtInfoUpdateMgmtInfo

Fault Code: F1000205

Message

[FSM:FAILED]: sam:dme:SdMgmtInfoUpdateMgmtInfo

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000205
mibFaultName: fsmFailSdMgmtInfoUpdateMgmtInfo
moClass: sd:MgmtInfo
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/mgmt-info
```

fsmFailSdNetMgmtBootstrapUpdateNetMgmtBootstrap

Fault Code: F1000206

Message

[FSM:FAILED]: sam:dme:SdNetMgmtBootstrapUpdateNetMgmtBootstrap

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000206
mibFaultName: fsmFailSdNetMgmtBootstrapUpdateNetMgmtBootstrap
moClass: sd:NetMgmtBootstrap
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/net-mgmt-bootstrap
```

fsmFailSdUpgradeTaskStopUpgradeStartApp

Fault Code: F1000207

Message

[FSM:FAILED]: sam:dme:SdUpgradeTaskStopUpgradeStartApp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000207
mibFaultName: fsmFailSdUpgradeTaskStopUpgradeStartApp
moClass: sd:UpgradeTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/slot-[slotId]/app-inst-[appInstId]/upgrade-task
```

fsmFailEtherServerIntFioConfigSpeed

Fault Code: F1000209

Message

[FSM:FAILED]: sam:dme:EtherServerIntFioConfigSpeed

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000209
mibFaultName: fsmFailEtherServerIntFioConfigSpeed
moClass: ether:ServerIntFio
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/rack-unit-[id]/diag/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fsmFailEtherFtwPortPairConfigFtw

Fault Code: F1000210

Message

[FSM:FAILED]: sam:dme:EtherFtwPortPairConfigFtw

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000210
mibFaultName: fsmFailEtherFtwPortPairConfigFtw
moClass: ether:FtwPortPair
```

```

Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/switch- [id] /fail-to-wire/ftw-port- [slotId] - [aggrPortId] - [portId] -port- [peerSlotId]
- [peerAggrPortId] - [peerPortId]

```

fsmFailExtpolEpRegisterFsm

Fault Code: F1000225

Message

[FSM:FAILED]: sam:dme:ExtpolEpRegisterFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000225
mibFaultName: fsmFailExtpolEpRegisterFsm
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol

```

fsmFailExtpolRegistryCrossDomainConfig

Fault Code: F1000226

Message

[FSM:FAILED]: sam:dme:ExtpolRegistryCrossDomainConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical

```



```

Cause: fsm-failed
mibFaultCode: 1000226
mibFaultName: fsmFailExtpolRegistryCrossDomainConfig
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmFailExtpolRegistryCrossDomainDelete

Fault Code: F1000227

Message

[FSM:FAILED]: sam:dme:ExtpolRegistryCrossDomainDelete

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000227
mibFaultName: fsmFailExtpolRegistryCrossDomainDelete
moClass: extpol:Registry
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg

```

fsmFailStorageSystemSync

Fault Code: F1000264

Message

[FSM:FAILED]: sam:dme:StorageSystemSync

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000264
mibFaultName: fsmFailStorageSystemSync
moClass: storage:System
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: storage-ep/system

fsmFailSysfileMutationSingle

Fault Code: F1000266

Message

[FSM:FAILED]: sam:dme:SysfileMutationSingle

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000266
mibFaultName: fsmFailSysfileMutationSingle
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation

fsmFailSysfileMutationGlobal

Fault Code: F1000267

Message

[FSM:FAILED]: sam:dme:SysfileMutationGlobal

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000267
mibFaultName: fsmFailSysfileMutationGlobal
moClass: sysfile:Mutation
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file-[name] | [switchId]/mutation
Affected MO: sys/corefiles/mutation
```

fsmFailApplicationDownloaderDownload

Fault Code: F1000271

Message

[FSM:FAILED]: sam:dme:ApplicationDownloaderDownload

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000271
mibFaultName: fsmFailApplicationDownloaderDownload
moClass: application:Downloader
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/app-catalogue/dnld-[fileName]
```

fsmFailCommSvcEpUpdateSvcEp

Fault Code: F1000272

Message

[FSM:FAILED]: sam:dme:CommSvcEpUpdateSvcEp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000272
mibFaultName: fsmFailCommSvcEpUpdateSvcEp
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmFailCommSvcEpRestartWebSvc**Fault Code: F1000273****Message**

[FSM:FAILED]: sam:dme:CommSvcEpRestartWebSvc

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000273
mibFaultName: fsmFailCommSvcEpRestartWebSvc
moClass: comm:SvcEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/svc-ext
```

fsmFailPkiEpUpdateEp

Fault Code: F1000291

Message

[FSM:FAILED]: sam:dme:PkiEpUpdateEp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000291
mibFaultName: fsmFailPkiEpUpdateEp
moClass: pki:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/pki-ext
```

fsmFailAaaEpUpdateEp

Fault Code: F1000292

Message

[FSM:FAILED]: sam:dme:AaaEpUpdateEp

Explanation

Cisco FPR Manager could not set the configurations for AAA servers.

Recommended Action

Check the error for the failed FSM stage and take the recommended action for that stage.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000292
mibFaultName: fsmFailAaaEpUpdateEp
moClass: aaa:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ldap-ext
Affected MO: sys/radius-ext
Affected MO: sys/tacacs-ext
```

fsmFailAaaRealmUpdateRealm

Fault Code: F1000293

Message

[FSM:FAILED]: sam:dme:AaaRealmUpdateRealm

Explanation

Cisco FPR Manager could not set the configurations for Authentication Realm.

Recommended Action

Check the error for the failed FSM stage and take the recommended action for that stage.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000293
mibFaultName: fsmFailAaaRealmUpdateRealm
moClass: aaa:Realm
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/auth-realm
```

fsmFailAaaUserEpUpdateUserEp

Fault Code: F1000294

Message

[FSM:FAILED]: sam:dme:AaaUserEpUpdateUserEp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000294
mibFaultName: fsmFailAaaUserEpUpdateUserEp
moClass: aaa:UserEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/user-ext
```

fsmFailSysdebugManualCoreFileExportTargetExport

Fault Code: F1000305

Message

[FSM:FAILED]: sam:dme:SysdebugManualCoreFileExportTargetExport

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000305
mibFaultName: fsmFailSysdebugManualCoreFileExportTargetExport
moClass: sysdebug:ManualCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file-[name] | [switchId]/export-to-[hostname]
```

fsmFailSysdebugLogExportPolicyConfigure

Fault Code: F1000306

Message

[FSM:FAILED]: sam:dme:SysdebugLogExportPolicyConfigure

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000306
mibFaultName: fsmFailSysdebugLogExportPolicyConfigure
moClass: sysdebug:LogExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/log-export-policy
```

fsmFailSysdebugAutoCoreFileExportTargetConfigure

Fault Code: F1000307

Message

[FSM:FAILED]: sam:dme:SysdebugAutoCoreFileExportTargetConfigure

Explanation

Cisco Firepower Manager could not set the configurations for auto core transfer to remote TFTP server.

Recommended Action

Check the error for the failed FSM stage and take the recommended action for that stage.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000307
mibFaultName: fsmFailSysdebugAutoCoreFileExportTargetConfigure
moClass: sysdebug:AutoCoreFileExportTarget
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/file-export
```

fsmFailSysdebugTechSupportInitiate

Fault Code: F1000308

Message

[FSM:FAILED]: sam:dme:SysdebugTechSupportInitiate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000308
mibFaultName: fsmFailSysdebugTechSupportInitiate
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support-[creationTS]
```


fsmFailSysdebugTechSupportDeleteTechSupFile

Fault Code: F1000309

Message

[FSM:FAILED]: sam:dme:SysdebugTechSupportDeleteTechSupFile

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000309
mibFaultName: fsmFailSysdebugTechSupportDeleteTechSupFile
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support- [creationTS]
```

fsmFailSysdebugTechSupportDownload

Fault Code: F1000310

Message

[FSM:FAILED]: sam:dme:SysdebugTechSupportDownload

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000310
mibFaultName: fsmFailSysdebugTechSupportDownload
moClass: sysdebug:TechSupport
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tech-support-files/tech-support- [creationTS]
```

fsmFailSysdebugCoreDownload

Fault Code: F1000311

Message

[FSM:FAILED]: sam:dme:SysdebugCoreDownload

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000311
mibFaultName: fsmFailSysdebugCoreDownload
moClass: sysdebug:Core
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/corefiles/file- [name] | [switchId]
```

fsmFailSysdebugLogControlEpLogControlPersist

Fault Code: F1000312

Message

[FSM:FAILED]: sam:dme:SysdebugLogControlEpLogControlPersist

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000312
mibFaultName: fsmFailSysdebugLogControlEpLogControlPersist
moClass: sysdebug:LogControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/sysdebug/logcontrol
```

fsmFailEpqosDefinitionDeploy

Fault Code: F1000376

Message

[FSM:FAILED]: sam:dme:EpqosDefinitionDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000376
mibFaultName: fsmFailEpqosDefinitionDeploy
moClass: epqos:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos- [name]
```

fsmFailEpqosDefinitionDelTaskRemove

Fault Code: F1000377

Message

[FSM:FAILED]: sam:dme:EpqosDefinitionDelTaskRemove

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000377
mibFaultName: fsmFailEpqosDefinitionDelTaskRemove
moClass: epqos:DefinitionDelTask
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /ep-qos-deletion- [defIntId]
```

fsmFailQosclassDefinitionConfigGlobalQoS

Fault Code: F1000380

Message

[FSM:FAILED]: sam:dme:QosclassDefinitionConfigGlobalQoS

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000380
mibFaultName: fsmFailQosclassDefinitionConfigGlobalQoS
moClass: qosclass:Definition
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan/classes
```

fsmFailMgmtControllerRegistryConfig

Fault Code: F1000387

Message

[FSM:FAILED]: sam:dme:MgmtControllerRegistryConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000387
mibFaultName: fsmFailMgmtControllerRegistryConfig
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
```

```

Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmFailMgmtIfSwMgmtOobIfConfig

Fault Code: F1000398

Message

[FSM:FAILED]: sam:dme:MgmtIfSwMgmtOobIfConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000398
mibFaultName: fsmFailMgmtIfSwMgmtOobIfConfig
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]

```

Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmFailMgmtIfSwMgmtInbandIfConfig

Fault Code: F1000399

Message

[FSM:FAILED]: sam:dme:MgmtIfSwMgmtInbandIfConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000399
mibFaultName: fsmFailMgmtIfSwMgmtInbandIfConfig
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmFailMgmtIPv6IfAddrSwMgmtOobIPv6IfConfig

Fault Code: F1000400

Message

[FSM:FAILED]: sam:dme:MgmtIPv6IfAddrSwMgmtOobIPv6IfConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000400
mibFaultName: fsmFailMgmtIPv6IfAddrSwMgmtOobIPv6IfConfig
moClass: mgmt:IPv6IfAddr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/ifConfig-ipv6/if-ipv6
Affected MO: sys/switch-[id]/mgmt/if-[id]/ifConfig-ipv6/if-ipv6

```

fsmFailNhTableHolderConfigureLinks

Fault Code: F1000413

Message

[FSM:FAILED]: sam:dme:NhTableHolderConfigureLinks

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000413
mibFaultName: fsmFailNhTableHolderConfigureLinks
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmFailNhTableHolderBootstrapLinks

Fault Code: F1000414

Message

[FSM:FAILED]: sam:dme:NhTableHolderBootstrapLinks

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000414
mibFaultName: fsmFailNhTableHolderBootstrapLinks
moClass: nh:TableHolder
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/tbh
```

fsmFailStatsCollectionPolicyUpdateEp

Fault Code: F1000418

Message

[FSM:FAILED]: sam:dme:StatsCollectionPolicyUpdateEp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000418
mibFaultName: fsmFailStatsCollectionPolicyUpdateEp
moClass: stats:CollectionPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: stats/coll-policy- [name]
```

fsmFailSyntheticFsObjCreate

Fault Code: F1000443

Message

[FSM:FAILED]: sam:dme:SyntheticFsObjCreate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000443
mibFaultName: fsmFailSyntheticFsObjCreate
moClass: synthetic:FsoObj
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/file- [name]
```

fsmFailCapabilityUpdaterUpdater

Fault Code: F1000448

Message

[FSM:FAILED]: sam:dme:CapabilityUpdaterUpdater

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000448
mibFaultName: fsmFailCapabilityUpdaterUpdater
moClass: capability:Updater
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/updater-[fileName]
```

fsmFailCapabilityCatalogueActivateCatalog

Fault Code: F1000449

Message

[FSM:FAILED]: sam:dme:CapabilityCatalogueActivateCatalog

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000449
mibFaultName: fsmFailCapabilityCatalogueActivateCatalog
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fsmFailCapabilityMgmtExtensionActivateMgmtExt

Fault Code: F1000450

Message

[FSM:FAILED]: sam:dme:CapabilityMgmtExtensionActivateMgmtExt

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000450
mibFaultName: fsmFailCapabilityMgmtExtensionActivateMgmtExt
moClass: capability:MgmtExtension
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities/ep/mgmt-ext
```

fsmFailCapabilityCatalogueDeployCatalogue

Fault Code: F1000451

Message

[FSM:FAILED]: sam:dme:CapabilityCatalogueDeployCatalogue

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000451
mibFaultName: fsmFailCapabilityCatalogueDeployCatalogue
moClass: capability:Catalogue
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: capabilities
```

fsmFailSwEthMonDeploy

Fault Code: F1000460

Message

[FSM:FAILED]: sam:dme:SwEthMonDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000460
mibFaultName: fsmFailSwEthMonDeploy
moClass: sw:EthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]
```

fsmFailSwSspEthMonDeploy

Fault Code: F1000509

Message

[FSM:FAILED]: sam:dme:SwSspEthMonDeploy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000509
mibFaultName: fsmFailSwSspEthMonDeploy
moClass: sw:SspEthMon
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/ssp-lanmon-eth/ssp-mon-session[name]
```

fsmFailSwSspEthMonSrcPhyEpDelete

Fault Code: F1000510

Message

[FSM:FAILED]: sam:dme:SwSspEthMonSrcPhyEpDelete

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000510
mibFaultName: fsmFailSwSspEthMonSrcPhyEpDelete
moClass: sw:SspEthMonSrcPhyEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
sys/switch- [id]/ssp-lanmon-eth/ssp-mon-session[name]/ssp-mon-src-phy- [chassisId]-slot-
[slotId]-port- [portId]-aggr- [aggrPortId]
```

fsmFailFabricVnetEpSyncEpPushVnetEpDeletion

Fault Code: F1000516

Message

[FSM:FAILED]: sam:dme:FabricVnetEpSyncEpPushVnetEpDeletion

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000516
mibFaultName: fsmFailFabricVnetEpSyncEpPushVnetEpDeletion
moClass: fabric:VnetEpSyncEp
Type: fsm
Callhome: none
Auto Cleared: true
```

```
Is Implemented: true
Affected MO: extpol/reg/providers/prov-[type]/syncEp
```

fsmFailFabricLanCloudSwitchMode

Fault Code: F1000517

Message

[FSM:FAILED]: sam:dme:FabricLanCloudSwitchMode

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000517
mibFaultName: fsmFailFabricLanCloudSwitchMode
moClass: fabric:LanCloud
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/lan
```

fsmFailFabricSanCloudSwitchMode

Fault Code: F1000518

Message

[FSM:FAILED]: sam:dme:FabricSanCloudSwitchMode

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000518
mibFaultName: fsmFailFabricSanCloudSwitchMode
moClass: fabric:SanCloud
Type: fsm
```

```

Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/san

```

fsmFailFabricEpMgrConfigure

Fault Code: F1000524

Message

[FSM:FAILED]: sam:dme:FabricEpMgrConfigure

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000524
mibFaultName: fsmFailFabricEpMgrConfigure
moClass: fabric:EpMgr
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: fabric/[id]

```

fsmFailMgmtExportPolicyReportConfigCopy

Fault Code: F1000530

Message

[FSM:FAILED]: sam:dme:MgmtExportPolicyReportConfigCopy

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000530
mibFaultName: fsmFailMgmtExportPolicyReportConfigCopy

```

```

moClass: mgmt:ExportPolicy
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: org- [name] /cfg-exp-policy- [name]
Affected MO: org- [name] /db-backup-policy- [name]

```

fsmFailExtpolProviderReportConfigImport

Fault Code: F1000531

Message

[FSM:FAILED]: sam:dme:ExtpolProviderReportConfigImport

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000531
mibFaultName: fsmFailExtpolProviderReportConfigImport
moClass: extpol:Provider
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol/reg/providers/prov- [type]

```

fsmFailMgmtIfVirtualIfConfig

Fault Code: F1000532

Message

[FSM:FAILED]: sam:dme:MgmtIfVirtualIfConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical

```



```

Cause: fsm-failed
mibFaultCode: 1000532
mibFaultName: fsmFailMgmtIfVirtualIfConfig
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmFailMgmtIfEnableVip

Fault Code: F1000533

Message

[FSM:FAILED]: sam:dme:MgmtIfEnableVip

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000533
mibFaultName: fsmFailMgmtIfEnableVip
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]

```

```

Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fsmFailMgmtIfDisableVip

Fault Code: F1000534

Message

[FSM:FAILED]: sam:dme:MgmtIfDisableVip

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000534
mibFaultName: fsmFailMgmtIfDisableVip
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]

```

Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmFailMgmtIfEnableHA

Fault Code: F1000535

Message

[FSM:FAILED]: sam:dme:MgmtIfEnableHA

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000535
mibFaultName: fsmFailMgmtIfEnableHA
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fsmFailMgmtBackupBackup

Fault Code: F1000536

Message

[FSM:FAILED]: sam:dme:MgmtBackupBackup

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000536
mibFaultName: fsmFailMgmtBackupBackup
moClass: mgmt:Backup
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/backup- [hostname]
```

fsmFailMgmtImporterImport**Fault Code: F1000537****Message**

[FSM:FAILED]: sam:dme:MgmtImporterImport

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000537
mibFaultName: fsmFailMgmtImporterImport
moClass: mgmt:Importer
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/import-config- [hostname]
```

fsmFailMgmtControllerSysConfig

Fault Code: F1000538

Message

[FSM:FAILED]: sam:dme:MgmtControllerSysConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000538
mibFaultName: fsmFailMgmtControllerSysConfig
moClass: mgmt:Controller
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

```

fsmFailNfsMountInstMount

Fault Code: F1000571

Message

[FSM:FAILED]: sam:dme:NfsMountInstMount

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000571
mibFaultName: fsmFailNfsMountInstMount
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmFailNfsMountInstUnmount

Fault Code: F1000572

Message

[FSM:FAILED]: sam:dme:NfsMountInstUnmount

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000572
mibFaultName: fsmFailNfsMountInstUnmount
moClass: nfs:MountInst
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch-[id]/nfs-mount-inst-[name]
```

fsmFailNfsMountDefReportNfsMountSuspend

Fault Code: F1000573

Message

[FSM:FAILED]: sam:dme:NfsMountDefReportNfsMountSuspend

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000573
mibFaultName: fsmFailNfsMountDefReportNfsMountSuspend
moClass: nfs:MountDef
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: nfs-ep/nfs-mount-def- [name]
```

fsmFailExtpolEpRepairCert

Fault Code: F1000594

Message

[FSM:FAILED]: sam:dme:ExtpolEpRepairCert

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000594
mibFaultName: fsmFailExtpolEpRepairCert
moClass: extpol:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: extpol
```

fsmFailPolicyControlEpOperate

Fault Code: F1000595

Message

[FSM:FAILED]: sam:dme:PolicyControlEpOperate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000595
mibFaultName: fsmFailPolicyControlEpOperate
moClass: policy:ControlEp
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]
```

fsmFailPolicyControlledTypeOperate

Fault Code: F1000596

Message

[FSM:FAILED]: sam:dme:PolicyControlledTypeOperate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000596
mibFaultName: fsmFailPolicyControlledTypeOperate
moClass: policy:ControlledType
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/control-ep- [type]/cfg-backup-ctrl/ctrlled-type- [type]
```



```

Affected MO: sys/control-ep- [type]/comm-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/datetime-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/discovery-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/dns-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/fabric-fw-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/fault-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/mep-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/monitoring-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/powermgmt-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/psu-ctrl/ctrlled-type- [type]
Affected MO: sys/control-ep- [type]/security-ctrl/ctrlled-type- [type]

```

fsmFailPolicyPolicyScopeReleasePolicyFsm

Fault Code: F1000599

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleasePolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000599
mibFaultName: fsmFailPolicyPolicyScopeReleasePolicyFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client- [id]/scope-cont- [appType]/context- [name]/scope- [policyType] -
[resolveType] - [policyName]
Affected MO:
extpol/reg/controllers/contro- [id]/scope-cont- [appType]/context- [name]/scope- [policyType]
pe] - [resolveType] - [policyName]
Affected MO:
extpol/reg/providers/prov- [type]/scope-cont- [appType]/context- [name]/scope- [policyType]
] - [resolveType] - [policyName]
Affected MO:
extpol/reg/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [polic
yName]
Affected MO:
policy-ep/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [polic
yName]

```

fsmFailPolicyPolicyScopeReleaseOperationFsm

Fault Code: F1000600

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseOperationFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000600
mibFaultName: fsmFailPolicyPolicyScopeReleaseOperationFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmFailPolicyPolicyScopeReleaseStorageFsm

Fault Code: F1000601

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseStorageFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000601
mibFaultName: fsmFailPolicyPolicyScopeReleaseStorageFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client- [id]/scope-cont- [appType]/context- [name]/scope- [policyType] -
[resolveType] - [policyName]
Affected MO:
extpol/reg/controllers/contro- [id]/scope-cont- [appType]/context- [name]/scope- [policyTy
pe] - [resolveType] - [policyName]
Affected MO:
extpol/reg/providers/prov- [type]/scope-cont- [appType]/context- [name]/scope- [policyType
] - [resolveType] - [policyName]
Affected MO:
extpol/reg/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [polic
yName]
Affected MO:
policy-ep/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [policy
Name]

```

fsmFailPolicyPolicyScopeResolveManyPolicyFsm

Fault Code: F1000602

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveManyPolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000602
mibFaultName: fsmFailPolicyPolicyScopeResolveManyPolicyFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true

```

Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeResolveManyOperationFsm

Fault Code: F1000603

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveManyOperationFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000603
mibFaultName: fsmFailPolicyPolicyScopeResolveManyOperationFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeResolveManyStorageFsm

Fault Code: F1000604

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveManyStorageFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000604
mibFaultName: fsmFailPolicyPolicyScopeResolveManyStorageFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
  extpol/reg/clients/client- [id]/scope-cont- [appType]/context- [name]/scope- [policyType] -
  [resolveType] - [policyName]
Affected MO:
  extpol/reg/controllers/contro- [id]/scope-cont- [appType]/context- [name]/scope- [policyTy
  pe] - [resolveType] - [policyName]
Affected MO:
  extpol/reg/providers/prov- [type]/scope-cont- [appType]/context- [name]/scope- [policyType
  ] - [resolveType] - [policyName]
Affected MO:
  extpol/reg/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [poli
  cyName]
Affected MO:
  policy-ep/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [policy
  Name]

```

fsmFailPolicyPolicyScopeReleaseManyPolicyFsm

Fault Code: F1000605

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseManyPolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000605
mibFaultName: fsmFailPolicyPolicyScopeReleaseManyPolicyFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmFailPolicyPolicyScopeReleaseManyOperationFsm

Fault Code: F1000606

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseManyOperationFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000606
mibFaultName: fsmFailPolicyPolicyScopeReleaseManyOperationFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true

```

Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeReleaseManyStorageFsm

Fault Code: F1000607

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseManyStorageFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000607
mibFaultName: fsmFailPolicyPolicyScopeReleaseManyStorageFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]
Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeResolveAllPolicyFsm

Fault Code: F1000608

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveAllPolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000608
mibFaultName: fsmFailPolicyPolicyScopeResolveAllPolicyFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmFailPolicyPolicyScopeResolveAllOperationFsm

Fault Code: F1000609

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveAllOperationFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000609
mibFaultName: fsmFailPolicyPolicyScopeResolveAllOperationFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client- [id]/scope-cont- [appType]/context- [name]/scope- [policyType] -
[resolveType] - [policyName]
Affected MO:
extpol/reg/controllers/contro- [id]/scope-cont- [appType]/context- [name]/scope- [policyTy
pe] - [resolveType] - [policyName]
Affected MO:
extpol/reg/providers/prov- [type]/scope-cont- [appType]/context- [name]/scope- [policyType
] - [resolveType] - [policyName]
Affected MO:
extpol/reg/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [polic
yName]
Affected MO:
policy-ep/scope-cont- [appType]/context- [name]/scope- [policyType] - [resolveType] - [policy
Name]

```

fsmFailPolicyPolicyScopeResolveAllStorageFsm

Fault Code: F1000610

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeResolveAllStorageFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000610
mibFaultName: fsmFailPolicyPolicyScopeResolveAllStorageFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true

```

Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeReleaseAllPolicyFsm

Fault Code: F1000611

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseAllPolicyFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000611
mibFaultName: fsmFailPolicyPolicyScopeReleaseAllPolicyFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true

Affected MO:
 extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

Affected MO:
 policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policyName]

fsmFailPolicyPolicyScopeReleaseAllOperationFsm

Fault Code: F1000612

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseAllOperationFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000612
mibFaultName: fsmFailPolicyPolicyScopeReleaseAllOperationFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
  extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
  [resolveType]-[policyName]
Affected MO:
  extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
  pe]-[resolveType]-[policyName]
Affected MO:
  extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
  ]-[resolveType]-[policyName]
Affected MO:
  extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
  yName]
Affected MO:
  policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
  Name]

```

fsmFailPolicyPolicyScopeReleaseAllStorageFsm

Fault Code: F1000613

Message

[FSM:FAILED]: sam:dme:PolicyPolicyScopeReleaseAllStorageFsm

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000613
mibFaultName: fsmFailPolicyPolicyScopeReleaseAllStorageFsm
moClass: policy:PolicyScope
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO:
extpol/reg/clients/client-[id]/scope-cont-[appType]/context-[name]/scope-[policyType]-
[resolveType]-[policyName]
Affected MO:
extpol/reg/controllers/contro-[id]/scope-cont-[appType]/context-[name]/scope-[policyTy
pe]-[resolveType]-[policyName]
Affected MO:
extpol/reg/providers/prov-[type]/scope-cont-[appType]/context-[name]/scope-[policyType
]-[resolveType]-[policyName]
Affected MO:
extpol/reg/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[polic
yName]
Affected MO:
policy-ep/scope-cont-[appType]/context-[name]/scope-[policyType]-[resolveType]-[policy
Name]

```

fsmFailFirmwareInfraPackInfraVersion

Fault Code: F1000730

Message

[FSM:FAILED]: sam:dme:FirmwareInfraPackInfraVersion

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000730
mibFaultName: fsmFailFirmwareInfraPackInfraVersion
moClass: firmware:InfraPack
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true

```

Affected MO: org-[name]/fw-infra-pack-[name]

fsmFailFirmwareValidationStatusValidate

Fault Code: F1000740

Message

[FSM:FAILED]: sam:dme:FirmwareValidationStatusValidate

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000740
mibFaultName: fsmFailFirmwareValidationStatusValidate
moClass: firmware:ValidationStatus
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/fw-catalogue/distrib-[name]/validation

fsmFailSdLogicalDeviceConfigureUserMacs

Fault Code: F1000751

Message

[FSM:FAILED]: sam:dme:SdLogicalDeviceConfigureUserMacs

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000751
mibFaultName: fsmFailSdLogicalDeviceConfigureUserMacs
moClass: sd:LogicalDevice
Type: fsm
Callhome: none

Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]

fsmFailMgmtIfSwMgmtOobIfDhcpConfig

Fault Code: F1000755

Message

[FSM:FAILED]: sam:dme:MgmtIfSwMgmtOobIfDhcpConfig

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

Severity: critical
Cause: fsm-failed
mibFaultCode: 1000755
mibFaultName: fsmFailMgmtIfSwMgmtOobIfDhcpConfig
moClass: mgmt:If
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/blade- [slotId]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/chassis- [id]/sw-slot- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/mgmt/if- [id]
Affected MO: sys/fex- [id]/slot- [id]/mgmt/if- [id]
Affected MO: sys/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/host-eth- [id]/if- [id]
Affected MO: sys/rack-unit- [id]/adaptor- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/boardController/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/ext-board- [id]/mgmt/if- [id]
Affected MO: sys/rack-unit- [id]/mgmt/if- [id]
Affected MO: sys/switch- [id]/mgmt/if- [id]

fsmFailSdLduUpdateInterfaceStatus

Fault Code: F1000758

Message

[FSM:FAILED]: sam:dme:SdLduUpdateInterfaceStatus

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000758
mibFaultName: fsmFailSdLduUpdateInterfaceStatus
moClass: sd:Ldu
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys-secsvc/ld- [name]/ldu- [slotId]
Affected MO: sys-secsvc/slot- [slotId]/app-inst- [appInstId]/ldu- [slotId]
```

fsmFailEquipmentChassisShutdownChassis

Fault Code: F1000764

Message

[FSM:FAILED]: sam:dme:EquipmentChassisShutdownChassis

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000764
mibFaultName: fsmFailEquipmentChassisShutdownChassis
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis- [id]
```

fsmFailEquipmentChassisRebootChassis

Fault Code: F1000765

Message

[FSM:FAILED]: sam:dme:EquipmentChassisRebootChassis

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000765
mibFaultName: fsmFailEquipmentChassisRebootChassis
moClass: equipment:Chassis
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/chassis-[id]
```

fsmFailIpsecEpUpdateEp

Fault Code: F1000770

Message

[FSM:FAILED]: sam:dme:IpsecEpUpdateEp

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000770
mibFaultName: fsmFailIpsecEpUpdateEp
moClass: ipsec:Ep
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/ipsec-ext
```


fsmFailNetworkEthLanMgmtUpdateInterfaceStatus

Fault Code: F1000783

Message

[FSM:FAILED]: sam:dme:NetworkEthLanMgmtUpdateInterfaceStatus

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000783
mibFaultName: fsmFailNetworkEthLanMgmtUpdateInterfaceStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /mgmt-port- [portId]
```

fsmFailNetworkEthLanMgmtUpdateMgmtInterfaceStatus

Fault Code: F1000784

Message

[FSM:FAILED]: sam:dme:NetworkEthLanMgmtUpdateMgmtInterfaceStatus

Explanation

None set.

Recommended Action

Copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at <http://www.cisco.com/tac>. If you cannot resolve the issue, create a **show tech-support** file and contact Cisco Technical Support.

Fault Details

```
Severity: critical
Cause: fsm-failed
mibFaultCode: 1000784
mibFaultName: fsmFailNetworkEthLanMgmtUpdateMgmtInterfaceStatus
moClass: network:EthLanMgmt
Type: fsm
Callhome: none
Auto Cleared: true
Is Implemented: true
Affected MO: sys/switch- [id] /mgmt-port- [portId]
```




Troubleshooting Transient Faults

Transient faults can occur during initial set up and discovery or when a server or virtual machine starts up. You can typically ignore these transient faults, as FXOS clears them automatically.

This chapter includes the following sections:

- [Initial Setup and Discovery Faults, page 4-1](#)
- [Virtual Machine Startup Faults, page 4-5](#)

Initial Setup and Discovery Faults

[Table 4-1](#) describes the transient faults that you may see during the initial setup and discovery process. The FXOS clears these faults. If you see them during the initial setup or discovery process, you can safely ignore these faults.

Table 4-1 *Transient Faults that Occur during Initial Setup and Discovery Process*

Fault Code	Fault Text	Description
F16581	[FSM:STAGE:RETRY:]: user configuration to secondary (FSM-STAGE:sam:dme:AaaUserEpUpdateUserEp:SetUserPeer)	The FSM could not send the user configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16745	[FSM:STAGE:RETRY:]: QoS Classification Definition classification configuration on secondary (FSM-STAGE:sam:dme:QosclassDefinitionConfigGlobalQoS:SetPeer)	The FSM could not send the quality of the service configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16725	[FSM:STAGE:RETRY:]: VM profile configuration on external VM manager (FSM-STAGE:sam:dme:VnicProfileSetConfigVmm:SetLocal)	The FSM could not send the VM profile configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16580	[FSM:STAGE:RETRY:]: realm configuration to secondary (FSM-STAGE:sam:dme:AaaRealmUpdateRealm:SetRealmPeer)	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.

Table 4-1 *Transient Faults that Occur during Initial Setup and Discovery (continued)*Process

Fault Code	Fault Text	Description (continued)
F16724	[FSM:STAGE:RETRY:]: external VM manager configuration on local fabric (FSM-STAGE:sam:dme:ExtvmmEpConfig:SetLocal)	The FSM could not send the VM manager configuration to the primary fabric interconnect during the initial cluster configuration or the setup.
F16579	[FSM:STAGE:RETRY:]: external aaa server configuration to secondary (FSM-STAGE:sam:dme:AaaEpUpdateEp:SetEpPeer)	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: Uplink eth port configuration on B (FSM-STAGE:sam:dme:SwEthLanBorderDeploy:UpdateConnectivity)	The FSM could not send the eth-uplink configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: internal network configuration on B (FSM-STAGE:sam:dme:SwAccessDomainDeploy:UpdateConnectivity)	The FSM could not send the internal network configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: Uplink fc port configuration on B (FSM-STAGE:sam:dme:SwFcSanBorderDeploy:UpdateConnectivity)	The FSM could not send the fibre channel uplink configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16680	[FSM:STAGE:RETRY:]: Enable virtual interface on local fabric interconnect (FSM-STAGE:sam:dme:MgmtIfEnableVip:Local)	The FSM could not send the virtual interface configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16579	[FSM:STAGE:RETRY:]: keyring configuration on secondary (FSM-STAGE:sam:dme:PkiEpUpdateEp:SetKeyRingPeer)	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16539	[FSM:STAGE:RETRY:]: Fabric interconnect mode configuration to primary (FSM-STAGE:sam:dme:FabricLanCloudSwitchMode:SwConfigPeer)	The FSM could not send the end-host mode configuration on to the primary fabric interconnect during the initial cluster configuration or the setup.
F0429	Fabric Interconnect A, HA functionality not ready	The cluster configuration cannot be completed until the chassis discovery is completed.
F0400	Chassis 1 connectivity configuration: un-acknowledged	FXOS discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. FXOS reacknowledges the chassis to activate the other links.

Table 4-1 *Transient Faults that Occur during Initial Setup and Discovery (continued)Process*

Fault Code	Fault Text	Description (continued)
F0401	IOM 1/2 (B) current connectivity does not match discovery policy: unsupported-connectivity	FXOS discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. FXOS can clear this fault when the communication is established between the chassis and the fabric interconnect with that link.
F0440	Chassis discovery policy conflict: Link IOM 1/2/2 to fabric interconnect B:1/1 not configured	FXOS discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active. FXOS can clear this fault when the communication is established between the chassis and the fabric interconnect with that link.
F0332	AssociatePnuOSLocalDiskConfig fails with Service-Unavailable	During discovery, the server association failed due to an error when configuring the local disk controller. The associated remote invocation error code is 4106.
F0277	ether port 1 on fabric interconnect B oper state: link-up, reason: FEX not configured	FXOS discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active.
F0276	ether port 4 on fabric interconnect B oper state: link-down, reason: Link failure or not-connected	One or more of the links on the chassis flapped during the initial discovery. This fault is generated when the link is down during the flapping.
F0206	Adapter 1/2/1 is unreachable	During discovery, the adapter information cannot be accessed from the server. This fault clears as soon as the information is available.
F0283	VIF 1 / 2 B-42/44 down, reason: Bound Physical Interface Down	The internal VIF that the FXOS uses during discovery failed.

Table 4-1 *Transient Faults that Occur during Initial Setup and Discovery (continued)Process*

Fault Code	Fault Text	Description (continued)
F0367	No link between IOM port 1/1/2 and fabric interconnect A:1/2	The ethernet server ports flapped on the fabric interconnect during the initial discovery, because the discovery policy was configured for more than one link. FXOS clears this fault when the initial discovery succeeds with one link and the other links can be marked as active.
F0399	Current connectivity for chassis 1 does not match discovery policy: unsupported-connectivity	FXOS discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active.
F16520	[FSM:STAGE:RETRY:]: Identify pre-boot environment agent on server 1/2 (FSM-STAGE:sam:dme:ComputeBladeDiscover:PnuOSIdent)	The FSM failed to identify the pre-boot environment on the server during discovery.
F77960	[FSM:STAGE:REMOTE-ERROR]: Result: end-point-unavailable Code: unspecified Message: Waiting for BIOS POST Completion information from IBMC (sam:dme:ComputeBladeDiscover: BiosPostCompletion)	The FSM did not receive a response from the server during discovery and is waiting for the BIOS POST completion information.
F0320	Server 1/1 (service profile:) has an invalid FRU: mismatch-identity-unestablishable	FXOS could not identify the FRUs from the servers during initial discovery.
F77959	[FSM:STAGE:REMOTE-ERROR]: Result: unidentified-fail Code: ERR-0505-IBMC-fru-retrieval-error Message: Could not get Fru from 7f060101, dn=fabric/server/chassis-1/slot-1 (sam:dme:FabricComputeSlotEpIdentify:ExecuteLocal)	FXOS could not identify the FRUs from the servers during initial discovery.
F16406	[FSM:STAGE:RETRY:]: triggering chassis discovery via IOM 1/2 (right) (FSM-STAGE:sam:dme:EquipmentIOCardFeConn:DiscoverChassis)	In a cluster configuration, after the FXOS discovers the chassis through the I/O module connected to the primary fabric interconnect, it raises discovery through the I/O module connected to the secondary fabric interconnect.

Virtual Machine Startup Faults

When you power on a virtual machine on a server that has network adaptors connected to a distributed virtual switch through a port profile, the Events tab of the VMware vCenter may display the following event:

```
Virtual machine powered On with vNICs connected to dvPorts that have a port level configuration, which might be different from the dvPort group configuration.
```

If you see this event, you can safely ignore it.

